



OneCommand™ Manager Command Line Interface Version 6.3 User Manual

Copyright © 2007–2013 Emulex. All rights reserved worldwide. No part of this document may be reproduced by any means or translated to any electronic medium without the prior written consent of Emulex.

Information furnished by Emulex is believed to be accurate and reliable. However, no responsibility is assumed by Emulex for its use; or for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent, copyright or related rights of Emulex.

Emulex, the Emulex logo, AutoPilot Installer, AutoPilot Manager, BlockGuard, Connectivity Continuum, Convergenomics, Emulex Connect, Emulex Secure, EZPilot, FibreSpy, HBAnyware, InSpeed, LightPulse, MultiPulse, OneCommand, OneConnect, One Network. One Company., SBOD, SLI, and VEngine are trademarks of Emulex. All other brand or product names referenced herein are trademarks or registered trademarks of their respective companies or organizations.

Emulex provides this manual "as is" without any warranty of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability or fitness for a particular purpose. Emulex may make improvements and changes to the product described in this manual at any time and without any notice. Emulex assumes no responsibility for its use, nor for any infringements of patents or other rights of third parties that may result. Periodic changes are made to information contained herein; although these changes will be incorporated into new editions of this manual, Emulex disclaims any undertaking to give notice of such changes.

Emulex, 3333 Susan Street

Costa Mesa, CA 92626

OpenSolaris DHCHAP Notice. Contains portions of Covered Software subject to the Common Development and Distribution License (CDDL) Version 1.0. Such portions of Covered Software in Source Code form may be obtained from the website www.opensolaris.org, or by contacting online support from the website www.emulex.com. Derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm. Copyright (C) 1991-2, RSA Data Security, Inc. Created 1991. All rights reserved.

Table of Contents

1. Introduction	10
Overview	10
Compatibility	11
Abbreviations	11
OneCommand Manager Secure Management	13
Overview	13
OCM Secure Management Configuration Requirements	15
Secure Management Installation.....	15
Linux and Solaris	16
Windows	16
Using OneCommand Manager with Secure Management Enabled	16
2. Installing and Uninstalling the CLI	17
Linux.....	17
Citrix.....	17
Installing in Linux Without an Existing OneCommand CLI Kit	17
Installing in Linux With an Existing OneCommand CLI Kit	18
Updating (Preserving Existing Settings)	19
Performing a Clean Install (Removing Existing Settings).....	19
Uninstalling in Linux.....	19
Uninstalling Older HBAnyware Kits in Linux	20
Solaris	20
Installing in Solaris.....	20
Uninstalling in Solaris	21
VMware ESX/ESXi	22
Installing in a New VMware ESX Server	22
Installing in a VMware ESX Server with an Existing HBAnyware or OneCommand Manager CLI	22
Uninstalling in a VMware ESX Server	23
Uninstalling an Older HBAnyware or a OneCommand Manager Kit in a VMware ESX Server	23
Installing the CIM Provider for VMware ESXi Hosts	23
Windows.....	24
Installing in Windows.....	24
Attended Installation.....	24
Unattended Installation.....	24
Uninstalling in Windows.....	26

Uninstalling through the Control Panel.....	26
Uninstalling through the Command Line	26
Starting and Stopping Daemon Processes	27
Linux and Solaris	27
VMware ESX Server	27
3. Updating to the OneCommand Manager Application Enterprise Kit	28
Linux.....	28
Solaris	28
Windows.....	29
4. CLI Client Command Usage	30
Overview.....	30
HbaCmd Syntax Usage	30
Secure Management CLI Interface	32
Device Management Using the Secure Management Interface.....	32
Syntax Rules for the Secure Management Interface.....	32
CIM Interface	32
Device Management Using the CIM Interface	33
Syntax Rules for the CIM Interface	33
Syntax Options and Setting CIM Credentials	33
Example of Using the CIM Interface to Display Adapters	34
CLI Client Commands Supported in CIM Interface	35
CIM Provider 3.0	37
CIM Provider 3.1	37
CIM Provider 3.2	38
CIM Provider 3.4.4	38
CIM Provider 3.5	38
Commands Supported in Target-Mode Ports.....	38
Unsupported Commands per Operating System.....	39
Linux	39
RHEL, SLES, and Oracle	39
Citrix	40
Solaris.....	40
VMWare ESX.....	41
Windows.....	42
5. CLI Client Command Descriptions.....	43
Help	48
Adapter License Management Commands.....	51

InstallAdapterLicense	51
ShowAdapterLicenseFeatures	52
ShowAdapterLicenseID	52
Attributes Commands	53
HbaAttributes	53
PortAttributes	53
PortStatistics	53
ServerAttributes	54
SetPfcThrottle.....	54
SetPhyPortSpeed	55
SetPortEnabled.....	56
Authentication Commands	56
AuthConfigList.....	56
DeleteAuthConfig	57
GetAuthConfig.....	57
GetAuthStatus	57
InitiateAuth	58
SetAuthConfig	58
SetPassword	59
Boot Commands.....	60
EnableBootCode.....	60
GetBootParams.....	61
SetBootParam	61
CEE Commands.....	62
Channel Management Commands	62
CMGetParams.....	62
CMMode.....	63
CMSetBW	64
DCB Commands	65
GetDCBParams	65
GetPGInfo	66
SetCnaPGBW	66
SetDCBParam	67
SetDCBPriority.....	68
Diagnostic Commands	70
EchoTest	70
GetBeacon	70
GetXcvrData	71

LoadList	71
LoopBackTest	72
LoopMap	73
PciData	73
PostTest	74
SetBeacon	74
SetCableNVP	75
TDRTest	75
Wakeup	76
Driver Parameter Commands	76
DriverConfig	77
GetDriverParams	77
GetDriverParamsGlobal	77
SaveConfig	78
SetDriverParam	78
SetDriverParamDefaults	79
Dump Commands	79
DeleteDumpFiles	79
Dump	80
GetDumpDirectory	80
GetDumpFile	81
GetDumpFileNames	82
GetRetentionCount	82
SetDumpDirectory	82
SetRetentionCount	83
FCoE Commands	84
GetFCFInfo	84
GetFIPParams	84
SetFIPParam	85
iSCSI Commands	85
AddARPTableEntry	86
AddRouteTableEntry	86
AddTarget	87
AddTargetPortal	88
CleariSNSServer	89
DelARPTableEntry	90
DelRouteTableEntry	90
DiscoveriSNSServer	90
ExportiSCSI	91

GetInitiatorProperties.....	91
GetiSCSILuns.....	91
GetiSCSIPortStats.....	92
GetNetworkConfiguration.....	92
GetSessionInfo.....	92
ImportiSCSI.....	93
iSCSIPing.....	94
ListSessions.....	94
RemoveTarget.....	94
RemoveTargetPortal.....	95
SetBootTargetSession.....	95
SetInitiatorProperties.....	96
SetiSCSIBoot.....	97
SetNetworkConfiguration.....	97
SetTargetLoginProperties.....	98
SetTargetProperties.....	99
SetTPLLoginProperties.....	99
ShowARPTable.....	101
ShowiSNSServer.....	101
ShowRouteTable.....	101
ShowTarget.....	102
ShowTargetPortal.....	102
TargetLogin.....	102
TargetLogout.....	104
UpdateiSNSServer.....	104
LUN Masking Commands.....	105
GetLunList.....	105
GetLunUnMaskByHBA.....	105
GetLunUnMaskByTarget.....	106
RescanLuns.....	106
SetLunMask.....	106
Miscellaneous Commands.....	107
AddHost.....	107
CnaClearEventLog.....	107
CnaGetEventLog.....	108
Download.....	108
ExportSANInfo.....	109
GetCimCred.....	109
GetElxSecInfo.....	110

GetQoSInfo	110
GetVPD	110
ListHBAs	111
RemoveHost	111
Reset	112
SetCimCred	112
SRIOVEnable	113
TargetMapping	113
Version.....	114
Persistent Binding Commands	115
AllNodeInfo	115
BindingCapabilities	115
BindingSupport	116
PersistentBinding	116
RemoveAllPersistentBinding.....	116
RemovePersistentBinding.....	117
SetBindingSupport	117
SetPersistentBinding	118
Personality Change Commands	119
ChangePersonality	119
ShowPersonalities.....	120
UMC Commands.....	120
UmcEnable	121
UmcGetParams	121
UmcSetBw.....	122
UmcSetLPVID	123
VPort Commands	125
CreateVPort.....	125
DeleteVPort.....	125
ListVFunctions	126
ListVMs.....	126
ListVPorts	127
VPortTargets.....	127
WWN Management Commands.....	128
ChangeWWN	128
GetWWNCap	129
ReadWWN	129
RestoreWWN.....	129

Appendix A. OneCommand Manager Error Messages 131

1. Introduction

Overview

The OneCommand™ Manager Command Line Interface (CLI) utility is a comprehensive management utility for Emulex host bus adapters (HBAs) and universal converged network adapters (UCNAs). The CLI provides support for commonly used commands without requiring installation of the OneCommand Manager graphical user interface (GUI). The OneCommand Manager CLI console application name is HbaCmd. A single operation is performed by entering “hbacmd”, followed by a CLI client command and its possible parameters, at the command line.

Use the OneCommand Manager application to do any of the following:

- OneCommand Manager Secure Management enhances active management security by enabling administrators to define each user's privileges for managing or viewing both local and remote adapters.
- Provide increased flexibility in assigning protocols to individual ports on adapters
- View and configure Universal Multichannel (UMC) and view properties of other multi-channel types
- Discover local and remote Emulex and OEM branded Emulex adapters, as well as hosts, targets, virtual ports, virtual machines and logical unit numbers (LUNs) over FC or TCP/IP
- Manage local, FC remote and TCP/IP-accessed adapters
- Remote TCP/IP management of adapters on IPv6 hosts
- Discover, log in to, and log out from iSCSI targets
- Manage Emulex FC, iSCSI, FCoE and NIC-Only Universal Converged Network Adapters (UCNAs)
- Manage OneConnect OCe11100 series adapters (NIC and iSCSI only)
- Manage adapters on VMware ESX servers through the Common Information Model (CIM) interface
- Manage a UCNA's DCB (Data Center Bridging) settings
- Manage a UCNA's Fibre Channel over Ethernet (FCoE) Initialization Protocol (FIP)
- Manage adapter licenses
- Manage protocol personalities
- Group hosts for easier parameter configuration and firmware download
- Retrieve adapter dump files from remote hosts
- Change an adapter's World Wide Port Name (WWPN) and World Wide Node Name (WWNN)
- Reset FC ports
- Configure persistent binding on FC targets

- Set FC/FCoE adapter driver parameters simultaneously to multiple adapters using Batch Update
- Update firmware and FC boot code (x86 BootBIOS, OpenBoot, or EFIBoot) on a single adapter or multiple adapters using Batch Update
- Set global FC/FCoE driver parameters
- Enable or disable adapter boot (x86 BootBIOS, FCode, EFIBoot, or PXE Boot)
- Run diagnostic tests on adapter ports
- Locate adapter ports using beaconing
- Mask and unmask FC LUNs
- Create and delete FC virtual ports through N_Port_ID virtualization (NPIV)
- View FC virtual ports and virtual machine mapping information
- Configure FC boot from SAN
- Modify an IP port number of the remote management agent
- View vital product data (VPD) for the selected adapter port
- View transceiver information for the selected adapter port
- View iSCSI target session information
- View vNIC data for supported adapters
- Create and save reports about discovered SAN elements
- Configure COMSTAR (COMmon Multiprotocol SCSI TARget) for Solaris 11 enabling the Emulex FC driver for Solaris (EMLXS) to make a host appear as a target to the SAN. (COMSTAR ports are supported on Solaris 11 with LightPulse FC HBAs only.)

Compatibility

The OneCommand Manager application can be installed on multiple operating systems: Windows, Linux, Solaris, and VMware ESX and ESXi.

For VMware ESXi 4.1, ESXi 5.0, and ESXi 5.1 hosts, you can manage adapters using the OneCommand Manager on Windows, but you must install and use the appropriate Emulex CIM Provider on those VMware hosts.

Note: For VMware ESXi 5.0 and ESXi 5.1 hosts, when advanced adapter management capabilities are required (for example, iSCSI Management and port disable), use the OneCommand Manager for VMware vCenter software plug-in. For more details, see the *OneCommand Manager for VMware vCenter User Manual*.

For supported versions of operating systems, platforms, and adapters, see the Emulex website.

Abbreviations

ARP	address resolution protocol
ASIC	application-specific integrated circuit
BIOS	basic input-output system

CEE	Converged Enhanced Ethernet
CHAP	Challenge Handshake Authentication Protocol
CIM	Common Interface Model
CIMOM	Common Information Model Object Manager
CIN	Cisco, Intel, Nuova (data center bridging exchange)
CLI	command line interface
COS	console operating system
CSV	comma-separated values
DAC	direct-attach copper
D_ID	destination ID
DCB	data center bridging
DCBX	data center bridging exchange
DH	Diffie-Hellman
DHCHAP	Diffie-Hellman Challenge Handshake Authentication Protocol
ETO	Extended TimeOut
FAT	File Allocation Table
FC	Fibre Channel
FCoE	Fibre Channel over Ethernet
FIP	FCoE Initialization Protocol
GUI	graphical user interface
HBA	host bus adapter
iBFT	iSCSI Boot Firmware Table
ICMP	Internet Control Message Protocol
IP	Internet Protocol
iSCSI	internet Small Computer System Interface
iSNS	internet Storage Name Server
LACP	Link Aggregation Control Protocol
LLDP	link layer discovery protocol
LPFC	LightPulse Fibre Channel
LPVID	Logical Port VLAN ID
LUN	logical unit number
MAC	media access control
MSI	message signaled interrupts
MTU	maximum transmission unit
NFS	network file system
NIC	network interface card (or controller)
NPVID	N_Port_ID virtualization

NVP	normal velocity of propagation
PFC	priority-based flow control
PGID	priority group ID
PGBW	priority group bandwidth
PHY	physical layer
POST	power-on self-test
PXE	Pre-boot Execution Environment
RHEL	Red Hat Enterprise Linux
RM	remote management
RPM	resource package manager
SAN	storage area network
SCSI	Small Computer System Interface
SFCB	Small Footprint CIM Broker
SFP	small form factor pluggable
SLES	SUSE Linux Enterprise Server
SR-IOV	single root I/O virtualization
SSH	Secure Shell
TCP	Transmission Control Protocol
TDR	time-domain reflectometer
UCNA	universal converged network adapter
UEFI	Unified Extensible Firmware Interface
UFP	Universal Fabric Port
UMC	Universal Multichannel
VPD	vital product data
VPort	virtual port
WWN	world wide name
WWNN	world wide node name
WWPN	world wide port name
VM	virtual machine
XML	extensible markup language

OneCommand Manager Secure Management

Overview

OneCommand Manager Secure Management gives system administrators the ability to further enhance the active management security of their networks. Using Secure Management, administrators can define each user's privileges for managing both local

and remote adapters. When running in Secure Management mode, users must log on with their user name and password to run the OneCommand Manager application. When users are authenticated, they can only perform the functions allowed by the OneCommand Manager user group to which they belong. If your systems are running in an LDAP or Active Directory domain, the OneCommand Manager application will authenticate the user with those defined in that domain. For Linux and Solaris systems this is done using PAM.

Note: OneCommand Manager Secure Management is supported on Linux, Solaris, and Windows, but is not supported on VMware hosts.

Administrators set up user accounts such that a user belongs to one of the OneCommand Manager application user groups. The user groups define the management capabilities for the user. The following table defines the OneCommand Manager application user groups and each group's management capabilities.

Table 1-1 Secure Management User Privileges

Group Name	OneCommand Manager Capability
ocmadmin	Allows full active management of local and remote adapters.
ocmlocaladmin	Permits full active management of local adapters only
ocmuser	Permits read-only access of local and remote adapters
ocmlocaluser	Permits read-only access of local adapters.

On Linux or Solaris systems, the unix “getent group” utility can be run on the target host system’s command shell to verify the correct configuration of the groups. The groups, and users within the groups, will appear in the output of this command.

Note: Although a user may belong to the administrator group or be the root user, they will not have full privileges to run OneCommand Manager unless they are also a member of the ocmadmin group. Otherwise, when secure management is enabled, a root user or administrator can only manage local adapters (similar to the ocmlocaladmin user).

Remote management operations between two machines is allowed or denied depending on the OneCommand Manager secure management status of the machines, and the domains to which the machines belong. The following tables list the behavior (assuming appropriate user credentials are used).

Table 1-2 Active Commands: machines on same domain

	Remote Server (Secure)	Remote Server (Not Secure)
Client (Secure)	Allowed	Denied *
Client (Not Secure)	Denied	Allowed

Table 1-3 Active Commands: machines on different domain

	Remote Server (Secure)	Remote Server (Not Secure)
Client (Secure)	Denied**	Denied *
Client (Not Secure)	Denied	Allowed

Table 1-4 Passive Commands: machines on any domain

	Remote Server (Secure)	Remote Server (Not Secure)
Client (Secure)	Allowed	Allowed
Client (Not Secure)	Allowed	Allowed

* To inform you of an unsecured server that you may want to secure.

** Allowed if the username and password are the same on both domains.

OCM Secure Management Configuration Requirements

For systems to run in the OCM secure management environment, they need to be configured to provide the following two capabilities:

- Authentication - On Linux and Solaris, this is done through the PAM interface and must be configured as follows:
 - On Solaris, place the correct setting in the “auth” section of the `/etc/pam.d/other` file, or its earlier equivalent, `/etc/pam.conf`.

Note: For Solaris systems, you must use ‘`useradd -G groupname`’ for authentication to work. You cannot use a lowercase ‘`g`’.
 - On Linux, it is the `/etc/pam.d/passwd` file “auth” section, or the equivalent.
- User Group Membership - From the host machine, OCM Secure Management must be able to access the OCM group to which the user belongs. For Linux and Solaris systems, it uses the ‘`getgrnam`’ and ‘`getgrid`’ C-library API calls. The equivalent to the API calls can be obtained by typing “`getent group`” from the shell command line. If the four OCM group names are listed with their member users, the machine is ready to use OCM secure management.

Secure Management Installation

The enabling or disabling of the Secure Management feature is specified at OCM installation time. This can be done either interactively or by using dedicated install switches on Windows, Linux and Solaris. On Linux and Solaris, if the OCM groups described above are not configured on the machine at the time of the OCM installation, installation will fail when the secure management feature is selected.

Note: Only a user with Administrator/Root privileges is allowed to either enable or disable the secure management feature on a local host machine.

Linux and Solaris

Interactive Installation

Enterprise OCM installations done in interactive mode will ask if OCM Secure Management mode should be enabled. If the answer is yes, the other management mode questions will be skipped. If the answer is no to the OCM Secure Management mode question, then the management mode installation questions will follow.

Unattended Installation with Install Script Switch Option Support

Enterprise OCM installations done in unattended mode provides a switch option to enable OCM Secure Management. If the OCM Secure Management switch is not used with the installation, Secure Management will be disabled.

Windows

During OCM installations done in interactive mode, you will be presented with a management mode window where you can select Secure Management as the management mode.

Using OneCommand Manager with Secure Management Enabled

To run the HBACMD application when Secure Management is enabled, you must include your user name and password each time you type a command. For example:

Secure Management disabled:

```
hbacmd <command>
```

Secure Management enabled:

```
hbacmd <m=sec> <userid><password><command>
```

User names and passwords are used to authenticate the commands. Once the credentials are authenticated, the OCM will determine which one of the four user groups you belong to and will allow command usage as appropriate.

2. Installing and Uninstalling the CLI

This chapter details prerequisites and procedures for installing and uninstalling the OneCommand Manager CLI in the following operating systems: Linux, Solaris, VMware ESX/ESXi, and Windows. It also describes the Secure Management capability and the procedure for starting and stopping daemon processes.

Linux

Citrix

Citrix is based on CentOS Linux, however, for the OneCommand Manager CLI, Citrix is more comparable to VMware – a hypervisor-style server for managing virtual machines. The Citrix XenServer 6.1 operating system contains the OneCommand Manager CLI application, and no additional installation is required. Citrix XenServer 5.6 SP2 and Citrix XenServer 6.0 operating systems will require OCM CLI installation if it is needed.

Note: Updated versions of OneCommand Manager CLI for Citrix XenServer are available as part of the Device Update Driver kit for Citrix XenServer 5.6 SP2 and Citrix XenServer 6.0. For the latest kit, see the Emulex website.

Installing in Linux Without an Existing OneCommand CLI Kit

Note: Prior to installation, OneCommand groups must be configured on the LDAP network or the local host machine for Secure Management operation. See “OCM Secure Management Configuration Requirements” on page 15 for configuration instructions.

For new systems, before installing the OneCommand Manager CLI, install the specific Linux driver rpm file.

Note: On RHEL 5.5 and later and RHEL 6 and later, the OneCommand Core rpm file requires the “Libnl” library. This library is not installed by default, but can be obtained from the operating system distribution media.

- For i386 RHEL 5.5, RHEL 5.6, and RHEL 6, use the 32bit libnl library.
- For x86_64 RHEL 5.5, RHEL 5.6, and RHEL 6, use the 64bit libnl library.
- For ia64 RHEL 5.5, RHEL 5.6, and RHEL 6, use the 64bit libnl library.
- For PPC RHEL 5.5, RHEL 5.6, and RHEL 6, use the 32bit libnl library.

For existing systems, before installing the OneCommand Manager CLI, download the appropriate Linux driver from the Emulex website, and install it. If specified, also download and install the appropriate library file. For example,

- On OneConnect FCoE adapters:
 - For RHEL 5 and SLES 10 operating systems, use Linux driver version 8.2.0.33.3p, or later.

- For RHEL 6 (and later versions) and SLES 11 SP1 (and later versions) operating systems, use Linux driver version 8.3.5. Also, the RHEL 6 Enterprise kit requires the installation of the libstdc++-5.so library. This library is available through the compat-libstdc++-33-3.2.3-68.<arch>.rpm or later. The PPC64 and x86_64 builds require the 64-bit version installed, which is installed in /usr/lib64. The i386 build requires the 32-bit version installed which is installed in /usr/lib.
- On OneConnect NIC adapters (including iSCSI-NIC and FCoE-NIC adapters), use the NIC driver.

To install the OneCommand Manager CLI in Linux without an existing OneCommand CLI:

1. Copy the applications kit tar file to a directory on the installation machine.
2. Change to the directory where you copied the tar file.
3. Untar the file:

```
tar zxvf elxocmcore-<supported_os>-<app_ver>-<rel>.tgz
```

4. Change to the core kit directory created in step 3.

```
cd elxocmcore-<supported_os>-<app_ver>-<rel>
```
5. Run the install.sh script.

```
./install.sh
```

The core kit consists of two or three rpm files for each supported architecture and each supported version of Linux. For example:

- elxocmlibhbaapi-*.rpm (on 64-bit platforms that support 32-bit applications, there are two of these files)
 - elxocmcore-*.rpm
6. When prompted, choose whether or not to enable Secure Management for OneCommand:

```
Do you want to enable Secure Management feature for OneCommand?  
(s/u)  
Enter 's' to select secure management. (LDAP/NIS OCM group  
configuration required)  
Enter 'u' to run without secure management (default).  
Enter the letter 's' or 'u'.
```

Installing in Linux With an Existing OneCommand CLI Kit

Before installing the OneCommand Manager CLI, download the appropriate driver from the Emulex website and install the driver. For example:

- On OneConnect FCoE adapters:
 - For RHEL 5.5 and later and SLES10 SP3 and later operating systems, use Linux driver version 8.2.0.x.
 - For RHEL6 and later and SL11 SP1 and later operating systems, use Linux driver version 8.3.5.x.
- On OneConnect iSCSI adapters, use the iSCSI driver.

- On OneConnect NIC adapters (including iSCSI-NIC and FCoE-NIC adapters), use the Ethernet driver.

Note: The OneCommand Manager core kit cannot be installed if a previous version of the HBAnyware utility is installed.

You have two options when installing the OneCommand Manager CLI on a Linux system with an existing OneCommand CLI kit:

- Updating an existing installation – preserve existing settings
- Performing a clean install – overwrite existing settings

Updating (Preserving Existing Settings)

To update the OneCommand Manager CLI and preserve settings, you must install the current core kit as detailed in “Installing in Linux Without an Existing OneCommand CLI Kit” on page 17. The “.rpm” file handles the configuration file update. The install script executes an rpm update (`rpm -U *.rpm`) to update the installed version of the core kit to the current version.

Note: There is no update path from an HBAnyware 4.x or 3.x core kit to a OneCommand Manager 5.1 or later core kit. You must un-install previous versions of the HBAnyware utility before installing a OneCommand Manager core kit. For information on uninstalling older versions of HBAnyware, see “Uninstalling Older HBAnyware Kits in Linux” on page 20.

Performing a Clean Install (Removing Existing Settings)

1. Uninstall the existing OneCommand Manager CLI using the uninstall script included in the tar file or in `/usr/sbin/ocmanager/scripts` directory. Your configuration files are backed up by rpm with an “.rpmsave” extension.

Note: If an HBAnyware CLI or enterprise kit is installed, follow the procedure for “Uninstalling Older HBAnyware Kits in Linux” on page 20.

2. Install the specific rpm file for your driver for Linux version. For information on installing the rpm file, see “Installing in Linux Without an Existing OneCommand CLI Kit” on page 17.

Uninstalling in Linux

To uninstall the OneCommand Manager CLI in Linux:

1. Log in as “root”.
2. Do one of the following:
 - Run the `uninstall_ocmanager.sh` script located in `/usr/sbin/hbanyware/scripts`.
 - Run the `uninstall.sh` script located in the installation tar file.

Uninstalling Older HBAnyware Kits in Linux

Uninstalling an Older HBAnyware Core Kit

1. Run the following command to remove the core kit.

```
rpm -e elxlinuxcorekit
```

Uninstalling an Older HBAnyware Enterprise Kit

1. Do one of the following:
 - Run the uninstall script located in `/usr/sbin/hbanyware/scripts` to remove the enterprise kit.
 - Run the uninstall script located in the tar file to remove the enterprise kit.

If the HBAnyware Security Configurator is installed, you must uninstall it before uninstalling the HBAnyware configuration utility. You must use the uninstall script that shipped with the version of OneCommand Security Configurator you want to remove and proceed to step 2. If the Security Configurator is not installed, proceed to step 3.

2. If the HBAnyware Security Configurator is installed, follow these steps:

- a. Log on as "root".
- b. Change to the directory containing the tar file.
- c. Extract the tar file using the `tar -xvf` command.
- d. Change to the newly created directory.
- e. Run the uninstall script with the `ssc` parameter specified. Type

```
./uninstall ssc
```

3. Uninstall the HBAnyware utility and the Application Helper module:

- a. Log on as "root".
- b. Change to the directory containing the tar file.
- c. Extract the tar file using the `tar -xvf` command.
- d. Change to the newly created directory.
- e. Uninstall any previously installed versions. Type

```
./uninstall
```

Solaris

Installing in Solaris

Note: Prior to installation, OneCommand groups must be configured on the LDAP network or the local host machine for Secure Management operation. See "OCM Secure Management Configuration Requirements" on page 15 for configuration instructions.

Before installing the OneCommand Manager CLI, install the appropriate driver:

- The Solaris FC/FCoE inbox driver version emlxs 2.80.8.0 or later or the out of box driver version elxfc 2.85.xx.xx must be installed for FC/FCoE management.
- The NIC inbox driver version oce 4.4.173.9.3S or later or the out of box driver version elxnic 4.1.xx.xx must be installed for UCNA management.

Note: If Emulex OneConnect UCNAs are installed on the system, the NIC driver must be installed and reporting all NIC ports. Otherwise, the OneCommand Manager application cannot manage UCNAs.

To install the OneCommand Manager CLI in Solaris:

1. Copy the OneCommand Manager core kit to a temporary directory on the system.

2. Untar the core kit by typing

```
tar xvf elxocmcore-solaris-<kit version>.tar
```

3. Change to the newly created elxocmcore-solaris-<kit version> directory:

```
cd ./elxocmcore-solaris-<kit version>/
```

4. Run the install script and follow the instructions.

```
./install
```

If any of the following are already present on the system, the install script attempts to remove them first:

- HBAnyware utility
- OneCommand Manager core kit
- OneCommand Manager application enterprise kit
- Solaris driver utilities

5. When prompted, choose whether or not to enable Secure Management for OneCommand:

```
Do you want to enable Secure Management feature for OneCommand?  
(s/u)
```

```
Enter 's' to select secure management. (LDAP/NIS OCM group  
configuration required)
```

```
Enter 'u' to run without secure management (default).
```

```
Enter the letter 's' or 'u'.
```

Uninstalling in Solaris

To uninstall the OneCommand Manager CLI in Solaris:

1. Log in as “root”.
2. Do one of the following:
 - Run /opt/ELXocm/scripts/uninstall.
 - Run the uninstall script located in the installation tar file.
 - Enter the command pkgrm ELXocmcore.

VMware ESX/ESXi

For installing and uninstalling the OneCommand Manager in VMware ESX, only VMware ESX 4.1 is supported.

For VMware ESXi 4.1, VMware ESXi 5.0, and ESXi 5.1 hosts, you must install and use the appropriate Emulex CIM Provider. See “Installing the CIM Provider for VMware ESXi Hosts” on page 23.

Installing in a New VMware ESX Server

To install the OneCommand Manager CLI in a new VMware ESX system, install the specific rpm file for the driver for your VMware ESX version.

The prerequisites for installation include the following:

- To manage FCoE adapters, the LPFC driver version 8.2, or later, must be loaded.
- To manage NIC, FCoE, or iSCSI adapters, driver version 2.102.440.0, or later, must be loaded.
- To manage iSCSI adapters, the iSCSI driver must be loaded.

To install the OneCommand Manager CLI:

1. Log in to the VMware ESX server COS.
2. Copy the `elxocmcore-esxNN-<kit version>.<arch>.rpm` file to a directory on the install machine.
 - “NN” is the VMware ESX version. It is “41” for VMware ESX 4.1.
 - <kit version> represents the complete version.
 - <arch> is “x86_64” and is applicable to x64 or x86 architectures.
3. Change to the directory where you copied the rpm file.
4. Install the rpm file by typing

```
rpm -Uvh elxocmcore-esxNN-<kit version>.<arch>.rpm
```

 - See the VMware ESX version, <kit version>, and <arch> parameter descriptions in step 2.

The rpm contents are installed in `/usr/sbin/ocmanager`. The OneCommand Manager CLI is also located in this directory.

Installing in a VMware ESX Server with an Existing HBAnyware or OneCommand Manager CLI

To install the OneCommand Manager CLI:

1. Install the rpm file:

```
# rpm -Uvh elxocmcore-esxNN-<kit version>.<arch>.rpm
```

 - “NN” is the VMware ESX version. It is “41” for VMware ESX 4.1.
 - <kit version> represents the complete version.
 - <arch> is “x86_64” and is applicable to x64 or x86 architectures.

Uninstalling in a VMware ESX Server

To uninstall the OneCommand Manager CLI from a VMware ESX server:

1. Log in to the ESX server COS.
2. Type

```
rpm -e elxocmcore-esxNN-<kit version>
```

- “NN” is the VMware ESX version. It is “41” for a VMware ESX 4.1.

Uninstalling an Older HBAnyware or a OneCommand Manager Kit in a VMware ESX Server

To uninstall an older HBAnyware or OneCommand Manager from a VMware server:

1. Log in to the ESX server COS.
2. Type

```
rpm -qa | grep elx
```

Locate either of the following rpm files:

```
elxvmwarecorekit-<kit version>
```

```
elxocmcore-esxNN-<kit version>
```

- “NN” is the VMware ESX version. It is “41” for VMware ESX 4.1.

3. Type one of the following:

```
rpm -e elxvmwarecorekit-<kit version>
```

```
rpm -e elxocmcore-esxNN-<kit version>
```

- “NN” is the VMware ESX version. It is “41” for VMware ESX 4.1.

Installing the CIM Provider for VMware ESXi Hosts

For VMware ESXi 4.1, ESXi 5.0, and VMware ESXi 5.1 hosts, you can manage adapters using the OneCommand Manager on Windows, but you must install and use the appropriate Emulex CIM Provider.

VMware ESXi comes with an inbox Emulex CIM Provider. The inbox Emulex CIM Provider enables you to manage Emulex LightPulse adapters, but not Emulex UCNAs. To manage Emulex UCNAs, you must install the out-of-box Emulex CIM Provider.

The Emulex CIM Provider is available as an offline bundle in ESXi platforms. VMware recommends using the offline bundle to update software on VMware platforms. For more information about the ESX Patch Management activities, see the VMware website.

To install the Emulex CIM Provider in a VMware ESXi 4.1 hypervisor environment, use the esxupdate command line utility and perform the following steps:

1. Enable Secure Shell (SSH) on the VMware Visor host.
2. Transfer the Emulex CIM Provider zip file to the VMware hypervisor host.
3. Log into the VMware hypervisor host, and execute the following command all on one line:

```
esxupdate
--bundle=vmware-esx-provider-emulex-cim-provider-410.3.6.10.1-23578
6.zip --nosigcheck --maintenancemode update
```

To install the Emulex CIM Provider in a VMware ESXi 5.0 or ESXi 5.1 hypervisor environment, use the esxcli command line utility and perform the following steps:

1. Copy the CIM provider zip file to /var/log/vmware.
2. Log into the VMware hypervisor host, and execute the following command all on one line:

```
esxcli software vib update -d
vmware-esx-provider-emulex-cim-provider-50.3.6.11.1-01.zip
--no-sig-check --maintenance-mode
```

3. Reboot the system.

Windows

Installing in Windows

There are two ways to install the OneCommand Manager CLI in Windows:

- Attended installation - you are present during the installation. You will be prompted for more information for the installation to continue.
- Unattended installation - you do not need to be present during the installation. Installation will complete on its own. Installation progress may be displayed as an option.

Attended Installation

To install the OneCommand Manager CLI, run the installation.exe file for a core Windows driver kit that does not include the OneCommand Manager GUI, and follow the installer directions.

Use the following syntax for the installation executable file:

```
elxocmcore-windows-<arch>-<kit version>.exe
```

- <arch> is either "x64" or "x86".
- <kit version> represents the complete kit version.

For example, at the command prompt, type

```
elxocmcore-windows-x64-5.0.2.14-1.exe
```

Note: For Itanium 64 systems, install the x86 kit.

Unattended Installation

To install the OneCommand Manager CLI in Windows unattended, use the following procedure:

1. From the Emulex website, download the x64 or x86 OneCommand Manager Core Kit installation file to your system.

2. Use the following syntax for the installation executable file:
`elxocmcore-windows-<arch>-<kit version>.exe <option>`
3. Activate the kit with switch /q or /q2.
 - The /q switch displays progress reports.
 - The /q2 switch does not display progress reports.
4. You can enable Secure Management Mode by adding the sec=1 argument or disable it by sec=0. If the sec argument is not entered, Secure Management is disabled by default. See “OneCommand Manager Secure Management” on page 13 for more information.

To enable Secure Management, at the command prompt type

```
elxocm-windows-x64-5.01.00.10-4.exe sec=1 /q2
```

To disable Secure Management, at the command prompt type

```
elxocm-windows-x64-5.01.00.10-4.exe sec=0 /q2
```

5. You can select a Management Mode by adding the mmode argument and the ability to change that Management Mode by adding the change argument with selected values as in the example below.

Note: If you enabled Secure Management in Step 4, you cannot enter an mmode value. Doing so will result in a 'conflicting parameters' error.

For example, at the command prompt type

```
elxocm-windows-x64-5.01.00.10-4.exe mmode=3 achange=1 /q2
```

The following are the possible mmode values:

- 1 - Local Only Management Mode
- 2 - Local Plus Management Mode
- 3 - Full Management Mode
- 4 - Local Plus Management Mode and Read Only
- 5 - Full Management Mode and Read Only
- 6 - Management host

The following are the possible achange values:

- 0 - Do not allow Management Mode to change
- 1 - Allow Management Mode to change

You can also set the following optional parameters:

- MHost - This optional switch allows a non-management-host user to select a Management Host with which to register. If this switch is not specified, the default value of 0 will be used and the capability will be disabled. If the switch is specified, the value can be a host name or an IP address which will be validated by the installer. An error message appears if /mmode is set as Local Only or Management Host.
- excl - This optional switch allows the non-management-host user to select whether the OneCommand Manager application will process requests

exclusively from the Management Host specified by the MHost switch. This option is only accepted if accompanied by a valid MHost value; otherwise an error message appears. If this switch is not specified, the default value of 0 will be used. If the switch is specified, the valid values are:

- 0 – Remotely managed by other hosts.
 - 1 – Remotely managed by Management Host ONLY.
- Mtcp – This optional switch allows you to enable or disable remote management and to specify the TCP/IP port number over which management will occur. If this switch is not specified, the default TCP/IP port number 2333 will be used.
If the management host option is selected, you must either select the default port number or enter a valid TCP/IP port number on the command line. A value of 0 will not be accepted.
If one of the non-management host options is selected, you can enter the TCP/IP port number on the command line.

Uninstalling in Windows

There are two ways to uninstall the OneCommand Manager CLI in Windows:

- Through the control panel
- Through the command line

Uninstalling through the Control Panel

To uninstall the OneCommand Manager CLI in Windows through the control panel:

1. In Windows 2008 and Windows 2008 R2, select **Start > Control Panel > Programs > Uninstall a Program**.
2. If present, select **Emulex Common SAN Management [version]**, and click **Remove** or **Uninstall**. Click **Yes**.

The Emulex Common SAN Management components are removed from the system.

3. Select **Emulex OCMManager CLI[version]** and click **Remove** or **Uninstall**.

Uninstalling through the Command Line

To uninstall the OneCommand Manager CLI in Windows through the command line:

1. Change to the appropriate uninstall directory:
`cd <Install Location>\Emulex\Util\Uninstall`
2. Type
`uninstall_OCMManager_Core.bat`

Starting and Stopping Daemon Processes

Linux and Solaris

On Linux and Solaris machines, you can stop and start the OneCommand Manager daemon processes using the “stop_ocmanager” and “start_ocmanager” scripts respectively. These are found in the following OneCommand Manager installation directories:

- Linux – /usr/sbin/ocmanager
- Solaris – /opt/ELXocm

There are two basic daemon processes, included with OneCommand Manager CLI, that are affected by these scripts. They are:

- elxhbmgrd – Remote management daemon which services requests from OneCommand Manager clients running on remote host machines.
- mili2d – MILI daemon that routes major portions of the local OneCommand Manager client UCNA management requests.

The daemon processes start at system boot time.

VMware ESX Server

Starting Daemon Processes

To start the OneCommand Manager daemon in VMware ESX 4.1:

1. Log in as “root”.
2. Change to the OneCommand Manager directory:
`cd /usr/sbin/ocmanager/`
3. Start the OneCommand Manager daemon:
`./start_ocmanager`

Stopping Daemon Processes

To stop the OneCommand Manager daemon in VMware ESX 4.1:

1. Log in as “root”.
2. Go to the OneCommand Manager directory:
`cd /usr/sbin/ocmanager/`
3. Stop the OneCommand Manager daemon:
`./stop_ocmanager`

3. Updating to the OneCommand Manager Application Enterprise Kit

Note: The full-featured OneCommand Manager application enterprise kit is not supported on Citrix XenServer 5.6 SP2, Citrix XenServer 6.0, or VMware ESX server.

This chapter details procedures for updating the OneCommand Manager CLI to the OneCommand Manager Application Enterprise kit in Linux, Solaris, and Windows operating systems. An update can be performed only if the version of the OneCommand Manager application enterprise kit is the same or later than the OneCommand Manager CLI version.

Note: You cannot update a OneCommand Manager CLI with a previous version of the OneCommand Manager application enterprise kit.

When the OneCommand Vision Sensor software is installed on production servers with Emulex adapters, the Sensor software may load and use some of the software components included in the OneCommand Manager application or HBAnyware utility software stacks. It is essential that the OneCommand Vision Sensor software be stopped before performing any updates to the OneCommand Manager application or HBAnyware software stack components. For information on stopping the OneCommand Vision Sensor, see the latest *Emulex OneCommand Vision Installation and Configuration Manual*.

Linux

To update from the OneCommand Manager CLI to the full-featured OneCommand Manager application enterprise kit in Linux, run the `install.sh` script of the OneCommand Manager application enterprise kit.

The install script executes an rpm update (`rpm -U *.rpm`) to update the installed core kit to an enterprise kit.

Solaris

To update from the OneCommand Manager CLI to the full-featured OneCommand Manager application enterprise kit in Solaris:

1. Download the OneCommand Manager application enterprise kit to a temporary directory on your system.
2. Untar the OneCommand Manager application enterprise kit tar file:

```
tar xvf elxocm-solaris-<kit version>.tar
```

3. Change to the newly created `elxocm-<kit version>` directory:

```
cd ./elxocm-solaris-<kit version>/
```

4. Run the install script and follow the instructions:

```
./install
```

Windows

To update from the OneCommand Manager CLI to the full-featured OneCommand Manager application enterprise kit in Windows:

1. From the desktop, run the “elxocm-windows--<kit version>.exe” file that contains the full application kit.

Running this executable file removes the OneCommand Manager CLI and installs a full-featured version of the OneCommand Manager application that includes the CLI and the GUI.

4. CLI Client Command Usage

Overview

The CLI Client component of the OneCommand Manager application provides access to the capabilities of the Remote Management library or the CIM interface from a console command prompt to get the management information. The CLI Client is intended for use in scripted operations from within shell scripts or batch files. The CLI Client is a console application named HbaCmd. A single operation is performed by entering "hbacmd", followed by a CLI client command and its possible parameters, at the command line. For example:

```
hbacmd <command> [parameters]
```

Note: To run the HBACMD application when Secure Management is enabled, you must include your user name and password each time you type a command. For example:

- Secure Management disabled:

```
hbacmd <command>
```

- Secure Management enabled:

```
hbacmd <m=sec> <userid><password><command>
```

User names and passwords are used to authenticate the commands. Once the credentials are authenticated, the OCM will determine which one of the four user groups you belong to and will allow command usage as appropriate. See "OneCommand Manager Secure Management" on page 13 for more information.

When the specified operation is completed, the command prompt is displayed. For a majority of commands, the first parameter following the command is the WWPN or MAC address of the port that the command is to act upon.

CLI in Read-Only Mode May Cause Error Message

Note: The CLI does not allow the execution of certain commands when it is configured for read-only mode. The following error message is returned if such a command is attempted:

```
Error: Read-only management mode is currently set on this host.  
The requested command is not permitted in this mode.
```

HbaCmd Syntax Usage

The following syntax rules and usage are applicable for the HbaCmd application:

- Parameters denoted within angle brackets < > are required.
- Parameters denoted within square brackets [] are optional.

- For Linux, Solaris, and VMware ESX (which are case-sensitive), program names must be in lowercase letters, therefore, the command line must begin with “hbacmd” (rather than “HbaCmd”). Windows is not case-sensitive, so the program name is not required to be in all lowercase letters.
- An optional IP address or host name can be specified using the “h” option with the following syntax:

```
hbacmd [h=IP_Address[:port] | Hostname[:port]] <command> [parameters]
```

- If the “h” option is omitted, the command is run on the local host.
- If the “h” option is specified, the command is sent to the specified remote host (assuming it is specified correctly, the remote host is up, and the remote host is running the OneCommand Manager remote management agent.
- The “:port” option is optional. If omitted, the OneCommand Manager remote management protocol uses the default TCP port. If specified, it uses the user-specified TCP port.
- Examples:
 - Using the IP address:


```
hbacmd h=138.239.91.121 ListHBAs
```
 - Using the host name:


```
hbacmd h=cp-hp5670 ListHBAs
```
- The “h” option is available for all commands except for the AddHost (page 107), RemoveHost (page 111), and the Version (page 114) commands.

- For FC ports, the WWPN of the adapter must be specified. Where the WWPN is specified, each pair of numbers within the WWPN is separated by colons (:) or spaces (.). When using space separators, the entire WWPN must be enclosed in quotes (“ ”). For example, the following command displays the port attributes for the adapter with the specified WWPN:

```
hbacmd PortAttributes 10:00:00:00:c9:20:20:20
```

- For iSCSI and NIC ports, the MAC address must be specified. Where a MAC address is specified, each pair of numbers within the MAC address is separated by a dash (-). For example, the following command sets the target properties for the UCNA port with the specified MAC address with an extended timeout value of “1”:

```
hbacmd SetTargetProperties 00-11-22-33-44-55 iscsiTarget 1
```

- For NIC ports, only the permanent MAC address is supported for the port address parameter on an HbaCmd command line.

Normally, for a UCNA port, the port’s permanent MAC address and current MAC address parameters are equal. However, it is possible to set a user-specified (current) MAC Address that is different from the permanent MAC address. Also, for some implementations, it is possible to have multiple UCNA ports with the same current MAC addresses, but with unique permanent MAC addresses. Therefore, to ensure that the OneCommand Manager can access the correct port, only the permanent MAC address is supported. Note that both the permanent MAC address and the current MAC address are displayed by using the ListHBAs command. See “ListHBAs” on page 111.

Secure Management CLI Interface

Supported By

Linux, Solaris, and Windows

Note: Users with “root” or “Administrator” privileges on the local machine will retain full OCM CLI configuration capability without the use of credentials (local machine only).

Device Management Using the Secure Management Interface

To run the HBACMD CLI client application when the Secure Management feature is enabled, each invocation must include a user name and password. The user name and password options are added to the existing hbacmd command in a similar fashion as is currently done for CIM commands, except the <m=CIM> option is replaced by the <m=SEC> option (to distinguish it from a CIM command). For example:

Without Secure Management (or if running as ‘root’ or ‘Administrator’):

```
hbacmd <cmd>
```

With Secure Management (as non-Root or non-Administrator User):

```
hbacmd <m=SEC> <u=userid> <p=password> <cmd>
```

Syntax Rules for the Secure Management Interface

For the secure management interface, all of the syntax rules in “HbaCmd Syntax Usage” on page 30 apply. Additionally, the “m=sec” parameter is required in the command for all users without ‘root’ or ‘Administrator’ privileges.

Usage Example

In Windows, to display a list of adapters managed for a specified host using the secure management interface, run the following command:

```
hbacmd <h=192.168.1.122> m=sec u=jsmith p=<joepassword> download  
00-12-34-56-78-9A oc11-4.6.96.2.ufi
```

CIM Interface

Notes:

- In Linux and Solaris, you cannot use hbacmd as a CIM client.
- The OneCommand Manager CLI running on the VMware ESX 4.1 COS does not support the management of adapters using the CIM interface.

Device Management Using the CIM Interface

VMware on the hypervisor-based ESXi platforms use the CIM as the only standard management mechanism for device management.

For VMware ESXi 4.1, VMware ESXi 5.0, and VMware ESXi 5.1 hosts, you can manage adapters using the OneCommand Manager on Windows, but you must install and use the appropriate Emulex CIM Provider. For installation, see “Installing the CIM Provider for VMware ESXi Hosts” on page 23.

Note: For VMware ESXi 5.0 and 5.1 hosts, when advanced adapter management capabilities are required (for example, iSCSI Management and port disable), use the OneCommand Manager for VMware vCenter software plug-in. For more details, see the *OneCommand Manager for VMware vCenter User Manual*.

Syntax Rules for the CIM Interface

For the CIM interface, all the syntax rules in section “HbaCmd Syntax Usage” on page 30 apply, except that the “h” option is required. Additionally, the “m=cim” parameter is required in the command line for getting the data from the ESXi host. For example:

```
hbacmd <h=IP_Address[:port]> m=cim u=root p=<password> n=<namespace>  
InstallAdapterLicense 00-12-34-56-78-9A K:\lf1324.lic
```

Note: If you specify the parameter “m=cim”, the CLI uses the CIM interface to talk to the CIM server running on ESXi to get the management information. If you do not specify the parameter “m=cim”, the CLI uses the RM interface to talk to the RM server to get the management information.

Syntax Options and Setting CIM Credentials

For issuing CIM-based commands, two main syntax options are available.

Option A

```
hbacmd <h=IP_Address[:port]> m=cim [u=userid] [p=password]  
[n=root/emulex] <command> <WWPN>
```

Option B

```
hbacmd <h=IP_Address[:port]> <m=cim> <command>
```

Before using the option B syntax, you must set the CIM credentials by doing one of the following:

- Set the default CIM credentials using the SetCimCred command (see page 112). This command sets only the CIM credentials. Once you have set them, subsequent HbaCmd commands do not require you specify the CIM credentials on the command line. For example:

```
hbacmd SetCimCred <username> <password> <namespace>  
<portnum>
```

- Add the host IP address with CIM credentials using the AddHost command. For example:

```
hbacmd <m=cim> [u=userid] [p=password] [n=namespace]  
AddHost <IP_Address>
```

Default CIM Credentials

If you specify the command with the CIM method “m=cim” without specifying the CIM credentials (userid, password, or namespace), the default value for the missing CIM credential is obtained in the following order:

1. The information entered using the addhost command is looked up.
2. If no values exist, the information entered using the setcimcred command is used.
3. If no values exist, the following defaults are used:

```
username=root  
password=root  
namespace=root/emulex  
portnum=5988
```

Example of Using the CIM Interface to Display Adapters

In Windows, to display a list of adapters managed for a specified host using the CIM interface, run the following command:

```
C:\Program Files\Emulex\Util\OCManager>hbacmd h=10.192.113.128  
m=cim u=root p=root n=root/emulex listhbas
```

The output displayed is similar to the following example:

```
Manageable HBA List  
  
Port WWN: 10:00:00:00:c9:6b:62:2b  
Node WWN: 20:00:00:00:c9:6b:62:2b  
Fabric Name: 00:00:00:00:00:00:00:00  
Flags: 00000000  
Host Name: eng.ma.emulex.com  
Mfg: Emulex Corporation  
Serial No.: BG73539764  
Port Number: n/a  
  
Mode: Initiator  
Discovery: cim  
  
Port WWN: 10:00:00:00:c9:6b:62:59  
Node WWN: 20:00:00:00:c9:6b:62:59  
Fabric Name: 00:00:00:00:00:00:00:00  
Flags: 00000000  
Host Name: eng.ma.emulex.com  
Mfg: Emulex Corporation
```

```
Serial No.: BG73539764
Port Number: n/a
Mode: Initiator
Discovery: cim
```

```
C:\Program Files\Emulex\Util\OCManager>hbacmd h=10.192.113.128
m=cim u=root p=root n=root/emulex portattributes
10:00:00:00:c9:6b:62:2b
```

```
Port Attributes for 10:00:00:00:c9:6b:62:2b
```

```
Node WWN: 20 00 00 00 c9 6b 62 2b
Port WWN: 10 00 00 00 c9 6b 62 2b
Port Symname:
Port FCID: 0000
Port Type: Fabric
Port State: Unknown
Port Service Type: 12
vNIC Name:
vNIC Outer VLAN ID:
vNIC Min. Bandwidth:
vNIC Max. Bandwidth:
Port Supported FC4: 00 00 01 20 00 00 00 01
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
Port Active FC4: 00 00 01 00 00 00 00 01
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
Max Frame Size: 2048
OS Device Name:
Num Discovered Ports: 0
Fabric Name: 00 00 00 00 00 00 00 00
```

For a list of HbaCmd commands supported through the CIM interface, see “CLI Client Commands Supported in CIM Interface” on page 35.

CLI Client Commands Supported in CIM Interface

Following is a list of HbaCmd commands supported through the CIM interface.

- AddHost
- AllNodeInfo
- CEEDownload

- ChangePersonality
- ChangeWWN
- CMGetParams
- CMMode
- CMSetBW
- DeleteDumpFiles
- Download
- Dump
- EnableBootCode
- GetBeacon
- GetDCBParams
- GetDriverParams
- GetDriverParamsGlobal
- GetDumpDirectory
- GetDumpFile
- GetDumpFileNames
- GetFCFInfo
- GetFIPParams
- GetLunList
- GetPGInfo
- GetQosInfo
- GetRetentionCount
- GetVPD
- GetWWNCap
- GetXcvrData
- HbaAttributes
- InstallAdapterLicense
- ListHBAs
- LoadList
- LoopBackTest
- PciData
- PortAttributes
- PortStatistics
- ReadWWN
- RemoveHost
- Reset
- RestoreWWN
- ServerAttributes
- SetBeacon

- SetCnaPGBW
- SetDCBParam
- SetDCBPriority
- SetDriverParam
- SetDriverParamDefaults
- SetDumpDirectory
- SetFIPParam
- SetPFCthrottle
- SetPhyPortSpeed
- SetRetentionCount
- ShowAdapterLicenseFeatures
- ShowLicenseAdapterID
- ShowPersonalities
- UmcEnable
- UmcGetParams
- UmcSetBw
- UmcSet LPVD
- TargetMapping
- Version

CIM Provider 3.0

CIM Provider 3.0 supports the following commands:

- Download
- ChangeWWN
- GetWWNCap
- GetXcvrData
- LoadList
- Loopbacktest
- GetBeacon
- SetBeacon
- ReadWWN
- Reset
- RestoreWWN

CIM Provider 3.1

CIM Provider 3.1 supports the following commands:

- All the commands listed in the previous section for “CIM Provider 3.0” on page 37.
- Dump

- GetDCBParams
- GetDumpDirectory
- GetDumpFile
- GetDumpFileNames
- GetFCFInfo
- GetFipParams
- GetRetentionCount
- GetPGInfo
- SetDCBParam
- SetCnaPgBw
- SetDCBPriority
- SetDumpDirectory
- SetFIPParam
- SetRetentionCount

CIM Provider 3.2

CIM Provider 3.2 supports the following commands:

- All the commands listed in the previous section for “CIM Provider 3.1” on page 37.
- ChangePersonality
- InstallAdapterLicense
- ShowAdapterLicenseFeatures
- ShowLicenseAdapterID
- ShowPersonalities

CIM Provider 3.4.4

CIM Provider 3.4.4 supports the following commands:

- All the commands listed in the previous section for “CIM Provider 3.2” on page 38.
- SetCableNVP

CIM Provider 3.5

CIM Provider 3.5 supports the following commands:

- All the commands listed in the previous section for “CIM Provider 3.4.4” on page 38.
- SetPhyPortSpeed

Commands Supported in Target-Mode Ports

The following HbaCmd commands are supported for managing target-mode ports:

- CreateVPort
- DeleteDumpFiles
- DeleteVPort
- Download
- DriverConfig
- ExportSanInfo
- GetDriverParams
- GetDriverParamsGlobal
- GetDumpDirectory
- GetDumpFile
- GetRetentionCount
- GetVPD
- GetXcvrData
- HbaAttributes
- ListHbas
- ListVPorts
- PortAttributes
- PortStatistics
- Reset
- SaveConfig
- ServerAttributes
- SetDriverParam
- SetDriverParamDefaults
- SetPortEnabled
- SetRetentionCount

Unsupported Commands per Operating System

For a list of all the supported commands, see Table 5-1, CLI Client Command Reference, on page 43.

Linux

RHEL, SLES, and Oracle

RHEL, SLES, and Oracle do not support the following CLI commands:

- BindingCapabilities
- BindingSupport
- GetCimCred
- GetLunUnMaskByHBA
- GetLunUnMaskByTarget

- ListVMs
- PersistentBinding
- RemoveAllPersistentBinding
- RemovePersistentBinding
- SetBindingSupport
- SetCimCred
- SetDumpDirectory
- SetLunMask
- SetPersistentBinding

Citrix

Citrix (acting as a hypervisor-style server for OneCommand Manager CLI) does not support the following CLI commands:

- AuthConfigList
- BindingCapabilities
- BindingSupport
- CreateVPort
- DeleteVPort
- GetAuthConfig
- GetAuthStatus
- GetCimCred
- GetElxSecInfo
- GetLunList
- GetLunUnMaskByHBA
- GetLunUnMaskByTarget
- InitiateAuth
- PersistentBinding
- RemoveAllPersistentBinding
- RemovePersistentBinding
- RescanLuns
- SetAuthConfig
- SetBindingSupport
- SetCimCred
- SetPersistentBinding
- SetLunMask
- SetPassword

Solaris

Solaris does not support the following CLI commands:

- CnaClearEventLog
- CnaGetEventLog
- DriverConfig
- GetCimCred
- GetElxSecInfo
- ListVMs
- SetCimCred
- SetDumpDirectory

VMWare ESX

VMWare ESX does not support the following CLI commands:

- AuthConfigList
- BindingCapabilities
- BindingSupport
- CreateVPort
- DeleteAuthConfig
- DeleteVPort
- GetAuthConfig
- GetAuthStatus
- GetCimCred
- GetElxSecInfo
- GetLunList
- GetLunUnMaskByHBA
- GetLunUnMaskByTarget
- GetProtocolInfo
- ImportSCSI
- InitiateAuth
- PersistentBinding
- RemoveAllPersistentBinding
- RemovePersistentBinding
- RescanLuns
- SetAuthConfig
- SetBindingSupport
- SetCimCred
- SetLunMask
- SetPersistentBinding
- SetPassword
- SetPortProtocol

Windows

Windows does not support the following CLI commands:

- SetDumpDirectory
- ListVMs

5. CLI Client Command Descriptions

A check mark (✓) designates a supported command for a particular operating system, CIM interface, and some CIM provider versions.

Table 5-1 CLI Client Command Reference

Command	Linux	Solaris	VMWare ESX	Windows	CIM	CIM Provider					Page
						3.0	3.1	3.2	3.4.4	3.5	
AddARPTableEntry	✓	✓	✓	✓							86
AddHost	✓	✓	✓	✓	✓						107
AddRouteTableEntry	✓	✓	✓	✓							86
AddTarget	✓	✓	✓	✓							87
AddTargetPortal	✓	✓	✓	✓							88
AllNodeInfo	✓	✓	✓	✓	✓						115
AuthConfigList	✓	✓		✓							56
BindingCapabilities		✓		✓							115
BindingSupport		✓		✓							116
ChangePersonality	✓	✓	✓	✓	✓			✓	✓	✓	119
ChangeWWN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	128
CleariSNSServer	✓	✓	✓	✓							89
CMGetParams	✓	✓	✓	✓	✓						62
CMMode	✓	✓	✓	✓	✓						63
CMSetBW	✓	✓	✓	✓	✓						64
CnaClearEventLog	✓		✓	✓							107
CnaGetEventLog	✓		✓	✓							108
CreateVPort	✓	✓		✓							125
DelARPTableEntry	✓	✓	✓	✓							90
DeleteAuthConfig	✓	✓		✓							57
DelRouteTableEntry	✓	✓	✓	✓							90
DeleteDumpFiles	✓	✓	✓	✓	✓						79
DeleteVPort	✓	✓		✓							125
DiscoveriSNSServer	✓	✓	✓	✓							90
Download	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	108
DriverConfig	✓		✓	✓							77
Dump	✓	✓	✓	✓	✓		✓	✓	✓	✓	80

Table 5-1 CLI Client Command Reference (Continued)

Command	Linux	Solaris	VMWare ESX	Windows	CIM	CIM Provider					Page
						3.0	3.1	3.2	3.4.4	3.5	
EchoTest	✓	✓	✓	✓							70
EnableBootCode	✓	✓	✓	✓	✓						60
ExportSANInfo	✓	✓	✓	✓							109
ExportiSCSI	✓	✓	✓	✓							91
GetBeacon	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	70
GetAuthConfig	✓	✓		✓							57
GetAuthStatus	✓	✓		✓							57
GetBootParams	✓	✓	✓	✓							61
GetCimCred				✓							109
GetDCBParams	✓	✓	✓	✓	✓		✓	✓	✓	✓	65
GetDriverParams	✓	✓	✓	✓	✓						77
GetDriverParamsGlobal	✓	✓	✓	✓	✓						77
GetDumpDirectory	✓	✓	✓	✓	✓		✓	✓	✓	✓	80
GetDumpFile	✓	✓	✓	✓	✓		✓	✓	✓	✓	81
GetDumpFileNames	✓	✓	✓	✓	✓		✓	✓	✓	✓	82
GetElxSecInfo	✓			✓							110
GetFCFInfo	✓	✓	✓	✓	✓		✓	✓	✓	✓	84
GetFIPParams	✓	✓	✓	✓	✓		✓	✓	✓	✓	84
GetInitiatorProperties	✓	✓	✓	✓							91
GetiSCSILuns	✓	✓	✓	✓							91
GetiSCSIPortStats	✓	✓	✓	✓							92
GetLunList	✓	✓		✓	✓						105
GetLunUnMaskByHBA		✓		✓							105
GetLunUnMaskByTarget		✓		✓							106
GetNetwork Configuration	✓	✓	✓	✓							92
GetPGInfo	✓	✓	✓	✓	✓		✓	✓	✓	✓	66
GetQosInfo	✓	✓	✓	✓	✓						110
GetRetentionCount	✓	✓	✓	✓	✓		✓	✓	✓	✓	82
GetSessionInfo	✓	✓	✓	✓							92
GetVPD	✓	✓	✓	✓	✓						110

Table 5-1 CLI Client Command Reference (Continued)

Command	Linux	Solaris	VMWare ESX	Windows	CIM	CIM Provider					Page
						3.0	3.1	3.2	3.4.4	3.5	
GetWWNCap	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	129
GetXcvrData	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	71
HbaAttributes	✓	✓	✓	✓	✓						53
Help	✓	✓	✓	✓							48
ImportiSCSI	✓	✓		✓							93
InitiateAuth	✓	✓		✓							58
InstallAdapterLicense	✓	✓	✓	✓	✓			✓	✓	✓	51
iSCSIPing	✓	✓	✓	✓							94
ListHBAs	✓	✓	✓	✓	✓						111
ListSessions	✓	✓	✓	✓							94
ListVFunctions	✓	✓	✓	✓							126
ListVMs	✓		✓								126
ListVPorts	✓	✓	✓	✓							127
VPortTargets	✓	✓	✓	✓							127
LoadList	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	71
LoopBackTest	✓	✓	✓	✓							72
LoopMap	✓	✓	✓	✓							73
PciData	✓	✓	✓	✓	✓						73
PersistentBinding		✓		✓							116
PortAttributes	✓	✓	✓	✓	✓						53
PortStatistics	✓	✓	✓	✓	✓						53
PostTest	✓	✓	✓	✓							74
ReadWWN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	129
RemoveAllPersistent Binding		✓		✓							116
RemovePersistent Binding		✓		✓							117
RemoveHost	✓	✓	✓	✓	✓						111
RemoveTarget	✓	✓	✓	✓							94
RemoveTargetPortal	✓	✓	✓	✓							95
RescanLuns	✓	✓		✓							106
Reset	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	112

Table 5-1 CLI Client Command Reference (Continued)

Command	Linux	Solaris	VMWare ESX	Windows	CIM	CIM Provider					Page
						3.0	3.1	3.2	3.4.4	3.5	
RestoreWWN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	129
SaveConfig	✓	✓	✓	✓							78
ServerAttributes	✓	✓	✓	✓	✓						54
SetAuthConfig	✓	✓		✓							58
SetBeacon	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	74
SetBindingSupport		✓		✓							117
SetBootParam	✓	✓	✓	✓							61
SetBootTargetSession	✓	✓	✓	✓							95
SetCableNVP	✓	✓	✓	✓					✓	✓	75
SetCnaPGBW	✓	✓	✓	✓	✓		✓	✓	✓	✓	66
SetCimCred				✓							112
SetDCBParam	✓	✓	✓	✓	✓		✓	✓	✓	✓	67
SetDCBPriority	✓	✓	✓	✓	✓		✓	✓	✓	✓	68
SetDriverParam	✓	✓	✓	✓	✓						78
SetDriverParamDefaults	✓	✓	✓	✓	✓						79
SetDumpDirectory			✓		✓		✓	✓	✓	✓	82
SetFIPParam	✓	✓	✓	✓	✓		✓	✓	✓	✓	85
SetInitiatorProperties	✓	✓	✓	✓							96
SetiSCSIBoot	✓	✓	✓	✓							97
SetLunMask		✓		✓							106
SetNetwork Configuration	✓	✓	✓	✓							97
SetPassword	✓	✓		✓							59
SetPersistentBinding		✓		✓							118
SetPfcThrottle	✓	✓	✓	✓	✓						54
SetPhyPortSpeed	✓	✓	✓	✓	✓					✓	55
SetPortEnabled	✓	✓	✓	✓	✓						56
SetRetentionCount	✓	✓	✓	✓	✓		✓	✓	✓	✓	83
SetTargetLogin Properties	✓	✓	✓	✓							98
SetTargetProperties	✓	✓	✓	✓							99
SetTPLLoginProperties	✓	✓	✓	✓							99

Table 5-1 CLI Client Command Reference (Continued)

Command	Linux	Solaris	VMWare ESX	Windows	CIM	CIM Provider					Page
						3.0	3.1	3.2	3.4.4	3.5	
ShowAdapterLicense-Features	✓	✓	✓	✓	✓			✓	✓	✓	52
ShowARPTable	✓	✓	✓	✓							101
ShowiSNSServer	✓	✓	✓	✓							101
ShowLicenseAdapterID	✓	✓	✓	✓	✓			✓	✓	✓	52
ShowPersonalities	✓	✓	✓	✓	✓			✓	✓	✓	120
ShowRouteTable	✓	✓	✓	✓							101
ShowTarget	✓	✓	✓	✓							102
ShowTargetPortal	✓	✓	✓	✓							102
SRIOVEnable	✓	✓	✓	✓							113
TargetLogin	✓	✓	✓	✓							102
TargetLogout	✓	✓	✓	✓							104
TargetMapping	✓	✓	✓	✓	✓						113
TDRTest	✓	✓	✓	✓							75
UmcEnable	✓	✓	✓	✓	✓						121
UmcGetParams	✓	✓	✓	✓	✓						121
UmcSetBw	✓	✓	✓	✓	✓						122
UmcSetLPVID	✓	✓	✓	✓	✓						123
UpdateiSNSServer	✓	✓	✓	✓							104
Version	✓	✓	✓	✓	✓						114
VPortTargets	✓	✓	✓	✓							127
Wakeup	✓	✓	✓	✓							76

Help

The Help command displays command information for the HbaCmd application. Without using its optional parameters, the Help command lists all the commands in their respective groups. Using the optional parameter, GroupName, it lists the commands in a group. Using the optional parameter, CmdName, it shows the details for a specific command.

Supported By

Linux, Solaris, VMware ESX, and Windows

Syntax

```
Help [GroupName] [CmdName]
```

Parameters

GroupName This optional parameter lists the commands in a particular group.

CmdName This optional parameter shows the details for a particular CLI command.

Example 1

This help command example lists all the commands in their respective groups:

```
hbacmd help
```

The example output:

```
Usage: hbacmd version
```

```
or hbacmd { h=IPv4 Address{:port} | Hostname{:port} } <Command>
```

```
or hbacmd { h={[]IPv6 Address[:port]} <Command>
```

Note: When specifying IPv6 address with port option, it must be enclosed in []. Example: [fe80::6445:80e9:9878:a527]:9876

Use the following syntax for issuing CIM based commands (IPv4 only):

```
A> hbacmd <h=IPv4 {:port}> <m=CIM> [u=userid] [p=password] [n=namespace] <cmd>
```

```
B> hbacmd <h=IPv4 {:port}> <m=CIM> <cmd>
```

Before specifying syntax B, the user should do one of the following:

1. Add the host IP with CIM credentials using the AddHost command.
e.g. hbacmd <m=CIM> [u=userid] [p=password] [n=namespace] AddHost <ip>
2. Set the default CIM credentials using the SetCimCred command.
e.g. hbacmd SetCimCred <u=userid> <p=password> <n=namespace> <o=port>

Command Summary

Help Commands

```
Help <Group>
```

```
Group: {AdapterLicense, Attributes, Authentication, Boot, CEE,  
Channel Management, DCB, Diagnostics, DriverParams, Dump,  
eAdapterManagement, eLunManagement, eLunMigration, FCoE, iSCSI,  
KeyManagerClientManagement, LUNMasking, Miscellaneous,  
PersistentBinding, Personality, PolicyManagement,
```


ServerKeyManagement, ServerLicenseManagement, UMC, VPort, WWN

Adapter License Management Commands

ShowLicenseAdapterID, InstallAdapterLicense, ShowAdapterLicenseFeatures

Attributes Commands

HbaAttributes, PortAttributes, PortStatistics, ServerAttributes,
SetPhyPortSpeed SetPortEnabled

Authentication Commands

AuthConfigList, DeleteAuthConfig, GetAuthConfig, GetAuthStatus,
InitiateAuth, SetAuthConfig, SetPassword

Boot Commands

EnableBootCode, GetBootParams, SetBootParam

CEE Commands (LP21000 series only)

CEEDownload, GetCEEPParams, SetCEEPParam

Channel Management Commands

CMGetParams, CMMode, CMSetBW

DCB Commands

GetDCBParams, SetDCBParam, GetPGInfo, SetDCBPriority, SetCnaPGBW

Diagnostic Commands

EchoTest, GetBeacon, GetXcvrData, LoadList, LoopBackTest, LoopMap,
PciData, PostTest, SetBeacon, SetCableNVP, TDRTest, Wakeup

Driver Parameter Commands

DriverConfig, GetDriverParams, GetDriverParamsGlobal, SaveConfig,
SetDriverParam, SetDriverParamDefaults

Dump Commands

DeleteDumpFiles, Dump, GetDumpDirectory, SetDumpDirectory,
GetRetentionCount, SetRetentionCount, GetDumpFileNames, GetDumpFile

FCoE Commands

GetFIPParams, SetFIPParam, GetFCFInfo

iSCSI Commands

AddARPTableEntry, AddRouteTableEntry, AddTarget, AddTargetPortal,
CleariSNSServer, DelARPTableEntry, DelRouteTableEntry, DiscoveriSNSServer,
ExportiSCSI, GetInitiatorProperties, GetiSCSILuns, GetiSCSIPortStats,
GetNetworkConfiguration, GetSessionInfo, ImportiSCSI, iSCSIPing,
ListSessions, RemoveTarget, RemoveTargetPortal, SetBootTargetSession,
SetInitiatorProperties, SetiSCSIBoot, SetNetworkConfiguration,
SetTargetLoginProperties, SetTargetProperties, SetTPLoginProperties,

ShowARPTable, ShowRouteTable, ShowTarget, ShowTargetPortal, TargetLogin, ShowiSNSServer, TargetLogout, UpdateiSNSServer

LUN Masking Commands

GetLunList, GetLunUnmaskByHba, GetLunUnmaskByTarget, RescanLuns, SetLunMask

Miscellaneous Commands

AddHost, CnaGetEventLog, CnaClearEventLog, Download, SRIOVEnable, ExportSANInfo, GetCimCred, GetElxSecInfo, GetQoSInfo, GetVPD, ListHBAs, ListVFunctions, RemoveHost, Reset, SetCimCred, SetPfcThrottle, TargetMapping

Persistent Binding Commands

AllNodeInfo, BindingCapabilities, BindingSupport, PersistentBinding, RemoveAllPersistentBinding, RemovePersistentBinding, SetBindingSupport, SetPersistentBinding

Personality Management Commands

ShowPersonalities, ChangePersonality

Universal Multichannel Commands

UmcEnable, UmcGetParams, UmcSetBw, UmcSetLPVID

Virtual Port "VPort" Commands

CreateVPort, DeleteVPort, ListVFunctions, ListVPorts, VPortTargets, ListVMs

WWN Management Commands

ChangeWWN, GetWWNCap, ReadWWN, RestoreWWN

Example 2

This help command example shows the details for the SetDCBParam command:

```
hbacmd help setdcbparam
```

The example output:

```
SetDCBParam <WWPN|MAC> <Param> <Value>
WWPN : World Wide Port Name of FCoE Port
MAC   : MAC address of iSCSI or NIC port
Param: Parameter Name
Value: Parameter Value
```

Note:

1. For FCoEPriority and iScsiPriority, the valid range is 0 to 7. A single priority must be specified.
2. For the following parameters, the valid values are 0 and 1:
 - DcbxState, DcbxMode
 - TxState, RxState, TxPortDesc, TxSysDesc, TxSysName, TxSysCap,

- ```
PfcEnable, PfcPriority
```
3. PfcPriority comma separated list where multiple PFC priorities supported.
  4. Specifying "defaults" for the Param argument sets all DCB parameters (including Priority Groups) to their default values.  
Ex: SetDCBParams <WWPN|MAC> defaults

## Adapter License Management Commands

### Notes:

- Adapter License Management commands are supported on OneConnect adapters only. These commands are not available on LP1600x adapters.
- These commands are not available on OCe11101-EM/EX or OCe11102-EM/EX adapters. The following error message will be returned:

```
There are no license features for this adapter
```

In these commands, the WWPN or MAC address argument specifies the adapter the command is acting upon. The the HbaCmd application uses the WWPN or MAC address to identify the adapter, but this does not mean that the command works successfully on the specified port.

### InstallAdapterLicense

This command installs the license keys from a license file to enable specific features on the adapter.

#### Supported By

Linux, Solaris, VMware ESX, and Windows

#### Syntax

```
InstallAdapterLicense <WWPN|MAC> <LicenseFile>
```

#### Parameters

|              |                                                                                                        |
|--------------|--------------------------------------------------------------------------------------------------------|
| WWPN         | The FCoE port WWPN of the adapter.                                                                     |
| MAC          | The NIC or iSCSI port address of the adapter.                                                          |
| License File | The path to the license key file containing the license keys obtained from the Emulex License website. |

#### Examples

For non-VMware ESX/ESXi hosts:

```
hbacmd InstallAdapterLicense 00-12-34-56-78-9A K:\lf1324.lic
```

For VMware ESX/ESXi hosts:

```
hbacmd h=<IP_Address> m=cim u=root p=<password> n=<namespace>
InstallAdapterLicense 00-12-34-56-78-9A K:\lf1324.lic
```

## ShowAdapterLicenseFeatures

This command displays the list of licensed and licensable features, as well as, features that are already licensed. The output is a list of features with an indication of whether or not the feature has been licensed.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ShowAdapterLicenseFeatures <WWPN|MAC>
```

### Parameters

**WWPN** The FCoE port WWPN of the adapter.

**MAC** The NIC or iSCSI port address of the adapter.

### Examples

For non-VMware ESX/ESXi hosts:

```
hbacmd ShowAdapterLicenseFeatures 00-12-34-56-78-9A
```

For VMware ESX/ESXi hosts:

```
hbacmd h=<IP_Address> m=cim u=root p=<password> n=<namespace>
ShowAdapterLicenseFeatures 00-12-34-56-78-9A
```

## ShowAdapterLicenseID

This command returns the adapter ID used for enabling licensed features. The adapter ID and the entitlement code are used to obtain license keys which enable various features on the adapter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ShowLicenseAdapterID <WWPN|MAC>
```

### Parameters

**WWPN** The FCoE port WWPN of the adapter.

**MAC** The NIC or iSCSI port address of the adapter.

### Examples

For non-VMware ESX/ESXi hosts:

```
hbacmd ShowLicenseAdapterID 00-12-34-56-78-9A
```

For VMware ESX/ESXi hosts:

```
hbacmd h=<IP_Address> m=cim u=root p=<password> n=<namespace>
ShowLicenseAdapterID 00-12-34-56-78-9A
```

## Attributes Commands

### HbaAttributes

This command shows a list of all adapter attributes for all ports on the adapter. The type of information listed may vary according to the adapter model.

#### Supported By

Linux, Solaris, VMware ESX, and Windows

#### Syntax

```
HbaAttributes <WWPN>
```

#### Parameters

**h** The IP address of the host.  
**WWPN** The WWPN of the adapter.

### PortAttributes

This command shows a list of port attributes for the adapter. The type of information listed may vary according to the adapter model.

#### Supported By

Linux, Solaris, VMware ESX, and Windows

#### Syntax

```
PortAttributes <WWPN|MAC>
```

#### Parameters

**h** The IP address of the host.  
**WWPN** The WWPN of the adapter.  
**MAC** The MAC address of the NIC or iSCSI port.

### PortStatistics

This command shows all port statistics for the adapter. The type of information listed may vary according to the adapter model.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
PortStatistics <WWPN>
```

### Parameters

**WWPN** The WWPN of the adapter.

## ServerAttributes

This command shows a list of server attributes for the adapter. The type of information listed may vary according to the adapter model.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ServerAttributes <WWPN|MAC>
```

### Parameters

**WWPN** The WWPN of the adapter.

**MAC** The MAC address of the NIC or iSCSI port.

## SetPfcThrottle

This command returns the PFC Throttle state as enabled or disabled.

**Note:** The PFC Throttle state returns when using the PortAttributes command for OneConnect OCe10102 adapters. However, for OneConnect adapters with older firmware that does not support PfcThrottle and for non-OneConnect adapters, the PFC Throttle state does not return when using the PortAttributes command.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetPfcThrottle <WWPN> <0|1>
```

### Parameters

**WWPN** The WWPN of the adapter.

0|1      The PFC throttle state:  
0 = Disabled  
1 = Enabled

## SetPhyPortSpeed

This command sets the port speed on OneConnect OCe11100-series adapters only.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetPhyPortSpeed <WWPN|MAC> <Mode> [Speed [Length]]
```

### Parameters

**WWPN**      The WWPN of the FCoE port.

**MAC**        The MAC address of the CNA port.

**Mode**        The Mode number:  
0 = Default  
1 = Auto-negotiate; requires the <Speed> argument.  
2 = Force; requires the <Speed> and <Length> arguments.

**Speed**        The Speed string.  
When <Mode> is 1 or 2, the <Speed> argument is required. When <Mode> is 0, the <Speed> argument is ignored.  
The speed of the PHY port. Some valid string values include "100Mb", "1Gb", and "10Gb". The PortAttributes command lists all the valid speeds in Auto-negotiate and Force modes.

**Length**        The length of the direct attach copper cable in meters. Valid values are 0-10. A <Length> value is required when using a 10Gb SFP Plus transceiver.  
When <Mode> is 2, the <Length> argument is required. When <Mode> is 0 or 1, the <Length> argument is ignored.

### Examples

The following example configures the PHY port to a forced speed of 1 Gb/sec with a cable length of two meters:

```
hbacmd setphyportspeed 00-00-c9-ad-ad-ac 2 1Gb 2
```

The following example tries to configure the PHY port to a forced speed of 100 Mb/sec:

```
hbacmd setphyportspeed 00-00-c9-a9-41-88 2 100Mb
```

This command results in an error because you must include a <Length> value when <Mode> is 2:

```
ERROR: <431>: Cable length required for force mode and interface type
```

## SetPortEnabled

This command enables or disables the FC or UCNA port.

### Notes:

- Ensure that all I/Os on the port are stopped before disabling the port.
- Only OneConnect adapters do not require a reset when the adapter port is enabled or disabled. For all other adapters, when the SetPortEnabled command disables an FC port, the adapter must be reset to activate the new setting.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetPortEnabled <WWPN|MAC> <PortEnable>
```

### Parameters

|             |                                                        |
|-------------|--------------------------------------------------------|
| WWPN        | The WWPN of the adapter.                               |
| MAC         | The MAC address of the NIC or iSCSI port.              |
| PortEnabled | The port-enabled state:<br>0 = Disabled<br>1 = Enabled |

## Authentication Commands

**Note:** Authentication commands are supported on FC adapter ports only. These commands are not available on LP1600x adapters.

### AuthConfigList

This command returns the list of WWPNs that have an authentication connection configuration with the specified adapter.

### Supported By

Linux, Solaris, and Windows

### Syntax

```
AuthConfigList <WWPN>
```

### Parameters

|      |                          |
|------|--------------------------|
| WWPN | The WWPN of the adapter. |
|------|--------------------------|



## DeleteAuthConfig

This command deletes the authentication configuration on the adapter.

### Supported By

Linux, Solaris, and Windows

### Syntax

```
DeleteAuthConfig <WWPN1> <WWPN2> <PasswordType> <Password>
```

### Parameters

|              |                                                                          |
|--------------|--------------------------------------------------------------------------|
| WWPN1        | The WWPN of the adapter.                                                 |
| WWPN2        | Use “ff:ff:ff:ff:ff:ff:ff:ff” for a switch or use the WWPN for a target. |
| PasswordType | 1 = ASCII<br>2 = Hex (binary)<br>3 = Password not yet defined            |
| Password     | The current password value.                                              |

## GetAuthConfig

This command retrieves the authentication configuration for the adapter.

### Supported By

Linux, Solaris, and Windows

### Syntax

```
hbacmd GetAuthConfig <WWPN1> <WWPN2>
```

### Parameters

|       |                                                                          |
|-------|--------------------------------------------------------------------------|
| WWPN1 | The WWPN of the adapter.                                                 |
| WWPN2 | Use “ff:ff:ff:ff:ff:ff:ff:ff” for a switch or use the WWPN for a target. |

## GetAuthStatus

This command returns the current status for the authentication connection specified by WWPN 1 and WWPN2 (adapter and the switch). It includes the current authentication state (connected or failed). Currently authenticated connections specify the hash algorithm and DH group used in the DHCHAP associated with this connection. Failed status includes the failure reason.

### Supported By

Linux, Solaris, and Windows

## Syntax

```
GetAuthStatus <WWPN1> <WWPN2>
```

## Parameters

**WWPN1** The WWPN of the adapter.  
**WWPN2** Use “ff:ff:ff:ff:ff:ff:ff:ff” for a switch or use the WWPN for a target.

## InitiateAuth

This command initiates the authentication configuration on the adapter.

## Supported By

Linux, Solaris, and Windows

## Syntax

```
InitiateAuth <WWPN1> <WWPN2>
```

## Parameters

**WWPN1** The WWPN of the adapter.  
**WWPN2** Use “ff:ff:ff:ff:ff:ff:ff:ff” for a switch or use the WWPN for a target.

## SetAuthConfig

This command sets the authentication configuration for the adapter.

## Supported By

Linux, Solaris, and Windows

## Syntax

```
SetAuthConfig <WWPN1> <WWPN2> <PasswordType> <Password> <Param> <Value>
```

**Note:** Where multiple parameters and values are used, separate them using commas.

## Parameters

**WWPN1** The WWPN of the adapter.  
**WWPN2** Use “ff:ff:ff:ff:ff:ff:ff:ff” for a switch or use the WWPN for a target.  
**PasswordType** 1 = ASCII  
2 = Hex (binary)  
3 = Password not yet defined  
**Password** The current password value.

|       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Param | The parameter names: <ul style="list-style-type: none"> <li>• Mode</li> <li>• Timeout</li> <li>• Bi-directional</li> <li>• Hash-priority</li> <li>• DH-priority</li> <li>• Re-authentication</li> <li>• Re-authentication-interval</li> </ul>                                                                                                                                                                                                                                                     |
| Value | The value is based on the type of <Param>: <ul style="list-style-type: none"> <li>• Mode: disabled, enabled, or passive</li> <li>• Timeout: time in seconds</li> <li>• Bi-directional = disabled or enabled</li> <li>• Hash-priority: md5 or sha1 (md5 = first md5, then sha1; sha1 = first sha1, then md5)</li> <li>• DH-priority: 1, 2, 3, 4, 5; any combination up to 5 digits</li> <li>• Re-authentication: disabled or enabled</li> <li>• Re-authentication-interval: 0, 10- 3600</li> </ul> |

## SetPassword

This command sets the password for the adapter.

### Supported By

Linux, Solaris, and Windows

### Syntax

```
SetPassword <WWPN1> <WWPN2> <Flag> <Cpt> <Cpw> <Npt> <Npw>
```

### Parameters

|       |                                                                                                                                                                                 |
|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| WWPN1 | The WWPN of the adapter.                                                                                                                                                        |
| WWPN2 | Must be "ff:ff:ff:ff:ff:ff:ff:ff" for a switch or the actual WWPN for a target.                                                                                                 |
| Flag  | 1 = Local (password used by the adapter when the adapter authenticates to the switch)<br>2 = Remote (password used by the adapter when the switch authenticates to the adapter) |
| Cpt   | Current password type<br>1 = ASCII<br>2 = Hex (binary)<br>3 = Password not yet defined                                                                                          |
| Cpw   | Current password value.                                                                                                                                                         |

|     |                                                    |
|-----|----------------------------------------------------|
| Npt | New password type<br>1 = ASCII<br>2 = Hex (binary) |
| Npw | New password value.                                |

## Boot Commands

### EnableBootCode

This command is used to perform either of the following:

- Enable or disable network boot for UCNA NIC ports. If network boot is being enabled, it is necessary to select the specific network boot type. The supported network boot types are PXE and iBFT. Note that iBFT is not supported on all UCNA types.
- Enable/disable the boot code for an FC adapter port. If the boot code is disabled on the FC adapter, the adapter does not boot from the SAN, regardless of the value for the EnableBootFromSan boot parameter. If the boot code is enabled on the FC adapter, the adapter boots from the SAN if the EnableBootFromSan parameter is also enabled.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
EnableBootCode <WWPN|NIC MAC> <Flag> <NetworkBootMethod>
```

### Parameters

|                   |                                                                                                                                                                                                                                                                                                                            |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| WWPN              | World Wide Port Name of FC port                                                                                                                                                                                                                                                                                            |
| NIC MAC           | MAC address of the NIC port.                                                                                                                                                                                                                                                                                               |
| Flag              | D = Disable the boot code.<br>E = Enable the boot code.                                                                                                                                                                                                                                                                    |
| NetworkBootMethod | Network boot method to be used by the NIC ("PXE" or "iBFT"). The network boot types supported on the specific NIC may be found in the Available Network Boot Methods string displayed by the HbaAttributes command. This parameter is not required for FC or FCoE ports, and is only specified when enabling network boot. |

### Examples

The following example enables iBFT for a NIC:

```
C:\Program Files\Emulex\Util\OCManager>HBACMD EnableNetworkBoot
00-00-c9-11-22-33 e iBFT
```

The following example disables network boot:

```
C:\Program Files\Emulex\Util\OCManager>HBACMD EnableNetworkBoot
00-00-c9-11-22-33 d
```

## GetBootParams

This command shows the boot parameters. If any arguments are missing or invalid, a suitable error is reported. If all arguments are correct, the data is displayed in tabular form.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetBootParams <WWPN> <Type>
```

### Parameters

|      |                          |
|------|--------------------------|
| WWPN | The WWPN of the adapter. |
| Type | X86, OpenBoot, or UEFI   |

## SetBootParam

This command changes the boot parameters. You can change adapter parameters and boot device parameters for x86, OpenBoot, and UEFI boot.

- When changing adapter parameters, omit the BootDev keyword and value; otherwise, an error is reported.
- When changing boot device parameters for OpenBoot, omit the BootDev keyword and value; otherwise, an error is reported.
- For boot device parameters for X86 or UEFI, you must provide the BootDev keyword and value.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetBootParam <WWPN> <Type> <Param> <Value1> [BootDev <Value2>]
```

### Parameters

|         |                                            |
|---------|--------------------------------------------|
| WWPN    | The WWPN of the adapter.                   |
| Type    | Possible values are X86, OpenBoot, or UEFI |
| Param   | The parameter name.                        |
| Value1  | The parameter value.                       |
| BootDev | The boot device.                           |

Value2      The boot device entry number: 0-7

## CEE Commands

Three CEE commands are listed when you run the help command; however, the commands are only applicable for a discontinued product and should be ignored.

## Channel Management Commands

These commands enable and disable channel management of CNA adapters and the setting of channel properties.

Each adapter's physical port can be partitioned into a maximum of four isolated channels providing a converged conduit for network and storage traffic. Each channel has its own unique MAC address. Depending on the type of channel management in effect, each channel provides various traffic management and provisioning capabilities, such as enabling and disabling, minimum and maximum transmit rates, and VLAN ID (in UMC for untagged packets, also called the LPVID).

OCM allows the enabling and disabling of channel management and in the case of UMC/vNIC2, the setting of each channel's properties. For the vNIC1 and UFP channel management types, OCM will display the channel properties, but not allow modification.

### Notes:

- For IBM adapters, UMC mode may be referred to as "vNIC2".
- There are OCM CLI commands for UMC management that are still available for backward compatibility with existing UMC scripts. They cannot be used to manage other channel management types. See "UMC Commands" on page 120 for information on UMC management.

## CMGetParams

This command shows the current channel management configuration for an adapter's physical port. For UMC configurations, the UMCGetParams command can still be used.

The command's output is the active (booted) channel management state for the adapter, the configured state, the configured management mode (not applicable if the configured state is disabled) and the available channel management modes. This is followed by a table showing the port's channels along with their channel properties. The Type column shows the protocol that is running on each channel.

**Note:** For some adapters, three channels will be shown instead of four because the physical port will only support three.

### Supported By

Linux, Solaris, VMware, and Windows

## Syntax

```
hbacmd CMGetParams <WWPN | MAC Address>
```

## Parameters

**WWPN** : WWPN of an FCoE function on the physical port

**Type** : MAC address of any NIC function on the physical adapter port

## Example

```
>hbacmd CMGetParams 00-00-c9-12-34-56
```

```
Active state: Disabled
```

```
Configured mode: None
```

```
Available modes: vNIC1, vNIC2, UFP
```

```
>hbacmd CMGetParams 00-00-c9-12-34-56
```

```
Active state: Enabled
```

```
Configured mode: UMC
```

```
Available modes: vNIC1, vNIC2, UFP
```

| Func# | Type | MAC Address       | LPVID | Min BW | Max BW |
|-------|------|-------------------|-------|--------|--------|
| 0     | NIC  | 00-00-c9-bb-cc-aa | 2     | 25     | 50     |
| 1     | NIC  | 00-00-c9-bb-cc-ab | 3     | 0      | 50     |
| 2     | NIC  | 00-00-c9-bb-cc-ac | 4     | 25     | 50     |
| 3     | NIC  | 00-00-c9-bb-cc-ad | 5     | 50     | 75     |

## CMMode

This command enables a channel management mode or disables channel management. For UMC configurations, the UMCEnable command can still be used (to enable UMC only).

This command sets the channel management type at the adapter level. A system reboot is required to make the change take effect.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
hbacmd CMMode <WWPN | MAC Address> <None | Type>
```

## Parameters

**WWPN** : WWPN of an FCoE function on the physical port

**MAC** : MAC address of any NIC function on the physical adapter port  
**Type** : Specify "None" to disable channel management or a channel management type (see CMGetParams) to enable channel management

### Example

```
>hbacmd CMMode 00-00-c9-bb-cc-aa None
```

This example disables channel management on an adapter containing a NIC function with a MAC address of 00-00-c9-ad-ad-aa.

## CMSetBW

This command sets the minimum and maximum bandwidths for each channel (up to four) on the physical port. For UMC configurations, this command can also be used to enable or disable a channel. For UMC, the UMCSetBW command can still be used instead of this command.

The total of the minimum bandwidths must add up to 100. The maximum bandwidths must be greater than or equal to the minimum bandwidth and has a maximum of 100. A reboot is not required to make these changes take effect (when channel management is enabled).

For UMC mode, you can disable a channel (logical link state down) by setting the minimum bandwidth (and maximum) to 0. Setting the minimum bandwidth to a value greater than 0 will enable the channel if it was previously disabled.

**Note:** This command will fail if the current channel management mode is vNIC1 or UFP.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
hbacmd CMSetBW <WWPN | MAC Address> <Min0,Max0> <Min1,Max1> <Min2,Max2>
[Min3,Max3]
```

### Parameters

**MAC Address** : MAC address of any NIC function on the physical adapter port  
**WWPN** : WWPN of an FCoE function on the physical port  
**Min0, Max0** : minimum and maximum bandwidths for channel 0  
**Min1, Max1** : minimum and maximum bandwidths for channel 1  
**Min2, Max2** : minimum and maximum bandwidths for channel 2  
**Min3, Max3** : minimum and maximum bandwidths for channel 3

### Examples

```
>hbacmd CMSetBW 00-00-c9-bb-cc-aa 25,50 50,75 0,0 25,100
```



For a port with a channel with the specified MAC address, this command:

Sets channel 0's minimum bandwidth to 25% and maximum to 50%

Sets channel 1's minimum bandwidth to 50% and maximum to 75%

Disables channel 2 (if UMC)

Sets channel 3's minimum bandwidth to 25% and maximum to 100%

If UMC, channels 0, 1 and 3, would be enabled if their previous bandwidths were 0.

## DCB Commands

This command shows the internal host PFC flag value and DCBX mode (DCB version), as well as the LLDP state for iSCSI, FCoE, and NIC UCNAs.

### Notes:

- DCB commands are for DCB management of OneConnect adapters only.
- DCB or parts of DCB may not always be available on an adapter, depending on its configuration. For example, when UMC is enabled, priority groups are not available. Therefore, the SetCNAPGBW and SetDCBPriority commands would not be available.
- These commands are not available on Ce11101-EM/EX or OCe11102-EM/EX adapters. The following error message will be returned:

```
ERROR: <222>: DCB not available
```

## GetDCBParams

This command shows the internal host PFC flag value and DCBX mode (DCB version), as well as the LLDP state for iSCSI, FCoE, and NIC UCNAs.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetDCBParams <WWPN|MAC>
```

### Parameters

WWPN            The WWPN of the adapter.

MAC             The MAC address of the NIC or iSCSI port.

### Example

```
hbacmd h=10.192.203.154 getdcbparams 00-00-c9-93-2f-d8
```

## GetPGInfo

This command shows the bandwidth percentages for all the priority groups for the port. Additionally, this command displays the number of priority groups supported by an adapter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetPGInfo <WWPN|MAC>
```

### Parameters

**WWPN** The WWPN address of the FCoE port.  
**MAC** The MAC address of the NIC or iSCSI port.

### Example

```
hbacmd h=10.192.203.154 getpginfo 00-00-c9-93-2f-d8
```

## SetCnaPGBW

This command sets the bandwidth percentage of a priority group according to the following rules:

1. Bandwidths (BW0-BW7) for priority groups 0-7 (PG0-PG7) must total 100 (for 100%).
2. Bandwidth can be assigned to a priority group that has priorities.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetCnaPGBW <WWPN|MAC> <BW0-BW7>
```

### Parameters

**WWPN** The WWPN of the adapter.  
**MAC** The MAC address of the NIC or iSCSI port.  
**BW0-BW7** The bandwidths allocated for the priority groups 0-7.

### Example

This command sets the bandwidth of PG0 to 50%, PG1 to 50%, and PG2-PG7 to 0%.

```
hbacmd SetCnaPGBW 10:00:00:00:c9:3c:f7:88 50 50 0 0 0 0 0 0
```

## SetDCBParam

This command configures the DCB and LLDP settings on the OneConnect adapter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetDCBParam <WWPN|MAC> <Param> <Value>
```

### Parameters

|       |                                                                                                                                     |
|-------|-------------------------------------------------------------------------------------------------------------------------------------|
| WWPN  | The WWPN of the adapter.                                                                                                            |
| MAC   | The MAC address of the NIC or iSCSI port.                                                                                           |
| Param | The parameter name. See the following “DCB Settings for <Param> and <Value>” and “LLDP Settings for <Param> and <Value>” sections.  |
| Value | The parameter value. See the following “DCB Settings for <Param> and <Value>” and “LLDP Settings for <Param> and <Value>” sections. |

### DCB Settings for <Param> and <Value>

| <Param>       | Description and <Value>                                                                                                                                                     |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DCBXState     | The DCBX protocol state.<br>0 = Disabled<br>1 = Enabled                                                                                                                     |
| DCBXMode      | The DCBX mode: DCB or CIN.<br>0 = CIN<br>1 = DCB<br>The <DCBXmode> also configures the FIP mode. If <DCBXmode> = DCB, FIP is enabled. If <DCBXmode> = CIN, FIP is disabled. |
| PFCEnable     | Flow control in both directions (transmit and receive).<br>0 = Disabled<br>1 = Enabled                                                                                      |
| FCoEPriority  | This parameter is applicable for FCoE adapters only. A single priority must be specified. The range of valid values is 0-7.                                                 |
| iSCSIPriority | This parameter is applicable for iSCSI adapters only. A single priority must be specified. The range of valid values is 0-7.                                                |
| PFCPriority   | A list of comma-separated values where multiple PFC priorities supported. The comma-separated list can contain up to seven values ranging from 0-7.                         |
| defaults      | Use to set the UCNA DCB parameters (including priority groups) to their default values. For example:                                                                        |

```
hbacmd SetDCBParam <WWPN|MAC> defaults
```

**LLDP Settings for <Param> and <Value>**

| <b>&lt;Param&gt;</b> | <b>Description and &lt;Value&gt;</b>                                                                                                                                                                                                            |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TxState              | Transmit State: DCBX uses LLDP to exchange parameters between two link peers. For the DCBX protocol to operate correctly, both LLDP Rx and Tx must be enabled. If either Rx or Tx is disabled, DCBX is disabled.<br>0 = Disabled<br>1 = Enabled |
| RxState              | Receive State: DCBX uses LLDP to exchange parameters between two link peers. For the DCBX protocol to operate correctly, both LLDP Rx and Tx must be enabled. If either Rx or Tx is disabled, DCBX is disabled.<br>0 = Disabled<br>1 = Enabled  |
| TxPortDesc           | Transmit Port Description: provides a description of the port in an alpha-numeric format.<br>0 = Disabled<br>1 = Enabled                                                                                                                        |
| TxSysDesc            | Transmit System Description: provides a description of the network entity in an alpha-numeric format.<br>0 = Disabled<br>1 = Enabled                                                                                                            |
| TxSysName            | Transmit System Name: provides the system's assigned name in an alpha-numeric format.<br>0 = Disabled<br>1 = Enabled                                                                                                                            |
| TxSysCap             | Transmit System Capabilities:<br>0 = Disabled<br>1 = Enabled                                                                                                                                                                                    |

**Example**

```
hbacmd h=10.192.203.151 m=cim u=root p=Swamiji001 n=root/emulex
setdcbparam 00-00-c9-3c-f7-88 fcoepriority 3
```

**SetDCBPriority**

This command sets the priorities for a priority group. The values must be set according to the following rules:

1. The priorities range from 0 to 7.
2. The PGIDs range from 0 to 7.
3. A priority can exist in only one priority group.
4. All priorities must appear once in any of the eight priority groups (PG0-PG7).

5. Each set of priorities for a group must be separated by a space.
6. Specify multiple priorities for the same group by a comma-separated list.
7. To specify "none", use "-" for the argument.
8. The same priority values cannot be specified to different groups.
9. All priorities (0-7) must be assigned to some PGID.
10. Not all PGIDs must be assigned a priority.
11. Not all adapters support two PFC priorities and eight priority groups. For adapters, if you exceed the PFC priorities or priority groups, an error message appears.

The following rules are specific to FCoE adapters:

1. A minimum of one and a maximum of two PFC priorities can be configured.
2. One of the PFC priorities must match the FCoE priority.
3. The additional PFC priority must be assigned to a priority group that has no other priorities.
4. The FCoE priority must be assigned to a priority group that has no other priorities.

The following rules are specific to iSCSI adapters:

1. A minimum of one and a maximum of two PFC priorities can be configured.
2. One of the PFC priorities must match the iSCSI priority.
3. The additional PFC priority must be assigned to a priority group that has no other priorities.
4. The iSCSI priority must be assigned to a priority group that has no other priorities.

The following rules are specific to NIC adapters:

1. Only one PFC priority can be configured.
2. The PFC priority must be assigned to a priority group that has no other priorities.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
hbacmd SetDCBPriority <WWPN|MAC> <PFC Priorities> <Priorities of PGID0>
<Priorities of PGID1>...<Priorities of PGID7>
```

## Parameters

|               |                                                                                          |
|---------------|------------------------------------------------------------------------------------------|
| WWPN          | The WWPN of the adapter.                                                                 |
| MAC           | The MAC address of the NIC or iSCSI port.                                                |
| PFCPriorities | The PFC priority that is a comma-separated list of up to seven values, ranging from 0-7. |

Priorities of PGID Priority group membership that is a comma-separated list of priorities ranging from 0-7. Each set of priorities for a group must be separated by a space. All priorities (0-7) must be assigned to some PGID.

### Example

```
hbacmd h=10.192.203.151 m=cim setdcbpriority 10:00:00:00:c9:3c:f7:88 3
0,1,2,4,5,6,7 3 0 0 0 0 0 0
```

## Diagnostic Commands

### EchoTest

This command runs the echo test on adapters.

#### Notes:

- This command is not supported for OneConnect adapters.
- Support for remote adapter is TCP/IP access only. The EchoTest command fails if the target WWPN does not support the ECHO ELS command.

#### Supported By

Linux, Solaris, VMware ESX, and Windows

#### Syntax

```
EchoTest <WWPN Source> <WWPN Destination> <Count> <StopOnError>
<Pattern>
```

#### Parameters

|                  |                                                                                   |
|------------------|-----------------------------------------------------------------------------------|
| WWPN Source      | The WWPN of the originating adapter.                                              |
| WWPN Destination | The WWPN of the destination (echoing) adapter.                                    |
| Count            | The number of times to run the test. Use "0" to run the test indefinitely.        |
| StopOnError      | Checks if the test must be halted on error:<br>0 = No halt.<br>1 = Halt on error. |
| Pattern          | Hexadecimal data pattern to transmit (up to 8 characters).                        |

### GetBeacon

This command shows the current beacon state (either "on" or "off").

#### Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
GetBeacon <WWPN|MAC>
```

## Parameters

WWPN      The WWPN of the adapter.  
MAC        The MAC address of the NIC or iSCSI port.

## GetXcvrData

**Note:** GetXcvrData is not supported for OneConnect OCe11100 series adapters.  
This command shows transceiver data such as vendor name and serial number.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
GetXcvrData <WWPN|MAC> [Type]
```

## Parameters

WWPN      The WWPN of the adapter.  
MAC        The MAC address of the NIC or iSCSI port.  
Type       The type of SFP data to display:

- 1 = Formatted data
- 2 = Raw data

## Example

```
C:\Program Files\emulex\Util\OCManager>hbacmd h=10.192.203.154 m=cim
u=root p=Swamiji001 n=root/emulex getxcvrdata 00-00-c9-93-2f-d6
```

## LoadList

**Note:** Not supported for OneConnect adapters.

This command shows the flash memory load list data for the adapter.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
LoadList <WWPN>
```

## Parameters

**WWPN**      The WWPN of the adapter.

## LoopBackTest

This command runs the loop test on the adapter specified by the WWPN or MAC address. Only PHY loopback test and MAC loopback tests are enabled for OneConnect adapters.

**Note:** Loopback tests can be run on FC ports being managed locally or remotely through TCP/IP-based management.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
LoopBackTest <WWPN|MAC> <Type> <Count> <StopOnError> [Pattern]
```

## Parameters

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>WWPN</b>        | The WWPN of the FC or FCoE port.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>MAC</b>         | The MAC address of the NIC or iSCSI port.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Type</b>        | The type of loopback test to run: <ul style="list-style-type: none"> <li>• 0 = PCI loopback test. Not supported for OneConnect UCNAs.</li> <li>• 1 = Internal loopback test. Not supported for OneConnect UCNAs.</li> <li>• 2 = External loopback test (requires loopback plug)</li> <li>• 3 = DMA loopback test. Only supported for OneConnect UCNAs. This DMA loopback test is not supported via the CIM interface.</li> <li>• 4 = PHY loopback test. Only supported for OneConnect UCNAs.</li> <li>• 5 = MAC loopback test. Only supported for OneConnect UCNAs.</li> </ul> |
| <b>Count</b>       | Number of times to run the test. Possible values are 1-99,9999. To run the test infinitely, use 0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>StopOnError</b> | Checks if the test must be halted on error.<br>0 = No halt<br>1 = Halt                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Pattern</b>     | An optional parameter that specifies 1-8 hexadecimal bytes to use for loopback data (for example: 1a2b3c4d).                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

## Example

```
hbacmd h=10.192.193.154 m=cim u=root p=Swamiji001 n=root/emulex
loopbacktest 00-00-c9-93-2f-9f 4 120 0
```



## LoopMap

**Note:** Supported for FC ports only.

This command shows the arbitrated loop map data.

### Supported By

Linux, Solaris, and Windows

### Syntax

```
LoopMap <WWPN>
```

### Parameters

**WWPN**        The WWPN of the adapter.

## PciData

This command shows the PCI configuration data.

The PCI registers displayed are specific to the function referenced in the OneCommand Manager CLI. For example, if you specify the WWPN for the FCoE function, the PCI registers for that FCoE function return. If you specify the MAC address for the NIC function on that same physical port, the PCI registers for that NIC function return. Only the base PCI registers return. The extended PCI registers are not available on a UCNA.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
PciData <WWPN|MAC>
```

### Parameters

**WWPN**        The WWPN of the adapter's port.

**MAC**         The MAC address of the NIC or iSCSI port.

### Example

```
C:\Program Files\emulex\Util\OCManager>hbacmd h=10.192.203.154
m=cim u=root p=Swamiji001 n=root/emulex pcidata 00-00-c9-93-2f-d6
```

The example output:

|                  |        |                |        |
|------------------|--------|----------------|--------|
| Vendor ID:       | 0x19A2 | Device ID:     | 0x0700 |
| Command:         | 0x0406 | Status:        | 0x0010 |
| Revision ID:     | 0x02   | Prog If:       | 0x00   |
| Subclass:        | 0x00   | Base Class:    | 0x02   |
| Cache Line Size: | 0x10   | Latency Timer: | 0x00   |

|                   |            |                     |            |
|-------------------|------------|---------------------|------------|
| Header Type:      | 0x80       | Built In Self Test: | 0x00       |
| Base Address 0:   | 0x00000000 | Base Address 1:     | 0xDF478000 |
| Base Address 2:   | 0xDF480004 | Base Address 3:     | 0x00000000 |
| Base Address 4:   | 0xDF4A0004 | Base Address 5:     | 0x00000000 |
| CIS:              | 0x00000000 | SubVendor ID:       | 0x10DF     |
| SubSystem ID:     | 0xE622     | ROM Base Address:   | 0x00000000 |
| Interrupt Line:   | 0x00       | Interrupt Pin:      | 0x01       |
| Minimum Grant:    | 0x00       | Maximum Latency:    | 0x00       |
| Capabilities Ptr: | 0x40       |                     |            |

## PostTest

**Note:** Not supported for OneConnect adapters.

This command runs the POST on the adapter. Support for a remote adapter is through TCP/IP access only.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
PostTest <WWPN>
```

### Parameters

**WWPN** The WWPN of the adapter.

## SetBeacon

This command turns the beacon on or off.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetBeacon <WWPN|MAC> <BeaconState>
```

### Parameters

**WWPN** The WWPN of the FC port.

**MAC** The MAC address of the NIC or iSCSI port.

**BeaconState** Indicates the state of the beacon to be set to:  
0 = Off  
1 = On

## SetCableNVP

**Note:** This command supports only OneConnect OCe11100 series adapters.

This command sets the NVP required for the TDRTest command, for the cable that connects to the physical port associated with the WWPN or MAC.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetCableNVP <WWPN|MAC> <NVP>
```

### Parameters

|      |                                                                                                        |
|------|--------------------------------------------------------------------------------------------------------|
| WWPN | The WWPN of the FC port.                                                                               |
| MAC  | The MAC address of the NIC or iSCSI port.                                                              |
| NVP  | A percentage value between 1 and 100. Consult your cable documentation to obtain the proper NVP value. |

## TDRTest

**Note:** This command is supported on OneConnect adapters only.

The TDR test attempts to determine if any cable faults are compromising the integrity of the link.

For each twisted pair cable (labeled A, B, C, or D):

- If a fault cannot be detected, the test output displays “OK” and an estimated cable length (in meters), if possible. If the length cannot be determined, the estimated length is displayed as “invalid”.
- If one of two faults (a short or an open connection) is detected, the test output displays the fault type (“Shorted” or “Open”) and the distance to the fault (in meters).

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
TDRTest <MAC_Address>
```

### Parameters

MAC\_Address The MAC address of the NIC or iSCSI port.

### Example

```
hbacmd TDRTest <MAC>
```

The example output:

```
Pair A: OK. Cable Length Estimation: 50m.
Pair B: OK. Cable Length Estimation: invalid.
Pair C: Open. Distance to Fault: 38m.
Pair D: Shorted. Distance to Fault: 36m.
```

## Wakeup

**Note:** Not supported for OneConnect adapters.

This command wakes up the adapter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
Wakeup <WWPN>
```

### Parameters

**WWPN**            The WWPN of the adapter.

## Driver Parameter Commands

### Notes:

- Supported for FC and FCoE ports only.
- Driver parameters that are set to temporary or global values (using the “T” and “G” flags, respectively) must be read using the GetDriverParams command to view the current value of the parameter. The GetDriverParamsGlobal command returns only permanently set driver parameter values.

Additionally, if temporary and global values have been set for one or more driver parameters, the “SaveConfig” command must be run with the “N” flag (using the “N” flag is analogous to the GetDriverParams command) to force the driver parameter values for the specified adapter to be saved. Inaccurate values may be saved if the “G” flag is used for this command.

- The DriverConfig and SetDriverParamDefaults commands are not supported for Solaris.

## DriverConfig

This command sets all driver parameters to the values in the .dpv file type. The .dpv file's driver type must match the driver type of the host platform adapter.

### Supported By

Linux, VMware ESX, and Windows

### Syntax

```
DriverConfig <WWPN> <FileName> <Flag>
```

### Parameters

|          |                                                                                                       |
|----------|-------------------------------------------------------------------------------------------------------|
| WWPN     | The WWPN of the adapter.                                                                              |
| FileName | The name of the .dpv file, which is stored in the Emulex Repository directory.                        |
| Flag     | G = Make change global (all adapters on this host).<br>N = Make change non-global (adapter-specific). |

## GetDriverParams

This command shows the name and values of each parameter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetDriverParams <WWPN>
```

### Parameters

|      |                          |
|------|--------------------------|
| WWPN | The WWPN of the adapter. |
|------|--------------------------|

## GetDriverParamsGlobal

This command shows the name and the global value of each driver parameter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetDriverParamsGlobal <WWPN>
```

### Parameters

|      |                          |
|------|--------------------------|
| WWPN | The WWPN of the adapter. |
|------|--------------------------|

## SaveConfig

This command saves the specified adapter's driver parameters to a file. The resulting file contains a list of driver parameter definitions in ASCII file format with definitions delimited by a comma. Each definition has the following syntax:

```
<parameter-name>=<parameter-value>.
```

The command saves either the values of the global set, or those specific to the adapter in the Emulex Repository directory.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SaveConfig <WWPN> <FileName> <Flag>
```

### Parameters

|          |                                                                                            |
|----------|--------------------------------------------------------------------------------------------|
| WWPN     | The WWPN of the adapter.                                                                   |
| FileName | Name of the file that contains the driver parameters list.                                 |
| Flag     | G = Save the global parameter set.<br>N = Save the local (adapter-specific) parameter set. |

## SetDriverParam

This command changes a driver parameter and designates the scope of the change.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetDriverParam <WWPN> <Flag1> <Flag2> <Param> <Value>
```

### Parameters

|       |                                                                                                     |
|-------|-----------------------------------------------------------------------------------------------------|
| WWPN  | The WWPN of the adapter.                                                                            |
| Flag1 | L = Make change local for this adapter only.<br>G = Make change global (all adapters on this host). |
| Flag2 | P = Make change permanent (persists across reboot).<br>T = Make change temporary.                   |
| Param | Name of the parameter to modify.                                                                    |
| Value | New parameter value, decimal or hexadecimal (0xNNNN).                                               |

## SetDriverParamDefaults

This command changes all values to the default for the adapter(s).

### Supported By

Linux, VMware ESX, and Windows

### Syntax

```
SetDriverParamDefaults <WWPN> <Flag1> <Flag2>
```

### Parameters

|       |                                                                                                                |
|-------|----------------------------------------------------------------------------------------------------------------|
| WWPN  | The WWPN of the adapter.                                                                                       |
| Flag1 | L = Make change local for this adapter only.<br>G = Make change global (applies to all adapters on this host). |
| Flag2 | P = Make change permanent (the change persists across reboot).<br>T = Make change temporary.                   |

## Dump Commands

The diagnostic dump feature enables you to create a “dump” file for a selected adapter. Dump files contain information such as firmware version, driver version, and operating system information. This information is useful when troubleshooting an adapter, but is unavailable in read-only mode.

**Caution:** Disruption of service can occur if a diagnostic dump is run during I/O activity.

The dump files created are text files (“.txt” extension) and binary files. The extension for binary files depends on the adapter type:

- OneConnect UCNAs (Enhanced FAT Dump) – “.edf” extension
- OneConnect UCNAs (Core Dump) – “.core” extension
- 16-Gb HBAs – “.bin” extension
- Legacy and LightPulse™ adapters – “.dmp” extension

## DeleteDumpFiles

This command deletes all diagnostic dump files for the adapter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
DeleteDumpFiles <WWPN|MAC>
```

### Parameters

|      |                                   |
|------|-----------------------------------|
| WWPN | The WWPN of the adapter.          |
| MAC  | The MAC address of the UCNA port. |

## Dump

This command creates a diagnostic dump file in the HbaCmd dump file directory.

**Note:** In some cases, a core dump can be performed on an inoperative OneConnect UCNA. To view inoperable UCNAs on the local host, use the “ListHBAs down” command. See “ListHBAs” on page 111.

**Note:** For OneConnect UCNAs, if the “core” optional parameter is not specified, an Enhanced FAT Dump is performed by default.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
Dump <WWPN|MAC> [core [Options]]
```

### Parameters

|         |                                                          |
|---------|----------------------------------------------------------|
| WWPN    | The WWPN of the adapter.                                 |
| MAC     | The MAC address of the UCNA port.                        |
| core    | Perform a core dump on a OneConnect UCNA.                |
| Options | For available Options, contact Emulex technical support. |

## GetDumpDirectory

This command shows the dump file directory for the adapters in the host.

**Note:** The dump directory can be set on VMware ESX hosts only.

**Note:** The dump directory applies to all adapters in the server. There is not a separate dump directory for each adapter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetDumpDirectory <WWPN|MAC>
```



## Parameters

|      |                                   |
|------|-----------------------------------|
| WWPN | The WWPN of the adapter.          |
| MAC  | The MAC address of the UCNA port. |

## GetDumpFile

This command gets the dump file. For dump file retrieval over FC/FCoE, the WWPN of a remote FC/FCoE port is required to access the remote host. This command gets the user-specified dump file to the local client's dump directory. The dump directory (local and remote) is named Dump, and is placed under the OneCommand Manager installation directory. The dump files are copied from the Dump directory of the remote host to the Dump directory of the local host. Therefore, specifying a local port identifier for this command returns the following error, since the source and destination directory is the same.

```
ERROR: HBACMD_GetDumpFile: RM_GetDumpFile call failed (2)
ERROR: <2>: Not Supported
```

Dump directory:

- For Windows - C:\Program Files\Emulex\Util\Dump
- For Linux - /usr/sbin/ocmanager/Dump
- For Solaris - /opt/ELXocm/Dump
- For VMware ESX - The dump directory set using the SetDumpDirectory command.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
GetDumpFile <WWPN|MAC> <filename>
```

## Parameters

|          |                                                              |
|----------|--------------------------------------------------------------|
| WWPN     | The WWPN of the adapter.                                     |
| MAC      | The MAC address of the UCNA port.                            |
| filename | The name of the dump file to be copied from the remote host. |

## Example

```
hbacmd h=10.192.193.154 m=cim u=root p=Swamiji001 n=root/emulex
getdumpfile BG-HBANYWARE-15_10000000c97d1314_20100120-032820421.dmp
```

## GetDumpFileNames

This command gets the names of the files in the remote host's dump directory.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetDumpFileNames <WWPN|MAC>
```

### Parameters

WWPN            The WWPN of the adapter.  
MAC             The MAC address of the UCNA port.

### Example

```
hbacmd h=10.192.193.154 m=cim u=root p=Swamiji001 n=root/emulex
getdumpfilenames
```

## GetRetentionCount

This command shows the maximum number of diagnostic dump files to keep.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetRetentionCount <WWPN|MAC>
```

### Parameters

WWPN            The WWPN of the adapter.  
MAC             The MAC address of the UCNA port.

## SetDumpDirectory

This command sets the dump directory for the VMware ESX/ESXi hosts only.

### Supported By

VMware ESX

To use the SetDumpDirectory command, you must have a directory (which must be a "Storage" partition) mapped under /vmfs/volumes where the files will be dumped. This directory points to the internal hard disk or an external storage area and can also be mapped using the vSphere Client utility from VMware.

The application checks for the dump directory and creates the dump files in that location.

**Notes:**

- The dump directory applies to all adapters in the server. There is no separate dump directory for each adapter.
- In a remote environment, you can use the SetDumpDirectory command from a host running any operating system (including Linux, Solaris, and Windows), but only to a remote host that is running VMware ESX/ESXi.

**Syntax**

For VMware ESX using the RM interface:

```
hbacmd h=IP_Address[:port] setdumpdirectory <DumpDirectoryName>
```

For VMware ESX/ESXi using the CIM interface:

```
hbacmd h=<IP_Address> m=cim [u=<username>] [p=<password>]
[n=<namespace>] setdumpdirectory <DumpDirectoryName>
```

**Parameters**

**DumpDirectoryName** The directory under /vmfs/volumes that you created to store the dump files.

**h** The IP address of the host.

**Example**

This example shows the dump directory set to /vmfs/volumes/ocm-datastore:

```
hbacmd h=10.192.203.173 m=cim u=root p=Swamiji001 n=root/emulex
setdumpdirectory 10:00:00:00:c9:61:f2:64 ocm-datastore
```

## SetRetentionCount

This command specifies the maximum number of diagnostic dump files for the adapter. When the count reaches the limit, the next dump operation deletes the oldest file.

**Note:** The retention count applies to all adapters in the server.

**Supported By**

Linux, Solaris, VMware ESX, and Windows

**Syntax**

```
SetRetentionCount <WWPN|MAC> <Value>
```

**Parameters**

**WWPN** The WWPN of the adapter.

**MAC** The MAC address of the UCNA port.

**Value** The number of dump files to retain.

### Example

```
hbacmd h=10.192.193.154 m=cim u=root p=Swamiji001 n=root/emulex
SetRetentionCount 00-00-c9-93-2f-9f 6
```

## FCoE Commands

**Note:** These commands are supported only on OneConnect FCoE ports.

### GetFCFInfo

This command shows the FCF information of the OneConnect adapter in FCoE mode.

#### Supported By

Linux, Solaris, VMware ESX, and Windows

#### Syntax

```
GetFCFInfo <WWPN>
```

#### Parameters

**WWPN**            The WWPN of the adapter.

#### Example

```
hbacmd getfcfinfo 10:00:00:00:c9:3c:f7:88
```

### GetFIPParams

This command gets the FIP parameters of the OneConnect adapter in FCoE mode.

#### Supported By

Linux, Solaris, VMware ESX, and Windows

#### Syntax

```
GetFIPParams <WWPN>
```

#### Parameters

**WWPN**            The WWPN of the adapter.

#### Example

```
hbacmd getfipparams 10:00:00:00:c9:5b:3a:6d
```

## SetFIPParam

This command sets the FIP parameters of the OneConnect adapter in FCoE mode.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetFIPParam <WWPN> <Param> <Value>
```

### Parameters

|       |                                                                                                                                                                                                                                                                                                                                                                                          |
|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| WWPN  | The WWPN of the adapter.                                                                                                                                                                                                                                                                                                                                                                 |
| Param | The FIP parameter name: <ul style="list-style-type: none"><li>• pfabric</li><li>• pswitch</li><li>• vlanid</li><li>• fcmap</li><li>• cinvlanid</li></ul>                                                                                                                                                                                                                                 |
| Value | The value based on the FIP parameter name: <ul style="list-style-type: none"><li>• pfabric: 8-byte fabric name (format XX:XX:XX:XX:XX:XX:XX:XX)</li><li>• pswitch: 8-byte switch name (format XX:XX:XX:XX:XX:XX:XX:XX)</li><li>• vlanid: 2-byte VLAN ID [0-4095] or "any" for any VLANID</li><li>• fcmap: 3-byte FC_map, 0x0EFCxx</li><li>• cinvlanid: 2-byte VLAN_ID [0-4095]</li></ul> |

### Example

```
hbacmd setfipparam 10:00:00:00:c9:5b:3a:6d fcmap 0x0efc99
```

## iSCSI Commands

The commands in this section support the iSCSI interface in the OCM CLI.

**Note:** iSCSI commands are supported only on OneConnect iSCSI ports.

The MAC address <MAC\_Address> of the UCNA port must be passed to each command as the first argument.

Some commands require values to be set in a format similar to: “option\_name=value”. Type the full option name or the abbreviated option name (shown in Table 5-2, Option Names) and enter the value. The abbreviations are not case sensitive.

**Table 5-2** Option Names

| Option Name     | Abbreviation | Example              |
|-----------------|--------------|----------------------|
| Auth            | au           | au=1                 |
| DataDigest      | dd           | dd=1                 |
| DHCP            | dh           | dh=1                 |
| HeaderDigest    | hd           | hd=1                 |
| ImmediateData   | id           | id=1                 |
| Initiator_Alias | ia           | ia="initiator_alias" |
| Initiator_Name  | in           | in="initiator_name"  |
| Priority        | pr           | pr=1                 |
| VLAN_ENABLED    | ve           | ve=1                 |
| VLAN_ID         | vi           | vi=1                 |

## AddARPTableEntry

This command adds an ARP table entry.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
AddARPTableEntry <MAC_Address> <Dest_MAC_Address> <Dest_IP_Address>
```

### Parameters

`MAC_Address` The MAC address of the UCNA port.  
`Dest_MAC_Address` The destination MAC address to add to the ARP table.  
`Dest_IP_Address` The destination IP address to add to the ARP table.

## AddRouteTableEntry

This command adds a new route table entry to the route table of the specified port.

### Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
AddRouteTableEntry <MAC_Address> <Dest_IP_Address> <Subnet_Mask>
<Gateway>
```

## Parameters

|                 |                                                   |
|-----------------|---------------------------------------------------|
| MAC_Address     | MAC address of the UCNA port.                     |
| Dest_IP_Address | Destination IP address to add to the route table. |
| Subnet_Mask     | Subnet Mask to add to the route table.            |
| Gateway         | Gateway to add to the route table.                |

## AddTarget

This command adds a target to the list of targets seen by the initiator and logs into the target once it has been successfully created. This command requires that you specify a valid target IP <Target\_IP>, port number <Port>, and iSCSI name <iscsi\_target\_name>. If you do not specify the remaining options, these options are set to their default values.

When you set the authentication method <Auth> to a value other than 0, you must set additional parameters. Each string should be enclosed in quotations to avoid mishandling by the Windows, Linux, Solaris, or VMware shell's parser.

- If you set the authentication method to "One-Way CHAP" (<Auth>=1), you must also specify the "Target CHAP Name" and "Target Secret." For example:

```
hbacmd AddTarget 00-11-22-33-44-55 192.168.1.1 8000
iscsitarget Auth=1 "TgtCHAPName" "TargetSecret1"
```

- If you set the authentication method to "Mutual CHAP" (<Auth>=2), you must specify all four values. For example:

```
hbacmd AddTarget 00-11-22-33-44-55 192.168.1.1 8000
iscsitarget Auth=1 "TgtCHAPName" "TargetSecret1"
"InitCHAPName" "InitialSecret1"
```

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
AddTarget <MAC_Address> <Target_IP> <Port> <iscsi_target_name>
[ImmediateData=<0|1>] [HeaderDigest=<0|1>] [DataDigest=<0|1>]
[Boot=<0|1>] [Login=<0|1>] [Auth=<0|1|2> "TgtCHAPName" "TgtSecret"
"InitCHAPName" "InitSecret"]
```

## Parameters

|                   |                                                                 |
|-------------------|-----------------------------------------------------------------|
| MAC_Address       | The MAC address of the UCNA port.                               |
| Target_IP         | IP address of the target portal.                                |
| Port              | Port number of the target portal (value: 102-65535).            |
| iscsi_target_name | Target's iSCSI name enclosed in quotes (string length: 11-255). |

|               |                                                                                                                                                                                                                                     |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ImmediateData | 0 = No<br>1 = Yes (default)                                                                                                                                                                                                         |
| HeaderDigest  | 0 = None (default)<br>1 = CRC32C                                                                                                                                                                                                    |
| DataDigest    | 0 = None (default)<br>1 = CRC32C                                                                                                                                                                                                    |
| Boot          | This optional parameter specifies whether the added target is a boot device:<br><br>0 = Added target is not a boot device.<br>1 = Added target is a boot device.                                                                    |
| Login         | This optional parameter specifies whether to log in to the target after it has been added:<br><br>0 = Do not log in to the target.<br>1 = Specify log in to the target.<br><br>If the Login parameter is omitted, the default is 1. |
| Auth          | 0 = None (default)<br>1 = One-Way CHAP<br>2 = Mutual CHAP                                                                                                                                                                           |
| TgtCHAPName   | Target CHAP name enclosed in quotes (string length: 1-256).                                                                                                                                                                         |
| TgtSecret     | Target Secret enclosed in quotes (string length: 12-16).                                                                                                                                                                            |
| InitCHAPName  | Initiator CHAP name enclosed in quotes (string length: 1-256).                                                                                                                                                                      |
| InitSecret    | Initiator Secret enclosed in quotes (string length: 12-16).                                                                                                                                                                         |

## AddTargetPortal

This command adds a new SendTarget Portal for the initiator and runs a target discovery once the SendTarget Portal is created. This command requires that you specify a valid portal IP address <Target\_IP> and a valid port number <Port>. If you do not specify the remaining options, these options are set to their default values.

When you set the authentication method <Auth> to a value other than 0, you must set additional parameters. Each string should be enclosed in quotations to avoid mishandling by the Windows, Linux, Solaris, or VMware shell's parser.

- If you set the authentication method to "One-Way CHAP" (<Auth>=1), you must also specify the "Target CHAP Name" and "Target Secret." For example:
 

```
hbacmd AddTargetPortal 00-11-22-33-44-55 10.0.0.1 8000 Auth=1
 "TgtCHAPName" "TargetSecret1"
```
- If you set the authentication method to "Mutual CHAP" (<Auth>=2), you must specify all four values. For example:
 

```
hbacmd AddTargetPortal 00-11-22-33-44-55 10.0.0.1 8000 Auth=2
 "TgtChapName" "TargetSecret1" "InitCHAPName" "InitialSecret1"
```

You must specify either the TSIH value or the ISID qualifier. If you specify the ISID qualifier, you must also specify the Target's ID address.



## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
AddTargetPortal <MAC_Address> <Target_IP> <Port> [ImmediateData=<0|1>]
[HeaderDigest=<0|1>] [DataDigest=<0|1>] [Auth=<0|1|2> "TgtCHAPName"
"TgtSecret" "InitCHAPName" "InitSecret"]
```

## Parameters

|               |                                                                |
|---------------|----------------------------------------------------------------|
| MAC_Address   | The MAC address of the UCNA port.                              |
| Target_IP     | IP address of the target portal.                               |
| Port          | Port number of the target portal (value: 1024-65535).          |
| ImmediateData | 0 = No<br>1 = Yes (default)                                    |
| HeaderDigest  | 0 = None (default)<br>1 = CRC32C                               |
| DataDigest    | 0 = None (default)<br>1 = CRC32C                               |
| Auth          | 0 = None (default)<br>1 = One-Way CHAP<br>2 = Mutual CHAP      |
| TgtCHAPName   | Target CHAP name enclosed in quotes (string length: 1-256).    |
| TgtSecret     | Target Secret enclosed in quotes (string length: 12-16).       |
| InitCHAPName  | Initiator CHAP name enclosed in quotes (string length: 1-256). |
| InitSecret    | Initiator Secret enclosed in quotes (string length: 12-16).    |

## CleariSNSServer

This command clears the configured iSNS server and disables iSNS target discovery. If no iSNS server is currently configured, this command does nothing.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
CleariSNSServer <MAC_Address>
```

## Parameters

|             |                                   |
|-------------|-----------------------------------|
| MAC_Address | The MAC address of the UCNA port. |
|-------------|-----------------------------------|

## DelARPTableEntry

This command removes an ARP table entry.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
DelARPTableEntry <MAC_Address> <Dest_MAC_Address> <Dest_IP_Address>
```

### Parameters

|                  |                                                           |
|------------------|-----------------------------------------------------------|
| MAC_Address      | The MAC address of the UCNA port.                         |
| Dest_MAC_Address | The destination MAC address to remove from the ARP table. |
| Dest_IP_Address  | The destination IP address to remove from the ARP table.  |

## DelRouteTableEntry

This command removes a route table entry from the specified port.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
DelRouteTableEntry <MAC_Address> <Dest_IP_Address> <Subnet_Mask>
<Gateway>
```

### Parameters

|                 |                                                        |
|-----------------|--------------------------------------------------------|
| MAC_Address     | MAC address of the UCNA port.                          |
| Dest_IP_Address | Destination IP address to delete from the route table. |
| Subnet_Mask     | Subnet Mask to delete from the route table.            |
| Gateway         | Gateway to delete from the route table.                |

## DiscoveriSNSServer

This command discovers an iSNS server address through DHCP. If the DHCP server returns an iSNS server address, it replaces the configured iSNS server and can be viewed using the ShowiSNSServer command.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
DiscoveriSNSServer <MAC_Address>
```

**Parameters**

`MAC_Address`      The MAC address of the UCNA port.

**ExportiSCSI**

This command outputs iSCSI target information in XML format. The output can be redirected to a specified file.

**Supported By**

Linux, Solaris, and Windows

**Syntax**

```
ExportiSCSI
```

**Example**

In this example, the command exports all the iSCSI targets of all the adapters on the host. The output is re-directed to the file "targets.xml".

```
hbacmd exportiscsi > targets.xml
```

**GetInitiatorProperties**

This command shows all the initiator login options for the specified port.

These properties are set as the target portal's login properties to be used when discovering the targets on the target portal. The discovered targets inherit these properties.

**Supported By**

Linux, Solaris, VMware ESX, and Windows

**Syntax**

```
GetInitiatorProperties <MAC_Address>
```

**Parameters**

`MAC_Address`      The MAC address of the UCNA port.

**GetiSCSILuns**

This command shows all the LUNs and their information for a specified target. The command gathers the information from the iSCSI target indicated by the `<iscsi_target_name>` parameter.

**Supported By**

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetiSCSILuns <MAC_Address> <iscsi_target_name>
```

### Parameters

`MAC_Address` The MAC address of the UCNA port.  
`iscsi_target_name` Target's iSCSI name enclosed in quotes (string length: 11-255)

## GetiSCSIPortStats

This command shows all the port statistics for a specified port.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetiSCSIPortStats <MAC_Address>
```

### Parameters

`MAC_Address` The MAC address of the UCNA port.

## GetNetworkConfiguration

This command lists a port's TCP/IP information.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetNetworkConfiguration <MAC_Address>
```

### Parameters

`MAC_Address` The MAC address of the UCNA port.

## GetSessionInfo

This command lists all session information for a specified session.

You must specify the `<iscsi_target_name>` and either the `<TSIH>` of the session or the session's ISID Qualifier `<ISID_Qual>` and the target's IP address `<Target_IP>`. These parameters tell the command to gather the information from the specified target and session. You can find the TSIH and ISID qualifier by running the `ListSessions` command.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
GetSessionInfo <MAC_Address> <iscsi_target_name> <TSIH | <ISID_Qual
Target_IP>>
```

## Parameters

|                   |                                                                 |
|-------------------|-----------------------------------------------------------------|
| MAC_Address       | The MAC address of the UCNA port.                               |
| iscsi_target_name | Target's iSCSI name enclosed in quotes (string length: 11–255). |
| TSIH              | TSIH value of the session (value: 1–65535).                     |
| ISID_Qual         | ISID qualifier of the session (value: 0–65535).                 |
| Target_IP         | The Target's IP address.                                        |

## ImportiSCSI

This command imports iSCSI targets from a file to the iSCSI ports on the host.

## Supported By

Linux, Solaris, and Windows

## Syntax

```
ImportiSCSI <Import_File> [clean]
```

## Parameters

|             |                                                                                                                                  |
|-------------|----------------------------------------------------------------------------------------------------------------------------------|
| Import_File | The name of XML file containing import information that was generated by the ExportiSCSI command (see “ExportiSCSI” on page 91). |
| clean       | Erases entire iSCSI configuration on all iSCSI ports before importing targets.                                                   |

**Note:** This command fails if the system is booted from an iSCSI target.

## Example

In this example, the command imports the iSCSI targets found in the targets.xml file to the iSCSI ports found on the host, and erases the iSCSI configuration (including targets) of all iSCSI ports on these host before importing the targets.

```
hbacmd importiscsi targets.xml clean
```

The example output:

```
All existing targets have been removed.
Added target iqn.2006-01.com.openfiler:target121-000.on.port.00-00-c9-be-1a-24
Added target iqn.2006-01.com.openfiler:target121-001.on.port.00-00-c9-be-1a-24
```

```
Added target iqn.2006-01.com.openfiler:target122-000.on.port.00-00-c9-2f-45-1b
```

```
Added target iqn.2006-01.com.openfiler:target122-001.on.port.00-00-c9-2f-45-1b
```

## iSCSIPing

This command issues ICMP echo requests to a target.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
iSCSIPing <MAC_Address> <IP_Address>
```

### Parameters

**MAC\_Address**      The MAC address of the UCNA port.

**IP\_Address**        IP address of target to send ICMP echo request.

## ListSessions

This command lists all the sessions on a specified target. The command gathers the information from the iSCSI target indicated by the <iscsi\_target\_name> parameter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ListSessions <MAC_Address> <iscsi_target_name>
```

### Parameters

**MAC\_Address**      The MAC address of the UCNA port.

**iscsi\_target\_name**    Target's iSCSI name enclosed in quotes. The string length is 11-255.

## RemoveTarget

This command removes the target with the specified iSCSI target name <iscsi\_target\_name>.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
RemoveTarget <MAC_Address> <iscsi_target_name>
```

### Parameters

|                   |                                                                      |
|-------------------|----------------------------------------------------------------------|
| MAC_Address       | The MAC address of the UCNA port.                                    |
| iscsi_target_name | Target's iSCSI name enclosed in quotes. The string length is 11-255. |

## RemoveTargetPortal

This command removes the SendTarget Portal containing the target IP <Target\_IP> and the port <Port> from the list of portals for the specified initiator.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
RemoveTargetPortal <MAC_Address> <Target_IP> <Port>
```

### Parameters

|             |                                                                           |
|-------------|---------------------------------------------------------------------------|
| MAC_Address | The MAC address of the UCNA port.                                         |
| Target_IP   | The target's IP address.                                                  |
| Port        | The port number of the target portal. The possible values are 1024-65535. |

## SetBootTargetSession

This command enables and disables a iSCSI target's session as a boot session. If a session is enabled as a boot session, and when the system reboots, it will attempt to boot from that target.

Depending on whether the target is logged in, there are two different ways to specify the session. If the target is logged in, use the <TSIH> parameter. If the target is not logged in, use the <ISID\_Qual Target\_IP> parameter.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetBootTargetSession <MAC Address> <Target> <TSIH | <ISID_Qual
Target_IP>> <0|1>
```

### Parameters

|             |                                                                 |
|-------------|-----------------------------------------------------------------|
| MAC_Address | The MAC address of the desired iSCSI port.                      |
| Target      | Specifies the iSCSI name of the desired iSCSI target.           |
| TSIH        | TSIH value of the session. The possible values are 1-65535.     |
| ISID_Qual   | ISID qualifier of the session. The possible values are 0-65535. |

0|1                    Specifies the state of the BootProperty for the target:  
                          0 = Disabled  
                          1 = Enabled

## SetInitiatorProperties

This command sets the initiator properties for the specified port. It allows you to specify an initiator name <Initiator\_Name> and an initiator alias <Initiator\_Alias>. If you opt not to specify these fields, a default iSCSI name is assigned.

Except for the <Initiator\_Name> and <Initiator\_Alias> properties, these properties are set as the target portal's login properties to be used when discovering the targets on the target portal. The targets inherit the target portal's properties when they are discovered. The discovered target's login properties can be changed using the SetTargetProperties command.

When you set the authentication method <Auth> to a value other than 0, you must set additional parameters. Each string should be enclosed in quotations to avoid mishandling by the Windows, Linux, Solaris, or VMware shell's parser. Additionally, these properties are used for iSNS target discovery to set the discovered target's login properties.

- If you set the authentication method to "One-Way CHAP" (<Auth>=1), you must also specify the "Target CHAP Name" and "Target Secret." For example:

```
hbacmd SetInitiatorProperties 00-11-22-33-44-55 Auth=1
 "TgtChapName" "TargetSecret1"
```

- If you set the authentication method to "Mutual CHAP" (<Auth>=2), you must specify all four values. For example:

```
hbacmd SetInitiatorProperties 00-11-22-33-44-55 Auth=2
 "TgtChapName" "TargetSecret1" "InitCHAPName" "InitialSecret1"
```

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetInitiatorProperties <MAC_Address> [Initiator_Name="initiator_name"]
[Initiator_Alias="initiator_alias"] [ImmediateData=<0|1>]
[HeaderDigest=<0|1>] [DataDigest=<0|1>] [Auth=<0|1|2> "TgtCHAPName"
"TgtSecret" "InitCHAPName" "InitSecret"]
```

### Parameters

|                 |                                                                 |
|-----------------|-----------------------------------------------------------------|
| MAC_Address     | The MAC address of the UCNA port.                               |
| Initiator_Name  | Initiator iSCSI name enclosed in quotes (string length: 1-224). |
| Initiator_Alias | Initiator iSCSI alias enclosed in quotes (string length: 0-32). |
| ImmediateData   | 0 = No<br>1 = Yes (default)                                     |



|              |                                                                |
|--------------|----------------------------------------------------------------|
| HeaderDigest | 0 = None (default)<br>1 = CRC32C                               |
| DataDigest   | 0 = None (default)<br>1 = CRC32C                               |
| Auth         | 0 = None (default)<br>1 = One-Way CHAP<br>2 = Mutual CHAP      |
| TgtCHAPNam   | Target CHAP name enclosed in quotes (string length: 1-256).    |
| TgtSecret    | Target Secret enclosed in quotes (string length: 12-16).       |
| InitCHAPName | Initiator CHAP name enclosed in quotes (string length: 1-256). |
| InitSecret   | Initiator Secret enclosed in quotes (string length: 12-16).    |

## SetiSCSIBoot

This command defines whether a specific iSCSI function's Boot ROM is active.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetiSCSIBoot <MAC_Address> <0|1>
```

### Parameters

|             |                                                                    |
|-------------|--------------------------------------------------------------------|
| MAC_Address | The MAC address of the desired iSCSI port.                         |
| 0 1         | Specifies the iSCSI boot ROM state:<br>0 = Disabled<br>1 = Enabled |

## SetNetworkConfiguration

This command sets the TCP/IP configuration on a specified port. The required fields for this command depend upon the values set for <DHCP> and <VLAN\_ENABLED>.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetNetworkConfiguration <MAC_Address> <VLAN_ENABLED=<0|1>
[<VLAN_ID=<0-4096>> <Priority=<0-7>>] <DHCP=<0|1>> [<IP_Address>
<Subnet_Mask> [Gateway]]
```

### Parameters

|             |                                   |
|-------------|-----------------------------------|
| MAC_Address | The MAC address of the UCNA port. |
|-------------|-----------------------------------|

|              |                                                              |
|--------------|--------------------------------------------------------------|
| VLAN_ENABLED | 0 = Disabled<br>1 = Enabled                                  |
| VLAN_ID      | VLAN ID of the interface. The possible values are 0-4095.    |
| Priority     | VLAN priority of the interface. The possible values are 0-7. |
| DHCP         | 0 = Disabled<br>1 = Enabled                                  |
| IP_Address   | New IP address. For example: 10.192.1.1.                     |
| Subnet_Mask  | Subnet Mask. For example: 255.255.255.0.                     |
| Gateway      | Gateway. For example: 10.192.1.1.                            |

**Note:** VLAN\_ID and Priority are required only if VLAN\_ENABLED is enabled; otherwise, these values should be omitted.

**Note:** IP\_Address and Subnet\_Mask are required only if DHCP is disabled; otherwise these values should be omitted.

## SetTargetLoginProperties

This command sets the login and authentication properties associated with a specific target. This command requires that you specify a valid iSCSI target name <iscsi\_target\_name>. If you do not specify some of the remaining properties, these options are set to their default values. However, if no properties are changed, an error is generated. You must change at least one property for this command to return successfully.

When you set the authentication method <Auth> to a value other than 0, you must set additional parameters. Each string should be enclosed in quotations to avoid mishandling by the Windows, Linux, Solaris, or VMware shell's parser.

- If you set the authentication method to "One-Way CHAP" (<Auth>=1), you must also specify the "Target CHAP Name" and "Target Secret." For example:

```
hbacmd SetTargetLoginProperties 00-11-22-33-44-55 iscsitarget
Auth=1 "TgtCHAPName" "TargetSecret1"
```

- If you set the authentication method to "Mutual CHAP" (<Auth>=2), you must specify all four values. For example:

```
hbacmd SetTargetLoginProperties 00-11-22-33-44-55 iscsitarget
Auth=2 "TgtChapName" "TargetSecret1" "InitCHAPName"
"InitialSecret1"
```

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetTargetLoginProperties <MAC_Address> <iscsi_target_name>
[ImmediateData=<0|1>] [HeaderDigest=<0|1>] [DataDigest=<0|1>]
[Auth=<0|1|2> "TgtCHAPName" "TgtSecret" "InitCHAPName" "InitSecret"]
```

## Parameters

|                   |                                                                 |
|-------------------|-----------------------------------------------------------------|
| MAC_Address       | The MAC address of the UCNA port.                               |
| iscsi_target_name | Target's iSCSI name enclosed in quotes (string length: 11-255). |
| ImmediateData     | 0 = No<br>1 = Yes (default)                                     |
| HeaderDigest      | 0 = None (default)<br>1 = CRC32C                                |
| DataDigest        | 0 = None (default)<br>1 = CRC32C                                |
| Auth              | 0 = None (default)<br>1 = One-Way CHAP<br>2 = Mutual CHAP       |
| TgtCHAPNam        | Target CHAP name enclosed in quotes (string length: 1-256).     |
| TgtSecret         | Target Secret enclosed in quotes (string length: 12-16).        |
| InitCHAPName      | Initiator CHAP name enclosed in quotes (string length: 1-256).  |
| InitSecret        | Initiator Secret enclosed in quotes (string length: 12-16).     |

## SetTargetProperties

This command sets the ETO value of a target.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SetTargetProperties <MAC_Address> <iscsi_target_name> <ETO>
```

### Parameters

|                   |                                                                                                                                                                                                         |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MAC_Address       | The MAC address of the UCNA port.                                                                                                                                                                       |
| iscsi_target_name | Target's iSCSI name enclosed in quotes (string length: 11-255)                                                                                                                                          |
| ETO               | The extended timeout option for the target: <ul style="list-style-type: none"> <li>For Windows, valid values are 0-3600.</li> <li>For Linux, Solaris, and VMware ESX, valid values are 0-30.</li> </ul> |

## SetTPLoginProperties

This command sets a target portal's login properties. This command requires that you specify a valid Target IP <Target\_IP> and Port <Port>. However, if you specify no options other than the Target IP and Port, no changes are made. You must change at least one of the optional parameters for this command to make any changes to the target portal's login properties.

These properties are used when discovering the targets on the target portal. The targets inherit the target portal's properties when they are discovered. Targets already discovered do not inherit the updated properties, only newly discovered targets inherit the properties.

When you set the authentication method <Auth> to a value other than 0, you must set additional parameters. Each string should be enclosed in quotations to avoid mishandling by the Windows, Linux, Solaris, or VMware shell's parser.

- If you set the authentication method to "One-Way CHAP" (<Auth>=1), you must also specify the "Target CHAP Name" and "Target Secret." For example:

```
hbacmd SetTPLoginProperties 00-11-22-33-44-55 10.192.1.1 5050
Auth=1 "TgtChapName" "TargetSecret1"
```

- If you set the authentication method to "Mutual CHAP" (<Auth>=2), you must specify all four values. For example:

```
hbacmd SetTPLoginProperties 00-11-22-33-44-55 10.192.1.1 5050
Auth=2 "TgtChapName" "TargetSecret1" "InitCHAPName"
"InitialSecret1"
```

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
SetTPLoginProperties <MAC_Address> <Target_IP> <Port>
[ImmediateData=<0|1>] [HeaderDigest=<0|1>] [DataDigest=<0|1>]
[Auth=<0|1|2> TgtCHAPName TgtSecret InitCHAPName InitSecret]
```

## Parameters

|               |                                                                    |
|---------------|--------------------------------------------------------------------|
| MAC_Address   | The MAC address of the UCNA port.                                  |
| Target_IP     | The IP address of the target portal.                               |
| Port          | The port number of the target portal (value: 1024–65535).          |
| ImmediateData | 0 = No<br>1 = Yes (default)                                        |
| HeaderDigest  | 0 = None (default)<br>1 = CRC32C                                   |
| DataDigest    | 0 = None (default)<br>1 = CRC32C                                   |
| Auth          | 0 = None (default)<br>1 = One-Way CHAP<br>2 = Mutual CHAP          |
| TgtCHAPName   | The Target CHAP name enclosed in quotes (string length: 1–256).    |
| TgtSecret     | The Target Secret enclosed in quotes (string length: 12–16).       |
| InitCHAPName  | The Initiator CHAP name enclosed in quotes (string length: 1–256). |
| InitSecret    | The Initiator Secret enclosed in quotes (string length: 12–16).    |

## ShowARPTable

This command shows the current ARP table for the specified port.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ShowARPTable <MAC_Address>
```

### Parameters

`MAC_Address`      The MAC address of the UCNA port.

## ShowiSNSServer

This command shows the currently configured Internet Storage Name Server. This command also indicates whether or not iSNS discovery is enabled.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ShowiSNSServer <MAC_Address>
```

### Parameters

`MAC_Address`      The MAC address of the UCNA port.

## ShowRouteTable

This command shows the route table for a specific port.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ShowRouteTable <MAC_Address>
```

### Parameters

`MAC_Address`      The MAC address of the UCNA port.

### Example

```
hbacmd h=10.192.203.240 showroutetableentry 00-00-c9-a0-ce-77
```

## ShowTarget

This command shows the properties for a specified target. If you do not specify the iSCSI target name <iscsi\_target\_name>, all targets and their associated properties return. If you specify <refreshtargets> in place of the <iscsi\_target\_name>, all targets are refreshed before returning the information. If you do not provide a <iscsi\_target\_name> or <refreshtargets> value, only the targets from the last refresh are displayed.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ShowTarget <MAC_Address> [<iscsi_target_name> | refreshtargets]
```

**Note:** Only one command option can be specified with this command. That is, you can only specify either <iscsi\_target\_name> or <refreshtargets>.

### Parameters

|                   |                                                                     |
|-------------------|---------------------------------------------------------------------|
| MAC_Address       | The MAC address of the UCNA port.                                   |
| iscsi_target_name | The target's iSCSI name enclosed in quotes (string length: 11-255). |
| refreshtargets    | Refresh all targets before displaying the information.              |

## ShowTargetPortal

This command shows the properties for a specified SendTarget Portal. If the <Target\_IP> and <Port> are not specified, all SendTarget Portals and their associated properties return.

### Supported By

Linux, Solaris, and Windows

### Syntax

```
ShowTargetPortal <MAC_Address> [<Target_IP> <Port>]
```

### Parameters

|             |                                   |
|-------------|-----------------------------------|
| MAC_Address | The MAC address of the UCNA port. |
| Target_IP   | IP address of the target portal.  |
| Port        | Port number of the target portal. |

## TargetLogin

This command logs in to a target. The iSCSI target name <iscsi\_target\_name> is the only mandatory option. The <target\_portal> and <port> information are optional and

if they are not provided a default target portal is used. If you do not specify the remaining options, these options are set to their default values.

When you set the authentication method <Auth> to a value other than 0, you must set additional parameters. Each string should be enclosed in quotations to avoid mishandling by the Windows, Linux, Solaris, or VMware shell's parser.

- If you set the authentication method to "One-Way CHAP" (<Auth>=1), you must also specify the "Target CHAP Name" and "Target Secret." For example:

```
hbacmd TargetLogin 00-11-22-33-44-55 iscsitarget Auth=1
 "TgtChapName" "TargetSecret1"
```

- If you set the authentication method to "Mutual CHAP" (<Auth>=2), you must specify all four values. For example:

```
hbacmd TargetLogin 00-11-22-33-44-55 iscsitarget Auth=2
 "TgtChapName" "TargetSecret1" "InitCHAPName" "InitialSecret1"
```

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
TargetLogin <MAC_Address> <iscsi_target_name> [target_portal_ip
<port>] [ImmediateData=<0|1>] [HeaderDigest=<0|1>] [DataDigest=<0|1>]
[Auth=<0|1|2> "TgtCHAPName" "TgtSecret" "InitCHAPName" "InitSecret"]
```

## Parameters

|                   |                                                                           |
|-------------------|---------------------------------------------------------------------------|
| MAC_Address       | The MAC address of the UCNA port.                                         |
| iscsi_target_name | The target's iSCSI name enclosed in quotes (string length: 11-255).       |
| Port              | The port number of the target portal. The possible values are 1024-65535. |
| ImmediateData     | 0 = No<br>1 = Yes (default)                                               |
| HeaderDigest      | 0 = None (default)<br>1 = CRC32C                                          |
| DataDigest        | 0 = None (default)<br>1 = CRC32C                                          |
| Auth              | 0 = None (default)<br>1 = One-Way CHAP<br>2 = Mutual CHAP                 |
| TgtCHAPName       | The Target CHAP name enclosed in quotes (string length: 1-255).           |
| TgtSecret         | The Target Secret enclosed in quotes (string length: 12-16).              |
| InitCHAPName      | The Initiator CHAP name enclosed in quotes (string length: 1-255).        |
| InitSecret        | The Initiator Secret enclosed in quotes (string length: 12-16).           |

## TargetLogout

This command logs out of a target.

You must specify the iSCSI target name <iscsi\_target\_name> and either the TSIH <TSIH> of the session, or the session's ISID Qualifier <ISID\_Qual> and the target's IP address <Target\_IP>.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
TargetLogout <MAC_Address> <iscsi_target_name> <TSIH | <ISID_Qual
Target_IP>>
```

### Parameters

|                   |                                                                     |
|-------------------|---------------------------------------------------------------------|
| MAC_Address       | The MAC address of the UCNA port.                                   |
| iscsi_target_name | The target's iSCSI name enclosed in quotes (string length: 11-255). |
| TSIH              | The TSIH value of the session. The possible values are 1-65535.     |
| ISID_Qual         | The ISID qualifier of the session. The possible values are 0-65535. |
| Target_IP         | The target's IP address.                                            |

## UpdateiSNSServer

This command updates the configured iSNS server. This command requires the server IP <Server\_IP> and port number <Port> of the iSNS server to be available to respond to the iSNS requests.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
UpdateiSNSServer <MAC_Address> <Server_IP> <Port>
```

### Parameters

|             |                                                                  |
|-------------|------------------------------------------------------------------|
| MAC_Address | The MAC address of the UCNA port.                                |
| Server_IP   | IP address of the iSNS server to configure.                      |
| Port        | Port number of the iSNS server to configure (value: 1024-65535). |



## LUN Masking Commands

### Notes:

- Supported for FC/FCoE ports only.
- Linux does not support the GetLunUnMaskByHBA, GetLunUnMaskByTarget, and SetLunMask commands.
- Solaris and VMware ESX do not support the GetLunUnMaskbyHBA, GetLunUnMaskbyTarget, RescanLuns, and SetLunMask commands.

### GetLunList

This command queries for the presence of any masked LUNs.

#### Supported By

Linux, Solaris, and Windows

#### Syntax

```
GetLunList <HBA WWPN> <Target WWPN> <Option>
```

#### Parameters

|             |                                                                                     |
|-------------|-------------------------------------------------------------------------------------|
| HBA WWPN    | The WWPN of the adapter.                                                            |
| Target WWPN | The WWPN of the target.                                                             |
| Option      | 0 = Get information from the driver.<br>1 = Get information from the configuration. |

### GetLunUnMaskByHBA

This command queries for the presence of any unmasked LUNs by adapter.

#### Supported By

Solaris and Windows

#### Syntax

```
GetLunUnMaskByHBA <HBA WWPN> <Option>
```

#### Parameters

|          |                                                                                     |
|----------|-------------------------------------------------------------------------------------|
| HBA WWPN | The WWPN of the adapter.                                                            |
| Option   | 0 = Get information from the driver.<br>1 = Get information from the configuration. |

## GetLunUnMaskByTarget

This command queries for any unmasked LUNs by target.

### Supported By

Solaris and Windows

### Syntax

```
GetLunUnMaskByTarget <HBA WWPN> <Target WWPN> <Option>
```

### Parameters

|             |                                                                                     |
|-------------|-------------------------------------------------------------------------------------|
| HBA WWPN    | The WWPN of the adapter.                                                            |
| Target WWPN | The WWPN of the target.                                                             |
| Option      | 0 = Get information from the driver.<br>1 = Get information from the configuration. |

## RescanLuns

This command rescans LUNs to find any new LUNs.

### Supported By

Linux, Solaris, and Windows

### Syntax

```
RescanLuns <HBA WWPN> <Target WWPN>
```

### Parameters

|             |                          |
|-------------|--------------------------|
| HBA WWPN    | The WWPN of the adapter. |
| Target WWPN | The WWPN of the target.  |

## SetLunMask

This command masks the specified LUNs.

### Supported By

Solaris and Windows

### Syntax

```
SetLunMask <HBA WWPN> <Target WWPN> <Option> <Lun> <LunCount> <MaskOp>
```

### Parameters

|             |                          |
|-------------|--------------------------|
| HBA WWPN    | The WWPN of the adapter. |
| Target WWPN | The WWPN of the target.  |

|          |                                                                                                                                                  |
|----------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| Option   | 0 = Get information from the driver.<br>1 = Get information from the configuration (make persistent).<br>2 = Send information to both.           |
| Lun      | The starting LUN number.                                                                                                                         |
| LunCount | The number of LUNs.                                                                                                                              |
| MaskOp   | A = Mask LUN<br>B = Clear unmask target level<br>C = Clear unmask HBA level<br>D = Unmask LUN<br>E = Unmask target level<br>F = Unmask HBA level |

## Miscellaneous Commands

### AddHost

This command adds a host to the hosts file for TCP/IP management in the OneCommand Manager GUI. The adapters for these hosts are also presented by the ListHBAs command.

#### Supported By

Linux, Solaris, VMware ESX, and Windows

#### Syntax

For the RM interface:

```
hbacmd AddHost host_address
```

**Note:** The “h=” option (for specifying an optional IP address or host name) after “hbacmd” is not available for the AddHost command.

For VMware ESX/ESXi using the CIM interface:

```
hbacmd m=cim [u=<username>] [p=<password>] [n=<namespace>] addhost
<IP_Address>
```

If the username, password, and namespace are not specified, see “Default CIM Credentials” on page 34.

#### Parameters

|              |                                                                  |
|--------------|------------------------------------------------------------------|
| host_address | The IP address (using the IPv4 or IPv6 format) or the host name. |
| IP_Address   | The IP address of the host.                                      |

### CnaClearEventLog

**Note:** Supported for OneConnect adapters only.

This command clears the UCNA event log specified by the WWPN or MAC address.

### Supported By

Linux, VMware ESX, and Windows

### Syntax

```
CnaClearEventLog <WWPN|MAC>
```

### Parameters

**WWPN** The WWPN of the UCNA FCoE port.  
**MAC** The MAC address of the NIC or iSCSI port of the UCNA.

## CnaGetEventLog

**Note:** Supported for OneConnect adapters only.

This command shows the UCNA event log specified by the WWPN or MAC address.

### Supported By

Linux, VMware ESX, and Windows

### Syntax

```
CnaGetEventLog <WWPN|MAC>
```

### Parameters

**WWPN** The WWPN of the adapter port.  
**MAC** The MAC address of the NIC or iSCSI port.

## Download

Loads the firmware image to the FC or UCNA port specified by the WWPN or MAC address.

### Notes:

- For 16-Gb HBA firmware downloads, OneCommand Manager only accepts “.grp” files.
- For OneConnect and 16-Gb HBAs, while the WWPN or MAC address is used to identify the adapter, the updated firmware applies to all ports on that adapter. It is not necessary to download the firmware on all the adapter ports of a OneConnect adapter or a 16-Gb HBA.

### Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

Download <WWPN|MAC> <FileName>

## Parameters

**WWPN** The WWPN of the adapter port.  
**MAC** The MAC address of the NIC or iSCSI port.  
**FileName** The name and location of the firmware image (any file accessible to the CLI client).

## ExportSANInfo

For reporting purposes, this command captures the SAN information in “.xml” for XML-formatted files and “.csv” for CSV-formatted files. Since this command can output a large amount of information, Emulex recommends that you re-direct the output to a file.

**Note:** Due to the amount of information that must be obtained and reported, this command can take a long time on large SAN configurations.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

ExportSANInfo [format]

**Note:** The “h=” option (for specifying an optional IP address or host name) after “hbacmd” is not available for the ExportSANInfo command.

## Parameters

**format** An optional parameter that specifies the format of the adapter information:

- csv
- xml

**Note:** Leaving the <format> blank shows the data in xml format (default).

## GetCimCred

This command shows the default credentials set for the CIM client.

**Note:** The password is encrypted.

## Supported By

Windows

**Syntax**

GetCimCred

**Parameters**

None.

**GetElxSecInfo**

This command shows the version of the ElxSec system.

**Supported By**

Windows and Linux

**Syntax**

GetElxSecInfo

**Parameters**

None

**GetQoSInfo**

This command shows the QoS information for a specified NIC port.

**Supported By**

Linux, Solaris, VMware ESX, and Windows

**Syntax**

GetQoSInfo <MAC\_Address>

**Parameters**

**h**            The IP address of name of the host.  
**WWPN**        The WWPN of the adapter port.  
**MAC**         The MAC address of the NIC or iSCSI port.

**Example**

```
C:\Program Files\emulex\Util\OCManager>hbacmd h=10.192.203.154 m=cim
u=root p=Swamiji001 n=root/emulex getqosinfo 00-00-c9-93-2f-d6
```

**GetVPD**

This command shows the port's VPD.

**Supported By**

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
GetVPD <WWPN|MAC>
```

## Parameters

**WWPN**        The WWPN of the adapter.

**MAC**         The MAC address of the NIC or iSCSI port.

## ListHBAs

This command shows a list of the manageable Emulex adapters found by local, remote in-band (FC), and remote out-of-band (TCP/IP) discovery. For a NIC-only or iSCSI adapter, the MAC address is displayed rather than the Port WWN. The Node WWN and Fabric WWN are not displayed. The type of information listed may vary according to the adapter model.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
listhbas [local] [m=model] [pt=type] [down]
```

## Parameters

**local**        Only display local adapters.

**m=model**     Model filter. Append \* to the end of the model name for a wildcard match.  
For example:  
              LP9\*

**pt=type**     The port type filter. Valid types are NIC, iSCSI, FC, and FCoE.

**down**        Display only the NIC functions of inoperative OneConnect UCNAs on the local system.

## RemoveHost

This command removes a host from the hosts file use for TCP/IP management in the OneCommand Manager application GUI. The <host\_address> can be an IP address, using the IPv4 or IPv6 format, or a host name.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

For the RM interface:

```
hbacmd RemoveHost host_address
```

For VMware ESX/ESXi using the CIM interface:

```
hbacmd m=cim removehost <IP_Address>
```

**Note:** The “h=” option (for specifying an optional IP address or host name) after “hbacmd” is not available for the RemoveHost command.

### Parameters

`host_address`     The host to remove.  
`IP_Address`        The IP address of the host to remove.

## Reset

This command resets the adapter. An adapter reset can require several seconds to complete, especially for remote devices. When the reset is completed, the system command prompt is displayed.

### Notes:

- Supported for FC and FCoE ports only.
- For OneConnect FCoE ports, this command only resets the driver to update changed driver parameters that require a driver reset. It does not cause a hardware reset of the adapter port.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
Reset <WWPN>
```

### Parameters

`WWPN`            The WWPN of the adapter.

## SetCimCred

This command sets the default CIM credentials. You must specify all four credentials: username, password, namespace, and port number. Default credentials are used if any credential is not in the hbacmd command argument. Once the default credentials for a host are set, any other command can be issued by specifying “m=cim”.

### Supported By

Windows

### Syntax

```
SetCimCred <username> <password> <namespace> <portnum>
```



**Note:** Use this command to set only the CIM credentials. Once this is done, subsequent hbacmd commands do not require you to specify the CIM credentials in the command line.

### Parameters

`username` Login User ID of the VMware ESX.  
`password` The login password of the VMware ESX.  
`namespace` The namespace where the Emulex provider is registered in the SFCB CIMOM of VMware ESX, specifically "root/emulex".  
`portnum` The port number of the SFCB CIMOM listening to, that is, 5988 (HTTP) or 5989 (HTTPS).

## SRIOVEnable

This command enables or disables SR-IOV on a specified NIC port (that is, physical function).

**Note:** This command is not available on OCe11101-EM/EX or OCe11102-EM/EX adapters. The following error will be returned:

```
ERROR: <251>: Hardware or firmware does not support command.
```

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
SRIOVEnable <MAC> <0|1>
```

### Parameters

`MAC` The MAC address of the port.  
`0|1` 0 = Disables SR-IOV.  
1 = Enables SR-IOV.

### Example

The following command enables SR-IOV on NIC physical function with MAC address 00-00-c9-12-34-56:

```
hbacmd sriovenable 00-00-c9-12-34-56 1
```

## TargetMapping

This command shows a list of mapped targets and the LUNs for the port.

### Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

TargetMapping <WWPN>

## Parameters

WWPN      The WWPN of the adapter.

## Version

This command shows the current version of the OneCommand Manager CLI Client.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

For the RM interface:

```
hbacmd Version
```

**Note:** The “h=” option (for specifying an optional IP address or host name) after “hbacmd” is not available for the Version command.

For VMware ESX/ESXi using the CIM interface:

```
hbacmd h=<IP address> m=cim version
```

## Parameters

None

## Persistent Binding Commands

### Notes:

- These commands are supported for FC/FCoE ports only.
- The following persistent binding commands are not supported on Linux or VMware ESX:
  - BindingCapabilities
  - BindingSupport
  - PersistentBinding
  - RemoveAllPersistentBinding
  - RemovePersistentBinding
  - SetPersistentBinding
  - SetBindingSupport

In a remote environment, you can perform persistent bindings operations from a host running any operating system (including Linux or VMware ESX), but only to a remote host that is running Windows or Solaris.

- For a binding to take effect immediately (that is, SetPersistentBinding parameter: Scope = I or B), the <SCSIBus> and <SCSITarget> parameters must match the SCSI bus and SCSI target to which the FC target is already automapped. If automapping is disabled, the binding takes effect immediately if the FC target is not already persistently bound, and the specified <SCSIBus> and <SCSITarget> parameters are available to be persistently bound. Also, the <BindType> parameter must match the currently active bind type. Otherwise, you are notified that you must reboot the system to cause the persistent binding to become active.

### AllNodeInfo

This command shows target node information for each target accessible by the adapter.

#### Supported By

Linux, Solaris, VMware ESX, and Windows

#### Syntax

```
AllNodeInfo <WWPN>
```

#### Parameters

**WWPN**      The WWPN of the adapter.

### BindingCapabilities

This command shows the binding capabilities of the adapter. If a binding is configured, it is maintained across reboots.

### Supported By

Solaris and Windows

### Syntax

```
BindingCapabilities <WWPN>
```

### Parameters

**WWPN**        The WWPN of the adapter.

## BindingSupport

This command shows the binding support for the adapter.

### Supported By

Solaris and Windows

### Syntax

```
BindingSupport <WWPN> <Source>
```

### Parameters

**WWPN**        The WWPN of the adapter.  
**Source**      C = Configuration support  
              L = Live support

## PersistentBinding

This command specifies which set of persistent binding information (configuration or live state) is requested.

### Supported By

Solaris and Windows

### Syntax

```
PersistentBinding <WWPN> <Source>
```

### Parameters

**WWPN**        The WWPN of the adapter.  
**Source**      C = Configuration support  
              L = Live support

## RemoveAllPersistentBinding

This command removes all persisting bindings for the adapter.

### Supported By

Solaris and Windows

### Syntax

```
RemoveAllPersistentBinding <WWPN>
```

### Parameters

**WWPN**            The WWPN of the adapter.

## RemovePersistentBinding

This command removes persistent binding between an FC target and a SCSI Bus and target. The binding to be removed can be to a target WWPN, target WWNN, or target D\_ID.

### Supported By

Solaris and Windows

### Syntax

```
RemovePersistentBinding <WWPN> <BindType> <ID> <SCSIBus> <SCSITarget>
```

### Parameters

**WWPN**            The WWPN of the adapter.

**BindType**        P = Remove binding by WWPN.  
                  N = Remove binding by WWNN.  
                  D = Remove binding by D\_ID.

**ID**              The type of ID based on <BindType>:

- Target WWPN if <BindType> = P
- Target WWNN if <BindType> = N
- Target D\_ID if <BindType> = D

**SCSIBus**        The bus number of the SCSI device.

**SCSITarget**    The target number of the SCSI device.

## SetBindingSupport

This command enables and sets the binding support(s) for the adapter.

### Supported By

Solaris and Windows

### Syntax

```
SetBindingSupport <WWPN> <BindFlag>
```

## Parameters

**WWPN** The WWPN of the adapter.

**BindFlag** The type of binding support for the adapter:

- D = Binding by D\_ID (not available for Storport Miniport driver)
- P = Binding by WWPN
- N = Binding by WWNN (not available for Storport Miniport driver)
- A = Binding by automap (not available for Storport Miniport driver)
- DA = Binding by D\_ID and automap
- PA = Binding by WWPN and automap
- NA = Binding by WWNN and automap

## SetPersistentBinding

This command sets a persistent binding between an FC target and a SCSI Bus target. The binding can be to a target WWPN, target WWNN, or target D\_ID.

### Supported By

Solaris and Windows

### Syntax

```
SetPersistentBinding <WWPN> <Scope> <BindType> <TargetId> <SCSIBus>
<SCSITarget>
```

### Parameters

**WWPN** The WWPN of the adapter.

**Scope** P = Permanent binding (survives reboot).  
I = Immediate binding.  
B = Binding is both permanent and immediate.

**BindType** P = Enable binding by WWPN  
N = Enable binding by WWNN  
D = Enable binding by D\_ID

**TargetId** If BindType = P, Target WWPN  
If BindType = N, Target WWNN  
If BindType = D, Target D\_ID

**SCSIBus** The bus number of the SCSI device.

**SCSITarget** The target number of the SCSI device.

## Personality Change Commands

The OneCommand Manager application enables you to change the personality or protocol running on OneConnect adapters. When you change the personality of the adapter and reboot the host, the adapter starts running the new personality or protocol. The personalities that the OneConnect adapters currently run are NIC-only, NIC + FCoE, and NIC + iSCSI. In some cases, the adapters are pre-configured to support multiple personalities. In other cases, you must install a license key before the adapter can support multiple personalities. See “Adapter License Management Commands” on page 51 for more information.

### Notes:

- The three different personalities may not always be available on an adapter. For example, a NIC + FCoE adapter can change to a NIC-only or a NIC + iSCSI adapter, but an iSCSI adapter may not be able to change to a NIC + FCoE adapter.
- It is possible to install one (or more) driver kits for the current personality, then change the personality and no longer have the drivers necessary to run the adapter. If you change personalities you must install the appropriate drivers. The appropriate drivers are available on the Emulex website.
- These commands are not available on LP1600x adapters.

## ChangePersonality

This command changes the personality on the adapter. After successful change, a reboot is required.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ChangePersonality <WWPN|MAC> <personality_type>
```

### Parameters

|                  |                                                |
|------------------|------------------------------------------------|
| WWPN             | The WWPN of the UCNA.                          |
| MAC              | The MAC address of the NIC or iSCSI port.      |
| Personality Type | The available values are nic, iscsi, and fcoe. |

### Example

For non-ESXi hosts:

```
hbacmd ChangePersonality 00-12-34-56-78-9A fcoe
```

For ESXi hosts:

```
hbacmd h=<IP_Address> m=cim u=root p=<password> n=<namespace>
ChangePersonality 00-12-34-56-78-9A fcoe
```

## ShowPersonalities

This command displays the list of personalities available on the adapter. The personality type is displayed as either NIC, iSCSI, or FCoE.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ShowPersonalities <WWPN|MAC>
```

### Parameters

WWPN        The WWPN of the UCNA.

MAC         The MAC address of the NIC or iSCSI port.

### Example

For non-ESXi hosts:

```
hbacmd ShowPersonalities 00-12-34-56-78-9A
```

For ESXi hosts:

```
hbacmd h=<IP_Address> m=cim u=root p=<password> n=<namespace>
showpersonalities 00-12-34-56-78-9A
```

## UMC Commands

The adapter's physical ports provide a converged conduit for network and storage traffic. Each channel has its own unique MAC address. Each channel provides traffic management capabilities such as enabling and disabling, minimum and maximum transmit rates, and VLAN ID (for untagged packets). For additional information on UMC, refer to the *Emulex Universal Multichannel Reference Guide*.

The CLI's UMC commands allow viewing of the UMC configuration, enabling and disabling of the UMC at the adapter level, and the modification of some of the channel properties. The UMC commands cannot be used to manage other channel management types; see "Channel Management Commands" on page 62 for more information.

### Notes:

- The UMC command "UmcSetChanLink" is no longer available. Its functionality can be done by the "UmcSetBw" command.
- Properties for all channels on a port can be viewed and modified with the UMC commands even when UMC is disabled. This allows enabling and configuration of UMC (on all channels), and rebooting and running UMC without further configuration.
- For IBM adapters, UMC mode may be referred to as "vNIC2".



- The UMC commands are not available on OCe11101-EM/EX or OCe11102-EM/EX adapters. The following error will be returned:  

```
ERROR: <251>: Hardware or firmware does not support command.
```

## UmcEnable

This command enables or disables UMC at the adapter level. A system reboot is required to make the change take effect.

### Notes:

- The UmcEnable command will enable UMC channel management only, but it will disable any channel management type in effect when it is used.
- The CMMMode command can also be used to enable UMC or other channel management modes.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
hbacmd UmcEnable <WWPN | MAC Address> <0 | 1>
```

### Parameters

|             |                                                     |
|-------------|-----------------------------------------------------|
| WWPN        | WWPN of the FCoE function on the physical port      |
| MAC Address | MAC address of any NIC function on the adapter port |
| 0           | Disable UMC                                         |
| 1           | Enable UMC                                          |

### Example

```
>hbacmd UmcEnable 00-00-c9-bb-cc-aa 1
```

## UmcGetParams

Shows the current UMC configuration for an adapter's physical port.

The command's output is the current UMC state for the adapter, and also a table showing the port's channels along with their UMC properties. On some adapters, only three channels will be shown instead of four because that is all the physical port supports. Also, the channel Type property shows the protocol that is running on the channel. This is controlled by the CLI's "ChangePersonality" command (not the UMC commands).

### Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
UmcGetParams <WWPN | MAC Address>
```

## Parameters

WWPN                   WWPN of an FCoE function on the physical port  
 MAC Address           MAC address of any NIC function on the adapter port

## Example

### All NIC

```
>hbacmd UmcGetParams 00-00-c9-bb-cc-aa
```

```
Active UMC State: Enabled
Configured UMC State: Enabled
```

| Func# | Type | MAC Address       | LPVID | Min BW | Max BW |
|-------|------|-------------------|-------|--------|--------|
| 0     | NIC  | 00-00-c9-bb-cc-aa | 2     | 25     | 50     |
| 1     | NIC  | 00-00-c9-bb-cc-ab | 3     | 0      | 0      |
| 2     | NIC  | 00-00-c9-bb-cc-ac | 4     | 25     | 50     |
| 3     | NIC  | 00-00-c9-bb-cc-ad | 5     | 50     | 75     |

### NIC Plus Storage

```
>hbacmd UmcGetParams 00-00-c9-bb-cc-aa
```

```
Active UMC State: Enabled
Configured UMC State: Enabled
```

| Func# | Type | MAC Address       | LPVID | Min BW | Max BW |
|-------|------|-------------------|-------|--------|--------|
| 0     | NIC  | 00-00-c9-bb-cc-aa | 1001  | 20     | 50     |
| 1     | FCoE | 00-00-c9-bb-cc-ab | n/a   | 50     | 100    |
| 2     | NIC  | 00-00-c9-bb-cc-ac | 1002  | 20     | 50     |
| 3     | NIC  | 00-00-c9-bb-cc-ad | 1003  | 10     | 75     |

## UmcSetBw

This command sets the minimum and maximum bandwidths for each channel (up to four) on the physical port. The total of the minimum bandwidths must add up to 100. The maximum bandwidth must be greater than or equal to the minimum bandwidth and has a maximum value of 100. Setting the minimum bandwidth of a channel to 0 will disable the channel, and setting it to a non-zero value will enable the channel. This command can also be used to disable the link on a channel by setting the minimum and maximum bandwidths of that channel to 0.

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
UmcSetBW <WWPN | MAC Address> <Min0,Max0> <Min1,Max1> <Min2,Max2>
[Min3,Max3]
```

## Parameters

|             |                                                     |
|-------------|-----------------------------------------------------|
| MAC Address | MAC address of any NIC function on the adapter port |
| WWPN        | WWPN of the FCoE function on the physical port      |
| Min0,Max0   | minimum and maximum bandwidths for channel 0        |
| Min1,Max1   | minimum and maximum bandwidths for channel 1        |
| Min2,Max2   | minimum and maximum bandwidths for channel 2        |
| Min3,Max3   | minimum and maximum bandwidths for channel 3        |

## Example

```
>hbacmd UmcSetBW 00-00-c9-bb-cc-aa 25,50 0,50 50,75 25,100
```

## Considerations

- This command is not supported on 1 Gb ports.
- When only three channels are available, specifying Min3,Max3 will cause an error.
- If UMC is disabled when this command is executed, a warning message will be displayed indicating that UMC is currently disabled and must be enabled for these changes to take effect.

## UmcSetLPVID

This command sets the LPVID for each channel on a physical port. A reboot is not required to make these changes take effect (when UMC is enabled).

## Supported By

Linux, Solaris, VMware ESX, and Windows

## Syntax

```
UmcSetLPVID <WWPN | MAC Address> <LPVID0> <LPVID1> <LPVID2> [LPVID3]
```

## Parameters

|             |                                                     |
|-------------|-----------------------------------------------------|
| WWPN        | WWPN of the FCoE function on the physical port      |
| MAC Address | MAC address of any NIC function on the adapter port |
| LPVID0      | LPVID for channel 0                                 |
| LPVID1      | LPVID for channel 1                                 |

LPVID2                    LPVID for channel 2  
LPVID3                    LPVID for channel 3

### Considerations for Using UmcSetLPVID:

- LPVID values are in the range of 2-4094.
- Every NIC channel on a physical port must have a unique LPVID.
- For FCoE and iSCSI channels, '0' must be entered since LPVIDs cannot be set for storage channels.
- When only three channels are available, specifying LPVID3 will cause an error.
- This command is not supported on 1 Gb ports.
- If UMC is disabled when this command is executed, a warning message will be displayed indicating that UMC is currently disabled and must be enabled for these changes to take effect.

### Examples

#### All NIC

```
>hbacmd UmcSetLPVID 00-00-c9-bb-cc-aa 1001 1002 1003 1004
```

#### NIC Plus Storage

```
>hbacmd UmcSetLPVID 00-00-c9-bb-cc-aa 1001 0 1002 1003
```

## VPort Commands

**Note:** Supported by FC and FCoE adapter ports only.

This command creates a virtual port with an automatically-generated WWPN or a user-specified virtual WWPN on the specified physical port. If you specify “auto”, the virtual WWPN is generated automatically. Otherwise, you must specify the virtual WWPN for this parameter. If creation is successful, the WWPN is displayed as part of the output from the command. The [vname] optional parameter can be specified for the virtual port’s name.

**Note:** In Linux, VPorts do not persist across system reboots.

### CreateVPort

#### Supported By

Linux, Solaris, and Windows

#### Syntax

```
CreateVPort <physical WWPN> auto [vname]
```

-or-

```
CreateVPort <physical WWPN> <virtual WWPN> <virtual WWNN> [vname]
```

#### Parameters

|               |                                                                   |
|---------------|-------------------------------------------------------------------|
| physical WWPN | The WWPN of the object adapter.                                   |
| auto          | The virtual WWPN is automatically generated for the virtual port. |
| vname         | The virtual port’s name (optional).                               |
| virtual WWPN  | The virtual WWPN to create.                                       |
| virtual WWNN  | The virtual WWNN to create.                                       |

### DeleteVPort

This command deletes the virtual port specified by a physical and virtual WWPN.

#### Supported By

Linux, Solaris, and Windows

#### Syntax

```
DeleteVPort <physical WWPN> <virtual WWPN>
```

### Parameters

`physical WWPN` The WWPN of the adapter.  
`virtual WWPN` The WWPN of the virtual port

## ListVFunctions

This command lists the virtual functions on a specified NIC port (that is, physical function).

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ListVFunctions <MAC>
```

### Parameters

`MAC` The MAC address of the port.

### Example

```
hbacmd ListVFunctions 00-00-c9-12-34-56
```

The example output:

```
Virtual Functions for 00-00-c9-12-34-56:
```

```
MAC Address : 00-00-c9-12-34-ab
VLADID : 10
Transmit Rate : 100 Mbit/sec.
```

```
MAC Address : 00-00-c9-12-34-cd
VLADID : 10
Transmit Rate : 100 Mbit/sec.
```

```
MAC Address : 00-00-c9-12-34-ef
VLADID : 10
Transmit Rate : 1 bbit/sec.
```

```
MAC Address : 00-00-c9-13-34-01
VLADID : 20
Transmit Rate : 1 Gbit/sec.
```

## ListVMs

This command lists all virtual machines and their information for all manageable ports.

If you specify the host with the “h=<host>” option or provide the physical WWPN, only the virtual machines for that host are returned. If you specify the physical port and the virtual port, only the virtual machine for the specified virtual port are returned.

The virtual machine name is only displayed if the virtual port is associated with a virtual machine on VMware ESX 4.1. If you are running this command on any other server that has virtual ports, you will not see the virtual machine name.

### Supported By

Linux and VMware ESX

### Syntax

```
ListVMs <physical WWPN> <virtual WWPN>
```

### Parameters

`physical WWPN` The WWPN of the adapter.

`virtual WWPN` The WWPN of the virtual port.

## ListVPorts

This command lists virtual ports on the specified physical port. Leaving the physical WWPN parameter blank lists all virtual ports on all manageable hosts that support virtual ports.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ListVPorts <physical WWPN>
```

### Parameters

`physical WWPN` The WWPN of the adapter.

## VPortTargets

This command lists targets visible to the specified virtual port.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
VPortTargets <physical WWPN> <virtual WWPN>
```

### Parameters

`physical WWPN` The WWPN of the adapter.  
`virtual WWPN` The WWPN of the virtual port.

## WWN Management Commands

### Notes:

- Supported for FC/FCoE adapter ports only.
- WWN Management validates WWNs carefully to avoid name duplication. Therefore, you may see error and warning messages if a name duplication is detected. Emulex strongly recommends that the activation requirement be fulfilled after each WWN change or restore. When running with “pending changes”, some diagnostic and maintenance features are not allowed.

## ChangeWWN

This command changes the volatile state of WWNs. If the volatile change is requested on an adapter that does not support volatile WWNs, it returns a “not supported” error.

### Notes:

- When a volatile change is supported, a reboot is required to activate the new setting. Volatile names are active until system power-down or adapter power-cycle.
- For VMware ESX:
  - After changing the WWN of an adapter, update your zoning settings before you reboot your ESX server. If the zoning is not updated before your reboot, the subsequent boot may take a long time.
  - After changing the WWN of an adapter, you must reboot the ESX system before trying to access the adapter on that system. For information on rebooting the ESX system, refer to the VMware documentation.
- For ESX COS:

If you are using the CIM interface to access adapters, after changing the WWN of an adapter, you must restart the CIMOM (that is, SFCB) on the ESX COS system before trying to access the adapter on that system. For information on restarting the CIMOM, refer to the VMware documentation.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ChangeWWN <WWPN> <New WWPN> <New WWNN> <Type>
```



### Parameters

|          |                                  |
|----------|----------------------------------|
| WWPN     | The WWPN of the adapter.         |
| New WWPN | The WWPN of the new adapter.     |
| New WWNN | The WWNN of the new adapter.     |
| Type     | 0 = Volatile<br>1 = Non-Volatile |

## GetWWNCap

This command shows if volatile change is supported for the WWPN.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
GetWWNCap <WWPN>
```

### Parameters

|      |                          |
|------|--------------------------|
| WWPN | The WWPN of the adapter. |
|------|--------------------------|

## ReadWWN

This command reads different types of WWNs.

### Supported By

Linux, Solaris, VMware ESX, and Windows

### Syntax

```
ReadWWN <WWPN> <Type>
```

### Parameters

|      |                                                                                          |
|------|------------------------------------------------------------------------------------------|
| WWPN | The WWPN of the adapter.                                                                 |
| Type | 0 = Volatile<br>1 = Non-Volatile<br>2 = Factory Default<br>3 = Current<br>4 = Configured |

## RestoreWWN

This command changes the WWNs to the factory default or non-volatile values. The change is non-volatile.

**Notes:**

- A reboot is required to activate the new setting.
- For VMware ESX: After changing the WWN of an adapter, you must reboot the ESX system before trying to access the adapter on that system. For information on rebooting the ESX system, see the VMware documentation.
- For ESX COS: If you are using the CIM interface to access adapters, after changing the WWN of an adapter, you must restart the CIMOM (that is, SFCB) on the ESX COS system before trying to access the adapter on that system. For information on restarting the CIMOM, see the VMware documentation.

**Supported By**

Linux, Solaris, VMware ESX, and Windows

**Syntax**

```
RestoreWWN <WWPN> <Type>
```

**Parameters**

|      |                                                      |
|------|------------------------------------------------------|
| WWPN | The WWPN of the adapter.                             |
| Type | 0 = Restore Default WWNs.<br>1 = Restore NVRAM WWNs. |

## Appendix A. OneCommand Manager Error Messages

Table A-1 contains a list of some of the error messages that may be encountered during an OCM session.

**Table A-1** OneCommand Manager Error Messages

| Error Message                                                                                                        | Command(s)                                                                  | Description                                                                                                                                                                                                                                                            |
|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Error: Read-only management mode is currently set on this host. The requested command is not permitted in this mode. |                                                                             | The CLI does not allow the execution of certain commands when it is configured for read-only mode. See “CLI in Read-Only Mode May Cause Error Message” on page 30.                                                                                                     |
| Not supported.                                                                                                       | ChangeWWN                                                                   | If a volatile change is requested on an adapter that does not support volatile WWNs, it returns a “not supported” error. See “ChangeWWN” on page 128.                                                                                                                  |
| There are no license features for this adapter                                                                       | ShowLicenseAdapterID<br>InstallAdapterLicense<br>ShowAdapterLicenseFeatures | Adapter License Management commands are not available on Ce11101-EM/EX or OCe11102-EM/EX adapters. See “Adapter License Management Commands” on page 51.                                                                                                               |
| ERROR: HBACMD_GetDumpFile:<br>RM_GetDumpFile call failed (2)<br>ERROR: <2>: Not Supported                            | GetDumpFile                                                                 | Dump files are copied from the Dump directory of the remote host to the Dump directory of the local host. Specifying a local port identifier for this command returns an error, since the source and destination directory are the same. See “GetDumpFile” on page 81. |
| ERROR: <180>: Authentication:<br>User unknown                                                                        | All                                                                         | The specified username is not valid or could not be authenticated by the system. See “OneCommand Manager Secure Management” on page 13 for more information.                                                                                                           |
| ERROR: <181>: Authentication:<br>Insufficient credentials                                                            | All                                                                         | The specified username and password are valid and the user is a member of an OCM group, however the OCM group does not have sufficient privileges to execute the specified command. See “OneCommand Manager Secure Management” on page 13 for more information.        |

Table A-1 OneCommand Manager Error Messages (Continued)

| Error Message                                                        | Command(s)                                                               | Description                                                                                                                                                                           |
|----------------------------------------------------------------------|--------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ERROR: <183>: Secure Mgmt: user not a member of OCM group            | All                                                                      | The specified username and password could be authenticated, but the user is not a member of an OCM group. See “OneCommand Manager Secure Management” on page 13 for more information. |
| ERROR: <206>: Authentication Failed                                  | All                                                                      | This indicates either a valid username, but invalid password, or a general user authentication error. See “OneCommand Manager Secure Management” on page 13 for more information.     |
| ERROR: <222>: DCB not available                                      | GetDCBParams<br>SetDCBParam<br>GetPGInfo<br>SetDCBPriority<br>SetCnaPGBW | These commands are not available on Ce11101-EM/EX or OCe11102-EM/EX adapters. See “DCB Commands” on page 65.                                                                          |
| ERROR: <251>: Hardware or firmware does not support command.         | SRIOVEnable<br>UmcGetParams<br>UmcEnable<br>UmcSetLPVID<br>UmcSetBW      | These commands are not available on Ce11101-EM/EX or OCe11102-EM/EX adapters. See “SRIOVEnable” on page 113, and “UMC Commands” on page 120.                                          |
| Error: <431> Cable length required for force mode and interface type | SetPhyPortSpeed                                                          | This error is displayed when a length value is not included when the mode is set to 2.<br>Example:<br>hbacmd setphyportspeed 00-00-c9-a9-41-88 2 100Mb<br>See “Examples” on page 55.  |