




HM40 Quick Guide


For more detailed information refer to the corresponding user manual on our homepage.

Getting to know your Device




Insert / Remove the Battery

1. Insert the battery




2. Removing the battery




Insert / Remove the USIM card

1. Insert the USIM card




2. Removing the USIM card




Insert / Remove the microSD card

1. Insert the microSD card




2. Removing microSD card



3. Precautions using the MicroSD Card

- The SD card can break if you frequently slide in/out or put or excessively put too much force.
- If the card is removed while being used or being turned off, the data can be lost or malfunction.
- Please back up important data. We are not responsible for the lost data.
- If the memory card does not slide out, do not remove by force. After removing the card at the repair center, exchange your device or get a refund.

Charging with Cradle




- When the device's battery is low, it may warn you with a ring and a message.
- The charging time can vary depending on the environment. A new battery is only partially charged. Please charge fully before using.

Connecting ActiveSync

1. Installing on PC


- [Microsoft ActiveSync 4.5] Korean version.
- The functions and the layout can be different if you use different version.
- [Microsoft ActiveSync] can be updated through the Microsoft homepage.
- [Windows Vista] users need to install [Windows Mobile Device Center].

① After connecting to the Microsoft homepage, download and install [Microsoft Activesync].



② On the window about the license terms, press <I accept the license terms> ► On the [Client information] window, input <User name> ► Specify where you want to install.

③ [Microsoft Active Sync] can be installed when it is ready to install.




④ [Microsoft ActiveSync] is installed.


2. Using ActiveSync

- You can see a Windows Mobile version on the display and it can be different according to the version.
- [Microsoft ActiveSync] can be used when the device is plugged into a notebook or pc. You can transfer files by syncing it. You can also install/uninstall new programs.
- The USB cable is sold separately. Please contact the service center for more details.(Code : 12132)


① You can connect with the Cradle.



② If the device and computer are successfully connected, [Microsoft Activesync] will automatically start. Please select the <Search> button.



③ In the <Mobile device> folder, you can check the photos, music, and documents stored in the device and move it to the computer.




[Precautions using ActiveSync]

- When "unknown USB device" can pop up, when the device is turning on while connected to the <Micro USB Cable>. If you reconnect the device from the <Micro USB Cable> the ActiveSync will run properly.
- If in ActiveSync, the state "connecting..." is continued for a long period of time, disconnect the device from the <Micro USB Cable>. In [ActiveSync] press FILE ► CONNECTION SETTINGS ► select <Allow USB connection> ► Press [OK]. Reconnect the device.

• If you have reconnected several times and still "unknown USB device" pops up
In certain cases the computer's USB host has gone wrong leading to connection failure.
Remove the device from the <Micro USB Cable> and reboot the computer. Reconnect the device to the cable and it will run properly.

• The device not running after removing the battery while device on.
For this to be avoided, do not remove the battery while the device on. You must press the [Power] button or the [Shut Down] button with the stylus pen in order for the Windows Mobile to [Turn off] correctly.
If in a case where you have removed the battery while the device is on, hold the [Reset] button + [OK] button to hard reset.
Please note if you hard reset, all the data in the memory will be erased.

3. Connecting ActiveSync



Your device and the surrounding devices can you used when connected with the <USB Cable>.

- If you use the function [USB-PC Connect] your device's battery consumption will be high. If you are not using the function [USB-PC Connect] disconnect to save your battery consumption.

Customers Service Center

Hours
Mon.- Fri. : 9:30 A.M. ~ 6:30 P.M.
(GMT Time: +9 Hours)

We are not open on Saturday,
Sundays and National Holidays.

Address : Dunchon-Daero 531,
Ssangyong IT Twin-Tower
B-703, Jungwon-gu, Seongnam,
Gyeonggi-do, Korea