

NovoSPT User's Manual (Novo Tech Software Ltd.)

Table of Contents

1. Introduction	3
2. References.....	4
3. Formulas.....	8
4. License Agreement.....	9
5. Contents.....	11
5.1 Getting Started	11
5.2 Data Entry.....	12
5.3 Changing Units System	15
5.4 Toolbar & Menu	15
5.5 Using Help	15
5.6 Results.....	16
5.6.1 Soil Type Filtering	16
5.6.2 Correlated results.....	17
5.6.3 Statistical report	18
5.6.4 Correlation with depth	19
5.7 Import / Export.....	20
5.7.1 Import from text file.....	20
5.7.2 SmartSync (gINT, GeoSystem, GAEA)	21
5.7.3 Exporting Tables and Graphs.....	22
5.7.4 Graph Presentation Tool	23
5.8 Tools.....	24
5.8.1 Wildcat Penetrometer Module.....	24
5.8.2 DCP Module.....	25
5.8.3 Bearing Capacity.....	27
5.8.4 Preferences	28
5.8.5 Reporting.....	29
6. Online.....	31
6.1 Novo Tech Software website	31
6.2 Our other programs.....	31
6.3 Updates	31
6.4 Contact us	31

1. Introduction

Software :  **NovoSPT**

Release Date: September 2009

Licensing Model : [License File](#), [On-demand](#)

Production Team : Design and Programming: [Alireza Afkhami](#) (M.A.Sc, M.C.P, I.C.D.L, P.Eng)

Similar Programs : [NovoFormula](#), [NovoSPT iPhone/iPad App](#)

Updates : [click to open](#)

Disclaimer : [click to read](#)(See 4.)

NovoSPT is a computer program for interpretation of Standard Penetration Test (SPT/ DCPT) and correlating blow counts (N) to soil properties based on more than 300 formulas. It is gINT, Excel and Microsoft Access database compatible and provides several reporting and additional features. Please keep your software up-to-date by visiting the program's [web page](#).

Although all efforts have been undertaken to ensure that this software is of the highest possible quality and that the results obtained are correct, the authors do not warrant the functions contained in the program will meet your requirements or that the operation of the program will be uninterrupted or error-free. The authors are not responsible and assume no liability for any results or any use made thereof, nor for any damages or litigation that may result from the use of the software for any purpose. All results to be verified independently by user.



2. References

1- Foundation analysis and design (5th edition)

Joseph E. Bowles

2- Reliability of shallow foundation design using the standard penetration test

D.P. Zekkos, J.D. Bray, A. Der kiureghian

3- A short course in foundation engineering

N.E. Simons, Bruce Keith Menzies

4- Empirical correlation between penetration resistance and internal friction angle of sandy soils

Munenori Hatanaka, Akihiko Uchida

5- Correlations of soil properties

Michael Carter, Stephen P. Bently

6- Analysis of spread footing foundations as a highway bridge alternative

Jill L. Meranda, Teruhisa Masada, Dennis Irwin, November 2005

7- Correlation of SPT to strength and modulus of elasticity of cohesive soils

L. Behpoor, A. Ghahramani

8- Piling Engineering

Ken Fleming, Austin Weltman, Keith Elson, Mark Randolph

9- Subsurface Investigation and Interpretation of Test Results for Foundation Design in Soft Clay

Gue See Sew, Tan Yean Chin

10- Foundation Design Codes and Soil Investigation in View of International Harmonization and Performance Based Design

Y. Honjo

11- Geotechnical engineering

V. N. S. Murthy

12- Analysis of Bearing Capacity-Driven Pile

Syaiful Ashari

13- Correlations between shear wave velocity and in-situ penetration test results

Recep Iyisan

14- Pile foundations in engineering practice

Shamsher Prakash, Hari D. Sharma

15- BPT-SPT correlations for evaluation of liquefaction resistance in gravely soils

Alex Sy, R.G. Campanella, Raymond A. Stewart

16- Earthquake Engineering: Proceedings of the 11th European conference, Paris, France

P. Bisch

17- Canadian Foundation Engineering Manual

4th Edition, 2006

18- Energy measurements and correlations of the standard penetration test (SPT) and the Becker penetration test (BPT)

Alexander Sy, University of British Columbia (UBC), October 1993

19- Relating K_a and K_s to SPT blow count and to CPT tip resistance for use in evaluating liquefaction potential

I.M. Idriss, R.W. Boulanger

20- Correlation between penetration resistance and relative density of sandy soils

M. Cubrinovski, K. Ishihara

21- Foundation engineering (2nd edition, 1974)

Peck, Hanson, Thornburn

22- Manual on estimating soil properties for foundation design

F.H. Kulhawy and P.W. Mayne, Cornell university, Ithaca, New York, 1990

23- Geotechnical engineering

S.J. Spigolon

24- Soft ground improvement

D. T. Bergado

25- Theory and practice of foundation design

N. N. Som, S. C. Das

26- A Portable Dynamic Penetrometer for Geotechnical Investigations

J. Fred Triggs, Paul D. Simpson

27- Soil mechanics in engineering practice

Karl Terzaghi, Ralph B. Peck, Gholamreza Mesri

28- A few comments on pile design

Yves Robert

29- Evaluation of modulus of subgrade reaction (Ks) in gravelly soils based on standard penetration test (SPT)

R. Ziaie Moayed, S.A. Naeini

30- Use of SPT Blow Counts to Estimate Shear Strength Properties of Soils: Energy Balance Approach

Hiroshan Hettiarachchi, Timothy Brown

31- Statistical correlations between seismic wave velocities and SPT blow counts and the relative density of soils

Emin U. Ulugergerli, Osman Uyanik

32- Mathematical Correlations Between The Effective Diameter Of Soil And Other Properties

Muayed M. Ismail

33- Engineering correlations for soils in Taipei

Z.Z Moh, C.T Chin, C.J Lin and S.M Woo

34- Geotechnical Engineering

Renato Lancellotta

35- Dynamic Properties of Fine Grained Soils in South of Tehran

Mohammad Kazem Jafari, Ali Shafiee, and Arash Razmkhah

36- Relationship Between S-Wave Velocities And Geotechnical Properties of Alluvial Sediments

Tomio INAZAKI, Public Works Research Institute, Tsukuba, JAPAN

37- Site response analyses based on site specific soil properties using geotechnical and geophysical tests

Anbazhagan P, Sitharam T.G, Divya C

38- Foundation engineering handbook

Hsai-Yang Fang

39- کاربرد آزمایش نفوذ استاندارد درمسائل استاتیکی در مهندسی ژئوتکنیک ارزیابی

Nader Hatef, Amin Keshavarz

40- Geotechnical earthquake engineering

Lkuo Towhata

41- Foundation engineering

P.C. Varghese

42- Earthquake geotechnical engineering

Kyriazis D. Pitilakis

43- Mapping of average shear wave velocity for Bangalore region : a case study

Anbazhagan, Sitharam

44- Piling engineering (3rd edition)

Ken Fleming, Austin Weltman, Mark Randolph and Keith Elson

45- Assessment of shear strength for design purposes

Thomas L. Brandon, Massimiliano Rolandi

46- The foundation engineering handbook

Manjriker Gunarantne

47- In-situ testing in geotechnics: the main tests

Fernando Schnaid

48- NEHRP guidelines for the seismic rehabilitation of buildings

Federal Emergency Management Agency, FEMA 273, October 1997

49- Correlación entre el Valor N del Ensayo de Penetración Estándar y Velocidad de Ondas de Corte para Arcillas en Bogotá - Colombia

Andrés José Alfaro Castillo, June 2007

50- Seismic Microzonation of Bangalore

Anbazhagan P, Sitharam T.G, Divya C

- 51- A comparison of pile performance base on static formulas and dynamic load test
Muhd Harris BIN Ramli (Universiti Teknologi Malaysia)
- 52- Research report: standard penetration test (SPT) correction
M. Sherif Aggour, W. Rose Radding
- 53- NCEER Workshop Report (1997)
- 54- Engineering and Design: Bearing Capacity of Soils
U.S. Army Corps of Engineers
- 55- Geotechnical Engineering Circular No. 5 (Evaluation of Soil and Rock Properties)
Federal Highway Administration (FHWA)
- 56- Experience of Suspension P-S Logging Method and Empirical Formula of Shear Wave Velocities in Taiwan
Ming-Hung Chen, Kuo-Liang Wen, Chin-Hsiung Loh, Robert L. Nigbor
- 57- Statistical correlations of shear wave velocity and penetration resistance for soils
Unal Dikmen (Earthquake Research Center, Ankara University, Turkey)
- 58- The relation of shear wave velocity and SPT for soils in Iran (11th European Conference on Earthquake Engineering Paris, France)
Baziar, M., Fallah, H., Razeghi, H. R. and Khorasani, M. M.
- 59- Relationship between the standard penetration test and the pressuremeter test on sandy silty clays (a case study from Denizli, Turkey)
S. Yagiz, E. Akyol, G. Sen
- 60- Correlation of standard penetration test and pressuremeter data (a case study from Istanbul, Turkey)
I. Bozbey, E. Togrol
- 61- Pressuremeter method for foundation design in Hong Kong
Y.C. Chiang, Y.M. Ho
- 62- Estimation of cyclic strength of sand from self-boring pressuremeter tests
D. Roy, J. Hughes and R.G. Campanella
- 63- Use of SPT Blow Counts to Estimate Shear Strength Properties of Soils: Energy Balance Approach
Hiroshan Hettiarachchi and Timothy Brown
- 64- Evaluation of geotechnical property variability
Kok-Kwang Phoon and Fred H. Kulhawy
- 65- Cone penetration testing in geotechnical practice
T. Lunne and P. K. Robertson
- 66- "Closure: Settlement of Spread Footings on Sand," Journal of the Soil Mechanics and Foundations Division
D'Appolonia, E. D., and Brissette, R. F. 1970
- 67- Potential application of dynamic and static cone penetrometers in MDOT pavement design and construction
Farshad Amini, Jackson State University, 2003
- 68- Relationship between Low Strain Shear Modulus and Standard Penetration Test N Values
P. Anbazhagan, T. G. Sitharam, 2010
- 69- Site Characterization – Guidelines for Estimating Vs Based on In-Situ Tests
Soil Interactions Laboratory UC Davis, 2007
- 70- Shear Wave Velocity as Function of SPT Penetration Resistance and Vertical Effective Stress at California Bridge Sites
Naresh Bellana (Masters degree thesis), University of California (Los Angeles)
- 71- Empirical correlations of shear wave velocity (Vs) and penetration resistance (SPT-N) for different soils in an earthquake-prone area (Erbaa-Turkey)
Muge K. Akin, Steven L. Kramer, Tamer Topal
- 72- SPT Capability to Estimate Undrained Shear Strength of Fine-Grained Soils of Tehran, Iran
Farzad Nassaji, Behzad Kalantari
- 73- Development of Empirical Correlation Between Shear Wave Velocity And Standard Penetration Resistance In Soils Of Chennai City
Uma Maheswari, Boominathan and Dodagoudar

[for an up-to-date list of references please visit this page](#)

3. Formulas

For updated and complete list of methods and formulas used in **NovoSPT** for correlation of soil properties based on SPT blow counts, please see [this page](#)

4. License Agreement

PLEASE READ THIS END USER LICENSE AGREEMENT ("EULA") CAREFULLY BEFORE DOWNLOADING OR USING THE SOFTWARE. BY DOWNLOADING THE SOFTWARE, OR USING THE SOFTWARE, YOU ARE CONSENTING TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT AGREE TO ALL OF THE TERMS OF THIS AGREEMENT DO NOT DOWNLOAD AND/OR USE THE SOFTWARE.

The Product is Copyright © 2009 "NOVO TECH SOFTWARE". You may use it and distribute it according to this following License Agreement. If you do not agree with these terms, please remove the Product from your system. By incorporating the Product in your work or distributing the Product to others you implicitly agree to these license terms.

1. DEFINITIONS

- 1.1. "NovoSPT" or "Software" refers to "NOVO TECH SOFTWARE"'s program, in each case, supplied by "NOVO TECH SOFTWARE" herewith, and corresponding documentation, associated media, and online or electronic documentation.
- 1.2. "Trial Version" means a free version of the Software for personal use only, so identified, to be used in one computer only and for a period of 14 days. The Trial Version is fully functional with no restrictions compared to the registered version.
- 1.3. "Registered Version" means a version which has been bought from "NOVO TECH SOFTWARE".

2. LIMITATION OF LIABILITY

Although all efforts have been undertaken to ensure that this software is of the highest possible quality and that the results obtained are correct, the authors do not warrant the functions contained in the program will meet your requirements or that the operation of the program will be uninterrupted or error-free. The authors are not responsible and assume no liability for any results or any use made thereof, nor for any damages or litigation that may result from the use of the software for any purpose. All results to be verified independently by user.

In no event shall "NOVO TECH SOFTWARE" be liable for any damages (including, without limitation, lost profits, business interruption, or lost information) rising out of 'Authorized Users' use of or inability to use the NovoSPT, even if "NOVO TECH SOFTWARE" has been advised of the possibility of such damages. In no event will "NOVO TECH SOFTWARE" be liable for loss of data or for indirect, special, incidental, consequential (including lost profit), or other damages based in contract, tort or otherwise. "NOVO TECH SOFTWARE" shall have no liability with respect to the content of the NovoSPT or any part thereof, including but not limited to errors or omissions contained therein, libel, infringements of rights of publicity, privacy, trademark rights, business interruption, personal injury, loss of privacy, moral rights or the disclosure of confidential information.

3. FOR NovoSPT TRIAL VERSION

- (a) The NovoSPT Trial version may be freely distributed, with exceptions noted below, provided the distribution package is not modified in ANY WAY.
- (b) The NovoSPT Trial version may not be distributed inside of any other software package without written permission of "NOVO TECH SOFTWARE".
- (c) The NovoSPT Trial version allows the user to publish its work according to the license agreement, but nor "NOVO TECH SOFTWARE" nor any member of the company can be held liable for the content or accuracy of the publication.

- (d) You may use the accompanying Product free of charge for a period of 14 days for the sole purpose of evaluating the Product. If, after this period, you wish to continue using this Product, you are required to purchase it. In other case, you are required to remove this Product, in its entirety, from all computers on which it is installed.
- (e) You shall not use, copy, rent, lease, sell, modify, decompile, disassemble, otherwise reverse engineer, or transfer the Product except as provided in this Agreement. Any such unauthorized use shall result in immediate and automatic termination of this Agreement.

4. FOR NovoSPT REGISTERED VERSION

- (a) You may install and use the Software on a single computer; OR install and store the Software on a storage device, such as a network server, used only to install the Software on your other computers over an internal network, provided you have a license for each separate computer on which the Software is installed and run. A license for the Software may not be shared, installed or used concurrently on different computers.
- (b) The NovoSPT Registered version allows the registered user to publish its work according to the license agreement, but nor "NOVO TECH SOFTWARE" nor any member of the company can be held liable for the content or accuracy of the publication.
- (c) The NovoSPT Registered version guaranties to the registered user free updates for a whole version cycle and for 12 (twelve) months.
- (d) You shall not use, copy, rent, lease, sell, modify, decompile, disassemble, otherwise reverse engineer, or transfer the Product except as provided in this Agreement. Any such unauthorized use shall result in immediate and automatic termination of this Agreement.
- (e) Once purchased, the Software may not be return to "NOVO TECH SOFTWARE". The price paid for the Software is not refundable.
- (f) The NovoSPT license is issued for one computer based on the Hardware ID provided by user. Each transfer of license to another computer, if approved by NOVO TECH SOFTWARE, will be subject to 20 percent charge based on latest NovoSPT price.

5. TERMS

This license is effective until terminated. You may terminate it by destroying the program, the documentation and copies thereof. This license will also terminate if you fail to comply with any terms or conditions of this agreement. You agree upon such termination to destroy all copies of the program and of the documentation, or return them to the author.

6. OTHER RIGHTS AND RESTRICTIONS

All other rights and restrictions not specifically granted in this license are reserved by "NOVO TECH SOFTWARE". If you have any questions regarding this agreement, please write to support@NovoTechSoftware.com

YOU ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT, UNDERSTAND IT AND AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS.

5. Contents


5.1 Getting Started ...

When starting a new analysis with NovoSPT, the following steps are recommended:

Step 1: enter input data for the size of the shallow and pile foundations, enter groundwater conditions and choose SPT correction methods ([see more here](#)(See 5.2)).

Step 2: enter subsurface soil layers and SPT blow counts in the corresponding tables, as shown below. Notice the plots on the right -hand side of the page are updated as you enter data ([see more here](#)(See 5.2)).

Step 3: when data entry is over, click on the depth row in the 'SPT Blow Counts' table to choose the depth in which you need the correlations. Then click on '[Correlate Soil Parameters](#)' button to see the correlated soil properties ([see more here](#)(See 5.6.2)).



please note that:

- by [clicking on any chart](#)(See 5.7.4) you will have access to several options for printing and exporting the chart
- ? sign at the top-right corner of each page, opens up the corresponding help page

- analysis files are saved with .SPT extension and the complete file path is shown at the bottom of the page
- if an update of the software is available, click on the yellow link at the top-right corner of the page to open the webpage

5.2 Data Entry

All data entry in **NovoSPT** is performed in **Input Data** tab. This data can be categorized into the following groups:

Shallow Footing: This data is used for calculating bearing capacity of shallow footings based on shear failure or settlement criteria (based on method). Footing size and load as well as safety factor against shear failure should be specified. Please notice that **depth of footing (Df) is considered to be the depth (Z) selected by user** on SPT table.

»Results are presented in "[Correlated Soil Properties](#)(See 5.6.2)" tab when "**Bearing capacity of footings on sand (qa)**" items is selected from the list.

Pile Foundation: Diameter of the pile should be specified in order to estimate the friction and end bearing of the piles based on SPT blow counts. Please notice that **pile length is considered to be the depth (Z) selected by user on SPT table.**

»Results are presented in "[Correlated Soil Properties](#)(See 5.6.2)" tab when "**Bearing capacity of piles**" items is selected from the list.

SPT Corrections: The following corrections should be applied on SPT number (N) to obtain N_{60} and $N_{1(60)}$ numbers:

- Energy level: this will adjust the SPT equipment energy to standard 60% energy. This correction factor is named **Ce** in **NovoSPT**.
- Borehole diameter: size of the borehole affects the SPT blow counts. This correction factor is named **Cb** in **NovoSPT**.
- Sampling method: some SPT samplers have a liner. This will affect the SPT blow counts and its correction factor is called **Cs** in **NovoSPT**.
- Rod length: this correction factor is called **Cr** and depends on length of SPT rods which is approximately equal to the depth of the test. The following formula proposed by Dr. Cetin is used in **NovoSPT**:

$$C_r = \frac{1}{0.989860781 + \frac{4.31663223}{z^2}} \quad \text{for } z \geq 3$$

- Overburden stress: this corrections is usually called as "depth correction factor" or **Cn** and depends on overburden stress due to soil, at the test depth.

Please choose your favorite method for each correction factor. The following formula is used to calculate the correction factors at each

depth:

$$C=C_e.C_b.C_s.C_r \quad N_{60}=C.N \quad N_{1(60)}=C_n.N_{60}$$

All the above-mentioned factors as well as N_{60} and $N_{1(60)}$ are plotted versus depth and presented on screen.

»Results for C_n corrections are presented in "[Correlated Soil Properties](#)(See 5.6.2)" tab when "Overburden correction factor (cn)" items is selected from the list.

Settings:The groundwater level affects the calculation of effective overburden stress (σ'_v) used in the correlations. In addition, user can choose to apply the water level correction on SPT blow counts, as proposed by Terzaghi. This correction is recommended for $N \geq 15$ in silty sands:

$$N_{cor}=15+0.5(N_{60}-15)$$

Another important point when using the correlations is 'applicability' of each correlation to soil type. For example if at depth of 3.4 meters where correlations are required, the soil type is generally "clay", a shear wave velocity correlation which is derived in "sand" would not be reliable and can provide somewhat wrong values. Some other soil parameters such as undrained shear strength are even meaningless for "sand" and "gravel" soil types. To filter the correlations based on each layer's soil type, click on "[Show only applicable correlations](#)". To read more details about this new feature, [please read this page](#)(See 5.6.1).

»Please notice that **NovoSPT** can provide correlations, either at a specific depth or [along depth of the borehole](#)(See 5.6.4). All correlations regarding a specific depth are presented in "[Correlated Soil Properties](#)(See 5.6.2)" tab and user **should specify the depth** at which, correlations are to be calculated. To do this, please click on the desired depth at SPT data table and notice to the change in **Depth** and **N60** fields on bottom-left of the page.

Soil Layers:This data is used to calculate the effective and total overburden stress at each depth where correlations are required. Please pick the soil type for each layer from the dropdown list (clay/silt/sand/gravel) and avoid details descriptions such as "sandy clay with gravel", etc. This soil type is used by **NovoSPT** when correlations are [to be filtered based on soil type](#)(See 5.6.1).

Some SPT correlations depend on OCR and D_{50} of the soil. These parameters should be specified for each soil layer.

»This data can be entered manually or maybe imported [from a text file](#)(See 5.7.1) or [from gINT database](#)(See 5.7.2).


SPT data:In this table please enter raw data gathered from SPT test. The first two columns of this table include depth and SPT blow counts (N) and the other columns are automatically calculated during data entry. While this data is being entered, SPT plots are updated and present both SPT blow counts and correction factors along depth of borehole.

»This data can be entered manually or maybe imported [from a text](#)


[file](#)(See 5.7.1) or [from gINT database](#)(See 5.7.2).

Note: Never enter zero for a SPT test depth; it may lead to calculation errors (because of dependency of most overburden pressure corrections to σ_v which will be zero at $Z=0$).

Clearing tables data

For clearing all data entered in a table, simply press  button on top-right side of the table.

Shallow footings bearing capacity and settlement

If you want to estimate the bearing pressure and settlement of foundation based on SPT blow counts, enter corresponding data. For most of these calculations, average of N_{60} or $N_{1(60)}$ should be calculated for a depth ranging from $0.5B$ to $2B$ underneath the footing. So make sure that you have entered enough data within this depth range. You may also click on  **Tools** ▶ **Bearing Capacity Analysis** menu to use NovoSPT's comprehensive analyses tool.


B: Footing width

L: Footing Length

Df: Depth of embedment for the footing (**will be equal to the depth selected by user** - see below)


P: Stress below the footing

SPT graph


Once you enter SPT versus depth data, and press  **Correlate Soil Parameters** button, SPT graph is updated and un-corrected as well as corrected SPT numbers are plotted versus depth. Another graph shows the variation of SPT correction factors against depth. Click on each graph to zoom, print or export to other formats.

IMPORTANT


How can I choose the depth in which I need the correlations?

When data entry is finished, simply click on the row in the SPT table at which depth you need the correlations. Notice that corresponding depth and SPT data is updates on the 'Correlated Soil Parameters' tab (see Figure below). For example, the following screenshot shows that **$N_{60}=8$** at **$Z=1.52m$** is chosen and once user clicks on  **Correlate Soil Parameters**, all correlations will be provided for this depth ([read more about filtering correlations](#)(See 5.6.1)).

In this example, for shallow footing bearing capacity analysis **$Df=1.52m$** and for pile bearing capacity **pile length=1.52m** will be considered.




5.3 Changing Units System

NovoSPT supports both Metric and Imperial units. To switch between units system, please use  **Tools** ▶ **Preferences** menu and click on **User Interface** tab.

You should restart the program for the new units system to take effect.

5.4 Toolbar & Menu


Most of the commonly used commands in NovoSPT are placed in toolbars. For other commands use menu bar. In each form, to read the user manual (Help) content for that page, click on ? button on top-right corner of the page.



5.5 Using Help


Activating Help


Help button is placed at the top-right corner of all pages, as shown on this screenshot. In order to get the help content associated with the page,




please click on this button.

How to Choose Help Language?


Most of our help files are available in both **English** and **Spanish** language. In order to choose your desired language please click on  **Help** > **Help Contents** menu and choose your language from the list. Please notice that Help language could be different from the program [user-interface language](#)(See 5.8.4).

The entire help content is also available in PDF format and is presented through  **User Manuals** menu as shown on the right.




5.6 Results

5.6.1 Soil Type Filtering

This feature can be activated by selecting "**Show only applicable correlations**" checkbox on input tab. If this option is activated, the  button on toolbar will be highlighted.

Obviously, any SPT correlation is derived based on case studies or field test in specific soil types. Most of the SPT correlations are only valid for one or two soil types. In **NovoSPT 2.1** and later, the applicable soil types are specified for each correlation, as it can be seen in the following screenshot:



Blue checkmark: valid for clay

Purple checkmark: valid for silt

Blue checkmark: valid for sand

Blue checkmark: valid for gravel


Gray checkmark: the author has not clearly specified the soil types for this correlation. In this case **NovoSPT** assumes that the correlation would be applicable to all soil types


Why using the 'soil type filter'?

Although not applying the soil type filter, provides you with more correlations for a SPT blow count, it should be noted that not all of the correlations are valid for all soil types. For example, in a sand layer with a SPT blow counts of $N_{60}=12$, **NovoSPT** may provide a value for undrained shear strength (S_u) at this depth if soil type filter is off (because you have asked the program not to check the soil type). But this is totally meaningless!!



You can prevent such confusion and simply concentrate on those correlations which are valid for the soil type at each depth. Since user has specified the soil layers in input form, it can easily filter the applicable correlations, during the calculations. If soil type filter is active, a funnel icon will be highlighted on toolbar and will be shown above the correlation grid.

5.6.2 Correlated results

When data entry in **NovoSPT** is done, pressing  **Correlate Soil Parameters** button will show the correlated results in "Correlated Soil Properties" tab. **NovoSPT** uses [more than 250 correlation](#)(See [3.](#)) formulas to prepare these results. For each soil property (e.g. "Relative Density (D_r)"), all available correlations are summarized in a table describing Reference, value and comments regarding each formulae or correlation used. The following picture describes parts of the correlation grid:




Each method may be turned on/off by using the checkbox in the first column and will be added/removed from the statistics chart.

To view the statistics of all correlations for the selected soil parameter, click on  **Show Statistics** button ([read more](#) (See 5.6.3)). If correlation of the selected soil parameter in the depth of the borehole is required, click on  **Depth Correlation** button ([read more](#) (See 5.6.4)).

How to copy table contents

If necessary, you can simply copy data within each table by selecting the target rows (by holding the left mouse button down and selecting the rows), and then pressing CTRL+C. Thereafter, pressing CTRL+V in any other editor in Windows, pastes the data.

How to export the tables into Microsoft Excel

Click on the table, and then select  **Tables** ▶ **Save As MS Excel ...** menu. Choose the file name and path in the dialog, and the table will be saved as an Excel file.


Visualization of correlated values

To better visualize the results of a specific soil property, a graph is presented on [statistical chart](#) (See 5.6.3). This graph shows a scatter of the results for each soil parameter and helps the user to compare those values and pick the most reasonable range for that parameter. Please notice that for those formulas which provide a range for the parameter, the corresponding value in the graph is shown as a vertical bar representing the minimum and maximum recommended range. To view additional information, move the mouse over each point on the graph to get more information about the method.

5.6.3 Statistical report

To better visualize the results of a specific soil property, a graph is presented on a statistical chart. This graph shows a scatter of the results for each soil parameter and helps the user to compare those

values and pick the most reasonable range for that parameter. Please notice that for those formulas which provide a range for the parameter, the corresponding value in graph is shown as a vertical bar representing the minimum and maximum recommended range. To view additional information, move the mouse over each point on the graph to get more information about the method.




Click on each chart to open the chart in [Chart Presentation Tool](#)(See 5.7.4) and you can export and print the data into other formats.

5.6.4 Correlation with depth


This feature is designed to plot the variation of a soil parameter in depth of a borehole based on SPT blow counts, and is accessible from **View** ▶ **Correlation versus depth of the borehole** menu. Follow these steps to obtain the correlation in depth of borehole:

1. Select the desired soil parameter (shear wave velocity is selected in the following screenshot)
2. Select the correlations from the list (two of the selected methods can be seen in the screenshot)
3. Click on **Plot Selected Methods** button and wait for the graph to be updated

4. If necessary, remove any or select more methods from the list and repeat step 3




For example in the above screenshot, 4 methods are selected and plotted along depth of borehole. The red and green lines (Yoshida et al., 1988 and Meyerhof, 1957 methods) provide comparatively lowest and highest values of Dr, respectively.


Note : Please notice that in this example, the funnel icon on top-right corner of the page  indicates the [soil type filter](#)(See 5.6.1) is ON. This means that only those correlations which are derived for the same soil type will be listed at each depth. Soil type at a depth is obtained from soil layers [input data](#)(See 5.2).

5.7 Import / Export

5.7.1 Import from text file

In case that there are large number of records for soil layers and/or SPT data, user may import data from Text files (*.txt) using  button above the tables . The Text file should have the following format :

one record per line and two numbers on each line separated by comma or tab. For instance, if your SPT data is stored in a Text file, it looks like the following:




where, 0.3048,0.6096,0.9144,etc are depths and 19,19,11,etc are corresponding blow counts per foot (N). Text files can be easily generated using Windows **Notepad** or by exporting your data from spreadsheet applications such as Microsoft Excel into text format. For soil layers text file, each line consists of layer *thickness*, its *unit weight* , *soil type* , *D50* and *OCR* separated by comma.


Note: Importing from file is mostly used when you have many rows of data; if your geotechnical model is simple, just enter them in the tables, manually.

Importing data from gINT, LogPlot, WinLog, LogDraft files

NovoSPT also supports import from above-mentioned files. So if you have already prepared this files for your project read more about this feature [here\(See 5.7.2\)](#) to find out how to import data files directly into NovoSPT.

5.7.2 SmartSync (gINT, GeoSystem, GAEA)

NovoSPT supports most of the well known log drafting programs such as gINT, LogPlot, WinLog and similar programs. To import a gINT project data into NovoSPT, simply click on  button from the toolbar or select **File** ► **Import from** ► **gINT** menu.

When "Open database file" dialog appears, choose your gINT file (*.gpj) from your hard disk. Next step is to specify where SmartSync can find data such as ground water level, borehole data, soil layering data and so on. If your gINT file structure is customized by you and does not follow the default database format, you will then need to choose the corresponding tables and fields in which specific data can be found. Select desire borehole and then press  **Import** button. All corresponding data will be imported to SPT table in main page of NovoSPT.


You can specify depth unit of your original gINT file. Data will be automatically converted to your default **NovoSPT** unit system.


Once you set the tables and fields name, you may select the "Remember This Settings" checkbox so that next time when you import from a gINT file, your setting will be automatically loaded.

[Read Online Help](#)

5.7.3 Exporting Tables and Graphs

Most of the users have already setup their spreadsheets and would rather keep their reports in the same format. To do this, they need to export the analysis results into other popular formats such as Microsoft Excel.

To export the results click on  button form toolbar. A dialog similar to the following screenshot will appear. List of all tables and charts of the analysis results, will be provided on left and right panels, respectively (see below).



Please specify the output folder (You can change this folder by clicking on ... button). Then select the items you want to export.

Exporting Data Tables


Tables can be saved as Microsoft Excel or may be directly sent to the printer.










Exporting Graphs (Charts)

All charts may be saved with image formats such as BMP, PNG, JPG, etc or be printed.


5.7.4 Graph Presentation Tool


We understand that presentation of the analysis results is very important to our users. Everywhere in Novo Tech Software programs when you click on a chart, a new dialog appears containing the chart and its associated data. In the following example, the corresponding dataset is shown on right and can be scrolled horizontally and vertically to view all data. In addition, toolbar buttons provide you with more features:



-  To change line styles of the plot
-  To change the scale (minimum, maximum and gridlines) of each axis. Please click on small arrow on right side of the icon to open the dropdown menu
-  To toggle between normal/logarithmic scale for horizontal axis
-  To change the chart type
-  To open the advanced settings page for the chart
-  To save the dataset table as Microsoft Excel file
-  To save the chart as text and graphic format
-  To print the chart
-  Opens this help page

How can I change the appearance of the chart such as legend, chart type, etc?

You can configure almost everything in the chart by clicking on  button from the toolbar. This will open the following dialog box:





Click on the desired element from the list located on the left side of the page; more options will be shown on the right portion. Click on OK button to apply your changes.

5.8 Tools

5.8.1 Wildcat Penetrometer Module

If you use Wildcat Dynamic Penetrometer (produced by Triggs company in US), this module helps you process and correlate Wildcat blow counts to equivalent SPT blow counts. Please enter depth of test and corresponding Wildcat blow counts in first 2 columns of the table. The other

parameters including equivalent SPT blow counts will be calculated immediately. To transfer the correlated N_{60} obtained from Wildcat, to the **NovoSPT** main page click on  **Accept Data** button.



5.8.2 DCP Module

DCP Processing

Preferences

Depth correction method for SPT: Log page depth (m):

Please enter DCP blow counts in the table:

Depth (m)	DCP Blows	Soil Class	N ₆₀	SPT Correction Factor C _n	N1(60)	Soil Consistency
0.5	5	B- 95% compacted soil	5	2	9	Medium / Loose
1	2	B- 95% compacted soil	3	2	6	Soft / Very Loose
1.5	3	B- 95% compacted soil	3	2	6	Soft / Very Loose
2	6	C- 90% compacted soil	7	2	14	Medium / Loose
2.5	8	C- 90% compacted soil	9	2	18	Stiff / Loose
3	7	A- Virgin Piedmont soil	9	2	19	Stiff / Loose
3.5	5	B- 95% compacted soil	7	2	15	Medium / Loose
4	2	C- 90% compacted soil	7	2	15	Medium / Loose
4	2	D- 85% compacted soil	4	2	7	Soft / Very Loose
4.5	9	E- Coastal plain soil	4	2	7	Soft / Very Loose
4.5	9	F- Piedmont alluvium	10	2	19	Stiff / Loose
5	11	F- Piedmont alluvium	11	2	22	Stiff / Medium Dense (Compact)
5.5	12	A- Virgin Piedmont soil	9	2	18	Stiff / Loose
6	8	A- Virgin Piedmont soil	7	1.95	13	Medium / Loose
6.5	5	A- Virgin Piedmont soil	5	1.85	10	Medium / Loose
7	3	D- 85% compacted soil	4	1.77	7	Medium / Loose
7.5	4	D- 85% compacted soil	6	1.65	10	Medium / Loose


Blow Counts (N) vs Depth (m) graph showing DCP Blows N, Eq. SPT Blows N₆₀, and Corrected SPT Blows N1(60).


Legend:

- DCP Blows N
- Eq. SPT Blows N₆₀
- Corrected SPT Blows N1(60)


Buttons:

[Is this my DCP? checkout the DCP specifications here](#)

If you use DCP (produced by Durham Geo Slope company in US), this module helps you process and correlate DCP blow counts to equivalent SPT blow counts. Please enter depth of test and corresponding DCP blow counts and soil class (A to F) in first 3 columns of the table. The other parameters including equivalent N_{60} and $N_{1(60)}$ will be calculated immediately. To transfer the correlated N_{60} obtained from DCP, to the **NovoSPT** main page click on  **Accept Data** button. The following chart presents the correlations between DCP blows per increment and standard SPT blow counts for different soil types.



For the complete reference please read this paper:

 **ASTM Special Technical Publication #399: Dynamic Cone for Shallow In-Situ Penetration Testing**

by: George F. Sowers and Charles S. Hodges

[Download link for user manual \(Durham\)](#)

5.8.3 Bearing Capacity

5.8.3.1 Bearing Capacity Module

For a discussion on bearing capacity methods used in NovoSPT [please read this article](#)(See 5.8.3.2).

5.8.3.2 Theory

Meyerhof, 1976 (based on 25mm settlement)

The allowable bearing capacity based on the SPT test according to Meyerhof is:

$$q_a = N_{60} \cdot K_d / F_1 \quad B \leq F_4$$

$$q_a = N_{60} \cdot K_d \cdot (B + F_3) / (B \cdot F_2) \quad B > F_4$$

where $K_d = 1 + D / (3B) \leq 1.33$ and F_1 to F_4 are defined as below for SI units:

$$F_1 = 0.05, F_2 = 0.08, F_3 = 0.30, F_4 = 1.20$$

and N_{60} is the average SPT blow counts from 0.5B above to 2B below the foundation level.

Parry, 1977 (based on 25mm settlement)

The allowable bearing capacity according to Parry for cohesionless soil is:

$$q_a = 30N_{60} \quad D_f \leq B$$

Where N_{60} is the average SPT blow counts below 0.75B underneath the footing.

Burland and Burbidge, 1985 (based on 25 mm settlement)

They collected more than 200 records of structures founded on sands and gravels. They started with the premise that the settlement could be represented by an equation of the form:

$$q_a = 2540 \cdot N_{60}^{1.4} / (10^T \cdot B^{0.75})$$

where N_{60} is the average SPT blow counts to a depth of $B^{0.75}$ below footing and $T \sim 2.23$

Peck, 1974

The following formula is used in NovoSPT for this method:

$$q_a = 10.6 N_{1(60)}$$

General Terzaghi Formula

The following Terzaghi equation is used for indirect estimation of bearing capacity of shallow footing on cohesionless soil:

$$q_{ult} = (\bar{q} N_q) + (0.5 \gamma B N_\gamma)$$

where:

q = is the overburden stress at foundation level (D_f).

$$N_q = e^{[\pi \cdot \tan(\phi)]} [\tan(\pi/4 + \phi/2)]^2 \quad \text{Bowles 1996}$$

$$N_v = 1.5(N_q - 1) \cdot \tan(\phi)$$

Brinch & Hansen 1970

ϕ = friction angle correlated from the equation proposed by Hatanaka and Uchida, 1996 based on SPT at foundation level

5.8.4 Preferences

Valid Ranges


The main aim for this tab is to control the valid ranges of output values, since some correlations produce invalid values like sand relative density more than 100 percent or friction angle more than 45 degrees. As it is shown on right, if the checkbox for "0 < Phi < 45" -for instance- is removed, no checking will be carried out on calculated Φ value. We highly recommend to keep all options selected.


Options

This tab is used to specify the relative density calculation method used in Duncan (2004) formulae.

User Interface


Use this tab to choose the input / output units system as well as user interface language.

By selecting  **Show help button on top-right corner of all forms**, a question mark [\(?\) button](#) (See 5.5) will appear on top-right corner of forms, by clicking on it, help page for that page will pop up.




5.8.5 Reporting

To prepare the reports after completing the calculations, simply click on **File ▶ Report** menu. This will bring up the report manager page, where you can choose the tables and graphs which should be included in the report:



By pressing **Print** button All selected tables and graphs will be summarized in the report. The print preview page will appear and allows user to change the page setup, send the print and zoom on the report. Toolbar buttons are described in the screenshot below:



6. Online

6.1 Novo Tech Software website

<http://www.novotechsoftware.com>

6.2 Our other programs

<http://www.novotechsoftware.com/products/>

6.3 Updates

<http://www.novotechsoftware.com/updatelogs/novoSPT.txt>

6.4 Contact us

<http://www.novotechsoftware.com/contact-us/>