## **DATA SHEET**

# LS Human Machine Interface

XP30-BTE/DC
XP30-TTE/DC



- When using LSIS equipment, thoroughly read this datasheet and associated manuals introduced in this datasheet. Also pay careful attention to safety and handle the module properly.
- Store this datasheet in a safe place so that you can take it out and read it whenever necessary.



- Safety Precautions is for using the product safe and correct in order to prevent the accidents and danger, so please go by them.
- ► The precautions explained here only apply to the XP30-BTE/DC and the XP30-TTE/DC. For safety precautions on the HMI system, refer to User's manual.
- ▶ The precautions are divided into 2 sections, 'Warning' and 'Caution'. Each of the meanings is represented as follows.
- If violated instructions, it can cause death, fatal injury or a considerable loss of property

If violated instructions, it can cause a slight injury or a slight loss of products

- ▶ The symbols which are indicated in the HMI and User's Manual mean as follows. This symbol means paying attention because of danger of injury, fire, or malfunction
- // This symbol means paying attention because of danger of electric shock.
- Store this datasheet in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user

# Warning

- Do not contact the terminals while the power is applied. Risk of electric shock and malfunction.
- Protect the product from being gone into by foreign metallic matter. Risk of fire, electric shock and malfunction.
- Risk of fire, electric shock and malfunction. Risk of injury and fire by explosion and ignition.

#### Before handling the product

#### Before handling the product

Before using the product, read the datasheet and the User's manual through to the end carefully in order to use the product efficiently.

Name	Code
XGT Panel Manual	10310000867
XGT Panel Communication Manual	10310000857
XP-Builder Manual	10310000876
XP30-BTE(TTE)/DC Datasheet	10310000969

#### Revision History

Publication Date	Version	Updated Information	
2008. 11.31	V1.0	New	
2010. 4. 23	V2.0	The new model XP30-TTE/DC added	
2010.10	V2.1	Branch address changed	

## 1. Introduction

XGT Panel as HMI (Human Machine Interface) watches and controls the condition of the PLC, Inverter and other instruments

#### XGT Panel series provide the function which is various and a stable efficiency.

$\square$	Caution						
•	<ul> <li>Be sure to check the rated voltage and terminal arrangement for the module before wiring work.</li> <li>Risk of electric shock, fire and malfunction.</li> </ul>						
•	<ul> <li>Tighten the screw of terminal block with the specified torque range.</li> <li>If the terminal screw looses, it can cause fire and electric shock.</li> </ul>						
<ul> <li>Use the HMI in an environment that meets the general specifications contained in this datasheet.</li> <li>Risk of electrical shock, fire, erroneous operation and deterioration of the HMI.</li> </ul>							
<ul> <li>Be sure that external load does not exceed the rating of output module.</li> <li>Risk of fire and erroneous operation.</li> </ul>							
<ul> <li>Do not use the HMI in the environment of direct vibration Risk of electrical shock, fire and erroneous operation.</li> </ul>							
<ul> <li>Do not disassemble, repair or modify the HMI.</li> <li>Risk of electrical shock, fire and erroneous operation</li> </ul>							
<ul> <li>When disposing of HMI and battery, treat it as industrial waste. Risk of poisonous pollution or explosion.</li> </ul>							
	Precautions for use Do not Install other places except HMI controlled place. Make sure that the FG terminal is grounded with class 3 grounding which is dedicated to the HMI. Otherwise, it can cause disorder or malfunction of HMI. $\begin{array}{c} \hline HMI & Others & HMI & Others & HMI & Others & \\ \hline A & Best & B & \\ \hline C & C & Bad & \\ \hline C & C & Bad & \\ \hline C & C & Bad & \\ \hline C & C & C & Bad & \\ \hline C & C & C & C & \\ \hline C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & C & \\ \hline C & C & C & \\ \hline$						

## 2. General Specifications

No	ltem	Specifications					Standard
1	Operating temp.	0 ℃ ~ +50 ℃					-
2	Storage temp.			<b>-20</b> °C	~+60℃		-
3	Operating humidity		10~	85%RH,	(Non-conde	ensing)	-
4	Storage humidity		10~	85%RH,	(Non-conde	nsing)	-
		For dis	conti	nuous vit	oration	Number	-
		Frequency	Acce	eleration	Amplitude		
		<b>5≤f&lt; 9</b> Hz		-	3.5mm		
5	Vibration	9≤f≤150 <sup>H</sup> z	ç	9.8m/s²	-	Each 10	
5	VIDIALION	For c	ontin	uous vibr	ation	times in X,Y,Z	IEC 61131-2
		Frequency	Acce	eleration	Amplitude	directions	
		<b>5≤f&lt; 9</b> Hz		-	1.75mm		
		9≤f≤150 <sup>Hz</sup>	4	1.9m/s*	-		
6	Shocks	* Max. impact acceleration: 147ൺ(15G) * Authorized time: 11™ * Pulse wave : Sign half-wave pulse (Each 3 times in X,Y,Z directions)					IEC 61131-2
		Square wave ±1,000V			LSIS Standard		
		Electrostat dischargin		Voltage	Voltage: 6 kV(contact discharging)		IEC 61131-2 IEC 61000-4-2
7 No	Noise		Radiated ctromagnetic 80 ~ 1000 MHz, 10 V/m ield noise			IEC 61131-2 IEC 61000-4-3	
		Fast Transi / Burst no		Class	Power module	Communication interface	IEC 61131-2 IEC 61000-4-4
8	Ambient conditions	Voltage         2 kV         1 kV           No corrosive gas or dust         1					-
9	Operating height	2,000m(6,562ft) or Less					-
10	Pollution degree	2 or Less					-
11	Cooling method	Self-Cooling				-	

Davis Controls A Bread Above the Pest Davis Controls Ltd is the authorized distributor of LSIS equipment and control solutions throughtout Canada

Founded in 1933, Davis Controls represents a strong and balanced portfolio of world class products. From head office facilities located in Oakville, Ontario, Davis Controls connects customers seeking high quality automation solutions with global manufacturers of state of the art products.

You can contact us at:

Toll Free Canada: 800.701.7460 Toll Free USA: 800.388.4159 Email: info@daviscontrols.com Website: www.daviscontrols.com

Thank you for your business and your interest in LSIS solutions.

LS constantly endeavors to improve our products so that information in this datasheet is subjected to change without notice ...

The date of issue: 2010. 2 10310000969

## 3. Performance Specification

Item		XP30-BTE	XP30-TTE			
	Display type	Monochrome LCD	TFT LCD			
	Screen size	5.7"(14cm)				
Di	splay resolution	320 x 240 pixel				
-	Display color	8 step Gray Scale	256 Colors			
		Left/Right: 45 deg.	Left/Right: 80 deg.			
	Display angle	Upper: 20 deg.	Upper: 80 deg.			
		Lower: 40 deg.	Lower: 80 deg.			
	Backlight	LED typ	e			
	Backlight life	50,000 ho	our			
	Contrast	Adjust through touc	ch/parameter			
	Brightness	230cd/m <sup>*</sup>	210cd/m <sup>*</sup>			
	Touch panel	Analog				
	Sound	Magnetic bi	uzzer			
	Process	ARM920T (32bit RI	SC), 200MHz			
Gr	aphic accelerator	Hardware Acc	elerator			
≤	Flash	16MB				
Memory	Operating RAM	32MB				
Backup RAM		128KB				
		Date/Hour data and Logging/Alarm/Recipe data,				
	Backup type	Nonvolatile Device				
E	Battery duration	Approximately 3 years (When operating at 25 $^\circ\!\!\!\!\!^\circ$ )				
USB host		1 channel, USB 2.0 (printer, USB memory stick driver is available)				
	RS-232C	Terminal Pleak type				
RS-422/485		Terminal Block type				
Mu	Itilingual language	Up to 4 language simultaneously				
	Animation	GIF format is available.				
	Recipe	Available				
	Data logging	Available				
;	Script executor	Available				
Standard certification		CE, UL, KCC				
Degree of protection		IP65F				
Dimension (mm)		181 x 140 x 56.5				
Panel cut (mm)		156 x 123.5				
Input voltage(V)		DC24V				
Po	wer consumption (W)	5				
	Weight (kg)	0.62				

#### Remark

1) Battery operation and life

: Battery is used to reserve backup data and RTC (data/time) when power is off. Because battery is used when power is off, battery is not consumed when power is on.

2) LCD Backlight replacement : XP30-BTE/DC and XP30-TTE/DC, LCD backlights are not replaceable because LCD and backlight are all-in-one type

## 4. Designations of Parts

Part names of functions are described as below







No.	Name	Description				
1	Front view	1) Analog touch panel: User touch input				
		2) LCD: screen display				
		Indicates operation status of module.				
			Normal RUN status			
2	LED Status	Green	(monitoring, downloading the project data)			
0			Initializing mode when booting (HMI does not Ready)			
			Error occurs			
		Red		nication error, project data error)		
3	Panel fixed part	XGT Pa		at panel by bracket.		
4	Power terminal cover	Prevention from electric shock				
		1) USB	1) USB memory connection: logging/recipe/screen data backup			
(5)	USB interface	2) USB memory connection: project data transmission/backup				
~		<ul><li>3) User interface connection: use of mouse/keyboard</li><li>4) Printer connection: printing is available</li></ul>				
	O					
6	Communication interface	RS-232 (PLC)	C, RS-422/4	85: For communication with controller		
~		. ,	x ,			
7	Reset switch	Hardwa	Hardware reset switch			
8	Battery cover	Open or close when replacing the battery				
		RS-232C interface				
(9)	Tool interface	1) Project data transmission				
۲		2) Logging/recipe/alarm/screen data backup				
		3) Machine software upgrade				
	O atting a such ab		Module setting switch			
	Setting switch	No.1	Reserved			
	4 3 2 1	No.2	A setting	Normal operation (basic setting)		
10		No.3	B setting	When upgrading Windows CE		
			A setting	Use of Watchdog (basic setting)		
		No.4	B setting	No use of Watchdog		
			A setting B setting	RS-422/485 terminal resistor setting (120Ω) No use of RS-422/485 terminal resistor		
(11)	Power terminal	It concir	U U	input and FG terminal		
U)	rower terminal	IL COUSIS	to or power			

## Remark

(1) If AC power is applied into the product for DC power, It may cause damage or fire. Be careful

of connection.

(2) XP30-BTE/DC and XP30-TTE/DC must be use DC 24V power. When using the product, check the label in the back of the product.

 (3) Using the <sup>(3)</sup> FG terminal for the module's frame ground.
 (4) There is prevention sheet in prevention of battery discharge. In order to use backup, remove the prevention sheet.

## 5. Communication cable specification and wiring method

### 5.1 Tool cable specification and wiring





#### 5.3 RS-422/485 cable specification and wiring ltem Description ▶ Please use the (UL) Style 2464 AWG22. Cable ► Keep the length of cable within 500[m]. specification ► Recommends to using the shielded cable Connect to PLC or control devices. (1:1, 1:N communication) PLC PLC PLC ┙╸╸ GT Pan Configuration and wiring Pin arrangement of XGT Panel's connector Connector type: Terminal Block 5 6 7 8 4 2 3 9 TX RX SG TX+ тх-RX+ RX-FG SG RS-232C RS-422/485 FG 1 2 3 4 5 6 7 8 9

## Remark

1) Wiring precaution Depend on PLC types and control devices have different wiring methods, Please refer to communication manual for more detail. When using RS-485 connect no. 4 (TX+) with no.6 (RX+), no. 5 (TX-) with no.7 (RX-)

# 2) Terminal Resistance Configuration When using RS-422/485 set terminal resistance switch On (default)

#### 6. Power Input Wiring

#### 6.1 DC (24V) power wiring



#### 6.2 Power terminal and wire specification



### Remark

) When the regulation of power is bigger than provision, use the constant voltage transformer

- (2) In case power has much noise, use the insulation transformer.
- (3) Separate the XGT Panel's power from the main circuit (high voltage, large current) cable, I/O signal cable. If possible, install at a interval of more than 100mm.

# 7. Installation





#### 7.2 Panel installation

Keep the distance of 100 mm between XGT Panel and panel per each direction. (unit: mm)



7.3 Fixation The bracket is included in the product.

### Remark

- Precaution for installation : This machine should be install within 0~50 °C, otherwise the screen may be changed or cause malfunction
- Because the product can be affected by dust, use the anti-vibration rubber packing. : Don't touch the terminals while power is on, otherwise, it may cause
- electric shock or erroneous operation.



#### 9. Warranty

1. Warranty period

LSIS provides an 18-month-warranty from the date of the production.

2. Warranty conditions

For troubles within the warranty period, LSIS will replace the entire HMI or repair the troubled parts free of charge except the following cases.

(1) The troubles caused by improper condition, environment or treatment except the instructions of LSIS.

(2) The troubles caused by external devices.

(3) The troubles caused by remodeling or repairing based on the user's own discretion.

(4) The troubles caused by improper usage of the product.

- (5) The troubles caused by the reason which exceeded the expectation from
- science and technology level when LSIS manufactured the product.

(6) The troubles caused by natural disaster.

3. This warranty is limited to the HMI itself only. It is not valid for the whole system which the HMI is attached to.