

PANEL MOUNTED CONTROLLER FP-e User's Manual

FP-e User's Manual ARCT1F369E-3 '06.2

Table of Contents

Precautions before using FP-e unit Programming tools

1.Features and Configurations	1-1
1.1 Features and Functions	1-2
1 1 1 Features	1-2
1 1 2 Functions	1_2
	1-2
1.2 Unit Name and Product Number	1-3
1.2.1 FP-e control unit	1-3
1.2.2 Related parts	1-3
1.3 Programming Tool	1-4
1.3.1 When using a tool software	1-4
2.Functions and I/O specifications	2-1
2.4 Section Names and Functions	
2.1 Section Names and Functions	Z-Z
2.2 Display Modes and Functions	2-4
2.2.1 Display modes and functions	2-4
2.2.2 Mode Displays	2-5
2.3 Input and Output Specifications	2-6
2.3.2 Output specifications	2-8
2.4 Display/Front Operation Switch Specifications	2-9
2.5 Calendar timer	2-10
2.5.1 Area for calendar timer	2-10
2.5.2 Setting of calendar timer function	2-10
2.5.3 Accuracy of calendar timer	2-11
2.6 Limitations in data hold/non-hold function	2-12
3.Installation and Wiring	3-1
2.1 Installation	2.0
2.1.1 Operating environment	3-2
3.1.1 Operating environment.	
3.1.2 Mounting and Removing the Unit	3-5
3.2 Terminal Layout Diagram and Terminal Block Wiring	3-6
3.2.1 Terminal layout diagram	3-6

3.2.2 Terminal block wiring	3-6
3.3 Power Supply Wiring	3-8
3.3.1 Power supply wiring	3-8
3.3.2 Grounding	3-9
3.4 Wiring of Input and Output	3-10
3.4.1 Input wiring	3-10
3.4.2 Output wiring	3-12
3.4.3 Common precautions for input and output wiring	3-12
3.5 Wiring COM. Port	3-13
3.6 Safety Measures	3-16
3.6.1 Safety measures	3-16
3.6.2 Momentary power failures	
3.6.3 Protection of power supply and output sections	3-17
3.7 Memory backup battery	
3.7.1 Installation of memory backup battery	
(For FP-e unit with a calendar timer function)	
3 7 2 System register setting	3-18
(For FP-e unit with a calendar timer function)	3-18
4.Display and Settings in N (Normal) Mode	4-1
4.1 Display and operation in N (Normal) mode	4-2
4.2 Instructions to control the display	4-3
4.2.1 F180 (SCR): Screen display instruction, Number of steps: 9	4-3
4.2.2 F180 (SCR) instruction: FPWIN GR Wizard 4.2.3 F181 (DSP) : Screen change instruction Number of steps: 3	4-8 4-9
4.3 N mode sample program	
······································	
4.4 Display screen and lock with the program	4-11
5.Data Display and Settings in S (Switch) Mode	5-1
5.1 Display and operation in S (Switch) mode	5-2
	5-3
5.2 S mode sample program	
6.Data Display and Settings in R (Register) Mode	6-1
6.Data Display and Settings in R (Register) Mode 6.1 Display and operation in R (Register) mode	6-1 6-2
 6.Data Display and Settings in R (Register) Mode 6.1 Display and operation in R (Register) mode 6.2 Operation in R (Register) mode 	6-1 6-2 6-3
 6.Data Display and Settings in R (Register) Mode 6.1 Display and operation in R (Register) mode 6.2 Operation in R (Register) mode	6-1 6-2 6-3 6-3

6.2.3 Changing the unit No. of COM. port	6-5
7.I (I/O Monitor) Mode	7-5
7.1 I/O monitor	7-5
8.PID Control	8-5
8.1 PID Control	8-5
8.1.1 Operation of PID control	8-5
8.2 PID control instruction	8-5
8.2.1 F355 (PID)	8-5
8.3 PID control sample program	8-5
8.4 Example of temperature control	8-5
9.Specifications	9-5
9.1 Specifications	9-5 9
9.1.1 General specifications	9-5 99
9.1.2 Performance specifications	
9.1.3 Specifications (High-Speed Counter/Pulse Output/PWM Output) 9.1.4 Functions and Restrictions (High-Speed Counter/Pulse Output/PWM Output)	9-5 9)9-5
9.2 I/O Allocation	9-5
9.3 Relays,memory Areas and Constants	9-5
9.4 ASCII characters displayed in the FP-e unit	9-5
9.4.1 Available ASCII characters	9-5
9.4.2 ASCII code and display	9-5
10.Dimensions	10-5
10.1 Dimensions	10-5

11.	Appendix 11-1
	11.1 System Registers / Special Internal Relays / Special Data Registers 11-3
	11.1.1 Table of System Registers for FP-e11-5
	11.1.2 Table of Special Internal Relays for FP-e11-9
	11.1.3 Table of Special Data Registers for FP-e11-13
	11.2 Table of Basic Instructions 11-20
	11.3 Table of High-level Instructions 11-54
	11.4 Table of Error codes 11-114
	11.5 MEWTOCOL-COM Communication Commands 11-128
	11.6 Hexadecimal/Binary/BCD 11-129
	11.7 ASCII Codes 11-130

Precautions before using FP-e unit

Installation environment

- Do not use the FP-e Control Unit in the places where it will be exposed to the followings:
- Direct sunlight and ambient temperature outside the range of 0°C to 55°C (32°F to 131°F).
- Ambient humidity outside the range of 30% to 85% RH(at 25°C) and sudden temperature changes causing condensation.
- Inflammable or corrosive gas.
- Excessive vibration or shock.
- Excessive airborne dust, metal particles or salts.
- Water or oil in any from including spray or mist.
- Benzine, paint thinner, alcohol or other organic solvents or strong alkaline solutions such as ammonia or caustic soda.
- Influence from power transmission lines, high voltage equipment, power cables, power equipment, radio transmitters, or any other equipment that would generate high switching surges.

Static electricity

- Before touching the unit, always touch a grounded piece of metal in order to discharge static electricity.
- In dry locations, excessive static electricity can cause problems.

Cleaning

- Do not use thinner based cleaners because they deform the unit case and fade the colors.

Power supply

- An insulated power supply with an internal protective circuit should be used. The power supply for the control unit operation is a non-insulated circuit.
- If using a power supply without a protective circuit, power should be supplied through a protective element such as a fuse.
- If an incorrect voltage is directly applied, the internal circuit may be damaged or destroyed.

Power supply sequence

- Have the power supply sequence such that the power supply of the control unit turns off before the power supply for input and output turns off.
- If the power supply for input and output is turned off before the power supply of the control unit turns off, the control unit will detect the input fluctuations and may begin an unscheduled operation.

Before turning on the power

When turning on the power for the first time, be sure to take the precautions as shown below.

- When performing installation, confirm that there are no scraps of wiring, particularly conductive fragments, adhering to the unit.
- Confirm that the power supply wiring, I/O wiring, and power supply voltage are all correct.
- Sufficiently tighten the installation screws and terminal screws.
- Set the RUN/PROG. switch to PROG. mode.

Before entering a program

Be sure to perform a program clear operation before entering a program.

Operation procedure when using Windows software FPWIN GR Ver. 2

- 1. Press "CTRL" and "F2" keys at the same time to switch the display to "Online Monitor."
- 2. Select [Edit (E)] \rightarrow [Program Clear (L)] on the menu.
- 3. When the confirmation dialog box appears, click [Yes (Y)] to clear the program.

Storing a program

To prevent the accidental loss of programs, users are requested to take the following measures. **Drafting documents**

To avoid accidentally losing programs, destroying files, or overwriting the contents of a file, documents should be printed out and then saved.

Specifying the password carefully

The passward setting is designed to avoid programs being accidentally overwritten. If the password is forgotten, however, it will be impossible to overwrite the program even if you want to. Also, if a passward is forcibly cleared, the program is deleted. When spesifying the passward, note it in the spcifications or in another safe locaton in case it is forgotten at some point.

Battery

Do not install the battery when it is not used.

There is a possibility of leak if the battery remains discharged.

Programming tools

			(As of Apr., 2004)
Туре		Restrictions	Instruction used/Function restrictions
Windows coffwore	FPWIN GR Ver. 2	Available.	Available from Ver. 2.2 or higher. $^{*1)}$
	FPWIN GR Ver. 1	Not available.	Not available.
Windows software conforms to IEC 61131-3	FPWIN Pro Ver. 4	Available	Available from Ver. 4.1 or higher. *2)
MS-DOS software	NPST-GR Ver. 4	Not available	Not available
	NPST-GR Ver. 3	Not available.	
	AFP1113V2 AFP1114V2	Not available.	Instructions and functions described in *3 can not be used. Use FPWIN GR or FPWIN Pro.
Handy programming unit	AFP1113 AFP1114	Not available.	Not available.
	AFP1111A AFP1112A AFP1111 AFP1112	Not available.	Not available.

· 1

Notes: Precautions concerning programming tools

- *1) Customers who use FPWIN GR Ver. 2 can upgrade the version from our HP free of charge.
 - Use Ver. 2.3 or higher to set the COM. port to MODBUS S RTU. (MODBUS S RTU is available from FP-e main unit Ver.1.2 or higher.)
- *2) Customers who use FPWIN Pro Ver.4 can upgrade the version from our
- HP free of charge.
 - The COM. port cannot be set to MODBUS S RTU.
 - It will be available from FPWIN Pro Ver. 5.
- *3) Functions that can not be used using a handy programming unit (AFP1113V2 and AFP1114V2):
 - Screen display registry instruction <F180 (SCR)>
 - Screen display switch instruction <F181 (DSP)>
 - Leading edge differential instruction (Initial execution type) <DFI>
 - On-delay timer instruction <TML>
 - Clear multiple steps instruction <SCLR>
 - Floating-point type data instruction <F309> to <F338>
 - PID processing instruction <F355>

Chapter 1

Features and Configurations

1.1 Features and Functions

1.1.1 Features



1. IP 66-compliant panel mounting type

Mounting panel front is waterproof and compliant with IP66, IEC standard. Compact controller: 48 mm (H), 48 mm (W), 70 mm (D)

2. Indicator function

Simple characters and numerical values (with a minus sign) can be displayed up to 5 digits. * 4 modes (N, S, R, and I modes) can be selected. Those 4 modes each have 2 selectable displays. Data indication section can be displayed in red, green, or orange.

3. Operation switches

Set data can be changed. This switch can be used as an input switch.

4. Control function

In addition to the functions of the programmable controller FP0 series, pulse output and high-speed counter functions are installed.

General-purpose communication COM. port is included as standard unit.

FP-e units with the calendar timer or thermocouple input function are also provided.

*Numerical values are displayed only in 16-bit. The data can be displayed in a bit, decimal, or hexadecimal system.

1.1.2 Functions

Item	Description
Power supply	24V DC
Input	8 points ¹¹ (24V DC)
Output	6 points (5 points : Tr. NPN 0.5A, 1 point : Ry 2A)
Program capacity	2.7 k step
Operation speed	0.9 μ/step (Basic instruction)
I/O update and Base time	2 ms ^{*2)}
Pulse catch/Interrupt input	6 points in total (High-speed counter included)
High speed counter	Single phase: 4 points (10 kHz in total)
rligh-speed counter	Dual phase: 2 points (2 kHz in total) ³⁾
Pulse output	2 points (10 kHz in total) ^{*4)}
COM north	RS232C/RS485 (according to models)
	* Must be provided aside from tool ports

*1) Thermocouple input type: 6 points

*2) Thermocouple input type: 2 to 3 ms (Typical), Max: 15 ms. (The time takes longer every 250 ms.)

*3) Thermocouple input type: 5 kHz (Single phase), 1 kHz (Dual phase)

*4) Thermocouple input type: 5 kHz

1.2.1 FP-e control unit

Name	Number of I/O points	Thermo- couple input	Calendar timer	COM port	Product No.
FP-e control unit (Standard type)	Input: 8/Output: 6 (Tr. NPN: 5, Ry: 1)	Not available	Not available	RS232C	AFPE224300
FP-e control unit (Calendar timer type)	Input: 8/Output: 6 (Tr. NPN: 5, Ry: 1)	Not available	Available	RS232C	AFPE224305
FP-e control unit (Thermocouple input type)	Input: 6/Output: 6 (Tr. NPN: 5, Ry: 1)	2 points	Available	RS232C	AFPE214325
FP-e control unit (Standard type)	Input: 8/Output: 6 (Tr. NPN: 5, Ry: 1)	Not available	Not available	RS485	AFPE224302
FP-e control unit (Thermocouple input type)	Input: 6/Output: 6 (Tr. NPN: 5, Ry: 1)	2 points	Not available	RS485	AFPE214322

1.2.2 Related parts

Name	Description	Product No.
Terminal driver	Used for connecting a terminal	AFP0806
Rubber gasket	Used for a waterproof unit (included in a unit package)	ATC18002
Mounting frame	Used for mounting a unit. (included in a unit package)	ATA4811
Battery for FP Σ	Used for calendar timer and operation memory backup. (Included in calendar timer function-provided type and themocouple input type)	AFPG804
Protective cover	Oil resistant soft cover	AQM4803
Terminal socket set	Set of four types of terminal socket for FP-e (Maintenance parts)	AFPE804
Panel cover	Color: Black, with NAiS · FP-e mark	AFPE803
	Color: Ash gray, without NAiS · FP-e mark	AFPE805
(20-pauk)	Color: Black, without NAiS · FP-e mark	AFPE806

1.3 Programming Tool

1.3.1 When using a tool software

- Tools needed for programming



1. Programming tool software

- · The tool software can also be used with the FP series.
- The "FPWIN GR Ver. 2" or "FPWIN Pro Ver. 4" (for Windows) is used with FP-e controllers.
- Note that the earlier "FPWIN GR Ver. 1," "NPST-GR (DOS version), or "FP programmer" cannot be used.

2. PC connection cables

1-4

This cable is needed for connection between the FP-e unit and the computer.

Software environment and suitable cables

Type of software		OS (Operating system)	Hard disc capacity	Product No.
FPWIN GR Ver. 2 English-language menu	Full type	WINDOWS 95 (OSR2 or higher)/ 98/Me/ NT (Ver. 4.0 or higher)/ 2000/XP		AFPS10520
	Upgraded version		40 MB or more	AFPS10520R
	Small type			AFPS11520

- Standard ladder diagram tool software "FPWIN GR Ver. 2"

Note 1) To use the "FP-e," software Ver. 2.2 or higher is required.

The software Ver. 2.3 or higher is required to set the COM. port to MODBUS S RTU. Customers who use the Ver.2 software can upgrade it through our HP free of charge.

Note 2) Customers who use the "FPWIN GR Ver.1" can use the "FPWIN GR Ver. 2" after purchasing the upgraded version software.

(The upgraded version software can be installed only when the "Ver.1.1" has been previously installed.

Note 3) Small type version can be used for the "FP-e," "FP5," "FP0," "FP1," and "FP-M" series.

Type of software		OS (Operating system)	Hard disc capacity	Product No.
FPWIN Pro Ver.4 English-language	Full type	WINDOWS 95 (OSR2 or higher)/	100 MB	AFPS50540
menu	Small type	NT (Ver. 4.0 or higher)/ 2000/XP	or more	AFPS51540

- IEC61131-3-compliant programming tool software FPWIN Pro Ver.4

Note 1)To use the "FP-e software Ver. 4.1 or higher is required.

Customers who use the Ver. 4 software can upgrade it through our HP free of charge. The COM. port cannot be set to MODBUS S RTU. It will be available from FPWIN Pro Ver. 5

Note 2) Small type version can be used for the "FP-e," "FPD," "FP1," and "FP-M" series.

- Type of computer and suitable cables

Connecter	Connecter on PLC side	Product No.
D-Sub 9-pin	Mini DIN round 5-pin	AFC8503
	Mini DIN round 5-pin streight type	AFC8503S

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Chapter 2

Functions and I/O specifications

2.1 Section Names and Functions



①Display mode switch

Changes the display mode to N, S, R, or I. When the switch is pressed for 2 seconds or longer, the front switch key is locked. Pressing the switch once more for 2 seconds or longer unlocks the key.

②Screen changeover switch

Changes the display to 1st Screen or 2nd Screen. When the numerical data is changed, pressing the switch for one second or longer determines the data.

③Front operation switch

Changes the data. This switch is also used as the input switch. Pressing a switch of the digit for which you would like to change the numerical value during the data change adds one to the numerical value displayed. (Data display blinks during the data change.)

④Display screen No.

Indicates the screen number used currently. "1st" or "2nd" is displayed.

⑤Display mode

Indicates "N," "S," "R," or "I."

6LOCK display

Shows that the switch is locked. (This display is lit when "LOCK" using the front switch or "ALL LOCK" using the program is selected.)

⑦RUN/PROG. display

Displays the operation mode (RUN or PROG.).

8 ERR./ALARM display

Indicates when an error or an alarm occurs.

ERR. : Lights up if an error is detected during the self-diagnostic function.

ALARM: Lights up if a hardware error occurs, or if operation slows because of the program, and the watchdog timer is activated.

③Data display (Upper section)

N and S modes

- Display the data registered using the F180 (SCR) command.
- Display the data in red, green, or orange.
- R mode
- Displays the address in the memory area in green.
- I mode
- Displays the external input monitor in green.

Data display (Lower section)

N and S modes

- Display the data registered using the F180 (SCR) command.
- Blink when the numerical value is changed.
- Display the data in red, green, or orange.

R mode

- Displays the data in the memory area in green.
- I mode
- Displays the external output monitor in green.

①Setting display

Indications (e.g.●, °F, °C, h, m, s, SV, and PV) and dot between the digits can be displayed individually by the ladder program.

12 Mode switch (RUN/PROG.)

Changes the mode of the FP-e unit to RUN or PROG. Modes can also be changed from the programming tool.

When performing remote switching from the programming tool, the position of the mode switch and the actual mode of operation may differ.

Verify the mode with the RUN/PROG. display on the front.

When power is supplied, the mode displayed is activated.

(I)Tool port (RS232C)

Used to connect a programming tool.

A commercial mini-DIN 5-pin connector is used for the tool port on the control unit.

4	2°	
ß		
Q	Est '	1
5	3	

Pin No.	Name	Abbr.	Signal direction		
1	Signal ground	SG	-		
2	Send data	SD	Unit \rightarrow External device		
3	Receive data	RD	Unit ← External device		
4	(Not used)	-	-		
5	+5V	+5V	Unit \rightarrow External device		

*The followings are default settings. Use the system register to change the settings.

Baud rate	9600hps
Character bit length	9 hit
Parity check	Odd parity
Stop bit	1 bit

Power supply/COM. port connector
 Input connector
 Output connector
 Battery cover

Note: Colors in the display section

④ to ⑦ and ⑪: green ⑧: red

(9) and (10): red, green, or orange (N and S modes), green (R and I modes)

2-3

2.2.1 Display modes and functions

Mode	N mode (Normal mode)	S mode (Switch mode)	R mode (Register mode)	I mode (I/O monitor mode)
Screen	Registered by F180 (SCR) command	Registered by F180 (SCR) command	NAIS FP-e	NAIS FP-e MODE
Number of screens	2	2	2	2
Display in the upper section	Arbitrary data display (Characters/Nume rical values)	Arbitrary data display (Characters/Nume rical values)	Address in the memory area	 Input status monitor Thermocouple input CH.0 monitor
Display in the lower section	Arbitrary data display (Characters/ Numerical values)	Arbitrary data display (Characters/ Numerical values)	Data in the memory area (Displayed in a decimal number system.)	 Output status monitor Thermocouple input CH.1 monitor
Operation switch	Used for changing numerical values	Used as the input switch	Used for changing numerical values	Used as the input switch
Example	Using the F180 (SCR) command, the elapsed value on the counter is displayed in the upper section, and the set value is displayed in the lower section. The set value can be changed with the front operation switch.	Using the F180 (SCR) command, the message is displayed in the upper section, and the data is displayed in the lower section. The display description can be changed with the input switch.	When program operation is checked, the data description can be checked by specifying the arbitrary memory area with the front operation switch. The data can also be changed with the front operation switch.	When program operation is checked, external I/O status is monitored. The front operation switch can be used as the input switch.(However, the input status of the front operation switch cannot be monitored.)

Note 1) Whenever the display mode switch is pressed, the mode displayed changes as follows: $N \rightarrow S \rightarrow R \rightarrow I \rightarrow N$. The display can also be switched from the program using the F180 (DSP)

 $N \rightarrow S \rightarrow R \rightarrow I \rightarrow N$. The display can also be switched from the program using the F180 (DSP) command.

- Note 2) When the display mode switch is pressed for 2 seconds or longer, the front switch is locked. Pressing the switch once more for 2 seconds or longer unlocks the switch.
- Note 3) Screen changeover switch changes the display to 1st Screen or 2nd Screen.
- Note 4) When the numerical values are changed, pressing the screen changeover switch for one second or longer determines the data.
- Note 5) The operation switches can also be used as input switches in all modes.

Reference: A.2 I/O Allocation

2.2.2 Mode Displays

N (Normal) mode Screen is registered using the F180 (SCR) command.



Upper section: Arbitrary character data or numerical values *
(WX, WY, WR, SV, EV, DT, IX, IY)
Lower section: Arbitrary character data or numerical values *
(WY, WR, SV, EV, DT, IX, IY)

Operation switch: The numerical value in the lower section can be changed when displayed in a decimal or hexadecimal number system.

*Numerical values are displayed only in 16-bit. The data can be displayed in a bit, decimal, or hexadecimal system.

S (Switch) mode



Screen is registered using the F180 (SCR) command.



Operation switch: Can be used as the input switch.

R (Register) mode

Screen cannot be defined using the F180 (SCR) command.



Upper section: Device type (DT, WR, SV, or EV) and its address in the memory area Lower section: Data in the memory area

Operation switch: Device type (DT, WR, SV, or EV), its address in the memory area, and data can be changed using this switch.

I (I/O monitor) mode

Screen cannot be defined using the F180 (SCR) command.



1st Screen: Upper section: External input (WX0) monitor display

Lower section: External output (WY0) monitor display

2-5

2nd Screen: Upper section: Temperature display of the thermocouple input CH.0 Lower section: Temperature display of the thermocouple input CH.1

Operation Switch: Can be used as the input switch.

2.3.1 Input specifications

-	DC	input	specifications	(X0 toX7)
			opooniounono	(/// //////////////////////////////////

	tem	Description
Number of input		8 points
Number of input		6 points (thermocouple input type)
Insulation method		Optical coupler
Rated input voltage	e	24 V DC
Operating voltage	range	21.6 to 26.4 V DC
Rated input curren	t	Approx. 4.3 mA
		8 points/common,
		6 points/common (thermocouple input type)
Input points per co	mmon	(Either the positive or negative of the input
		power supply can be connected to
		common terminal.)
ON voltage/ON cur	rent	19.2 V or less / 4 mA or less
OFF voltage/OFF c	oltage/OFF current 2.4 V or more / 1 mA or more	
		Approx. 5.1 kΩ (X0, X1)
Input impedance		Approx. 5.6 kΩ (X2 to X7)
		50 µs or less (X0, X1) Note)
Response time	OFF to ON	100 µs or less (X2 to X5) Note)
		2 ms or less (X6, X7)
		50 us or less (X0_X1) Note)
ON to OFF		$100 \mu s or less (X2 to X5)^{Note}$
		2 ms or less (X6, X7)
Operation indicato	r	LCD display (I/O monitor mode)

Note) X0 through X5 are inputs for the high-speed counter and have a fast response time. If used as normal inputs, you are recommend to insert a timer in the ladder program as chattering and noise may be interpreted as an input signal.

Also, the above specifications apply when the rated input voltage is 24V DC and the temperature is 25 $^{\circ}$ C.

Internal circuit diagram



	R ₁	R ₂
X0 and X1	5.1 kΩ	3 kΩ
X2 to X5	5.6 kΩ	2 kΩ
X6 and X7	5.6 kΩ	1 kΩ

- Thermocouple input specifications

ltem	Specifications
Number of input	2 points (CH0: WX1, CH1: WX2)
Temperature sensor type	Thermocouple type K
Input range	- 30.0 to 300.0 °C ^{*1)} (- 22 to 572 °F)
Accuracy	±0.5%FS±1.5 °C (FS = -30 to 300 °C)
Resolution	0.1 °C
Conversion time	250 ms/2CH ^{*2)}
Insulation method	Between internal circuit and thermocouple input circuit: noninsulated ^{*3)} Between CH0 and CH1 of thermocouple input: PhotoMos insulation
Detection function of wire disconnection	Available

*1)Temperature can be measured up to 330 °C (626 °F). When the measured temperature exceeds 330 °C (626 °F) or the thermocouple wiring is disconnected, "K20000" is written to the register.

*2)Temperature conversion for thermocouple input is performed every 250 ms. The conversion data is updated on the internal data register after the scan is completed.

*3)The internal circuit and thermocouple input circuit are not insulated. Therefore, use the nongrounding type thermocouples and sheath tubes.

Note:

- To prevent the influence of noise, use the shielded thermocouples and compensating lead wires after grounding them. When the shielding types are not used, thermocouples and compensating lead wires should be used less than 10 m.
- When the wire of the thermocouple is extended, be sure to use compensating lead wires according to the thermocouple type.
- It takes about 2 seconds until the input processing is completed after the power is supplied.
 Therefore, the input data is necessary to be valid after the temperature input completion flags X4E (CH0) and X4F (CH1) turn ON.

After that, the temperature input completion flags turn on for only one scan at every time that the temperature conversion process has been completed (every 250ms approx).

- 1 to 50 times (Average) can be set using the system register 409. The initial setting is "0." (Average: 20 times)
- Set the value to 20 or more to prevent the fluctuation of the thermocouple input value.
- For accurate temperature measurement, we recommend to warm up the unit for 30 minutes after the power is supplied.
- Connecting/disconnecting the thermocouple input terminal block while the thermocouple unit is ON will lower accuracy temporarily. In that case, it is recommended to warm up the unit for at least 15 minutes.
- A rapid temperature change in the thermocouple unit might change the temperature data temporarily.
- Prevent a direct air (wind) from the cooling fan built in the control panel etc. The direct air (wind) to the thermocouple unit will lower accuracy.

Input temperature	Internal data (WX1 and WX2)
- 30.0 °C (- 22.0 °F)	K-300 (K-220)
25.0 °C (77.0 °F)	K 250 (K 770)
200.0 °C (392.0 °F)	K2000 (K3920)

Example of Input temperature and internal data processing

To display the temperature in the Fahrenheit scale (°F), turn Y37 contact ON.

 $F = C \times 9/5 + 32$

F: Fahrenheit, C: Celsius, 0 °C = 32 °F, 100 °C = 212 °F

2.3.2 Output specifications

-Transistor output specifications (For Y0 to Y4)

Item		Description (NPN)	
Number of output		5 points	
Insulation method		Optical coupler	
Output type		Open collector	
Rated load voltage		5 to 24 V DC	
Operating load voltage range	9	4.75 to 26.4 V DC	
Max. load current		0.5 A	
Max. surge current		1 A	
Output points per common		5 points/common	
OFF state leakage current		100 μA or less	
ON state voltage drop		1.5 V or less	
		50 µs or less (For Y0 and Y1)	
Response time		1 ms or less (For Y2,Y3 and Y4)	
Response time	ON to OFF	50 µs or less (For Y0 and Y1)	
		1 ms or less (For Y2,Y3 and Y4)	
External newer supply Voltage		21.6 to 26.4 V DC	
(Eor driving internal circuit)	Current	6 mA/point (For Y0 and Y1)	
	Guirent	3 mA/point (For Y2, Y3, and Y4)	
Surge absorber		Zener diode	
Operation indicator		LCD display (I/O monitor mode)	

Internal circuit diagram



- Relay output specifications (Y5)

Iten	n	Description	
Number of output	t	1 point	
Output type		Normally open (1 Form A)	
Rated control cap	acity	2 A 250 V AC, 2 A 30 V DC Note1)	
Output points per	common	1point/common	
Posponso timo	OFF to ON	Approx. 10 ms	
Response time	ON to OFF	Approx. 8 ms	
Life time Mechanical		Min. 20,000,000 operations	
Electrical		Min. 100,000 operations (resistive load) Note2)	
Surge absorber		None	
Operation indicat	or	LCD display (I/O monitor mode)	

Note1) Resistance load

Note2) Open/Close frequency: 20 times/min (at the rated control capacity)

Internal circuit diagram



2.4 Display/Front Operation Switch Specifications

- Display section specifications

İtem	Description				
Data display	5 digits with a decimal point. (Minus sign can also be used.) Note				
Data display	7-segment, color selectable display (Green, red, or orange)				
Mark display	PV SV (Green, red, or orange)				
Mark display	● °F °C h m s (Green)				
	4 modes (Green)				
	N: Normal modeSimple characters, data display,				
	data setting/data input switch				
	S: Switch modeSimple characters, data setting/PLC external				
Display mode	input switch				
	R: Register modeInternal data, timer/counter value reading				
	and writing modes				
	I : I/O monitor modeI/O status display/PLC external input switch				
Screen No.	1 2 _(Green)				
Status display	LOCK, RUN and PROG. (Green) ERR ALARM (Red)				
	8 points For mode switching 1 point				
Switch input	For screen switching 1 point				
Switch input	For data setting or external input 6 points				
	*Refer to the input address (below) for external input.				
Display	Negative backlight LCD				
Display	(Colors in the numerical section can be changed: green, red, or orange				
	7-segment 6.7 mm LOCK				
Size of the	PV SV 1.6 mm ERR ل 1.4 mm				
characters	N S R I 1.7 mm ALARM				
	● °F °C h m s 1.6 mm				

Note: Numerical values are displayed only in 16-bit. The data can be displayed in a bit, decimal, or hexadecimal system.

- Front operation switch (External input address)

When the front operation switch is used for external input, use the allocated addresses as shown below.



Example: When "0" is pressed during the S mode, "X30" and "X38" turn ON at the same time.



2-9

2.5 Calendar timer

2.5.1 Area for calendar timer

With the clock/calendar function, data indicating the hour, minute, second, day, year and other information stored in the special data registers DT9053 to DT9057 can be read using the transmission instruction and used in sequence programs.

Special data Register No.	Upper byte	Lower byte	Reading	Writing
DT9053	Hour data H00 to H23	Minute data H00 to H59	Available	Not available
DT9054	Minute data H00 to H59	Second data H00 to H59	Available	Available
DT9055	Day data H01 to H31	Hour data H00 to H23	Available	Available
DT9056	Year data H00 to H99	Month data H01 to H12	Available	Available
DT9057	_	Day- of - the- week data H00 to H06	Available	Available



Note:

- 1. The area above is available for the FP-e unit with a calendar timer function.
- 2. The value is not fixed initially when the battery is connected. Set the appropriate value to the calendar timer.

Lithium battery is included in the FP-e unit, but it is not connected to the unit. Connect the battery to the unit before using the FP-e controller.

- 3. Put in a new battery within a minute after removing the old battery.
- 4. A calendar timer is available only when a battery is installed.

2.5.2 Setting of calendar timer function

There are two ways to set the calendar timer function as described below.

- Setting using FPWIN GR

- 1. Press the [CTRL] and [F2] keys at the same time, to switch the screen to [Online].
- 2. Select "Set PLC Date and Time" under "Tool" on the menu bar.

PLC Date and Time setting dialog box



The above steps display the "Set PLC Date and Time dialog box" shown on the left. Input the date and time, and click on the "OK" button.

- Setting and changing using program

- 1. The values written to the special data registers DT9054 to DT9057, which are allocated as the calendar timer setting area, are transferred.
- 2. A value of H8000 is written to DT9058.

Example: showing the date and time being written

Set the time to 12:30:00 on the 5th day of October, 2002 when the X0 turns ON.



2.5.3 Accuracy of calendar timer

Accuracy 200 s / month (0 °C) 70 s / month (25 °C) 240 s /month (55 °C)

2.6 Limitations in data hold/non-hold function

Setting a system register can expand the data hold area. In this case, however, a back-up battery must be previously installed.

Product No.	Settings Note 1	Data
AFPE224300	System register setting	Non-hold
AFPE224302		
AFPE224322 Note 2		
AFPE224305	System register setting with a back-up battery	Hold
AFPE214325	System register setting without a back-up battery	Non-hold

Note 1: System register settings are effective only when a back-up battery is installed in the FP-e control unit.(A set value will be returned to the default value.)

Note 2: A back-up battery cannot be installed in this type of product.

System register setting screen – (Hold/Non-hold)

Areas for Nos. 6, 7, 8 and 14 can be expanded.

PLC Configuration - Unti	tle1		×
Interrupt Input Hold/Non-hold	Temperature input Too Action on Error Time	IPort COMPort High Speed Counter	<u>o</u> k (
No.5 Counter starting	address	(0-144)	<u>C</u> ancel
No.6 Hold type area s	tarting address for timer/counter	140 (0-144)	<u>B</u> ead PLC
No.7 Hold type area s	tarting word address for internal relay	61 (0-63)	Initialize
No.8 Hold type area s	tarting address for data registers	1652 (0-1660)	<u>H</u> elp
No.14 Step Ladder ho	old 🗖		
NOTICE: In case of no the hold area	ot using back-up battery(option),we can't value.	t guarantee	

Note: "NOTICE" in the screen above is described for the FPWIN GR Ver. 2.24 or higher.

Note: System register initial values on Hold/Non-hold tab are within the ones that can be backed up with a ROM.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Chapter 3

Installation and Wiring

3.1 Installation

3.1.1 Operating environment

Avoid mounting the unit in the following locations:

-Ambient temperatures outside the range of 0 °C to 55 °C.

-Ambient humidity outside the range of 30 % to 85 %RH (at 25 °C, non-condensing).

-Sudden temperature changes causing condensation

- -Corrosive and inflammable gases
- -Excessive airborne dust, metal particle, or salts
- -Benzine, thinner, alcohol or other organic solvents, or strong alkaline solutions such as ammonia or caustic soda
- -Excessive vibration or shock
- -Direct sunlight
- -Water, oil, or chemicals in any form including spray or mist

Measures regarding noise:

-The unit should be installed apart from the high voltage cables, high voltage equipment, power cables, power equipment, or any other equipment that would generate high switching surges.

-The unit should also be installed apart from the devices which have radio transmitters.

-If noise occurs in the power supply line even after the above countermeasures are taken, you are recommended to supply power through an insulation transformer, noise filter, or like.

Measures regarding heat discharge:

-Always amount the unit oriented with the LCD facing upward in order to prevent the generation of heat. Do not amount the units vertically as shown below.



-Do not install the unit as shown below.



-Do not amount the unit above which generate large heat such as heaters, transformers, or large scale resisters.

Note that the ambient temperature and electrical voltage are restricted when the mounting panel is installed at the angle of 0 (horizontal) to 60.



Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Mounting panel cut size (Unit: mm)

- Standard mounting panel cut size



Mounting panel cut size is shown in the diagram on the left. (Panel thickness: 1 to 5 mm)

-When using two or more units:



Make holes in the specified size as shown in the diagram on the left.

-When mounting units in a row



Units can be mounted horizontally in a row. In that case, however, waterproofing property on the unit will be lost.

When "n" units are mounted in a row, "A" should be:

$$A = (48 \times n - 2.5) \stackrel{+0.6}{0}$$

Note: When mounting the units horizontally in a row:



Mount the units oriented with the molded spring sections of the mounting flame facing upward and downward.



Do not mount the units vertically in a row in order to prevent the generation of heat.

3-3

Installation space

3-4

- Leave at least 50 mm of space between the wiring ducts of the unit and other devices to allow heat radiation and unit replacement.



- Maintain 100 mm or more space between the unit and other devices in order to allow room for programming tool connections and wiring, or to avoid radiated noise and heat from other devices.



3.1.2 Mounting and Removing the Unit

Mounting the unit

Insert the unit into the mounting panel opening from its front and mount the mounting frame from the unit's rear all the way not to have any space with the mounting panel. In addition, secure the mounting frame using screws.



Precautions for mounting

The front of the unit is waterproof, but do not forget to fix the mounting frame using screws to make coherent a unit, rubber gasket and panel front sufficiently.

(Check the both screws are tightened to the same extent and are stable. Tightening too much might remove the mounting frame.)

Always mount a unit with a rubber gasket to keep the unit front section's waterproof.

Removing the unit

Loosen the screws for the mounting frame. Then, pull outward the frame while widening the hooks.



3.2 Terminal Layout Diagram and Terminal Block Wiring

3.2.1 Terminal layout diagram

-Terminal layout diagram

-Wiring diagram



3.2.2 Terminal block wiring

Terminal block used and suitable wire

A screw-down terminal block (from Phoenix Contact Co.) or equivalent is used. The suitable wires are shown below.



-Suitable wires

Size	Nominal cross-sectional area
AWG#24 to 16	0.2 mm^2 to 1.25mm^2
For the COM, port and analog input section	of the thermocouple input type, the suitable

For the COM. port and analog input section of the thermocouple input type, the suitable wire size is AWG#28 to 16 (0.08 mm² to 1.25 mm²).

-Pole terminal with a compatible insulation sleeve

When a pole terminal is used, use the following models from Phoenix Contact Co.

Manufacturer	Cross-sectional area	Nominal cross-sectional area	Parts No.
	0.25 mm ²	AWG#24	AI 0.25-6YE
Phoenix	0.50 mm ²	AWG#20	AI 0.5-6WH
Contact Co.	0.75 mm ²	AWG#18	AI 0.75-6GY
	1.00 mm ²	AWG#18	AI 1-6RD
	0.5 mm ² X 2	AWG#20 X 2	AI-TWIN2 X 0.5-8WH

-Pressure welding tool for pole terminals

Manufacturor	Model No.	
Manufacturer	Parts No.	Product No.
Phoenix Contact Co.	CRIMPFOX UD 6	12 04 43 6

Suitable screwdriver

When tightening the terminals of the terminal block, use a screwdriver (Phoenix Contact Co. Product No.1205037) with a blade size of 0.4 X 2.5 (Model No. SZS 0.4 X 2.5) The tightening torque should be 0.22Nm to 0.25 Nm (2.3 kgfcm to 2.5 kgfcm)

Manufacturor	Model No.		Order product No	
Walturacturer	Parts No.	Product No.	lo.	
Phoenix Contact Co.	SZS0.4 X 2.5	1205037	AFP0806	

Wiring

1. Remove a portion of the wire's insulation.



2. Insert the wire into the terminal block until it contacts the back of the terminal block. Then, tighten the screw clockwise to fix the wire in place.



Notes

-When removing the wire's insulation, be careful not to scratch the core wire.

-Do not twist the wires to connect them.

-Do not solder the wires to connect them. The solder may break due to vibration.

-After wiring, make sure stress is not applied to the wire.

-In the terminal block socket construction, if the wire closes upon counter-clockwise rotation, the connection is faulty. Disconnect the wire, check the terminal hole, and then re-connect the wire.



3-7

3.3 Power Supply Wiring

3.3.1 Power supply wiring

Power supply wire

To minimize adverse effects from noise, twist the wires of the power supply cable.

Power supply type

-To protect the system against erroneous voltage from the power supply line, use an insulated power supply with an internal protective circuit.

-The regulator on the FP-e is a non-insulated type.

-When using a power supply device without an internal protective circuit, male sure power is supplied to the unit through a protective element such as a fuse.

Power supply voltage

Rated voltage	24 V DC
Operating voltage range	21.6 V DC to 26.4V DC

Wiring system

Isolate the wiring systems to the control unit, input/output devices, and mechanical power devises.

Circuit breaker



Insulated DC power supply

Power supply sequence

-The power supply sequence should be set so that power to the FP-e is tuned off before the input/output power turns off.

-If the input/output power supply turns off before the power to the FP-e turns off, the FP-e will detect the input fluctuations and may start an unscheduled sequential operation.

3-8

3.3.2 Grounding

Grounding to prevent noise

Under normal conditions, the inherent noise resistance is sufficient. However, in situations of excessive noise, ground the instrument to increase noise suppression.

Use an exclusive ground

- For grounding purpose, use wiring with a minimum of 2 mm². The grounding connection should have a resistance of less than 100Ω .
- The point of grounding should be as close to the FP-e unit as possible. The ground wire should be as short as possible.
- If two devices share a single ground point, it may produce an adverse effect. Be sure to use an exclusive ground for each device.



- **Note:** Depending on the surroundings in which the FP-e unit is used, grounding may cause problems.
- **Example:** The power supply line of the FP-e unit is connected to the function earth through a varistor. If there is an irregular potential between the power supply line and the earth, the varistor may be shortened.



FP-e power supply line

Do not ground an FP-e function earth terminal when grounding a plus (+) terminal of the power The FP-e tool port shielding and function earth terminal are connected.

In some computers, the SG terminal of RS232C port and connector shielding are connected. When the FP-e is connected to a computer with a plus (+) terminal grounded, therefore, an FP-e's minus (-) terminal is connected with the function earth terminal. As a result, short circuit occurs which may lead to the breakage of FP-e and its neighboring parts.



Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

3.4.1 Input wiring

3-10

- Connection of photoelectric sensor and proximity sensor



- Precaution when using LED-equipped reed switch



When a LED is connected in series to an input contact such as LED-equipped reed switch, make sure that the ON voltage applied to the FP-e input terminal is greater than 19.2V DC. In particular, take care when connecting a number of switches in series.
Precaution when using two-wire type sensor



When the input of FP-e does not turn off because of leakage current from the two-wire type sensors (e.g. photoelectric sensor and proximity sensor), the use of a bleeder resistor is recommended, as shown in the diagram on the left. The formula below is based on an input impedance of 5.6 k Ω The input impedance varies depending on the input terminal number.

I : Sensor's leakage current (mA)

R: Resistance of the bleeder resistor (k Ω)

The OFF voltage of the input is 2.4V. Determine the value of bleeder resistor "R" so that the voltage between the COM terminal and the input terminal will be less than 2.4V.

$$| \times \frac{5.6R}{5.6+R} \le 2.4$$
 $R \le \frac{13.44}{5.6+2.4}$ $(k\Omega)$

The wattage (W) of the resistor is: $W = \frac{(Power supply voltage)^2}{(Power supply voltage)^2}$

Normally, use a value that is 3 to 5 times determined for the value of "W."

- Precautions when using LED-equipped limit switch



If the input of FP-e does not turn off because of the leakage current from the LED-equipped limit switch, the use of a bleeder resistor is recommended as shown in the diagram on the left.

3-11

r : Internal resistor of limit switch $(k\Omega)$

R : Resistance of the bleeder resistor $(k\Omega)$

The OFF voltage of input is 2.4V. When the power supply voltage is 24V, determine the value for the bleeder resistor "R" so that the current will be greater than "I" as shown below:

$$I = \frac{24 - 2.4}{r} \text{ or more}$$

"R" of the bleeder resistor is:

$$R \le \frac{13.44}{5.61 - 2.4} \ (k\Omega)$$

The wattage (W) of the resistor is:

W = $\frac{(Power supply voltage)^2}{R} \times (3 \text{ to } 5 \text{ times})$

Normally, use a value that is 3 to 5 times determined for the value of "W."

3.4.2 Output wiring

Protective circuit for inductive loads

-With an inductive load, a protective circuit should be installed in parallel with the load.

-When switching DC inductive loads with relay output type, be sure to connect a diode across the ends of the load.

When using an AC inductive load (Relay output)





Reverse voltage: 3 times the load voltage Average rectified forward current: Load current or more

Precautions when using capacitive load

When connecting large rush current loads, install a protection circuit (below) to minimize their effect.



Provide over-load protection with an external fuse

There is no fuse protection built into the output circuit. Therefore, in order to protect against overheating of the output circuit by possible short circuit, install an external fuse at each point. However, in cases such as short circuits, the control unit itself may not be able to be protected.

3.4.3 Common precautions for input and output wiring

Separate the input, output, and power wiring

- Be sure to select the thickness (dia.) of the input and output wires while taking into consideration the required current capacity.
- Arrange the wiring so that the input and output wiring are separated, and these wiring are separated from the power wiring, as much as possible. Do not route them through the same duct or bind them together.
- Separate the input or output wire from the power's high voltage wire by at least 100 mm /3.937 in.

3.5 Wiring COM. Port

Terminal layout

- Power supply and COM. port



- COM. Port specifications

COM. port type	RX232C *Note 2	RS485						
Isolation status with the internal circuit	Non-isolated	Isolated						
Transmission distance	15 m	1200 m						
Baud rate	300, 600, 1200, 2400, 4800, 9600, 19200 bit/s	9600, 19200 bit/s ^{*Note 3, 4}						
Communication method	Half-duplex							
Synchro system	Synchronous communication method							
	Stop bit: 1-bit/2-bit							
Transmission data	Parity: None/Even/Odd							
	Data length: 7-bit/8-bits							
Iomat	Beginning code: STX available/STX not available							
	Ending code: CR/CR+LF/None/ETX							
Data output order	Starting from 0 bit per character							
No. of connected units	– 99 ^{*Note 5, 6}							
Communication mode	- General-purpose communication - Computer link - MODBUS S RTU *Note7							

Note1) When communicating between FP-e and other device, it is recommnedable to perform resend Processing as it may be affected by excessive noise depending on the environments installed.

Note2) For RS232C wiring, be sure to use shield wires for higher noise immunity.

- Note3) Set the baud rate of RS485 to both FP-e system register and FP-e internal switch. Set the baud rate of RS232C to FP-e system register.
- Note4) After sending a command from the FP-e in RS485 communication, send a response from the receiving device to the FP-e after the following time has been elapsed. 9600 bit/s: 2 ms or longer 19200 bit/s: 1 ms or longer



3-13

- It takes at least 1 scan time (at least 2 ms) for the FP-e to send back a response after receiveing the command.
- Note5) When our C-NET Adapter or other RS485 device than recommended is connected in the system, the maximum connection number is limited to 32 units.
- Note6) For a RS485 converter on the computer side, SI-35 (from LINE EYE Co., Ltd.) is recommended. (When SI-35 is used in the system, up to 99 units can be connected.)

Note7) MODBUS S RTU (binary communication) is available with FP-e Ver. 1.2 or higher.

- Settings when shipped from factory

System register	Description
No.412	Computer Link
	Character bit: 8 bits
	Parity check: odd
No.413	Stop bit: 1 bit
	Header: STX not exist
	Terminator: CR
No.414	Baud rate: 9600 bit/s
No.415	Unit No.: 1
No.416	Modem: Not enable



3-14

Reference: B.3 System register list

- Suitable wires (twisted wire)

Size	Conductor cross-sectional area
AWG#28 to 16	0.08 mm^2 to 1.25 mm^2
Line a phial dad wire of the phone wiring It is	recommend to ground the chield costion

Use a shielded wire of the above wiring. It is recommend to ground the shield section.

Reference: 3.2 Terminal layout and terminal block wiring

- Recommended cables for RS485 communication

	Cond	ductor	Insul	ator	Cabla		
Cable	Size	Resistance (at 20 °C)	Material	Thickness	Diameter	Applicable cables	
Twist pair with shield	0.5 mm ² (AWG20) or more	Max. 33.4 Ω/km	Polyethylene	Max. 0.5 mm	Approx. 7.8 mm	HITACHI KPEV-S0.5 mm ² × 1P Belden Inc. 9207	
VCTF	0.75 mm ² (AWG18) or more	Max. 25.1 Ω/km	PVC	Max. 0.6 mm	Approx. 6.6 mm	VCTF0.75 mm ² × 2C (JIS)	

Use the transmission cables shown below for the FP-e RS485 communication system.

Cable	Section
Twist pair with shield	Shield Jacket Conductor Insulator
VCTF	Conductor Insulator

*1. Use shielded type twist cables.

- *2. Use only one type of the transmission cables. Do not mix different types of the cables.
- *3. Use twist pair cables under a bad noise environment.
- *4. When connecting two cables to the "+" and "-" terminals of the COM. port (RS485), use the above cables of which conductor cross section is 0.5 to 0.75 mm², and the cross sections of two cables should be the same.

- RS485 wiring and terminal station setting

- 1. For the FP-e unit at RS485 terminal station, wire the transmission line (-) terminal and E-terminal using a short circuit.
- 2. For RS485 transmission line, three or more pairs of cables should not be connected to one station.
- 3. When using shielded cables for RS485 transmission line, connect one end of the shielded cable to the ground. Provide an exclusive ground for each FP-e power supply section and RS485 transmission shield line. Do not share a ground with other lines.



3.6 Safety Measures

3.6.1 Safety measures

System design

In applications in which FP-e is used, malfunctions may occur for the following reasons:

-Power on timing difference between the FP-e system and input/output or mechanical power devices.

-Response time lag when a momentary power failure occurs.

-Abnormality in the FP-e unit, external power supply, or other devices.

In order to prevent a malfunction resulting in system shutdown, take the adequate safety measures as listed below:

- Interlock circuit

When a motor clockwise/counter-clockwise operation is controlled, provide an interlock circuit on the outside of the FP-e unit.

- Emergency stop circuit

Add an emergency stop circuit on the outside of the FP-e unit to turn off the output devices in order to prevent a system shutdown or an irreparable accident when malfunction occurs.

- Start up sequence

The FP-e should be operated after all of the input/output devices and power devices are energized.

Procedure:

-After power is supplied to the FP-e unit, switch the mode from PROG. to RUN. -Install the timer circuit to delay the FP-e startup.

.

Note: When stopping the FP-e unit, the I/O devices should be turned off after the unit has stopped operating.

- Secure grounding

When grounding the FP-e unit next to an inverter, or other such device that produces high-voltage due to switching, avoid common grounding. Use an exclusive ground connection for each device.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

3-16

3.6.2 Momentary power failures

Operation of momentary power failures

If the duration of the power failure is less than 10 ms, the FP-e unit continues to operate. If the power is turned off for 10 ms or longer, operation changes depending on the combination of units, the power supply voltage, and other factors. (In some cases, operation may be the same as that for a power supply reset.)

3.6.3 Protection of power supply and output sections

Power supply

An insulated power supply with an internal protective circuit should be used. The power supply for the control unit operation is a non-insulated circuit, so if an incorrect voltage is directly applied, the internal circuit may be damaged or destroyed. If using a power supply without a protective circuit, power should be supplied through a protective element such as a fuse.

Protection of output

If current exceeding the rated control capacity is being supplied in the form of a motor lock current or a coil shorting in an electromagnetic device, a protective element such as a fuse should be attached externally.

3.7 Memory backup battery

3.7.1 Installation of memory backup battery

(For FP-e unit with a calendar timer function)

Although FP-e units with a calendar timer have a built-in lithium battery, a lithium battery connector is not connected to an FP-e unit connector. Follow the procedure as shown below to connect them.

- 1. Open the battery cover on the top of the FP-e unit.
- 2. Connect the lithium battery connector to the FP-e unit connector.
- 3. Place a lithium battery in the battery holder in the FP-e unit.
- 4. Close the battery cover.



Note: A calendar timer is available only when a battery is installed. Install a new battery within a minute after removing the old battery.

3.7.2 System register setting

(For FP-e unit with a calendar timer function)

- Setting the battery error alarm

In the system register default settings, "No.4 Alarm Battery Error" is set to "OFF." When using the battery, set system register No. 4 of the control unit so that the battery error alarm is turned on.

PLC Configuration setting dialog box



- Setting procedure using FPWIN GR

- 1. Select "PLC Configuration" on the "Option (O)" menu, and click on "Action on Error" tab.
- 2. Turn on "No. 4 Alarm Battery Error" check box.

- Specifying the hold area

In order to use backup functions such as data registers, settings must be entered for system registers Nos. 6 to 12.

For hold area setting using FPWIN GR, select "PLC Configuration" on the "Option (O)" menu, and click on "Hold/Non-hold."

Note: Be sure to install a lithium battery when changing the hold area with the system register or using the calendar timer function.

Ŕ.

Chapter 4

Display and Settings in N (Normal) Mode

4.1 Display and operation in N (Normal) mode



Operation examples

- Values of EV0 and SV0 are displayed in the upper and lower sections of the controller screen respectively, using the F180 (SCR) instruction.
- Pressing the operation switches ("0" to "5") when the value (indicated in decimal or hexadecimal system) is displayed in the lower section changes the value in each digit.
 When the ASCII code or bit is displayed in the lower section, however, it cannot be changed.
- In the data change mode after the operation switch "0" to "5" is pressed, the data in the lower section blinks.
- For writing the changed data, press the screen changeover switch "1/2/SET" for about one second. Then, the blinking stops and the data is written.
- For canceling the data change process before the data is not completely changed, press the operation switch "5" for about one second. Then, blinking the display data stops.
- Pressing the operation switch "5" adds or deletes a minus sign. (when displayed in a decimal system.)
- Pressing the "MODE" switch for about 2 seconds displays "LOCK." In this mode, the data cannot be changed even if the operation switch is pressed.
 The "LOCK" status cannot be cancelled even if the power turns ON/OFF.
- For canceling the "LOCK" status, press the "MODE" switch for about 2 seconds again.

Notes:

- 1. Arbitrary characters and data (WX, WY, WR, SV, EV, DT, IX, or IY) can be displayed in the upper section of the screen.
- 2. Arbitrary characters and data (WY, WR, SV, EV, DT, IX, or IY) can be displayed in the lower section of the screen.
- 3. Numerical values are displayed only in 16-bit. (The data can be displayed in a bit, decimal, or hexadecimal system.
- In a decimal system display: K-32768 to K32767
- In a hexadecimal system display: H0000 to HFFFF
- 4. The front switches can be used as the input contact switches "X38" to "X3F." (Available in the "LOCK" mode as well.)
- 5. Switching the power ON/OFF or RUN/PROG. mode cancels the data changed using the front switches.
- 6. Only the data displayed in the lower section can be changed with the operation switches "0" to "5".

4.2 Instructions to control the display

4.2.1 F180 (SCR): Screen display instruction, Number of steps: 9

Screen display instructions in the N and S modes of FP-e unit

The FPWIN GR wizard facilitates the programming.

F180 SCR, K0, DT0, EV0, SV0] **S1 S2 S3 S4**

- **S1:** Used to specify the registration screen.
- S2: Used to specify the head of the screen display control data (3 words).
- **S3**: Used to specify the data displayed in the upper section (Numerical values are displayed only in 16-bit.)
- **S4:** Used to specify the data displayed in the lower section. (Numerical values are displayed only in 16-bit.)

Example:

F180 (SCR), K0, DT0, EV0, SV0

Registration of N mode 1st screen Control data: DT0, DT1, DT2 Upside display data: EV0 Downside display data: SV0

		wx	WY	WR	sv	EV	DT	іх	IY	к	н	Index modifier
S1	Display mode and No. (0 to 3 can be specified.)	А	A	A	A	А	A	A	A	А	A	A
S2	Head address of the area to specify the display measure.	A	A	A	A	A	A	N/A	N/A	N/A	N/A	A
S3	Area which stores the data to be displayed in the upper section.	A	A	A	A	A	A	A	A	N/A	N/A	A
S4	Area which stores the data to be displayed in the lower section.	N/A	A	A	A	A	A	A	A	N/A	N/A	A

- Available memory areas A: Can be specified N/A: Cannot be specified (Unit: Word)

Note: Special register "DT9***" cannot be specified for the lower section display data "S4." This instruction cannot be used in the interrupt program.

- Specifying the "S1" registration screen

Display type of the FP-e unit can be specified.							
Values for "S1"	Display type						
K0	N mode 1 st screen						
K1	N mode 2 nd screen						
K2	S mode 1 st screen						
K3	S mode 2 nd screen						

- Flag conditions

R9007	Turns ON when the area specified using the
R9008	Index modifier exceeds the limit.
(ER)	Turns ON when the "S1" or "S2" value is outside
	of the range specified.

- Configuration of "S2" screen display control data



0: Not displayed, 1: Displayed





* When a value with a decimal point is to be displayed in the "Signed Dec 5 digits" mode, the value(s) before the decimal point should be displayed.

3rd word Low byte

(Display control: Lower section) Same as the low byte display control data for 2nd word

3rd word High byte

(Display control: Lower section) Same as the high byte display control data for 2nd word

- Examples of control	register	
1 st word "0 0 0 0 0 0 0 <u>0 0</u> ↑ Upper/Lower section display	<u>1</u> 000 ↑ ●	0 0 <u>1</u> <u>1</u> " = H83 ↑ ↑ SV PV
2 nd word "0 <u>1 0</u> <u>0 0 0 0 0</u> ↑ ↑ ↑ 1 Red All digits Zero suppression	<u>0000 (</u> ↑ Decimal p	0 0 0 0" = H4000 point: Not displayed
3rd word " <u>0</u> <u>1</u> <u>1</u> <u>0</u> <u>0</u> <u>0</u> <u>0</u> <u>0</u> ↑ ↑ ↑ 1 Orange All digits Zero suppression	<u>0 0 0 0</u> Decimal	<u>0 0 0 0</u> " = H6000 ↑ point: Not displayed

- ASCII code and its display

When 5 characters from DT0 are displayed (for 5 bytes from DT0):

DT0	H32	H31	(H32:2, H31:1)
DT1	H34	H33	(H34:4, H33:3)
DT2	H36	H35	(H36:6, H35:5)

The ASCII code above are displayed as follows.

12345

- 7-segment data and its display

When the data of 5 digits from DT0 are displayed (Lower byte in 1 word stores the data of 1 digit.): DT0 H3F (7-segment display data H3F: 0) 5th digit (highest-order digit) DT1 H6 (7-segment display data H6: 1) 4th digit DT2 H5B (7-segment display data H5B: 2) 3rd digit DT3 H4F (7-segment display data H4F: 3) 2nd digit DT4 H66 (7-segment display data H66: 4) 1st digit (lowest-order digit) The 7-segment data above are displayed as follows: 171 Ļí 1 1 ŧ

Note) An arbitrary segment can be displayed using this function.

- Display description and data

Value	Со	nvers	ion d	ata	7-segment display data (for 1 digit)									7-segment display				
, and a	(for	1 dig	git)			g	f	е	d	с	b	а		r ooginon alopidy				
0	0	0	0	0	0	0	1	1	1	1	1	1	23					
1	0	0	0	1	0	0	0	0	0	1	1	0						
2	0	0	1	0	0	1	0	1	1	0	1	1	7		LSB			
3	0	0	1	1	0	1	0	0	1	1	1	1	1.1		а			
4	0	1	0	0	0	1	1	0	0	1	1	0	4		b			
5	0	1	0	1	0	1	1	0	1	1	0	1	5		с			
6	0	1	1	0	0	1	1	1	1	1	0	1	2		d	a		
7	0	1	1	1	0	0	1	0	0	1	1	1	- 1		е	f g b		
8	1	0	0	0	0	1	1	1	1	1	1	1	X		f	e C		
9	1	0	0	1	0	1	1	0	1	1	1	1	10		g	d		
Α	1	0	1	0	0	1	1	1	0	1	1	1	X					
В	1	0	1	1	0	1	1	1	1	1	0	0	5		MSB			
С	1	1	0	0	0	0	1	1	1	0	0	1	1					
D	1	1	0	1	0	1	0	1	1	1	1	0	á					
Е	1	1	1	0	0	1	1	1	1	0	0	1	E					
F	1	1	1	1	0	1	1	1	0	0	0	1	F					

	play screen	1	N m	ode The 1st screen	•	NAIS		FP-e
Control d	ata	DT	-	0 (0 - 1657)				
Upside displa	ay data	EV	•	0 (0 · 143)		DUN	193	45
Downside disp	olay data	SV	-	0 (0 - 143)		RON S	1531	45
Mark displa	ay	•	⊏ °F	C °C ₽	v	MODE 1/2/SET 5		
l legide contr		□ h	n m	□s IS	V			
Upside contri Display mode ASCII data	ol Signed E	Downside	control	「 s ▼ S 「 Nondisplay	∨ Digit no □ 5 □ 4	ndisplay — th	Decimal po	pint display
Upside contr Display mode ASCII data Zero suppression	ol Signed I	Downside	control	S S Nondisplay	∨ - Digit no □ 5 □ 4 □ 3	ndisplay — h h	Decimal po	oint display

Using the FPWIN GR wizard facilitates the programming.

Ţ



* FPWIN GR Ver. 2.2 or higher can be used with the FP-e unit. Customers who use the FPWIN GR Ver.2 software can upgrade it through our HP free of charge.

4.2.3 F181 (DSP) : Screen change instruction Number of steps: 3



──┤├───{[F181 DSP , DT 20] **S**

- Avai	lable memory areas	A: Can be specified N/A: Cannot be specified								(Unit: Word)		
		wx	WY	WR	sv	EV	DT	IX	IY	К	Н	Index modifier
s	Display mode and No. (0 to 7 can be specified.)	А	А	А	A	А	А	A	А	А	A	A

- Operation

The FP-e display mode is changed to the one specified using "S."

- Specifying the "S1" registration display

Values for "S"	Display type
K0	N mode 1st screen
K1	N mode 2nd screen
K2	S mode 1st screen
K3	S mode 2nd screen
K4	R mode 1st screen
K5	R mode 2nd screen
K6	I mode 1st screen
K7	I mode 2nd screen

Display type of the FP-e unit can be specified.

- Flag conditions

·

R9007 R9008	Turns ON when the area specified using the index modifier exceeds the limit.
(ER)	Turns ON when the value "S" is not "0" to "7."

Notes: 1. If the value other than "0" to "7" is specified for "S," an operation error will occur. 2. The F181 (DSP) instruction cannot be used during the interrupt program.

4.3 N mode sample program

- Sample program



- Screen display

On N mode 1st screen, EV0 (red) and SV0 (orange) are displayed in the upper and lower sections respectively.

On N mode 2nd screen, EV1 (red) and SV1 (green) are displayed in the upper and lower sections respectively.

- Front switches

Ser 1

Pressing the operation switch "0" to "4" on N mode 1st screen changes the mode to the change mode for SV0.

Note: Data blinks in the change mode.

When the display selection switch "1/2/SET" is pressed for about one second, the data for the SV0 is changed and the blinking of the data stops.

Note: Data which is out of the specified range (16-bit) cannot be written.

When the display selection switch "1/2/SET" is pressed, the current screen changes to 2^{nd} screen. The operation switches ("0" to "5") are locked by the program on 2^{nd} screen. (Y32 is ON.) Even when the operation switch is pressed, therefore, SV1 cannot be changed.

Reference: For further information, see "Locking the Switch" in A.2 I/O Allocation."

Pressing the "MODE" switch for about 2 seconds locks both display selection switch and operation switch. In this "LOCK" status, the display and data cannot be changed. In addition, the "LOCK" status is not cancelled even when the power turns ON/OFF.

Pressing the "MODE" switch for about 2 seconds again unlocks the "LOCK" status. At this time, the "LOCK" display turns off.

4.4 Display screen and lock with the program

- Sample program



- Program operation

Turning ON the "R0" to "R6" switches the screen to be displayed.

Note: Even if the "MODE" switch or the "1/2/SET" switch is pressed under the condition that the "R0" is always set to ON using the sample program, the N1 screen cannot be switched to other screen. Using this function prevents operation mistake of the front switch.

Setting the "Y30" to "Y34" to ON locks the front switch. Using this function prevents operation mistake of the front switch.

Reference: For further information, see "Locking the Switch" in A.2 I/O Allocation.

Chapter 5

Data Display and Settings in S (Switch)

Mode

5.1 Display and operation in S (Switch) mode



The ASCII characters "FP-E-" and the description of the "DT20" are displayed in the upper and lower sections of the controller screen respectively, using the F180 (SCR) instruction.

The front switches can be used as the input contacts "X30" to "X37." The switch can also be used to change the display description, and so on depending on the program.

Note: 1. The front switches are allocated as the input contacts "X30" to "X37" and "X38" to "X3F." "X30" to "X37": The switch can be locked using the program. "X38" to "X3F": The switch cannot be locked using the program.



Reference: For further information, see "Locking the Switch" in A.2 "I/O Allocation."

- 2. Pressing the "MODE" switch for about 2 seconds displays the "LOCK." In this condition, the input contacts "X30" to "X37" cannot be used, but "X38" to "X3F" can be used.
- 3. The input contacts "X30" to "X3F" do not turn ON during the first scanning after the mode is switched to RUN mode.

5.2 S mode sample program



- Screen display

On S mode 1st screen, the ASCII character "FP-E-" is displayed in the upper section in orange.

Reference: See "ASCII character and 7-segment display" in Appendix A of this manual. On 2nd screen, the data of "DT20" is displayed in green.

- Front switches

- When the front switch "0" is pressed, "X30" turns ON and "30" is displayed in the lower section of the screen.
- When the front switch "1" is pressed, "X31" turns ON and "31" is displayed in the lower section of the screen.
- Pressing the "MODE" switch for about 2 seconds locks all the front operation switches and "LOCK" is displayed. In this "LOCK" status, the display cannot be changed even if the front operation switch "0" to "5" is pressed.

5-3

Chapter 6

Data Display and Settings in R (Register) Mode

6.1 Display and operation in R (Register) mode



Device type (DT, WR, SV, or EV) in the memory areas displayed in green.

Specified device type data (16-bit data in the decimal system) is displayed in green.

Used to change the device type and descritpion

- 1. When the device type (DT, WR, SV, or EV) in the memory area is specified using the front operation switch, the specified device type data is displayed.
 - When "PV" blinks, the device type in the memory area can be specified.
 - The device No. can be specified using the switches "0" to "3." The device type can be switched using the switch "4" in the following order: DT→WR→SV→EV
 - **Note:** When specifying the No. which is out of the designated range, the display color in the upper section switches from green to red and the display in the lower section turns off.

2. The specified device data can be changed using the front switch.

- When the switch "5" is pressed for about 1 second, "SV" blinks. In this status, the data can be changed.
- When the switch "0" to "5" is pressed, the data in the lower section is changed and then blinks.
- When the "1/2/SET" switch is pressed for about 1 second, the blinking stops and the data change completes.
- For canceling the data change process before the data is not yet completely changed, press the operation switch "5" for about one second. Then, blinking the display data stops.
- For changing to the device specification mode after the data change has completed, press the operation switch "5" for about one second. When the mode changes to the device specification mode, "PV" blinks.
- The mode cannot be changed to the device specification mode before the data is not yet completely changed. Wait for the completion of the data change process or cancel the data change process to change the mode to the device specification mode.
- **Note:** If you try to change the data to the one which is out of the specified range, the data is displayed in red only when the "1/2/SET" switch is pressed, and blinking does not stop.

When the power ON/OFF or RUN/PR OG. mode switching is performed, the data which is not yet completely changed using the front switch will be cancelled.

The data change can also be cancelled by turning Y38 ON.

(This is available for Ver. 1.1 or higher.)

6-2

- 3. Pressing the "1/2/SET" switch changes the current screen to 1st screen or 2nd screen.
- 4. When "MODE" switch is pressed for about 2 seconds, "LOCK" is displayed. In this "LOCK" status, the display cannot be changed even if any switches are pressed.

6.2.1 Specifying the device type

When "PV" blinks, the device type and No. can be changed.

1. Specifying the device type (Example of "EV")



Press the switch "4" until "EV" is displayed as shown above.

Note: At this moment, the "EV0" data is displayed in the lower section.

2. Specifying the device No. (Example of "EV123")



Specify the device No. "EV123" using the switches "0" to "3."

Note: When specifying the No. which is out of the designated range, the display color in the upper section changes from green to red and the data display in the lower section turns off.

6.2.2 Changing the data

1. Switching to the data change mode



- When the switch "5" is pressed for about 1 second, the "PV" display turns off and then the "SV" blinks. While the "SV" is blinking, data can be changed.
- **Note:** When the switch "5" is pressed for about 1 second again, the "SV" display turns off and the "PV" display blinks. While the "PV" is displayed, the device type can be specified.

2. Changing the data



- Pressing the switch "0" to "5" changes the data displayed. The changed data blinks.
- Pressing the switch "1/2/SET" for about 1 second stops blinking. At this point, data change completes.

Notes:

6-4

1. Press the operation switch "5" for about one second when the data display is blinking to cancel the data under change.

The data change can also be cancelled by turning Y38 ON.

(This is available for Ver. 1.1 or higher.)

- 2. If you try to change the data to the one which is out of the specified range, the data is displayed in red only when the "1/2/SET" switch is pressed, and blinking does not stop.
- 3. When the power ON/OFF or RUN/PROG. mode switching is performed, the data under change will be cancelled.

6.2.3 Changing the unit No. of COM. port

The unit No. specified in the system register can be changed by the front switch (for Ver. 1.2 or higher).

1. Displaying the unit No.



- Press the switch "4" to display the unit No.

2. Switching to the unit No. change mode



- When the switch "5" is pressed for about 1 second, the "PV" display turns off and then the "SV" blinks. While the "SV" is blinking, data can be changed.

Note: When the switch "5" is pressed for about 1 second again, the "SV" display turns off and the "PV" display blinks. While the "PV" is displayed, the device type can be specified.

3. Changing the unit No.



- Pressing the switch "0" and "1" changes the unit No. displayed. The changed No. blinks.
- Pressing the switch "1/2/SET" for about 1 second stops blinking. At this point, data change completes.

Notes:

1. Change the unit No. in PROG. mode.

The unit No. cannot be changed in RUN mode.

- 2. Press the operation switch "5" for about one second when the unit No. display is blinking to cancel the unit No. under change.
- 3. If you try to change the data to the one which is out of the specified range (1 to 99), the changing process of the unit No. is cancelled by pressing the "1/2/SET" switch.
- 4. When the power ON/OFF or RUN/PROG. mode switching is performed, the data under change will be cancelled.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Chapter 7

I (I/O Monitor) Mode

7.1 I/O monitor



1. I/O status of "WX0" and "WY0" can be monitored using 1st screen. - Example:



- **Note:** 1. "Y6" or higher does not exist for the FP-e external output, but it can be used as the contact on the program.
 - 2. In case of forced input/output, the monitoring of the forced input contact is not available.
- Temperature display of the thermocouple input can be monitored using 2nd Screen.
 Example:



Note: Turning Y37 contact ON displays the Fahrenheit degree. (°F)

3. The front switches can be used as the input contacts "X30" to "X37."

Note: 1. The front switches are allocated as the input contacts "X30" to "X37" and "X38" to "X3F." "X30" to "X37": The switch can be locked using the program. "X38" to "X3F": The switch cannot be locked using the program.

Reference: For further information, see "Locking the Switch" in Appendix A, "I/O Allocation" of this manual.

2. Pressing the "MODE" switch for about 2 seconds displays the "LOCK." In this condition, the input contacts "X30" to "X37" cannot be used, but "X38" to "X3F" can be used.

Chapter 8

PID Control

8.1.1 Operation of PID control

PID is a control method widely used in the instrumentation field involving feedback control of process quantities such as temperature, pressure, flow, and fluid level.

- Proportional operation

Proportional operation generates an output which is proportional to the input.



The amount of control is held constant. An offset (steady-state deviation) remains. Proportional control grows stronger as "Kp" is increased.

Kp: Proportional gain

- Integral operation

Integral operation generates an output which is proportional to the integral time of the input.



In combination with proportional operation or proportional-derivative operation, integral operation removes the offset produced by these methods. Integral operation grows stronger as the integral time "Ti" is shortened.

Ti: Integral time

- Derivative operation

Derivative operation generates an output which is proportional to the derivative time of the input.



The advancing characteristic of derivative operation alleviates the adverse effect that the delaying characteristic of the process exerts on control. Derivative control grows stronger as the

Derivative control grows stronger as the derivative time "Td" is increased. In the case of pure derivative operation, control can temporarily become ineffective if noise is input, and this can have an adverse effect on the process being controlled. For this reason, incomplete differential operation is executed.

Td: Derivative time

- PID operation

PID operation is a combination of proportional, integral, and derivative operations.



If the parameters are set to the optimum values, PID control can quickly bring the amount of control to the target value and maintain it there.

8-2

8.2.1 F355 (PID)

- PID control

	Address		Instru	action
1	10	ST	R	10
1	11	F 355(PID)	
		DT		10
]	Address 10 11	Address 10 ST 11 F 355 (DT	Address Instru- 10 ST R 11 F 355 (PID) DT

- Operands

												(•	
		WX	WY	WR	\\/I	SV	EV/	л		C	Constan	ıt	Index
		VVX	VVI	VVIX	VVL	5	LV		•	К	Н	f	modifier
s	Starting number of PID parameter area (31 words)	N/A	N/A	N/A	N/A	N/A	N/A	А	N/A	N/A	N/A	N/A	N/A

- Descriptions

(A: Available, N/A: Not Available)

(Unit: Word)

- PID processing is performed to hold the measured value specified by [S+2] at the set value [S+1], and the result is output to [S+3].
- Derivative control or proportional-derivative control can be selected for the PID processing type.
- Set the PID processing coefficients (proportional gain, integral time and derivative time) and the processing mode and cycle in the parameter table. PID processing will be performed based on these settings.

- Types of PID processing

1. Reverse and forward operations

- When a process has been changed, whether the output will be increased or decreased can be selected.
- \cdot When the measured value decreases, "Reverse operation" is specified to boost the output (heating, etc.).
- When the measured value increases, "Forward operation" is specified to boost the output (cooling, etc.).
- 2. Derivative type (PI-D) and Proportional-derivative type (I-PD)

Derivative type (PI-D): When a set value is changed, fluctuation in the output is large, however convergence is fast.

Proportional-derivative type (I-PD): When a set value is changed, fluctuation in the output is small, however convergence is slow.

- Parameter table settings

[S]		Control mode
[S+1]		Set value (SP)
[S+2]	1	Measured value (PV)
[S+3]		Output value (MV)
[S+4]		Output lower limit
[S+5]		Output upper limit
[S+6]	F	Proportaional gain (Kp)
[S+7]	1	integral time (Ti)
[S+8]		Derivative time (Td)
[S+9]		Control cycle (Ts)
[S+10]		Auto-tuning progress
[S+11]]
~		PID processing work area *
[S+30]		

* For FP-e, [S+11] to [S+30] (20 words) are used as the PID processing work area.

- Flag conditions

R9007	Turns ON when the value set for the parameter is out of range.
(ER)	The area specified using the index modifier exceeds the limit.

8-3

- Descriptions of parameters

1. Control mode: [S]

Select the type of PID processing and auto-tuning ON/OFF using the H constants.

Control r	aada	Value of [S]				
Control r	node	Auto-tuning: Not executed	Auto-tuning: Executed			
Derivative type	Reverse operation	H0	H8000			
(PI-D)	Forward operation	H1	H8001			
Proportional-derivative	Reverse operation	H2	H8002			
type (I-PD)	Forward operation	H3	H8003			

Auto-tuning

The optimum values for the Kp, Ti, and Td of the PID parameters can be measured by checking the process response. When auto-tuning is executed, the estimated results are reflected in the parameter area after auto-tuning has been completed. (There may be cases in which auto-tuning cannot be executed, depending on the process. If this happens, a value returns to the original parameter operation value.)

Reverse and forward operations

When a process has been changed, whether the output will be increased or decreased can be determined.

Reverse operation: When the measured process value decreases, the output will be boosted. (Example: heating, etc.)

Forward operation: When the measured process value increases, the output will be boosted. (Example: cooling, etc.)

Derivative type (PI-D) and Proportional-derivative type (I-PD)

When the set value is changed, the output changes.

Derivative type (PI-D): When a set value is changed, fluctuation in the output is large, however, convergence is fast.

Proportional-derivative type (I-PD): When a set value is changed, fluctuation in the output is small, however, convergence is slow.

2. Set value (SP): [S + 1]

Set the target value (temperature set value) within the following range which determines the amount of process control. K0 to K10000

3. Measured value (PV): [S + 2]

Set the current process control value (temperature data WX1 and WX2) within the following range. K0 to K10000

4. Output value (MV): [S + 3]

The result of PID processing is stored. Use the PWM output function to output it to the process. K0 to K10000

5. Output lower limit value: [S + 4] K0 to K9999 (< upper limit value)

6. Output upper limit value: [S + 5]

K1 to K10000 (> lower limit value) Specify the range of the output value (MV). The values specified for the range are output. The limits should be as follows; $0 \le$ Output lower limit value < Output upper limit value ≤ 10000
7. Proportional gain (Kp): [S + 6]

Specify the coefficient used for PID processing.

The set value \times 0.1 will be the actual proportional gain.

The setting range is K1 to K9999 (0.1 to 999.9, Specify the range in increments of 0.1.) When the auto-tuning is selected for the specified control mode, the set value is automatically adjusted and rewritten.

8. Integral time (Ti): [S + 7]

Specify the coefficient used for PID processing.

The set value \times 0.1 will be the actual integral time.

The setting range is K1 to K30000 (0.1 to 3000 sec., Specify the range in increments of 0.1 sec.) When the set value is "0," the integration is not executed.

When the auto-tuning is selected for the specified control mode, the set value is automatically adjusted and rewritten.

9. Derivative time (Td): [S + 8]

Specify the coefficient used for PID processing.

The set value \times 0.1 will be the actual derivative time.

The setting range is K0 to K10000 (0 to 1000 sec., Specify the range in increments of 0.1 sec.) When the auto-tuning is selected for the specified control mode, the set value is automatically adjusted and rewritten.

10. Control cycle (Ts): [S + 9]

Specify the cycle for executing PID processing. The set value \times 0.01 will be the actual control cycle. The setting range is K1 to K6000 (0.01 to 60.00 sec., Specify the range in increments of 0.01 sec.)

11. Auto-tuning progress: [S + 10]

When the auto-tuning is specified in the control mode, the progress of the auto-tuning is indicated. The values for K1 to K5 are stored based on the progress from the default value of "0." When the auto-tuning has been completed, the value returns to the default value.

12. PID processing work area: [S + 11] to [S + 30]

This work area that is necessary for PID processing is used in the system.



- Precautions when executing auto-tuning

When "Execute auto-tuning" is specified using the parameter table (control mode [S]), attention should be paid to the following points.

- \cdot Before the auto-tuning is executed for the first time, confirm the range of the set values for [S] to [S + 30].
- After the auto-tuning has been completed, the control mode [S] area is automatically rewritten from H8000-H8003 to H0-H3. Make sure the mode is not rewritten again in the program.
- After the auto-tuning has been completed, the optimum values are stored for the proportional gain (Kp), the integral time (Ti) and derivative time (Td). Before executing the auto-tuning, however, the appropriate values (e.g. the lower limit value) within the specified setting range must be set.
- After the auto-tuning has been completed, the optimum values are stored for the proportional gain (Kp), the integral time (Ti) and derivative time (Td). Be careful that the stored values are not inadvertently rewritten.
- In the auto-tuning, the optimum values for Kp, Ti and Td are calculated for the set value (SP) by checking the fluctuations of the measured values (PV) when the output value (MV) is the upper limit and lower limit.
- During this process, the set value (SP) can exceed the measured value (PV).
- · The output value (MV) in the auto-tuning fluctuates at least three times:
- Upper limit output Lower limit output Upper limit output

If the value for the auto-tuning progress remains "0" after the fluctuation is performed more than twice, shorten the control synchronization period (Ts) and then execute the auto-tuning once more.

- Precautions during programming

- A 31-word area is required for the parameter table, including the work area for processing. Take care that other instructions do not overwrite the values in this area.
- · An error will not be detected even if the parameter table exceeds its area. When specifying [S], select a number at least 31 words before the last number.
- \cdot Take care that the area is not exceeded due to index modification. An error will not be detected even if the area is exceeded.
- · For the current measured value [S+2], input the temperature data (WX1 and WX2).
- \cdot Output the result of PID processing [S+3] to the process using the PWM output function.
- · For FP-e, this instruction F355 (PID) cannot be programmed in the interrupt program.

8.3 PID control sample program

- PID control

When a K-type thermocouple is connected with the thermocouple input of FP-e, PID temperature control can be easily conducted. (In addition, parameter setting can be automatically selected using "AUTO TUNING.")



- Thermocouple input specifications

Item	Description
Number of input point	2 points (CH0: WX1, CH1: WX2)
Temperature sensor type	K-type thermocouple
Input temperature range	- 30.0 to 300.0 °C (- 22 to 572 °F)
Accuracy	±0.5 %FS±1.5 °C (FS = - 30 to 300 °C)
Resolution	0.1 °C
Conversion time	250 ms/2CH
Insulation method	Between internal circuit and thermocouple input circuit: noninsulated Between CH0 and CH1 of thermocouple input: PhotoMos insulation
Detection function of wire disconnection	Available

Reference: Description of the specifications <2.3.1 Input specifications>

- Thermocouple

A thermocouple is the sensor that measures the temperature using the thermoelectromotive force generated by the temperature difference between two metal wires connected, whose materials are different.

- (1) Screen display setting sample program

Sample program

0	- P1	V = D)T202, S1	√ = C	T2	01										
	R9013	-[F0	MV	,	Н	23	,	DT	0]						
	-	[F0	MV	,	Н	6001	,	DT	1]						
	-	[F0	MV	,	Н	2001	,	DT	2]						
	-	[F1	80 SCR	,	K	0	,	DT	0	,	DT	202	,	DT	201	

Screen display setting: K0 (N mode 1st screen) Display control data: D0 to D2 Upper section display data: DT202 Lower section display data: DT201

Screen display

Screen display setting	: K0: N mode 1 st screen
Display control data	: DT0: H23: ^o C, PV, SV display DT1: H6001: Signed Dec 5 digits, 2 nd decimal place display, Orange DT2: H2001: Signed Dec 5 digits, 2 nd decimal place display, Green
Upper display data	: DT202: Measured temperature
Lower display data	: DT201: Set temperature

- (2) PID parameter setting sample program

Sample program

25	***	***	****	PID data	table setti	ngs	***	****	**>	*****
	R9013	-[F0	MV	,	H 0		DT	200]	Control code
	-	[F0	MV	,	K 550	,	DT	201	1	Set temperature (SP)
36		-[F0	MV		WX 1		DT	202	1	Current temperature (PV)
42		-[F0	MV	x)	KO		DT	203	1	PID output value (MV)
	-	[F0	MV	,	КО	,	DT	204	1	PID output lower limit
	-	[F0	MV	,	K 10000		DT	205	1	PID output upper limit
	2	[F0	MV	,	DT 1652	,	DT	206	1	Proportional gain (Kp)
	-	[F0	MV	,	DT 1653	,	DT	207	1	Integral time (Ti)
	-	[F0	MV		DT 1654		DT	208	1	Derivative time (Td)
	-	[F0	MV	,	K 100	,	DT	209	1	PID çvcle (Ts)
	-	[F0	MV	,	КО		DT	210	1	Auto-tuning progress

Note: DT211 to DT230 are used for the PID processing work area. Therefore, do not use them for other uses.

- Control code



Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net



- (3) PID processing sample program Sample program

Notes:

1. Before starting the auto-tuning for the first time, set the parameters (Kp, Ti, Td) specified for the PID control.

(Using the FPWIN GR data monitor facilitates the setting.)

Setting example

- · DT1652: K1 Proportional gain (Kp)
- · DT1653: K1 Integral time (Ti)
- · DT1654: K0 Derivative time (Td)
- 2. To store the PID control parameters obtained in the auto-tuning, write them in the storage type data area (e.g., DT 1652 to DT1653) when the auto-tuning is completed.

- (4) Heater PWM control sample program Sample program



Setting the input timing

Set the input timings as shown below so that the temperature conversion cycle (250 ms for FPe), PID control cycle (DT209) and PWM output cycle (TM0) are all equal, or PID control cycle takes longer than other two cycles.

Correct:

Correct:		I Tad I I	1
\cdot Tad = Tpid = Tout	Temperature conversion cycle (250 ms) —		
	PID control cuole (DT200) -	< Tpid >	
· Tad < Tpid > Tout		Tout	a.
Incorrect: · Tad > Tpid < Tout	PWM output cycle (TM0)	\leftrightarrow	

8.4 Example of temperature control

- Example of auto-tuning

Control cycle: Ts = K100 (1 s)

Selected parameter: Proportional gain (Kp) = K171 (17.1), Integral time (Ti) = K600 (60 s),



- The temperature input conversion for FP-e is performed every 250 ms. The average cycle (1 to 50 times) can be set using the system register 409. The initial setting is "0." (Average: 20 times) When the heat capacity of the control system is small and heating/cooling is performed at high speed, set a value for the average time to a smaller one.
- Executing the auto-tuning sets the parameters suitable for any control system automatically. Optimum control can be conducted by changing the values (1/2 to 2 times).

Generally, Kp (proportional gain) affects on the response characteristics. As the value of Kp becomes larger, the response error becomes smaller. When the value is too large, however, it may cause the hunting. Ti (Integral time) greatly affects on the response characteristics. As the value of Ti becomes smaller, the response becomes faster. When the value is too small, however, it may cause the overshoot.

- Example of PID parameter characteristics

When Ti is changed to 30, 60, 90, and 120 under the conditions as follows: Ts = 250, Kp = 300, Td = 1



- Example of PID processing



Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Chapter 9

Specifications

9.1.1 General specifications

ltem	Description	
Rated voltage		
Operating voltage range	21.6 to 26.4V DC	
Allowed momentary power off time	10 ms	
Ambient temperature	0 to +55°C	
Storage temperature	-20 to +70°C	
Ambient humidity	30 to 85%RH (at 25 °C, non-condensing	1)
Storage humidity	30 to 85%RH (at 25 °C, non-condensing	1)
Breakdown voltage	Between insulated circuits: 500V AC, 1 min However, between 3) Output terminal (Y5, COM) and other insu- lated circuits: 1500V AC, 1 min (Cut-off current: 10mA, excluding the barrister for protection) Between insulated circuits: 100 MO or	Insulated circuit 1) Power supply terminal, function earth, Input terminal (A0,A1), COM.(RS232C)Terminal 2) Input terminal (COM, X0 to Xn) 3) Output terminal (+, -, Y0 to Y4)
Insulation resistance	higher (measured with 500V DC)	4) Output terminal (Y5, COM) 5) COM. (RS485) terminal
Vibration resistance	10 to 55 Hz, 1 cycle/min. Double amplitude: 0.75 mm, 10 min. on	X, Y , and Z axes
Shock resistance	98 m/s ² , 4 times on X, Y, and Z axes	
Noise resistance	1000V (p-p) with pulse widths 50 ns 1 µs ments)	s (based on in-house measure-
Operating condition	Free from corrosive gases and excessiv	e dust
Electric current	200 mA or less (24V DC), surge current	: 20 A
Protection	IP66-compliant front section (Only when	a rubber packing is used.)
Weight	Approx. 130 g (Weight of the mounting frame and unit	package is not included.)

9.1.2 Performance specifications

Item	<u> </u>	Model	AFPE224300 (Standard type) RS232C	AFPE224302 (Standard type) RS485	AFPE224305 (Calendar timer type) RS232C	AFPE214325 (Thermo- couple input type) RS232C	AFPE224322 (Thermo- couple input type) RS485				
Prog Cont	ramm trol m	ning method/ ethod	Relay symbol/C	Cyclic operation							
Num	ber o	f Control unit	14 points [Input: 8, Outpu	14 points 12 points [Input: 8, Output: 6 (Tr. NPN: 5/Ry 1)] [Input: 6, Output: 6]							
controllable I/O points Front switch input			8 points For m For se For d	8 points For mode switching 1 point For screen switching 1 point For data setting or external input 6 points							
Prog	jram nory	Built-in memory	Built-in EEP-RO	ОМ							
Prog	ram c	apacity	2,720 steps								
Num	ber o	f Basic	83								
instr	uction	n High-level	168 Note ()								
Oper	ration	speed	0.9 µ s/step (Ba	sic instruction)							
I/O u	pdate	and Base time	2 ms			Typical 2 to 3 r	ns Max. 15 ms				
		Internal relay (R)	1,008 points (R	0 to R62F)		•					
ory	ays	Special internal relay (R)	64 points (R900	00 to R903F)							
nts	Rela	Timer/Counter (T/C)	144 points (Initial setting: 100 timer points, T0 toT99/44 counter points, C100 to C143 ^{Note 3})								
oi		Data register (DT)	1 660 words (DT0 to DT1650)								
ati p	2 "	Special data	ו,000 אטוט (10 ט ט ט ט ט ט ט ט ט ט ט ט ט ט ט ט ט ט ט								
Oper	emol	register (DT)	112 words (DT9000 to DT9111)								
•	й ^е	Index registers (IX. IY)	2 points								
Diffe	erentia	I points	Unlimited number of points								
Mast (MCI	ter co R)	ntrol relay points	32 points								
Num LOO	ber of P)	f labels (JP and	64 labels								
Num	ber o	f step ladders	128 stages								
Num	ber of	f subroutines	16 subroutines								
Num	ber of	f interrupt programs	7 programs (ex	ternal: 6, interna	d 1)						
Self-	diagn	ostic function	Watchdog time	r, program synta	ix check, etc.						
Clock/calendar function Note 4)			Not available		Available (year, month, day, hour, minute, second and day of week) However, this can only be used when a battery has becon installed						
Battery life		No battery		220 days or more (actual usage value: approx. 870 days (25 °C) (Periodic re- placement interval: 1 year) (Value applies when no pow- er is supplied at all.)							
Pulse catch input			6 points in total	(X0 and X1.50	us X2 to X5. 10	(au 0					
Interrupt input					μ3, Λ2 το Λ3. ΤΟ	ο μ3)					
CON	I. port	Note 5)	RS232C	RS485	RS232C	RS232C	RS485				
Perie	odical	interrupt	0.5 ms to 30 s								
Con	stant	scan	Available								
Pass	sword		Available								
Noto		the lovel instructions of	ro available for	Vor1 2 or high	or						

Note 2) The time takes longer every 250 ms. Note 3) The proportion of timer points to counter points can be changed using a system register.

- Note 4) Precision of calendar timer: At 0 °C/32 °F, less than 200 seconds error per month At 25 °C/77 °F, less than 70 seconds error per month At 55 °C/131 °F, less than 240 seconds error per month
- Note 5) When using the COM. port to communication with other devices, retransmission is recommended as it may be affected by excessive noise depending on the environments installed. The driver IC for the RS232C port conforms to EIA/TIA-232E and CCITT V. 28 standards.

Item Model			Model	AFPE224300 (Standard type) RS232C	AFPE224302 (Standard type) RS485	AFPE224305 (Calendar timer type) RS232C	AFPE214325 (Thermo- couple input type) RS232C	AFPE224322 (Thermo- couple input type) RS485			
	High-spee function * The com 1-phase x 2-phase x also possi the high-s	d cour binatio 2 ch. a 1 ch. a ible for peed c	nter ons and are r counter.	Counter mode: - Input points: 4 - Max. speed: 1 - Input contact: - Min. input put X3 and X4: 100 Counter mode: - Input points: 2	Addition/subtract ch. (Max.) 0 kHz (total of 4 X0: count inpu X1: count inpu X2: reset inpu X3: count inpu X4: count inpu x5: reset inpu se width: X0, X1 µs (5kHz) 2-phase/individe 2 ch (Max.)	tion (1-phase) [№] ch.) t (ch. 0) t (ch. 1) t ^{Note 7)} tt (ch. 2) t (ch. 3) t ^{Note 7)} : 50µs(10 kHz) ual/direction deci	^{ke 6)}]:Max. 5 kHz]X0, X1: 100µs (sion (2-phase)	5 kHz)			
* For details and I imitations on the high-speed counter, see the following pages.				 Max. speed: 2 Input contact: Min. input puls X3 and X4: 100 	- Input contact: X0: count input (ch. 0) X1: count input (ch. 0) X2: reset input X3: count input (ch. 2) X4: count input (ch. 2) X5: reset input - Min. input pulse width: X0, X1: 50µs(10 kHz)]X0, X1: 100µs (5 kHz)						
S	Pulse outp function	ut	Output points	2 independent (No interpolatio	points (Y0 and Y	′1)					
	* For details and limitations on the high- speed counter, see the follow- ing pages		Output fre- quency	40 Hz to 10 kH 40 Hz to 5 kHz	-point) (2-point)						
	PWM outpu function * For detail and limitat	ut s ions	Output points	2 points (Y0 and Y1)							
	on the high speed cour see the foll ing pages.	n- nter, low-	Output fre- quency	Frequency: 0. 15 Hz to 1 kHz, Duty: 0.1 to 99.9 %							
	Timer			Non-hold (all po	oints)						
dn		Non-	hold type	From set value	to C139		<u>,</u>				
y back	Counter	Hold	type	SV: Non-hold ^N	EV140 to EV143 ote 10)	SV: Hold	5)	SV: Non-hold			
O.	Internal	Non-	hold type	976 points (R	0 to R60F)	61 words (WR0	to WR60)				
em	relay	Hold	type	32 points (R6	10 to R62F)	2 words (WR61	to WR62)				
Š	Data	Non-	hold type	1652 words (E	DT0 to DT1651)	,	,				
	register	Hold type		8 words (DT1652 to DT1659)							

Note 6) The max counting speed (10 kHz) is the counting speed with a rated input voltage of 24 V DC and an ambient temperature of 25 °C. The counting speed (frequency) will decrease depending on the voltage and temperature.

Note 7) If the unit is equipped with both reset inputs X0 and X1, X2 serves as the reset input for X1. If X3 and X4 are used, X5 serves as the reset input for X4.

Note 8) When the positioning control instruction "F168" is performed, the maximum output frequency is 9.5 kHz.

Note 9) The program, system registers and the hold type area (internal relay, data register, and timer/ counter) are backed up by the built-in EEP-ROM. Data can be written 10000 times or less with the EEP-ROM writing instruction. When a battery is replaced with a new one in the FP-e unit with a calendar timer function, settings can be changed using the system register. If a battery is not installed, the data cannot be stored even when the settings of the system register are changed. Note 10) Use the following methods for holding the SV data:

Note 10) Use the following methods for holding the SV data: 1. Set the transfer instruction for the special data register (DT) to hold the data. Then, perform the setting so that the data can be transferred from DT to SV after the RUN mode starts.

2. Use the FP-e model with a battery.

9.1.3 Specifications (High-Speed Counter/Pulse Output/PWM Output)

Table of high-speed counter function specific

Input/Output counter number being used			Built-in high- speed counter	Memory	/ area used		Perform tions	Related instruc- tions		
On/Off output	Count mode	Input contact	chan- nel No.	Con- trol	Elapsed value	Target value	Min. of input	Max. cou speed		
		No (Val- ue in paren- thesis is reset input) (Note 1)		nag	area	area	width	Using only 1 chan- nel	Using multi- ple chan- nels	
Specify the desired output	Incre- mental input	X0 (X2)	CH0	R903A	DT9044 DT9045	DT9046 DT9047	50 µs Note 2)	Max. 10 kHz _{Note 3)}	Total of 4 CH with Max.	F0 (MV), F1 (DMV), F166 (HC1S,
from Y0 to Y5	Decre- mental input	X1 (X2)	CH1	R903B	DT9048 DT9049	DT9050 DT9051		Max. 10 kHz _{Note 3)}	10 KHZ Note 3)	(HC1R)
		X3 (X5)	CH2	R903C	DT9104 DT9105	DT9106 DT9107	100 µs	Max. 5 kHz		
		X4 (X5)	СНЗ	R903D	DT9108 DT9109	DT9110 DT9111		Max. 5 kHz		
Specify the desired output from Y0 to Y5	2- phase input Incre- men- tal/dec remen-	X0 X1 (X2)	CH0	R903A	DT9044 DT9045	DT9046 DT9047	250 µs _{Note 4)}	Max. 2 kHz Note 5)	Total of 2 CH with Max. 2 kHz _{Note 5)}	
	tal input Direc- tional distinc tion	X3 X4 (X5)	CH2	R903C	DT9104 DT9105	DT9106 DT9107	500 µs	Max. 1 kHz		

Note 1) Reset input X2 can be set to either CH0 or CH1. Reset input X5 can be set to either CH2 or CH3.

Note 2) Thermocouple input type: 100 µs

Note 3) Thermocouple input type: Max. 5 kHz.

Note 4) Thermocouple input type: 500 µs

Note 5) Thermocouple input type: Max. 1 kHz

Table of pulse output function specifications

Input/O being u	utput con ised	itact num	ber	Built-in high- speed counter	Memory	area used	Torret	Performance specifica- tions for maximum	Related instruc- tions	
out- put	tional output	input	home input	No.	flag	value area	value area	quency		
Y0	Y2	X0	DT9052 <bit 2=""></bit>	CH.0	R903A	DT9044 DT9045	DT9046 DT9047	Max. 10 kHz for 1-point output Max	F0 (MV), F1 (DMV), F168 (SPD1),	
Y1	Y3	X1	DT9052 <bit 6=""></bit>	CH1	R903B	DT9048 DT9049	DT9050 DT9051	5 kHz for 2-point output	(91 D 1), F169 (PLS)	

Notes: - The maximum 1-point output for instruction F168 (SPD1) is 9.5 kHz. - For the thermocouple input type, the maximum output frequency is 5 kHz (1-point output) and 2.5 kHz (2-point output).

Table of PWM output specifications

Output number being used	Built-in high-speed counter channel No.	Memory area used Control flag	Performance specifications for output frequency	Related instructions
Y0	CH0	R903A	Frequency: 0.15 Hz to 1kHz	F0 (MV), F1 (DMV),
Y1	CH1	R903B	Duty: 0.1% to 99.9%	F170 (PWM)

9.1.4 Functions and Restrictions (High-Speed Counter/Pulse Output/PWM Output)

Channel

The same channel cannot be used by more than one function.

Example of prohibited application:

You cannot share CH.0 with the high-speed counter and pulse output functions.

I/O number (input/output contact point)

The number allocated to each function cannot be used for normal inputs or outputs.

Example of prohibited application

When using CH.0 for 2-phase inputting with the high-speed counter function, you cannot allot X0 and X1 to normal inputs.

When using Y0 for the pulse output function, you cannot allot origin input X0 to a normal input.

When using Y0 for the pulse output (with directional output operating) function, you cannot allot Y2 (directional output) to a normal input or output.

When using the high-speed counter with a mode that does not use the reset input, you can allot the inputs listed in parenthesis in the specifications table to a normal input.

Example of allowable application

When using the high-speed counter with no reset input and 2-phase input, you can allot X2 to a normal input.

Restrictions on the execution of related instructions (F166 to F170)

When any of the instructions related to the high-speed counter (**F166** to **F170**) are executed, the control flag (special internal relay: R903A to R903D) corresponding to the used channel turns on.

When the flag for a channel turns on, another instruction cannot be executed using the same channel.

Example of prohibited application

While executing **F166** (target value match on instruction) and flag R903A is in the on state, **F167** (target value match off instruction) cannot be executed with CH.0.

Restrictions for maximum counting speed/pulse output frequency

The counting speed when using the high-speed counter function will differ depending on the counting mode as shown in the table.

Example 1:

While in the incremental input mode and using the two channels CH.0 and CH.1, if CH.0 is being used at 8 kHz, then CH.1 can be used up to 2 kHz.

Example 2:

While in the 2-phase input mode and using the two channels CH.0 and CH.2, if CH.0 is being used at 1 kHz, then CH.2 can be used up to 1 kHz.

The maximum output frequency when using the pulse output function will differ depending on the output contact number as shown in the table.

Example 1:

When using either only Y0 or only Y1, the maximum output frequency is 10 kHz.

Example 2:

When using the two contacts Y0 and Y1, the maximum output frequency is 5 kHz.

When using the high-speed counter function and pulse output function, specifications will differ depending on the conditions of use.

Example:

9-8

When using one pulse output contact with a maximum output frequency of 5 kHz, the maximum counting speed of the high-speed counter being used simultaneously is 5 kHz with the incremental mode and 1 kHz with the 2-phase mode.

9.2 I/O Allocation

- I/O Allocation of FP-e control unit

Contact	Description	Note
X0	External input	
X1	External input	
X2	External input	
X3	External input	X0 to X5: Used for thermocouple input type.
X4	External input	X6, X7: Not used. (Thermocouple input type)
X5	External input	
X6	External input	
X7	External input	
X8		
	Not used.	
XF		
X10		
	CH 0 Temperature data (W/X1)	Used only for thermocouple input type.
V1E		
X20 :		llood only for the measure input type
	CH.1 Temperature data (WX2)	Osed only for thermocouple input type.
X2F		
X30	Front switch input "0" switch	
X31	Front switch input "1" switch	
X32	Front switch input "2" switch	
X33	Front switch input "3" switch	Available when the mode is set to S or I mode
X34	Front switch input "4" switch	(Not available when the mode is set to "LOCK.")
X35	Front switch input "5" switch	st st
X36	Front switch input "1/2/SET" switch	Note: X30 to X3F do not turn ON in the 1 st scan-
X37	Front switch input "MODE" switch	ning after the mode is set to RUN.
X38	Front switch input "0" switch	
X39 X2A	Front switch input 1 switch	Available in all madee
X3A	From Switch input 2 Switch	Available in all modes
X3B	Front switch input 3 switch	(Available even when the mode is set to LOCK.)
X3C	Front switch input "4" switch	
X3D X2E	Front switch input 5 switch	Note: X30 to X3F do not turn ON in the 1 st scan
X3E X2E	Front switch input 1/2/SET switch	after the mode is set to RUN.
X40	Data setting error (Out of the specified 16-bit)	
X40 X41	Determination of N mode 1 st screen data	
X42	Determination of N mode 2 nd screen data	When the data change starts: 0
X42	Determination of R mode 1 st screen data	When the data is determined: 1
X43 X44	Determination of R mode 2 nd screen data	When the data is determined. I
X45	Not used	2
X46	Not used	
X47	Not used	
X48	Not used.	
X49	N mode 1 st screen data is being changed	
X4A	N mode 2 nd screen data is being changed.	When the data is being changed: 1
X4B	R mode 1 st screen data is being changed.	Date is determined or cancelled: 0 Note 1)
X4C	R mode 2 nd screen data is being changed	
X4D	Not used.	[[*]
X4E	CH. 0 Temperature conversion completion flag	
X4F	CH. 1 Temperature conversion completion flag	
		· · · · · · · · · · · · · · · · · · ·

Note 1) To cancel the data change, press the operation switch "5" for 1 second, or switch the mode using the RUN/PROG. switch.

The data change can also be cancelled by turning Y38 ON. (Ver.1.1 or higher)

Contact	Description	Note
Y0	External output	
Y1	External output	
Y2	External output	
Y3	External output	
Y4	External output	
Y5	External output	
Y6	Not used.	
Y7	Not used.	
Y8	Not used.	
Y9	Not used.	
YA	Not used.	
YB	Not used.	
YD	Not used.	
YD	Not used.	
YE	Not used.	
	"Mode" "1/2/SET" "0" to "5" owitches: Locked	<u>`</u>
130	Widde, 1/2/3E1, 0 to 5 Switches. Locked.	Switch is locked: 1
131	Switch lock (0 to 5) of N mode 1 screen	Switch is sucifable. 0
132 V22	Switch lock (0 to 5) of N mode 2 screen	Switch is available: 0
133	Switch lock (0 to 5) of R mode 7 Screen	
V35	Not used)
Y36	Not used.	
V37	Temperature data unit change (Ver 1.1 or higher)	⁰F·1 ⁰C·0
V38	Data change cancellation (Ver 1.1 or higher)	Cancellation: Yes:1 No: 0
V20	Net used	
139	Not used.	
13A	Not used.	
13B	NOT USED.	
Y3C	Not used.	
Y3D	Not used.	
Y3E	Not used.	
Y3F	Not used.	

9.3 Relays, memory Areas and Constants

		Number of	Memory area av	ailable for use		
	Item	points	Matsushita	IEC	Function	
	External input relay (See Note 3.)	208	X0 - X12F	%IX0.0 - %IX12.15	Turns on or off based on external input.	
	External output relay (See Note 3.)	208	Y0 - Y12F	%QX0.0 - %QX12.15	Outputs on or off state externally.	
	Internal relay (See Note 2.)	1008	R0 - R62F	%MX0.0 - %MX0.62.15	Turns on or off only within a program.	
Relay	Timer (See Notes 1 and 2.)	100	T0 -T99/ C100 - C143	%MX1.0 - %MX1.99/ %MX2.100 - %MX2.143	Turns on when the timer reaches the specified time. Corresponds to the timer number.	
	Counter (See Notes 1 and 2.) 44		C100 -C143/ T0 - T99	%MX2.100 - %MX2.143/ %MX1.0 - %MX1.99	Turns on when the counter increments. Corresponds to the counter number.	
	Special internal relay	64	R9000 - R903F	%MX0.900.0 - %MX0.903.15	Turns on or off based on specific conditions. Used as a flag.	
	External input relay (See Note 3.)	13 words	WX0 - WX12	%IW0 - %IW12	Code for specifying 16 external input points as one word (16 bits) of data.	
	External output relay (See Note 3.)	13 words	WY0 - WY12	%QW0 - %QW12	Code for specifying 16 external output points as one word (16 bits) of data.	
s)	Internal relay (See Note 2.)	63 words	WR0 - WR62	%MW0.0 - %MW0.62	Code for specifying 16 internal relay points as one word (16 bits) of data.	
a (word	Data register (See Note 2.)	1660 words	DT0 - DT1659	%MW5.0 - %MW5.1659	Data memory used in a program. Data is handled in 16-bit units (one word).	
emory are	Timer/counter set value area 144 words		SV0 - SV143	%MW3.0 - %MW3.143	Data memory for storing a target value of a time and an initial value of a counter. Stores by time/counter number.	
Me	Timer/counter elapsed value area (See Note 2.)	144 words	EV0 - EV143	%MW4.0 - %MW4.143	Data memory for storing the elapsed value during operation of a timer/counter. Stores by time/counter number.	
	Special data register	112 words	DT9000 - DT9111	%MW5.9000 - %MW5.9111	Data memory for storing specific data. Various settings and error codes are stored.	
	Index register	2 words	IX - IY	%MW6.0 - %MW6.1	Used as an address of memory area and constants modifier.	

	Item	Number of points	Memory area ava Matsushita	ailable for use IEC	Function
	External input relay (See Note 3.)	6 double words	DWX0 - DWX11	%ID0 -%ID11	Code for specifying 32 external input points as a double word (32 bits) of data.
e 4.)	External output relay (See Note 3.)	6 double words	DWY0 - DWY11	%QD0 - %QD11	Code for specifying 32 external output points as double word (32 bits) of data.
See Not	Internal relay 31 double words		DWR0 - DWR61	%MD0.0 - %MD0.61	Code for specifying 32 internal relay points as double word (32 bits) of data.
word) (Data register (See Note 2.)	830 double words	DDT0 - DDT1658	%MD5.0 - %MD5.1658	Data memory used in a program. Data is handled in 32-bit units (double words).
a (double	Timer/counter72 doubleset value areawords		DSV0 - DSV142	%MD3.0 - %MD3.142	Data memory for storing a target value of a timer and an initial value of a counter. Stores by timer/counter number.
emory are	Timer/counter elapsed value area (See Note 2.)	72 double words	DEV0 - DEV142	%MD4.0 - %MD4.142	Data memory for storing the elapsed value during operation of a timer/counter. Stores by timer/counter number.
Ŵ	Special data register	56 double words	DDT9000 - DDT9110	%MD5.9000 - %MD5.9110	Data memory for storing specific data. Various settings and error codes are stored.
	Index register	1 double words	DIO	%MD6.0	Used as an address of memory area and constants modifier.

	Item	Number of points
oint	Master control relay points(MCR)	32 points
tion p	Number of labels (JP and LOOP)	64 labels
struc	Number of step ladders	128 stages
trol in	Number of subroutiones	16 subroutiones
Con	Number of interrupt programs	7 programs (external:6,internal:1)

Item		Range available for use					
		Matsushita	IEC				
	Desimal constants	K – 32768 to K32767 (for 16-bit operation)	- 32768 to 32767 (for 16-bit operation)				
		K – 2147483648 to K2147483647	- 2147483648 to 2147483647				
t.	(integral type)	(for 32-bit operation)	(for 32-bit operation)				
an	Havadaaimal	H0 to HFFFF (for 16-bit operation)	16#0 to 16#FFFF (for 16-bit operation)				
Jst	constants	H0 to HEFEFEFE (for 22 bit operation)	16#0 to 16#FFFFFFF				
ō	Constants	HO to HEFFFFFFF (IOI 52-bit operation)	(for 32-bit operation)				
0	Decimal constants	$F - 1.175494 \times 10^{-38}$ to $F - 3.402823 \times 10^{38}$	- 1.17549410E-38 to - 3.402823E38				
	(monorefined real number)	F1.175494 \times 10 $^{\!\!-38}$ to F3.402823 \times 10 $^{\!\!38}$	1.17549410E-38 to 3.402823E38				



- 1. The points for the timer and counter can be changed by the setting of System register No.5. The number given in the table above are the numbers when System register No. 5 is at its default setting.
- 2. There are two unit types; the hold type that saves the conditions that exist just before turning the power off or changing from the RUN mode to PROG. mode, and the non-hold type that resets them. These areas can be specified as hold type or non-hold type by setting system register. For the FP-e, that area is fixed and allotted the numbers as shown in the table below. For the FP-e with clock/calendar function type, the selection of hold type and non-hold type can be changed by the setting of system register.
- 3. The number of points noted above is the number reserved in the system. For the actual number of points available for use, refer to "I/O Allocation" in Appendix A.
- 4. Double words cannot be specified with FPWIN GR.

Thore type and non-noid type aleas							
	Model	AFPE224300	AFPE224305	AFPE214325			
	<u> </u>	(Standard type)	(Calendar timer	(Thermocouple input			
		(type)	type)			
Timer		Non-hold type: all poi	ints				
	Non-hold type	From the set value to	C139				
Counter		C140 to C143, EV140 to EV143 (elapsed value)					
	поіа туре	SV: non-hold Note 2) SV: hold					
	Non hold type	976 points (R0 to R60F)					
Internal	Non-noid type	61 words (WR0 to WR60)					
relay	Hold type	32 points (R610 to R62F)					
	r loid type	2 words (WR61 to WR62)					
Data	Non-hold type	1652 words (DT0 to I	DT1651)				
register	Hold type	8 words (DT1652 to I	DT1659)				

Hold type and non-hold type areas ^{Note 1)}

Notes:

1. When a battery is installed in a calendar timer type FP-e, the areas above can be changed using the system register.

If a battery is not installed, the data cannot be stored even when the settings are changed using the system register.

2. Use the following methods for holding the SV data:

1. Set the transfer instruction for the special data register (DT) to hold the data. Then, perform the setting so that the data can be transferred from DT to SV after the RUN mode starts.

2. Use the FP-e model with a battery.

9.4 ASCII characters displayed in the FP-e unit

9.4.1 Available ASCII characters

	0xh	1xh	2xh	3xh	4xh	5xh	6xh	7xh
x0h	NUL	DEL	SPACE	0	@	Р	``	р
x1h	SOH	DC1	!	1	А	Q	а	q
x2h	STX	DC2	"	2	В	R	b	r
x3h	ETX	DC3	#	3	С	S	С	S
x4h	EOT	DC4	\$	4	D	Т	d	t
x5h	ENQ	NAK	%	5	Е	U	е	u
x6h	ACK	SYN	&	6	F	V	f	v
x7h	BEL	ETB	,	7	G	W	g	w
x8h	BS	CAN	(8	Н	Х	h	х
x9h	HT	EM)	9	Ι	Y	i	У
xAh	LF	SUB	*	:	J	Ζ	J	z
xBh	VT	ESC	+	• • • •	К	[k	{
xCh	FF	FS	,	v	L	¥	Ι	
xDh	CR	GS	-	=	М]	m	}
xEh	SO	RS		>	Ν	٨	n	~
xFh	SI	US	/	?	0	_	0	DEL

Available output characters using ASCII Code

Note 1) If specifying a characters which cannot be output, a blank is output.

Note 2) There is no discrimination between uppercase (41 h to 5Ah) and lowercase (61h to 7Ah) characters.

Therefore, "A" and a" is output in the same way.

Ascii code	Ascii character	Output image	Ascii code	Ascii character	Output image	Ascii code	Ascii character	Output image
20h	(SPACE)	Ħ	30h	0		40h	@	Ø
21h	!	Ħ	31h	1	1	41h	A	8
22h	"	• •	32h	2		42h	В	4
23h	#	Ħ	33h	3		43h	С	1
24h	\$	Ħ	34h	4	1_1	44h	D	
25h	%		35h	5		45h	E	
26h	&	Ħ	36h	6		46h	F	, -
27h	I	I	37h	7	1 1	47h	G	
28h	(Ħ	38h	8		48h	н	; -
29h)		39h	9		49h	I	-
2Ah	*	Ħ	3Ah	:	;	4Ah	J	
2Bh	+	-1	3Bh	•	Ø	4Bh	K	,-1 ,-1
2Ch	,	J	3Ch	<	Ľ	4Ch	L	
2Dh	_	•	3Dh	=	•	4Dh	М	,
2Eh	•	Ħ	3Eh	>		4Eh	Ν	1
2Fh	/	\blacksquare	3Fh	?	Ø	4Fh	0	

Ascii code	Ascii character	Output image	Ascii code	Ascii character	Output image	Ascii code	Ascii character	Output image
50h	Р		60h	`	B	70h	р	, , ,
51h	Q	7	61h	а	R	71h	q	11
52h	R	/ -	62h	b	4	72h	r	, -
53h	S	5	63h	С		73h	S	
54h	Т	k	64h	d	1	74h	t	1
55h	U		65h	е	E	75h	u	
56h	V	<u>」</u>	66h	f	<i>[</i> -	76h	v	ľ
57h	Ŵ	1_1	67h	g		77h	w	
58h	Х	;;	68h	h	<u>}-</u>	78h	x	H
59h	Y	4	69h	i	-	79h	У	
5Ah	Z	•	6Ah	j		7Ah	z	• •
5Bh	[6Bh	k	!-1	7Bh	{	Ø
5Ch	¥	\square	6Ch	I		7Ch		B
5Dh]		6Dh	m	, i	7Dh	}	B
5Eh	^	\square	6Eh	n	171	7Eh	~	-
5Fh	_	-	6Fh	0	Ū	7Fh	(DEL)	

Note) When specifying the control code (00h to 1Fh, or 7Fh), a blank appears. (No display is turned on.)

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Chapter 10

Dimensions

10.1 Dimensions

NAIS

□48

FP-e



70

7.5

Analog input without thermocouple



AFPE224300 AFPE224305 AFPE224302

Analog input with thermocouple



AFPE214325 AFPE214322

- When FP-e is on a mounting panel



Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Chapter 11

Appendix

11.	Appendix 11-1
	11.1 System Registers / Special Internal Relays / Special Data Registers 11-3
	11.1.1 Table of System Registers for FP-e11-5
	11.1.2 Table of Special Internal Relays for FP-e11-9
	11.1.3 Table of Special Data Registers for FP-e11-13
	11.2 Table of Basic Instructions 11-20
	11.3 Table of High-level Instructions 11-54
	11.4 Table of Error codes 11-114
	11.5 MEWTOCOL-COM Communication Commands 11-128
	11.6 Hexadecimal/Binary/BCD 11-129
	11.7 ASCII Codes 11-130

11.1 System Registers / Special Internal Relays / Special Data Registers

Precation for System Registers

What is the system register area

- System registers are used to set values (parameters) which determine operation ranges and functions used. Set values based on the use and specifications of your program.
- There is no need to set system registers for functions which will not be used.

Type of system registers

(1) Allocation of user memory (System registers 0, 1 and 2)

These registers set the size of the program area and file register area, allowing the user memory area to be configured for the environment used. The size of the memory area will vary depending on the type.

(2) Allocation of timers and counters (System register 5)

The number of timers and counters is set by specifying the starting couner number.

(3) Hold/non-hold type setting (System registers 6 to 18)

When these registers are set to "hold type", the values in the relays and data memory will be retained even if the system is switched to PROG. mode or the power is turned off. If set to "non-hold type", the values will be cleared to "0".

(4) Operation mode setting on error (System registers 4, 20 to 28)

Set the operation mode when errors such as battery error, duplicated use of output, I/O verification error and operation error occur.

(5) Time settings (System registers 30 to 34)

Set time-out error detection time and the constant scan time.

(6) Remote I/O operation settings (System registers 35 and 36)

These registers are used to select whether or not to wait for a slave station connection when the remote I/O is started, and the remote I/O update timing.

(7) MEWNET-W0/MEWNET-W/P PLC link settings (System registers 40 to 47, 50 to 55, and 57)

These settings are for using link relays and link registers for MEWNET-W0/MEWNET-W/P PC(PLC) link communication.

Note) The default value setting is "no PC(PLC) link communication".

(8) MEWNET-H PC(PLC) link settings (System register 49)

Set the data size to be processed during one scan in the MEWNET-H PC(PLC) link communication.

(9) Input settings (System registers 400 to 406)

When using the high-speed counter function, pulse catch function or interrupt function, set the operation mode and the input number to be used for the function.

(10) Input time constant settings (FP1/FP-M System registers 404 to 407)

Changing the input signal width to be loaded enables to prevent the malfunctions caused by chattering or noises.

(11) Number of temperature input averaging process settings (System register 409)

The number of averaging times can be set in order to even out the variation in the input thermocouple values. For normal use it, set the number of times to t least twenty. For default value "0", the number of average processing times is 20.

(12) Tool and COM. ports communication settings (System registers 410 to 421)

Set these registers when the Tool port, and COM1 and COM2 ports are to be used for computer link, general-purpose serial communication, PC(PLC) link, and modem communication. Note that the default setting is computer link mode.

Checking and changing the set value of system register

If you are going to use a value which is already set(the value which appears when read), there is no need write it again.

Using programming tool software Produce:

- 1. Set the control unit in the PROG mode.
- 2.Option ->PLC Configuration

3. When the function for which setting are to be entered is selected in the PLC Configuration dialog box, the value and setting status for the selected system register are displayed.

To change the value and setting status, write in the new value and /or select the setting status.

4.To register these settings, choose OK

Using FP programmer II Produce:

- 1. Set the mode selector of the CPU to PROG.
- 2. Press the keys on the FP programmer II, as shown below.



3. Specify the register number (e.g. No. 26) for the parameter to be set and read the parameter. The value set in the selected register (e.g. No. 26) will be displayed.



4. To change the set value, press the <CLR (clear)> key and write the new value as indicated in the system register table using decimal (K) or hexadecimal (H) constant.

Precautions for system register setting

-System register settings are effective from the time they are set.

However, input settings,tool port,COM port,and modem connection settings become effective when the mode is changed from PROG. to RUN. With regard to the modem connection setting, when the power is turned off and on or when the mode is changed from PROG. to RUN, the controller sends a command to the modem which enables it for reception.

-When the initialized operation is performed, all set system register values (parameters) will be initialized.

	No.	Name	Default value	Desc	criptions
	5	Starting number setting for counter	100	0 to 144	
Hold/ Non- hold	6	Hold type area starting number setting for timer and counter	140	0 to 144	
	7	Hold type area starting number setting for internal relays	61	0 to 63	(See note.)
	8	Hold type area starting number setting for data registers	1652	0 to 1660	
	14	Hold or non-hold setting for step ladder process	Non-hold	Hold/Non-hold	
Action on error	20	Disable or enable setting for duplicated output	Yes FPWIN GR: Disabled	Fixed FPWIN GR: Disa	bled/Enabled
	26	Operation setting when an operation error occurs	Stop	Stop/Continuatior	n of operation
	4	Alarm battery error (Operating setting when battery error occurs)	Disabled	Dis- abled: a self-dia issued a does no Ena- bled: a self-dia issued a bled: a self-dia issued a lights.	battery error occurs, agnostic error is not nd the ERROR LED t light. battery error occurs, agnostic error is nd the ERROR LED
Time set- ting	31	Wait time setting for multi- frame communication	6500.0 ms	10 to 81900 ms	
	34	Constant value settings for scan time	0.0 ms	0: Normal scan 0 to 160 ms: Scan specified time inte	ns once each erval

11.1.1 Table of System Registers for FP-e

Note) Use models without a clock/calendar function with the default value left as is. If you change the setting the hold/non-hold operation will be unstalbe.

Settings are valid for models with a clock/calendar time function.

FP-e	F	Р-	е
------	---	----	---

	No.	Name	Default value	Descriptions	
High- speed coun- ter	400	High-speed counter operation mode settings (X0 to X2)	CH0: Do not set input X0 as high- speed counter	CH0	Do not set input X0 as high-speed counter. Two-phase input (X0, X1) Two-phase input (X0, X1), Reset input (X2) Incremental input (X0) Incremental input (X0), Reset input (X2) Decremental input (X0), Reset input (X2) incremental/decremental input (X0, X1) incremental/decremental input (X0, X1), Reset input (X2) Incremental/decremental control input (X0, X1) Incremental/decremental control input (X0, X1), Reset input (X2)
			CH1: Do not set input X1 as high- speed counter	CH1	Do not set input X1 as high-speed counter. Incremental input (X1) Incremental input (X1), Reset input (X2) Decremental input (X1) Decremental input (X1), Reset input (X2)
	401	High-speed counter operation mode settings (X3 to X5)	CH2: Do not set input X3 as high- speed counter HC3: Do not set	CH2	Do not set input X3 as high-speed counter. Two-phase input (X3, X4) Two-phase input (X3, X4), Reset input (X5) Incremental input (X3) Incremental input (X3), Reset input (X5) Decremental input (X3), Reset input (X5) Incremental/decremental input (X3, X4) Incremental/decremental input (X3, X4), Reset input (X5) Incremental/decremental control input (X3, X4) Incremental/decremental control input (X3, X4), Reset input (X5) Do not set input X4 as high-speed counter.
			input X4 as high- speed counter	СНЗ	Incremental input (X4) Incremental input (X4), Reset input (X5) Decremental input (X4), Reset input (X5)

FP-e

	No.	Name	Default value	Descriptions
Inter- rupt- input	402	Pulse catch input settings	Not set	x0 x1 x2 x3 x4 x5 Specify the input contacts used as pulse catch input.
	403	Interrupt input settings	Not set	X0 X1 X2 X3 X4 X5 Specify the input contacts used as intrrupt input. X0 X1 X2 X3 X4 X5 Specify the effective interrupt edge. (When set: $ON \rightarrow OFF$ is valid)

Note1) If the operation mode is set to two-phase, incremental/decremental, or incremental/decremental control, the setting for CH1 is invalid in part 2 of system register 400 and the setting for CH3 is invalid in part 2 of system register 401.

Note2) If reset input settings overlap, the CH1 setting takes precedence in system register 400 and the CH3 setting takes precedence in system register 401.

Note3) The settings for pulse catch and interrupt input can only be specified in system registers 402 and 403.

Note4) If system register 400 to 403 have been set simultaneously for the same input relay, the following precedence order is effective:

1. High-speed counter

2. Pulse catch

3. Interrupt input.

This means, the counter keeps counting even after an interrupt.

FP-e					
	No.	Name	Default value	Descriptions	
Tem- pera- ture inout	409	Number of temperature input average processing times (Available PLC: model with thermocouple input)	0	0 to 50 For default valeu "0", the number of average processing times is 20.	
	410	Unit No. setting	1	1 to 99	
Tool port set- ting	411	Communication format setting	Disabled Data length: 8 bits	Modem connection: enabled/Disabled Data length: 7 bits/8 bits When connecting a modem, the format will be as follows depending on the data length setting. 8 bits data length: no parity, 1 stop bit 7 bits data length: odd parity, 1 stop bit	
	414	Communication speed (Baud rate) setting	9600 bps	9600 bps 19200 bps	
	412	Communication mode setting	Computer link	Computer link General-purpose serial communication MODBUS RTU (Ver.1.2 and higher)	
	413	Communication format setting	Data lenght bit: 8 bits Parity check: Odd Stop bit: 1 bit	Enter the settings for the various items. - Data lenght: 7 bits/8 bits - Parity check: none/with odd/with even - Stop bit: 1 bit/2 bits - The following setting is valid only when the communication mode specified by system register 412 has been set to "General-purpose serial communication". - Terminator CR/CR+LF/None - Header: STX not exist/STX exist	
COM. port	414	Communication speed (Baud rate) setting	9600 bps	300 bps / 600 bps / 1200 bps / 2400 bps / 4800 bps / 9600 bps / 19200 bps	
set- ting	415	Unit no. setting	1	1 to 99 (In Ver.1.2 and higher, settings can be changed in R mode even with the front operation switch.)	
	416	Selection of modem connection	Disabled	Enabled/Disabled	
	417	Starting address for received buffer of general (serial data) communication mode	0	0 to 1659	
	418	Buffer capacity setting for data received of general (serial data) communication mode	1660	0 to 1660	

11.1.2 Table of Special Internal Relays for FP-e

The special internal relays turn on and off under special conditions. The on and off states are not output externally. Writing is not possible with a programming tool or an instruction.

Relay No.: Matsushita IEC	Name	Description	
R9000 %MX0 900 0	Self-diagnostic error	Turns on when a self-diagnostic error occurs. \Rightarrow The content of self-diagnostic error is stored in DT90000	
R9001 %MX0.900.1	Not used	-	
R9002 %MX0.900.2	Not used	-	
R9003 %MX0.900.3	Not used	-	
R9004 %MX0.900.4	Not used	-	
R9005 %MX0.900.5	Backup battery error flag (non-hold)	Turns on for an instant when a backup battery error occurs.	
R9006 %MX0.900.6	Backup battery error flag (hold)	Turns on and keeps the on state when a backup battery error occurs. Once a battery error has been detected, this is held even after recovery has been made. It goes off if the power supply is turned off, or if the system is initialized.	
R9007 %MX0.900.7	Operation error flag (hold)	Turns on and keeps the on state shen an operation error occurs. ⇒The address where the error occurred is stored in DT9017. (Indicates the first operation error which occurred).	
R9008 %MX0.900.8	Operation error flag (non-hold)	Turns on for an instant when an operation error occurs. ⇒The address where the operation error occurred is stored in DT9018. The contents change each time a new error occurs.	
R9009 %MX0.900.9	Carry flag	This is set if an overflow or underflow occurs in the calculation results, and as a result of a shift system instruction being executed.	
R900A %MX0.900.10	> Flag	Turns on for an instant when the compared results become larger in the comparison instructions.	
R900B %MX0.900.11	= Flag	 Turns on for an instant, when the compared results are equal in the comparison instructions. when the calculated results become 0 in the arithmetic instructions. 	
R900C %MX0.900.12	< Flag	Turns on for an instant when the compared results become smaller in the comparison instructions.	
R900D %MX0.900.13	Auxiliary timer instruction flag	Turns on when the set time elapses (set value reaches 0) in the timing operation of the F137(STMR)/F183(DSTM) auxiliary timer instruction. The flag turns off when the trigger for auxiliary timer instruction turns off.	
R900E %MX0.900.14	Tool port communication error	Turns on when a communication error at Tool port has occurred.	
R900F %MX0.900.15	Constant scan error flag	Turns on when the scan time exceeds the time specified in system register 34 during constant scan execution. This goes on if 0 has been set using system register 34.	

11-10

Relay No.: Matsushita IEC	Name	Description	
R9010 %MX0.901.0	Always on relay	Always on.	
R9011 %MX0.901.1	Always off relay	Always off.	
R9012 %MX0.901.2	Scan pulse relay	Turns on and off alternately at each scan.	
R9013 %MX0.901.3	Initial (on type) pulse relay	Goes on for only the first scan after operation (RUN) has been started, and goes off for the second and subsequent scans.	
R9014 %MX0.901.4	Initial (off type) pulse relay	e Goes off for only the first scan after operation (RUN) has been started, and goes on for the second and subsequent scans.	
R9015 %MX0.901.5	Step ladder initial Turns on for only the first scan of a process aft nulse relay (on type) the step ladder control		
R9016 %MX0.901.6	Not used	-	
R9017 %MX0.901.7	Not used	-	
R9018 %MX0.901.8	0.01 s clock pulse relay	Repeats on/off operations in 0.01 s	
R9019 %MX0.901.9	0.02 s clock pulse relay	Repeats on/off operations in 0.02 s	
R901A %MX0.901.10	0.1 s clock pulse relay	Repeats on/off operations in 0.1 s	
R901B %MX0.901.11	0.2 s clock pulse relay	Repeats on/off operations in 0.2 s	
R901C %MX0.901.12	1 s clock pulse relay	Repeats on/off operations in 1 s	
R901D %MX0.901.13	2 s clock pulse relay	Repeats on/off operations in 2 s	
R901E %MX0.901.14	1 min clock pulse relay	Repeats on/off operations in 1 min	
R901F %MX0.901.15	Not used	-	

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net
FP-e

Relay No.: Matsushita IEC	Name	Description
R9020 %MX0 902 0	RUN mode flag	Turns off while the mode selector is set to PROG.
R9021 %MX0.902.1	Not used	-
R9022 %MX0.902.2	Not used	-
R9023 %MX0.902.3	Not used	-
R9024 %MX0.902.4	Not used	-
R9025 %MX0.902.5	Not used	-
R9026 %MX0.902.6	Message flag	Turns on while the F149 (MSG) instruction is executed.
R9027 %MX0.902.7	Not used	-
R9028 %MX0.902.8	Not used	-
R9029 %MX0.902.9	Forcing flag	Turns on during forced on/off operation for input/output relay timer/counter contacts.
R902A %MX0.902.10	Interrupt enable flag	Turns on while the external interrupt trigger is enabled by the ICTL instruction.
R902B %MX0.902.11	Interrupt error flag	Turns on when an interrupt error occurs.
R902C %MX0.902.12	Not used	-
R902D %MX0.902.13	Not used	-
R902E %MX0.902.14	Not used	-
R902F %MX0.902.15	Not used	-

FP-e

Relay No.: Matsushita IEC	Name		Description
R9030 %MX0.903.0	Not used		-
R9031 %MX0.903.1	Not used		-
R9032 %MX0.903.2	Not used		-
R9033	Print instruction		Off: Printing is not executed.
%MX0.903.3	execution flag		On: Execution is in progress.
R9034	RUN overwrite		Goes on for ony the first scan following completion of a
%MX0.903.4	complete flag		rewrite during RUN operation.
R9035 %MX0.903.5	Not used		-
R9036 %MX0.903.6	Not used		-
R9037 %MX0.903.7	COM port communication en flag	rror	- Goes on is a transmission error occurs during data communication.
R9038 %MX0.903.8	COM port reception done flag during general-purpose s communication	on serial	- Turns on when the terminator is received during general - purpose serial communication.
R9039 %MX0.903.9	COM port transmission don flag during genera purpose serial communication	e al-	 Goes on when transmission has been completed in general-purpose serial communication. Goes off when transmission is requested in general- purpose serial communication.
R903A %MX0.903.10	High-speed counter control flag	ch0	Turns on while the high-speed counter instructions F166(HC15), F167(HC1R) and the pulse output instructions F168(SPD1) to F170(PWM) are executed.
R903B %MX0.903.11	High-speed counter control flag	ch1	Turns on while the high-speed counter instructions F166(HC15), F167(HC1R) and the pulse output instructions F168(SPD1) to F170(PWM) are executed.
R903C %MX0.903.12	High-speed counter control flag	ch2	Turns on while the high-speed counter instructions F166(HC15), F167(HC1R) and the pulse output instructions F168(SPD1) to F170(PWM) are executed.
R903D %MX0.903.13	High-speed counter control flag	ch3	Turns on while the high-speed counter instructions F166(HC15), F167(HC1R) and the pulse output instructions F168(SPD1) to F170(PWM) are executed.
R903E			-
%MX0.903.14			
R903F %MX0.903.15			-

The special data registers are one word (16-bit) memory areas which store specific information.

Register No. Matsushita IEC	Name	Descriptions	Read -ing	Writ- ing
DT9000 %MW5.9000	Self-diagnostic error code	The self-diagnostic error code is stored here when a self-diagnostic error occurs.	A	N/A
DT9001 %MW5.9001	FP-e screen display switching	Switches the FP-escreen to the screen of the mode specified. K0: N mode first screen K1: N mode second screen K2: S mode first screen K3: S mode second screen K4: R mode first screen K5: R mode second screen K6: I mode first screen K7: I mode second screen	A	N/A
DT9002 DT9003	Analog input data	Ch.0 analog input data (2-word real data)	А	N/A
DT9004 DT9005	Analog input data	Ch.1 analog input data (2-word real data)	А	N/A
DT9014 %MW5.9014	Operation auxiliary register for data shift instruction	One shift-out hexadecimal digit is stored in bit positions 0 to 3 when the data shift instruction, F105 (BSR) or F106 (BSL) is executed. The value can be read and written by executing the F0 (MV) instruction.		
DT9015 %MW5.9015 DT9016 %MW5.9016	Operation auxiliary register for division instruction	The divided remainder (16-bit) is stored in DT9015 when the division instruction F32(%) or F52(B%) instruction is executed. The divided remainder (32-bit) is stored in DT9015 and DT9016 when the division instruction F33(D%) or F53(DB%) is executed. The value can be read and written by executing the F0(MV) instruction.	A	A
DT9017 %MW5.9017	Operation error address (hold type)	After commencing operation, the address where the first operation error occurred is stored. Monitor the address using decimal display.		
DT9018 %MW5.9018	Operation error address (non-hold type)	The address where an operation error occurred is stored. Each time an error occurs, the new address overwrites the previous address. At the beginning of a scan, the address is 0. Monitor the address using decimal display.	A	N/A
DT9019 %MW5.9019	2.5 ms ring counter Note1)	The data stored here is increased by one every 2.5 ms. (H0 to HFFFF) Difference between the values of the two points (absolute value) x 2.5 ms = Elapsed time between the two points.		

FP-e	(A: Available,	N/A: Not	available)
------	----------------	----------	------------

Register No. Matsushita IEC	Name	Descriptions	Read -ing	Writ -ing
DT9020 %MW5.9020 DT9021	Not used	-	N/A	N/A
%MW5.9021	Not used	-		
DT9022 %MW5.9022	Scan time (current value) ^{Note)}	The current scan time is stored here. Scan time is calculated using the formula: Scan time (ms) = stored data (decimal) x 0.1 ms Example: K50 indicates 5 ms.		
DT9023 %MW5.9023	Scan time (minimum value) _{Note)}	The minimum scan time is stored here. Scan time is calculated using the formula: Scan time (ms) = stored data (decimal) x 0.1 ms Example: K50 indicates 5 ms.		
DT9024 %MW5.9024	Scan time (maximum value) ^{Note)}	The maximum scan time is stored here. The scan time is calculated using the formula: Scan time (ms) = stored data (decimal) x 0.1 ms Example: K125 indicates 12.5 ms.	A	N/A
DT9025 %MW5.9025	Mask condition monitoring register for interrupts	The mask conditions of interrupts using the instruction can be stored here. Monitor using binary display.		
DT9026 %MW5.9026	Not used	-	N/A	N/A
DT9027 %MW5.9027	Periodical interrupt interval (INT24)	The value set by the ICTL instruction is stored. K0: periodical interrupt is not used. K1 to K3000: 0.5ms to 1.5s or 10ms to 30s	A	N/A
DT9028 %MW5.9028 DT9029	Not used	-	N/A	N/A
%MW5.9029 DT9030 %MW5.9030	Message 0			
DT9031 %MW5.9031	Message 1			
DT9032 %MW5.9032	Message 2	The contents of the specified message (Data	Δ	N/A
DT9033 %MW5.9033	Message 3	when F149 (MSG) instruction is executed.	17	
DT9034 %MW5.9034	Message 4			
DT9035 %MW5.9035	Message 5			

Note) Scan time display is only possible in RUN mode and shows the operation cycle time. (in PROG mode, the scan time for the operation is not displayed.) The maximum and minimum values are cleared each time the mode is switched from RUN to PROG.

FP-e (A: Available, N/A: Not available)

Register No. Matsushita IEC	Name		Descriptions	Read -ing	Writ -ing
DT9036 %MW5.9036	Not used		-	N/A	N/A
DT9037 %MW5.9037	Operation aux register for sea instruction F96(SRC)	iliary arch	The number of data that match the searched data is stored here when F96 (SRC) insturction is executed.	0	•
DT9038 %MW5.9038	Operation auxiliary register for search instruction F96(SRC)		The position of the first matching data is stored here when an F96 (SRC) instruction is executed.	А	A
DT9039 %MW5.9039	Not used		-	N/A	N/A
DT9040 %MW5.9040 DT9041 %MW5.9041	Temperature in ch.0 Temperature in ch 1	nput nput	The value of the temperature input before average processing is stored.	A	N/A
DT9042 %MW5.9042	Not used		-	N/A	N/A
DT9043 %MW5.9043	Used by the system		Used by the system (Battery).	A	N/A
DT9044 %MW5.9044 DT9045 %MW5.9045	High-speed counter elapsed value	For CH0	The elapsed value (24-bit data) of the high- speed counter is stored here. The value can be read and written by executing F1 (DMV) instruction.	A	A
DT9046 %MW5.9046 DT9047 %MW5.9047	High-speed counter target value	For CH0	The targe value (24-bit data) of the high-speed counter specified by the high-speed counter instruction is stored here. Target values have been preset for the various instructions to be used when the high-speed counter related instruction is executed. The value can be read by executing F1 (DMV) instruction.	A	N/A
DT9048 %MW5.9048 DT9049 %MW5.9049	High-speed counter elapsed value area	For CH1	The elapsed value (24-bit data) of the high- speed counter is stored here. The value can be read and written by executing F1 (DMV) instruction.	A	A

FP-e	(A:	Available,	N/A:	Not	available)
------	-----	------------	------	-----	-----------	---

Register No. Matsushita IEC	Name		Descriptions	Read -ing	Writ -ing
DT9050 %MW5.9050	High-speed counter	For	The target value (24-bit data) of the high-speed counter specified by the high-speed counter instruction is stored here. Target values have been preset for the various instructions to be	А	N/A
DT9051 %MW5.9051	target value area	e CH1	used when the high-speed counter related instruction is executed. The value can be read by executing F1 (DMV) instruction.	A	
DT9052 %MW5.9052	High-speed co and pulse out control flag	ounter out	A value can be written with F0 (MV) instruction to reset the high-speed counter, disable counting, continue or clear high-speed counter instruction. Control code setting For ch3 For ch2 For ch1 For ch0 15 12 11 8 7 4 3 2 1 0 High-speed counter instruction 0: Continue/1: Clear Pulse output 0: Continue/1: Stop Hardware reset 0: Enable/1: Disable Home near input 0: Off/1: On Count 0: Enable/1: Disable Software reset 0: No/1: Yes	Z/A	A
DT9053 %MW5.9053	Clock/calenda monitor (hour/minute)	r	Hour and minute data of the clock/calendar are stored here. This data is read-only data. It cannot be overwritten. Higher byte Lower byte Hour data Minute data Hour data Hou to H23 Hou to H59	A	N/A

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

FP-e (A: Available, N/A: Not available)

Register No. Matsushita IEC	Name	Descriptions	Read -ing	Writ -ing
DT9054 %MW5.9054	Clock/calendar setting (minute/second)	The year, month, day, hour, minute, second and day-of-the-week data for the calender timer is stored. The built-in calendar timer will operate		
DT9055 %MW5.9055	Clock/calendar setting (day/hour)	correctly through the year 2099 and supports leap years. The calendar timer can be set by writing a value using a programming tool		
DT9056 %MW5.9056	Clock/calendar setting (year/month)	software or a program that uses the F0 (MV) instruction.(see example for DT90058)	Δ	Δ
DT9057 %MW5.9057	Clock/calendar setting (day-of-the- week)	DT9054 Minute data (H00 to H59) Second data (H00 to H59) DT9055 Day data (H01 to H31) Hour data (H00 to H23) DT9056 Year data (H00 to H99) Month data (H01 to H12) DT9057 - Day-of-the-week (H00 to H06)		
DT9058 %MW5.9058	Clock/calendar time setting	By setting the highest bit of DT9058 to 1, the time becomes that written to DT9054 to DT9057 by the F0 (MV) instruction. After the time is set, DT9058 is cleared to 0. (Cannot be performed with any instruction other than the F0 (MV) instruction.) <example> Set the time to 12:00:00 on the 5th day when X0 turns on. FPWIN GR: X0 F0 MV, H 0, DT9054 [F0 MV, H 512, DT9055] [F0 MV, H8000, DT9058] Inputs 12th hour 5th day Sets the time If you changed the values of DT9054 to DT9057 with the programming tool software, the time will be set when the new values are written. Therefore, it is unnecessary to write to DT9058.</example>	А	A

Register No. Matsushita IEC	Name	Descriptions	Read -ing	Writ -ing
DT9059 %MW5.9059	Serial communication error code	Error code is sotred here when a communication error occurs. DT9059 Error flag of Error flag of COM port tool port • Tool port bit 0 = 1: Over run error bit 1 = 1: Framing error bit 2 = 1: Parity error • COM port bit 8 = 1: Over run error bit 9 = 1: Framing error bit 9 = 1: Framing error bit 1 = 1: Parity error	A	N/A
DT9060 %MW5.9060 DT9061 %MW5.9061 DT9062 %MW5.9062 DT9063 %MW5.9058 DT9064 %MW5.9064 DT9065 %MW5.9065 DT9066 %MW5.9066 DT9067	Step ladder process (0 to 15) Step ladder process (16 to 31) Step ladder process (32 to 47) Step ladder process (48 to 63) Step ladder process (64 to 79) Step ladder process (80 to 95) Step ladder process (96 to 111) Step ladder process	Indicates the startup condition of the step ladder process. When the process starts up, the bit corresponding to the process number turns on. Monitor using binary display. Example: DT9060 15 11 7 3 0 (Bit No.) 15 11 7 3 0 (Process No.) 1: Executing 0: Not executing A programming tool software can be used to write data.	A	A

FP-e (A: Available, N/A: Not available)

Register No. Matsushita IEC	Name		Descriptions	Read -ing	Writ -ing
DT9104 %MW5.9104 DT9105 %MW5.9105	High-speed counter elapsed value	For ch2	The elapsed value (24-bit data) for the high- speed conter is stored here. The value can be read and written by executing the F1 (DMV) instruction.	A	A
DT9106 %MW5.9106	High-speed	For	The target valeu (24-bit data) of the high-speed counter specified by the high-speed counter instruction is stored here. Target values have been preset for the various	Δ	N/A
DT9107 %MW5.9107	target value	ch2	instructions, to be used when the high-speed counter related instruction is executed. The value can be read by executing the F1 (DMV) instruction.	~	
DT9108 %MW5.9108 DT9109 %MW5.9109	High-speed counter elapsed value	For ch3	The elapsed value (24-bit data) for the high- speed counter is stored here. The value can be read and written by executing the F1 (DMV) instruction.	A	A
DT9110 %MW5.9110	High-speed	For	The target value (24-bit data) of the high-speed counter specified by the high-speed counter instruction is stored here. Target values have been preset for the various	٨	N/A
DT9111 %MW5.9111	target value	ch3	instructions, to be used when the high-speed counter related instruction is executed. The value can be read by executing the F1 (DMV) instruction.	Λ	11/7

11.2 Table of Basic Instructions

Name	Boolean	Symbol	Description	Steps (*1)
Sequence ba	sic instru	ctions		
Start	ST	X, Y, R, T, C, L, P, E	Begins a logic operation with a Form A (normally open) contact.	1 (2)
Start Not	ST/	X, Y, R, T, C, L, P, E	Begins a logic operation with a Form B (normally closed) contact.	1 (2)
Out	от	Y, R, L, E	Outputs the operated result to the specified output.	1 (2)
Not	1	/	Inverts the operated result up to this instruction.	1
AND	AN	X, Y, R, T, C, L, P, E	Connects a Form A (normally open) contact serially.	1 (2)
AND Not	AN/	X, Y, R, T, C, L, P, E	Connects a Form B (normally closed) contact serially.	1 (2)
OR	OR	X, Y, R, T, C, L, P, E	Connects a Form A (normally open) contact in parallel.	1 (2)
OR Not	OR/	X, Y, R, T, C, L, P, E	Connects a Form B (normally closed) contact in parallel.	1 (2)
Leading edge start	ST↑	X, Y, R, T, C, L, P, E	Begins a logic operation only for one scan when the leading edge of the trigger is detected.	2
Trailing edge start	st↓	X, Y, R, T, C, L, P, E	Begins a logic operation only for one scan when the trailing edge of the trigger is detected.	2

						A	vailabili	ity					
						FP1		FP	Р-М				н
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
Sequence basic instructions													
Start	A	A	A	А	А	А	A	А	А	A	А	A	А
Start Not	A	A	A	A	A	A	A	A	A	A	A	A	A
Out	A	A	A	A	A	A	A	A	A	A	A	A	A
Not	A	A	A	A	A	A	A	A	A	A	A	A	A
AND	A	A	A	A	A	A	A	A	A	A	A	A	A
AND Not	A	A	A	A	A	A	A	A	A	A	A	A	A
OR	A	A	A	A	A	A	A	A	A	A	A	A	A
OR Not	A	A	A	A	A	A	A	A	A	A	A	A	A
Leading edge start	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Trailing edge start	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	A	A

• A: Available, N/A: Not available

1) In the FP2/FP2SH/FP10SH, when using X1280, Y1280, R1120 (special internal relay included), L1280, T256, C256 or anything beyond for the ST, ST/, OT, AN, AN/, OR and OR/ instructions, the number of steps is shown in parentheses. Also, in the FP2/FP2SH/FP10SH, when a relay number has an index modifier, the number of steps is shown in parentheses.

Name	Boolean	Symbol	Description	Steps (*1)
Leading edge AND	AN↑	X, Y, R, T, C, L, P, E	Connects a Form A (normally open) contact serially only for one scan when the leading edge of the trigger is detected.	2
Trailing edge AND	AN↓	X, Y, R, T, C, L, P, E	Connects a Form A (normally open) contact serially only for one scan when the trailing edge of the trigger is detected.	2
Leading edge OR	OR↑	X, Y, R, T, C, L, P, E	Connects a Form A (normally open) contact in parallel only for one scan when the leading edge of the trigger is detected.	2
Trailing edge OR	OR↓	X, Y, R, T, C, L, P, E	Connects a Form A (normally open) contact in parallel only for one scan when the trailing edge of the trigger is detected.	2
Leading edge out	от↑	[↑]	Outputs the operated result to the specified output only for one scan when leading edge of the trigger is detected. (for pulse relay)	2
Trailing edge out	от↓	[↓]	Outputs the operated result to the specified output only for one scan when trailing edge of the trigger is detected. (for pulse relay)	2
Alternative out	ALT	Y, R, L, E	Inverts the output condition (on/off) each time the leading edge of the trigger is detected.	3
AND stack	ANS		Connects the multiple instruction blocks serially.	1
OR stack	ORS		Connects the multiple instruction blocks in parallel.	1
Push stack	PSHS	\vdash	Stores the operated result up to this instruction.	1
Read stack	RDS		Reads the operated result stored by the PSHS instruction.	1
Pop stack	POPS		Reads and clears the operated result stored by the PSHS instruction	1
Leading edge differential	DF	——(DF)—	Turns on the contact for only one scan when the leading edge of the trigger is detected.	1
Trailing edge differential	DF/	(DF/)	Turns on the contact for only one scan when the trailing edge of the trigger is detected.	1

	Availability												
						FP1		FP	-M			_	т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
Leading edge AND	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Trailing edge AND	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Leading edge OR	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Trailing edge OR	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Leading edge out	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Trailing edge out	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Alternative out	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
AND stack	A	A	A	А	A	A	A	A	A	A	A	A	A
OR stack	A	A	A	А	A	A	A	A	A	A	A	A	A
Push stack	A	A	A	А	А	A	A	А	A	A	A	A	A
Read stack	A	A	A	A	A	A	A	A	A	A	A	A	A
Pop stack	A	A	A	A	A	A	A	A	A	A	A	A	A
Leading edge differential	A	A	A	A	A	A	A	A	A	A	A	A	A
Trailing edge differential	A	A	A	A	A	A	A	A	A	A	A	A	A

Name	Boolean	Symbol	Description	Steps (*1)
Leading edge differ- ential (initial execution type)	DFI	(DFI)	Turns on the contact for only one scan when the leading edge of the trigger is detected. The leading edge detection is possible on the first scan.	1
Set	SET	Y, R, L, E	Output is set to and held at on.	3
Reset	RST	Y, R, L, E	Output is set to and held at off.	3
Кеер	KP	Set Reset	Outputs at set trigger and holds until reset trigger turns on.	1 (2)
No operation	NOP	•	No operation.	1

						A	vailabili	ity					
						FP1		FP	Р-М				н
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
Leading edge differ- ential (initial execution type)	N/A	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Set	A	A	A	A	A	A	A	A	A	A	A	A	A
Reset	A	A	A	A	A	A	A	A	A	A	A	A	A
Кеер	A	A	A	A	A	A	A	A	A	A	A	A	A
No operation	A	A	A	A	A	A	A	A	A	A	A	A	A

. K

Note:

• A: Available, N/A: Not available

1) In the FP2/FP2SH/FP10SH, when using Y1280, R1120 (special internal relay included), L1280 or anything beyond for the KP instruction, the number of steps is shown in parentheses. Also, in the FP2/FP2SH/FP10SH, when a relay number has an index modifier, the number of steps is shown in parentheses.

Name	Boolean	Symbol	Description	Steps (*1)				
Basic function	on instruct	tions						
On-delay timer	TML		After set value "n" x 0.001 seconds, timer contact "a" is set to on.					
	TMR	TMa. n]	After set value "n" x 0.01 seconds, timer contact "a" is set to on.	3 (4)				
	тмх		After set value "n" x 0.1 seconds, timer contact "a" is set to on.					
	ТМҮ		After set value "n" x 1 second, timer contact "a" is set to on.					
Auxiliary timer (16-bit)	F137 (STMR)	YR L E [F137 STMR S. D]-[]-	After set value "S" x 0.01 seconds, the specified output and R900D are set to on.	5				
Auxiliary timer (32-bit)	F183 (DSTM)	YR LE │ {{E183 DSTM. S. D}-[]-	After set value "S" x 0.01 seconds, the specified output and R900D are set to on.	7				
Counter	СТ	Count Reset n	Decrements from the preset value "n"	3 (4)				
UP/DOWN counter	F118 (UDC)	Count S Reset D	Increments or decrements from the preset value "S" based on up/donw input.	5				



Note: 1) In the FP2/FP2SH/FP10SH, when timer 256 or higher, or counter 255 or lower, is used, the number of steps is the number in parentheses. Also, in the FP2/FP2SH/FP10SH, when a timer number or counter number has an index modifier, the number of steps is the number in parentheses.

						A	vailabili	ity					
						FP1		FP	Р-М				н
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
Basic function instructions													
On-delay	А	А	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
timer TML	(*1)												
On-delay	А	А	А	А	А	А	А	А	А	А	А	А	А
timer TMR													
On-delay	А	А	А	А	А	А	А	А	А	А	А	А	А
timer TMX													
On-delay	А	А	А	А	А	А	А	А	А	А	А	А	А
timer TMY													
Auxiliary	А	А	А	А	N/A	N/A	А	N/A	А	А	А	А	А
timer (16-bit)													
Auxiliary	А	А	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
timer (32-bit)													
Counter	А	А	А	А	А	А	А	А	А	А	А	А	А
UP/DOWN	A	A	A	A	A	A	А	A	A	А	А	А	A
counter													



• A: Available, N/A: Not available

1) This instruction is available for FP0 C10, C14, C16, C32 CPU Ver. 2.0 or later/FP0 T32C.

Name	Boolean	Symbol	Description	Steps
Shift register	SR	Data Shift Shift Reset	Shifts one bit of 16-bit [word internal relay (WR)] data to the left.	1 (2) (*1)
Left/right shift register	F119 (LRSR)	L/R Data Data Dit Shift Reset	Shifts one bit of 16-bit data range specified by "D1" and "D2" to the left or to the right.	5
Control instr	uctions	•		
Master	МС		Starts the master control program.	2
control relay		Master control area		
Master control relay end	MCE	(MCE n)-	Ends the master control program.	2
Jump	JP		The program jumps to the label instruction and continues	2 (3)
Label	LBL	(JP n)- (LBL n)-	from there.	(*2) 1
Auxiliary jump	F19 (SJP)		The program jumps to the label instruction specified by "S" and continues from there.	3
Label	LBL	(LBL n)-		1

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

		-		-	-	A	vailabili	ty		-	-		-
						FP1		FP	Р-М				т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
Shift register	A	A	A	A	A	A	A	A	A	A	A	A	A
Left/right shift register	A	A	A	A	A	A	A	A	A	A	A	A	A
Control instructions													
Master control relay	A	A	A	A	A	A	A	A	A	A	A	A	A
Master control relay end	A	A	A	A	A	A	A	A	A	A	A	A	A
Jump Label	A	A	A	A	A	A	A	A	A	A	A	A	A
Auxiliary jump Label	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A



• A: Available, N/A: Not available

1) In the FP2/FP2SH/FP10SH, when internal relay WR240 or higher is used, the number of steps is the number in parentheses. Also, in the FP2/FP2SH/FP10SH, when the specified internal relay number (word address) has an index modifier, the number of steps is the number in parentheses.

2) In the FP2/FP2SH/FP10SH, when the number "n" in a jump instruction has an index modifier, the number of steps is the number in parentheses.

Name	Boolean	Symbol	Description	Steps
Loop Label	LOOP LBL	(LBL n)-	The program jumps to the label instruction and continues from there (the number of jumps is set in "S").	4 (5) (*1) 1
Break	BRK	H H(BRK)	Stops program execution when the predetermined trigger turns on in the TEST/RUN mode only.	1
End	ED	(ED)-	The operation of program is ended. Indicates the end of a main program.	1
Conditional end	CNDE		The operation of program is ended when the trigger turns on.	1
Eject	EJECT	(EJECT)	Adds page break fo ruse when printing.	1
Step ladder i	instructior	ns		
Start step	SSTP	(SSTP n)	The start of program "n" for process control	3
Next step	NSTL	(NSTL n)-	Start the specified process "n" and clear the process currently started. (Scan execution type)	3
	NSTP	(NSTP n)-	Start the specified process "n" and clear the process currently started. (Pulse execution type)	3
Clear step	CSTP	CSTP n)-	Resets the specified process "n".	3
Clear multi- ple steps	SCLR		Resets multiple processes specified by "n1" and "n2".	5
Step end	STPE	(STPE)	End of step ladder area	1

		-		-		A	vailabili	ty		-	-	-	-
						FP1		FP	P-M			_	т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
Loop	А	A	A	А	А	A	A	A	A	A	A	A	A
Label													
Break	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
End	А	A	A	A	A	A	A	A	A	A	A	A	A
Conditional end	A	A	A	A	A	A	A	A	A	A	A	A	A
Eject	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Step ladder i	nstruc	tions		-			-	-	-	-		-	
Start step	A	A	A	A	A	A	A	A	A	A	A	A	A
Next step NSTL	A	A	A	A	A	A	A	A	A	A	A	A	A
Next step NSTP	A	A	A	A	A	A	A	A	A	A	A	A	A
Clear step	A	A	A	A	A	A	A	A	A	A	А	A	A
Clear multi- ple steps	N/A	А	A	А	N/A	N/A	N/A	N/A	N/A	N/A	A	А	A
Step end	A	A	A	A	A	A	A	A	A	A	A	A	A

• A: Available, N/A: Not available

1) In the FP2/FP2SH/FP10SH, when the number "n" in a loop instruction has an index modifier, the number of steps is the number in parentheses.

Name	Boolean	Symbol	Description	Steps
Subroutine in	nstruction	S		
Subroutine call	CALL	(CALL n)	Executes the specified subroutine. When returning to the main program, outputs in the subroutine program are maintained.	2 (3) (*1)
Output off type subrou- tine call	FCAL	(FGAL n)-	Executes the specified subroutine. When returning to the main program, all outputs in the subroutine program are set to off.	4 (5) (*1)
Subroutine entry	SUB	(SUB n)-	Indicates the start of the subroutine program "n".	1
Subroutine return	RET		Ends the subroutine program.	1
Interrupt inst	tructions			
Interrupt	INT	(INT n)-	Indicates the start of the interrupt program "n".	1
Interrupt return	IRET		Ends the interrupt program.	1
Interrupt control	ICTL		Select interrupt enable/disable or clear in "S1" and "S2" and execute.	5

						A	vailabili	ity					
						FP1		FP	Р-М				т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
Subroutine in	nstruct	tions											
Subroutine call	A	A	A	A	A	A	A	A	A	A	A	A	A
Output off type subrou- tine call	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A
Subroutine entry	A	A	A	A	A	A	A	A	A	A	A	A	A
Subroutine return	A	A	A	A	A	A	A	A	A	A	A	A	A
Interrupt inst	tructio	ns											
Interrupt	A	A	A	A	N/A	A	A	A	A	A	A	A	A
Interrupt return	A	A	A	A	N/A	A	A	A	A	A	A	A	A
Interrupt control	A	A	A	A	N/A	A	A	N/A (*2)	A	A	A	A	A

• A: Available, N/A: Not available

1) In the FP2/FP2SH/FP10SH, when the number "n" of a subroutine program has an index modifier, the number of steps is the number in paretheses.

2) The ICTL instruction cannot be used with the FP-M C16T.

(Interrupt masking and clearing are not possible.)

The interrupt operation is possible using the interrupt setting of the system register 403.

Name	Boolean	Symbol	Description	Steps
Special setting	ng instruc	tions		
Communica- tion condi- tions setting	SYS1		Change the communication conditions for the COM port or tool port based on the contents specified by the character constant.	13
Password setting			Change the password specified by the PLC based on the contents specified by the character constant.	
Interrupt setting			Set the interrupt input based on the contents specified by the character constant.	
PLC link time setting		<u> </u> -{OF>-[SYS1, М]	Set the system setting time when a PLC link is used, based on the contents specified by the character constant.	
MEWTOCOL -COM response control			Change the communication conditions of the COM. port or tool port for MEWTOCOL-COM based on the contents specified by the character constant.	
High-speed counter operation mode changing			Change the operation mode of the high-speed counter, based on the contents specified by the character constant.	
System registers "No. 40 to No. 47" changing	SYS2	H H[\$Y\$2, S, D1, D2]}	Change the setting value of the system register for the PLC link function.	7

						A	vailabili	ity					
						FP1		FP	Р-М				н
Name	FP0	FΡΣ	FP-X	е-Ч	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
Special setting	ng inst	ructio	ıs										
Communica- tion condi- tions setting	N/A	A	A Note2)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Password setting	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Interrupt setting	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
PLC link time setting	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
MEWTOCOL -COM response control	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
High-speed counter operation mode changing	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
System registers "No. 40 to No. 47" changing	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

Name	Boolean	Symbol	Description	Steps
Data compar	e instructi	ions		
16-bit data compare (Start)	ST=	= S1. S2	Begins a logic operation by comparing two 16-bit data in the comparative condition "S1=S2".	5
	ST<>	└└ < > \$1, \$2 └	Begins a logic operation by comparing two 16-bit data in the comparative condition "S1 <s2" "s1="" or="">S2".</s2">	5
ST>		↓	Begins a logic operation by comparing two 16-bit data in the comparative condition "S1>S2".	5
	ST>=	└── ^{> =} S1, S2 ┐_	Begins a logic operation by comparing two 16-bit data in the comparative condition "S1>S2" or "S1=S2".	5
	ST<	└└ ^{< \$1, \$2} ᄀ	Begins a logic operation by comparing two 16-bit data in the comparative condition "S1 <s2".< th=""><th>5</th></s2".<>	5
	ST<=	└── < = \$1, \$2	Begins a logic operation by comparing two 16-bit data in the comparative condition "S1 <s2" "s1='S2".</th' or=""><th>5</th></s2">	5

						A	vailabili	ty					
						FP1		FP	Р-М				н
Name	6P0	Σd∃	FP-X	е-Ч	C14 C16	C24 C40	C56 C72	C16	C20 C32	EP3	FP2	FP2SH	FP10SI
Data compar	e instr	uction	s										
16-bit data compare (Start) ST=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (Start) ST<>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (Start) ST>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (Start) ST>=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (Start) ST<	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (Start) ST<=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A



Name	Boolean	Symbol	Description	Steps
16-bit data compare (AND)	AN=	= \$1,\$2	Connects a Form A (normally open) contact serially by comparing two 16-bit data in the comparative condition "S1=S2".	5
	AN<>	< > \$1, \$2	Connects a Form A (normally open) contact serially by comparing two 16-bit data in the comparative condition "S1 <s2" "s1="" or="">S2".</s2">	5
	AN>	^{> \$1, \$2}	Connects a Form A (normally open) contact serially by comparing two 16-bit data in the comparative condition "S1>S2".	5
	AN>=	>= \$1, \$2	Connects a Form A (normally open) contact serially by comparing two 16-bit data in the comparative condition "S1>S2" or "S1=S2".	5
	AN<	< \$1, \$2	Connects a Form A (normally open) contact serially by comparing two 16-bit data in the comparative condition "S1 <s2".< th=""><th>5</th></s2".<>	5
	AN<=	<= \$1, \$2	Connects a Form A (normally open) contact serially by comparing two 16-bit data in the comparative condition "S1 <s2" "s1='S2".</th' or=""><th>5</th></s2">	5

						A	vailabili	ity					
						FP1	-	FP	Р-М				т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
16-bit data compare (AND) AN=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (AND) AN<>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (AND) AN>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (AND) AN>=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (AND) AN<	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (AND) AN<=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A

Name	Boolean	Symbol	Description	Steps					
16-bit data compare (OR)	OR=	= \$1,\$2	Connects a Form A (normally open) contact in parallel by comparing two 16-bit data in the comparative condition "S1=S2".	5					
	OR<>	^{< >} \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 16-bit data in the comparative condition "S1 <s2" "s1="" or="">S2".</s2">	5					
	OR>	> \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 16-bit data in the comparative condition "S1>S2".						
	OR>=	> = S1, S2	Connects a Form A (normally open) contact in parallel by comparing two 16-bit data in the comparative condition "S1>S2" or "S1=S2".	5					
OR<		< \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 16-bit data in the comparative condition "S1 <s2".< th=""></s2".<>						
OR<=		<= \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 16-bit data in the comparative condition "S1 <s2" "s1='S2".</th' or=""><th>5</th></s2">	5					

						A	vailabili	ity					
						FP1		FP	Р-М				т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
16-bit data compare (OR) OR=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (OR) OR<>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (OR) OR>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (OR) OR>=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (OR) OR<	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
16-bit data compare (OR) OR<=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A

Name	Boolean	Symbol	Description	Steps					
32-bit data compare (Start)	STD=	↓	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)=(S2+1, S2)".	9					
	STD<>	ר ^{D<> S1, S2} ⊐_	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)>(S2+1, S2)".	9					
	STD>	↓ ^{□> S1, S2}	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)".						
	STD>=	↓D> = \$1, \$2	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9					
	STD<	↓ ^{□< \$1, \$2}	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)".	9					
	STD<=	↓ ^{D< = S1, S2}	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9					

						A	vailabili	ity					
						FP1		FP	Р-М				т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
32-bit data compare (Start) STD=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (Start) STD<>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (Start) STD>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (Start) STD>=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (Start) STD<	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (Start) STD<=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A

Name	Boolean	Symbol	Description	Steps
32-bit data compare (AND)	AND=	^{D= S1, S2}	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)=(S2+1, S2)".	9
	AND<>		Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)>(S2+1, S2)".	9
	AND>	^{D> \$1, \$2}	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)".	9
	AND>=	D> = \$1, \$2	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9
	AND<	^{D< \$1, \$2}	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)".	9
AND<=		D< = \$1, \$2	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9

	Availability												
Name					FP1			FP-M					т
	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
32-bit data compare (AND) AND=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (AND) AND<>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (AND) AND>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (AND) AND>=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (AND) AND<	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (AND) AND<=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A

Name	Boolean	Symbol	Description	Steps									
32-bit data compare (OR)	ORD=	D= \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)=(S2+1, S2)".	9									
	ORD<>	^{D<> \$1, \$2}]	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)>(S2+1, S2)".	9									
	ORD>	D> \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)".	9									
	ORD>=	D>=_ S1, S2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9									
	ORD<	D< \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)".	9									
	ORD<=	D< = S1, S2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9									
						A	vailabili	ity					
---	-----	-----	------	------	------------	------------	------------	-----	------------	-----	-----	-------	-------
						FP1	-	FP	Р-М				т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
32-bit data compare (OR) ORD=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (OR) ORD<>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (OR) ORD>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (OR) ORD>=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (OR) ORD<	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
32-bit data compare (OR) ORD<=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A

• A: Available, N/A: Not available

Name	Boolean	Symbol	Description	Steps
Floating point type real number data compare (Start)	STF=	F= \$1, \$2	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)=(S2+1, S2)".	9
	STF<>	↓	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)>(S2+1, S2)".	9
	STF>	F> S1. S2 ⊥	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)".	9
	STF>=	↓ ^{F> = S1, S2}	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9
	STF<	⊢⊏ ^{F< \$1, \$2} ⊥	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)".	9
	STF<=	F< = \$1, \$2	Begins a logic operation by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9

						Α	vailabil	ity					
						FP1		FP	Р-М				н
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
Floating point type real number data compare (Start) STF=	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (Start) STF<>	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (Start) STF>	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (Start) STF>=	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (Start) STF<	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (Start) STF<=	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)

Note) These instructions can be used with FP-X V1.10 or later, FP_Σ 32k and FP₂/FP₂SH V2.0 or later.



• A: Available, N/A: Not available

Note:

Name	Boolean	Symbol	Description	Steps
Floating point type real number data compare (AND)	ANF=	^{F= S1, S2}]	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)=(S2+1, S2)".	9
	ANF<>	^{F<> \$1, \$2}]	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)>(S2+1, S2)".	9
	ANF>	F> \$1, \$2	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)".	9
	ANF>=	F> = S1, S2	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9
	ANF<	^{F< S1, S2}	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)".	9
	ANF<=	^{F< = \$1, \$2}]	Connects a Form A (normally open) contact serially by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9

						Α	vailabil	ity					
						FP1		FP	Р-М				т
Name	FP0	FΡΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
Floating point type real number data compare (AND) ANF=	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (AND) ANF<>	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (AND) ANF>	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (AND) ANF>=	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (AND) ANF<	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)
Floating point type real number data compare (AND) ANF<=	N/A	A Note)	A Note)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A Note)	A Note)	A Note)

Note) These instructions can be used with FP-X V1.10 or later, FP_Σ 32k and FP2/FP2SH V2.0 or later.



• A: Available, N/A: Not available

Note:

Name	Boolean	Symbol	Description	Steps
Floating point type real number data compare (OR)	ORF=	F≈ \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)=(S2+1, S2)".	9
	ORF<>	^{F< > S1, S2}	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)>(S2+1, S2)".	9
	ORF>	F> \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)".	9
	ORF>=	F> = \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)>(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9
	ORF<	F< \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)".	9
	ORF<=	F<= \$1, \$2	Connects a Form A (normally open) contact in parallel by comparing two 32-bit data in the comparative condition "(S1+1, S1)<(S2+1, S2)" or "(S1+1, S1)=(S2+1, S2)".	9

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						Α	vailabil	ity					
						FP1		FP	Р-М				н
Name	FP0	FPΣ	FP-X	FP-e	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
Floating point type real number data compare (OR) ORF=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
Floating point type real number data compare (OR) ORF<>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
Floating point type real number data compare (OR) ORF>	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
Floating point type real number data compare (OR) ORF>=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
Floating point type real number data compare (OR) ORF<	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
Floating point type real number data compare (OR) ORF<=	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A

Note) These instructions can be used with FP-X V1.10 or later, FP_Σ 32k and FP₂/FP₂SH V2.0 or later.



• A: Available, N/A: Not available

Note:

•

11.3 Table of High-level Instructions

The high-level instructions are expressed by the prefixes "F" or "P" with numbers. For most of the high-level instructions, "F" and "P" types are available. The differences between the two types are explained as follows:

- Instructions with the prefix "F" are executed in every scan while its trigger is in the on.
- Instructions with the prefix "P" are executed only when the leading edge of its trigger is detected.

Num- ber	Name	Boolean	Operand	Description	Steps
Data tr	ansfer instruc	tions			
F0 P0	16-bit data move	MV PMV	S, D	(S)→(D)	5
F1 P1	32-bit data move	DMV PDMV	S, D	(S+1, S)→(D+1, D)	7
F2 P2	16-bit data invert and move	MV PMV/	S, D	(S)→(D)	5
F3 P3	32-bit data invert and move	DMV/ PDMV/	S, D	(S+1, S) →(D+1, D)	7
F4 P4	Reading of head word No. of the specified slot	GETS PGETS	S, D	The head word No. of the specified slot is read.	5
F5 P5	Bit data move	ВТМ РВТМ	S, n, D	The specified one bit in "S" is transferred to the specified one bit in "D". The bit is specified by "n".	7
F6 P6	Hexadecimal digit (4-bit) data move	DGT PDGT	S, n, d	The specified one digit in "S" is transferred to the specified one digit in "D". The digit is specified by "n".	7
F7 P7	Two 16-bit data move	MV2 PMV2	S1, S2, D	$(S1) \rightarrow (D),$ (S2) $\rightarrow (D+1)$	7
F8 P8	Two 32-bit data move	DMV2 PDMV2	S1, S2, D	(S1+1, S1)→(D+1, D), (S2+1, S2)→(D+3, D+2)	11
F10 P10	Block move	BKMV PBKMV	S1, S2, D	The data between "S1" and "S2" is transferred to the area starting at "D".	7

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ty					
	((1	(1	(1		FP1 (*1)		FP-N	1 (*1)				н
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
Data transfer	[·] instru	ctions											
F0	А	А	А	А	А	А	А	А	А	А	А	А	А
P0													
F1	А	А	А	А	А	А	А	А	А	А	А	Α	А
P1													
F2	А	А	А	А	А	А	А	А	А	А	А	А	Α
P2													
F3	А	А	А	А	А	А	А	А	А	А	А	А	А
P3													
F4	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	Α	N/A
P4											(*2)	(*2)	
F5	А	А	А	А	А	А	А	А	А	А	А	А	А
P5													
F6	А	А	А	А	А	А	А	А	А	А	А	А	А
P6													
F7	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P7													
F8	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	Α	А
P8													
F10	А	А	А	А	А	А	А	А	А	А	А	А	А
P10													

• A: Available, N/A: Not available

1) For the FP0/FP Σ /FP-X/FP-e/FP1/FP-M, the P type high-level instructions are not available.

2) The instruction is available for FP2/FP2SH CPU Ver. 1.5 or later.

Num- ber	Name	Boolean	Operand	Description	Steps
F11 P11	Block copy	COPY PCOPY	S, D1, D2	The data of "S" is transferred to the all area between "D1" and "D2".	7
F12 P12 F12	Data read from IC card/ROM	ICRD PICRD ICRD	S1, S2, D	The data stored in the expansion memory of the IC card or ROM specified by "S1" and "S2" are transferred to the area startign at "D".	11
F13 P13 P13	Data write to IC card/ROM	ICWT PICWT PICWT	S1, S2, D	The data specified by "S1" and "S2" are transferred to the IC card expansion memory area or ROM starting at "D".	11
F14 P14	Program read from IC memory card	PGRD PPGRD	S	The program specified using "S" is transferred into the CPU from IC memory card and executes it.	3
F15 P15	16-bit data exchange	ХСН РХСН	D1, D2	(D1)→(D2), (D2)→(D1)	5
F16 P16	32-bit data exchange	DXCH PDXCH	D1, D2	(D1+1, D1)→(D2+1, D2) (D2+1, D2)→(D1+1, D1)	5
F17 P17	Higher/lower byte in 16-bit data exchange	SWAP PSWAP	D	The higher byte and lower byte of "D" are exchanged.	3
F18 P18	16-bit data block exchange	ВХСН РВХСН	D1, D2, D3	Exchange the data between "D1" and "D2" with the data specified by "D3".	7
Contro	ol instruction	T	1		•
F19	Auxiliary jump	SJP	S	The program jumps to the label instruction specified by "S" and continues from there.	3
Binary	arithmetic ins	structions			
F20	16-bit data	+ P+	S, D	(D)+(S)→(D)	5
F21 P21	32-bit data addition	D+ PD+	S, D	(D+1, D)+(S+1, S)→(D+1, D)	7
F22 P22	16-bit data addition	+ P+	S1, S2, D	(S1)+(S2)→(D)	7

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

	Availability												
	<u> </u>	<u> </u>	,	_		FP1 (*1)		FP-N	/ (*1)			_	т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
F11	Α	Α	Α	А	Α	А	А	А	А	А	А	А	А
P11													
F12	-	-	-	-	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А
P12													
F12	Α	А	А	А									
	(*2)												
F13	-	-	-	-	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А
P13													
P13	A	A	A	A									
	(*2)												
F14	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A
P14													
F 4 F	^	^	^	^	^	^	۸	^	^	^	۸	^	٨
F 15 P15	A	А	А	А	A	А	А	А	A	А	А	А	А
F16	Α	Α	Δ	Α	Α	Δ	Α	Α	Α	Α	Α	Α	Α
P16	~	~		~	~	~		~	~		~		~
F17	Α	Α	А	А	Α	А	А	А	А	А	А	А	А
P17													
F18	N/A	А	Α	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P18													
Control instr	uction		1		1				r	r			
F19	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
Discourse and the													
Binary arithm	netic ir	istruct	ions										
F20 P20	A	A	A	A	A	A	A	A	A	A	A	A	A
F21	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ
P21	~	~	~	~	~	~	~	~	~		~	~	~
F22	А	А	А	А	А	А	А	А	А	А	А	А	А
P22													

• A: Available, N/A: Not available

1) For the FP0/FP2/FP-X/FP-e/FP1/FP-M, the P type high-level instructions except for P13 (PICWT) instruction are not available.

2) This instruction is available for FP0 T32C and FP0 C10/C14/C16/C32 CPU Ver. 2.0 or later.

Num- ber	Name	Boolean	Operand	Description	Steps
F23 P23	32-bit data addition	D+ PD+	S1, S2, D	(S1+1, S1)+(S2+1, S2)→(D+1, D)	11
F25 P25	16-bit data subtraction	- P-	S, D	(D)-(S)→(D)	5
F26 P26	32-bit data subtraction	D- PD-	S, D	(D+1, D)-(S+1, S)→(D+1, D)	7
F27 P27	16-bit data subraction	- P-	S1, S2, D	(S1)-(S2)→(D)	7
F28 P28	32-bit data subtraction	D- PD-	S1, S2, D	(S1+1, S1)-(S2+1, S2)→(D+1, D)	11
F30 P30	16-bit data multiplication	* P*	S1, S2, D	(S1)X(S2)→(D+1, D)	7
F31 P31	32-bit data multiplication	D* PD*	S1, S2, D	(S1+1, S1)X(S2+1, S2)→(D+3, D+2, D+1, D)	11
F32 P32	16-bit data division	% P%	S1, S2, D	(S1)÷(S2)→quotient (D) remainder (DT9015 for FP0/FP-e/FP1/FP-M/FP3 or DT90015 for FP0 T32/FP Σ /FP2/FP2SH/FP10SH)	7
F33 P33	32-bit data division	D% PD%	S1, S2, D	(S1+1, S1)÷(S2+1, S2) \rightarrow quotient (D+1, D) remainder (DT9016, DT9015 for FP0/FP-e/FP1/ FP-M/FP3 or DT90016, DT90015 for FP0 T32/ FP Σ /FP2/FP2SH/FP10SH)	11
F34 P34	16-bit data multiplication (result in 16 bits)	*W P*W	S1, S2, D	(S1)X(S2)→(D)	7
F35 P35	16-bit data increment	+1 P+1	D	(D)+1→(D)	3
F36 P36	32-bit data increment	D+1 PD+1	D	(D+1, D)+1→(D+1, D)	3

						A	vailabili	ity					
	_	<u> </u>	÷	<u> </u>		FP1 (*1)		FP-N	/ (*1)				т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
F23 P23	A	A	A	A	A	A	A	A	A	A	A	A	A
F25 P25	А	A	A	A	А	A	A	А	А	A	A	A	A
F26 P26	A	A	A	A	A	A	A	A	A	A	A	A	A
F27 P27	A	A	A	A	A	A	A	A	A	A	A	A	A
F28 P28	А	A	A	A	A	A	A	A	A	A	A	A	A
F30 P30	A	A	A	A	A	A	A	A	A	A	A	A	A
F31 P31	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F32 P32	A	A	A	A	A	A	A	A	A	A	A	A	A
F33 P33	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F34 P34	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F35 P35	А	A	A	A	А	A	A	А	А	A	A	A	A
F36 P36	A	A	A	A	A	A	A	A	A	A	A	A	A



Num- ber	Name	Boolean	Operand	Description	Steps
F37	16-bit data	-1	D	(D)-1→(D)	3
P37	decrement	P-1			
F38	32-bit data	D-1	D	(D+1, D)-1→(D+1, D)	3
P38	decrement	PD-1			
F39	32-bit data	D*D	S1, S2, D	(S1+1, S1)x(S2+1, S2)→(D+1, D)	11
P39	multiplication	PD*D			
	(result in 32				
	bits)	_			
BCD a	rithmetic instru	uctions	I		1
F40	4-digit	B+	S, D	(D)+(S)→(D)	5
P40	BCD data	PB+			
F41	8-digit	DB+	S. D	(D+1. D)+(S+1. S)→(D+1. D)	7
P41	BCD data	PDB+	- /		
	addition				
F42	4-digit	B+	S1, S2, D	(S1)+(S2)→(D)	7
P42	BCD data	PB+			
	addition				
F43	8-digit	DB+	S1, S2, D	(S1+1, S1)+(S2+1, S2)→(D+1, D)	11
P43	BCD data	PDB+			
	addition				
F45	4-digit	В-	S, D	(D)-(S)→(D)	5
P45	BCD data	PB-			
= 10	subtraction				-
F46	8-digit	DB-	S, D	$(D+1, D)-(S+1, S) \rightarrow (D+1, D)$	1
P46	BCD data	PDR-			
E 47		в	61 62 D		7
P47	H-uigit BCD data	DR.	31, 32, D		[′]
F41	subtraction	10-			
	Subliaction				1

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ity					
	—	<u> </u>	Ę	<u> </u>		FP1 (*1)		FP-N	/ (*1)				т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
F37 P37	A	A	A	A	А	A	A	А	A	A	A	A	A
F38 P38	A	A	A	A	А	A	A	A	A	A	A	A	A
F39 P39	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
BCD arithme	tic inst	tructio	ns										
F40 P40	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F41 P41	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F42 P42	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F43 P43	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F45 P45	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F46 P46	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F47 P47	A	A	A	A	A	A	A	N/A	A	A	A	A	A

• A: Available, N/A: Not available

Num- ber	Name	Boolean	Operand	Description	Steps
F48	8-digit	DB-	S1, S2, D	(S1+1, S1)-(S2+1, S2)→(D+1, D)	11
P48	BCD data subraction	PDB-			
F50	4-digit	В*	S1, S2, D	(S1)X(S2)→(D+1, D)	7
P50	BCD data multiplication	PB*			
F51	8-digit	DB*	S1, S2, D	(S1+1, S1)X(S2+1, S2)→(D+3, D+2, D+1, D)	11
P51	BCD data multiplication	PDB*			
F52	4-digit	В%	S1, S2, D	(S1)÷(S2)→quotient (D)	7
P52	BCD data division	PB%		remainder (DT9015 for FP0/FP-e/FP1/FP-M/FP3 or DT90015 for FP0 T32/FP2/FP2/FP2SH/FP10SH)	
F53	8-digit	DB%	S1, S2, D	(S1+1, S1)÷(S2+1, S2)→quotient (D+1, D)	11
P53	BCD data	PDB%		remainder (DT9016, DT9015 for FP0/FP-e/FP1/	
	division			FP-M/FP3 or DT90016, DT90015 for FP0 T32/ FPΣ/FP2/FP2SH/FP10SH)	
F55	4-digit	B+1	D	(D)+1→(D)	3
P55	BCD data increment	PB+1			
F56	8-digit	DB+1	D	(D+1, D)+1→(D+1, D)	3
P56	BCD data increment	PDB+1			
F57	4-digit	B-1	D	(D)-1→(D)	3
P57	BCD data decrement	PB-1			
F58 P58	8-digit BCD data	DB-1 PDB-1	D	(D+1, D)-1→(D+1, D)	3
	decrement				

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ity					
	<u> </u>	<u> </u>	Ę	<u> </u>		FP1 (*1))	FP-N	l (*1)				т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	£РЗ	FP2	FP2SH	FP10SI
F48 P48	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F50 P50	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F51 P51	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F52 P52	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F53 P53	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F55 P55	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F56 P56	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F57 P57	A	A	A	A	A	A	A	N/A	A	A	A	A	A
F58 P58	A	A	A	A	A	A	A	N/A	A	A	A	A	A



Num- ber	Name	Boolean	Operand	Description	Steps
Data co	mpare instruction	ons		-	-
F60	16-bit data	CMP	S1, S2	(S1)>(S2)→R900A: on	5
P60	compare	PCMP		(S1)=(S2)→R900B: on	
				(S1)<(S2)→R900C: on	
F61	32-bit data	DCMP	S1, S2	(S1+1, S1)>(S2+1, S2)→R900A: on	9
P61	compare	PDCMP		(S1+1, S1)=(S2+1, S2)→R900B: on	
				(S1+1, S1)<(S2+1, S2)→R900C: on	
F62	16-bit data	WIN	S1, S2, S3	(S1)>(S3)→R900A: on	7
P62	band	PWIN		(S2)< or=(S1)< or=(S3)→R900B: on	
	compare			(S1)<(S2)→R900C: on	
F63	32-bit data	DWIN	S1, S2, S3	(S1+1, S1)>(S3+1, S3)→R900A: on	13
P63	band	PDWIN		(S2+1, S2)< or=(S1+1, S1)< or=(S3+1,	
	compare			S3)→R900B: on	
				(S1+1, S1)<(S2+1, S2)→R900C: on	
F64	Block data	BCMP	S1, S2, S3	Compares the two blocks beginning with "S2" and	7
P64	compare	PBCMP		"S3" to see if they are equal.	
Logic o	peration instruc	tions	<u>.</u>		
F65	16-bit data	WAN	S1, S2, D	(S1) AND (S2)→(D)	7
P65	AND	PWAN			
F66	16-bit data	WOR	S1, S2, D	(S1) OR (S2)→(D)	7
P66	OR	PWOR			
F67	16-bit data	XOR	S1, S2, D	$\{(S1) \text{ AND } (\overline{S2})\} \text{ OR } \{(\overline{S1}) \text{ AND } (S2)\} \rightarrow (D)$	7
P67	exclusive OR	PXOR			
F68	16-bit data	XNR	S1, S2, D	$\{(S1) \text{ AND } (S2)\} \text{ OR } \{(\overline{S1}) \text{ AND } (\overline{S2})\} \rightarrow (D)$	7
P68	exclusive	PXNR			
	NOR				
F69	16-bit data	WUNI	S1, S2, S3,	([S1] AND [S3]) OR ([S2] AND [S3])→(D)	9
P69	unite	PWUNI	D	When (S3) is H0, (S2)→(D)	
				When (S3) is HFFFF, (S1) \rightarrow (D)	

		-	-	-	-	A	/ailabili	ty		-	-	-	-
	~	<u> </u>	Ê	<u> </u>		FP1 (*1)		FP-N	/ (*1)				т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	EP3	FP2	FP2SH	FP10SI
Data compare	instruc	tions											
F60 P60	A	A	A	A	A	A	A	A	A	A	A	A	A
F61 P61	A	A	A	A	A	A	A	A	A	A	A	A	A
F62 P62	A	A	A	A	A	A	A	A	A	A	A	A	A
F63 P63	A	A	A	A	A	A	A	A	A	A	A	A	A
F64 P64	А	A	A	A	N/A	A	А	N/A	A	A	A	A	A
Logic operation	on instru	uctions	-	-	-				-		-	-	-
F65 P65	A	A	A	A	A	A	A	A	A	A	A	A	A
F66 P66	А	A	A	A	A	A	A	A	A	A	A	A	A
F67 P67	А	A	A	A	A	A	A	A	A	A	A	A	A
F68 P68	A	A	A	A	A	A	A	A	A	A	A	A	A
F69 P69	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A



Num- ber	Name	Boolean	Operand	Description	Steps
Data co	onversion instruc	tions	•		
F70	Block check	BCC	S1, S2, S3,	Creates the code for checking the data specified by	9
P70	code	PBCC	D	"S2" and "S3" and stores it in "D".	
	calculation			The calculation method is specified by "S1".	
F71	Hexadecimal	HEXA	S1, S2, D	Converts the hexadecimal data specified by "S1"	7
P71	data \rightarrow ASCII	PHEXA		and "S2" to ASCII code and stores it in "D".	
	code			Example: HABCD \rightarrow H <u>42</u> <u>41</u> <u>44</u> <u>43</u>	
				BADC	
F72	ASCII code	AHEX	S1, S2, D	Converts the ASCII code specified by "S1" and	7
P72	\rightarrow Hexadeci-	PAHEX		"S2" to hexadecimal data and stores it in "D".	
	mal data			Example: H 44 43 42 $41 \rightarrow$ HCDAB	
				D C B A	
F73	4-digit BCD	BCDA	S1, S2, D	Converts the four digits of BCD data specified by	7
P73	data → ASCII	PBCDA		"S1" and "S2" to ASCII code and stores it in "D".	
	code			Example: H1234 \rightarrow H <u>32</u> <u>31</u> <u>34</u> <u>33</u>	
			04.00.5		
F/4	ASCII code	ABCD	S1, S2, D	Converts the ASCII code specified by "S1" and	9
P/4	\rightarrow 4-digit	PABCD		"S2" to four digits of BCD data and stores it in "D".	
	BCD data			Example: H $\frac{34}{4}$ $\frac{33}{2}$ $\frac{32}{2}$ $\frac{31}{4}$ \rightarrow H3412	
E75	16 hit hinom		61 62 D	4 3 2 1	7
F73			51, 52, D	"Converts the 16 bits of binary data specified by	'
F73		FDINA		bytes)	
	code			Example: $K_{-100} \rightarrow H 30 30 31 2D 20 20$	
F76	ASCII code	ABIN	S1, S2, D	Converts the ASCII code specified by "S1" and	7
P76	→ 16-bit	PABIN		"S2" to 16 bits of binary data and stores it in "D".	
	binary data			Example: H 30 30 31 2D 20 20 → K-100	
				0 0 1 -	
F77	32-bit binary	DBIA	S1, S2, D	Converts the 32 bits of binary data (S1+1, S1) to	11
P77	data \rightarrow ASCII	PDBIA		ASCII code and stores it in D (area of "S2" bytes).	
	code				

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

		-	-	-	-	A	vailabili	ty		-	-	-	-
	÷.	Ę	÷	÷		FP1 (*1)		FP-N	/I (*1)	ļ		_	т
Name	FP0 (*1	FPΣ (*1	·∗)Х-Ч∃	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
Data conversion	on instr	uctions											
F70 P70	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F71 P71	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F72 P72	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F73 P73	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F74 P74	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F75 P75	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F76 P76	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F77 P77	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A

• A: Available, N/A: Not available

Num- ber	Name	Boolean	Operand	Description	Steps
F78	ASCII code	DABI	S1, S2, D	Converts the ASCII code specified by "S1" and	11
P/8	\rightarrow 32-bit binary data	PDABI		$^{\circ}$ S2° to 32 bits of binary data and stores it in (D+1, D).	
F80	16-bit binary	BCD	S, D	Converts the 16 bits of binary data specified by "S"	5
P80	data → 4-digit BCD	PBCD		to four digits of BCD data and stores it in "D". Example: $K100 \rightarrow H100$	
	data				
F81	4-digit BCD	BIN	S, D	Converts the four digits of BCD data specified by	5
P81	data → 16-bit binarv data	PBIN		"S" to 16 bits of binary data and stores it in "D". Example: H100 \rightarrow K100	
F82	32-bit binary	DBCD	S, D	Converts the 32 bits of binary data specified by	7
P82	data →	PDBCD		(S+1, S) to eight digits of BCD data and stores it in	
	data				
F83	8-digit BCD	DBIN	S, D	Converts the eight digits of BCD data specified by	7
P83	data → 32-bit binary data	PDBIN		(S+1, S) to 32 bits of binary data and stores it in	
F84	16-bit data	INV	D	Inverts each bit of data of "D".	3
P84	invert (com-	PINV			
F85	plement of 1)	NEG	D	Inverts each bit of data of "D" and adds 1 (inverts	3
P85	complement	PNEG		the sign).	Ū
	of 2				
F86	32-bit data	DNEG	D	Inverts each bit of data of (D+1, D) and adds 1	3
P86	complement of 2	PDNEG		(inverts the sign).	
F87	16-bit data	ABS	D	Gives the absolute value of the data of "D".	3
P87	absolute	PABS			

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ity					
	—	<u> </u>	Ę	<u> </u>		FP1 (*1))	FP-N	/ (*1)	ļ			т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
F78 P78	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F80 P80	A	A	A	A	A	A	A	A	A	A	A	A	A
F81 P81	A	A	A	A	A	A	A	A	A	A	A	A	A
F82 P82	A	A	A	A	A	A	A	A	A	A	A	A	A
F83 P83	A	A	A	A	A	A	A	A	A	A	A	A	A
F84 P84	A	A	A	A	A	A	A	A	A	A	A	A	A
F85 P85	A	A	A	A	A	A	A	A	A	A	A	A	A
F86 P86	A	A	A	A	A	A	A	A	A	A	A	A	A
F87 P87	A	A	A	A	A	A	A	A	A	A	A	A	A

• A: Available, N/A: Not available

Num- ber	Name	Boolean	Operand	Description	Steps
F88 P88	32-bit data absolute	DABS PDABS	D	Gives the absolute value of the data of (D+1, D).	3
F89 P89	16-bit data sign extension	EXT PEXT	D	Extends the 16 bits of data in "D" to 32 bits in (D+1, D).	3
F90 P90	Decode	DECO PDECO	S, n, D	Decodes part of the data of "S" and stores it in "D". The part is specified by "n".	7
F91 P91	7-segment decode	SEGT PSEGT	S, D	Converts the data of "S" for use in a 7-segment display and stores it in (D+1, D).	5
F92 P92	Encode	ENCO PENCO	S, n, D	Encodes part of the data of "S" and stores it in "D". The part is specified by "n".	7
F93 P93	16-bit data combine	UNIT PUNIT	S, n, D	The least significant digit of each of the "n" words of data beginning at "S" are stored (united) in order in "D".	7
F94 P94	16-bit data distribute	DIST PDIST	S, n, D	Each of the digits of the data of "S" are stored in (distriuted to) the least significant digits of the areas beginning at "D".	7
F95 P95	Character→ ASCII code	ASC PASC	S, D	Twelve characters of the characer constants of "S" are converted to ASCII code and stored in "D" to "D+5".	15
F96 P96	16-bit table data search	SRC PSRC	S1, S2, S3	The data of "S1" is searched for in the areas in the range "S2" to "S3" and the result is stored in DT9037 and DT9038 for FP0/FP-e/FP1/FP-M/FP3 and DT90037 and DT90038 for FP0 T32/FP Σ /FP2/FP2SH/FP10SH.	7
F97 P97	32-bit table data search	DSRC PDSRC	S1, S2, S3	The data of (S1+1, S1) is searched for in the 32-bit data designated by "S3", beginning from "S2", and the result if stored in DT90037 and DT90038.	11
Data sh	nift instructions				
F98 P98	Data table shift-out and compress	CMPR PCMPR	D1, D2, D3	Transfer "D2" to "D3". Any parts of the data between "D1" and "D2" that are 0 are compressed, and shifted in order toward "D2".	7

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ity					
	-	((<u> </u>		FP1 (*1))	FP-N	A (*1)	ļ			т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
F88 P88	A	A	A	A	A	A	A	A	A	A	A	A	A
F89 P89	A	A	A	A	A	A	A	A	A	A	A	A	A
F90 P90	A	А	A	A	A	A	A	A	A	A	A	A	A
F91 P91	A	A	A	A	A	A	A	A	A	A	A	A	A
F92 P92	A	A	A	A	A	A	A	A	A	A	A	A	A
F93 P93	A	A	A	A	A	A	A	A	A	A	A	A	A
F94 P94	A	A	A	A	A	A	A	A	A	A	A	A	A
F95 P95	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F96 P96	A	A	A	A	A	A	A	A	A	A	A	A	A
F97 P97	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Data shift inst	ructions	3			-				-	-		-	
F98 P98	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A



Num- ber	Name	Boolean	Operand	Description	Steps
F99	Data table	CMPW	S, D1, D2	Transfer "S" to "D1". Any parts of the data between	7
P99	shift-in and	PCMPW		"D1" and "D2" that are 0 are compressed, and	
	compress			shifted in order toward "D2".	
F100	Right shift of	SHR	D, n	Shifts the "n" bits of "D" to the right.	5
P100	multiple bits	PSHR			
	16-bit data				
F101	Left shift of	SHL	D, n	Shifts the "n" bits of "D" to the left.	5
P101	multiple bits	PSHL			
	(n bits) in a				
	16-bit data				
F102	Right shift of	DSHR	D, n	Shifts the "n" bits of the 32-bit data area specified	5
P102	n bits in a 32-	PDSHR		by (D+1, D) to the right.	
E 400	bit data	DOLU	D		-
F103	Left shift of n	DSHL	D, n	Shifts the "n" bits of the 32-bit data area specified	5
P103	bits in a 32-	PDSHL		by $(D+1, D)$ to the left.	
F105	Bight shift of	BSR	D	Shifts the one digit of data of "D" to the right	3
P105	one hexade-	PBSR	D		5
	cimal digit	_			
	(4-bit)				
F106	Left shift of	BSL	D	Shifts the one digit of data of "D" to the left.	3
P106	one hexade-	PBSL			
	(4-bit)				
F108	Right shift of	BITR	D1, D2, n	Shifts the "n" bits of data range by "D1" and "D2" to	7
P108	multiple bits	PBITR		the right.	
	(n bits)				
F109	Left shift of	BITL	D1, D2, n	Shifts the "n" bits of data range by "D1" and "D2" to	7
P109	multiple bits	PBITL		the left.	
	(n bits)				
F110	Right shift of	WSHR	D1, D2	Shifts the one word of the areas by "D1" and "D2"	5
P110	one word	PWSHR		to the right.	
	(16-bit)				
F111	Left shift of	WSHL	D1, D2	Shifts the one word of the areas by "D1" and "D2"	5
P111	one word	PWSHL		to the left.	
E112	(10-DII) Bight shift of	WRSD	D1 D2	Shifts the one digit of the grade by "D1" and "D2" to	5
P112	one hexade-	PWRSR	01, 02	the right	5
	cimal digit			l de light	
	(4-bit)				

						A	vailabili	ity					
	_	÷	÷	Ê		FP1 (*1))	FP-N	/ (*1)			_	т
Name	,*) 0	ي ۲	*)X-	-e(*	C14	C24	C56	C16	C20	ę	2	2SH	10S
	E E	ĿР	Ц	Е	C16	C40	C72	010	C32	4	ĿЬ	Ц	ЕÞ
F99	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А	А
P99													
F100	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α
P100				~				~					~
F101	A	А	А	А	A	A	А	А	А	А	A	А	А
P101													
F102	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P102													
F 400	N1/A	•	•	N1/A	N1/A	N1/A	N1/A	N1/A	N1/A	N1/A	•	•	•
F103 P103	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
1 100													
F105	Α	А	A	Α	A	А	A	Α	Α	A	А	Α	А
P105													
F106	A	A	A	A	A	А	A	A	A	A	A	A	A
FIUO													
F108	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
P 100													
F109	N/A	Α	Α	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Α	Α	А
P109													
F110	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α	Α	А
P110		~	~	~	~	~	~	~	~	~	~	~	~
F111	A	А	A	A	A	А	A	A	A	A	А	A	А
P111													
F112	Α	A	A	Α	Α	A	A	Α	Α	A	Α	Α	A
P112													

• A: Available, N/A: Not available

1) For the FP0/FP Σ /FP-X/FP-e/FP1/FP-M, the P type high-level instructions are not available.

Num- ber	Name	Boolean	Operand	Description	Steps
F113 P113	Left shift of one hexade-	WBSL PWBSL	D1, D2	Shifts the one digit of the areas by "D1" and "D2" to the left.	5
	(4-bit)				
FIFO in	structions	I			
F115	FIFO buffer	FIFT	n, D	The "n" words beginning from "D" are defined in the	5
P115	define	PFIFT		buffer.	
F116	Data read	FIFR	S, D	The oldest data beginning from "S" that was written	5
P116	from FIFO buffer	PFIFR		to the buffer is read and stored in "D".	
F117	Data write	FIFW	S, D	The data of "S" is written to the buffer starting from	5
P117	into FIFO	PFIFW		"D".	
Decis	buffer				
F118			SD	Counts up or down from the value preset in "S" and	5
	counter		0, 0	stores the elapsed value in "D".	U
F119	Left/right	LRSR	D1, D2	Shifts one bit to the left or right with the area	5
	shift register			between "D1" and "D2" as the register.	
Data ro	tate instructions	i 1	I		1
F120	16-bit data	ROR	D, n	Rotate the "n" bits in data of "D" to the right.	5
P120	right rotate	PROR	D		-
F121	left rotate		D, n	Rotate the n bits in data of D to the left.	5
F122	16-bit data	RCR	D. n	Rotate the "n" bits in 17-bit area consisting of "D"	5
P122	right rotate	PRCR	_,	plus the carry flag (R9009) data to the right.	-
	with carry				
	flag (R9009)				
	data				
F123	16-bit data	RCL	D, n	Rotate the "n" bits in 17-bit area consisting of "D"	5
P123	with carry	PRCL		plus the carry flag (R9009) data to the left.	
	flag (R9009)				
	data				

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ity					
	^	(((FP1 (*1)		FP-N	A (*1)				н
Name	FP0 (*1	FPΣ (*1	FP-X(*1	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
F113	А	А	А	А	А	А	А	А	А	А	А	А	А
P113													
FIFO instruction	ons												
F115	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А	А
P115		•					N 1/A		N1/A	•		•	•
F116	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	А
1110													
F117	N/A	А	Α	N/A	N/A	N/A	N/A	N/A	N/A	А	Α	А	А
P117													
Basic function	instruc	tions											
F118	A	A	A	A	A	A	A	A	A	А	A	A	A
F119	A	A	A	A	A	A	A	A	A	A	A	A	A
Data rotate ins	struction	าร	1	1	1			1			1		
F120	А	А	А	А	А	А	А	А	А	А	А	А	А
P120													
F121	A	А	A	A	А	A	A	A	A	А	A	А	А
P121	٨	۸	٨	۸	۸	۸	۸	۸	٨	۸	۸	۸	۸
P122	A	A	A	A	A	A	A	A	A	A	A	А	А
F123 P123	A	A	A	A	A	A	A	A	A	A	A	A	A

• A: Available, N/A: Not available

Num- ber	Name	Boolean	Operand	Description	Steps
F125	32-bit data	DROR	D, n	Rotate the number of bits specified by "n" of the	5
P125	right rotate	PDROR		double words data (32 bits) specified by (D+1, D) to the right.	
F126	32-bit data	DROL	D, n	Rotate the number of bits specified by "n" of the	5
P126	left rotate	PDROL		double words data (32 bits) specified by (D+1, D) to the left.	
F127	32-bit data	DRCR	D, n	Rotate the number of bits specified by "n" of the	5
P127	right rotate	PDRCR		double words data (32 bits) specified by (D+1, D) to	
	with carry			the right together with carry flag (R9009) data.	
	data				
F128	32-bit data	DRCL	D, n	Rotate the number of bits specified by "n" of the	5
P128	left rotate	PDRCL		double words data (32 bits) specified by (D+1, D) to	
	with carry			the left together with carry flag (R9009) data.	
	flag (R9009)				
Dit	data				
Bit mar	ipulation instruc	ctions	<u> </u>		-
F130	16-bit data bit	BIS	D, n	Set the value of bit position "n" of the data of "D" to	5
P130	Set	PDIS	Dr	I.	<i>_</i>
P131	reset		D, N		Э
F132	16-bit data bit	BTI	Dn	Unvert the value of hit position "n" of the data of "D"	5
P132	invert	PBTI	2,11		0
F133	16-bit data bit	BTT	D, n	Test the value of bit position "n" of the data of "D"	5
P133	test	PBTT		and output the result to R900B.	
F135	Number of on	BCU	S, D	Store the number of on bits in the data of "S" in "D".	5
P135	(1) bits in	PBCU			
	16-bit data				
F136	Number of on	DBCU	S, D	Store the number of on bits in the data of (S+1, S)	7
P136	(1) bits in	PDBCU		in "D".	
	32-bit data				

						A	vailabili	ity					
	~	<u> </u>	÷	<u> </u>		FP1 (*1)		FP-N	A (*1)				т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
F125 P125	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F126 P126	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F127 P127	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F128 P128	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Bit manipulation	on instr	uctions	5	-	-	-		-	-	-		-	
F130 P130	A	A	A	A	A	A	А	A	A	A	A	A	A
F131 P131	A	A	A	A	A	A	A	A	A	A	A	A	A
F132 P132	A	A	A	A	A	A	A	A	A	A	A	A	A
F133 P133	A	A	A	A	A	A	A	A	A	A	A	A	A
F135 P135	A	A	A	A	A	A	A	A	A	A	A	A	A
F136 P136	A	A	A	A	A	A	A	A	A	A	A	A	A

. E

• A: Available, N/A: Not available

Num- ber	Name	Boolean	Operand	Description	Steps
Basic f	unction instructi	on			
F137	Auxiliary timer (16-bit)	STMR	S, D	Turn on the specified output and R900D after 0.01 s \times set value.	5
Special	instructions				
F138 P138	Hours, min- utes and sec- onds data to seconds data	HMSS PHMSS	S, D	Converts the hour, minute and second data of (S+1, S) to seconds data, and the converted data is stored in (D+1, D).	5
F139 P139	Seconds data to hours, minutes and seconds data	SHMS PSHMS	S, D	Converts the seconds data of $(S+1, S)$ to hour, minute and second data, and the converted data is stored in $(D+1, D)$.	5
F140 P140	Carry flag (R9009) set	STC PSTC	-	Turns on the carry flag (R9009).	1
F141 P141	Carry flag (R9009) reset	CLC PCLC	-	Turns off the carry flag (R9009).	1

						A	vailabili	ity					
	<u> </u>	_	÷	÷		FP1 (*1))	FP-N	/ (*1)			_	т
Name	FP0 (*1	FPΣ (*'	FP-X(*	FP-e(*'	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
Basic function	instruc	tion											
F137	Α	А	A	A	N/A	N/A	A	N/A	А	A	A	А	А
Special instrue	ctions												
F138	Α	А	Α	Α	N/A	А	А	N/A	Α	А	Α	Α	А
P138	(*2)												
F139	А	А	Α	А	N/A	А	А	N/A	Α	А	А	Α	А
P139	(*2)												
F140	Α	А	А	А	N/A	А	А	N/A	Α	А	А	А	А
P140													
F141 P141	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A



1) For the FP0/FP Σ /FP-X/FP-e/FP1/FP-M, the P type high-level instructions are not available.

2) On the FP0 it is only possible to use F138 and F139 with the T32 type.

Num- ber	Name	Boolean	Operand	Description	Steps
F142	Watching	WDT	S	The time (allowable scan time for the system) of	3
P142	dog timer	PWDT		watching dog timer is changed to "S" \times 0.1 (ms) for	
	update			that scan.	
F143	Partial I/O	IORF	D1, D2	Updates the I/O from the number specified by "D1"	5
P143	update	PIORF		to the number specified by "D2".	
F144	Serial data	TRNS	S, n	The COM port received flag (R9038) is set to off to	5
	communica-			enable reception.	
	tion control			Beginning at "S", "n" bytes of the data registers are	
				sent from the COM port.	
F145	Data send	SEND	S1, S2, D, N	Sends the data to another station in the network	9
P145		PSEND		(MEWNET).	
F146	Data receive	RECV	S1, S2, N, D	Receives the data to another station in the network	9
P146		PRECV		(MEWNET).	
F145	Data send	SEND	S1, S2, D, N	Sends the data to the slave station as the MOD	9
P145				bus master.	
F146	Data receive	RECV	S1, S2, N, D	Receives the data from the slave station as the	9
P146				MOD bus master.	
F145	Data send	SEND	S1, S2, D, N	Sends the data to the slave station as the	9
P145				MEWTOCOL master.	
F146	Data receive	RECV	S1, S2, N, D	Receives the data from the slave station as the	9
P146				MEWTOCOL master.	
F147	Printout	PR	S, D	Converts the ASCII code data in the area starting	5
				with "S" for printing, and outputs it to the word	
				external output relay WY specified by "D".	
F148	Self-	ERR	n	Stores the self-diagnostic error number "n" in	3
P148	diagnostic	PERR	(n: k100 to	(DT9000 for FP0/FP-e/FP1/FP-M/FP3 or DT90000	
	error set		K299)	for FP0 T32/FP Σ /FP2/FP2SH/FP10SH), turns	
				R9000 on, and turns on the ERROR LED.	

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

		-		-	-	A	vailabili	ty		-	-	-	-
	<u> </u>	<u> </u>	÷	<u> </u>		FP1 (*1)		FP-N	l (*1)	ļ			т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
F142 P142	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A
F143 P143	А	А	A	A	N/A	A	A	А	A	A	A	А	A
F144	A	N/A	A	A	N/A	A (*2)	A (*2)	N/A	A (*2)	N/A	A	A	A
F145 P145	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
F146 P146	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
F145 P145	N/A	A (*3)	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F146 P146	N/A	A (*3)	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F145 P145	N/A	A (*3)	A (*3)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F146 P146	N/A	A (*3)	A (*3)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F147	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F148 P148	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A



1) For the FP0/FP Σ /FP-X/FP-e/FP1/FP-M, the P type high-level instructions are not available.

2) Available for: - FP1 C24C, C40C, C56C, and C72C

- FP-M C20RC, C20TC, C32TC

3) These instructions can be used with FP-X V1.20 or later and FP Σ 32k.

Num- ber	Name	Boolean	Operand	Description	Steps
F149 P149	Message display	MSG PMSG	S	Displays the character constant of "S" in the connected programming tool.	13
F150 P150	Data read from intelli- gent unit	READ PREAD	S1, S2, n, D	Reads the data from the intelligent unit.	9
F151 P151	Data write into intelli- gent unit	WRT PWRT	S1, S2, n, D	Writes the data into the intelligent unit.	9
F152 P152	Data read from MEWNET-F slave station	RMRD PRMRD	S1, S2, n, D	Reads the data from the intelligent unit at the MEWNET-F (remote I/O) slave station.	9
F153 P153	Data write into MEWNET-F slave station	RMWT PRMWT	S1, S2, n, D	Writes the data into the intelligent unit at the MEWNET-F (remote I/O) slave station.	9
F154 P154	Machine language program call	MCAL PMCAL	n	The machine language program is called.	3
F155 P155	Sampling	SMPL PSMPL	-	Starts sampling data.	1
F156 P156	Sampling trigger	STRG PSTRG	-	When the trigger of this instruction turns on, the sampling trace stops.	1
F157 P157	Time addition	CADD PCADD	S1, S2, D	The time after (S2+1, S2) elapses from the time of (S1+2, S1+1, S1) is stored in (D+2, D+1, D).	9
F158 P158	Time substruction	CSUB PCSUB	S1, S2, D	The time that results from subtracting (S2+1, S2) from the time (S1+2, S1+1, S1) is stored in (D+2, D+1, D).	9
F159 P159	Serial data communica- tion	MTRN PMTRN	S, n, D	This is used to send data to or receive data from an external device through the specified CPU COM port or MCU COM port.	7
F161 P161	Serial data reception (for MCU COM port)	MRCV PMRCV	S, D1, D2	Data is received from external equipment via the COM port of the specified MCU.	7

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net
		-		-	-	A	vailabili	ty		-	-	-	-
	_	<u> </u>	Ę	<u> </u>		FP1 (*1)		FP-N	l (*1)	ļ			т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
F149 P149	A	A	A	A	N/A	A	A	N/A	A	A	A	A	A
F150 P150	N/A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
F151 P151	N/A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
F152 P152	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
F153 P153	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
F154 P154	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	N/A	N/A
F155 P155	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
F156 P156	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
F157 P157	A (*3)	A	A	A	N/A	A	A	A	A	A	A	A	A
F158 P158	A (*3)	A	A	A	N/A	A	A	A	A	A	A	A	A
F159 P159	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A (*4)	A (*4)	N/A
F161 P161	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A (*4)	A (*4)	N/A

• A: Available, N/A: Not available

1) For the FP0/FP Σ /FP-X/FP-e/FP1/FP-M, the P type high-level instructions are not available.

2) This instruction is available for FP Σ CPU Ver. 2.0 or later.

3) On the FP0 it is only possible to use F157 and F158 with the T32 type.

4) This instruction is available for FP2/FP2SH CPU Ver. 1.5 or later.

Num- ber	Name	Boolean	Operand	Description	Steps
BIN arit	thmetic instruction	n			
F160 P160	Double word (32-bit) data square root	DSQR PDSQR	S, D	$\sqrt{(S)} \rightarrow (D)$	7
Special	instructions (Hig	h-speed co	unter instruct	ions)	
F0	High-speed counter and Pulse output controls	MV	S, DT9052	Performs high-speed counter and Pulse output controls according to the control code specified by "S". The control code is stored in DT9052.	5
F1	Change and read of the elapsed value	DMV	S, DT9044	Transfers (S+1, S) to high-speed counter and Pulse output elapsed value area (DT9045, DT9044).	7
	of high-speed counter and Pulse output		DT9044, D	Transfers value in high-speed counter and Pulse output elapsed value area (DT9045, DT9044) to (D+1, D).	7
F162	High-speed counter output set	HC0S	S, Yn	The specified external output relay (Yn) turns on when the elapsed value of the high-speed counter agrees with the specified target value (S+1, S).	7
F163	High-speed counter output reset	HCOR	S, Yn	The specified external output relay (Yn) turns off when the elapsed value of the high-speed counter agrees with the specified target value (S+1, S).	7
F164	Speed control (Pulse output and pattern output con- trols) (See below.)	SPD0	S	Controls conditions of outputs according to the elapsed value of the high-speed counter. Two types of output control available: - Pulse output control - Pattern output control	3
F165	Cam control	CAM0	S	Controls cam operation (on/off patterns of each cam output) according to the elapsed value of the high-speed counter.	3

Pulse output specifications for FP-M/FP1

Item	FP1 C14/C16, FP-M C16T	FP1 C24/C40	FP1 C56/C72								
			FP-M C20T/C20R/C32T								
Pulse output terminal	Y7	Y7	Y6 and Y7 (selectable)								
Pulse frequency	1440 Hz to 5 kHz/720 Hz to 5 kHz/360 Hz to 5kHz/180 Hz to 5 kHz/90 Hz to 5 kHz/45										
	Hz to 5 kHz (Switches betwee	en 6 ranges)									
Internal connection	Not possible	Not possible	Possible								
between pulse output											
and counter input											

Switching of the pulse frequency range is supported by CPU Ver. 2.7 or later.

In versions prior to CPU Ver. 2.7, the range is fixed at 360 Hz to 5 kHz.

In Ver. 2.7 or later but prior to CPU Ver. 2.9, switching is possible among 4 ranges (360 Hz to 5 kHz/180 Hz to 5 kHz/90 Hz to 5 kHz/45 Hz to 5 kHz).

In CPU Ver. 2.9 and later versions, switching is possible among 6 ranges.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ity					
	_	Ê	÷	Ê		FP1 (*1))	FP-N	/I (*1)			_	т
Name	FP0 (*'	FPΣ (*·	FP-X(*	FP-e(*	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
BIN arithmetic	instruc	tion											
F160 P160	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	A
Special instrue	ctions (High-sp	eed co	unter in	structi	ons)							
FO	A	N/A	N/A	A	A	A	A	A	A	N/A	N/A	N/A	N/A
F1	A (*1)	N/A	N/A	A	A	A	A	A	A	N/A	N/A	N/A	N/A
F162	N/A	N/A	N/A	N/A	A	A	A	A	A	N/A	N/A	N/A	N/A
F163	N/A	N/A	N/A	N/A	A	A	A	A	A	N/A	N/A	N/A	N/A
F164	N/A	N/A	N/A	N/A	A	A	A	A	A	N/A	N/A	N/A	N/A
F165	N/A	N/A	N/A	N/A	A	A	A	N/A	A	N/A	N/A	N/A	N/A



1) The elapsed value area varies depending on the channel being used.

Num- ber	Name	Boolean	Operand	Description	Steps
High sp	beed counter/Pul	se output ir	nstruction for F	FP0, FP-e	
F166	High-speed counter	HC1S	n, S, Yn	Turns output Yn on when the elapsed value of the built-in high-speed counter reaches the target value	11
	output set (with channel specification)			of (S+1, S).	
F167	High-speed counter output reset (with channel specification)	HC1R	n, S, Yn	Turns output Yn off when the elapsed value of the built-in high-speed counter reaches the target value of (S+1, S).	11
F168	Positioning control (with channel specification)	SPD1	S, n	Outputs a positioning pulse from the specified output (Y0 or Y1) according to the contents of the data table beginning at "S".	5
F169	Pulse output (with channel specification)	PLS	S, n	Outputs a pulse from the specified output (Y0 or Y1) according to the contents of the data table beginning at "S".	5
F170	PWM output (with channel specification)	PWM	S, n	Performs PWM output from the specified outptu (Y0 or Y1) according to the contents of the data table beginning at "S".	5

						A	/ailabili	ty					
	((1	1)	(1		FP1 (*1)		FP-N	/ (*1)			_	н
Name	FP0 (*1	FPΣ (*'	FP-X(*	FP-e(*'	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
High speed co	unter/P	ulse ou	tput ins	structio	n for FF	Р0, FP-е							
F166	A	N/A	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F167	A	N/A	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F168	A	N/A	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F169	A	N/A	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F170	A	N/A	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A



The elapsed value area varies depending on the channel being used.

Num- ber	Name	Boolean	Operand	Description	Steps
High sp	beed counter/Puls	se output ir	struction for I	FPΣ/FP-X	
FO	High-speed counter and Pulse output controls	MV	S, DT90052	Performs high-speed counter and Pulse output controls according to the control code specified by "S". The control code is stored in DT90052.	5
F1	Change and read of the elapsed value of high-speed	DMV	FPΣ: S, DT90044 FP-X: S, DT90300	Transfers (S+1, S) to high-speed counter and Pulse output elapsed value area (DT90045, DT90044).	7
	counter and Pulse output		FPΣ: DT90044, D FP-X: DT90300, D	Transfers value in high-speed counter and Pulse output elapsed value area (DT90045, DT90044) to (D+1, D).	7
F166	Target value much on (with channel specification)	HC1S	n, S, D	Turns output Yn on when the elapsed value of the built-in high-speed counter reaches the target value of (S+1, S).	11
F167	Target value much off (with channel specification)	HC1R	n, S, D	Turns output Yn off when the elapsed value of the built-in high-speed counter reaches the target value of (S+1, S).	11
F171	Pulse output (with channel specification) (Trapezoidal control and home return)	SPDH	S, n	Positioning pulses are output from the specified channel, in accordance with the contents of the data table that starts with S.	5
F172	Pulse output (with channel specification) (JOG operation)	PLSH	S, n	Pulse strings are output from the specified output, in accordance with the contents of the data table that starts with S.	5
F173	PWM output (with channel specification)	PWMH	S, n	PWM output is output from the specified output, in accordance with the contents of the data table that starts with S.	5
F174	Pulse output (with channel specification) (Selectable data table control operation)	SPOH	S, n	Outputs the pulses from the specified channel according to the data table specified by S.	5
F175	Pulse output (Linear interpolation)	SPSH	S, n	Pulses are output from channel, in accordance with the designated data table, so that the path to the target position forms a straight line.	5
F176	Pulse output (Circular interpolation)	SPCH	S, n	Pulses are output from channel, in accordance with the designated data table, so that the path to the target position forms an arc.	5

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabil	ity					
	÷	(÷	÷		FP1 (*1)		FP-N	l (*1)			_	I
Name	FP0 (*'	FPΣ (*·	FP-X(*	FP-e(*	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10S
High speed co	unter/P	ulse ou	tput ins	structio	n for Fl	PΣ/FP-X		L	L	I	L	L	L
F0	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F1	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F166	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F167	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F171	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F172	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F173	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F174	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F175	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F176	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

Note1) The elapsed value area differs depending on used channels.

Num- ber	Name	Boolean	Operand	Description	Steps
Screen	display instruct	ions			
F180	FP-e screen	SCR	S1, S2, S3,	Register the screen displayed on the FP-e.	9
	display		S4		
	registration				
F181	FP-e screen	DSP	S	Specify the screen to be displayed on the FP-e.	3
	display				
	switching				
Basic f	unction instructi	on			<u> </u>
F183	Auxiliary	DSTM	S, D	Turn on the specified output and R900D after	7
Data ta	timer (32-bit)			0.01 s. × set value.	
Data tra	Three 40 hit	ns May (a	04,00,00	(04) (D) (00) (D (4) (00) (D (0))	40
F190	Inree 16-bit		51, 52, 53,	$(S1) \rightarrow (D), (S2) \rightarrow (D+1), (S3) \rightarrow (D+2)$	10
P190	data move	PIVIV3			16
F191	data movo		51, 52, 53,	$(S_{1+1}, S_{1}) \rightarrow (D_{+1}, D), (S_{2+1}, S_{2}) \rightarrow (D_{+3}, D_{+2}),$	10
	neration instruc	tions	D	(33+1, 33)→(D+3, D+4)	
E0910 0	32-bit data		S1 S2 D	$(S1+1, S1)$ AND $(S2+1, S2) \rightarrow (D+1, D)$	12
P215	AND	PDAND	01, 02, 0		12
F216	32-bit data	DOR	S1, S2, D	(S1+1, S1) OR (S2+1, S2)→(D+1, D)	12
P216	OR	PDOR	- , - ,		
F217	32-bit data	DXOR	S1, S2, D	{(S1+1, S1) AND (S2+1, S2)} OR {(S1+1, S1) AND	12
P217	XOR	PDXOR		(S2+1, S2)}→(D+1, D)	
F218	32-bit data	DXNR	S1, S2, D	{(S1+1, S1) AND (S2+1, S2)} OR {(S1+1, S1) AND	12
P218	XNR	PDXNR		(S2+1, S2) }→(D+1, D)	
F219	Double word	DUNI	S1, S2, S3,	{(S1+1, S1) AND (S3+1, S3)} OR {(S2+1, S2) AND	16
P219	(32-bit) data	PDUNI	D	(S3+1, S3) }→(D+1, D)	
	unites				
Data co	onversion instruc	ctions			•
F230	Time data \rightarrow	TMSEC	S, D	The specified time data (a date and time) is	6
P230	second	PTMSEC		changed into the number of seconds.	
	conversion				
F231	Second →	SECTM	S, D	The specified number of seconds is changed into	6
P231	time data	PSECTM		time data (a date and time).	
1	conversion				

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ity					
	^	(()	(FP1 (*1))	FP-N	/ (*1)				т
Name	FP0 (*1	FPΣ (*1	FP-X(*'	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
Screen display	y instru	ctions			1				1	1			
F180	N/A	N/A	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F181	N/A	N/A	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Basic function	instruc	ction											
F183	A	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Data transfer i	nstruct	ions			1				1	1			
F190	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P190													
F191	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P191													
Logic operatio	on instru	uctions											
F215 P215	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F216	N/A	Α	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Α	А	А
P216													
F217	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P217													
F218 P218	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F219 P219	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Data conversio	on instr	uctions											
F230	N/A	A	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	N/A
P230		(*3)									(*2)	(*2)	
F231	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	N/A
P231		(*3)									(*2)	(*2)	

• A: Available, N/A: Not available

1) For the FP0, FP Σ , FP-X and FP-e, the P type high-level instructions are not available.

- 2) The instruction is available for FP2/FP2SH CPU Ver. 1.5 or later.
- 3) The instruction is available for FP Σ 32k.

Num- ber	Name	Boolean	Operand	Description	Steps
F235 P235	16-bit binary data → Gray code conversion	GRY PGRY	S, D	Converts the 16-bit binary data of "S" to gray codes, and the converted result is stored in the "D".	6
F236 P236	32-bit binary data → Gray code conversion	DGRY PDGRY	S, D	Converts the 32-bit binary data of (S+1, S) to gray code, and the converted result is stored in the (D+1, D).	8
F237 P237	16-bit gray code → binary data conversion	GBIN PGBIN	S, D	Converts the gray codes of "S" to binary data, and the converted result is stored in the "D".	6
F238 P238	32-bit gray code → binary data conversion	DGBIN PDGBIN	S, D	Converts the gray codes of (S+1, S) to binary data, and the converted result is stored in the (D+1, D).	8
F240 P240	Bit line to bit column conversion	COLM PCOLM	S, n, D	The values of bits 0 to 15 of "S" are stored in bit "n" of (D to DC+15).	8
F241 P241	Bit column to bit line conversion	LINE PLINE	S, n, D	The values of bit "n" of (S) to (S+15) are stored in bits 0 to 15 of "D".	8
F250	Binary data → ASCII conversion	ΒΤΟΑ	S1, S2, n, D	The "ij" set of 16-bit or 32-bit data is converted from (S) to "m" characters of ASCII data, and stored from the first character of D.	12
F251	ASCII → binary data conversion	ATOB	S1, S2, n, D	The "ij" set of ASCII data in "m" characters unit is converted from the first character of (S), and stored in D.	12
Charac	ter strings instru	ictions			
F257 P257	Comparing character strings	SCMP	S1, S2	These instructions compare two specified character strings and output the judgment results to a special internal relay.	10
F258 P258	Character string coupling	SADD	S1, S2, D	These instructions couple one character string with another.	12
F259 P259	Number of characters in a character string	LEN	S, D	These instructions determine the number of characters in a character string.	6
F260 P260	Search for character string	SSRC	S1, S2, D	The specified character is searched in a character string.	10
F261 P261	Retrieving data from character strings (right side)	RIGHT	S1, S2, D	These instructions retrieve a specified number of characters from the right side of the character string.	8

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

		-		-	-	A	vailabili	ty		-	-	-	-
	_	Ê	1)	Ê		FP1 (*1)		FP-N	1 (*1)			_	т
Name	,*) 0	ې ۲	*)X-'	-e(*	C14	C24	C56	C16	C20	ę	Ŋ	2SH	10S
	Ë	£	8	£	C16	C40	C72	010	C32	£	4	4	4
F235	N/A	Α	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P235													
F236 P236	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F237 P237	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F238 P238	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F240 P240	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F241 P241	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F250	N/A	A (*2)	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
F251	N/A	A (*2)	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Character strin	ngs inst	ruction	s										
F257 P257	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F258 P258	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F259 P259	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F260 P260	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F261 P261	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A



- A: Available, N/A: Not available
- 1) For the FP $\!\Sigma$, FP-X, the P type high-level instructions are not available.
- 2) The instruction is available for FP Σ 32k.

Num- ber	Name	Boolean	Operand	Description	Steps
F262 P262	Retrieving data from character strings (left side)	LEFT	S1, S2, D	These instructions retrieve a specified number of characters from the left side of the character string.	8
F263 P263	Retrieving a character string from a character string	MIDR	S1, S2, S3, D	These instructions retrieve a character string consisting of a specified number of characters from the specified position in the character string.	10
F264 P264	Writing a character string to a character string	MIDW	S1, S2, D, n	These instructions write a specified number of characters from a character string to a specified position in the character string.	12
F265 P265	Replacing character strings	SREP	S, D, p, n	A specified number of characters in a character string are rewritten, starting from a specified position in the character string.	12
Integer	type data proces	ssing instru	ctions		
F270 P270	Maximum value (word data (16-bit))	MAX PMAX	S1, S2, D	Searches the maximum value in the word data table between the "S1" and "S2", and stores it in the "D". The address relative to "S1" is stored in "D+1".	8
F271 P271	Maximum value (double word data (32-bit))	DMAX PDMAX	S1, S2, D	Searches for the maximum value in the double word data table between the area selected with "S1" and "S2", and stores it in the "D". The address relative to "S1" is stored in "D+2".	8
F272 P272	Minimum value (word data (16-bit))	MIN PMIN	S1, S2, D	Searches for the minimum value in the word data table between the area selected with "S1" and "S2", and stores it in the "D". The address relative to "S1" is stored in "D+1".	8
F273 P273	Minimum value (double word data (32-bit))	dmin Pdmin	S1, S2, D	Searches for the minimum value in the double word data table between the area selected with "S1" and "S2", and stores it in the "D". The address relative to "S1" is stored in "D+2".	8
F275 P275	Total and mean values (word data (16-bit))	MEAN PMEAN	S1, S2, D	The total value and the mean value of the word data with sign from the area selected with "S1" to "S2" are obtained and stored in the "D".	8
F276 P276	Total and mean values (double word data (32-bit))	DMEAN PDMEAN	S1, S2, D	The total value and the mean value of the double word data with sign from the area selected with "S1" to "S2" are obtained and stored in the "D".	8

						A	vailabili	ity					
	(((1	(FP1 (*1)		FP-N	1 (*1)				н
Name	0 (*1	Σ (*1	×,	-e(*1	C14	C24	C56	040	C20		7	2SH	10S
	Ę	Ę	Ę	£	C16	C40	C72	C16	C32	£	Ę	£	ЕP
F262 P262	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F263 P263	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F264 P264	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F265 P265	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Integer type da	ata proc	essing	instruc	tions									
F270 P270	N/A	A	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F271 P271	N/A	A	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F272 P272	N/A	A	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F273 P273	N/A	A	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F275 P275	N/A	A	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F276 P276	N/A	A	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A

• A: Available, N/A: Not available

1) For the $FP\Sigma/FP-X$, the P type high-level instructions are not available.

2) Available from Ver. 1.2 or higher.

Num- ber	Name	Boolean	Operand	Description	Steps
F277 P277	Sort (word data (16-bit))	SORT PSORT	S1, S2, S3	The word data with sign from the area specified by "S1" to "S2" are sorted in ascending order (the smallest word is first) or descending order (the largest word is first).	8
F278 P278	Sort (double word data (32-bit))	DSORT PDSORT	S1, S2, S3	The double word data with sign from the area specified b "S1" ato "S2" are sorted in ascending order (the smallest word is first) or descending order (the largest word is first).	8
F282 P282	Scaling of 16-bit data	SCAL PSCAL	S1, S2, D	The toutptu value Y is found for the input value X by performing scaling for the given data table.	8
F283 P283	Scaling of 32-bit data	DSCAL PDSCAL	S1, S2, D	The toutptu value Y is found for the input value X by performing scaling for the given data table.	10
Integer	type non-linear	function ins	tructions		
F285 P285	Upper and lower limit control (16-bit data)	LIMT PLIMT	S1, S2, S3, D	When S1>S3, S1 \rightarrow D When S1 <s3, s2<math="">\rightarrowD When S1<or =="" s3<math="" s3<or="S2,">\rightarrowD</or></s3,>	10
F286 P286	Upper and lower limit control (32-bit data)	DLIMT PDLIMT	S1, S2, S3, D	When $(S1+1, S1)>(S3+1, S3)$, $(S1+1, S1)$ \rightarrow (D+1, D) When $(S2+1, S2)<(S3+1, S3)$, $(S2+1, S2)$ \rightarrow (D+1, D) When $(S1+1, S1)<$ or = $(S3+1, S3)<$ or = $(S2+1, S2)$, $(S3+1, S3)\rightarrow$ (D+1, D)	16
F287 P287	Deadband control (16-bit data)	BAND PBAND	S1, S2, S3, D	When S1>S3, S3–S1 \rightarrow D When S2 <s3, s3–s2<math="">\rightarrowD When S1<or 0<math="" =="" s3<or="S2,">\rightarrowD</or></s3,>	10
F288 P288	Deadband control (32-bit data)	DBAND PDBAND	S1, S2, S3, D	When $(S1+1, S1)>(S3+1, S3), (S3+1, S3)-(S1+1, S1)\rightarrow(D+1, D)$ When $(S2+1, S2)<(S3+1, S3), (S3+1, S3)-(S2+1, S2)\rightarrow(D+1, D)$ When $(S1+1, S1)$	16
F289 P289	Zone control (16-bit data)	ZONE PZONE	S1, S2, S3, D	When S3<0, S3+S1→D When S3=0, 0→D When S3>0, S3+S2→D	10
F290 P290	Zone control (32-bit data)	DZONE PDZONE	S1, S2, S3, D	When $(S3+1, S3)<0$, $(S3+1, S3)+(S1+1, S1)$ → $(D+1, D)$ When $(S3+1, S3)=0$, 0 → $(D+1, D)$ When $(S3+1, S3)>0$, $(S3+1, S3)+(S2+1, S2)$ → $(D+1, D)$	16

						A	vailabili	ity					
	((1)	(1		FP1 (*1)		FP-N	/ (*1)				н
Name	0 (*1	Σ (*	×, ×-	-e(*1	C14	C24	C56	040	C20		5	2SH	10S
	Ę	£	£	Ę	C16	C40	C72	C16	C32	Б	FР	£	ЕP
F277	N/A	Α	Α	А	N/A	N/A	N/A	N/A	N/A	N/A	А	Α	А
P277				(*2)									
F278	N/A	A	A	A (*0)	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F2/0				(*2)									
F202	N1/A	•		•	N1/A	N1/A	N1/A	N1/A	N1/A	N1/A	•	^	•
P282	N/A	А	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
F283	N/A	А	А	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P283													
Integer type no				ruction:	S N/A	NI/A	NI/A	NI/A	NI/A	NI/A	۸	۸	۸
P285	11/1	^	^	(*2)	11/1	IN/A	IN/A	11/7	11/7	IN/A	~	~	~
F286	ΝΙ/Δ	Δ	Δ	Δ	Ν/Δ	NI/A	N/A	ΝΙ/Δ	ΝΙ/Δ	NI/A	Δ	Δ	Δ
P286	11/1	^	^	(*2)	11/1	IN/A	IN/A	11/7	11/7	IN/A	~	~	~
F287	N/A	А	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P287				(*2)									
F288	N/A	А	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P288				(*2)									
F 000	N1/A	•	•	•	N1/A	N1/A	N1/A	N1/A	N1/A	N1/A	•	•	•
F289 P289	N/A	A	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
				(-)									
F290	N/A	A	A	A (*2)	N/A	N/A	N/A	N/A	N/A	N/A	А	A	А
F290				("2)									

Ň.

Note:

- A: Available, N/A: Not available
- 1) For the FP Σ /FP-X, the P type high-level instructions are not available.
- 2) Available from Ver. 1.2 or higher.

Num- ber	Name	Boolean	Operand	Description	Steps
BCD ty	pe real number o	operation ins	structions		
F300	BCD type	BSIN	S, D	SIN(S1+1, S1)→(D+1, D)	6
P300	sine operation	PBSIN			
F301	BCD type	BCOS	S, D	COS(S1+1, S1)→(D+1, D)	6
P301	cosine	PBCOS			
	operation				
F302	BCD type	BTAN	S, D	TAN(S1+1, S1)→(D+1, D)	6
P302	tangent operation	PBTAN			
F303	BCD type	BASIN	S, D	SIN ⁻¹ (S1+1, S1)→(D+1, D)	6
P303	arcsine	PBASIN			
	operation				
F304	BCD type	BACOS	S, D	COS ⁻¹ (S1+1, S1)→(D+1, D)	6
P304	arccosine operation	PBACOS			
F305	BCD type	BATAN	S, D	TAN ⁻¹ (S1+1, S1)→(D+1, D)	6
P305	arctangent	PBATAN			
	operation				

						A	vailabili	ity					
	-	(1)	(FP1 (*1)		FP-N	/ (*1)				н
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
BCD type real	numbe	r operat	tion ins	tructior	าร								
F300	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	Α	А
P300													
F301	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P301													
F302 P302	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F303 P303	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F304 P304	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F305 P305	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A



Num- ber	Name	Boolean	Operand	Description	Steps
Floatin	g-point type real	number ope	eration instruc	tions	
F309 P309	Floating- point type data move	FMV PFMV	S, D	(S+1, S)→(D+1, D)	8
F310 P310	Floating- point type data addition	F+ PF+	S1, S2, D	(S1+1, S1)+(S2+1, S2)→(D+1, D)	14
F311 P311	Floating- point type data subtraction	F- PF-	S1, S2, D	(S1+1, S1)–(S2+1, S2)→(D+1, D)	14
F312 P312	Floating- point type data multiplication	F* PF*	S1, S2, D	(S1+1, S1)×(S2+1, S2)→(D+1, D)	14
F313 P313	Floating- point type data division	F% PF%	S1, S2, D	(S1+1, S1)÷(S2+1, S2)→(D+1, D)	14
F314 P314	Floating- point type data sine operation	SIN PSIN	S, D	SIN(S+1, S)→(D+1, D)	10
F315 P315	Floating- point type data cosine operation	COS PCOS	S, D	COS(S+1, S)→(D+1, D)	10
F316 P316	Floating- point type data tangent operation	TAN PTAN	S, D	TAN(S+1, S)→(D+1, D)	10
F317 P317	Floating- point type data arcsine operation	ASIN PASIN	S, D	SIN ⁻¹ (S+1, S)→(D+1, D)	10
F318 P318	Floating- point type data arccosine operation	ACOS PACOS	S, D	COS ⁻¹ (S+1, S)→(D+1, D)	10

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

						A	vailabili	ity					
	_	<u> </u>	,	<u> </u>		FP1 (*1))	FP-N	/ (*1)	ļ		_	т
Name	0 (*1	× ۵	×, ×-	-e	C14	C24	C56	040	C20		N	2SH	10S
	Ę	Ę	£	Ę	C16	C40	C72	C16	C32	Ę	£	Ę	£
Floating-point	type re	al numl	ber ope	ration i	nstruct	ions							
F309	А	А	А	Α	N/A	N/A	N/A	N/A	N/A	N/A	Α	Α	А
P309	(*2)												
F310	А	Α	Α	Α	N/A	N/A	N/A	N/A	N/A	N/A	Α	Α	Α
P310	(*2)												
F311	Α	Α	А	Α	N/A	N/A	N/A	N/A	N/A	N/A	Α	Α	А
P311	(*2)												
F312	A (to)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
P312	(^2)												
F313	Α	Α	А	А	N/A	N/A	N/A	N/A	N/A	N/A	Α	Α	А
P313	(*2)								-				
F314	Α	Α	А	Α	N/A	N/A	N/A	N/A	N/A	N/A	Α	Α	Α
P314	(*2)												
F315	Α	Α	Α	Α	N/A	N/A	N/A	N/A	N/A	N/A	Α	Α	Α
P315	(*2)												
F316	A	Α	A	Α	N/A	N/A	N/A	N/A	N/A	N/A	Α	Α	Α
P316	(^2)												
F317	Α	А	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	Α	А
P317	(*2)												
F318	Α	А	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	А	А
P318	(*2)												

• A: Available, N/A: Not available

1) For the FP0, FP Σ , FP-X and FP-e, the P type high-level instructions are not available.

2) The instruction is available for FP0 T32C and FP0 C10/C14/C16/C32 CPU Ver. 2.0 or later.

Num- ber	Name	Boolean	Operand	Description	Steps
F319 P319	Floating- point type data arctangent operation	ATAN PATAN	S, D	TAN ⁻¹ (S+1, S)→(D+1, D)	10
F320 P320	Floating- point type data natural logarithm	LN PLN	S, D	LN(S+1, S)→(D+1, D)	10
F321 P321	Floating- point type data exponent	EXP PEXP	S, D	EXP(S+1, S)→(D+1, D)	10
F322 P322	Floating- point type data logarithm	LOG PLOG	S, D	LOG(S+1, S)→(D+1, D)	10
F323 P323	Floating- point type data power	PWR PPWR	S1, S2, D	(S1+1, S1) ^ (S2+1, S2)→(D+1, D)	14
F324 P324	Floating- point type data square root	FSQR PFSQR	S, D	√(S+1, S)→(D+1, D)	10
F325 P325	16-bit integer data to floating-point type data conversion	FLT PFLT	S, D	Converts the 16-bit integer data with sign specified by "S" to real number data, and the converted data is stored in "D".	6
F326 P326	32-bit integer data to floating-point type data conversion	DFLT PDFLT	S, D	Converts the 32-bit integer data with sign specified by (S+1, S) to real number data, and the converted data is stored in (D+1, D).	8

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

				-	-	A	vailabili	ty			-	-	-
	<u> </u>	<u> </u>	Ê	<u> </u>		FP1 (*1)		FP-N	A (*1)				т
Name	FP0 (*1	FPΣ (*1	FP-X(*1	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
F319 P319	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F320 P320	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F321 P321	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F322 P322	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F323 P323	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F324 P324	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F325 P325	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F326 P326	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A



1) For the FP0, FP Σ , FP-X and FP-e, the P type high-level instructions are not available.

2) The instruction is available for FP0 T32C and FP0 C10/C14/C16/C32 CPU Ver. 2.0 or later.

Num- ber	Name	Boolean	Operand	Description	Steps
F327 P327	Floating- point type data to 16-bit integer con- version (the largest inte- ger not ex- ceeding the floating-point type data)	INT PINT	S, D	Converts real number data specified by (S+1, S) to the 16-bit integer data with sign (the largest integer not exceeding the floating-point data), and the converted data is stored in "D".	8
F328 P328	Floating- point type data to 32-bit integer con- version (the largest inte- ger not ex- ceeding the floating-point type data)	DINT PDINT	S, D	Converts real number data specified by (S+1, S) to the 32-bit integer data with sign (the largest integer not exceeding the floating-point data), and the converted data is stored in (D+1, D).	8
F329 P329	Floating- point type data to 16-bit integer con- version (rounding the first decimal point down to integer)	FIX PFIX	S, D	Converts real number data specified by (S+1, S) to the 16-bit integer data with sign (rounding the first decimal point down), and the converted data is stored in "D".	8
F330 P330	Floating- point type data to 32-bit integer con- version (rounding the first decimal point down to integer)	DFIX PDFIX	S, D	Converts real number data specified by (S+1, S) to the 32-bit integer data with sign (rounding the first decimal point down), and the converted data is stored in (D+1, D).	8

11-104

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

		-	-	-	-	A	vailabili	ity			-	-	-
	<u> </u>	_	,	÷		FP1 (*1))	FP-N	/ (*1)			_	т
Name	0 (*1	ي ۲	*)×-	-e(*	C14	C24	C56	C16	C20	ę	N	2SH	10S
	£	Ð	£	£	C16	C40	C72	C16	C32	£	£	£	Ð
F327 P327	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F328 P328	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F329 P329	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F330 P330	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A

• A: Available, N/A: Not available

1) For the FP0, FP Σ , FP-X and FP-e, the P type high-level instructions are not available.

2) The instruction is available for FP0 T32C and FP0 C10/C14/C16/C32 CPU Ver. 2.0 or later.

Num- ber	Name	Boolean	Operand	Description	Steps
F331 P331	Floating- point type data to 16-bit integer con- version (rounding the first decimal point off to integer)	ROFF PROFF	S, D	Converts real number data specified by (S+1, S) to the 16-bit integer data with sign (rounding the first decimal point off), and the converted data is stored in "D".	8
F332 P332	Floating- point type data to 32-bit integer con- version (rounding the first decimal point off to integer)	DROFF PDROFF	S, D	Converts real number data specified by (S+1, S) to the 32-bit integer data with sign (rounding the first decimal point off), and the converted data is stored in (D+1, D).	8
F333 P333	Floating- point type data round- ding the first decimal point down	FINT PFINT	S, D	The decimal part of the real number data specified in (S+1, S) is rounded down, and the result is stored in (D+1, D).	8
F334 P334	Floating- point type data round- ding the first decimal point off	FRINT PFRINT	S, D	The decimal part of the real number data stored in (S+1, S) is rounded off, and the result is stored in (D+1, D).	8
F335 P335	Floating- point type data sign changes	F+/- PF+/-	S, D	The real number data stored in (S+1, S) is changed the sign, and the result is stored in (D+1, D).	8
F336 P336	Floating- point type data absolute	FABS PFABS	S, D	Takes the absolute value of real number data specified by (S+1, S), and the result (absolute value) is stored in (D+1, D).	8
F337 P337	Floating- point type data degree → radian	RAD PRAD	S, D	The data in degrees of an angle specified in (S+1, S) is converted to radians (real number data), and the result is stored in (D+1, D).	8

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

	Availability												
	-	(,	÷		FP1 (*1)		FP-N	/ (*1)			_	т
Name	.*) 0	Σ (*	*)X-	-e(*	C14	C24	C56	C16	C20	ę	Ŋ	2SH	10S
	Б	Ę	Ę	Ę	C16	C40	C72	010	C32	£	Ę	£	Ę
F331	А	А	А	А	N/A	N/A	N/A	N/A	N/A	N/A	А	Α	А
P331	(*2)												
F332 P332	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F333 P333	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F334 P334	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F335 P335	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F336 P336	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F337 P337	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A

• A: Available, N/A: Not available

1) For the FP0, FP Σ , FP-X and FP-e, the P type high-level instructions are not available.

2) The instruction is available for FP0 T32C and FP0 C10/C14/C16/C32 CPU Ver. 2.0 or later.

Num- ber	Name	Boolean	Operand	Description	Steps					
F338	Floating-	DEG	S, D	The angle data in radians (real number data)	8					
P338	point type	PDEG		specified in (S+1, S) is converted to angle data in						
	\rightarrow degree			degrees, and the result is stored in (D+1, D).						
Floatin	q-point type real	number dat	a processing i	instructions	L					
F345	Floating-	FCMP	S1, S2	(S1+1, S1)>(S2+1, S2)→ R900A: on	10					
P345	point type	PFCMP		(S1+1, S1)=(S2+1, S2)→ R900B on						
	data compare			(S1+1, S1)<(S2+1, S2)→ R900C: on						
F346	Floating-	FWIN	S1, S2, S3	$(S1+1, S1)>(S3+1, S3)\rightarrow R900A$: on	14					
P346	point type	PFWIN		(S2+1, S2) <or =(s1+1,="" s1)<or="(S3+1," s3)<="" th=""><th></th></or>						
	data band			\rightarrow R900B on						
	compare			$(S1+1, S1) < (S2+1, S2) \rightarrow R900C: on$ When $(S1+1, S1) > (S3+1, S3)$ $(S1+1, S1)$						
F347	Floating-	FLIMT	S1, S2, S3,	When (S1+1, S1)>(S3+1, S3), (S1+1, S1)	17					
P347	point type	PFLIMT	D	\rightarrow (D+1, D)						
	and lower			When (S2+1, S2)<(S3+1, S3), (S2+1, S2)						
	limit control			\rightarrow (D+1, D) When (S1+1, S1) cor = (S2+1, S2) cor = (S2+1, S2)						
				(31+1, 31) < 0 = (33+1, 33) < 0 = (32+1, 32),						
F348	Floating-	FBAND	S1, S2, S3,	When $(S1+1, S1) > (S3+1, S3)$	17					
P348	point type	PFBAND	D	(S3+1, S3)–(S1+1, S1)→(D+1, D)						
	data dead-			When (S2+1, S2)<(S3+1, S3),						
	band control			(S3+1, S3)–(S2+1, S2)→ (D+1, D)						
				When (S1+1, S1) <or (s3+1,="" =="" s2),<="" s3)<or="(S2+1," th=""><th></th></or>						
				0.0→(D+1, D)						
F349	Floating-	FZONE	S1, S2, S3,	When (S3+1, S3)<0.0,	17					
P349	point type	PFZONE	D	(S3+1, S3)+(S1+1, S1)→(D+1, D)						
	data zone			When $(S3+1, S3)=0.0, 0.0 \rightarrow (D+1, D)$						
	control			When (S3+1, S3)>0.0, (S3+1, S3)+(S2+1, S2)						
E250	Floating	EMAY	Q1 Q2 D	\rightarrow (D+1, D) Secrete the maximum value in the real number	0					
P350	noint type		31, 32, D	data table between the area selected with "S1" and	0					
1 330	data maxi-			"S2" and stores it in the (D+1 D) The address						
	mum value			relative to "S1" is stored in $(D+2)$.						

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

		Availability											
	_	<u> </u>	÷	<u> </u>		FP1 (*1)		FP-N	/ (*1)				т
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SI
F338 P338	A (*2)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
Floating-point	type re	al numl	ber data	a proces	ssing ir	structio	ons						
F345 P345	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F346 P346	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F347 P347	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F348 P348	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F349 P349	N/A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F350 P350	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A

• A: Available, N/A: Not available

1) For the FP0, FP2, FP-X and FP-e, the P type high-level instructions are not available.

2) The instruction is available for FP0 T32C and FP0 C10/C14/C16/C32 CPU Ver. 2.0 or later.

Num- ber	Name	Boolean	Operand	Description	Steps
F351 P351	Floating- point type data mini- mum value	FMIN PFMIN	S1, S2, D	Searches the minimum value in the real number data table between the area selected with "S1" and "S2", and stores it in the (D+1, D). The address relative to "S1" is stored in (D+2).	8
F352 P352	Floating- point type data total and mean values	FMEAN PFMEAN	S1, S2, D	The total value and the mean value of the real number data from the area selected with "S1" to "S2" are obtained. The total value is stored in the (D+1, D) and the mean value is stored in the (D+3, D+2).	8
F353 P353	Floating- point type data sort	FSORT PFSORT	S1, S2, S3	The real number data from the area speciified by "S1" to "S2" are stored in ascending order (the smallest word is first) or descending order (the largest word is first).	8
F354 P354	Scaling of real number data	FSCAL PFSCAL	S1, S2, D	Scaling (linearization) on a real number data table is performed, and the output (Y) to an input value (X) is calculated.	12
Time se	eries processing	instruction		·	
F355	PID processing	PID	S	PID processing is performed depending on the control value (mode and parameter) specified by (S to S+2) and (S+4 to S+10), and the result is stored in the (S+3).	4
F356	Eaay PID	EZPID	S1, S2, S3, S4	Temperature control (PID) can be easily performed using the image of a temperautre controller.	10
Compa	re instructions				•
F373 P373	16-bit data revision detection	DTR PDTR	S, D	If the data in the 16-bit area specified by "S" has changed since the previous execution, internal relay R9009 (carry flag) will turn on. "D" is used to store the data of the previous execution.	6
F374 P374	32-bit data revision detection	DDTR PDDTR	S, D	If the data in the 32-bit area specified by (S+1, S) has changed since the previous execution, internal relay R9009 (carry flag) will turn on. (D+1, D) is used to store the data of the previous execution.	6

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

	Availability												
	<u> </u>		—			FP1 (*1))	FP-N	// (*1)				–
Name	FP0 (*1	FPΣ (*1	FP-X(*1	FP-e(*1	C14 C16	C24 C40	C56 C72	C16	C20 C32	FP3	FP2	FP2SH	FP10SH
F351 P351	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F352 P352	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F353 P353	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F354 P354	N/A	A (*5)	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A (*3)	A (*3)	N/A
Time series pr	ocessir	ng instr	uction										
F355	A (*1)	A	A	A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F356	N/A	A (*4)	A (*4)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Compare instr	uctions	;											
F373 P373	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
F374 P374	N/A	A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A



1) For the FP0, FP Σ , FP-X and FP-e, the P type high-level instructions are not available.

2) For the FP0, the instruction is available for the T32C and C10, C14, C16, C32 CPU Ver. 2.0 or later.

- 3) The instruction is available for FP2/FP2SH CPU Ver. 1.5 or later.
- 4) The instruction is available for FP-X V1.20 or later and FP Σ 32k.
- 5) The instruction is available for FP Σ 32k.

Num- ber	Name	Boolean	Operand	Description						
Index r	egister bank pro	cessing inst	ructions							
F410 P410	Setting the index regis- ter bank number	SETB PSETB	n	Index register (I0 to ID) bank number change over.	4					
F411 P411	Changing the index regis- ter bank number	CHGB PCHGB	n	Index register (I0 to ID) bank number change over with remembering preceding bank number.	4					
F412 P412	Restoring the index regis- ter bank number	POPB PPOPB	-	Changes index register (I0 to ID) bank number back to the bank before F411 (CHGB)/P411 (PCHGB) instruction.	2					
File reg	jister bank proce	essing instru	ictions							
F414 P414	Setting the file register bank number	SBFL PSBFL	n	File register bank number change over.	4					
F415 P415	Changing the file register bank number	CBFL PCBFL	n	File register bank number change over with remembering preceding bank number.	4					
F416 P416	Restoring the file register bank number	PBFL PPBFL	-	Changes file register bank number back to the bank before F415 (CBFL)/P415 (PCBFL) instruction.	2					

						A	/ailabili	ity					
	((1)	(1		FP1 (*1)		FP-N	/ (*1)			_	Н
Name	FP0 (*1	FPΣ (*1	FP-X(*	FP-e(* [.]	C14 C16	C24 C40	C56 C72	C16	C20 C32	EP3	FP2	FP2SH	FP10S
Index register	bank p	rocessi	ng instr	uctions	5								
F410 P410	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A
F411 P411	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A
F412 P412	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A
File register ba	ank pro	cessing	instru	ctions									
F414 P414	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	N/A
F415 P415	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	N/A
F416 P416	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	N/A



11.4 Table of Error codes

Difference in ERROR display

There are differences in the way errors are displayed depending on the model.

Model	Display	Display method				
FP1,FP-M,FP2,FP3,FP10SH	LED	ERROR.	Continually lit			
$FP\Sigma$, FP0, FP-X	LED	ERROR/ALARM	Flashes/contunually lit			
FP-e	Screen display	ERR.	Continually lit			

Error Confirmation When ERROR Turns ON

When the "ERROR" on the control unit (CPU unit) turns on or flashes, a self-diagnostic error or syntax check error has occurred. Confirm the contents of the error and take the appopriate steps.

-Error Confirmation Method

Procedure:1.Use the programming tool software to call up the error code.

- By executing the "STATUS DISPLAY", the error code and content of error are displayed.
- 2.Check the error contents in the table of error codes using the error code ascertained above.

-Syntax check error

This is an error detected by the total check function when there is a syntax error or incorrect setting written in the program. When the mode selector is switched to the RUN mode, the total check function automatically activates and eliminates the possibility of incorrect operation from syntax errors in the program.

When a syntax check error is detected

-ERROR turns on or flashes.

-Operation will not begin even after swirching to the RUN mode.

-Remote operation cannot be used to change to RUN mode.

Clearing a syntax check error

By changing to the PROG.mode, the error will clear and the ERROR will turn off.

Steps to take for syntax error

Change to the PROG. mode, and then execute the total check function while online mode with the programming tool connected. This will call up the content of error and the address where the error occurred.

Correct the program while referring to the content of error.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

-Self-diagnostic Error

This error occurs when the control unit (CPU unit) self-diagnostic function detects the occurrence of an abnormality in the system. The self-diagnostic function monitors the memory abnormal detection, I/O abnomal detection, and other devices.

When a self-diagnostic error occurs

- The ERROR turns on or flashes.

- The operation of the control unit (CPU unit) might stop depending on the contect of error and the system

register setting.

- The error codes will be stored in the special data register DT9000(DT90000).

- In the case of operation error, the error address will stored in the DT9017(DT90017) and DT9018(DT90018).

Clearing the self-diagnostic error

At the "STATUS DISPLAY", execute the "error clear". Error codes 43 and higher can be cleared. -You can use the initialize/test switch to clear an error. However, this will also clear the contents of operation memory.

-Errors can also be cleared by turning off and on the power while in the PROG.mode.

However, the contents of operation memory, not stored with the hold type data, will also be cleared. -The error can also be cleared depending on the self-diagnostic error set instruction F148(ERR).

Steps to take for self-diagnostic error

The steps to be taken will differ depending on the error contents. For more details, use the error code obtained above and consult the table of aself-diagnostic error codes.

MEWTOCOL-COM Transmission Errors

These are error codes from a PC or other computer device that occur during an abnormal response when communicating with a PLC using MEWTOCOL-COM.

Opera-FP1/FP-M Error FP10SH Name tion Description and steps to take **FP2SH** code FP-X FP-e FPΣ FP2 FP3 FP0 status A program with a syntax error has been Syntax written. E1 Stops A A А А A А Α А А ⇒ Change to PROG. mode and correct error the error. Two or more OT(Out) instructions and KP(Keep) instructions are programmed using the same relay. Also occurs when using the same timer/counter number. \Rightarrow Change to PROG. mode and correct Duplicated E2 the program so that one relay output Stops A А А А А А А А А (Note) is not used for two or more OT error instructions, Or, set the duplicated output to "enable" in system register20. A timer/counter instructon double definition error will be detected even if double output permission has been selected. For instructions which must be used in a pair such as jump (JP and LBL), one instruction is either missing or in an Not paired E3 Stops incorrect position. A А А A А А А A А error \Rightarrow Change to PROG. mode and enter the two instructions which must be used in a pair in the correct positions. An instruction has been written which does not agree with system register settings. For example, the number Para-meter setting in a program does not agree with E4 mismatch Stops the timer/counter range setting. A А А А А А А А Α \Rightarrow Change to PROG. mode, check the error system register settings, and change so that the settings and the instruction agree. An instruction which must be written in a specific area (main program area or subprogram area) has been written to a E5 Program different area (for example, a subroutine Stops A А А А А А А А А (Note) SUB to RET is placed before an ED area error instruction). \Rightarrow Change to PROG. mode and enter the instruction into the correct area.

Table of Syntax Check Error

A:Available

Note) This error is also detected if you attempt to execute a rewrite containing a syntax error during RUN. In this case, nothing will be written to the CPU and operation will continue.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FPΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
E6	Compile memory full error	Stops	The program is too large to compile in the program memory. ⇒ Change to PROG. mode and reduce the total number of steps for the program. -FP10SH If memory expansion is possible,compilation will become possible when the memory is expanded.	A	A	A	A	A		A	A	
E7	High-level instruction type error	Stops	In the program, high-level instructions, which execute in every scan and at the leading edge of the trigger, are programmed to be triggered by one contact. (e.g. F0 (MV) and P0 (PMV) are programmed using the same trigger continuously.) ⇒ Correct the program so that the high- level instructions executed in every scan and only at the leading edge are triggered separately.			А	A		A	A	A	A
E8	High-level instruction operand combina- tion error	Stops	There is an incorrect operand in an instruction which requires a specific combination operands (for example, the operands must all be of a certain type). ⇒ Enter the correct combination of operands.	A	A	A	A	A	A	A	A	А
E9	No program error	Stops	Program may be damaged. ⇒Try to send the program again.							A	A	
E10	Rewrite during RUN syntax error	Conti- nues	When inputting with the programming tool software, a delection, addition or change of order of an instruction(ED,LBL,SUB,RET,INT,IRET, SSTP, and STPE) that cannot perform a rewrite during RUN is being attempted. Nothing is written to the CPU.						A	A	A	A

A:Available

Table of Self-Diagnostic Error

Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FPΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
E20	CPU error	Stops	Probably a hardware abnormality ⇒Please contact your dealer.						А	А	А	А
E21	RAM error1											
E22	RAM error2											
E23	RAM error3	Stops	Probably an abnormality in the internal RAM.						А	А	А	А
E24	RAM error4		\Rightarrow Please contact your dealer.									
E25	RAM error5											
E26	User's ROM error	Stops	FP-e,FP0,FPΣ, and FP1 C14,C16:Probably a hardware abnormality. ⇒ Please contact your dealer. FP-X: When the master memory cassette is mounted, the master memor cassette may be damaged. Remove the master memory, and check whether the ERROR turns off. When the ERROR turned off, rewrite the master memory as its contents are damaged, and use it again. When the ERROR does not turn off, please contact your dealer. FP1 C24,C40,C56,C72,and FP-M: Probably an abnormality in the memory unit ⇒Program the memory unit again and try to operate. If the same error is detected, try to operate with another memory unit. FP2,FP2SH,FP10SH,and FP3: There may be a problem with the installed ROM. -ROM contens are damaged. -Program size stored on the ROM is larger than the capacity of the ROM ⇒Check the contents of the ROM	A	А	A	A	A	A	A	A	A
E27	Unit installation error	Stops	Units installed exceed the limitations.(i.e.,4 or more link units) ⇒ Turn off the power and re-configure units referring to the hardware manual.			A	A		A	A	A	A
E28	System register error	Stops	Probably an abnormality in the system register. \Rightarrow Check the system register setting or initialize the system registers.						A			A

A:Available

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net
Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FPΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
E29	Configu- ration parameter error	Stops	A parameter error was detected in the MEWNET-W2 configuration area. Set a correct parameter.						A	A		
E30	Interrupt error 0	Stops	Probably a hardware abnormality. \Rightarrow Please contact your dealer.									А
E31	Interrupt error 1	Stops	An interrupt occurred without an interrupt request . A hardware problem or error due to noise is possible. ⇒ Turn off the power and check the noise conditions.	A	A	A	A	A	A	A	A	A
E32	Interrupt error 2	Stops	There is no interrupt program for an interrupt which occurred. ⇒ Check the number of the interrupt program and change it to agree with the interrupt request.	A	A	A	A	A	A	A	A	A
E33	Multi-CPU data unmatch error	CPU2 Stops	This error occurs when a FP3/FP10SH is used as CPU2 for a multi-CPU system. ⇒Refer to "Multi-CPU system Manual".							A	A	
E34	I/O status error	Stops	An abnormal unit is installed. -FP Σ , FP-X, FP2,FP2SH and FP10SH: Check the contents of special data register DT90036 and locate the abnormal unit.Then turn off the power and replace the unit with a new one. -FP3: Check the contents of special data register DT9036 and locate the abnormal unit. Then turn off the power and replace the unit with a new one.			А	A	А		A	A	A
E35	MEWNET-F slave illegal unit error	Stops	A unit, which cannot be installed on the slave station of the MEWNET-F link system,is installed on the slave station. ⇒Remove the illegal unit from the slave station.						A	A	A	А
E36	MEWNET-F (remore I/O) limitation error	Stops	The number of slots or I/O points used for MEWNET-F(remote I/O) system exceeds the limitation. ⇒Re-configure the system so that the number of slots and I/O points is within the specified range.						A	A	A	А
E37	MEWNET-F I/O mapping error	Stops	I/O overlap or I/O setting that is over the range is detected in the allocated I/O and MEWNET-F I/O map. \Rightarrow Re-configure the I/O map correctly						A	A	A	А

Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FPΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
E38	MEWNET-F slave I/O terminal mapping error	Stops	I/O mapping for remote I/O terminal boards,remote I/O terminal units and I/O link is not correct. ⇒Re-configure the I/O map for slave stations according to the I/O points of the slave stations.						A	A	A	А
E39	IC card read error	Stops	 When reading in the program from the IC memory card(due to automatic reading because of the dip switch setting or program switching due to F14(PGRD) instruction): IC memory card is not installed. There is no program file or it is damaged. Writing is disabled. There is an abnormality in the AUTOEXEC.SPG file. Program size stored on the card is larger than the capacity of the CPU. ⇒Install an IC memory card that has the program proterly recorded and execute the read once again. 							A	A	
E40	I/O error	Sele- ctable	Abnormal I/O unit. FPΣ, FP-X: Check the contents of special data register DT90002 and abnormal FPΣ expansion unit (application cassette for FP-X). Then check the unit. FP2 and FP2SH: Check the contents of special data registers DT90002,DT90003 and abnormal I/O unit. Then check the unit. Selection of operation status using system register21: -to continue operation,set 1 -to stop operation,set 0 Verification is possible in FPWIN GR/Pro at"I/O error" in the status display function. MEWNET-TR communication error FP3 and FP10SH: Check the contents of special data registers(FP3:DT9002,DT9003,FP10S H:DT90002,DT90003) and the erroneous master unit and abnormal I/O unit. Then check the unit. Selection of operation, set 1 -to stop operation, set 0 Verification is possible in FPWIN GR/Pro at"I/O error" in the status display function.			A	A		A	A	A	A

A:Available

11-120

Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FPΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
E41	Intelligent unit error	Selec- table	An abnormality in an intelligent unit. $FP\Sigma$, $FP-X$: Check the contetns of special data register "DT90006" and locate the abnormal FP intelligent unit (application cassette for FP-X). FP2, $FP2SH$, and $FP10SH$: Check the contents of special data registers DT90006, DT90007 and locate the abnormal intelligent unit. Then check the unit referring to its manual Selection of operation status using system register22: -to continue operation, set 1 -to stop operation, set 0 FP3: Check the contents of special data registers DT9006, DT9007 and locate the abnormal intelligent unit. Then check the unit referring to its manual Selection of operation status using system register22: -to continue operation, set 1 -to stop operation, set 0 Verification is possible in FPWIN GR/Pro at"I/O error" in the status display function.			А	А		А	A	А	A
E42	I/O unit verify error	Selec- table	 I/O unit(Expansion unit) wiring condition has changed compared to that at time fo power-up. ⇒ Check the contents of special data register (FP0: DT9010, FPΣ, FP-X: DT90010,DT90011) and locate the erroneous expansion unit. It checks whether an expansion connector is in agreement. ⇒ Check the contents of special data register (FP2,FP2SH,and FP10SH:DT90010,DT90011,FP3 DT9010,DT9011) Selection of operation status using system register23: -to continue operation,set 1 -to stop operation,set 0 Verification is possible in FPWIN GR/Pro at"I/O error" in the status display function. 	A		A	А		A	A	A	A

Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FPΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
E43	System watching dog timer error	Selec- table	Scan time required for program execution exceeds the setting of the system watching dog timer. ⇒ Check the program and modify it so that the program can execute a scan within the specified time. Selection of operation status using system register24: -to continue operation,set 1 -to stop operation,set 0							A	A	
E44	Slave staiton connecting time error for MEWNET-F system	Selec- table	The time required for slave station connection exceeds the setting of the system register 35. Selection of operation status using system register25: -to continue operation,set 1 -to stop operation,set 0						A	A	A	A
E45	Operation error	Selec- table	Operation became impossible when a high-level instruction was executed. Selection of operation status using system register26: -to continue operation,set K1 -to stop operation,set K0 In the FP2,FP2SH,and FP10SH,Check the contents of special data registers DT90017,DT90018 to find the instruction address where the operation error occurred. Then correct the program. In the FP3,Check the contents of special data registers DT9017,and DT9018 to find the instruction address where the operation error occurred.Then correct the program. Verification is possible in FPWIN GR/Pro at"I/O error" in the status display function.	A	A	A	A	A	A	A	A	A

A:Available

11-122

Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FPΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
		Selec- table	S-LINK error Occurs only in FP0-SL1 When one of the S-LINK errors (ERR1, 3 or 4) has been deteced,error code E46 (remote I/O (S-LINK) communication error) is stored. Selection of operation status using system register27: -to continue operation,set K1 -to stop operation,set K0	A								
E46	Remote I/O commu- nication error	Selec- table	MEWNET-F communication error A communication abnormally was caused by a transmission cable or during the power-down of a slave station. FP2, FP2SH, and FP10SH: Check the contents of special data registers DT90131 to DT90137 and locate the abnormal slave station and recover the communication condition. FP3: Check the contents of special data registers DT9131 to DT9137 and locate the abnormal slave station and recover the communication condition. Selection of operation status using system register27: -to continue operation,set K1 -to stop operation,set K0					A	A	A	A	A
E47	MEW-NET- F attribute error	Selec- table	In the unit on the slave station, an abnormallty such as: -missing unit -abnormal intelligent unit was detected. FP2, FP2SH, and FP10SH: Check the contents of special data registers DT90131 to DT90137 and locate the abnormal slave station and recover the slave condition. FP3: Check the contents of special data registers DT9131 to DT9137 and locate the abnormal slave station and recover the slave condition. Selection of operation status using system register28: -to continue operation,set 1 -to stop operation,set 0						A	A	A	A
E49	Expansion unit power supply sequence error	Stops	The power supply for the expansion unit was turned on after the control unit. Turn on the power supply for the expansion unit at the same time or before the control unit is turend on.				A					

Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FPΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
E50	Backup battery errror	Conti- nues	The voltage of the backup battery lowered or the backup battery of conrol unit is not installed. ⇒ Check the installation of the backup battery and then replace battery if necessary. By setting the system register 4, you can disregard this self-diagnostic error.		А	А	A	A Note)	А	А	Α	А
E51	MEWNET-F terminal station error	Conti- nues	Terminal station setting was not properly performed. Check stations at both ends of the communication path,and set them in the terminal station using the dip switches.						A	A	A	A
E52	MEWNET-F I/O update synchro- nous error	Conti- nues	Set the INITIALIZE/TEST selecto1inmjvbgycfrde892 r to the INITIALIZE position while keeping the mode selector in the RUN position.If the same error occurs after this,please contact your dealer.						A	A	A	A
E53	Multi-CPU I/O regis- tration error (CPU2 only)	Conti- nues	Abnormality was detected when the multi- CPU system ws used. Please contact your dealer.								A	A
E54	IC memory card back- up battery error	Conti- nues	The voltage of the backup battery for the IC memory card lowered. The BATT.LED does not turn on. Charge or replace the backup battry of IC memory card.(The contents of the IC memory card cannot be guaranteed.)							A	A	
E55	IC memory card back- up battery error	Cont- inues	The voltage of the backup battery for IC memory card lowers.The BATT.LED does not turn on. Charge or replace the backup battery of IC memory card. (The contents of the IC memory card cannot be guaranteed.)							А	A	
E56	Incompat- ible IC memory card error	Cont- inues	The IC memory card installed is not compatible. Replace the IC memory card compatible with FP2SH/FP10SH.							A	A	
E57	No unit for the configu- ration	Conti- nues	MEWNET-W2 The MEWNET-W2 link unit is not installed in the slot specified using the configuration data. Either install a unit in the specified slot or change the parameter.						A	A		

A:Available

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

E100 Self- diagnostic E199 The error specified by the F148 (ERR)/P148(PERR) instruction is occurred. ⇒ Take steps to clear the error condition according to the specification you chose. A <th< th=""><th>Error code</th><th>Name</th><th>Opera- tion status</th><th>Description and steps to take</th><th>FP0</th><th>FP-e</th><th>FРΣ</th><th>FP-X</th><th>FP1/FP-M</th><th>FP2</th><th>FP2SH</th><th>FP10SH</th><th>FP3</th></th<>	Error code	Name	Opera- tion status	Description and steps to take	FP0	FP-e	FРΣ	FP-X	FP1/FP-M	FP2	FP2SH	FP10SH	FP3
E200 by F148 according to the specification you chose.	E100 to E199	Self- diagnostic error set	Stop	The error specified by the F148 (ERR)/P148(PERR) instruction is occurred. \rightarrow Take steps to clear the error condition	A	A	A	A	A	A			
to (PERR) nues E299 instruction	E200 to E299	by F148 (ERR)/P148 (PERR) instruction	Conti- nues	according to the specification you chose.	А	A	A	A	А	А			

Note) Available PLC:FP1 C24,C40,C56,C76,and FP-M

11-125 Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Table of MEWTOCOL-COM Communication Error

Error code	Name	Description
!21	NACK error	Link system error
!22	WACK error	Link system error
!23	Unit No. overlap	Link system error
!24	Transmission format error	Link system error
!25	Link unit hardware error	Link system error
!26	Unit No. setting error	Link system error
!27	No support error	Link system error
!28	No response error	Link system error
!29	Buffer closed error	Link system error
!30	Time-out error	Link system error
132	Transmission	Link system error
.52	impossible error	
!33	Communication stop	Link system error
!36	No destination error	Link system error
!38	Other communication error	Link system error
!40	BCC error	A transfer error occurred in the received data.
!41	Format error	A command was received that does not fit the format.
!42	No support error	A command was received that is not supported.
1/13	Multiple frames	A different command was received when processing multiple
.45	procedure error	frames.
150	l ink setting error	A route number that does not exist was spacified. Verify the
		route number by designating the transmission station.
!51	Transmission	Transmission to anather device not possible because
	time-out error	transmissition buffer is congested.
!52	Transmit disable	Transmission processing to another device is not possible.(Link
	error	unit runaway,etc.)
150	Duou orror	Command process cannot be received because of multiple
153	Busy error	haing processing. Or, cannot be received because command
160	Baramatar arrar	Content of apacified parameter does not evict at cannot be used
100		There was a mistake in the contact data area data number
!61	Data error	designation size designation range or format designation
	Registration over	Operation was does when number of registrations was exceeded
!62	error	or when there was no registration
<u> </u>		PC command that cannot be processed was executed during
!63	PC mode error	RUN mode.

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

Error code	Name	Description
!64	External memory error	An abnormality occurred when loading RAM to ROM/IC memory card.There may be a problem with the ROM or IC memory card. -When loading,the specified contents exceeded the capacity. -Write error occurs. -ROM or IC memory card is not installed. -ROM or IC memory card does not conform to specifications -ROM or IC memory card board is not installed.
!65	Protect error	A program or system register write operation was executed when theb protect mode (password setting or DIP switch,etc.)or ROM operation mode was being used.
!66	Address error	There was an error in the code format of the address data. Alsi.when exceeded or insufficient of address data, there was a mistake in the range designation.
!67	No program error and No data error	Cannot be read because there is no program in the program area or the memory contains an error.Or,reading was attempted of data that was not registered.
!68	Rewrite during RUN error	When inputting with programming tool software,editing of an instruction (ED,SUB,RET,INT,IRET,SSTP,and STPE) that cannot perform a rewrite during RUN is being attempted. Nothing is written to the CPU.
!70	SIM over error	Program area was exceeded during a program write process.
!71	Exclusive access control error	A command that cannot be processed was executed at the same time as a command being processed.

11.5 MEWTOCOL-COM Communication Commands

Command name	Code	Description
	RC	Reads the on and off status of contact.
Dood contract area	(RCS)	- Specifies only one point.
Read contact area	(RCP)	- Specifies multiple contacts.
	(RCC)	- Specifies a range in word units.
	WC	Turns contacts on and off.
Write contact area	(WCS)	- Specifies only one point.
write contact area	(WCP)	- Specifies multiple contacts.
	(WCC)	- Specifies a range in word units.
Read data area	RD	Reads the contents of a data area.
Write data area	WD	Writes data to a data area.
Read timer/counter set value area	RS	Reads the value set for a timer/counter.
Write timer/counter set value area	WS	Writes a timer/counter setting value.
Read timer/counter ellapsed value area	RK	Reads the timer/counter elapsed value.
Write timer/counter elapsed value area	WK	Writes the timer/counter elapsed value.
Register or Reset contacts monitored	MC	Registers the contact to be monitored.
Register or Reset data monitored	MD	Registers the data to be monitored.
Monitoring start	MG	Monitors a registered contact or data using the
		Code MC or MD .
Preset contact area (fill command)	SC	Embeds the areaor a specified range in a 16-
		point on and on pattern.
Preset data area (fill command)	SD	specified range
Read system register	RR	Reads the contents of a system register
Write system register		Specifies the contents of a system register
	VVIX	Reads the specifications of the programmable
Read the status of PLC	RT	controller and error codes if an error occurs
		Switches the operation mode of the
Remote control	RM	
Abort		
ADOIT	AB	Abons communication.

Table of MEWTOCOL-COM commands

-11-128 - Phone: 800 894 0412 - Fay: 888 723 4773 - Web: www.ct

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

11.6 Hexadecimal/Binary/BCD

Desimal	Hevedeeimel	Dinomy data	BCD data
Decimal	пехацесниа	Binary data	(Binary Coded Decimal)
0	0000	0000000 0000000	0000 0000 0000 0000
1	0001	0000000 0000001	0000 0000 0000 0001
2	0002	0000000 0000010	0000 0000 0000 0010
3	0003	0000000 0000011	0000 0000 0000 0011
4	0004	0000000 00000100	0000 0000 0000 0100
5	0005	0000000 00000101	0000 0000 0000 0101
6	0006	0000000 00000110	0000 0000 0000 0110
7	0007	0000000 00000111	0000 0000 0000 0111
8	0008	0000000 00001000	0000 0000 0000 1000
9	0009	0000000 00001001	0000 0000 0000 1001
10	000A	0000000 00001010	0000 0000 0001 0000
11	000B	0000000 00001011	0000 0000 0001 0001
12	000C	0000000 00001100	0000 0000 0001 0010
13	000D	0000000 00001101	0000 0000 0001 0011
14	000E	0000000 00001110	0000 0000 0001 0100
15	000F	0000000 00001111	0000 0000 0001 0101
16	0010	0000000 00010000	0000 0000 0001 0110
17	0011	0000000 00010001	0000 0000 0001 0111
18	0012	0000000 00010010	0000 0000 0001 1000
19	0013	0000000 00010011	0000 0000 0001 1001
20	0014	0000000 00010100	0000 0000 0010 0000
21	0015	0000000 00010101	0000 0000 0010 0001
22	0016	0000000 00010110	0000 0000 0010 0010
23	0017	0000000 00010111	0000 0000 0010 0011
24	0018	0000000 00011000	0000 0000 0010 0100
25	0019	0000000 00011001	0000 0000 0010 0101
26	001A	0000000 00011010	0000 0000 0010 0110
27	001B	0000000 00011011	0000 0000 0010 0111
28	001C	0000000 00011100	0000 0000 0010 1000
29	001D	0000000 00011101	0000 0000 0010 1001
30	001E	0000000 00011110	0000 0000 0011 0000
31	001F	0000000 00011111	0000 0000 0011 0001
•	•		
63	003F	0000000 00111111	0000 0000 0110 0011
•	•	•	
•	•	•	
		•	•
255	00FF	0000000 11111111	0000 0010 0101 0101
•	•		
•	•		•
		•	
9999	270F	00100111 00001111	1001 1001 1001 1001

11-129

11.7 ASCII Codes

															61
0						•	b7								
						->	b6	0	0	0	0	1	1	1	1
						-	b5	0	0	1	1	0	0	1	1
							b4	0	1	0	1	0	1	0	1
b7	b6	b5 b4	b3	b2	b1	b0	RC	0	1	2	3	4	5	6	7
			0	0	0	0	0	NUL	DEL	SPACE	0	@	Ρ	Ň	р
			0	0	0	1	1	SOH	DC1	!	1	А	Q	а	q
			0	0	1	0	2	STX	DC2	п	2	В	R	b	r
			0	0	1	1	3	ETX	DC3	#	3	С	S	С	s
			0	1	0	0	4	EOT	DC4	\$	4	D	Т	d	t
			0	1	0	1	5	ENQ	NAK	%	5	Е	U	е	u
			0	1	1	0	6	ACK	SYN	&	6	F	V	f	v
			0	1	1	1	7	BEL	ETB	Ū	7	G	W	g	w
			1	0	0	0	8	BS	CAN	(8	Н	Х	h	х
			1	0	0	1	9	HT	EM)	9	1	Y	i	у
			1	0	1	0	А	LF	SUB	*	i	J	Z	j	z
			1	0	1	1	В	VT	ESC	+	;	к	[k	{
			1	1	0	0	С	FF	FS	,	<	L	¥	T	1
			1	1	0	1	D	CR	GS	-	=	М]	m	}
			1	1	1	0	Е	SO	RS		>	N	۸	n	~
			1	1	1	1	F	SI	US	1	?	0	_	0	DEL

Record of changes

Manual No.	Date	Desceiption of changes
ARCT1F369E	DEC., 2002	First edition
ARCT1F369E-1	JUL., 2003	2 nd edition PDF Only Addition of Chapter 8 "PID Control"
AFCT1F369E-2	APR., 2003	3 rd edition PDF Only Addition of functions available for Ver. 1.2 or higher Addition of new models (RS485 type) - AFPE224302 - AFPE214322
ARCT1F369E-3	FEB.2006	4 nd edition