

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any means for any purpose without the express written permission of HT OMEGA, Inc.

CLARO II® and HT OMEGA logo are trademarks of HT OMEGA, Inc. C-Media, the C-Media logo and Xear 3D are trademarks of C-media Electronics Inc. Dolby, Dolby Digital, Dolby Pro Logic IIx, Dolby Virtual Speaker and Dolby Headphone are trademarks of Dolby Laboratories. DTS Connect, DTS Interactive and DTS: NEO:PC are trademarks of Digital Theater System, Inc. DTS is a registered trademark of Digital Theater System, Inc. EAX and A3D are trademarks of Creative Technology Ltd. Microsoft, DirectSound3D, Microsoft Windows are trademarks of Microsoft Corporation. Other company and product names may be trademarks of the respective companies with which they are associated.

Dolby Digital RTCE driver is manufactured under license from Dolby Laboratories.
Manufactured under license from DTS, Inc. U.S. Pat. No's. 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535 and other U.S. and world-wide patents issued and pending. DTS CONNECT, DTS INTERACTIVE and DTS NEO:PC are trademarks of DTS, Inc. DTS is a registered trademark of DTS, Inc. Copyright 1996, 2002-2005 Digital Theater Systems, Inc. All Rights Reserved.
ASIO is a trademark and software of Steinberg Media Technologies GmbH.

© 2011 HT OMEGA, Inc.

The product described in this manual has been developed and produced by HT OMEGA, Inc. The information furnished in this document is provided for the customers' reference. However, HT OMEGA, Inc. assumes no liability for any incidental, consequential and certain other damages that arise out of or relating in any way to the software or hardware device.

HT OMEGA, Inc.

1912 Augusta Ct. Ontario, CA 91761 USA.

Webservice: <http://www.htomega.com>


Table of Contents

1. Instruction	4
2. Features Overview	5
3. Installing H/W, S/W, and Speakers	6
3.1 CLARO II Hardware	6
3.2 Connection and Speaker Setup.....	9
3.3 CLARO II Software	11
4. Using Audio Driver	13
4.1 CLARO II Software Control Panel	13
4.2 Main Setting	14
4.3 Mixer/Volume.....	23
4.4 Sound Effects	25
4.5 Magic Voice™ and Karaoke	26
4.6 FlexBass™	27
4.7 Look for Information.....	28
5. FAQ & Troubleshooting.....	29
6. Support / Contact.....	31

1. Introduction

Thanks for choosing an HT OMEGA audio solution!

This manual will guide you in configuring the Advanced Driver Software Architecture (ADSA™) used by the Claro II. And Xear 3D™ technology, the CLARO II provides a value-added PC audio solution with maximum support for all kinds of applications. With this manual, users can quickly take advantage of these great features to enjoy amazing sound quality.



What's in the box?

You should have received the following with your CLARO II:

- **CLARO II soundcard**
- **Drivers/Applications CD**
- **Fiber Optical Digital Cable**
- **This manual**

Specifications

(1) Sound Processor

- C-Media CMI8788/PCI-8ch PCI Chipset
- 24-bit/192kHz Stereo ADC
- Full-duplex ultra high 24-bit/192kHz DACs

(2) Interface

- PCI 2.2
- High performance 1/8" (3.5mm) output connectors.
- Onboard Optical transmitter and Gold Plated RCA Connector for digital output.
- Onboard 2pin digital Input and Output.
- Front Panel Audio supports: 10pin connector (Intel® Front Panel Audio Compliant) for Front Panel Audio of PC case.

2. Features Overview

The following is an overview of the features of the CLARO II. The CLARO II driver supports recent generation multi-channel digital functions and the following key features:

- C-Media Xear 3D™ 7.1 Virtual Speaker Shifter technology
- C-Media FlexBass™ – configurable LFE channel crossover frequency (from 50 to 250Hz)
- C-Media Magic Voice™, a popular feature for disguising voice in online chatting
- C-Media's unique Karaoke functions: Microphone Echo, 10-band EQ, 27 global reverberation environments
- Supports 3D sound for PC gaming by DirectSound™
- Support 7.1 CH audio playback


System Requirements (Minimum)

- Genuine Intel® Pentium® III 800 MHz or equivalent AMD® processor
- 256 MB RAM
- Microsoft® Windows® XP Service Pack 1 (SP1)
- Available one PCI 2.2 slot
- A headphone or 2channel amplified speakers (available separately)
- 500 MB of free hard disk space
- CD-ROM or DVD-ROM drive required for software installation from CD

3. Installing H/W, S/W, and Speakers

3.1 CLARO II Hardware

(1) Connectors




Connectors on Bracket

- ① **MIC IN (3.5mm Stereo-jack):** Connects to external condenser (stereo jack) microphone for voice input.
- ② **LINE IN (3.5mm Stereo-jack):** Connects to external analog line-level sources, such as CD players, MP3 players and other analog stereo output devices.
- ③ **FRONT (3.5mm Stereo-jack):** Connects to Front Left/Right inputs on powered analog speakers, an external amplifier or headphones.
- ④ **SIDE SURROUND (REAR / 3.5mm Stereo-jack):** Connects to Rear Left/Right inputs on powered multi-channel analog speakers.
- ⑤ **CENTER/S.WOOFER (3.5mm Stereo-jack):** Connects to Center and Sub-Woofer inputs on powered multi-channel analog speakers.

- ⑥ **BACK SOURROUND (REAR CENTER / 3.5mm Stereo-jack):** Connects Rear Center 1 / 2 inputs on powered multi-channel analog speakers.
- ⑦ **OPTICAL INPUT (S/PDIF OPTICAL Digital Input connector):** Connection for external digital devices such as a CD player. Only PCM digital audio (2ch digital) can be monitored on sound card analog outputs. Dolby® Digital, DTS® stream, and other Non-PCM digital audio sources can be pass-through to digital output connectors
- ⑧ **OPTICAL OUTPUT (S/PDIF OPTICAL Digital Output connector):** Connects to external digital devices like AV receivers, decoders or digital speaker systems. It allows pass-through of PCM and Dolby® Digital and DTS® stream to external DD/DTS decoder and A/V receivers.
- ⑨ **COAXIAL OUTPUT (S/PDIF COAXIAL Digital Output, Gold Plated RCA Jack):** Connects to external digital devices like AV receivers, decoders or digital speaker systems with Coaxial S/PDIF output.

(2) Headers/Connectors on board



Headers/Connectors on board

⑩ **Front Panel Audio (10 Pin Header): Connects to the Front Panel Audio Cable of your PC case. Pin configuration:**

Pin 1 - MIC

Pin 2 - Ground

Pin 3 - Bias (MIC Power)

Pin 5 - Front Right

Pin 9 - Front Left


Pin 4,6,7,8 and10 are not available

Note: Front Panel Audio Cable not included

⑪ **AUX_IN (4Pin MPC2):** Connects to the internal analog audio from user's AUX output such as TV card.

⑫ **CD_IN (4Pin MPC2):** Connects to the CD analog audio output on an internally mounted CD/DVD drive using an analog CD audio cable.

⑬ **2Pin digital IN:** Connects to external digital device or the CD digital audio (16-bit/44.1kHz) output.



Optional 2pin-RCA cable


Note: Cable not included. Please contact HT OMEGA for purchasing this cable.

⑭ **2Pin digital OUT:** Connects to external digital input device such as VGA 2pin digital input connector for HDMI output.

3.2 Connection and Speaker Setup


(1) Connection

① Connecting 7.1 Channel Speakers




7.1ch Speakers connect

② Connecting 5.1 Channel Speakers




5.1ch Speakers connect

③ Connecting 4 Channel Speakers




4ch Speakers connect

④ Connecting 2 Channel Speakers




2ch Speakers connect

⑤ Connecting Headphone




Headphone connect

⑥ Connecting Microphone and External Analog Devices



Microphone and Line in setup

⑦ Connecting External Digital Devices




Link to external decoder or digital AV receiver

3.3 CLARO II Software

Please disable any existing PCI or onboard sound/audio devices (may need to disable in BIOS) and remove the associated software and drivers before installing "Claro II" to avoid potential device and/or driver conflicts. Drivers and applications can be removed through the "Add or Remove Programs" menu in Windows Control Panel.


(1) Installing the drivers and software

① Turn on PC. Windows will automatically detect **new hardware-Multimedia Audio Controller** and prompt the **Found New Hardware Wizard**. Click the **Cancel** button to end this process.




② Insert installation CD into the CD/DVD drive. Installation CD will launch automatically only if the Auto-Insert Notification option is enabled for your CD/DVD drive. If the installation menu does not appear after inserting the installation CD into your CD/DVD drive, browse to the drive letter that contains the installation CD and double-click on the CD/DVD drive icon to explore it. Search for and run "**SETUP.EXE**" and proceed to the next step.

③ When the installation menu appears, select "**Next**". Follow the instructions that appear during the installation selecting the options that best match your audio setup.



- ④ When prompted, reboot the system. Wait a few minutes for the installation to complete. The wait time will vary depending on the speed of your PC. Please wait for the system to reboot to properly complete the installation.



(4) TO UNINSTALL "Claro II" drivers and softwares

- ① Open the Windows Control Panel (Start => Settings => Control Panel).
- ② Open the Programs & Features. Select "HT OMEGA CLARO SERIES" and click on the "Uninstall/Change" button to the lower right of the screen.
- ③ To complete the uninstall process, Windows needs to be restarted. Select **Yes, I want restart my computer now** then press **Finish**. (Please do not skip restart now before installing updated driver)

4. Using Audio Driver


4.1 CLARO II Software Control Panel

This is C-Media's 3D audio control panel that allows the user to manage all audio configurations. After finishing the installation of the driver and rebooting the system, the audio control panel will be available through two locations:

1. Left-Click the icon in the system tray in the right-bottom of your screen. You can also click right button the icon to access the audio-related menu.




2. Double-click "HT OMEGA CLARO SERIES" icon in Windows "Control Panel". (Start > Control Panel > All Control Panel Items (View By: Small Icons))



Main Control Program icon on Control Panel

4.2 Main Setting

Xear3D Claro control panel is the graphic interface for Claro II driver. You can control all features of the Claro II on this control panel. The following pictures show a basic overview of the Claro II. The Xear3D control panel has Main Setting, Mixer, Effect, Karaoke/Magic Voice, FlexBass and Information tabs.



CLARO II Main Setting for XP



CLARO II Main Setting for VISTA and Windows7

(1) Analog Output select mode

This part can let user to select analog and digital output mode. There are 5 types analog output modes: **Headphone, 2 / 4 / 5.1 / 7.1 Channel Output Mode.**

(2) Digital Output select mode

Digital output mode is configured to define which format will be out by S/PDIF interface. There are a total 7 digital output modes: **Dolby Digital Live/ DTS Interactive/ Digital audio 44.1K/ 48K/ 96K/ 192K/ SPDIF In Loopback.**

- **Dolby Digital Live**--- Audio data will be encoded to AC-3 5.1 format and output via S/PDIF out
- **DTS Interactive**--- Audio data will be encoded to DTS cinema 5.1 bit stream format and output via S/PDIF out
- **Digital Audio 44.1 KHz**---S/PDIF out with 44.1KHz sample rate
- **Digital Audio 48 KHz**---S/PDIF out with 48KHz sample rate
- **Digital Audio 96 KHz**---S/PDIF out with 96KHz sample rate
- **Digital Audio 192 KHz**---S/PDIF out with 192KHz sample rate


NOTE: When Dolby Digital Live or DTS Interactive is enabled the analog outputs will be turned off automatically to prevent interference.

NOTE: Windows VISTA and Windows7 driver provides S/PDIF Output mode separately. You can choose PCM, Dolby Digital Live, DTS:Interactive on S/PDIF Output.

(3) DSP Mode

This button switches the DSP vision function on or off. When DSP mode is turned on the visual function menu will be displayed. When DSP is off, the standard speaker mode will be displayed.

There are a total 5 selectable DSP modes. **C-Media 7.1 Virtual Speaker Shifter** / **Dolby ProLogic IIx** / **Dolby Headphone** (only exist when Headphone on speaker mode setup) / **Dolby Virtual Speaker** (only exist when 2CH on speaker mode)/ **DTS NEO:PC** (exclusive with Dolby ProLogic IIx).

C-Media 7.1 Virtual Speaker shifter	Dolby ProLogic IIx	Dolby Headphone	Dolby Virtual Speaker	DTS NEO:PC
				


NOTE: Dolby Headphone will be shown at Headphone Mode of Analog Output under Windows VISTA and Windows7.

(4) Individual DSP control

Audio DSP allows adjustments to the settings of the corresponding DSP. The DSP can be divided into categories: Input Processor for stereo audio source and Output Processor

Processor.


1. Dolby feature process in C-Media driver:



DOLBY FEATURE PROCESS


2. DTS feature process in C-Media driver:

The C-Media Oxygen HD driver allows a range of different processing options for stereo/ 5.1/ 7.1 channel audio.



DTS FEATURE PROCESS


3. Dolby Pro Logic IIx Mode



Dolby Pro Logic IIx

- ① Center Width Control
- ② Reset balance button
- ③ Dimension Control
- ④ Music mode / Cinema mode select, 1 and 2 only can be adjusted under Music mode
- ⑤ Panorama Control, this is tested by measuring the output levels of the Left / Right surround channel when turned on and off


4. Dolby Headphone Mode



Dolby Headphone

- ① Reference Room Emulation
- ② Livelier Room Emulation
- ③ Larger Room Emulation


5. Dolby Virtual Speaker



Dolby Virtual Speaker

- ① Reference Room Mode
- ② Wide Mode


6. DTS NEO:PC



DTS NEO:PC


- ① 10 degrees Center Width Control
- ② Reset balance button
- ③ Dimension Control
- ④ Music mode / Cinema mode select, 1 and 2 only can be adjusted under Music mode

7. C-Media SPEAKER SHIFTER



SPEAKER SHIFTER


- ① Volume Control: Increase / decrease the volume of all channels by 1 dB.
- ② Auto Rotation Mode: The virtual speakers will rotate clockwise or counterclockwise slowly. For example, if clockwise is selected:




- ③ Manually Rotation Mode: Use mouse to rotate the virtual speakers on the screen manually.
- ④ Free Moving Mode: Use pointer and click-and-drag to move the location of individual virtual speakers / virtual listener.
- ⑤ Reset: Reset the location of virtual speakers / virtual listener to default.
- ⑥ Virtual Speaker: Each virtual speaker virtualizes one channel of the 7.1 channel speakers in the real world.
- ⑦ Virtual Listener: The virtual listener virtualizes your position in the real world.
- ⑧ Volume indicator for each channel.

(5) Speaker volume adjustment.

Speaker Tester is used to aid users with speakers placements.



Speaker Test for XP



Speaker Test for VISTA and Windows7


- ① Volume Control: You can adjust each speaker output volume level by 1 dB.
- ② Test each speaker output.

(6) System Input

In VISTA and Windows7, the System Input is different from XP driver. XP provides DirectX for multiple audio outputs but VISTA does not. C-media provides System Input for this feature. User must select System Input channel depending on sound source.


If you play 2ch stereo files such as MP3, AVI and games then set to 2ch for System Input no matter what type of multi-channels speaker system you have. For playback of multi-channel data such as DVDs, please set to 6ch in System Input.

Please set to 2ch on System Input and 6ch on Analog Output when outputting 2ch data through 5.1ch analog speaker system.



System Input setting for VISTA and Windows7

4.3 Mixer/Volume



Main Mixer


1. Audio System Status: Displays the output channel mode of the system.
2. Volume Control of Audio Source: Use to adjust the volume level.
3. Volume Indication Meter of Playback: Displays the playback volume in real-time.
4. Mute Button: Mute On/Off button.
5. Graphic of Selected Recording Device: The icon represents the selected recording device.

6. Recording Source Selection: Only one recording source is allowed to be selected at one time.

7. Monitoring : Monitoring of recording source is enabled here

8. Advanced Setting: There are two advanced setting options for Microphone

Microphone Setting



Microphone Advanced Settings

- ① Microphone Boost: If you feel that the mic volume is too low there is an option to boost +20dB. Check the “Boost” box to enable it. Keep in mind that background noise will also increase.

NOTE: The CLARO II uses a sensitive microphone preamp. To avoid damage to your speakers, do not use maximum volume level when plugging in a microphone. We recommend that volume be set at half or less. Volume level can be safely adjusted once the microphone has been connected.

- ② Monitoring: Select to hear microphone input played back through speakers.

4.4 Sound Effects

(1) Environment Emulation

1: Select an Environment effect to emulate multiple environments.


Note: Do not Select “More Option” if you don’t want to any effects.

2: Environment Size can be adjusted from large to small (default setting is medium). Changing the size will alter the virtual space in which the sound is reproduced.

(2) 10-Band Equalizer

3: There are 12 preset modes such as Bass, Treble, Live, Rock, Jazz, etc.

4: Custom equalizer settings can be saved. Enter a name into the blank space and click “+” to add your personal setting into the “User Defined” list. Click “-” to delete the currently selected user defined setting from the list.



Effect Setting

Copyright © 2011, HT OMEGA, Inc. All Right Reserved.

<http://www.htomega.com>

4.5 Magic Voice™ and Karaoke

1: Click “On” to turn on the Karaoke function (button should be blue).


NOTE: First time you turn on Magic Voice, the driver will default select the microphone input as the recording source. Click “OK” to close this window.

2: Reset all settings to default values.

3: “Microphone Echo” will add an echo effect. The volume and amount of echo can be adjusted according to user’s preference. Magic Voice™ is a special effects tool that will change the sound of your voice. To use it, select Magic Voice from the pull-down menu and choose one of the five effects buttons. The special effects can be used when talking to other people over the network, such as messenger applications, VOIP and online games. Because these two features require real-time microphone recording, you should suspend other recording applications while using Microphone Echo or Magic Voice.

4: You can enable Key-Shifting for the Karaoke VCD or the music to suit your voice pitch. The range is adjustable from -4b to +4#.


5: If the music source includes the original vocals, you may try the “Vocal Cancellation” function to cancel it (0~100). The success of the effect depends on the recording method used to create the audio source. Karaoke VCD or CD, typically do not include vocals and should not require “Vocal Cancellation.”



Karaoke/ Magic Voice Setting

4.6 FlexBass™

“FlexBass” is a driver feature that incorporates Bass Management technology. Bass Management is a necessary feature of Dolby Digital technology. A bass management feature allows management of the low-frequency content of your audio. In general, humans cannot tell which direction frequencies below 100 Hz come from. If speaker cannot output low frequencies, it is better to send them to another speaker such as a subwoofer, or the full range speaker (Large Speaker).




FlexBass Setting

1. **FlexBass On/Off switch button.** Turn on to start FlexBass function.
2. **Crossover frequency adjustment.** To define low frequency signal threshold in numerical hz range from 50-250 Hz.
3. **Frequency Meter.** Displays your selection.
4. **Large/Small speaker select.** By default, all speakers other than the subwoofer are set to “small”. The low frequency audio content is extracted and sent to the subwoofer out. Individual speaker (or pairs) can be defined as “large” allowing playback of low frequency signals.
5. **Speaker configuration status.** Graphic representation of speaker setting.

4.7 Look for Information

The Information tab displays details about the CLARO II's audio-related properties including the audio chip, driver version, 3D Audio Engine and Microsoft DirectX Version. The Audio Configuration icon can be shown in the system tray by checking the box.



Driver Information



5. FAQ & Troubleshooting

Q1 : What is a 7.1CH listening environment and how it is different from 5.1CH.

1. The 7.1 channel mode is the latest multi-channel audio format and technology on the market. It includes center, subwoofer, front left, front right, left surround, right surround, left back surround, and right back surround according to Dolby Digital and DTS ES standards.
2. The 7.1CH content is referred to as Dolby Digital EX by Dolby Lab and DTS-ES (Extended Surround) by DTS.
3. The difference between 5.1CH and 7.1CH is the addition of 2CH. The two extra speakers were placed in the rear side(s) to enhance the immersive experience of surround sound.




5.1CH Environment



7.1CH Environment

Q2 : I can't see Dolby Headphone mode (VISTA and Windows7)



You can use Dolby Headphone feature under Headphone mode. Please set Headphone on Analog Output option.

6. Support / Contact

HT OMEGA offers various resources to provide customer support. Please visit our website <http://www.htomega.com> to access our customer service section. The latest FAQ's, drivers, product documentation and applications can be found on the website, along with any new product development and information.

Thank you for choosing an HT OMEGA product. We look forward to providing you with the highest quality products and service.

LIMITED WARRANTY

HT OMEGA, Inc. warrants to the original purchaser only that the hardware product will be free of defects in materials and workmanship for a period of twelve (12) months from the date of purchase. HT OMEGA, Inc. will, at its sole discretion, repair or replace the product if it is found to be defective. This warranty does not cover a product failure that is the result of misuse, abuse, modification, misapplication, or normal wear and tear. No claim is made for merchantability or fitness for any purpose. In no event will HT OMEGA, Inc. be liable for any direct, indirect, consequential, or incidental damages arising out of the use of this product. In no event will HT OMEGA's liability exceed the purchase price you paid for the product.

The purchaser must contact HT OMEGA, Inc or its regional representative to receive prior approval before returning a faulty unit. All such returns must be shipped to HT OMEGA, Inc in the original packaging including all accessories (documents, cables, software, etc.) along with the original sales receipt. Any costs associated with the return/shipping/insuring the package are the sole responsibility of the end-user. Shipments without freight prepaid will not be accepted. If the returned product is deemed to be defective, the repaired or replacement product will be returned at no extra charge via the carrier chosen by HT OMEGA, Inc.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

