

Telegesis		TG-RF-PM-501 ZigBee RangeFinder
ZigBee RangeFinder		Product Manual 0501 r2

Telegesis ZigBee RangeFinder

Product Manual



Rev: 2

Date: Jan 2013

Patent pending: GB1222898.7

Table of Contents

Table of Contents.....	2
Package Contents.....	5
Specifications.....	6
Handheld Terminal (HHT).....	6
Satellite (SAT-x)	6
Handheld Terminal Unit	7
Layout	7
Functionality	9
Start-up:.....	10
Menu Screens:.....	11
Normal Test Modes:.....	12
Continuous Test Modes:	16
Device Configurations:	22
Firmware Upgrades:	26
Data Logging:	29
Power	32
Batteries	32
Charging	32
Power Saving.....	32
Satellite Unit.....	33
Layout	33
Functionality	34
Buttons	34
LEDs.....	34
Power	35
Batteries	35
Power Consumption.....	35
Usage	35
System Topology.....	35
Workflow	37
Interpreting Test Results	38
RSSI Calculation.....	38
Packet Error Rate	38
Pass/Fail Criteria.....	38
Warranty	39

Compliance with Laws and Regulations	41
Disclaimer	41
Contact Information.....	41

Table of Figures

Figure 1: Package Contents.....	5
Figure 2: Handheld Terminal Front.....	7
Figure 3: Handheld Terminal Back.....	8
Figure 4: Product Label.....	9
Figure 5: Start-up Screen.....	10
Figure 6: Start-up Screen.....	11
Figure 7: Pre-Test Screen.....	12
Figure 8: Test Start Screen.....	13
Figure 9: Screen for Test A and B.....	14
Figure 10: Energy Scan Screen.....	15
Figure 11: Tx tone.....	16
Figure 12: Continuous Ping Configuration.....	17
Figure 13: Continuous Ping Results.....	18
Figure 14: Single Channel E-Scan.....	19
Figure 15 One hop configuration screen.....	20
Figure 16 One Hop Test Result Screens.....	21
Figure 17: Configurations Screen.....	23
Figure 18: Advanced Configurations Screen.....	24
Figure 19: Configurations Parameter Limits.....	25
Figure 20 Firmware Upgrade Screens.....	26
Figure 21 HHT Firmware Upgrade.....	26
Figure 22 HHT Firmware upgrade options.....	27
Figure 23 SAT Firmware Options.....	28
Figure 24 Data Logger Screen.....	29
Figure 25: Battery Symbol.....	32
Figure 26: Battery Charging Symbol.....	32
Figure 27: Satellite Front.....	33
Figure 28: Satellite Back.....	33
Figure 29: Satellite Product Label.....	34
Figure 30: Satellite LED States.....	34
Figure 31: A typical floor plan with Smart Energy equipment locations.....	35
Figure 32: RangeFinder locations: Electric meter, Gas meter and Kitchen work surface.....	36
Figure 33: Workflow.....	37

Package Contents

The package contains the following items,



Figure 1: Package Contents

- a) 1x Quick Start Guide
- b) 4x 1.5V AA Alkaline Batteries
- c) 2x Satellite Units SAT100
- d) 1x USB A to USB Micro Cable
- e) 1x Handheld Terminal ZHT100
- f) 2x 1.2V AA 2000mA Rechargeable Batteries
- g) 3x 2.4GHz Half-wave Antennas

Specifications

Handheld Terminal (HHT)

Model Number	ZHT100
RF Interface	2.4GHz IEEE802.15.4
RF Output Power	-9dBm to +8dBm
Antenna	Half-wave Dipole Antenna 2dBi Gain
Battery	2x 1.2V 2000mAH NiMH Rechargeable
Expected Battery Life	Tbd
Charging	5Volts @ 300mA via USB Micro Connector
Operating Temperature	0 to 50C
Humidity	95% TH Non-condensing
IP Rating	IP54 (subject to testing)

Satellite (SAT-x)

<i>Model Number</i>	SAT100
<i>RF Interface</i>	2.4GHz IEEE802.15.4
<i>RF Output Power</i>	-9dBm to +8dBm
<i>Antenna</i>	Half-wave Dipole Antenna 2dBi Gain
<i>Battery</i>	2x 1.5V AA Alkaline Batteries
<i>Expected Battery Life</i>	Tbd
<i>Operating Temperature</i>	0 to 50C
<i>Humidity</i>	95% TH Non-condensing
<i>IP Rating</i>	IP54 (subject to testing)

Handheld Terminal Unit

Layout




Figure 2: Handheld Terminal Front

Handheld Terminal Front

- (a) Product Model Number
- (b) LCD Display
- (c) Navigation Keys
- (d) Value Change Keys
- (e) Escape (Back) Key
- (f) Enter (Activate) Key
- (g) Power On/Off Key
- (h) USB-B Micro Connector




Figure 3: Handheld Terminal Back

Handheld Terminal Back

- (a) SMA Connector for Antenna
- (b) Product Label
- (c) 2x Screw for Battery Compartment
- (d) Battery Compartment
- (e) Dummy Battery (non-removable)
- (f) 2x Rechargeable Batteries




Figure 4: Product Label


Handheld Terminal Label

- (a) Product name “ZigBee RangeFinder” and product model number “ZHT100”
- (b) Serial number of the product
- (c) Operating parameters of the product
- (d) Warning
- (e) Barcode with following content:
 <Model>/L<Serial>
 e.g. ‘ZHT100/L9001’
- (f) Compliance marking for CE and WEEE
- (g) Manufacturer’s logo
- (h) Manufacturer’s contact information

Functionality

The Hand-Held Terminal (HHT) is the centre point of the system and all communication in the system is with respect to the HHT. The operator can set up parameters for tests, perform the tests and configure other test settings from the HHT. Below are the explanations of various options and output screens one can use on the HHT.

Start-up:

Upon pressing the power button  for four seconds the following screen will be displayed. This screen has useful information about the product such as the serial numbers of device and the firmware version of HHT. This screen is only displayed upon power up.







Figure 5: Start-up Screen

Menu Screens:

Menu items can be scrolled through using the navigations keys  and  Press  button to enter the selected menu item. The battery symbol shows the current battery status.




Figure 6: Start-up Screen

Normal Test Modes:

Pre-Test:

A Pre-Test is required before the 'Test A' or 'Test B' can be performed. The Pre-Test has the function of sanity checking the link between the HHT and the SAT units. Also performing Pre-Test will configure the current test settings in SAT units. A test carried out without running a Pre-Test may **NOT** present valid results. Any change in the Configuration settings should be followed by a Pre-Test.





Figure 7: Pre-Test Screen




The completion of the Pre-Test is indicated by a short beep from the built-in buzzer. To return to the main menu from the Pre-Test Screen please press 

Test A / Test B:

Telegesis Range Finder tests are designed to evaluate the suitability of deployment of a Smart Energy device which is why they focus on the ZigBee Smart Energy recommended RF channels in the 2.4GHz spectrum. Tests A and B are performed on ZigBee SE channels 11, 14, 15 and 19 during Test-A, while the remaining of SE channels 20, 24 and 25 are tested in Test-B.

Although the Rangefinder is designed to assist with ZSE installations, the [Continuous test](#) and [Energy scan](#) can be used to analyse the entire ZigBee 2.4GHz spectrum.

At the start of each test-A/B, countdown is activated to give a chance for the operator to put the HHT in place of simulated test device such as electricity meter and move away from the meter housing if necessary. This timer is configurable in the Configuration Menu.

To perform tests A or B, navigate to the menu item on [Menu Screen 1](#) using  and  keys and press  button for the test start screen to appear. Continuous and




Figure 8: Test Start Screen

Once the countdown has elapsed, the test starts and the test results are displayed for each channel for the test as the test progresses. The completion of the test is indicated by a short beep from the built-in buzzer. The display backlight changes to Red for test failure and to Blue colour if the test is a pass. Also the failed values will be inverted. For details of the Pass/Fail criteria please see section "Interpreting Test Results".








Figure 9: Screen for Test A and B

The completion of the Test-A/B is indicated by a short beep from the built-in buzzer. To return to the menu screen press 

Energy Scan:

The operator can make use of the Energy Scan of the network to get a measure of the noise or traffic present on a channel. Due to the dynamic nature of protocols (Wi-Fi, Bluetooth, ZigBee) each scan may show a different noise level even when done back to back. Each channel is scanned for noise for about 260mS. The results are painted for each channel as they become available.

-35dBm is considered to be very noisy and -85dBm is considered very quiet. The channels preferred by the ZigBee Smart Energy standard are highlighted in the test results. A sample of the test screen is shown below. To perform the Energy Scan, navigate to the Energy Scan menu item on [Menu Screen 1](#) using  and  keys and press  for the energy scan result graph as shown below to appear on screen.







Figure 10: Energy Scan Screen

Continuous Test Modes:

Tx Tone

The Transmit Tone option can be useful in situations in which one has to test immunity of the existing ZigBee network against noise from other devices operating on the same channel. This option will transmit a continuous tone on the user selected channel and power level. To transmit a tone on a channel, navigate to the Tx Tone menu option on [menu screen 2](#) using  and  keys and press  for following screen to appear.











Figure 11: Tx tone

Once on this screen, the user can scroll through parameters using the  and  keys, press  to be able to edit the transmit power and channel number on which to transmit a continuous tone which can be done using the  and  keys and again press  to set the new value.

After setting all the parameters, user will navigate to START option and press  to start transmitting the tone. The symbol on the right will start blinking to indicate that the tone is being transmitted on the set channel.

Ch Ping

This is another continuous mode tests which can be used whenever the user wants to find the best location to position the SAT-A and SAT-B units to get the optimum signal strength that can be achieved.




Figure 12: Continuous Ping Configuration

The main advantage of this test is the ability to set different test parameters such as Tx Power and RSSI threshold limits in all three (SAT-A; SAT-B and HHT) devices. This gives the operator flexibility to emulate different devices with different settings which can be the case in an actual ZigBee network.

This option can be used to measure the RSSI between the HHT and the SAT-A and/or SAT-B units. As with the other options navigate to the Ch Ping option on menu screen-2 using and keys and select the option using key. The single channel Ping Config screen as shown above will appear. There are different parameters as shown in the figure above which are to be set according to test requirements. To scroll through list of parameters, use and arrow keys. Press to edit, and to edit values and again press to set the parameter value for the continuous Ping test to be performed.

Once all the parameter values are set press navigate to START and press **OK** to start the test. Now the test will run for the time in sec set for DUR parameter. If the time set is 0 then the test will keep on running and updating the display with the Single Channel Ping Results screen unless stopped manually by pressing **ESC** key.







Figure 13: Continuous Ping Results

Ch E-Scan

This channel scan will show the dynamic values of the current noise levels in the selected channel. To select this single channel E-Scan option, navigate to the option on menu screen 2 using  and  keys and press . The following screen will appear.














Figure 14: Single Channel E-Scan

Once on this screen, scroll through the list of channels (from CH-11 to CH-26) on which the noise scan is to be done by using  and  keys and again press  to set the desired channel. The scan is started by navigating to START and pressing . The dynamic energy levels on that channel will be displayed on the screen as shown in the figure above.

One Hop Test

The One Hop test is a very useful test in systems that require a repeater in between two nodes. The SAT-A will operate as a repeater (RTR) between the HHT and SAT-B. All messages from the HHT which are directed towards SAT-B will be relayed by the RTR. This test will help finding the best possible location for the repeater to be placed and simultaneously tests the link between nodes through the repeater. The following configuration screen is displayed when the one hop test option is selected. The configuration screen allows the operator to modify the test parameters like Tx Power, RSSI threshold, Channel used for test and the duration of test. To scroll through list of parameters, use  and  arrow keys. Press  to edit,  and  to edit values and then press  to set the parameter value for the current session of test.





Figure 15 One hop configuration screen

Once parameters are set navigate to the start button on the screen and press  to start the test. At this point the one hop results screen as shown below will be displayed on screen. Depending on the test state one of the following result screens will be displayed.




Figure 16 One Hop Test Result Screens

Screen-1:

This is the initialization state of the test when there is no one hop link established between HHT and SAT-B as shown in Screen-1. Initially when the devices (RTR or SAT) are out of range of the HHT or are not turned on the HHT cannot pass on the message to the SAT-B. Hence the link status shows a broken link between the HHT and RTR and SAT-B.


Screen-2:

The test will remain in the initialization state and periodically retry to establish the link (indicated by periodic beeps). To run the test, turn on the RTR and bring it closer to the HHT until you see Screen-2. When the HHT can communicate with RTR Screen-2 will be displayed which indicates that the link between HHT and RTR is established but the link between HHT and SAT-B is not established as the RTR cannot pass on the messages to the SAT-B. The HHT will try to continuously establish one hop link until successful when screen 3 is displayed.

Screen-3:






When Screen-2 appears, turn on the SAT-B and bring it closer to the RTR so that it can get the messages for the RTR. Once that happens Screen-3 will appear and the HHT will set the test channel on all devices and start pinging messages to SAT-B for the set test duration and update the RSSI values.

As the test is running the operator can move the devices to get a measure of the optimum range between devices. If any of the devices move outside the pre-configured RSSI limits or if some packets are missing the HHT will beep to indicate this and the operator can react accordingly.

To end the test press  key and the HHT will send a message to end the test on both RTR and SAT-B units. Until both units are in range the end message will not carry forward to SAT-B and the HHT will keep retrying which is indicated by periodic beeps on the HHT.

Device Configurations:




Single Satellite Configuration:

In some cases it may be necessary to run the test using only one Satellite unit. Such a situation might exist where only an electricity meter is being installed together with an IHD. In such cases it is possible to select the Satellite unit labelled IHD only to be used for test. To do so one has to go to the Home Screen and scroll to (using  and ) item **I G** and press keys  or  to select between **I** or **I G** and press  to save the setting. This setting is volatile and will revert to **I G** once the device is turned off.

Configuration Settings:

The Configuration Settings are the important device settings that are used by the HHT and SAT units while performing the tests. The Telegesis Range Finder is designed to be able to simulate any actual ZigBee SE device – such as IHD's, GAS meters, ESI's etc. All these devices may operate at different power levels and may be able to operate at different RSSI thresholds in an actual SE network. The Configuration Settings menu provides the way to introduce different settings for different devices settings at the time of test.

There are 10 pre-stored device profiles that can be used by the operator on site. The values within these settings cannot be changed without inputting a PIN number which is a 4 digit code. This pass code can be restricted to authorised technicians to prevent accidental entering of incorrect parameters by the operator in the field.

The Configuration Settings screen provides options for the user to change the test parameters. The Operator can navigate through the options using  and  keys may press  to modify a setting. The Configuration screen is shown below,













Figure 17: Configurations Screen

- The Countdown Timer value is set to a default of 5 seconds; the operator can change it to values between 10 and 120 seconds. The change made is volatile and will revert back to the default value¹ after power-off.
- A four digit PIN code allows access to advanced settings. The factory programmed PIN code is 1985 which can be entered using keys , ,  and  and submitted using the  key. This PIN can be reset to default or changed to a new PIN via a serial command.
- The Operator can select the configurations settings from previously stored settings. Memory required for 10 profiles reserved in non-volatile memory. These profiles can be edited and stored by PIN protected serial commands. To set configuration a particular settings from a particular profile and navigate to the profile for device using , , and then press . Then scroll through list of profile and press  to set the device with settings from selected profile.

¹ The default CDT value can be changed in the advance configuration settings.

Advanced Configurations Settings:

The Advance Configurations Settings Screen is visible only after entering the correct device PIN.

















Figure 18: Advanced Configurations Screen

To display the settings of different profiles stored in the HHT navigate to the Profile section using  and  keys, then use  and  keys to scroll through the 10 profile settings stored into HHT. To change a particular parameter of the displayed profile use keys ,  to navigate to the parameter and then press  to start modifying it using keys , ,  and , and press  to save the settings. To cancel the changes while modifying press . The parameters are explained below.

- (a) IHD Serial: Serial number of Satellite unit labelled as IHD. Only the Satellite with matching serial number will be used in the test.
- (b) GAS Serial: Serial number of Satellite unit labelled as GAS. Only the Satellite with matching serial number will be used in the test.
- (c) Profile Name: Is the name of the profile out of the 10 stored profiles, whose settings are currently displayed on screen.
- (d) Countdown Timer: This is the default setting of the Countdown time which is non-volatile and will be used each time the unit is turned on. The valid limit for the timer is 5 to 120 seconds.

- (e) Packet Number: Number of packets to be sent to a Satellite on a given channel during the test, the selection is available between 50 to 100 packets and can be changed in steps of 5 packets.
- (f) Packet Interval: The time gap between two consecutive packets sent during a test. The minimum interval can be 10mS and the maximum is 25mS and can be changed in steps of 5mS.
- (g) TX Power: Transmit power level while sending the packets, the power setting available is from +8dBm to -9dBm in steps of 1dBm.
- (h) Receive Threshold: The minimum receive signal strength for a packet to be considered valid for test purpose. The limit available is -85dBm to -45dBm changeable in steps of 1dBm.
- (i) Packet Error Rate: Maximum allowed packet error rate for a successful test. The limits are 2% to 10% maximum - changeable in 1% steps.

Label	Parameter	Minimum Value	Maximum Value	Change Steps
CDT	Countdown Timer	5 Seconds	120 sec	1 sec
IHD	IHD Serial	0000	65535	1
GAS	GAS Serial	0000	65535	1
PN	Packet Number	50	100	5
PI	Packet Interval	10mS	25mS	5mS
TX	TX Power	-9dBm	8dBm	1dBm
RTH	Receive Threshold	-85dBm	-45dBm	1dBm
PER	Packet Error Rate	2%	10%	1%

Figure 19: Configurations Parameter Limits

The mechanism by which the above parameters affect the testing is explained in the section “Interpreting Test Results”.

Firmware Upgrades:

The Telegesis Range Finder comes with an Over-The-Air (OTA) Bootloader. This enables the HHT to upgrade its own firmware via the USB link and also remotely upgrade the firmware of the SAT units. The Firmware Upgrades function is PIN protected for security.





Figure 20 Firmware Upgrade Screens

Once the device PIN is entered correctly the Firmware Upgrade screen will give the options to select a device to perform the upgrade.

Upgrading the HHT unit:

Select the HHT unit for upgrade by navigating to it and pressing  key. That will start the bootloader in serial mode and the new firmware image can be transferred via Xmodem at 115200 8N1 baud using the Telegesis Terminal or any other terminal program that supports Xmodem. The display on the HHT unit will show the following screen and the backlight will start to blink with red and green lights indicating that the bootloader is active and waiting for new firmware image.





Figure 21 HHT Firmware Upgrade

- Now Press Enter key on host PC to get the bootloader options on the terminal as shown in the fig->



- To upload the new firmware image press '1' on the host PC, which will put the bootloader in Xmodem receive mode.
- Indicated by outputting 'C' on the terminal as shown in the fig->.
- Now Transfer the new firmware *.ebl file to the HHT unit.
- Once the file is transferred press '2' on host PC to run the new firmware.






Figure 22 HHT Firmware upgrade options

Upgrading the SAT units:

It is possible to perform OTA firmware upgrades of the SAT units. The upgrade image (*.ebi file) will be passed to the HHT to send it across to the SAT unit. Select the IHD/GAS unit for upgrade by navigating to the particular option on the Firmware Upgrade Screen and press  key. That will start the bootloader in OTA pass-through mode and the new firmware image can be transferred to the remote IHD or GAS unit over the air via HHT unit using Xmodem protocol at 115200 baud 8N1.

- When the remote SAT unit is selected for OTA firmware upgrade, the red LED starts flashing continuously.
- And the HHT outputs 'C' as shown in fig-> the terminal indicating that it expects the image to be transferred to SAT unit.
- Transfer the firmware upgrade *.ebi file to the HHT using Xmodem and the HHT will send it to the remote SAT unit.
- When the new firmware image is being transferred the red LED on the SAT unit stops blinking and the green LED starts flashing.



- If for any reason (eg. Battery on SAT dying while transfer of file or ZigBee link broken), the SAT unit will remain in the same bootload mode with red LED flashing. The HHT will timeout after 30 sec and send out a message on the terminal as shown in fig->
- The entire file needs to be transferred again to the SAT unit.




Figure 23 SAT Firmware Options

Data Logging:

The test results of Test-A/B and Energy scan results will be automatically logged into an on-board serial flash of 8MBits if the data logging feature is included into the device. The results will be stored along with the device configurations settings at the time of test. The Data Logging screen will pop up at every turn-on just after the Start-up screen to give a chance for user to enter the site ID before the start of tests. This screen can also be accessed via the data logger option on [menu screen 2](#). The logger will start with a new record and increment record counter every time the site ID is changed.




Figure 24 Data Logger Screen

Record Main Header

The record header will be of following type:

```
//Record size
int16u recordSize;
//Main record header
typedef struct {
    int8u recordSiteId[16];
    int16u recordMainNumber;
}recordMainHeader;
```

Where,

recordSize – This is the total size of data collected at each site location. recordSize is the addition of the recordMainHeader bytes; recordSubHeader bytes; records. Since there can be any number of tests performed at any given site, the recordSize is variable hence it is calculated at the end of the last test carried out at the site (i.e. when the new site ID is entered by the user). But it is stored at the start of each record before the site ID in order to make scan through records faster.

recordMainHeader – This is the main record header at the start of each set of records collected at new site location.

recordSiteID[16] – This will be an 16 byte field used to store the site ID which will be entered by the user manually through arrow keys on the HHT. The first 8 bytes of the Site ID will be fixed and can be used as a Start Of Record (SOR) pointer.

recordMainNumber - It can be the Record ID or just a simple record counter which increments after each record stored in the flash. This number will increment when the test is done at new site location.

Record Sub Header

```
//Sub Record Header
Typedef struct{
    int8u recordSubNumber;
    int8u recordType;
    int8u recordLength;
    testSettings
    recordTestSettings;
}recordSubHeader;
```

recordSubHeader – This header will be at the start of each individual record for a test conducted at same site location.

recordSubNumber – The value recordSubNumber will indicate the record number for the current site and will increment after each test performed at the same site.

recordType – The one byte recordType identifier which will indicate which type of test results is stored in the record field.

recordLength – This value will be the actual length of the record excluding the record header bytes as the record header will be of fixed length.

recordTestSettings – This will be the configuration settings set in the HHT at the time of current test.

Record Structures

Test A record

Sub Header

recordType – 0x01
recordLength – 28
recordTestSettings –

```
//testSettings for Test A and Test B
Typedef struct{
    int8u PingNumber;
    int8u PingInterval;
    int8u perThreshold;
    int8s transmitPowerHHT;
    int8s transmitPowerA;
    int8s transmitPowerB;
    int8s rssiThresholdHHT;
    int8s rssiThresholdA;
    int8s rssiThresholdB;
}testSettings;
```

Record data

```
//test Records for Test A
typedef struct{
    int8u satARssi [4][2];
    int8u satBRssi [4][2];
    int8u perA[4];
    int8u perB[4];
    int8u testResult[4];
}recordTestARecords;
```

Column-0 – RSSI received at the SAT- A or SAT-B end

Column-1 – RSSI received by HHT

Row-0 – CH11 result

Row-1 – CH14 result

Row-2 – CH15 result

Row-3 – CH19 result

Test B record

Sub header

recordType – 0x02

recordLength – 21

Record Data

```
//test Records for Test B
typedef struct{
    int8u satARssi[3][2];
    int8u satBRssi[3][2];
    int8u perA[3];
    int8u perB[3];
    int8u testResult[3];
}recordTestBRecords;
```

Column-0 – RSSI received at the SAT- A or SAT-B end

Column-1 – RSSI received by the HHT

Row-0 – CH20 result

Row-1 – CH24 result

Row-2 – CH25 result

Energy Scan Record

recordType – 0x03

recordLength – 16

Record Data:

```
//test Record for Test B
typedef struct{
    int8u energy[16];
}EScanRecords;
```

The energy results array will hold the values of Energy scan on all the ZigBee channels 11-26

Power

The HHT is powered by rechargeable NiMH batteries which are charged through the USB connection.

Batteries

The unit takes two 1.2 V 2000mAh NiMH batteries. To conserve the power consumption the unit will turn itself off after a period of inactivity. The battery compartment is accessible on the back side of the HHT and can be opened using a coin as shown in the Layout section. The battery compartment is designed to take 3 AA cells hence the extra space is blanked off using a dummy pass-through AA cell which should not be removed. The battery state is shown on the Home screen using the following symbol,



Figure 25: Battery Symbol

The above symbol is showing 50% battery charge remaining.

Charging

The HHT can be charged or powered using the USB port connection. The USB connector is a USB “B” Micro socket. The detection of the USB power source is indicated by a beep from the built-in buzzer. The HHT does not go to sleep while it is powered from USB power source. The charger charges the 2000mAh batteries at C/10 rate and it terminates the charge via voltage detection and a 12 hour timer. The power requirement for charging as well as operating the unit is 1.5Watts at 5 Volts. The charging state is shown on the Home screen by showing the following the symbol,




Figure 26: Battery Charging Symbol

The charging symbol shown above is replaced with the battery capacity remaining symbol as shown in Figure 25: Battery Symbol once the charging is finished.

Power Saving

The HHT incorporates several ways to reduce power consumption and extend battery life. Most of the power is consumed by the LED backlight for the screen so it is important to turn off the backlight when not needed; the backlight is turned off in the following instances:

- a) No key press by the operator for 10 seconds
- b) 60 Seconds after a test has been completed

Moreover the unit is turned off after a period of inactivity of 15 minutes to save power. This 15 minutes is counted from the time the unit is turned on using the  and will be extended by 5 minutes if the user presses a key or a test is underway and the unit is in the last 5 minutes of the 15 minute wake period.

Satellite Unit

Layout




Figure 27: Satellite Front

- (a) Model number: SAT100
- (b) Power Button to turn the unit On or Off
- (c) Red/Green LED to indicate the operation state of the unit




Figure 28: Satellite Back

- (a) SMA connector for Antenna
- (b) Product Label
- (c) Battery Compartment



Figure 29: Satellite Product Label

- (a) Product name
- (b) Module number of Satellite (SAT100)
- (c) Serial number of the product
- (d) Operating parameters of the product
- (e) Warning
- (f) Barcode with following content:
<Model>/L<Serial>
e.g. 'SAT100/L157'
- (g) Manufacturer's contact information
- (h) Compliance marking for CE and WEEE
- (i) Manufacturer's logo

Functionality

The Satellite units (SAT-A/B) are always listening to commands from the HHT to which they are paired to and respond with the information required to calculate the results for various tests performed by the HHT. There is an ON/OFF button for power ON/OFF and status LED's for SAT activity indication.

Buttons

There is only button on the Satellite which is the Power Button as shown in Figure 266. The Power Button needs to be pressed down for 3 seconds for it to take effect. When the Power Button is pressed, the LED indicator turns to solid RED colour and then turns off completely if the power is switched off or changes to flashing Red or Green if it is turned on.

LEDs

The indicator LED has two colours and it can represent following states for the Satellite.

Red LED	Green LED	Satellite State
ON	OFF	Power Button is pressed.
OFF	Flashing 1 flash/sec	SAT unit ON and Battery State healthy.
Flashing 1 flash/sec	OFF	SAT ON and Battery Low.
Flashing 2 flash/sec	OFF	SAT unit waiting for upgrade image.
ON	Flashing 2 flash/sec	SAT receiving new image from HHT

Figure 30: Satellite LED States

Power

Batteries

The Satellite is powered by two 1.5 V AA Alkaline batteries. The battery state is indicated by the flashing Red for low and flashing Green for good battery state. The percentage battery capacity remaining is also sent to the HHT as part of the Pre-Test and is shown on the Pre-Test screen (see Figure 7).

Power Consumption

To conserve the power the Satellite units are turned off after 15 minutes of wakeup period. If the Satellite receives any radio message from the HHT in the last 15 minutes of the wakeup period then it extends the wakeup period by 5 more minutes.

Nominal power consumed by the Satellite while it is turned on is 100mW.

Usage

System Topology

In a typical ZigBee Smart Energy installation it is expected the Electric and Gas meter will always be static whereas the IHD can move around. It is also expected that in some cases there will be no Gas meter present. This gives us the Electricity meter as a static element which will always be present. In many cases this is also the ESI for the Smart Energy network. The HHT is the centre point of the ZigBee RangeFinder and all the measurements are made with respect to the HHT, hence it makes sense to put the HHT in place where the Electricity meter will be installed and place the two Satellites in location where IHD and Gas meter are expected to be placed. A typical setup is shown below,




Figure 31: A typical floor plan with Smart Energy equipment locations

The Electricity and Gas meter locations are fixed whereas the IHD can be in any location such as indicated by points A,B,C and D in the above floor plan.



Figure 32: RangeFinder locations: Electric meter, Gas meter and Kitchen work surface

In the above picture the HHT is placed adjacent to the Electricity meter; the Satellite unit labelled GAS is placed on the GAS meter and the Satellite unit labelled IHD is placed on the kitchen work surface. The tests are then run on the HHT to make sure that all simulated devices will be able to communicate with each other.

Workflow

The following flowchart shows the expected procedural flow for performing a test.



Figure 33: Workflow

Interpreting Test Results

The RF over-the-air transmission mechanism, verified by observation, suggests that given a large enough sample size of RF packets the RSSI value does not change any more than a few dBm provided that the physical environment around the test units does not change during the test. If there is RF interference present during the test then it is more likely to cause failure of the packets to be received, decoded properly or a failure to pass the CRC test than to affect the RSSI value. Hence, it is important to take into account both RSSI values as well as Packet Error Rate when deciding the quality of the link.

A high number of packets (e.g. 50 packets 10millisecond apart) will be sent to the Satellite units from the Handheld unit which will echo the packets back and the results of the echoed-back packet will be used to calculate the *RSSI* , *PER* and eventually a PASS or FAIL result.

RSSI Calculation

The RSSI calculation is a mixture of Median and Mode and will be calculated as follows,

n = number of RSSI samples taken

S_n = value of n th RSSI sample

e = error margin (dBm)

* n samples will be taken and S_n stored in memory

* For each unique ' S_n ' the occurrence of ' $S_n \square e$ ' will be calculated and the highest occurring value shall be used as the *RSSI* value

Packet Error Rate

An ' n ' number of packets will be sent ' t ' seconds apart

Responses will be received and counted against the number sent

A packet error rate (*PER*) will be calculated in terms of percentage packet loss

Pass/Fail Criteria

For a Pass the *RSSI* and *PER* parameters needs to be following,

- 1) $NUM_BAD_RSSI_VALUES < RSSI_BAD_NUM_THRESHOLD$
- 2) $RSSI > RSSI_THRESHOLD$
- 3) $PER < PER_THRESHOLD$

Where:

The *NUM_BAD_RSSI_VALUES* is the total number of packets received with an RSSI value of less than *RSSI_THRESHOLD*

The *RSSI_BAD_NUM_THRESHOLD* is 10% (factory default) of total packets sent ' n '

The *RSSI_THRESHOLD* is -85dBm as factory default

The *PER_THRESHOLD* factory default value is 10%

The above parameters can be changed from their factory default to user-specified in the Advanced Config menu.

Warranty

1. Telegesis warrants that at the date of delivery the Goods will conform in all material respects to any written specification published or provided by Telegesis and that for the periods set out below in respect of each product type the Goods will be free from defects in workmanship and materials under normal use and service. The Buyer must notify Telegesis of any defect in writing. Telegesis's obligation under this warranty will not arise until the Buyer returns the defective Goods at its own expense and risk, to Telegesis. Telegesis sole obligation under this warranty shall be at its option to replace or repair without charge such defective Goods or component parts thereof. Any replacement of Goods or component parts under this warranty shall not extend the period of warranty beyond that of the goods or component parts so replaced.
2. All Hardware is supplied with one year return to base warranty unless indicated otherwise. All Software is supplied with a 90-day warranty period.
3. With respect to any computer software comprised in the Goods supplied by Telegesis any defects arising after expiry of the warranty period referred to above should be notified to Telegesis in writing, Telegesis may at its discretion endeavour to correct any such defects but Telegesis gives no warranty that any such defects can be corrected or that defects will be corrected within a particular time.
4. Telegesis shall not be liable hereunder:
 - a) If the Goods alleged to be defective have been repaired or altered by any person other than Telegesis designated personnel or authorised representative or other person approved by Telegesis in writing; or
 - b) Where testing or examination by Telegesis reveals any alleged defect in the goods to have been caused by the buyers misuse, neglect, improper installation, failure to follow instructions (whether oral or in writing), or the supply by the Buyer of incorrect or inadequate instructions or information with the regards to the design of any Goods or to have been caused by any similar equipment to which the Goods are attached or in which the Goods are incorporated or any cause beyond the range of intended use of the Goods or by accident, fire or other hazard; or
 - c) Where component parts alleged to be defective were not manufactured by Telegesis but were included in the Goods at the request of the Buyer, in which case the Buyer shall only be entitled to the benefit of any such warranty or guarantee as is given by the manufacturer or supplier of such parts to Telegesis.

5. If the goods are to be manufactured or any process is to be applied to them by Telegesis in accordance with a specification submitted by the Buyer, the Buyer shall indemnify Telegesis against all loss, damages, costs and expenses awarded against or incurred by Telegesis in connection with or paid or agreed to be paid by Telegesis in settlement of any claim which results from Telegesis's use of the Buyers specification, including but not limited to any claim for infringement of any patent, copyright, design, trade mark or other intellectual property rights of any other person.
6. Telegesis's liability hereunder shall be in lieu of any other representation (unless fraudulent), warranty or condition, expressed or implied by law or otherwise with respect to the goods or any liability imposed by common law, statute or otherwise and Telegesis hereby excludes all such representations (unless fraudulent), warranties and conditions and shall not be liable to the Buyer for any loss or damage whatsoever (including without prejudice to generality of the foregoing any liability in contract, negligence, or any other tort for indirect consequential or economic loss or for loss of profit or opportunity of any kind) arising directly or indirectly in connection with the contract, the Goods or otherwise except insofar as any exclusion or limitations of Telegesis liability hereunder is prohibited, void or enforceable by law.
7. Telegesis shall not be responsible in any manner whatsoever for any software, information or memory data stored on or integrated with any of the Goods returned to Telegesis for repair or replacement under this warranty.
8. Without prejudice to any other provision in these Terms, in any event Telegesis's total liability for any one claim or for the total of all claims arising from one act of default on Telegesis's part (whether arising from Telegesis's negligence or otherwise) shall not exceed the purchase price of the Goods the subject matter of any claim but nothing herein shall limit or exclude Telegesis liability for death or personal injury caused by Telegesis's negligence or Telegesis's liability for fraudulent r misrepresentation.
9. Where the buyer deals as a consumer within the meaning of the unfair contract Terms Act 1977 nothing in these terms shall restrict or exclude any liability of Telegesis for breach of its implied undertakings as to conformity of the goods with description or sample or as to their quality or fitness for the purpose.
10. In the case of a consumer transaction nothing in these terms sham affect the statutory rights of the Buyer as defined in the Consumer Transaction (Restrictions on Statements) Order 1976 (as mentioned).
11. The period or terms of the warranty contained in this clause shall only be varied or extended where Telegesis has granted the Buyer an Extended Warranty.

Compliance with Laws and Regulations

Any Buyer of Telegesis products (Goods) will not knowingly sell the Goods to any person where such sale may be or may result in a sale to an end user that may put Telegesis in breach of any laws, embargoes or regulations from time to time or any relevant jurisdiction. The Buyer hereby certifies that no Goods will be exported directly or indirectly outside the United Kingdom unless the appropriate prior authorisation to such export has been obtained from the Department of Trade and Industry, London, and/or (where applicable) the Office of Export Administration of the US Department of Commerce.

Disclaimer

Product and Company names and logos referenced may either be trademarks or registered trademarks of their respective companies. We reserve the right to make modifications and/or improvements without prior notification. All information is correct at time of issue. Telegesis (UK) Ltd. does not convey any license under its patent rights or assume any responsibility for the use of the described product.

This device should not be used without proper consideration and design of associated system architecture and redundant safety features in applications where failure may result in death or injury. The manufacturer accepts no responsibility for injury, death or loss human or material caused by the use or misuse of this device

Contact Information

Website: www.telegesis.com
E-mail sales@telegesis.com
Telegesis (UK) Limited
Abbey Barn Business Centre
Abbey Barn Lane
High Wycombe
Bucks
HP10 9QQ