

Disney<sup>+</sup>mobile<sup>SM</sup>

# USER MANUAL

DM-S105 / DM-S110



SAMSUNG



## INTELLECTUAL PROPERTY

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating there to (the "Phone System"), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

### **Samsung Telecommunications America (STA), L.P.**

Headquarters:	Customer Care Center:
1301 E. Lookout Drive	1000 Klein St.
Richardson, TX 75082	Plano, TX 75074
	Toll Free Tel: 1.888.987.HELP (4357)

Internet Address: <http://www.samsungusa.com>

©2007 Samsung Telecommunications America, L.P. is a registered trademark of Samsung Electronics America, Inc. and its related entities.

Do you have questions about your Samsung Mobile Phone?

For 24-hour information and assistance, we offer a new FAQ/ARS System (Automated Response System) at: [www.samsungwireless.com/support](http://www.samsungwireless.com/support).

Printed in China.

RSA® is a registered Trademark RSA Security, Inc.

## DISCLAIMER OF WARRANTIES;

### EXCLUSION OF LIABILITY

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS," AND NEITHER SAMSUNG NOR DISNEY MOBILE MAKE ANY EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION, OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, NEITHER SAMSUNG NOR DISNEY MOBILE SHALL BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

# TABLE OF CONTENTS

<b>SECTION 1. GETTING STARTED</b>	5
Important Safety Information	5
Battery Use and Care	5
Turning the Phone On/Off	6
Setting Up Your Voicemail	7
<b>SECTION 2. UNDERSTANDING YOUR PHONE</b>	8
Key Features	8
Keypad Functions	9
Display Screens and Icons	10
Command Keys	11
Your Phone's Modes	13
<b>SECTION 3. CALL FUNCTIONS</b>	15
Making a Call	15
Adjusting the Call Volume	16
Answering a Call	16
In Use Menu	16
Call History	16
Silent Mode	18
Selecting Functions and Options	18
<b>SECTION 4. MENU NAVIGATION</b>	20
Menu Navigation	20
Menu Summary	20
<b>SECTION 5. ENTERING TEXT</b>	22
Changing the Text Entry Mode	22
Using T9® Mode	22
Using Abc Mode	23
Entering Numbers	23
Entering Symbols	23
Entering Quicknotes	23
Entering Emoticons	24

<b>SECTION 6. CONTACTS</b>	25
Accessing Contacts	25
Finding a Contacts Entry	25
Adding a New Contacts Entry	26
Editing a Contacts Entry	27
Saving a Number After a Call	30
Contact Groups	31
Speed Dial	32
Services	33
<b>SECTION 7. MESSAGING</b>	34
Accessing Messaging	34
Creating and Sending Messages	34
Receiving Text Messages	36
Receiving Pix (Picture) Messages	36
Sending Pix Messages	37
Inbox	37
Outbox and Drafts	38
Voicemail	39
<b>SECTION 8. FAMILY CENTER™</b>	40
Family Center™ Overview	40
Family Locator™ Service	41
Family Monitor™ Service	42
Call Control Features	44
Family Alert!™ Service	46

<b>SECTION 9. ENTERTAINMENT</b>	49
Entertainment Overview	49
Shopping	49
Previewing	50
Purchasing and Downloading	50
My Ringtones	51
My Themes	52
My Images	52
My Games	55
My Applications	55
My Subscriptions	56
Disney Zone	56
 <b>SECTION 10. TOOLBOX: MY PROFILE, CAMERA, VOICE RECORDER</b>	 57
My Profile	57
Camera	57
Camera Options	59
Voice Recorder	63
 <b>SECTION 11. TOOLBOX: TOOLS</b>	 65
Bluetooth®	65
Calendar	66
Alarm Clock	68
Notepad	69
Calculator	70
Stopwatch	70
World Clock	70

<b>SECTION 12. TOOLBOX: SETTINGS</b>	71
Display	71
Sound	72
Roaming	74
Messaging	74
Security	75
Setup/Others	78
Phone Info	82

<b>SECTION 13. HEALTH AND SAFETY INFORMATION</b>	83
Health and Safety Information	83
UL Certified Travel Adapter	84
Consumer Information on Wireless Phones	84
Road Safety	88
Operating Environment	89
Using Your Phone Near Other Electronic Devices	89
Potentially Explosive Environments	90
Emergency Calls	90
FCC Notice and Cautions	90
Other Important Safety Information	91
Product Performance	91
Availability of Various Features/Ringtones	92
Battery Standby and Talk Time	92
Battery Precautions	92
Care and Maintenance	93

<b>SECTION 14. WARRANTY INFORMATION</b>	94
Standard Limited Warranty	94

<b>INDEX</b>	96
--------------	----



# SECTION 1

## GETTING STARTED

### Topics Covered

- Important Safety Information
- Battery Use and Care
- Turning the Phone On/Off
- Setting Up Your Voicemail

### IMPORTANT SAFETY INFORMATION

Please see [Section 13, "Health and Safety Information,"](#) for important safety information that you should know before using your DM-S105/DM-S110 phone.



## BATTERY USE AND CARE

### Installing the Battery

**NOTE:** YOUR PHONE COMES PACKAGED WITH A PARTIALLY CHARGED RECHARGEABLE STANDARD LI-ION BATTERY AND TRAVEL ADAPTER.


**IMPORTANT!** YOU MUST FULLY CHARGE THE BATTERY BEFORE YOU USE YOUR PHONE; OTHERWISE, YOU COULD DAMAGE THE BATTERY. A FULLY DISCHARGED BATTERY REQUIRES UP TO 4 HOURS OF CHARGE TIME.

1. Pressing down on the release (1), remove the battery cover (located on the back of the phone) by sliding it in the direction of the arrow (2).
2. Carefully lift the battery cover away from the phone.
3. Slide the battery into the compartment so that the tabs on the end align with the slots at the bottom of the phone, making sure to line up the gold contacts (3).
4. Gently press down on the battery until it snaps into place (4).
5. Replace the cover by lining up the tabs and sliding the cover up until it snaps into place (5).



## Removing the Battery

1. Follow steps 1 and 2 from “Installing the Battery” on page 5.
2. Grip the battery from the side (1) and lift it up and out (2).



## Charging the Battery

Your phone is powered by a rechargeable standard Lithium-ion battery.

A travel adapter comes with your phone for charging the battery. Use only approved batteries and chargers.

**NOTE:** YOU MUST FULLY CHARGE THE BATTERY BEFORE USING YOUR PHONE FOR THE FIRST TIME. A FULLY DISCHARGED BATTERY REQUIRES UP TO 4 HOURS OF CHARGE TIME.

1. With the battery installed, plug the connector of the travel adapter into the jack on the side of the phone.



**IMPORTANT!** THE ILLUSTRATION AT RIGHT DISPLAYS THE **CORRECT** METHOD FOR CONNECTING THE CHARGER. IF ATTEMPTED INCORRECTLY, DAMAGE TO THE ACCESSORY PORT OCCURS AND VOIDS THE PHONE'S WARRANTY.

2. Plug the adapter into a standard AC wall outlet.
3. When charging is finished, unplug the adapter from the power outlet and disconnect it from the phone.

**IMPORTANT!** ALWAYS UNPLUG THE ADAPTER BEFORE YOU REMOVE THE BATTERY FROM THE PHONE DURING CHARGING; OTHERWISE, THE PHONE COULD BE DAMAGED

## Low Battery Indicator

When the battery is weak, a warning tone sounds and the “Warning Low Battery” message repeats at regular intervals on the display. When this happens, your phone turns off the backlight to conserve the remaining battery power.

When the battery level becomes too low, the phone automatically turns off.



## TURNING THE PHONE ON/OFF


1. Press and hold the key until the Disney Mobile logo is displayed.
2. If you are prompted to enter your Lock Code, enter the Lock Code and press the OK key (). Your Lock Code is preset to the last four digits of your mobile phone number. Refer to “Security” on page 75 for more information.

**NOTE:** THE DISPLAY LANGUAGE IS PRESET TO ENGLISH AT THE FACTORY. TO CHANGE THE LANGUAGE, USE THE **LANGUAGE** MENU. REFER TO “LANGUAGE” ON PAGE 80 FOR MORE INFORMATION.

3. To turn off the phone, press and hold the key until the Disney Mobile logo is displayed.




## SETTING UP YOUR VOICEMAIL

For new users, follow the instructions below to set up Voicemail:

1. In **Idle** mode, press and hold the  key on the keypad. You may be prompted to enter your Pass Code.
2. Follow the tutorial voice prompts.

## Accessing Your Voicemail

You can access your Voicemail by pressing and holding the  key on the keypad or by going to the menu. To access Voicemail using the menu:

1. In **Idle** mode, press the **Menu** soft key ().
2. Highlight the **Messaging** option and press .
3. Highlight the **Voicemail** option and press .
4. When connected, follow the voice prompts.

## SECTION 2

### UNDERSTANDING YOUR PHONE

#### Topics Covered

- Key Features
- Keypad Functions
- Display Screens and Icons
- Command Keys
- Your Phone's Modes

#### KEY FEATURES

Your new DM-S105/DM-S110 phone is lightweight, easy to use, and offers outstanding features, including:

- User-friendly, menu-driven access to features and options.
- VGA Camera.
- Text and multimedia messaging.
- Bluetooth® Wireless Technology.
- Ability to record voice messages and special greetings.
- Disney Mobile family features.
- Ability to download and personalize your phone with ringtones, games, images, themes, and applications.



## KEYPAD FUNCTIONS

Refer to phone illustrations.

1. **Earpiece/Speaker** — Allows you to hear the other caller and the ringtones and other sounds available on your phone.
2. **Display Screen** — Shows the received signal strength, battery level, the date and time, and other phone status information.
3. **NAV KEY** — Within a menu, allows you to scroll through menu items. In **Idle** mode:
  - **Down** — Access Menu
  - **Up** — Access Entertainment
  - **Left** — Access Family Center
  - **Right** — Access MessagingWhen entering text, moves the cursor to the left or right.
4. **OK Key** — In **Idle** mode, launches the main menu. Within a menu, selects the highlighted menu option.
5. **Left Soft Key** — Performs the functions indicated by the text on the bottom left line of the display.
6. **Volume Key** — In **Idle** mode, lets you adjust the ringer level. During a call, lets you adjust the earpiece/speaker volume. When receiving a call, lets you mute the ringtone. Can also be used to scroll through menus.
7. **TALK Key** — Lets you place or receive calls. In **Idle** mode, displays the **Recent** calls log.
8. **Voicemail Key** — In **Idle** mode, accesses voice mail when held down.
9. **Numeric Keypad** — Enters numbers, letters, and some special characters.

10. **Shift/Star Key** — In **Idle** mode, pressing and holding this key enables/disables the **Silent: All** mode.
11. **Microphone** — Used for voice calls and voice recordings.
12. **Next/Plus Code Dialing Key** — In **Idle** mode, press and hold this key to insert a plus sign in the dialing screen for international dialing.
13. **Space/Pound Key** — In **Idle** mode, press and hold this key to lock the keypad.
14. **BACK Key** — Deletes characters from the display. Returns you to the previous menu level.
15. **Power/Accessory Connector** — Lets you connect the travel adapter to charge the battery, or connect accessories, such as a hands-free headset.
16. **END Key** — With the phone off, press this key to turn the phone on. In **Idle** mode, press and hold this key to turn the phone off. During a call, ends the call. Within a menu, cancels your input and returns the phone to **Idle** mode.
17. **Camera Key** — In **Idle** mode, press this key to launch the **Camera** menu. In **Idle** mode, press and hold this key to launch the Camera. In Camera mode, takes a photo (pix).
18. **Right Soft Key** — Performs the functions indicated by the text on the bottom right line of the display.
19. **Headset Jack** — Lets you connect a hands-free headset or TTY device (see “[TTY Options](#)” on page 80 for more information).
20. **Camera Lens** — Lens for the built-in digital camera.
21. **External Display** — Shows some status icons and the current date, day, and time.

# DISPLAY SCREENS AND ICONS

Your phone has displays on the outside (front) and inside of the phone flip. These displays indicate when you have an incoming call or message. They also alert you when you receive calls or messages and at a specified time when you have set an alarm. The backlight illuminates and a corresponding icon appears in the display.

In **Idle** mode, the displays show the current time, day, and date.

## Front Display

1. The top line of your phone's front display shows icons that indicate signal strength, network status, battery power, and more.
2. The center portion of the front display shows information about incoming calls or messages, the camera viewfinder screen, and battery charging progress.



## Main Display

1. The top line of your phone's main display contains icons that indicate signal strength, network status, battery power, connection type, and more.
2. The center portion of the main display shows information such as call progress information, messages, and photos.
3. The bottom line of the main display shows current soft key functions.


















3. The bottom line of the main display shows current soft key functions. Press the **Left** soft key (⋮) to launch the **Contact List** screen, and press the **Right** soft key (⋮) to display the main menu.

## Display Icons

Names and definitions are provided below for many of the icons that appear on the top lines of the front and main displays and in camera mode display.

	<b>Signal</b> Indicates signal strength. More lines = a stronger signal.
	<b>In Use</b> Indicates a call is in progress.
	<b>No Service</b> Indicates the phone is not receiving a network signal.
	<b>3G Data Status</b> Indicates the phone is in data mode and is ready to send and receive calls.
	<b>3G Data Sending</b> <b>3G Data Receiving</b> <b>3G Data Dormant</b>
	<b>Location</b> Your phone's location can be determined.
	<b>Location off</b> Your phone's location can be determined only when you dial 911.
	<b>Security</b> Indicates your phone is in Lock mode.
	<b>Roaming</b> Indicates your phone is roaming off the Disney Mobile network.
	<b>New Text Message</b> Indicates you have a new text message.
	<b>Unread Message</b> <b>Read Message</b> <b>Sent Message</b>
	<b>Ringer</b> Indicates the phone is set to ringer mode.
	<b>Ringer Off</b> <b>Vibrate</b> <b>Ringer and Vibrate</b>

	<b>TTY</b> Indicates the phone's TTY mode is active.
	<b>Alarm</b> Appears when events or alarms are set.
	<b>Battery</b> Battery indicator. More bars = a stronger charge.
	<b>Low Battery</b> Indicates the battery is weak and only a few minutes of talk time remain.
	<b>Mute</b> Indicates the phone has been muted. The caller cannot hear you.
	<b>Speaker</b> Indicates the phone is in Speakerphone mode.
	<b>Camera</b> Camera is activated.
	<b>Self Timer</b>
	<b>Tungsten</b>
	<b>Sunny</b>
	<b>Fluorescent</b>
	<b>Cloudy</b>
	<b>Manual</b>
	<b>Bluetooth Enable</b> Indicates your phone is ready to connect to your Bluetooth device.
	<b>Bluetooth Connected</b> Indicates your phone and your Bluetooth device are connected.

### To access the Icon Glossary on your phone:

Press  ,  ,  ,  , .



**NOTE:** SEE SECTION 4, "MENU NAVIGATION," FOR MORE INFORMATION ON KEYPAD MENU SHORTCUTS.

### Backlight

A backlight illuminates the display and the keypad. When you press any key, the backlight comes on. It goes off when no keys are pressed within a given period of time, depending on the setting in the **Backlight** menu. (See "Backlight" on page 72 for more information.)



During a call, the backlight turns off after 10 seconds (regardless of the **Backlight** menu setting) to conserve battery power for talking.

### COMMAND KEYS

Functions for the soft keys are defined by the words that appear above each in the display. There are two soft keys, the left soft key () and the right soft key () .



### Left Soft Key

Some functions of the left soft key are as follows:

- In **Idle** mode, press the **Contacts** (left) soft key () to access the **Contact List** screen.
- When the left soft key function is **Edit**, press the **Edit** (left) soft key () to edit a contact's information.




### Right Soft Key

Some functions of the right soft key are as follows:



- In **Idle** mode, press the **Menu** (right) soft key () to access your phone's main menu.
- When the right soft key function is **Options**, press the **Options** (right) soft key () to view a menu of options.







## OK Key





- Within a menu, press the **OK** key () to accept the highlighted selection.
- In camera mode, press the **OK** key () to take a photo.
- When viewing a draft message, press the **OK** key () to edit the message.

## BACK Key


The **BACK** key () is used to erase or clear numbers, text, or symbols you've entered. You can also use the  key to return to a previous menu or to return to **Idle** mode from any menu.







1. If you enter an incorrect character, briefly press  to backspace (and delete) the character.
2. To erase the entire sentence, press and hold .
3. To back up one menu level, briefly press .
4. To return to **Idle** mode, press and hold .

## END Key


1. In **Idle** mode, press and hold the **END** key () to turn your phone off.
2. Briefly press  once to disconnect a call.
3. Press  to return to **Idle** mode from any menu, or to cancel the last input.
4. With your phone turned off, press to  turn your phone on.

## TALK Key


The **TALK** key () is used to answer calls, dial calls, and to recall the last number(s) dialed, received, or missed.

1. Press  once to answer a call.
2. Enter a number and briefly press  to make a call.
3. Briefly press  in **Idle** mode to display a list of recent calls to and from your phone.
4. Press  twice in **Idle** mode to call the most recent number.
5. Press  to pick up a waiting call. Press  again to switch back to the other call.



## Navigation Key (NAV KEY)

Use the NAV KEY () to scroll up, down, left, right through menus, submenus, and lists. In **Idle** mode, the NAV KEY also serves as a shortcut to the following areas:

- **UP** = Entertainment
- **DOWN** = Menu
- **LEFT** = Family Center
- **RIGHT** = Messaging



## Camera Key

In **Idle** mode, momentarily press the Camera key () — located on the right side of your phone — to launch the **Camera** menu. Press the Camera key () a second time to activate the camera built into your phone.

In **Idle** mode, press and hold the Camera key () to activate the camera.

In Camera mode, press the Camera key () to take a photo.

## YOUR PHONE'S MODES


### Idle Mode

In **Idle** mode, your phone is on, and the following Idle screens appear:

**Idle** mode is the state of the phone once it has found service and is idle.




Front Idle Screen





Main Idle Screen

The phone goes into **Idle** mode:






- After you power the phone on.
- When you press  after a call or from within a menu.

In **Idle** mode, you will see the time, day, and date as well as all phone status icons.

1. While in **Idle** mode, enter a phone number, and press  to place a call.
2. Press  to return to **Idle** mode.


### Call Answer Mode

You can select how you wish to answer a call.

- **Any Key** — Pressing any key except the  key,  key,  key,  key, or **Ignore** () answers a call.
- **Talk or OK Key** — Pressing either of these keys answers a call.
- **Flip Activation** — Opening the phone's flip answers a call.

**TIP:** YOU CAN SET YOUR PHONE TO ANSWER CALLS AUTOMATICALLY, WITHOUT ANY INPUT FROM YOU. (SEE "AUTO ANSWER" ON PAGE 78 FOR MORE INFORMATION.)


### Input Mode

Input mode determines how you enter text, numbers, and symbols. While at any text entry screen, press the right soft key () , then use the NAV KEY to choose the input mode from the pop-up menu. Available input modes are **Abc**, **T9® Word**, **123**, **Symbols**, **Quicknotes**, and **Emoticons**. (See [Section 5, "Entering Text,"](#) for more information.)

### Lock Mode





When the phone is in Lock Mode, restrictions are placed on phone use. You can receive calls and messages, but cannot place outgoing calls (except for emergency numbers and special numbers) until you unlock the phone. Lock Mode also restricts access to menus and the volume key. Unlock your phone by entering your Lock Code when prompted. (See ["Lock Phone" on page 75](#) for more information.)

## Talk Mode

You can place and receive calls only when your phone is on. While on a call your phone is in talk mode. Press the **Options** (right) soft key () to display a list of options available while you are on a call. See “In Use Menu” on page 16 for more information.

## Enter/Exit Silent Mode


Silence all tones your phone makes, including the calls ringer.

- In **Idle** mode, press and hold the  key, or press and hold the Down volume key () on the left side of the phone until you see “**Silent: All**”. Release the key. Your phone returns to **Idle** mode, and “**\*Silent: All\***” appears in the display.
- While in Silent mode and **Idle** mode, press and hold the  key, or press the Up volume key (). “**\*Silent: All\***” disappears from the display, and your phone returns to **Idle** mode.



## Vibrate Mode

In **Idle** mode, repeatedly press and hold the Down volume key () until **Vibrate** appears in the display.

### Adjusting the Ringer

1. In **Idle** mode, press the Up/Down volume key () on the left side of the phone. Options are:
  - **High & Vibrate**
  - **Level 1 – 5**
  - **Vibrate**
  - **Silent: All**
2. Release the key when the desired setting is shown. Your phone returns to **Idle** mode.



**TIP:** YOU CAN ALSO PRESS MENU () , THEN THE **5 JKL** , **5 JKL** , **2 ABC** , AND **1**  KEYS. USE THE VOLUME KEY OR LEFT/RIGHT NAV KEY TO ADJUST THE SETTING, AND THEN PRESS ().

**NOTE:** THE VIBRATE ICON () APPEARS IN THE DISPLAY WHEN THE PHONE IS IN **VIBRATE** MODE. THE VIBRATE PLUS RING ICON () APPEARS IN THE DISPLAY WHEN THE PHONE IS IN **HIGH & VIBRATE** MODE.

## Camera Mode

Camera mode lets you activate your phone’s camera to take pictures. In Camera mode, you can also adjust the resolution and appearance of your pictures.

See “Camera” on page 57 for more information.

- **Entering Camera Mode** — In **Idle** mode, press the **Camera** key () on the right side of your phone.
- **Exiting Camera Mode** — Press the  key.


## SECTION 3

### CALL FUNCTIONS



#### Topics Covered

- Making a Call
- Adjusting the Call Volume
- Answering a Call
- In Use Menu
- Call History
- Silent Mode
- Selecting Functions and Options



#### MAKING A CALL

1. From the **Idle** screen, enter the number you wish to dial and press the  key.

#### Making an International Call

1. Press and hold the  key. The + character appears.
2. Enter the country code, area code, and phone number and press the  key.

#### Correcting the Number

1. To clear the last digit displayed, press the  key.
2. To clear the entire number and return to Idle mode, press and hold the  key.





#### Ending a Call


1. Briefly press the  key when you want to finish your call.

#### Redialing the Last Number

The phone stores the numbers of the calls you've dialed, received, or missed if the caller is identified.

To recall any of these numbers:

1. Press the  key to display a list of the most recent numbers used in the order you dialed or received them.
2. Scroll through the numbers by pressing the Up/Down NAV KEY and highlighting the number you want. Press **Options** () from this screen to view the following:
  - **Send Message** — Allows you to send a text message, pix message, or voice recording to the number.
  - **Delete** — Allows you to delete the selected number.
  - **Delete All** — Allows you to delete all of the most recent calls displayed.
3. Press  to view details of the number.
4. Press the  key to dial the number.

Before you dial the number, you can press **Options** () for the following options:

- **Send Message:** Allows you to send a text message, pix message, or voice recording to the number.
- **View Contacts:** View this contact's information (appears only if saved to your Contact List).
- **Prepend:** Allows you to enter a dialing prefix.
- **Delete:** Allows you to delete the selected number.

## Making a Call from the Contact List

You can store phone numbers in your Contact List.

Once you have stored a number in the Contact List, you can dial it by pressing a few keys. You can also assign your most frequently used numbers to number keys using the Speed Dial feature.

1. Press **Contacts** (  ).
2. Select an entry from the Contact List and press the  key.







## ADJUSTING THE CALL VOLUME



During a call, use the volume key on the left side of the phone to adjust the speaker volume.

Press the  key to increase the volume level and the  key to decrease the level.

## ANSWERING A CALL

The caller's phone number (or name if stored in your Contact List) is displayed.

1. Press the  key to answer the incoming call. If the **Any Key** option in the **Answer Call** menu is activated, you can press any key to answer a call except the  key,  key,  key,  key, or **Ignore** (  ).




**NOTE:** TO REJECT AN INCOMING CALL, PRESS **IGNORE** (  ) OR THE  KEY.

2. End the call by pressing the  key.

**NOTE:** YOU CAN ANSWER A CALL WHILE MAKING MENU SELECTIONS. AFTER ENDING THE CALL, THE PHONE RETURNS TO THE FUNCTION SCREEN YOU WERE USING.




## IN USE MENU

Your phone provides an **In Use** menu that lets you access phone functions and applications while you are on a call.

1. Press **Options** (  ) while on a call to display the following options:
  - **Turn On/Off Speaker** — Launches/cancels Speakerphone mode.
  - **Turn On/Off Whisper** — Lets you conduct a call in a noisy environment.
  - **Record Voice** — Records and saves recording of your caller's voice to Voice Gallery.
  - **View Contact List** — Accesses your Contact List.
2. Select an option and press .
3. Press **Mute/Unmute** (  ) to mute (caller cannot hear you) or unmute the current call.

## CALL HISTORY

All incoming, outgoing, and missed calls are listed in the Call History.

1. Press **Menu** (  ).
2. Select **Messaging** and press .
3. Select **Call History** and press .

The following **Call History** options are available:

- Recent
- Missed
- Received
- Dialed

## Recent Calls

The **Recent** menu lets you view the 60 most recent calls you have received, dialed, and missed.

The phone number (and name, if already stored in your Contact List) displays with the number of occurrences of each number.

**NOTE: AT ANY TIME WHILE YOU ARE IN CALL HISTORY, YOU CAN USE THE LEFT/RIGHT NAV KEY TO SCROLL BETWEEN MISSED CALLS, RECEIVED CALLS, AND DIALED CALLS.**

## Missed Calls

The **Missed** menu lets you view the 20 most recent calls you received, but did not answer.

The phone number (and name, if already stored in your Contact List) are displayed.



### Viewing Missed Calls Immediately

When you are unable to answer a call, you can find out who is calling so that you can return the call.

The total number of missed calls displays on your phone's front display immediately after a call is missed. If you have missed only one call, the call's details will be shown on your phone's main display.


If you have missed more than one call:

1. On the main display, a missed call list will be displayed with the names of the callers (if in your Contact List).
2. Select a missed call with the NAV KEY.

3. To call the number displayed, press the  key. Before calling you can press  to view call details, including the caller's phone number and the time the call was received.

4. Press **Options** (  ) for the following options:

- **Send Message** — Allows you to send a text message, pix message, or voice recording to this number.
- **View Contacts** — View contact information if contact is in your Contact List.
- **Prepend** — Allows you to enter a dialing prefix.
- **Delete** — Allows you to delete the selected call record.

In Idle mode, press **Missed** (  ) to access the list of missed calls whose details you haven't viewed.

**NOTE: YOU CAN PRESS THE  KEY AT ANY TIME TO EXIT THE MISSED CALLS FEATURE.**

## Received Calls

The **Received** menu lets you view the 20 most recent calls you received.

The phone number (and name, if already stored in your Contact List) displays with the number of occurrences of each number.

## Dialed Calls

The **Dialed** menu lets you view the 20 most recent calls you dialed.

The phone number (and name, if already stored in your Contact List) displays with the number of occurrences of each number.



## Delete All

This menu allows you to delete all of the records in the Call History.

1. Press **Menu** (⋮).
2. Select **Messaging** and press **OK**.
3. Select **Call History** and press **OK**.
4. Select the type of call you want to delete (Recent, Missed, Received, or Dialed) and press **OK**.
5. Press **Options** (⋮) and highlight **Delete**; or press **Delete All** to delete all calls in the category.
6. When a "Delete?" message displays, select **Yes** or **No** and press **OK**.

## SILENT MODE

Silent Mode is convenient when you wish to stop the phone from making noise, in a theater for example.

1. Press and hold the  key until "Silent: All" appears in the display.
2. To exit and reactivate the previous sound settings, press and hold the  key again until "Silent: All" disappears from the display.

## SELECTING FUNCTIONS AND OPTIONS

### Soft Keys


The roles of the soft keys vary depending on the function you are currently using. The labels on the bottom line of the display just above each key indicate their current role.

### Selecting Options

To view the various functions and options available and to select the one you want:

1. Press the appropriate soft key. Use the NAV KEY as needed.
2. Press **OK** to select the function displayed or the option highlighted.



3. Press the **Down** NAV KEY to view the next function or highlight the next option on a list.
4. Press the **Up** NAV KEY to move back to the previous function or option on a list.
5. Press the **Back** soft key to move back up one level in the menu structure.
6. Press  to exit the menu structure without changing the settings.

You may be asked for your Lock Code or PIN. Enter the code and press **OK**.

## Options During a Call

Your phone provides functions that you can use during a call.

### Switching Microphone Off (Mute)

You can temporarily switch your phone's microphone off, so that the other person cannot hear you.

**EXAMPLE:** YOU WISH TO SAY SOMETHING TO A PERSON IN THE ROOM BUT DO NOT WANT THE PERSON ON THE PHONE TO HEAR YOU.

To switch the microphone off temporarily:

1. Press **Mute** (⋮). The other person can no longer hear you.





2. To switch the microphone on, press **Unmute** (  ). The other person can hear you again.

## Using the Speakerphone

While on a call, you can use your Speakerphone to conduct a hands-free conversation, or you can use your Speakerphone to let others with you join in the call.

### To turn the speakerphone on:



1. Press **Options** (  ).
2. Select the **Turn On Speaker** option and press  .

### To turn the speakerphone off:

End the call by pressing the  key.

**NOTE:** YOUR PHONE AUTOMATICALLY TURNS THE SPEAKERPHONE OFF WHEN YOU END A CALL.

— or —

1. Press **Options** (  ).
2. Select the **Turn Off Speaker** option and press  .

## Searching for a Number in the Contact List

You can search for a number in **Contact List** during a call.

1. Select **Options** (  ).
2. Select **View Contact List** and press  . Your Contact List is displayed.

**NOTE:** SEE “[MAKING A CALL FROM THE CONTACT LIST](#)” ON PAGE 16 FOR FURTHER DETAILS ABOUT THE **CONTACT LIST** FEATURE.

## SECTION 4

### MENU NAVIGATION






#### Topics Covered

- Menu Navigation
- Menu Summary

#### MENU NAVIGATION

Menus and sub-menus can be accessed by scrolling with the NAV KEY or by pressing the number that corresponds with each menu item.

#### Accessing a Menu Function by Scrolling

1. Press **Menu** (  ).
2. Scroll using the NAV KEY to select a menu. Press  to enter the menu.
3. If the menu contains sub-menus, you can access them by pressing  after the sub-menu is highlighted.
4. Press the  key to return to the previous menu level.
5. Press the  key to exit the menu without changing the settings.

#### Using Shortcuts

Menu items are numbered and can be accessed quickly by pressing their assigned numbers.

#### MENU SUMMARY

LEVEL ONE	LEVEL TWO	LEVEL THREE	LEVEL FOUR
CONTACTS	1. Contact List 2. New Contact 3. Groups  4. Speed Dial 5. Services	1. Family 2. Friends 3. School 4. Business 5. Colleague 6. No Group 7 – 0. Empty  1. Guest Service 2. Dir Assistance 3. Check Usage	
MESSAGING	1. Call History  2. Voicemail 3. Create Message 4. Inbox 5. Outbox 6. Drafts	1. Recent 2. Missed 3. Received 4. Dialed	
FAMILY CENTER	1. Family Locator 2. Family Monitor 3. Family Alert! 4. Call Control 5. Shop Family		
ENTERTAINMENT	1. Shop Entertainment 2. Disney Zone 3. My Ringtones 4. My Themes 5. My Images 6. My Games 7. My Applications 8. My Subscriptions 9. Web Browser		

#### EXAMPLE: TO ACCESS THE DISPLAY SETTINGS FOR YOUR PHONE:

1. PRESS **MENU** (  ).
2. PRESS THE  KEY FOR **TOOLBOX**.
3. PRESS THE  KEY FOR **SETTINGS**.
4. PRESS THE  KEY FOR **DISPLAY**.

LEVEL ONE	LEVEL TWO	LEVEL THREE	LEVEL FOUR
TOOLBOX	1. My Profile 2. Camera  3. Voice Recorder  4. Tools         5. Settings	1. Take Pix 2. Pix Gallery  1. Record Voice 2. Voice Gallery  1. Bluetooth®   2. Calendar 3. Alarm Clock   4. Notepad 5. Calculator 6. Stopwatch 7. World Clock  1. Display   2. Sound   3. Roaming   4. Messaging   5. Security	1. Enable 2. Trusted Devices 3. Visibility 4. Device Name 5. Device Info  1. Alarm # 1 2. Alarm # 2 3. Alarm # 3      1. Greeting 2. Menu Style 3. Clock 4. Backlight  1. Ringtone Volume 2. Earpiece Volume 3. Alert Volume 4. Game Volume 5. Key Tone  1. Set Mode 2. Call Guard 3. Data Roam Guard  1. Auto Delete Inbox 2. Signature 3. Quicknotes 4. Text Entry  1. Lock Phone 2. Change Lock Code 3. Special Numbers 4. Delete Contacts 5. Default Settings 6. Reset Phone

LEVEL ONE	LEVEL TWO	LEVEL THREE	LEVEL FOUR
TOOLBOX	5. Settings (cont.)	6. Setup/Others       7. Phone Info	1. Shortcuts 2. Answer Call 3. Auto Answer 4. Dialing Match 5. Text Entry 6. Language 7. TTY Options 8. Airplane Mode 9. Location 0. Key Guard  1. Device Info 2. Version 3. Icon Glossary

# SECTION 5



## ENTERING TEXT

### Topics Covered

- Changing the Text Entry Mode
- Using T9® Mode
- Using Abc Mode
- Entering Numbers
- Entering Symbols
- Entering Quicknotes
- Entering Emoticons

### CHANGING THE TEXT ENTRY MODE



Text messages can be made up of alphabetical characters, numbers, and symbols. You can use the following text entry modes to simplify text entry:

- **T9® Word** — Press each key only once to enter the letter of the word that you're spelling. T9 Word mode capitalization options (set by pressing the  key) are:
  - **T9® Word** — Enter initial capital letters.
  - **T9® WORD** — Enter all uppercase letters.
  - **T9® word** — Enter all lowercase letters.
- **Abc** — Enter letters, numbers, and symbols by repeatedly pressing each key until the desired character appears in the display. ABC mode capitalization options (set by pressing the  key) are:
  - **Abc** — Enter initial capital letters.
  - **ABC** — Enter all uppercase letters.
  - **abc** — Enter all lowercase letters.
- **123** — Enter numbers by pressing the corresponding key on the keypad.
- **Symbols** — Enter symbols into your message by pressing the number above the symbol in the **Symbols** pop-up window.

- **Quicknotes** — Enter quicknotes from your list.
- **Emoticons** — Enter emoticons.





The current text entry mode (**T9 Word**, **Abc**, **ABC**, **123**, or **Symbols**) is indicated at the bottom of a text entry screen.



### To change the text entry mode:


1. While composing a text message, press **Options** (). The following options appear in the display:
  - **Abc**
  - **T9® Word**
  - **123**
  - **Symbols**
  - **Quicknotes**
  - **Emoticons**
2. Use the NAV KEY to highlight the desired text entry mode, and then press .

### USING T9® MODE

T9 Word recognizes commonly used words for the numeric sequence of keys pressed and inserts the word into your message. T9 Word is much faster than the traditional method of text entry (**Abc**) and *requires only one key press per letter* of the word that you're spelling.

1. Press **Menu** (.
2. Select **Messaging**, and press .
3. Select **Create Message**, and press . The **Add Recipients** screen appears in the display.
4. Enter or select a recipient for this message. (See [Section 7, "Messaging,"](#) for more information.)
5. Press **Next** (). The **Send Message** screen appears in the display with the **Subject** field highlighted.





6. Press . The **Subject** screen appears in the display.
7. Press **Options** (  ). The following options appear in the display:
  - **Abc**
  - **T9® Word**
  - **123**
  - **Symbols**
  - **Quicknotes**
  - **Emoticons**

8. Select **T9® Word** and press .
  - For practice, enter the word “Disney” by pressing each of the following keys *only once*:




T9 Word recognizes that the most commonly used word for the numeric sequence you just entered is “Disney.” If more than one word shares the same numeric sequence, T9 Word provides the most commonly used word. Press to display other words, if available.

## USING ABC MODE

1. See steps 1–7 in “Using T9 Mode” on pages 22 and 23.
2. Select **Abc** and press .
  - Enter characters while in Abc mode by pressing the key labeled with the desired characters (such as, press  for “G”).
  - Press the key repeatedly until the desired character appears in the display (such as, press  twice for “H”).
  - Pause briefly and the displayed character is accepted and inserted into your message.
  - Press (  ) to enter a space.



## ENTERING NUMBERS

Enter numbers into a text message while in **123** mode.

1. See steps 1–7 in “Using T9 Mode” on pages 22 and 23.
2. Select **123** and press .
3. Press the key with the number you wish to insert into your message.



## ENTERING SYMBOLS

Symbol mode enables you to enter symbols such as “@” or “%” into a text message.

1. See steps 1–7 in “Using T9 Mode” on pages 22 and 23.
2. Select **Symbols**, and press . The first of four symbol screens appears in the display.
3. Scroll with the NAV KEY to view other symbols.
4. Press the key that corresponds with the symbol that you wish to enter. For example, press (  ) for an exclamation point (!).
5. Repeat steps 1–4 to insert as many symbols into your message as desired.

## ENTERING QUICKNOTES



Enter pre-composed phrases or sentences into your text message.

1. See steps 1–7 in “Using T9 Mode” on pages 22 and 23.
2. Select Quicknotes and press .
3. Scroll with the NAV KEY to select a quicknote and press .
4. The selected quicknote is inserted at the cursor into your text message.

**NOTE:** REFER TO “[QUICKNOTES](#)” ON [PAGE 75](#) FOR MORE INFORMATION ON EDITING AND COMPOSING QUICKNOTES.

## ENTERING EMOTICONS

Choose from a selection of fun emoticons to insert into your text message.

1. See steps 1–7 in “[Using T9 Mode](#)” on [pages 22](#) and [23](#).
2. Select Emoticons and press .
3. Select an emoticon with the NAV KEY and press .
4. The selected emoticon is inserted at the cursor into your text message.

# SECTION 6

## CONTACTS

### Topics Covered

- Accessing Contacts
- Finding a Contacts Entry
- Adding a New Contacts Entry
- Editing a Contacts Entry
- Saving a Number After a Call
- Contact Groups
- Speed Dial
- Services

### ACCESSING CONTACTS

Up to 500 entries can be stored in Contacts. Each entry can have up to five associated phone numbers and two e-mail addresses. Phone numbers can be up to 72 digits in length, including **2sec Pause** (2-second pause) or **Hard Pause** (see “Pause Dial from Contacts” on page 28 for more information), and associated names can be up to 72 characters in length. You can assign the Speed Dial number of your choice for each entry.

**TIP:** SPEED DIAL **ONE-TOUCH DIALING** AND **TWO-TOUCH DIALING** GIVE YOU FASTER WAYS TO CALL NUMBERS STORED IN CONTACTS.

### To access Contacts:

1. Press **Menu** () , then press () for **Contacts**. The following items appear:

- **Contact List** — Find a Contact by name.

**TIP:** YOU CAN ALSO ACCESS YOUR **CONTACT LIST** FROM **IDLE** MODE, BY PRESSING **CONTACTS** () .

- **New Contact** — Add a number or e-mail address to your Contacts.
- **Groups** — Review, send messages to, add Contacts to, or rename four out of your five groups.
- **Speed Dial** — Assign a Contacts entry to a Speed Dial number.
- **Services** — Access preassigned services.

2. Select the desired item and press () .


### FINDING A CONTACTS ENTRY

#### Soft Key Method

If you’ve stored a name entry in Contacts, **Contact List** allows you to find it quickly.







1. Press **Contacts** () .

The **Contact List** screen appears. Your contacts are listed below the **Find** entry field.

2. Enter a name as saved in your list. For example, if you saved the name as “Amy Smith,” begin the search by pressing () (for “A”).











3. The name you've entered will be highlighted.

- Press  to dial the number associated with the name.
- Press **Add New** () to add a new contact.
- Press **Options** () to view the following:
  - **Edit:** Change the selected contact's information.
  - **Send Message:** Send a text or pix message to the selected contact.
  - **Delete:** Delete the selected contact. (This option appears only when the selected contact is not on your calling plan.)
- Press  to view the information for this entry. Press **Edit** () to change information.
- Press **Options** (). Access **Send Message** and **Delete** from this screen.




## ADDING A NEW CONTACTS ENTRY

You can use either of two methods to add an entirely new entry to contacts. Dial method and menu method are described below.

### Dial Method

1. Using the keypad, enter the number you wish to add to your Contacts.
2. Press **Save** (). Under "**Save As**," the following options appear:
  - **New Entry** — Lets you create a new Contacts entry.
  - **Existing Entry** — Lets you add the number you entered to an existing Contacts entry.
3. Under **Select Label**, the following categories appear:
  -  **Mobile**
  -  **Home**
  -  **Office**
  -  **Mobile2**
4. Use the NAV KEY to highlight the type that matches your new entry, then press .
5. Use the keypad to enter a name for this entry and press .
6. Press **Save** () to save the entry.

### Menu Method

1. Press **Menu** () , () , and () for **New Contact**.  
The **New Contact** screen appears in the display with the **Name** field highlighted.
2. Enter the name of the new entry using the keypad. (See [Section 5, "Entering Text,"](#) for more information.)

3. Use the NAV KEY to highlight one of the following fields:

- Name
- Mobile
- Home
- Office
- Mobile2
- E-mail
- E-mail2
- Default Ringtone (or ringtone name)
- No Group
- Add Pix ID





4. Enter a phone number or e-mail address, and select a ringer, group, or picture in the highlighted field.


5. Repeat steps 3 and 4 as needed.

6. Press **Save** (  ) to save the entry.

## EDITING A CONTACTS ENTRY

### *Editing Contact Name and Numbers*

1. Use the NAV KEY to highlight the entry you wish to change and press . The **Contact** screen appears with the entry's information.
2. Use the NAV KEY to review the information and then press **Edit** (  ). The **Edit Contact** screen appears.
3. Use the NAV KEY to highlight the information you want to add or change. You have the following options to aid you in adding numbers and information:
  - Press  to backspace and delete numbers or letters.
  - Press and hold  to clear all numbers or letters in the highlighted field.

- For phone numbers and e-mail addresses, press **Options** (  ). The following options appear:

#### For phone numbers

- **Save as Main #** — Assign as first number displayed for this contact.
- **Speed Dial** — Assign a speed dial number.
- **Hard Pause** — Further dialing waits for input from you.
- **2sec Pause** — A two-second pause after which dialing resumes. (See [“Add Pauses to Contacts Numbers” on page 28](#) for more information.)

#### For e-mail addresses

- **Abc / T9 Word / 123 / Symbols** — Text input mode options. (See [Section 5, “Entering Text,”](#) for more information.)
- **ShortCut** — Lets you select a domain type for addition to the domain name portion of an e-mail address.

For Pix ID, press **Add** (  ) for the following options:

- **Pix Gallery** — Lets you select a photo you have taken with your phone's camera as a Contact's Pix ID.
- **Images** — Lets you select a preloaded or downloaded image as a Contact's Pix ID.

For **Default Ringtone** and **No Group**, press **Change** (  ) for the following:

- **My Ringtones** — Lets you select from your list of ringtones.
- **Voice Gallery** — Lets you select from your list of voice recordings.

Use the NAV KEY to highlight the desired option, then press .

4. When you're finished changing the contents of a field, press . To save all changes, press **Save** (  ). A confirmation message will appear in the display.




## Add Pauses to Contacts Numbers




Calls to automated systems such as banking services often require a password or account number. Instead of manually entering these numbers, you can store them in a Contacts entry with the phone number and with special characters called pauses, up to a maximum of 72 digits.

- **Hard Pause** — Stops the calling sequence until the phone receives further input.
- **2sec Pause** — Stops the calling sequence for two seconds, then sends the remaining digits.


**NOTE: YOU CAN ENTER MULTIPLE 2SEC PAUSES TO EXTEND THE LENGTH OF A PAUSE. FOR EXAMPLE, TWO CONSECUTIVE 2SEC PAUSES EQUAL A TOTAL PAUSE TIME OF FOUR SECONDS. KEEP IN MIND THAT PAUSES COUNT AS DIGITS TOWARDS THE 72-DIGIT MAXIMUM.**

To add pauses to a Contacts entry number, do the following:



1. Select the Contacts entry and press .
2. Select a phone number and press Edit (). See *"Editing a Contacts Entry" on page 27* for more information.
3. Press **Options** (). The following pause options appear in the display:
  - **Save as Main #**
  - **Speed Dial**
  - **Hard Pause** — See above. For contacts on your calling plan, this option will appear only for phone numbers you've added.
  - **2sec Pause** — See above. For contacts on your calling plan, this option will appear only for phone numbers you've added.




4. Use the Left/Right NAV KEY to position the cursor where you want to insert the pause. Then, select the desired pause option.
5. Press  to enter the selected pause into the number sequence. Repeat as needed.
6. Press  when you're finished entering the pause(s). Press **Save** () to save the number to Contacts.

## Pause Dial from Contacts

1. If you stored the number using **2sec pause(s)**, simply recall the number from Contacts.
2. If you stored the number using **Hard Pause**, recall the number from Contacts and wait for the appropriate prompt from the dialed number.
3. Press  to dial the number.

## Editing an Existing E-mail Address

1. Use the NAV KEY to highlight the desired Contacts entry, and then press **Options** ().
2. Select **Edit** and press .
 

The **Edit Contact** screen appears in the display.
3. Scroll to the e-mail address you wish to edit and press .
4. Use the keypad to edit the e-mail address. (See *Section 5, "Entering Text,"* for more information.) When you're finished, press  or **Save** (.

## Assigning a Picture to a Contacts Entry

When you assign a picture to an entry, the picture you assigned appears in the display when you receive a call from that contact.

1. Select a Contact List entry and then press **Options** (⋮).
2. Select **Edit**.  
The **Edit Contact** screen appears in the display.
3. Use the NAV KEY to highlight the **Add Pix ID** field (at the top of the **Edit Contact** screen), and then press **Add** (⋮). Under **Add Pix ID**, the following options appear:
  - **Pix Gallery** — Lets you select a photo you have taken with your phone's camera as a contact's Pix ID.
  - **Images** — Lets you select an image as a contact's Pix ID.
4. Select the desired option, and then press **OK**.  
The **Pix Gallery** thumbnail screen or a full-screen image appears in the display.
5. In **Pix Gallery**, use the Left/Right/Up/Down NAV KEY to select a pix. If you selected **Images**, use the Left/Right NAV KEY to select an image. Press **Assign** (⋮). The **Edit Contact** screen appears in the display with a thumbnail view of the selected pix or image in the Pix ID field.
6. Press **Save** (⋮) to save the pix or image assignment to the selected Contacts entry.

## Assigning a Ringtone to a Contacts Entry



When you assign a ringtone to a Contacts entry, the phone plays the ringtone that you assigned to that entry.

1. Select the desired Contacts entry, and then press **Options** (⋮).
2. Select **Edit**.  
The **Edit Contact** screen appears in the display.
3. Use the NAV KEY to highlight the **Default Ringtone** field, and then press **Change** (⋮). Under **Add Ringtone ID**, the following options appear:
  - **My Ringtones** — Lets you select a ringtone.
  - **Voice Gallery** — Lets you select a voice recording.
4. Select the desired option, and then press **OK**.  
The **My Ringtones** or **Voice Gallery** file list appears in the display.
5. Use the NAV KEY to select the ringtone or voice file that you wish to assign to the Contacts entry.
6. Press **OK**. The **Edit Contact** screen appears in the display with the name of the selected file now in the **Default Ringtone** field.
7. Press **OK** to play the newly assigned ringer.
8. Press **Save** (⋮) to save the ringer assignment to the selected Contacts entry.

## SAVING A NUMBER AFTER A CALL







Once you finish a call, you can store the caller's number to your Contact List.

**NOTE: IF THE CALL WAS INCOMING AND CALLER ID INFORMATION WAS UNAVAILABLE, THE **SAVE** OPTION WILL ALSO BE UNAVAILABLE.**

1. Press  to end your call. The call time, length of call, phone number, and name of the party (if available) appear in the display.
2. Press **Save** (). The following options appear in the display:
  - **New Entry** — Lets you create a new Contacts entry.
  - **Existing Entry** — Lets you add the number you entered to an existing Contacts entry.
3. Follow the instructions in the upcoming sub-sections depending on whether the number is a new entry or you wish to add it to an existing entry.

### Create a New Entry

Continued from "Saving a Number After a Call" above.


4. Select **New Entry** and press . The **Select Label** screen appears in the display showing the following number type options:
  -  **Mobile**
  -  **Home**
  -  **Office**
  -  **Mobile2**
5. Select the number type that matches your new entry, and then press **Done** (.






The **New Contact** screen appears in the display with the **Name** field highlighted.



6. Enter a name for the new entry (see [Section 5, "Entering Text"](#) for more information), then press the  key.
7. Press **Save** (). The new entry is saved to your Contacts list.

### Add to an Existing Entry

Continued from "Saving a Number After a Call" above.

4. Select **Existing Entry** and press .
 

The **Contact List** screen appears in the display with the **Find** field highlighted.
5. Find the Contacts entry to which you want to add the new number. See ["Finding a Contacts Entry" on page 25](#) for more information.
6. Press . The following number type options appear in the display:
  -  **Mobile**
  -  **Home**
  -  **Office**
  -  **Mobile2**

Number types that are already assigned with a number show the number instead of the number type label.
7. Select the desired unassigned number type, and then press . The **Edit Contact** screen appears in the display with the new number posted in the appropriate number type field.
8. Press **Save** () to save your changes to the existing entry.

## CONTACT GROUPS


Contact Groups let you easily send messages to multiple Contacts. You can also use Groups to find Contact entries and to add/remove Contacts names in a Group or to create or rename a Group.

### Add a Contacts Entry to a Group

1. Press **Menu** (  ), then press (  ) for **Contacts**.
2. Select **Groups** and press .



The following Groups are listed:

- Family
- Friends
- School
- Business
- Colleague
- No Group

3. Select the Group you want to assign a Contact to, and then press **Options** (  ). The following options appear in the display:
  - **Set Ringtone ID** — Lets you assign a unique ringtone to calls from members of this Group.
  - **Send Message** — Lets you send a message to all members in the Group.
  - **Add Member** — Lets you add one or more selected Contacts entries to this Group. You cannot add members to the Family Group.
  - **Delete Member** — Lets you remove one or more selected Contacts entries from this group. You cannot delete members from the Family Group.





4. Select **Add Member** and press .

The **Contact List** screen appears in the display.

5. Use the NAV KEY and press  to select the Contacts entry or entries you want to add.
6. Press **Done** (  ) to add the selected Contacts entries to the Group. The selected Group screen appears in the display listing the members of the Group.

### Delete a Contacts Entry from a Group

The **Delete Member** option lets you delete members in a Group, thus freeing you to reassign the Contacts formerly in the Group.

1. See steps 1–3 of “Add a Contacts Entry to a Group” above.
  2. Select **Delete Member** and press .
- The selected Group screen appears in the display.
3. Use the NAV KEY and press  to select the Contacts entry or entries you want to remove.
  4. Press **Done** (  ) to remove the selected Contacts entries from the Group.
  5. Select **Yes** (to confirm removal of the selected Contacts entries from the Group) or **No** (to retain the selected Contacts entries in the Group).
  6. Press . The selected Group screen appears in the display listing the members of the Group.

## SPEED DIAL

A contact's Speed Dial number (or location) corresponds to the number key you press to speed dial one of that contact's numbers.




For example:

- To speed dial the phone number assigned to Location 5, press and hold the (5 JKL) key, (1-touch dialing).
- To speed dial the phone number assigned to Location 35, press (3 DEF) and then press and hold the (5 JKL) key, (2-touch dialing).





**TIP:** YOU CAN ASSIGN A SPEED DIAL NUMBER TO EACH CONTACT'S PHONE NUMBER.

### Assigning a Speed Dial Number

**NOTE:** SPEED DIAL LOCATION 1 IS PREASSIGNED TO VOICEMAIL.


1. Press **Menu** (...), and then press (1 ) for **Contacts**.
2. Select **Speed Dial** and press . your speed dial assignments are displayed on the **Speed Dial** screen.
3. Select the Speed Dial location you wish to assign and press .
4. The **Contact List** screen is displayed.
5. Select the contact that you want to assign to this Speed Dial location.

6. Press **Done** (...). The **Select Label** screen is displayed when more than one phone number is associated with the contact. You can only select a number type that you've not already assigned.

-  **Mobile** or phone number
-  **Home** or phone number
-  **Office** or phone number
-  **Mobile2** or phone number

7. Select the number type and press **Assign** (...). The **Speed Dial** screen shows the new Speed Dial location assignment.








### Deleting a Speed Dial Assignment

1. On the **Speed Dial** screen, select a contact.
2. Press **Options** (...). The following options appear in the display:
  - **Delete** — Erases the assignment for this Speed Dial location.
  - **Delete All** — Erases the assignments for all Speed Dial locations.
3. Select an option and press . You are prompted to confirm deletion of the selected assignment or all assignments.










## Changing a Speed Dial Assignment

### To change the Contacts number assigned to a Speed Dial location:

1. On the **Speed Dial** screen, select an entry.
2. Press **Replace** (  ). The **Contact List** screen appears in the display.
3. Find the contact that you want to assign to this Speed Dial location.
4. Press **Done** (  ). The **Select Label** screen appears in the display showing the following number type options:
  -  **Mobile** or phone number
  -  **Home** or phone number
  -  **Office** or phone number
  -  **Mobile2** or phone number
5. Select the number that you want to assign as this Speed Dial location, and then press **Assign** (  ). The **Speed Dial** screen appears in the display showing the new Speed Dial location assignment. The number you replaced is no longer assigned.

## SERVICES

The **Services** menu lets you view and dial the emergency and service numbers preset in your device.

1. Press **Menu** (  ), and then press (  ) for **Contacts**.
2. Select **Services** and press . The **Services** screen appears in the display with the following numbers listed:
  - (  ) — **Guest Service** — Contact Disney Mobile Guest Services.
  - (  ) — **Dir Assistance** — Automatically dials directory assistance (411). \* Subject to additional fees.
  - (  ) — **Check Usage** — Check your current usage.
3. To dial any of these numbers, press the associated number key, and then press the (  ) key.

# SECTION 7

## MESSAGING

### Topics Covered

- Accessing Messaging
- Creating and Sending Messages
- Receiving Text Messages
- Receiving Pix (Picture) Messages
- Sending Pix Messages
- Inbox
- Outbox and Drafts
- Voicemail

### ACCESSING MESSAGING




You can send and receive messages containing text, pictures or images, and sound files to compatible phones and devices. Your message text can be up to 160 characters in length.

**NOTE:** AVAILABLE MEMORY IS SHARED BETWEEN ALL MESSAGES. YOU CAN STORE UP TO 100 MESSAGES. HOWEVER, THE EXACT NUMBER IS DEPENDENT UPON MESSAGE LENGTH.

### To access Messaging:

1. In **Idle** mode, press the Right NAV KEY. The **Messaging** menu appears with the following options:
  - **Call History** — Access the Call History logs. See “[Call History](#)” on [page 16](#).
  - **Voicemail** — Access your Voicemail account. See “[Setting Up Your Voicemail](#)” on [page 7](#).
  - **Create Message** — Address messages, compose text for messages, and add image, photo, and/or sound files to messages.
  - **Inbox** — Access your received messages folder.
  - **Outbox** — Access your outgoing messages folder.
  - **Drafts** — Access and edit draft messages for sending.

### CREATING AND SENDING MESSAGES

1. In **Idle** mode, press the Right NAV KEY.
2. Use the Down NAV KEY to highlight **Create Message**, and then press . The **Add Recipient(s)** screen appears in the display.
3. Press **Options** (  ) to find and select message recipients. Select one of the following and press :
  - **Add Contacts** — Lets you find and select one or more Contacts entries to receive this message.
  - **Add Groups** — Lets you find and select one or more Contacts Groups to receive this message.
  - **Add Recent** — Lets you select one or more originating numbers from Recent Calls to receive this message.
  - **Abc** — See below.
  - **T9 Word** — See below.
  - **123** — See below.
  - **Symbols** — See below.

(See “Finding a Contacts Entry” on page 25, “Contact Groups” on page 31, and “Recent Calls” on page 17 for more information.)

— or —

Use the keypad to enter the phone numbers or e-mail addresses of recipients of the message. (See Section 5, “Entering Text,” for more information.)

To change the text entry mode, press **Options** (⋮). The following options appear in the display:

- **Add Contacts** — See above.
- **Add Groups** — See above.
- **Add Recent** — See above.
- **Abc** — Multi-keypress text entry mode.
- **T9 Word** — Predictive text entry mode.
- **123** — Number entry mode.
- **Symbols** — Punctuation and special symbols entry mode. (See Section 5, “Entering Text,” for more information.)

4. After entering a recipient’s number or e-mail address, press **OK** to add another recipient.

After you have selected or entered all recipient numbers or e-mail addresses, press **Next** (⋮). The **Send Message** screen appears in the display with the **Subject** field highlighted.

5. Press **OK** or begin entering text. The **Subject** screen appears in the display.
6. Use the keypad to enter a subject for the message. When you’ve entered the subject, press **Done** (⋮). (See Section 5, “Entering Text,” for more information.)
7. Use the Down NAV KEY to highlight the message text field, then press **OK** or begin entering the message text using the keypad.
8. If you wish to insert a pix (picture) into your message, highlight the **Add Pix** field, then press **OK**. The **Pix Gallery** screen appears in the display.

9. Use the NAV KEY to select a pix and press **Add** (⋮). The **Send Pix Msg** screen appears with “Pix Added” now in the **Add Pix** field.

10. If you wish to insert a voice memo into your message, highlight the **Add Voice** field and press **OK**. Otherwise, proceed to step 11.

- The **Voice Gallery** screen appears in the display. You can press **Options** (⋮) to view the following options:
  - **Record New** — Press **OK** to record a new recording to insert into the message.

**NOTE: YOU CAN RECORD AND INSERT A VOICE RECORDING OF UP TO 60 SECONDS IN LENGTH, IF YOU RECORD BEFORE ATTACHING A PICTURE. IF A PICTURE IS ATTACHED BEFORE RECORDING, THE SIZE OF THE VOICE MEMO IS LIMITED TO THE AMOUNT OF REMAINING MEMORY.**



- **View Info** — Press **OK** to view details about the selected voice recording.



Select a recording from the list and then press **Add** (⋮). “Voice Added” will now appear.

Press **BACK** to exit **Voice Gallery** without inserting a sound.





11. Press **Options** (⋮), select one of the following, and press **OK**. Depending on the field selected, the following options will appear:
  - **Preview** — View pix/hear voice playback as the recipient will.
  - **Save to Drafts** — Save the message to your Drafts folder.
  - **Edit** — Change text.
  - **Delete Pix** — Remove the pix from your message.
  - **Delete Voice** — Remove the sound file from your message.
12. Press **Send** (⋮) to send the message. “Sent!” appears in the display to confirm that your message has been sent.

## RECEIVING TEXT MESSAGES




When you receive a text message in **Idle** mode, an alert sounds and **New Text Msg** appears on your main screen along with the closed envelope icon () . When you receive a message while on a call, **New Text Msg** and () appear on your main screen.

The sender's name (if in your Contact List), the message subject and message text, and the date and time of the message also appear in the display. To reply directly, press **Reply** () . Press **Options** () to forward the message, save a new contact, view message information, or delete the message.

## RECEIVING PIX (PICTURE) MESSAGES

When you receive a pix message in **Idle** mode, an alert sounds, and **New Pix Msg** appears in the display along with the closed envelope icon () . The date and time of the message also appear in the display. Press  or **Download** () to download and open the message. Press **Options** () to save the message to your Inbox or to delete the message.

### View a Pix Message Now




1. After you select **Download** () , "Downloading" appears in the display followed by "Loading." A progress bar shows that the message is downloading to your phone.
2. After the pix message has downloaded, an alert sounds, and the new pix message appears in the display. If the message includes a sound file, it will now play back.
3. While viewing your message, you can also press **Options** () , select one of the following, and press  :

The following options appear in the display:

- **Forward** — Send a copy of this message to another recipient.
- **Play Again** — Play the sound file included in the picture message again.

- **Save Contact** — Save the sender's number to your Contacts.
- **Save Attachment** — Save the sound file included in this message to the **Voice Gallery** folder. Save the pix included in this message to **Pix Gallery**.
- **Info** — Shows message delivery status, addressee, size, and so on.
- **Delete** — Delete the message from your Inbox.



### View a Pix Message in Your Inbox

1. In **Idle** mode, press the Down NAV KEY, then press () (for **Inbox**). The Inbox appears in the display.
2. If the new pix message is not highlighted, use the NAV KEY to highlight the new message.
3. Press  and then press **Download** () . "Downloading" appears in the display followed by "Loading." A progress bar shows that the message is downloading to your phone.
4. Once downloaded, the new pix message appears in the display. If the message includes a sound file, it will now play back.

**NOTE:** SEE "INBOX" ON PAGE 37 FOR MORE INFORMATION ON VIEWING AND MANAGING RECEIVED PIX MESSAGES.





## SENDING PIX MESSAGES

Pix messages can be sent to recipients with compatible phones or devices. You can even add a voice recording to the message.

1. In **Idle** mode, press the Right NAV KEY. Select **Create Message** and press .
2. Under Add Recipient(s), enter the phone number or e-mail address of your recipient(s), and then press **Next** (.


**NOTE:** YOU CAN SEND A PICTURE MESSAGE TO UP TO TEN RECIPIENTS.

**NOTE:** SEE [“CAMERA” ON PAGE 57](#) FOR INFORMATION ABOUT SENDING PIX IN CAMERA MODE.

3. Enter a subject for the pix message. (See [Section 5, “Entering Text,”](#) for more information.)
4. Press the Down NAV KEY to highlight the text field. Enter your message text.
5. Select the **Add Pix** field and then press . A gallery of thumbnail pix (**Pix Gallery**) appears in the display.
6. Use the NAV KEY to highlight a picture to be added to your message.
  - You can press **Options** () , select **Expand** and press  to expand the highlighted picture to full-screen size.
  - Press **Add** () to add the highlighted picture to your message.






You are returned to the **Send Pix Msg** screen with the selected picture in the **Add Pix** field.

7. To complete and send your message, follow steps 10–12 under [“Creating and Sending Messages” on pages 34 and 35.](#)






**TIP:** PRESS **OPTIONS** () TO DISPLAY A POP-UP MENU THAT INCLUDES CONTACTS, GROUPS, AND RECENT CONTACTS. THESE OPTIONS ALLOW YOU TO FIND AND ADD RECIPIENTS.

## INBOX

Received text and pix messages (except Voicemail) are saved in the **Inbox**.

1. In **Idle** mode, press the Right NAV KEY, select **Inbox** and then press .
2. Use the NAV KEY to select a message.
3. Press  to view message contents.
4. To reply to the message, press **Reply** (). You can also press **Options** () , select one of the following, and press :
  - **Forward** — Send a copy of this message to another recipient.
  - **Play Again** — Play the sound file included in the pix message.
  - **Save Contact** — Save to your Contact List.
  - **Save Attachment** — Save the audio file (sound) included in this message to **Voice Gallery**. Save the pix included in this message to **Pix Gallery**.
  - **Info** — Shows message delivery status, addressee, size, and so on.
  - **Delete** — Delete the selected message.

## Managing Inbox Messages

1. In **Idle** mode, press the Right NAV KEY, select **Inbox** and then press .
2. Use the NAV KEY to select a message.
3. Press **Reply** () to reply to the selected message. Press **Options** () , select one of the following, and press :
  - **Info** — Shows message delivery status, addressee, size, and so on, select one of the following and press :
  - **Delete** — Delete the selected message.
  - **Delete All** — Delete all messages from the Inbox.






## Messages and Lock Mode

Your phone can still receive messages while in Lock Mode. You cannot access the message until you enter the Lock Code.






## OUTBOX AND DRAFTS

Your phone stores messages in the Outbox, regardless of whether the message was successfully sent. Messages in Drafts have been composed but not sent. You can go to Drafts to view, edit, and send a draft message at any time.

## Review Outbox Messages and Drafts

1. In **Idle** mode, press the Right NAV KEY, select **Outbox** or **Drafts** and then press .
2. Use the NAV KEY to select a message and press .
3. Press **Send** () to send your message. You can press **Options** () , select one of the following, and press :
  - **Preview** — View pix and hear audio playback.
  - **Save to Drafts** — Saves the message as a draft.
  - **Edit** — Change text.
  - **Delete Pix** — Delete pix from the message.
  - **Delete Voice** — Delete audio from the message.

## Managing Outbox Messages and Drafts

1. In **Idle** mode, press the Right NAV KEY, select **Outbox** or **Drafts** and press .
2. Use the NAV KEY to select a message.
3. For an Outbox message, press **Forward** () to forward the message to another recipient. For a Draft message, press **Send** () to save the message. Press **Options** () , select one of the following, and press :
  - **Resend** — Resend the highlighted Outbox message to the original recipient.
  - **Info** — Shows message delivery status, subject, addressee, size, and date of the Outbox message.
  - **Delete** — Delete the selected message from the Outbox or Drafts.
  - **Delete All** — Delete all messages from the Outbox or Drafts.


## VOICEMAIL

Open **Voicemail** to view the **Callback #** (if available), **Urgency**, and other details of the Voicemail message.

When you receive a new voicemail message, under “**Missed Alerts**,” you have the option to either:

- **Listen** — Calls your voice mailbox and allows you to listen to your messages after you enter your passcode.
- **Dismiss** — Returns you to **Idle** mode. Call your voice mailbox and review your messages at a later time.

If you choose to review your voicemail messages at a later time:

1. In **Idle** mode, press the Right NAV KEY. Select **Voicemail (New)** and press . The Voicemail screen appears in the display, showing the number of new voicemail messages received and the date and time the latest message was received.
2. You'll be prompted to enter your passcode to access the messages in your voice mailbox.

**NOTE:** YOU CAN ALSO PRESS AND HOLD (  ) TO DIAL YOUR VOICE MAILBOX.

# SECTION 8

## FAMILY CENTER™

### Topics Covered

- Family Center™ Overview
- Family Locator™ Service
- Family Monitor™ Service
- Call Control Features
- Family Alert!™ Service

This section explains how to access and use your Family Center services and features. For information on Disney Mobile's Pictureland™, located in the Entertainment area of your phone and in Family Center at [www.disneymobile.com](http://www.disneymobile.com), see "Pictureland" in Section 9.

### FAMILY CENTER OVERVIEW

Disney Mobile's unique Family Center features family-centric applications that help you stay connected to and manage your family.

Listed below is an easy to read chart that clearly defines the roles for adults and kids for each Disney Mobile application.

FAMILY CENTER SERVICES	FAMILY MANAGER	FAMILY MEMBERS (18 & OVER)	FAMILY MEMBERS (UNDER 18)
<b>FAMILY LOCATOR SERVICE</b>			
CAN LOCATE KIDS' PHONES ON THE ACCOUNT	YES	YES	NO
CAN LOCATE ADULTS' PHONES ON THE ACCOUNT	NO	NO	NO
PHONES CAN BE LOCATED	NO	NO	YES
<b>FAMILY MONITOR SERVICE</b>			
CAN SET SPENDING ALLOWANCES FOR FAMILY MEMBERS	YES	NO	NO
CAN HAVE SPENDING ALLOWANCES SET FOR THEM	NO	NO	YES
<b>CALL CONTROL FEATURES</b>			
CAN SET PHONE USAGE RESTRICTIONS BY DAY & TIME	YES	NO	NO
CAN SET ALWAYS ON AND PROHIBITED NUMBERS	YES	NO	NO
CAN HAVE RESTRICTIONS IMPOSED ON USAGE	NO	NO	YES
<b>FAMILY ALERT! SERVICE</b>			
CAN SEND FAMILY ALERTS!	YES	YES	YES
CAN RECEIVE FAMILY ALERTS!	YES	YES	YES



**NOTE:** A FAMILY MANAGER IS THE ONE PERSON WHO OVERSEES THE DAY-TO-DAY ACTIVITY IN A DISNEY MOBILE CALLING PLAN. THE FAMILY MANAGER CAN SET USAGE ALLOWANCES FOR FAMILY MEMBERS UNDER THE AGE OF 18 VIA FAMILY MONITOR; AND RESTRICT USAGE AND SET ALWAYS ON AND PROHIBITED NUMBERS THROUGH CALL CONTROL.

**NOTE:** FAMILY CENTER™ FEATURES (OTHER THAN FAMILY ALERT!) MAY ONLY BE USED WITH PHONES ASSIGNED TO KIDS UNDER THE AGE OF 18. FAMILY CENTER FEATURES MAY NOT BE AVAILABLE OR FUNCTION, OR MAY BE SUBJECT TO CERTAIN FEES, UNDER CERTAIN CONDITIONS INCLUDING, BUT NOT LIMITED TO, PHONES BEING TURNED OFF, ONE OR MORE PHONES ROAMING OFF THE DISNEY MOBILE NETWORK, POOR NETWORK SIGNAL, OR OTHER SYSTEM, EQUIPMENT, OR NETWORK LIMITATIONS. SEE DISNEY MOBILE TERMS OF SERVICE FOR DETAILS.




## Accessing Family Center

### To access Family Center:

1. Press **Menu** (⋮), select **Family Center** and press . (Or press the left NAV KEY.) The following menu items appear:
  - Family Locator
  - Family Monitor
  - Family Alert!
  - Call Control
  - Shop Family
2. Use the Up/Down NAV KEY to select the desired service. Before going to the service, you can press **Options** (⋮) to access the following:
  - **Check Upgrade** — Check availability of an upgrade
  - **View Info** — Provides details about the selected application.
3. Press  to go to the service you've selected.

## FAMILY LOCATOR™ SERVICE



Family Locator provides locations and maps of locations to locate your children's phones right from your wireless phone without calling. From within Family Locator, select your child's name, enter your PIN and press .

Your Calling Plan may include a specific number of free locates per billing cycle; additional searches are available for a nominal fee per request. Please review your Calling Plan details.

**NOTE:** THE FAMILY MANAGER AND ADULTS ON THE ACCOUNT CAN LOCATE PHONES ASSIGNED TO FAMILY MEMBERS ON THE ACCOUNT UNDER THE AGE OF 18; FAMILY LOCATOR CANNOT BE ACCESSED FROM PHONES ASSIGNED TO FAMILY MEMBERS UNDER THE AGE OF 18.

## Accessing Family Locator



### To access Family Locator:

1. Press **Menu** (⋮), select **Family Center** and press .
2. Select **Family Locator** and press .



Family Managers and adults who have activated Family Locator can also access this feature in Family Center at [www.disneymobile.com](http://www.disneymobile.com).

## Setting Your PIN

The first time you use the Family Locator feature, you will be prompted to create your PIN. You will need to enter your PIN each time you access the Family Locator feature from your phone or the website.

1. Under **OK to Locate**, select a child's name and press .
2. Enter your temporary PIN (provided in Welcome E-mail) and press .
3. If correct, review and then accept or decline the Terms & Conditions.






**NOTE:** IF YOU HAVE ALREADY SET YOUR FAMILY LOCATOR PIN FROM [WWW.DISNEYMOBILE.COM](http://WWW.DISNEYMOBILE.COM), YOU WILL NOT BE PROMPTED AGAIN. IF YOU HAVE ALREADY ACCEPTED TERMS & CONDITIONS FROM [WWW.DISNEYMOBILE.COM](http://WWW.DISNEYMOBILE.COM), YOU WILL NOT BE PROMPTED AGAIN. IF YOU DECLINE THE TERMS & CONDITIONS, YOU WILL NOT BE ABLE TO USE FAMILY LOCATOR FUNCTIONALITY FROM YOUR PHONE OR FROM [WWW.DISNEYMOBILE.COM](http://WWW.DISNEYMOBILE.COM). YOU WILL CONTINUE TO BE PROMPTED EACH TIME YOU ACCESS THE FEATURE UNTIL YOU ACCEPT THE TERMS & CONDITIONS.

4. Under **Create PIN**, enter a new 4-digit PIN and press .
5. Reenter your new 4-digit PIN to confirm and press .
6. "New PIN Set" will appear to confirm the completed action.

**NOTE:** IT IS VERY IMPORTANT TO CHANGE YOUR PIN TO SAFEGUARD THE FAMILY LOCATOR FEATURE ON YOUR PHONE. YOUR NEW PIN MUST BE 4 DIGITS AND MUST BE DIFFERENT FROM YOUR TEMPORARY PIN.

### Using Family Locator

Here's how to locate your children's phones:




1. Under **OK to Locate**, select a name and press .
2. Enter your PIN and press .
3. "Locating" will appear to confirm action in progress.
4. If you have already used the locates included in your calling plan, you will be prompted to continue this search for an additional fee. Select **Yes** and press  to continue. Select **No** and press  to return to the previous screen.
5. For a successful locate: under **Location**, the location, accuracy range and the local time will be displayed.
6. For unsuccessful attempts, press **Retry** (.

**NOTE:** AFTER ENTERING AN INCORRECT PIN THREE TIMES IN A ROW, YOU WILL BE LOCKED OUT. THE ACCOUNT OWNER MUST CONTACT GUEST SERVICES AT 1-866-DISNEY2 TO RESET YOUR PIN.

**NOTE:** PRESSING BACK OR END WHILE CONDUCTING A SEARCH WILL COUNT AGAINST ANY LOCATES INCLUDED IN YOUR CALLING PLAN. UNSUCCESSFUL LOCATE ATTEMPTS WILL NOT BE DEDUCTED AGAINST ANY LOCATES INCLUDED IN YOUR CALLING PLAN.

### Viewing Maps

After receiving a location, you can access an area map to get a better view of your child's phone location.

1. Under **Location**, press **Map** (.
2. An area map will appear with a shaded circle indicating the reported location and accuracy range.
3. Use the NAV KEY to view the surrounding area. Press **Zoom** () to zoom in or out of map using the Left/Right NAV KEY.
4. Press **Back** () to return to the **Location** page.

**NOTE:** LOCATION INFORMATION CAN ONLY BE PROVIDED IF THE PHONE BEING LOCATED IS TURNED ON AND BOTH PHONES ARE WITHIN DISNEY MOBILE'S COVERAGE AREA. LOCATION CANNOT BE COMPLETED IF THE PHONE BEING LOCATED IS MAKING A VOICE CALL.

**NOTE:** FAMILY LOCATOR SERVICE MAY ONLY BE USED WITH PHONES ASSIGNED TO KIDS UNDER THE AGE OF 18. FAMILY LOCATOR FEATURES MAY NOT BE AVAILABLE OR FUNCTION, OR MAY BE SUBJECT TO CERTAIN FEES, UNDER CERTAIN CONDITIONS INCLUDING, BUT NOT LIMITED TO, PHONES BEING TURNED OFF, ONE OR MORE PHONES ROAMING OFF THE DISNEY MOBILE NETWORK, POOR NETWORK SIGNAL, OR OTHER SYSTEM, EQUIPMENT, OR NETWORK LIMITATIONS. SEE DISNEY MOBILE TERMS OF SERVICE FOR DETAILS.

### FAMILY MONITOR™ SERVICE




Stay in control of your family's wireless spending. Check total family usage, and set voice, text, pix, and download usage allowances for Family Members under the age of 18.

When allowances are reached for voice usage or messaging, the Family Manager will receive a mobile alert that lets him or her decide to view usage, increase allowances, or restrict service through Call Control. When a download allowance is reached, a restriction on further downloading will go into effect without the Family Manager's intervention, and an alert will not be sent.

Phones assigned to Family Members under the age of 18 on the account will be set up to be managed via Family Monitor, but phones assigned to Family Members over the age of 18 cannot be managed.

## Accessing Family Monitor




### To access Family Monitor:


1. Press **Menu** (  ), select **Family Center** and press .
2. Select **Family Monitor** and press . The following menu items appear:
  - **Set Allowances**
  - **View Usage**

This service is also available in Family Center at [www.disneymobile.com](http://www.disneymobile.com).

## Setting Allowances

Only the Family Manager can set allowances for children through the following steps:

1. From **Family Monitor**, select **Set Allowances** and press .
2. Select a child's name and press . (This step is omitted if there is only one member under the age of 18 on the account.)
3. Press Up/Down NAV KEY to select voice, text, pix, or downloads and press  to edit.
4. Under **Edit Allowance**, use the Left/Right NAV KEY to increase or decrease amount.

5. Press  to save the new allowance.

6. "Updating Allowance" will appear briefly, followed by a confirmation message.



**NOTE: SETTING ALLOWANCES FROM THE HANDSET IS ONLY AVAILABLE WITHIN DISNEY MOBILE'S COVERAGE AREA.**

## Viewing Usage

Only the Family Manager can view the usage of all family members on the account. Other family members on the account can view their own personal usage only.

### Family Manager's View


To view up-to-the-minute usage information:

1. From **Family Monitor**, select **View Usage** and press .
2. An "Updating Usage" message will appear briefly while the phone gets up-to-the-minute usage information for all members on your family plan.
3. Select a family member's name, **Myself**, or **Family Total** and press .
4. Press Up/Down NAV KEY to select voice, text, pix, or downloads.
5. Usage information appears at the bottom of each screen.
6. You can also set allowances from this screen for family members under the age of 18.

**NOTE: VIEWING USAGE FROM THE HANDSET IS ONLY AVAILABLE WITHIN DISNEY MOBILE'S COVERAGE AREA.**

## Other Family Members' View

All other family members can only view, not edit, their personal allowances and usage.

1. From **Family Monitor**, select **My Spending** and press .
2. Children view allowances and voice, text, pix, and download usage. Adults view usage only.

## Spending Alerts

When a family member under the age of 18 reaches an allowance for voice usage or messaging, a pop-up message called a Spending Alert will appear on his or her phone and on the Family Manager's phone.

**NOTE:** AFTER RECEIVING ALERTS, VOICE, TEXT MESSAGING, AND PIX MESSAGING USAGE WILL CONTINUE UNLESS SERVICE IS SUSPENDED VIA CALL CONTROL.

**NOTE:** FAMILY MONITOR SERVICE MAY ONLY BE USED WITH PHONES ASSIGNED TO KIDS UNDER THE AGE OF 18. FAMILY MONITOR FEATURES MAY NOT BE AVAILABLE OR FUNCTION UNDER CERTAIN CONDITIONS INCLUDING, BUT NOT LIMITED TO, PHONES BEING TURNED OFF, ONE OR MORE PHONES ROAMING OFF THE DISNEY MOBILE NETWORK, POOR NETWORK SIGNAL, OR OTHER SYSTEM, EQUIPMENT, OR NETWORK LIMITATIONS. SEE DISNEY MOBILE TERMS OF SERVICE FOR DETAILS.

## CALL CONTROL FEATURES

Call Control enables the Family Manager to create usage schedules and restrict a child's phone access by time of day and day of the week. Use Call Control to:

- Suspend usage when a child reaches a spending limit that has been set in **Family Monitor**
- Suspend usage for certain times of the day, like school hours
- Set **Always On Numbers**—phone numbers that can always be communicated with, even during restricted periods
- Set **Prohibited Numbers**—phone numbers that can never be communicated with

Go to Call Control in Family Center at [www.disneymobile.com](http://www.disneymobile.com) to create and edit usage schedules. From the website or your phone, view and assign schedules and set Always On and Prohibited Numbers.

## Restricted Periods

During restricted periods, your child will not be able to:

- Send or receive voice calls, text messages, or pix messages
- Purchase downloads

**NOTE:** ALWAYS ON NUMBERS AND 911 REMAIN FULLY ACCESSIBLE DURING RESTRICTED PERIODS.

## Always On Numbers

Always On numbers are phone numbers that can always be called, regardless of Call Control restrictions. All mobile phone numbers included in your Disney Mobile calling plan and 911 are Always On numbers.

You may choose to set other Always On numbers for your children, such as your home and work phone numbers. The Family Manager can designate up to 20 Always On numbers for each child.

## Prohibited Numbers

Prohibited numbers are numbers which cannot be called and from which calls cannot be received. The Family Manager can set up to 20 Prohibited numbers for each child.

**NOTE:** CALL CONTROL FEATURES ARE ONLY AVAILABLE WHEN THE RESTRICTED PHONE IS WITHIN DISNEY MOBILE'S COVERAGE AREA, SO OUTSIDE OUR COVERAGE AREA PROHIBITED NUMBERS CAN BE COMMUNICATED WITH.

## Creating Schedules on the Website





Select any of the schedules listed below to use as the basis for a new schedule. You can save the schedule just as it is, or edit it to your preference before saving.

- Any child's current schedule
- The following Ready Schedules:
  - **No Restrictions**—Assign this schedule to allow your child unrestricted phone access—with the exception of Prohibited Numbers

- **Restrict All**—Assign this schedule to restrict your child's phone access to Always On Numbers and 911
- **School Week**—Assign this schedule to restrict phone use when your child is in the classroom
- Custom Schedules that you've created and saved





## Accessing Call Control Features on Your Phone

To access Call Control features on your phone:

1. Press **Menu** () , select **Family Center** and press .
2. Select **Call Control** and press .
3. Select the name of the child whose schedule or numbers list you wish to view and press . The following menu items appear:
  - **Manage Schedule**
  - **Always On Numbers**
  - **Prohibited Numbers**




## Assigning Schedules

To view or change a usage schedule:

1. Select **Manage Schedule** and press . The child's current usage schedule is displayed.
2. Press **Change** () to view menu of available schedules.
3. Use the Up/Down NAV KEY to select a schedule and press .
4. Use Left/Right NAV KEY to preview all schedules.
5. Press **Assign** () to assign the selected schedule.
6. After a confirmation message, the child's new schedule will be displayed.




## Viewing Always On or Prohibited Numbers

To view an Always On or Prohibited number:

1. Select **Always On Numbers** or **Prohibited Numbers** and press .
2. Use the Up/Down NAV KEY to select a contact, then press  to view the contact's phone number.
3. Press **Back** () to return to **Always On Numbers** or **Prohibited Numbers** list.




## Adding New Numbers

Designate a new Always On or Prohibited number.

1. Select **Always On Numbers** or **Prohibited Numbers** and press .
2. Press **Add** ()
3. Under **Add New Number**, enter the new name and number. Press **Save** ()
4. After a confirmation message, you'll see the updated numbers list.





## Deleting Numbers You've Added

Only numbers that you've added can be deleted.

1. Select **Always On Numbers** or **Prohibited Numbers** and press .
2. Press the Up/Down NAV KEY to select a contact. To delete this contact, press **Delete** () , select "Yes," and then press .
3. You'll see a message confirming that the contact has been deleted.

## Child's Phone

Here's how your child can view his or her current schedule and Always On numbers list:

1. Press **Menu** () , select **Family Center** and press .
2. Select **Call Control** and press .
3. Select **My Schedule** or **Always On Numbers** and press .

**NOTE:** CALL CONTROL FEATURES MAY ONLY BE USED WITH PHONES ASSIGNED TO KIDS UNDER THE AGE OF 18. CALL CONTROL FEATURES MAY NOT BE AVAILABLE OR FUNCTION UNDER CERTAIN CONDITIONS INCLUDING, BUT NOT LIMITED TO, PHONES BEING TURNED OFF, ONE OR MORE PHONES ROAMING OFF THE DISNEY MOBILE NETWORK, POOR NETWORK SIGNAL, OR OTHER SYSTEM, EQUIPMENT, OR NETWORK LIMITATIONS. SEE DISNEY MOBILE TERMS OF SERVICE FOR DETAILS.

## FAMILY ALERT!™ SERVICE

Perfect for important intra-family communication. This feature allows you to instantly send priority messages that will pop up on the recipient's phone's screen as soon as they are received. Create new messages or choose any of the preloaded QuickAlerts, and then press a button to "alert" one or multiple family members simultaneously.

**NOTE:** MESSAGES CAN BE SENT TO AND FROM DISNEY MOBILE FAMILY MEMBERS REGARDLESS OF CALL CONTROL RESTRICTIONS.

## Accessing Family Alert!

### To access Family Alert!:

1. Press **Menu** (⋮), select **Family Center** and press **OK**.
2. Select **Family Alert!** and press **OK**. The following menu items appear:
  - Send Alerts
  - Edit QuickAlerts
  - Alerts Received

This service is also available in Family Center at [www.disneymobile.com](http://www.disneymobile.com).

**NOTE: SEE SECTION 5, "ENTERING TEXT," FOR MORE INFORMATION ON ENTERING LETTERS, NUMBERS, AND SYMBOLS.**

## Sending QuickAlerts

QuickAlerts are ready-to-send text messages that save time when communicating with your family.

Use as is or edit to fit your needs. You can also create a new alert. To send an alert:

1. From **Family Alert!**, select **Send Alert** and press **OK**.
2. Under **Add Recipients**, use the Up/Down NAV KEY and **OK** to select family member(s) and press **Next** (⋮).
3. Under **Add QuickAlert**, choose a QuickAlert, or select **(Create New)** to type your own, and then press **OK**.
4. Under **Send Alert**, edit a QuickAlert, leave it as is or enter the new alert.
5. Press **OK Send** (⋮). "Alert Sent!" will appear to confirm the completed action.

## Editing QuickAlerts

Personalize and save the QuickAlerts that are preloaded in your phone. Edited QuickAlerts are available for repeat use on the **Add QuickAlert** screen.

1. From **Family Alert!**, select **Edit QuickAlerts** and press **OK**.
2. Under **Edit QuickAlerts**, use the Up/Down NAV KEY to choose a QuickAlert to edit, or select **(Enter New)** to type your own and press **OK**.
3. Under **Edit Alert**, change or add text to the QuickAlert and press **Save** (⋮).
4. "Saved!" will appear to confirm the completed action. "Added!" will appear if you selected **(Enter New)**.
5. To send the saved message, follow "Sending QuickAlerts" directions above.

## Viewing, Replying to, and Deleting Alerts



You can view and reply directly to messages when they are first received. You can also view the last 10 Family Alert! messages you've received. It's easy to read, reply to, or delete these alerts.

1. From **Family Alert!**, select **Alerts Received** and press **OK**.
2. Under **Alerts Received**, select an alert, press **OK** (or press **Reply** (⋮) to display the **Add Recipient(s)** screen immediately).
3. Use the Left/Right NAV KEY to view all alerts. Press **Delete** (⋮) to delete an alert or **Reply** (⋮) to display the **Add Recipient(s)** screen.
4. Under **Add Recipient(s)**, use the Up/Down NAV KEY and **OK** to select family members and press **Next** (⋮).
5. Under **Add QuickAlert**, select a QuickAlert or **(Create New)** to type your own and press **OK**.
6. Under **Send Alert**, edit the QuickAlert, leave as is or enter the new text message, and press **Send** (⋮).

**NOTE:** ALERTS THAT HAVE NOT BEEN READ DISPLAY A SPECIAL ICON WITH THE LETTER N FOR “NEW.”

Family Alert! will delete messages saved in **Alerts Received** as new messages arrive.

To delete alerts from the **Alerts Received** screen:

1. From **Family Alert!**, select **Alerts Received** and press .
2. Select an alert. Press **Delete** () then select **Delete** or **Delete All** and press .
3. “Deleted!” will appear to confirm the completed action.

**NOTE:** FAMILY ALERT! FEATURES MAY NOT BE AVAILABLE OR FUNCTION, OR MAY BE SUBJECT TO CERTAIN FEES, UNDER CERTAIN CONDITIONS INCLUDING, BUT NOT LIMITED TO, PHONES BEING TURNED OFF, ONE OR MORE PHONES ROAMING OFF THE DISNEY MOBILE NETWORK, POOR NETWORK SIGNAL, OR OTHER SYSTEM, EQUIPMENT, OR NETWORK LIMITATIONS. SEE DISNEY MOBILE TERMS OF SERVICE FOR DETAILS.



## SECTION 9

### ENTERTAINMENT

#### Topics Covered

- Entertainment Overview
- Shopping
- Previewing
- Purchasing and Downloading
- My Ringtones
- My Themes
- My Images
- My Games
- My Applications
- My Subscriptions
- Disney Zone




This section explains how to shop for and enjoy the mobile content that's available in the Entertainment area of your phone.

#### ENTERTAINMENT OVERVIEW

Entertainment is where you'll find an array of popular content offerings, including ringtones, games, images, themes, and applications. Preview and sample to your heart's content, then purchase and download your favorites. Every item in our shop is designed to sound and look good—just like the cool, ready-to-enjoy content we've built right into your phone. Entertainment also includes Disney Mobile's Disney Zone.




#### Accessing Entertainment



##### To access Entertainment:

1. Press **Menu** () , select **Entertainment**, and press  . (Or press the Up NAV KEY.) The following menu items appear:
  - Shop Entertainment
  - Disney Zone
  - My Ringtones
  - My Themes
  - My Images
  - My Games
  - My Applications
  - My Subscriptions
  - Web Browser
2. Use the NAV KEY to select the desired area and press  .

#### SHOPPING

Here's how to purchase subscriptions and preview, purchase, and download content packs and individual ringtones, images, themes, games, and applications:




1. From **Entertainment**, use the NAV KEY to select **Shop Entertainment** and press  .
2. Select one of many options, including Ringtones, Images, Themes, Games, Applications, and other special offers.
3. Select a content category and press  .
4. Select an individual item in the category or pack and press  .

5. Select one of the following options and press .
  - **Preview** — To view or listen before buying, scroll left or right to preview all available content in the selected category or pack.
  - **Buy** — Initiates purchase transaction.
  - **Info** — Displays content details.
  - **Close** — Dismisses the Preview, Buy, and Info menu.
6. You can also select **Menu** () to display **Shop Entertainment** and navigate to another content type.

**NOTE: THERE IS NO PREVIEW OPTION FOR SUBSCRIPTIONS. SELECT INFO TO VIEW SUBSCRIPTION DETAILS.**




## PREVIEWING

This feature allows you to “try before you buy.” Here’s how:

1. After choosing your content, select **Preview** and press .
2. View or listen to your selection and press .
3. Use the Left/Right NAV KEY to preview other items in the category or pack.
4. Select one of the following options and press .
  - **Pause/Play** (ringtones only) — Allows you to pause or play the ringtone preview.
  - **Buy** — Initiates purchase transaction.
  - **Info** — Displays content details.
  - **Close** — Dismisses the Preview/Buy/Info menu.

## PURCHASING AND DOWNLOADING

To buy with or without previewing:

1. After choosing your content, select **Buy** and press . The purchase price will now be displayed.
2. Select the displayed price (e.g., \$1.49) from the Buy/View Info options and press .
3. Press  to confirm purchase.

### *For Images, Ringtones, and Themes*

After content has downloaded, select **Continue Shopping**, **Exit**, or an **Assign** option from the menu. Downloaded images, ringtones, or themes are saved and accessible via the **Entertainment** menu. Please refer to the My images, My Ringtones, and My Themes sections for details on assigning images, ringtones, and themes.

### *For Games and Applications*

After content has downloaded, select **Play**, **Continue Shopping**, or **Exit** from the menu. Downloaded games and applications are saved and accessible via the **Entertainment** menu.

### *For Content Packs*

**Content Packs** consist of predefined selections of content types (e.g., two ringtones and an image) or a set of like-type content (e.g., two images) available for a set price.

After content has downloaded, select **Continue Shopping**, **Exit**, or one of the following and press .

- **Assign All** (mixed content packs only) — Automatically assigns each piece of content in a mixed pack.
- **Assign [CONTENT]** — Advances to **Assign** screen. Select each item, and assign as desired.

## For Subscriptions




After “Successfully Purchased” appears, the **Shop Entertainment** screen will be displayed. Items purchased with your subscription credits are saved and accessible, via the **Entertainment** menu, in their appropriate content categories. You can manage your subscriptions, via the **Entertainment** menu, in **My Subscriptions**. Refer to the My Subscriptions section for details on managing your subscriptions.

**NOTE:** ALTHOUGH YOU MAY DELETE PURCHASED CONTENT, SOME PRELOADED IMAGES, RINGTONES, THEMES, GAMES, AND APPLICATIONS CANNOT BE DELETED.


## MY RINGTONES

You can assign your voice recordings and preloaded or purchased ringtones as Ringtone IDs to identify callers or as your phone’s default ringtone. Your saved voice recordings are stored in **Voice Gallery**. All voice recordings and purchased ringtones can be deleted.





## Accessing Ringtones and Voice Gallery

1. Press **Menu** (  ), select **Entertainment**, and press .
2. Select **My Ringtones** and press .
3. Your ringtones will be listed below **Voice Gallery**.

## Previewing Ringtones

1. Once in **My Ringtones**, use the NAV KEY to scroll through your ringtone list, make a selection, and press  to play.
2. Use the Left/Right NAV KEY to preview all ringtones.




## Previewing Voice Gallery

1. Once in **My Ringtones**, select **Voice Gallery** and press .
2. Use the NAV KEY to scroll through your voice recording list, make a selection, and press  to start playback.
3. Press **Pause** (  ) or **Finish** (  ) as desired.
4. When playback ends, the **Voice Gallery** menu will be displayed.

## Assigning Ringtones & Voice Recordings



Ringtones can be assigned via the main **My Ringtones** screen or when previewing. Voice recordings can be assigned from the **Voice Gallery** menu or when previewing.

## Assigning as a Ringtone ID

1. Select a ringtone or voice recording (see above) and press **Assign** (  ).
2. Under **Assign**, select **Ringtone ID** and press  to view your Contact List.
3. Under the Find entry field, your list of Contacts will be displayed.
4. At the cursor, enter a name (or select a name using the NAV KEY) and press .
5. “[Ringtone name] assigned” will appear to confirm the completed action.

**NOTE:** SEE SECTION 5, “ENTERING TEXT,” FOR MORE INFORMATION ON ENTERING LETTERS, NUMBERS, AND SYMBOLS.

## Assigning as a Default Ringtone

1. Select a ringtone or voice recording (see above) and press **Assign** (  ).
2. Under **Assign**, select **Ringtone** and press .
3. “[Ringtone name] assigned” will appear to confirm the completed action.

### Deleting Ringtones/Voice Recordings & Viewing Info

Purchased ringtones can be deleted via the main **My Ringtones** screen or when previewing. Voice recordings can be deleted from the main **Voice Gallery** menu or when previewing.

1. For voice recordings and purchased ringtones, press **Options** (⋮), select one of the following and press **OK**.
  - **View Info** — Provides details about the selected voice recording or ringtone.
  - **Delete** — Deletes the selected voice recording or purchased ringtone.
  - **Delete All** — Deletes all voice recordings or purchased ringtones.

## MY THEMES

You can assign your preloaded or purchased themes to completely transform your phone's menu display. All purchased themes can be deleted.

### Accessing Themes

1. Press **Menu** (⋮), select **Entertainment**, and press **OK**.
2. Select **My Themes** and press **OK**.

### Previewing Themes

1. Once in **My Themes**, use the NAV KEY to scroll through your theme list, make a selection, and press **OK** to view the selected theme.
2. Use the Left/Right NAV KEY to preview all themes.

### Assigning Themes

Themes are assigned via the main **My Themes** screen or the preview screen.

1. Select a theme and press **Assign** (⋮).
2. "[Theme name] assigned" will appear to confirm the completed action.

### Deleting Themes & Viewing Info

Themes can be deleted via the main **My Themes** screen or the preview screen.

1. For purchased themes, press **Options** (⋮), select one of the following, and press **OK**.
  - **View Info** — Provides details about the selected theme.
  - **Delete** — Deletes the selected purchased theme.
  - **Delete All** — Deletes all purchased themes.

## MY IMAGES


You can assign your pix (photos) and preloaded or purchased images as a Pix ID to identify callers or as wallpaper for your phone's Idle screen. Your saved pix are stored in **Pix Gallery**. All pix and purchased images can be deleted.

You can also preview, receive, and send pix from albums you've created in **Pictureland™** at [www.disneymobile.com](http://www.disneymobile.com).



### Accessing Images, Pix Gallery, and Pictureland

1. Press **Menu** (⋮), select **Entertainment**, and press **OK**.
2. Select **My Images** and press **OK**.
3. Your images will be listed below **Pix Gallery** and **Pictureland**.

## Previewing Images

1. Once in **My Images**, use the NAV KEY to scroll through your image list, make a selection, and press  to view the selected image.
2. Use the Left/Right NAV KEY to preview all images.




## Previewing Pix (Photos)

1. Once in **My Images**, select **Pix Gallery** and press .
2. Use the NAV KEY to select a pix thumbnail and press .
3. Use the Left/Right NAV KEY to preview all pix in full-screen view.



## Assigning Images & Pix (Photos)

Images can be assigned via the main **My Images** screen or the preview screen. Pix can be assigned from either **Pix Gallery** thumbnail or full-screen previews.

### Assigning as a PIX ID



1. Select an image or pix (see above) and press **Assign** (.
2. Under **Assign**, select **Pix ID** and press  to see your Contact List.
3. Under the Find entry field, your list of Contacts will be displayed.
4. At the cursor, enter a name (or select a name using the NAV KEY) and press .
5. “[Image name] assigned” will appear to confirm the completed action.

## Assigning as Wallpaper

1. Select an image or pix (see above) and press **Assign** (.
2. Under **Assign**, select **Wallpaper** and press .
3. “[Image name] assigned” will appear to confirm the completed action.

## Deleting Images and Pix & Viewing Info

Downloaded images can be deleted via the main **My Images** screen or the preview screen. Pix can be deleted in **Pix Gallery** thumbnail or full-screen previews.

1. For pix and purchased images, press **Options** () , select one of the following, and press  .
  - **View Info** — Provides details about the selected pix or image.
  - **Delete** — Deletes the selected pix or purchased image.
  - **Delete All** — Deletes all pix or purchased images.

## Pictureland™

Go to **Pictureland** in **My Images** on your phone to preview, receive, and send pix from albums you’ve created in **Pictureland** in **Family Center** at [www.disneymobile.com](http://www.disneymobile.com).

To upload pix to **Pictureland**, you must access your phone’s Camera mode. See “Taking a Snapshot” on page 57 and “Pix Gallery” on page 62 for more information on uploading pix.

**NOTE:** SEE SECTION 5, “ENTERING TEXT,” FOR MORE INFORMATION ON ENTERING LETTERS, NUMBERS, AND SYMBOLS.

## Initial Use of Pictureland on Your Phone

The first time you access **Pictureland** in **My Images**, or access the upload function in Camera mode, you will be prompted to review and then accept the Pictureland Terms and Conditions for phone use. There are three areas on your phone where you can accept the Pictureland Terms and Conditions: In Entertainment, access **My Images**; in Camera mode, access **Take Pix** or **Pix Gallery**. For initial use in **My Images**, do the following:

1. Under **My Images**, select **Pictureland** and press .
2. Review and then accept or decline the Terms and Conditions.

See “Taking a Snapshot” on page 57 and “Pix Gallery” on page 62 for initial use in Camera mode.

**NOTE: IF YOU HAVE ALREADY ACCEPTED PICTURELAND TERMS & CONDITIONS IN CAMERA MODE, YOU WILL NOT BE PROMPTED AGAIN.**

**IF YOU DECLINE THE TERMS & CONDITIONS, YOU WILL NOT BE ABLE TO USE PICTURELAND FUNCTIONALITY FROM YOUR PHONE.**

**YOU WILL CONTINUE TO BE PROMPTED EACH TIME YOU ACCESS PICTURELAND UNTIL YOU ACCEPT THE TERMS & CONDITIONS FROM YOUR PHONE.**

**IN ADDITION, YOU WILL BE REQUIRED TO ACCEPT A SEPARATE SET OF TERMS & CONDITIONS PRIOR TO BEING ABLE TO ACCESS PICTURELAND AT [WWW.DISNEYMOBILE.COM](http://WWW.DISNEYMOBILE.COM).**

## Viewing Your Pictureland Albums

1. Once in **My Images**, select **Pictureland**. You can press **Options** () to view the following:
  - **Check Upgrade** — Check availability of an upgrade.
  - **View Info** — View information about this version of **Pictureland**.
2. Press to access **Pictureland**.
3. Use the Up/Down NAV KEY to select an album and press .




4. Use the NAV KEY to select thumbnails. For full-screen view, press or **View** (). Press **Thumbnail** () to return to thumbnail view.
5. In full-screen view, press **Options** () to select one of the following and press .
  - **Send** — Send the selected pix to the mobile numbers or e-mail addresses of your recipients.
  - **Receive Pix** — Receive the selected pix as a pix message and download pix to **Pix Gallery**.
  - **View Info** — View information about the selected pix.

## Sending Pix from an Album

1. Select a pix from thumbnail view (see above) and press . Scroll with the Left/Right NAV KEY to view all full-screen pix.
2. Press **Options** () , select **Send**, and press . The **Add Recipient(s)** screen is displayed.
3. Press **Options** () to find and select pix message recipients from your Contact List or Groups. You can also enter a recipient’s phone number or e-mail address.
4. After you’ve selected your recipient(s), press **Next** ().
5. The **Send Pix Msg** screen appears with “Pix Added.”
6. Enter optional subject or message text.
7. Press **Send** () to send the pix message. “Successfully Sent!” will appear as confirmation.

**NOTE: SEE SECTION 5, “ENTERING TEXT,” FOR MORE INFORMATION ON ENTERING LETTERS, NUMBERS, AND SYMBOLS.**

## Receiving Pix from an Album

1. Select a pix from thumbnail view (see above) and press .
2. Press **Options** (). Select **Receive Pix** and press .
3. Following an audible alert, the **New Pix Msg** screen will be displayed.
4. To download the pix to Pix Gallery and view pix options, see "Receiving Pix (Picture) Messages" on page 36.



**NOTE:** WHEN YOU SEND A PIX FROM YOUR ALBUM, UPLOAD A PIX TO PICTURELAND, OR DOWNLOAD A PIX FROM PICTURELAND, YOU WILL BE CHARGED THE CURRENT PIX MESSAGE RATE.

## MY GAMES



### Accessing Games

1. Press **Menu** () , select **Entertainment** and press .
2. Select **My Games** and press .

### Playing Games

1. Under **Games**, select a game and press  or **Play** (.
2. Your subscription will be validated and you will be connected to your game automatically.

### Deleting Games & Viewing Info



1. For purchased or other downloaded games, press **Options** () , select one of the following, and press .
  - **View Info** — Provides details about the selected game.
  - **Delete** — Deletes the selected downloaded, non-subscription game.

- **End Subscription** — Ends your subscription to the selected game. You can continue playing until the subscription expires.
- **End & Delete** — Ends your subscription and immediately deletes the selected game.


## MY APPLICATIONS

Launch and manage your applications.



### Accessing Applications

1. Select **Entertainment** and press .
2. Select **My Applications** and press .

### Starting Applications

1. Under **My Applications**, select an application and press  or **Start** (.




### Deleting Applications & Viewing Info

1. For purchased and other downloaded applications, press **Options** () , select one of the following, then press .
  - **View Info** — Provides details about the selected application.
  - **Delete** — Deletes the selected downloaded, non-subscription application.
  - **End Subscription** — Ends your subscription to the selected application. You can continue using the application until the subscription expires.
  - **End & Delete** — Ends your subscription and immediately deletes the selected application.



## MY SUBSCRIPTIONS

Your subscription purchases are accessible in their appropriate content categories in **Entertainment** and are managed in the **My Subscriptions** section.

### Accessing Subscriptions

1. Press **Menu** (  ), select **Entertainment**, and press .
2. Select **My Subscriptions** and press .

### Managing Subscriptions

1. Under **My Subscriptions**, select a subscription.
2. Press **Options** (  ), select one of the following, and press .
  - **View Info** — Provides details about the selected content.
  - **End Subscription** — Ends your subscription to the selected content. You can continue using the content until the subscription expires.




**NOTE:** WHEN YOU SUBSCRIBE, YOU MUST AGREE TO THE TERMS AND CONDITIONS. WHEN YOU END A SUBSCRIPTION, YOU WILL STILL BE BILLED FOR THE CURRENT BILLING CYCLE, AND YOU WILL NOT RECEIVE ANY PRORATED REFUND.

## DISNEY ZONE

Be sure to visit Disney Zone regularly to check out the latest Disney entertainment applications plus games, themes, ringtones, and wallpapers designed specifically for your Disney Mobile phone. While in Disney Zone, open up Vault Disney and enjoy access to vintage and classic Disneyana.

Here's how to access everything available in Disney Zone:

### Accessing Disney Zone

1. Press **Menu** (  ), select **Entertainment**, and press .
2. Select **Disney Zone** and press .

### Selecting a Product in Disney Zone

Use the NAV KEY to choose a product area and press .



## SECTION 10

### TOOLBOX: MY PROFILE, CAMERA, VOICE RECORDER

#### Topics Covered

- My Profile
- Camera
- Voice Recorder

#### MY PROFILE

**My Profile** shows you the phone number for your mobile phone and the memory (in kilobytes) available for storing pix, applications, pix messages, and voicemail messages.

1. Press **Menu** (⋮), then select **Toolbox** and **My Profile**. Under **My Profile**, the following information is displayed:
  - **Disney Mobile #** — Your phone number
  - **Available Memory:**
    - **Camera:** Memory available for storing pictures in **Pix Gallery**.
    - **Java:** Memory available for storing applications.
    - **MMS:** Memory available for storing pix messages in your Inbox.
    - **Voice:** Memory available for storing voicemail messages.

#### CAMERA

Taking a pix (picture) with your phone's built-in camera is as simple as choosing a subject, pointing the lens (located above the external display), and pressing a button.

#### *Taking a Snapshot\**

To take a pix, do the following:

1. In **Idle** mode, press and hold the camera key (📷).

The message "**Loading...**" followed by the camera viewfinder screen appears in the display. (See "**Camera Screen**" on page 58 for more information.)

**NOTE: YOU CAN ALSO ACTIVATE THE CAMERA BY PRESSING MENU (⋮), THEN SELECTING **TOOLBOX, CAMERA, AND TAKE PIX.****

2. Point the camera at your subject.
3. Using the display as a viewfinder, press **Capture** (⋮), **OK**, or the Camera key (📷) when the image that you wish to capture appears in the display.
 

"**Saving to Pix Gallery – Please Wait!**" appears in the display, followed by the pix you have taken.
4. To review the other pix in **Pix Gallery**, use the Left/Right NAV KEY.
5. To take another pix, press **Take Pix** (⋮).
6. To access other functions, press **Options** (⋮). Select one of the following and press **OK**:
  - **Send** — Launches the **Add Recipient(s)** screen, letting you send this pix as part of a message.
  - **Upload\*\*** — Lets you upload a copy of the selected pix to your account on Disney Mobile's Pictureland™ in Family Center at [www.disneymobile.com](http://www.disneymobile.com).
  - **Assign** — Lets you assign this pix as Wallpaper or as a Pix ID for your contacts.
  - **View Info** — Shows you the title of this pix, the time and date you took the pix, the size of the pix file (in kilobytes).
  - **Delete** — Deletes this pix.
  - **Pix Gallery** — Launches Pix Gallery thumbnail view and gives you access to Pix Gallery options.

**\*NOTE:** IF THIS IS YOUR FIRST TIME ACCESSING A PICTURELAND FUNCTION ON YOUR PHONE, YOU WILL BE PROMPTED TO REVIEW AND THEN ACCEPT THE PICTURELAND TERMS & CONDITIONS. SEE “[PICTURELAND](#)” ON PAGE 53 FOR MORE INFORMATION.

IF YOU HAVE ALREADY ACCEPTED PICTURELAND TERMS & CONDITIONS IN MY IMAGES OR PIX GALLERY IN CAMERA MODE, YOU WILL NOT BE PROMPTED AGAIN.

IF YOU DECLINE THE TERMS & CONDITIONS, YOU WILL NOT BE ABLE TO USE PICTURELAND FUNCTIONALITY FROM YOUR PHONE.


YOU WILL BE PROMPTED EACH TIME YOU ACCESS PICTURELAND UNTIL YOU ACCEPT THE TERMS & CONDITIONS FROM YOUR PHONE. IN ADDITION, YOU WILL BE REQUIRED TO ACCEPT A SEPARATE SET OF TERMS & CONDITIONS PRIOR TO BEING ABLE TO ACCESS PICTURELAND AT [WWW.DISNEYMOBILE.COM](http://WWW.DISNEYMOBILE.COM).

**\*\*NOTE:** WHEN YOU SEND A PIX FROM YOUR ALBUM, UPLOAD A PIX TO PICTURELAND OR DOWNLOAD A PIX FROM PICTURELAND, YOU WILL BE CHARGED THE CURRENT PIX MESSAGE RATE.

## Camera Screen

When you activate your phone's camera:

1. The top line of the display is the Status Bar and is reserved for camera status icons.
2. The center of the display shows a viewfinder image of the subject at which the camera is pointed.
3. The soft key labels on the bottom line of the display change to the following:



- **Capture** — Pressing the left soft key (⏏) takes a pix of the image currently appearing on the display.
- **Options** — Pressing the right soft key (⋮) before taking the pix opens a pop-up menu of camera settings.

**TIP:** YOU CAN CHANGE A NUMBER OF THE CAMERA'S SETTINGS TO SUIT PARTICULAR USES FOR YOUR PIX. SEE “[CAMERA SETTINGS](#)” ON PAGE 61 FOR MORE INFORMATION.

## Camera Screen Icons


Camera screen icons are shown on page 11. You can also view the icon glossary on your phone by pressing **Menu** (⋮), then **Toolbox**, **Settings**, **Phone Info**, and **Icon Glossary**.

## Point, Click, and Send a Pix

Take a pix and send it to anyone with a compatible device in a few easy steps.

**TIP:** YOU CAN SEND A PIX MESSAGE TO UP TO TEN RECIPIENTS.


1. In **Idle** mode, press and hold the Camera key (⏏) to activate the camera.
  2. Using the display as a viewfinder, take the desired pix by pressing the Camera key (⏏), **Capture** (⏏), or **OK**.
- “**Saving to Pix Gallery – Please Wait!**” appears in the display, followed by the pix you have taken.
3. Press **Options** (⋮).

4. Use the NAV KEY to highlight the **Send** option, and then press . The **Add Recipient(s)** screen appears in the display.

5. Enter recipient phone number(s) or e-mail address(es) using the keypad. (See [Section 5, "Entering Text,"](#) for more information on entering numbers or text.)

— or —

Press **Options** () and select **Add Contacts**, **Add Groups**, or **Add Recent**.


6. Press **Next** (). Under **Send Pix Msg**, you'll see "Pix Added" is displayed.

7. Use the NAV KEY and the keypad keys to complete composing your message. (See [Section 7, "Messaging,"](#) for more information.)

8. Press **Send** () to send your message.

## CAMERA OPTIONS

### To access the camera Options menu:

1. In camera mode (before taking a pix), press **Options** (). The following options appear in the display:

- **Add a Frame**
- **Change View Mode**
- **Color Tones**
- **Self Timer**
- **Pix Controls**
- **Settings**
- **Pix Gallery**

Changes to certain camera options (**Add a Frame**, **Change View Mode**, **Color Tones**, and **Self Timer**) only take effect during the current camera session.

When you exit the camera, your options revert to the preset default values.

Changes you make to Pix Controls and Settings remain in effect in succeeding camera sessions until you change them. Saved pix are stored in **Pix Gallery**.

**NOTE: PIX GALLERY IS NOT INITIALLY VISIBLE IN THE POP-UP MENU. USE THE NAV KEY TO SCROLL DOWN AND VIEW THIS MENU ITEM.**




2. Use the NAV KEY to highlight the desired option and press .



## Single-Session Options

### Add a Frame

**Add a Frame** lets you temporarily apply one of the preloaded pix frames in your phone to characterize or enhance one or more pix taken during the current camera session.



**NOTE: THE NORMAL FRAME IS A BLANK FRAME.**

1. Select **Add a Frame** and press . The name of the current frame appears in the top line of the display.
2. Use the Left/Right NAV KEY to show the various frames.
3. To select a frame, press **Select** () or . The camera screen appears in the display with your selected frame in place.

The next time you press the Camera key () or , the camera includes the selected frame in your picture.

## Change View Mode

The **Change View Mode** option lets you change your camera viewfinder image from a portrait, full-screen view of the subject to a landscape, wide-screen view without rotating your phone.


1. In the camera **Options** menu, select **Change View Mode** and press . The View Mode menu pops up in the display.
2. Select **Wide Screen** or **Full Screen** and press . You are returned to the camera viewfinder screen, which shows the selected View Mode image.



## Color Tones



**Color Tones** lets you temporarily apply one of the following color-based special effects to one or more pictures:

- **Auto** — No special effect.
- **Negative** — Reverses light and dark shades of gray.
- **Sepia** — Replaces all colors with shades of sepia.
- **Emboss** — Creates a three-dimensional effect in the monochrome picture.
- **Aqua** — Replaces all colors with shades of aqua.
- **Gray** — Replaces all colors with shades of gray.
- **Sketch** — Reduces the picture to outlines.

**NOTE: THE AUTO COLOR TONE LEAVES THE PICTURE UNCHANGED.**




1. In the camera **Options** menu, select **Color Tones** and press . The name of the current color tone appears in the top line of the display.
2. Use the Left/Right NAV KEY to show the various color tones and the effects they have on a picture.



3. When you decide on the color tone you wish to use, press **Select** () or . The camera screen appears in the display with your selected color tone applied.

The next time you press the **Camera** key () or , the camera applies the selected color tone to your pix.

## Self Timer




**Self Timer** lets you delay the exposure long enough so you or the person taking the pix can join others in the pix.

1. In the camera **Options** menu, select **Self Timer** and press . The following options appear in the display:
  - Off
  - 5 Seconds
  - 10 Seconds
2. Select the desired delay, and then press . The Self Timer icon () appears in the display.

The next time you press the **Camera** key () or , a countdown timer appears in the display that indicates the time remaining before the camera takes the pix.

## Pix Controls

**Pix Controls** settings remain in effect until you change them.

1. In camera mode, (before taking a pix) press **Options** () , select **Pix Controls** and press .
2. Select one of the following options and press :
  - **Brightness**
  - **White Balance**
  - **Night Shot**

## Brightness

**Brightness** allows you to change the brightness of your pictures. Options are +5 – -5.

1. In the **Pix Controls** menu, select the **Brightness** option. The current brightness setting appears in the top line of the display.
2. Use the Left/Right NAV KEY to browse to the desired brightness, then press **Select** (⋮) or **OK** to save your selection. You're then returned to the camera viewfinder screen.

## White Balance

**White Balance** allows you to adjust picture quality according to available light.

1. In the **Pix Controls** menu, select the **White Balance** option. Select one of the following options and press **OK**:
  - **Auto** — The camera automatically adjusts pix quality to available light.
  - **Sunny** — Use this setting when taking pix in full sun.
  - **Cloudy** — Use this setting when taking pix in cloudy conditions.
  - **Tungsten** — Use this setting when taking pix under incandescent lights.
  - **Fluorescent** — Use this setting when taking pix under fluorescent lights.
  - **Manual** — Lets you manually select a particular white balance value (+5 – -5) using the Left/Right NAV KEY.

## Night Shot

**Night Shot** allows you to take pictures in low light.

1. In the **Pix Controls** menu, select the **Night Shot** option. Select one of the following options and press **OK**.
  - **On** — Lets you take pictures in low light.
  - **Off** — Lets you take pictures in bright light.

## Camera Settings

Camera **Settings** are saved in your phone and remain in effect until you change them.

1. In camera mode, press **Options** (⋮), select **Settings**, and press **OK**.
2. Select one of the following options and press **OK**:
  - **Resolution**
  - **Quality**
  - **Shutter Sound**
  - **Status Bar**

## Resolution

**Resolution** lets you change the size (in pixels) of your pictures.

1. In the **Settings** menu, select the **Resolution** option. Select one of the following options and press **OK**:
  - **High: 640 X 480**
  - **Med: 320 X 240**
  - **Low: 128 X 160**


Zoom in on a Subject




Your camera has digital zoom capabilities of up to +5, provided you set **Resolution** to **Med(ium)** or **Low**.

**NOTE: PIX MAY APPEAR SOMEWHAT GRAINY AS YOU ZOOM IN; THIS IS A NORMAL RESULT OF DIGITAL ENHANCEMENT.**

To enable **Zoom**:


1. In the **Settings** menu, select the **Resolution** option.
2. Select **Med: 320 X 240** or **Low: 128 X 160**, and then press **OK** to save your selection.

You are returned to the camera viewfinder screen, with the **Zoom** icon () appearing in the middle of the Status Bar.

3. To zoom in and out on your subject, use the Left/Right NAV KEY.
4. To take the pix, press the **Camera** key (), **Capture** (), or .


## Quality

You can affect how much your pix is compressed, which reduces its overall size (not to be confused with resolution).

1. In the **Settings** menu, select the **Quality** option.
2. Select **Fine**, **Normal**, or **Economy** and press .

## Shutter Sound

Choose from five different sounds whenever you take a pix. Aside from being a cool sound effect, **Shutter Sound** acts as an audible reminder that your camera has taken the pix.


1. In the **Settings** menu, select the **Shutter Sound** option.
2. Select one of the following shutter sounds and press .


**NOTE: EACH SOUND PLAYS AS IT IS HIGHLIGHTED.**

- Off
- Shutter1
- Shutter2
- Shutter3
- Say Cheese

## Status Bar








The **Status Bar** setting enables or disables the status bar on the top line of the camera viewfinder screen.

1. In the **Settings** menu, select the **Status Bar** option.
2. Select **On** (enabled) or **Off** (disabled), and then press .

**NOTE: SETTING STATUS BAR TO OFF REMOVES ALL ICONS FROM THE CAMERA VIEWFINDER SCREEN EXCEPT THE CAMERA ICON () THAT INDICATES YOUR PHONE IS IN CAMERA MODE.**

## Pix Gallery\*

Saved pix are stored in the **Pix Gallery**. You can browse Pix Gallery one pix at a time (expanded view), or view several pix at once in thumbnail format.

1. In **Idle** mode, briefly press the **Camera** key (). The following options appear in the display:
  - **Take Pix** — Activates your phone's camera and lets you take pix.
  - **Pix Gallery** — Lets you view and manage your saved pix.
2. Select **Pix Gallery** and press . The **Pix Gallery** screen appears, showing your saved pix.
3. To browse pix in Pix Gallery, use the NAV KEY or the Volume key.
4. To assign the displayed or highlighted pix as a **Wallpaper** or as a **Pix ID**, press **Assign** (.
5. Press **Options** () while viewing pix. Select one of the following and press .
  - **Send** — Send the currently displayed or highlighted pix in a message.
  - **Upload\*\*** — Upload a copy of the selected pix to your account on Disney Mobile's Pictureland™ in Family Center at [www.disneymobile.com](http://www.disneymobile.com).
    - To expand a pix to full-screen size, press .
    - To close a full-screen pix and return to the **Pix Gallery** thumbnail screen, press **Thumbnail** (.
  - **Edit Title** — Rename the currently displayed or highlighted pix.

- **View Info** — View the title, time and date created, size, and quality of the currently highlighted or displayed pix.
- **Delete** — Erase the currently displayed or highlighted pix.
- **Delete All** — Erase all of the pix in Pix Gallery.
- **Take Pix** — Launches the camera.

**\*NOTE:** IF THIS IS YOUR FIRST TIME ACCESSING A PICTURELAND FUNCTION ON YOUR PHONE, YOU WILL BE PROMPTED TO REVIEW AND THEN ACCEPT THE PICTURELAND TERMS & CONDITIONS. SEE “[PICTURELAND](#)” ON PAGE 53 FOR MORE INFORMATION.

IF YOU HAVE ALREADY ACCEPTED PICTURELAND TERMS & CONDITIONS IN MY IMAGES OR TAKE PIX IN CAMERA MODE, YOU WILL NOT BE PROMPTED AGAIN.

IF YOU DECLINE THE TERMS & CONDITIONS, YOU WILL NOT BE ABLE TO USE PICTURELAND FUNCTIONALITY FROM YOUR PHONE.

YOU WILL BE PROMPTED EACH TIME YOU ACCESS PICTURELAND UNTIL YOU ACCEPT THE TERMS & CONDITIONS FROM YOUR PHONE.

IN ADDITION, YOU WILL BE REQUIRED TO ACCEPT A SEPARATE SET OF TERMS & CONDITIONS PRIOR TO BEING ABLE TO ACCESS PICTURELAND AT [WWW.DISNEYMOBILE.COM](http://WWW.DISNEYMOBILE.COM).

**\*\*NOTE:** WHEN YOU SEND A PIX FROM YOUR ALBUM, UPLOAD A PIX TO PICTURELAND OR DOWNLOAD A PIX FROM PICTURELAND, YOU WILL BE CHARGED THE CURRENT PIX MESSAGE RATE.


## VOICE RECORDER

The Voice Recorder tool lets you use your phone as a personal voice/sound recorder for making voice recordings and recording one side of phone conversations.

**NOTE:** A VOICE RECORDING CAN BE A MAXIMUM OF 1 MINUTE IN LENGTH.


### Making a Voice Recording

1. Press **Menu** (⋮), then select **Toolbox**, **Voice Recorder**, and **Record Voice**. You are prompted to “Please Record After The Beep,” followed by the **Record Voice** screen appearing in the display.
2. Speak into your phone’s microphone in a normal voice.
3. To pause your recording, press **Pause** (⋮). To continue recording, press **Resume** (⋮).
4. To end your recording, press **Finish** (⋮). The **Record Voice** screen is replaced by the **Voice Gallery** screen.




### Recording the Other Caller During a Call

1. During a call, press **Options** (⋮), then select the **Record Voice** option. A 60-second countdown timer appears in the call information screen, above the call timer.
2. To pause recording the other caller, press **Pause** (⋮). To continue recording, press **Resume** (⋮).
3. To end your recording, press **Done** (⋮). The making voice recordings countdown timer disappears from the call information screen.



## Playing Your Voice Recordings

1. Press **Menu** (⋮), then select **Toolbox**, **Voice Recorder**, and **Voice Gallery**. The **Voice Gallery** screen appears in the display.
2. Select a voice recording using the Up/Down NAV KEY.
3. To assign this voice recording as a **Ringtone**, or as a **Ringtone ID** for Contacts, press **Assign** (⋮).
4. To play this voice recording, press **OK**.
5. To access other options, press **Options** (⋮).



## Erasing Your Voice Recordings

1. Press **Menu** (⋮), then select **Toolbox**, **Voice Recorder**, and **Voice Gallery**. The **Voice Gallery** screen appears in the display.
2. Highlight a particular voice recording using the NAV KEY.
3. Launch the options menu by pressing **Options** (⋮).
4. Press **Delete** to delete the selected recording or **Delete All** to delete all recordings.



# SECTION 11

## TOOLBOX: TOOLS





### Topics Covered

- Bluetooth®
- Calendar
- Alarm Clock
- Notepad
- Calculator
- Stopwatch
- World Clock

### BLUETOOTH®




The Bluetooth tool lets you pair Bluetooth technology devices (headsets and printers) with your phone and connect to them for use.

#### To enable the Bluetooth tool:



1. Press **Menu** () , then select **Toolbox**, **Tools**, and **Bluetooth**. The **Bluetooth** menu appears in the display showing the following options:
  - **Enable** — Lets you launch and disable your phone's Bluetooth tool.
  - **Trusted Devices** — Lets you add, connect with, and delete paired Bluetooth devices.
  - **Visibility** — Lets you make your phone visible to your Bluetooth device.
  - **Device Name** — Lets you change the name of the Bluetooth device currently connected with your phone.
  - **Device Info** — Shows your phone's Bluetooth device name, address, device type, and supported services.
2. Select **Enable** and press  . The **Enable** menu pops up in the display.
3. Select **On** and press  . "Bluetooth is enabled" and the Bluetooth Active icon () appear in the display.

### Trusted Devices

#### To pair a Bluetooth technology device with your phone:

1. Press **Menu** () , then select **Toolbox**, **Tools**, **Bluetooth**, and **Trusted Devices**. The **Trusted Devices** screen appears in the display showing a list of any devices currently paired with your phone.
2. Place your Bluetooth device in "discover" mode.
3. With no devices listed, press **Add New** () . With devices listed, press **Options** () and select the **Add New** option.


The Searching screen appears in the display until the **Found Devices** screen appears in the display listing the name of your Bluetooth device.

4. Press **Add to List** () . You are prompted to enter the device's PIN (Personal Identification Number).
5. Enter the Bluetooth device's PIN and press  . "Pairing..." appears in the display followed by "Pairing Successful," then the **Renaming Device** screen appears in the display.
6. To change the name of your Bluetooth device, use the keypad keys. (See [Section 5, "Entering Text,"](#) for more information.)

To keep the current device name, press **Done** () .

The Trusted Devices screen appears in the display showing the name of your Bluetooth device.

#### To connect a trusted device with your phone:

1. Press **Menu** () , then select **Toolbox**, **Tools**, **Bluetooth**, and **Trusted Devices**. The **Trusted Devices** screen appears in the display showing a list of any devices currently paired with your phone.
2. Place your Bluetooth device in "discover" mode.
3. Select the name of the Trusted Device you wish to connect with your phone.

4. Connect your phone and your Bluetooth device by pressing **Connect** (...). "Connecting..." appears in the display followed by "Connecting Successful," then the **Trusted Devices** screen appears in the display showing the name of your Bluetooth device.




## CALENDAR



With the Calendar tool, you can:

- Schedule events (Personal, Business, Appointments, Birthdays, and Vacations).
- Set an alarm to act as a reminder, if necessary.

When you launch the Calendar tool, the current month appears in the display with the current date highlighted.

At the bottom of the Calendar, the following event icons appear along with the number of entries in the calendar for each event type:

-  **Personal events**
-  **Appointments**
-  **Vacations**

-  **Business events**
-  **Birthdays**

**NOTE:** THE NUMBER OF ENTRIES NEXT TO EACH ICON REFLECTS THE NUMBER OF ENTRIES FOR THE SELECTED DAY ON THE CALENDAR.

### To launch the Calendar tool:

1. Press **Menu** (...), then select **Toolbox**, **Tools**, and **Calendar**. The Calendar screen appears in the display with Today's date highlighted.
2. To view the events scheduled for the highlighted date, press **View** (...).






3. To access other options, press **Options** (...). The following options pop up in the display:

- **Add New** — Lets you create a Personal, Business, Appointment, Birthday, or Vacation event.
- **Jump to date** — Lets you choose to view Today's events or to view events on a date you enter, or you can specify that the Event will occur a number of days after the current date.
- **Delete All** — Lets you delete all events from your Calendar.

## Adding Events

### To add an Event to your Calendar:

1. Press **Menu** (...), then select **Toolbox**, **Tools**, and **Calendar**. The Calendar screen appears in the display with Today's date highlighted.
2. To move to another date, do one of the following:
  - To select another month, use the Up/Down NAV KEY.
  - To select another day, use the Left/Right NAV KEY.
  - To specify a date or a time interval (in days), press **Options** (...), then select the **Jump to date** option.
3. Press **Options** (...). The following options pop up in the display:
  - **Add New**
  - **Jump to date**
  - **Delete All**
4. Select **Add New** and press **OK**. The **New Event** text entry screen appears in the display.
5. Use the keypad to enter the Event name and any memo text, then press **Next** (...). (See [Section 5, "Entering Text,"](#) for more information.)
6. Use the Left/Right NAV KEY to select the type of Event (**Personal**, **Business**, **Appointment**, **Birthday**, or **Vacation**).


7. To set or delete an alarm for this Event:
  - Use the Up/Down NAV KEY to highlight the alarm field (🕒), then use the Left/Right NAV KEY to select **No Alarm**, **On Time**, **10min before**, **30min before**, or **1Hr before**.
  - Highlight the repetition field (🔁), then use the Left/Right NAV KEY to select **Once**, **Daily**, **Weekly**, **Monthly**, or **Yearly**.
8. To select a distinct ringer for your Event:
  - Use the Up/Down NAV KEY to highlight the alarm ringer field (🔊), and then press . The **Schedule** options pop up in the display.
  - Select **My Ringtones** or **Voice Gallery**, and then press . The selected ringer list pops up in the display.
  - Select the desired ringer and press .
9. To schedule your Event:
  - Use the Up/Down NAV KEY to highlight the **Start** field, and then use the keypad to enter the Start time and date.
  - Highlight the **End** field, and then use the keypad to enter the End time and date.

**TIP:** TO TOGGLE THE START AND END TIMES BETWEEN **AM** AND **PM**, PRESS (⋮).

10. To save your Event to your Calendar, press **Done** (⋮).

## Changing Events

### To change the settings for an Event:

1. Select **Menu** (⋮), then select **Toolbox**, **Tools**, and **Calendar**. The Calendar screen appears in the display with Today's date highlighted.
2. To move to another date, do one of the following:
  - To select another month, use the Up/Down NAV KEY.
  - To select another day, use the Left/Right NAV KEY.
  - To specify a date or a time interval (in days), press **Options** (⋮), and then select the **Jump to date** option.
3. To view the Events scheduled for the highlighted date, press **View** (⋮). A list of Events appears in the display.
4. To show an Event for changing, select the Event to be changed, and then press . The name, **Start** time, and **End** time for the Event appear in the display.
5. To change the settings for this Event, press **Edit** (⋮). The **Edit Schedule** screen appears in the display.
6. Use the keypad to change the Event name and any memo text, then press **Next** (⋮). (See [Section 5, "Entering Text,"](#) for more information.)
7. Follow steps 6–10 under "Adding Events" on page 66.

## Deleting Events

1. Select **Menu** (⋮), then select **Toolbox**, **Tools**, and **Calendar**. The Calendar screen appears in the display with Today's date highlighted.
2. To move to another date, do one of the following:
  - To select another month, use the Up/Down NAV KEY.
  - To select another day, use the Left/Right NAV KEY.
  - To specify a date or a time interval (in days), press **Options** (⋮), then select the **Jump to date** option.

3. To view the Events scheduled for the highlighted date, press **View** (⋮). A list of Events appears in the display.
4. Select the Event you want to delete.
5. Press **Options** (⋮). The following options pop up in the display:
  - **Jump to date**
  - **Delete**
  - **Delete All**
6. To delete the highlighted Event, use the NAV KEY to highlight **Delete**. To delete all events from your calendar, highlight **Delete All**. Press **OK**. You are prompted to confirm the deletion.
7. Select **Yes** to delete the Event(s) or **No** to retain the Event(s) in your Calendar.
8. Press **OK**. The **Calendar** menu appears in the display.

## ALARM CLOCK

The Alarm Clock tool lets you set up to 3 alarms to ring at specified times.

### To set an Alarm:

1. Press **Menu** (⋮), then select **Toolbox**, **Tools**, and **Alarm Clock**. The following options appear in the display:
  - **Alarm #1**
  - **Alarm #2**
  - **Alarm #3**
2. Select the desired Alarm option and press **OK** or **Edit** (⋮). The **Set Alarm** screen appears in the display with the **Alarm** field highlighted.



3. Use the Left/Right NAV KEY to set **Alarm** to **On**.
4. To set the time for your Alarm, press the Down NAV KEY to highlight the **Time** field, then enter the time you want the Alarm to sound.  
To set the time for AM, press **2 ABC**. To set the time for PM, press **7 PQRS**.
5. To select a distinctive ringer for your Alarm:
  - Highlight the alarm ringer field (🔔) and press **OK**. The **Alarms** options pop up in the display.
  - Select **My Ringtones** or **Voice Gallery** and press **OK**. The selected ringer list pops up in the display.
  - Select the desired ringer or voice recording and press **OK**.
6. To specify how often your Alarm should repeat, highlight the **Repeat** option, then use the Left/Right NAV KEY to select **Once**, **Mon to Fri**, **Sat & Sun**, or **Daily**.
7. To specify a Snooze interval, highlight the **Snooze** field, then use the Left/Right NAV KEY to select **5 min**, **10 min**, **15 min**, or **20 min**.
8. To save your Alarm settings, press **Done** (⋮).

**NOTE:** TO STOP THE ALARM WHEN IT RINGS, PRESS **OK**, THE VOLUME KEYS, OR **BACK**, **TALK**, OR **END**.

## NOTEPAD

Create Notes and store them in Notepad. Notes that you create in Notepad cannot be prioritized or assigned an alert. Return to Notepad anytime to review and edit your Notes.

### Creating a Note


1. Press **Menu** (  ), then select **Toolbox, Tools**, and **Notepad**.
2. Do one of the following:
  - Your saved notes appear as a list in the display. Press **Add New** (  ). The **New Note** screen appears in the display.
  - If this is your first time in Notepad, the **New Note** screen appears in the display.
3. Enter note text using the keypad. (See [Section 5, "Entering Text,"](#) for more information.)


**NOTE:** THE CURRENT TEXT ENTRY MODE IS INDICATED IN THE LOWER RIGHT CORNER OF THE DISPLAY. PRESS **OPTIONS** (  ) TO CHANGE THE TEXT ENTRY MODE.



4. When you're finished entering details for the Note, press **Save** (  ).

### Viewing, Editing, and Deleting Notes


#### To view and/or edit a Note:

1. Press **Menu** (  ), then select **Toolbox, Tools**, and **Notepad**. The **Notepad** screen appears in the display, showing a list of your stored Notes.





2. Select a Note, then view the Note text by pressing . You can do the following:

- Scroll through the Note text by using the Up/Down NAV KEY.
- View other Notes by using the Left/Right NAV KEY.
- Change the Note contents by pressing **Edit** (  ).
- Access other options by pressing **Options** (  ). The following options appear in the display:

- **Set Background** — Lets you assign a background image to this note.
- **Add New** — Lets you compose a new Note.
- **Delete** — Erases the highlighted Note.


Select an option and press  to perform the function for the highlighted option.

#### To delete one Note or all Notes:


1. Press **Menu** (  ), then select **Toolbox, Tools**, and **Notepad**. The **Notepad** screen appears in the display, showing a list of your stored Notes.
2. Select the Note to be deleted.
3. Press **Options** (  ). The following options pop up in the display:
  - **Delete** — Lets you delete the highlighted Note.
  - **Delete All** — Lets you delete all of your Notes.
4. Select the desired option and press . You are prompted to confirm the selected deletion.
5. Select **Yes** to delete one/all Notes. Select **No** to retain one/all Notes.
6. Press . You are returned to the **Notepad** screen or the **Tools** menu.

## CALCULATOR

With the Calculator tool, you can use your phone as a calculator, performing basic arithmetic functions: addition, subtraction, multiplication, and division.

1. Press **Menu** () , then select **Toolbox**, **Tools**, and **Calculator**. The Calculator screen appears in the display.
2. Enter the first number using the keypad numeric keys.
3. Select the operator for your calculation by using the NAV KEY.





**NOTE: THE CALCULATOR SCREEN SHOWS THE SPECIAL KEY AND NAVIGATION KEY (ARITHMETIC OPERATOR) ASSIGNMENTS.**

4. Enter the next number.
5. To view the result, press .

Repeat steps 2–5 as many times as required.


## STOPWATCH

This tool lets you use your phone as a stopwatch.



1. Press **Menu** () , then select **Toolbox**, **Tools**, and **Stopwatch**. The **Stopwatch** screen appears in the display.
2. Press  to start or stop the Stopwatch.
3. Press **Lap** () for the lap time(s). You can have up to 10 lap times.
4. Press **Reset** () to erase all stopwatch times recorded.

## WORLD CLOCK




This tool lets you find out the time in other parts of the world.

1. Press **Menu** () , then select **Toolbox**, **Tools**, and **World Clock**. The **World Clock** screen appears in the display.
2. Use the Left/Right NAV KEY to browse cities and their current times. The following cities are supported.

New York, Miami	Caracas, La Paz	Buenos Aires, Sao Paulo
Mid Atlantic	Cape Verde	London
Rome, Paris, Berlin	Athens, Helsinki	Moscow
Abu Dhabi	Tashkent	Alma-ata
Bangkok, Jakarta	Hong Kong, Beijing	Seoul, Tokyo
Guam, Sydney	Okhotsk	Wellington, Auckland
Samoa, Midway	Honolulu	Anchorage
LA, Seattle	Denver	Chicago, Dallas

3. Do one of the following:
  - To set the selected time zone as the default time zone for your World Clock, press .
  - To return to the **Tools** menu, press .

### Enabling Daylight Savings Time (DST)

1. While viewing the World Clock map, press **Set DST** (). **On / Off** pops up in the display.
2. Press  to accept the highlighted setting. If the DST icon () appears in the display, it indicates that Daylight Savings Time is enabled.

# SECTION 12

## TOOLBOX: SETTINGS

### Topics Covered




- Display
- Sound
- Roaming
- Messaging
- Security
- Setup/Others
- Phone Info

### DISPLAY

Display settings let you change your phone's menu appearance, display brightness and contrast, and display content to better meet your needs.

#### Greeting



Create your own personalized greeting that appears in the display while your phone is in standby mode.

1. Press **Menu** (  ), then select **Toolbox, Settings, Display,** and **Greeting**. Press  . The following options appear in the display:
  - **Disney Mobile**
  - **Custom**
2. Select the desired greeting and press  .
3. If you select **Custom**, the **Custom** text entry screen appears in the display.
4. Enter a word or short phrase to appear in your phone's display while in **Idle** mode (up to 14 characters). (See [Section 5, "Entering Text,"](#) for more information.)

**TIP:** PRESS AND HOLD  TO ERASE AN EXISTING GREETING, IF NECESSARY.



5. Press **Done** (  ) or  to save your changes.

#### Menu Style

1. Press **Menu** (  ), then select **Toolbox, Settings, Display,** and **Menu Style**. The following options appear in the display:
  - **Graphic View** — Shows all main menus as an array of icons.
  - **List View** — Shows main menus in scrollable list (text) format.
2. Select the desired option and press  .

#### Clock

Lets you choose whether the time and date appear in the Main and Sub (front) displays on your phone in optional digital or analog (clock face) style or in the default digital style (Main display only).

1. Press **Menu** (  ), then select **Toolbox, Settings, Display,** and **Clock**. The following display options appear in the display:
  - **Main LCD**
  - **Sub LCD**
2. Select the desired display and press  . The following clock format options appear in the display:
  - **Main LCD:**
    - **Digital 1**
    - **Digital 2**
    - **Analog**
    - **Dual Clock** — Time, date, and day of the week are shown for two different locations (local and another selected with the World Clock) in the small digital format. (See ["World Clock"](#) on page 70 for more information.)

- Sub LCD:




- Analog 1
- Analog 2
- Digital

3. Press  and then use the Left/Right NAV KEY to highlight the clock format that you wish to use. Press **Assign** () or  to save your selection.

## Backlight

You can set the backlight for your display or keypad to remain on for a specified period of time or remain on as long as the folder is open.

**NOTE: PROLONGED BACKLIGHT USE DRAINS YOUR BATTERY FASTER.**



1. Press **Menu** () , then select **Toolbox, Settings, Display**, and **Backlight**. The following sub-menus appear in the display:
  - **Main Display** — Lets you set the amount of time the main (internal) display backlight remains on after a period of inactivity. Optional settings are: **Flip open, 30 seconds, 15 seconds**, and **8 seconds**.
  - **Keypad** — Lets you set the amount of time the keypad backlight remains on after a period of inactivity. Optional settings are: **Flip open, 30 seconds, 15 seconds**, and **8 seconds**.
  - **Power Save Mode** — Lets you dim display backlight brightness and turn off the keypad backlight to reduce battery drain and increase talk time.
  - **Brightness** — Use the Left/Right NAV KEY to select any one of the 5 optional settings.
2. Use the Up/Down NAV KEY to highlight the desired sub-menu and press .
3. Use the NAV KEY to change settings as desired in the selected sub-menu, and press  to save your selection.

## SOUND

Sound options provide a convenient means of adjusting your phone's volume settings, such as for ringers, keypad tones, alerts, and more.



### Ringtone Volume

Use the Ringtone Volume option to set the default volume for call ringers.

1. Press **Menu** () , then select **Toolbox, Settings, Sound**, and **Ringtone Volume**.
2. Use the Left/Right NAV KEY or the Volume key on the left side of your phone to select the volume level (**Silent : All, Level 1 – 5**) or vibration mode (**Vibrate, High & Vibrate**) for the selected option. Press  to save.

### Earpiece Volume

Use the Earpiece Volume option to set the default volume for the earpiece.

1. Press **Menu** () , then select **Toolbox, Settings, Sound**, and **Earpiece Volume**.
2. Use the Left/Right NAV KEY or the Volume key on the left side of your phone to select the volume level (**Level 1 – 5**). Press  to save.



### Alert Volume

Use the Alert Volume options to set the default volumes for your alert sound. You can also allow specific alerts to ring or set them to not ring.





## Alerts

Set the default volume for your alert sound.

1. Press **Menu** (  ), then select **Toolbox, Settings, Sound, Alert Volume**, and **Alerts**.
2. Use the NAV KEY or the Volume key on the left side of your phone to select the volume level (**Sound Off, Vibrate, Beep**, or **Beep & Vibrate**). Press  to save.



## Service Change

Enable/disable the alert that sounds when you leave your Disney Mobile service area while on a call.

1. Press **Menu** (  ), then select **Toolbox, Settings, Sound, Alert Volume**, and **Service Change**.
2. Use the NAV KEY or the Volume key on the left side of your phone to select **On/Off**. Press  to save.



## Minute Beep

Enable/disable the alert that sounds ten seconds before each elapsed minute of a call.

1. Press **Menu** (  ), then select **Toolbox, Settings, Sound, Alert Volume**, and **Minute Beep**.
2. Use the NAV KEY or the Volume key on the left side of your phone to select **On/Off**. Press  to save.




## Call Connect

Enable/disable the alert that sounds when you answer or disconnect a call.

1. Press **Menu** (  ), then select **Toolbox, Settings, Sound, Alert Volume**, and **Call Connect**.
2. Use the NAV KEY or the Volume key on the left side of your phone to select **On/Off**. Press  to save.




## Game Volume

Use the Game Volume option to set the default volume for game sounds.

1. Press **Menu** (  ), then select **Toolbox, Settings, Sound**, and **Game Volume**. Press  .
2. Use the NAV KEY or the Volume key on the left side of your phone to select the volume level (**Sound Off, Level 1 – 5**). Press  to save.

## Key Tone



Key Tone lets you select the tone that the keypad generates each time you press a key.

1. Press **Menu** (  ), then select **Toolbox, Settings, Sound**, and **Key Tone**. Press  . The following options appear in the display:
  - DTMF Tone
  - Xylophone
  - Voice
2. Use the NAV KEY or the Volume key on the left side of your phone to select the desired keypad tone and press  to save.

## ROAMING

Roaming options let you limit use of your phone to the Disney Mobile network or allow use of your phone in any accessible network.



### Set Mode

1. Press **Menu** (⋮), then select **Toolbox, Settings, Roaming**, and **Set Mode**. Press . The following options appear in the display:
  - **Automatic** — Lets your phone search for an alternate system when unable to find the Disney Mobile network.
  - **Disney Only** — Restricts your phone to accessing only the Disney Mobile network.
2. Select the desired roaming mode and press  to save.

**NOTE: FAMILY CENTER FEATURES MAY NOT FUNCTION PROPERLY WHEN ROAMING. SEE PAGE 40 FOR MORE INFORMATION.**



### Call Guard

While your phone is roaming, Call Guard requires you to perform an extra step when making or answering calls. (This additional step is not required when you make or receive calls while on the Disney Mobile network.)

1. Press **Menu** (⋮), then select **Toolbox, Settings, Roaming**, and **Call Guard**. Press .
2. Select **On** or **Off** and press  to save.

## Data Roam Guard

While your phone is roaming, Data Roam Guard requires you to perform an extra step before sending or receiving non-voice data. (This additional step is not required when you make or receive calls while on the Disney Mobile network.)



1. Press **Menu** (⋮), then select **Toolbox, Settings, Roaming** and **Data Roam Guard**. Press .
2. Select **Always Ask** or **Never Ask** and press  to save. By selecting **Always Ask**, you will be prompted before sending or receiving data (non-voice) when you are in a roaming area. By selecting **Never Ask**, you will not be prompted.

## MESSAGING

Use the Messaging sub-menus to specify default settings that help you manage your message storage space and help you compose text for your messages.




### Auto Delete Inbox

When your message Inbox fills, and the Auto Delete Inbox option is enabled, your phone erases older messages to make room for newly received messages.

1. Press **Menu** (⋮), then select **Toolbox, Settings, Messaging**, and **Auto Delete Inbox**. Press . The following options appear in the display:
  - **Enable** — Older messages are automatically erased from the Inbox when it fills, to make room for newly received messages.
  - **Disable** — When your phone receives a message and the Inbox is nearly full, you are prompted to manually erase some messages to make room for newly received messages.
2. Select the preferred option and press  to save.

## Signature







Lets you select and compose a visible or invisible signature for inclusion in your messages.

1. Press **Menu** (  ), then select **Toolbox, Settings, Messaging,** and **Signature**. Press  . The **Signature** screen appears in the display showing the current Signature.
2. Use the Left/Right NAV KEY to select the preferred Signature: **Invisible** or **Visible**.
3. To compose a signature:
  - Use the Up/Down NAV KEY to highlight the signature text box.
  - Use the keypad to enter the signature text. (See [Section 5, "Entering Text,"](#) for more information.)
4. Press  to save the option setting and signature text.



## Quicknotes

Your phone can store up to 40 pre-composed text phrases or sentences that you can reuse when composing message text. Your phone is preloaded with 21 Quicknotes. You can use and/or change these preloaded Quicknotes as you choose.

### To review or edit Quicknotes:




1. Press **Menu** (  ), then select **Toolbox, Settings, Messaging,** and **Quicknotes**. Press  . A list of available pre-composed texts appears in the display.
2. To page through the list, use the Volume key on the left side of your phone.
3. To highlight individual text entries, use the NAV KEY.
4. To view/edit a highlighted text entry, press **Edit** (  ) or  . The **Edit Quicknotes** screen appears in the display.  
To compose a new Quicknote, highlight an **Empty** entry and press **Edit** (  ) or  .

**NOTE: YOU CAN ENTER A MAXIMUM OF 128 CHARACTERS INTO A QUICKNOTE.**

5. Use the keypad to enter or change the text. (See [Section 5, "Entering Text,"](#) for more information.)
6. To save your text or changes, press **Done** (  ) or  .

## Text Entry

The Text Entry option lets you select a default text entry mode for composing text for your messages.



1. Press **Menu** (  ), then select **Toolbox, Settings, Messaging,** and **Text Entry**. Press  .
2. Select your preferred text entry mode: **Abc** or **T9 Word**. (See [Section 5, "Entering Text,"](#) for more information about text entry modes.) Press  to save.

## SECURITY

This feature prevents unauthorized use of your phone.


### Lock Phone

Locking your phone blocks all outgoing calls except those to 911 and to the three user-programmed emergency numbers. You can lock your phone manually, or set the phone to lock automatically when you turn it on. In Lock mode, you can answer calls, but you must unlock the phone to place calls (except to emergency and special numbers).

1. Press **Menu** (  ), then select **Toolbox, Settings,** and **Security**. Press  .  
The "User Lock" prompt pops up in the display.
2. Enter your four-digit lock code using the keypad.

**NOTE: THE DEFAULT LOCK CODE IS 0-0-0-0 (FOUR ZEROES).**

The “**User Lock**” prompt disappears and the **Security** menu appears in the display.

3. Press **1**  for **Lock Phone**. The following options appear in the display:
  - **Unlocked** — The phone remains unlocked.
  - **On Power-Up** — The phone locks automatically the next time your phone is powered on and stays locked until you enter the lock code.
  - **Lock Now** — The phone locks immediately and stays locked until you enter the lock code.
4. Select the desired Lock Phone option and then press **OK** to save.

### Change Lock Code

The default lock code is four zeroes. It is advisable to change the default lock code to a secret code for security purposes.


1. Press **Menu** () , then select **Toolbox, Settings, and Security**. Press **OK** .


The “**User Lock**” prompt pops up in the display.

2. Enter the four-digit lock code using the keypad.

**NOTE: THE DEFAULT LOCK CODE IS 0-0-0-0 (FOUR ZEROES).**

The “**User Lock**” prompt disappears and the **Security** menu appears in the display.

3. Press **2** **ABC** for **Change Lock Code**. You’re prompted to enter the new lock code.
4. Enter the new lock code and press **Next** () . You’re prompted to re-enter the new lock code for verification.

5. Enter the new lock code again and press **Done** () . Your changes are stored.

**NOTE: YOUR PHONE DOES NOT ALLOW YOU TO VIEW THE LOCK CODE FOR OBVIOUS SECURITY REASONS. IF YOU CHANGE THE LOCK CODE, BE SURE TO WRITE DOWN OR MEMORIZE THE NEW CODE.**

### Special Numbers

You have the option of storing up to three emergency numbers to your phone. Each number can be up to 32 digits in length. All emergency numbers can be dialed any time, even when your phone is locked or restricted.

**NOTE: SPECIAL NUMBER 911 IS HARD-CODED INTO YOUR PHONE. YOU CAN DIAL THIS NUMBER ANY TIME, EVEN WHEN THE PHONE IS LOCKED OR RESTRICTED. IF YOU CALL 911 AN AUDIBLE TONE IS HEARD AND AN EMERGENCY PROMPT APPEARS IN THE DISPLAY FOR THE DURATION OF THE CALL.**



**IMPORTANT! BECAUSE OF VARIOUS TRANSMISSION METHODS, NETWORK PARAMETERS, AND USER SETTINGS USED TO COMPLETE A CALL FROM YOUR WIRELESS PHONE, A CONNECTION CANNOT ALWAYS BE GUARANTEED. THEREFORE, EMERGENCY CALLING MAY NOT BE AVAILABLE ON ALL WIRELESS NETWORKS AT ALL TIMES.**

**IMPORTANT! DO NOT DEPEND ON THIS PHONE AS A PRIMARY METHOD OF CALLING 911 OR FOR ESSENTIAL OR EMERGENCY CALLS.**

Remember to always turn your phone on and check for adequate signal strength before placing a call.






**NOTE: WHEN YOU DIAL AN EMERGENCY NUMBER, YOUR PHONE LOCKS ITSELF TO THE EMERGENCY LOCATION THAT ANSWERED THE CALL AND LOCKS ITSELF IN 911-ONLY MODE, BLOCKING YOU FROM DIALING ANY NUMBER BUT A SPECIAL NUMBER.**

### To store Special Numbers:


1. Press **Menu** () , then select **Toolbox**, **Settings**, and **Security**. Press .
- The “**User Lock**” prompt pops up in the display.
2. Enter the four-digit lock code using the keypad.

**NOTE: THE DEFAULT LOCK CODE IS 0-0-0-0 (FOUR ZEROES).**

The “**User Lock**” prompt disappears and the **Security** menu appears in the display.



3. Press  for **Special Numbers**. The **Special Numbers** screen appears in the display.
4. Select one of the three Special Numbers.
5. To change the highlighted Special Number, press  or **Edit** ().
6. Enter the emergency number (up to 32 digits in length).  
(See [Section 5, “Entering Text,”](#) for more information.)
7. Press the  key to cancel your entry and return to **Idle** mode.
8. Press  to save the number you entered.

### To call Special Numbers while in Lock Mode:

1. In **Idle** mode, enter the emergency number using the keypad.
2. Press  to place the call.




### Delete Contacts

The Delete Contacts option lets you erase all entries you’ve added to your Contact List.

1. Press **Menu** () , then select **Toolbox**, **Settings**, and **Security**. Press .
- The “**User Lock**” prompt pops up in the display.
2. Enter the four-digit lock code using the keypad.

**NOTE: THE DEFAULT LOCK CODE IS 0-0-0-0 (FOUR ZEROES).**




The “**User Lock**” prompt disappears and the **Security** menu appears in the display.

3. Press  for **Delete Contacts**. You are prompted to confirm that you want to “**Delete Entire Contacts?**”
4. To cancel the deletion and keep the entries in your Contacts list, select **No**.  
To confirm the deletion and remove all entries from your Contacts list, select **Yes**.
5. Press  to carry out your selection.  
If you selected **Yes**, you are prompted a second time to confirm that you understand that “**This will delete the entire Contacts.**”
6. To cancel the deletion and keep the entries in your Contacts list, select **No**.  
To confirm the deletion and remove all entries from your Contacts list, select **Yes**.
7. Press  to carry out your selection.


## SETUP/OTHERS

### Shortcuts

The Up, Down, Left, and Right Navigation Keys (NAV KEY) can be customized to launch any one of numerous applications or functions on your phone from **Idle** mode. Use the **Shortcuts** sub-menus to choose the application that you wish each navigation key to launch.












1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others**, and **Shortcuts**. Press  . The following options appear in the display:
  - **Left Navigation**
  - **Right Navigation**
  - **Up Navigation**
  - **Down Navigation**
2. Select the shortcut you want to change.
3. Press  . The following options appear in the display.
  - **Menu**
  - **Contacts**
  - **Messaging**
  - **Family Center**
  - **Entertainment**
  - **Toolbox**
  - **Calendar**

The current shortcut setting is highlighted.




4. Select the desired function.
5. Press  to save your selection.

### Answer Call

The Answer Call option lets you specify what action you wish to take to answer incoming calls.

1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others**, and **Answer Call**. Press  . The following options appear in the display:
  - **Any Key** — Press any key except the  key,  key,  key,  key, or **Ignore** (  ) to answer an incoming call.
  - **Talk or OK Key** — Press  or  to answer an incoming call.
  - **Flip Activation** — Open the flip or press  to answer an incoming call.
2. Select the method you wish to use for answering calls and press  to save.


### Auto Answer

1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others**, and **Auto Answer**. Press  . The following options appear in the display:
  - **Car Kit/Headset**
  - **Off**
2. Select the desired setting and press  to save.

## Dialing Match

### Abbreviated Dial

The Abbreviated Dial option lets you reduce the number of digits you dial for Contacts entries that all begin with the same 5–6 digits.

1. Press **Menu** (⋮), then select **Toolbox, Settings, Setup/Others, Dialing Match**, and **Abbreviated Dial**. Press . The following options appear in the display:


- On
- Off

2. Select **On** or **Off** and press .

When you select **On**, the **Abbreviated Dial – Edit Number** box pops up in the display.

3. Enter the first 5–6 digits common to all the Contacts entries you will be dialing using Abbreviated Dial.



### Contacts Match

1. Press **Menu** (⋮), then select **Toolbox, Settings, Setup/Others, Dialing Match**, and **Contacts Match**. Press . The following options appear in the display:


2. Select **On** or **Off** and press  to save.

## Text Entry



### Auto Capital

1. Press **Menu** (⋮), then select **Toolbox, Settings, Setup/Others, Text Entry**, and **Auto Capital**. Press .
2. Select **On** or **Off** and press  to save.



### Personal Dictionary

1. Press **Menu** (⋮), then select **Toolbox, Settings, Setup/Others, Text Entry**, and **Personal Dic.** Press . The **Personal Dic.** screen appears in the display.
2. To find a word, enter the first few characters in the **Word** field.
3. To add a word, press **Add** (⋮). The Personal Dic. text entry screen appears in the display.
4. Enter a new dictionary entry using the keypad. (See [Section 5, “Entering Text,”](#) for more information.)
5. To add the new entry, press **Done** (⋮).
6. To delete entries, select an entry.
7. Press **Options** (⋮) and select **Delete** or **Delete All**.




### Used Word Dictionary

1. Press **Menu** (⋮), then select **Toolbox, Settings, Setup/Others, Text Entry**, and **Used Word Dictionary**. Press . The following options appear in the display:
2. Select **Yes** or **No** and press  to save.




### Display Candidate

1. Press **Menu** (⋮), then select **Toolbox, Settings, Setup/Others, Text Entry**, and **Display Candidate**. Press . The following options appear in the display:
  - Multiple Line
  - In Line
2. Select the desired option and press  to save.




## Prediction Start

1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others, Text Entry**, and **Prediction Start**. Press  . The following options appear in the display:
  - 3rd letters
  - 4th letters
  - 5th letters
2. Select the desired option and press  to save.




## Dual Language

1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others, Text Entry**, and **Dual Language**. Press  . The following options appear in the display:
  - None
  - Spanish
2. Select the desired option and press  to save.

## Insert Space




1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others, Text Entry**, and **Insert Space**. Press  . The following options appear in the display:
2. Select **On** or **Off** and press  to save.

## Help

1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others, Text Entry**, and **Help**. Press  . Instructions for using T9 Word entry mode are presented.
2. Page through the help text using the NAV KEY.
3. Press  key to return to the **Text Entry** menu.

## Language




The Language option changes the language of menus, sub-menus, and other user-interface features.

1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others**, and **Language**. Press  . The following options appear in the display:
  - English
  - Español
2. Select your language preference and press  to save.

## TTY Options

Your phone is fully Teletypewriter (TTY)/Telecommunication Device for the Deaf (TDD) compatible. You connect TTY/TDD equipment to the headset connector on the top of your phone, behind the folder hinge.

**NOTE: TTY MODE MUST BE ENABLED (TTY FULL SELECTED) BEFORE YOU CAN USE YOUR PHONE WITH TTY/TDD EQUIPMENT.**

1. Press **Menu** (  ), then select **Toolbox, Settings, Setup/Others**, and **TTY Options**. Press  .  
A message pops up warning of possible headset and non-TTY accessory performance impairment when in TTY mode.
2. Press  . The following options appear in the display:
  - **TTY Off** — Disables TTY mode.
  - **TTY Full** — Enables TTY mode while letting you hear and speak with the other party.
  - **TTY + Hear** — Enables TTY mode while letting you hear the other party.
  - **TTY + Talk** — Enables TTY mode while letting you speak with the other party.




**NOTE: THE TTY MODE OPTION HAS NO EFFECT ON THE PHONE'S EARPIECE, MICROPHONE, OR SPEAKER. WHEN YOU SELECT TTY FULL, ALL CURRENTLY ENABLED SOUND FUNCTIONS REMAIN ENABLED.**

3. Highlight your selection and press . You're returned to the previous menu and the TTY icon () appears in the top of the display.

## Airplane Mode


When set to **On**, Airplane Mode disables all radio functions of your phone. This prevents you from making or receiving calls, but allows you to use other features (such as the Camera and the Tools) safely in sensitive environments, such as on board an aircraft.

1. Press **Menu** () , then select **Toolbox, Settings, Setup/Others,** and **Airplane Mode**. Press  .
  - **On** — Disables the radio transmitter and receiver in your phone.

**TIP: IF YOU NEED TO MAKE AN EMERGENCY CALL WITH AIRPLANE MODE ENABLED, JUST DIAL THE EMERGENCY NUMBER AND PRESS .**




- **Off** — Enables the radio transmitter and receiver in your phone.

**NOTE: PRESS  TO RETURN TO THE PHONE SETTINGS MENU.**

- **On Power Up** — Disables the radio transmitter and receiver in your phone when you turn it on.
2. Select the desired option and press  to save.

## Location


You can set your phone to pass Global Positioning System (GPS) data to identify your location to the network continually or only when you make an emergency (911) call.

1. Press **Menu** () , then select **Toolbox, Settings, Setup/Others,** and **Location**. Press  . The following Location options appear in the display:
  - **On** — Your location data is continually sent wherever the feature is available.
  - **Off** — Your location data is sent only when you dial 911.
2. Select an option and press  to save.

**NOTE: IN "OFF" MODE, THE FAMILY LOCATOR SERVICE WILL NOT BE AVAILABLE OR ACTIVE.**

## Key Guard

When set to **On**, the Key Guard option locks the Volume and Camera keys when you close the flip.




1. Press **Menu** () , then select **Toolbox, Settings, Setup/Others,** and **Key Guard**. Press  .
2. Select **On** or **Off** and press  to save.

## PHONE INFO

**Phone Info** lets you identify the hardware and software versions of your phone and identify the phone number assigned to your phone.




### Device Info

View the numbers assigned to your phone.

1. Press **Menu** (  ), then select **Toolbox, Settings, Phone Info**, and **Device Info**. Press .
2. Your MDN (phone number), MSID, and the phone's ESN appear in the display.
3. Press  to return to the **Phone Info** menu.




### Version

You can view the PRL (Preferred Roaming List), software version, and hardware version on your phone.

1. Press **Menu** (  ), then select **Toolbox, Settings, Phone Info**, and **Version**. Press .
- Hardware and software information for your phone appears in the display.
2. Press  to return to the **Phone Info** menu.

### Icon Glossary

View the icons that can appear in the top line of your phone's display and the names of the icons.

1. Press **Menu** (  ), then select **Toolbox, Settings, Phone Info**, and **Icon Glossary**. Press .
2. To page through the Icon Glossary, use the NAV KEY.
3. Press  to return to the **Phone Info** menu.

# SECTION 13

## HEALTH AND SAFETY INFORMATION

### Topics Covered

- Health and Safety Information
- UL Certified Travel Adapter
- Consumer Information on Wireless Phones
- Road Safety
- Operating Environment
- Using Your Phone Near Other Electronic Devices
- Potentially Explosive Environments
- Emergency Calls
- FCC Notice and Cautions
- Other Important Safety Information
- Product Performance
- Availability of Various Features/Ringtones
- Battery Standby and Talk Time
- Battery Precautions
- Care and Maintenance

**This section outlines the safety precautions associated with using your phone. These safety precautions should be followed to safely use your phone.**

### HEALTH AND SAFETY INFORMATION

#### *Exposure to Radio Frequency (RF) Signals*

##### **Certification Information (SAR)**

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. government. These FCC exposure limits are derived from the

recommendations of two expert organizations, the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg). The FCC exposure limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC. For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

The FCC has granted an Equipment Authorization for this mobile phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. The maximum SAR values for this model phone as reported to the FCC are:

AMPS/CDMA mode (Part 22):

Head: 0.488 W/Kg

Body-worn: 0.378 W/Kg

PCS mode (Part 24):

Head: 1.46 W/Kg

Body-worn: 0.571 W/Kg

SAR information on this and other model phones can be viewed on-line at [www.fcc.gov/cgb/sar](http://www.fcc.gov/cgb/sar). To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone. Sometimes it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional product specific SAR information can also be obtained at [www.fcc.gov/cgb/sar](http://www.fcc.gov/cgb/sar).

## UL CERTIFIED TRAVEL ADAPTER

The Travel Adapter for this phone has met UL 1310 safety requirements. Please adhere to the following safety instructions per UL guidelines.

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.

FOR CONNECTION TO A SUPPLY NOT IN THE U.S.A., USE AN ATTACHMENT PLUG ADAPTER OF THE PROPER CONFIGURATION FOR THE POWER OUTLET. THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTATED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.

## CONSUMER INFORMATION ON WIRELESS PHONES

The U.S. Food and Drug Administration (FDA) has published a series of Questions and Answers for consumers relating to radio frequency (RF) exposure from wireless phones. The FDA publication includes the following information:

### *What kinds of phones are the subject of this update?*

The term wireless phone refers here to hand-held wireless phones with built-in antennas, often called "cell," "mobile," or "PCS" phones. These types of wireless phones can expose the user to measurable radio frequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures well within the FCC's compliance limits.

### *Do wireless phones pose a health hazard?*

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radio frequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

### ***What is FDA's role concerning the safety of wireless phones?***

Under the law, FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radio frequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure.

FCC relies on FDA and other health agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the primary subject of the safety questions discussed in this document.

### ***What are the results of the research done already?***

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radio frequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phones RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

### ***What research is needed to decide whether RF exposure from wireless phones poses a health risk?***

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but ten or more years' follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop—if they do—may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

### ***What is FDA doing to find out more about the possible health effects of wireless phone RF?***

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radio frequency energy (RF).

FDA has been a leading participant in the World Health Organization international Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic

organizations. CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

### ***What steps can I take to reduce my exposure to radio frequency energy from my wireless phone?***

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radio frequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

- If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna.

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

### ***What about children using wireless phones?***

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radio frequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.



Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

### ***Do hands-free kits for wireless phones reduce risks from exposure to RF emissions?***

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used with wireless phones for convenience and comfort. These systems reduce the absorption of RF energy in the head because the phone, which is the source of the RF emissions, will not be placed against the head. On the other hand, if the phone is mounted against the waist or other part of the body during use, then that part of the body will absorb more RF energy. Wireless phones marketed in the U.S. are required to meet safety requirements regardless of whether they are used against the head or against the body. Either configuration should result in compliance with the safety limit.

### ***Do wireless phone accessories that claim to shield the head from RF radiation work?***

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that accessories that claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone. Studies have shown that these products generally do not work as advertised. Unlike “hand-free” kits, these so-called “shields” may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate,

leading to an increase in RF absorption. In February 2002, the Federal Trade Commission (FTC) charged two companies that sold devices that claimed to protect wireless phone users from radiation with making false and unsubstantiated claims. According to FTC, these defendants lacked a reasonable basis to substantiate their claim.

### ***What about wireless phone interference with medical equipment?***

Radio frequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI. FDA has tested wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a compatible phone and a compatible hearing aid at the same time. This standard was approved by the IEEE in 2000.

FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations:

- FCC RF Safety Program:  
<http://www.fcc.gov/oet/rfsafety/>
- Environmental Protection Agency (EPA):  
<http://www.epa.gov/radiation/>

- Occupational Safety and Health Administration (OSHA):  
<http://www.osha.gov/SLTC/radiofrequencyradiation/index.html>
- National Institute for Occupational Safety and Health (NIOSH):  
<http://www.cdc.gov/niosh/topics/emf/>
- World Health Organization (WHO):  
<http://www.who.int/peh-emf/en>
- International Commission on Non-Ionizing Radiation Protection:  
<http://www.icnirp.de>
- National Radiation Protection Board (UK):  
<http://www.hpa.org.uk/radiation>
- US Food and Drug Administration  
<http://www.fda.gov/cellphones>

## ROAD SAFETY

Your wireless phone gives you the powerful ability to communicate by voice, almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

1. Get to know your wireless phone and its features, such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
2. When available, use a hands-free device. If possible, add an additional layer of convenience and safety to your wireless phone with one of the many hands-free accessories available today.
3. Position your wireless phone within easy reach. Be able to access your wireless phone without removing your eyes from the road. If you get an incoming call at an inconvenient time, let your voice mail answer it for you.

4. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice and even heavy traffic can be hazardous.
5. Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility, driving safely.
6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
7. Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.
8. Use your wireless phone to call for help. Dial 9-1-1 or other local emergency number in the case of fire, traffic accident, or medical emergencies. Remember, it is a free call on your wireless phone!
9. Use your wireless phone to help others in emergencies. If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.
10. Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency number.

**"The wireless industry reminds you to use your phone safely when driving."**

For more information, please call 1-888-901-SAFE, or visit our web-site [www.ctia.org/](http://www.ctia.org/)

Provided by the Cellular Telecommunications & Internet Association.



## OPERATING ENVIRONMENT

Remember to follow any special regulations in force in any area and always switch your phone off whenever it is forbidden to use it, or when it may cause interference or danger. When connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder if you are using an external antenna).

## USING YOUR PHONE NEAR OTHER ELECTRONIC DEVICES

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Consult the manufacturer to discuss alternatives.

### *Pacemakers*

Pacemaker manufacturers recommend that a minimum distance of 15 cm (6 inches) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker.

These recommendations are consistent with the independent research and recommendations of Wireless Technology Research.

#### **Persons with pacemakers:**

- should always keep the phone more than 15 cm (6 inches) from their pacemaker when the phone is switched on.
- should not carry the phone in a breast pocket.

- should use the ear opposite the pacemaker to minimize potential interference.

If you have any reason to suspect that interference is taking place, switch your phone off immediately.

### *Hearing Aids*

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may wish to consult your hearing aid manufacturer to discuss alternatives.

### *Other Medical Devices*

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your phone off in healthcare facilities when any regulations posted in these areas instruct you to do so. Hospitals or healthcare facilities may be using equipment that could be sensitive to external RF energy.

### *Vehicles*

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

### *Posted Facilities*

Switch your phone off in any facility where posted notices require you to do so.

## POTENTIALLY EXPLOSIVE ENVIRONMENTS

Switch your phone off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Users are advised to switch the phone off while at a refueling point (service station). Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress.


Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

## EMERGENCY CALLS

This phone, like any wireless phone, operates using radio signals, wireless and landline networks as well as user-programmed functions, which cannot guarantee connection in all conditions. Therefore, you should never rely solely on any wireless phone for essential communications (medical emergencies, for example).

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and/or phone features are in use. Check with local service providers.

To make an emergency call:

1. If the phone is not on, switch it on.
2. Key in the emergency number for your present location (for example, 911 or other official emergency number). Emergency numbers vary by location.
3. Press the  key.

If certain features are in use (call barring, for example), you may first need to deactivate those features before you can make an emergency call. Consult this document and your local cellular service provider.

When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your phone may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

## *Restricting Children's Access to your Phone*

Your phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone, or make calls that increase your phone bill.

## FCC NOTICE AND CAUTIONS

### *FCC Notice*

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.

### *Cautions*

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment, and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending, or sitting on it.

## OTHER IMPORTANT SAFETY INFORMATION

### Other Important Safety Information

- Only qualified personnel should service the phone or install the phone in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch your phone off before boarding an aircraft. The use of wireless phone in aircraft is illegal and may be dangerous to the aircraft's operation.
- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

## PRODUCT PERFORMANCE

### *Getting the Most Out of Your Signal Reception*

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current signal strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal.

If you're inside a building, being near a window may give you better reception.

### *Understanding the Power Save Feature*

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. If your phone is active, it periodically rechecks service availability or you can check it yourself by pressing any key.

Anytime the Power Save feature is activated, a message displays on the screen.

When a signal is found, your phone returns to standby mode.

### *Understanding How Your Phone Operates*

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watts to 0.2 watts in digital mode.

### *Maintaining Your Phone's Peak Performance*

For the best care of your phone, only authorized personnel should service your phone and accessories. Faulty service may void the warranty.

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- If your phone is equipped with an external antenna, hold the phone with the antenna raised, fully-extended, and over your shoulder.
- Do not hold, bend, or twist the phone's antenna, if applicable.
- Do not use the phone if the antenna is damaged.
- If your phone is equipped with an internal antenna, obstructing the internal antenna could inhibit call performance.
- Speak directly into the phone's receiver.
- Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it is inoperable, call Customer Care for service.

## AVAILABILITY OF VARIOUS FEATURES/RINGTONES

Many services and features are network dependent and may require additional subscription and/or usage charges. Not all features are available for purchase or use in all areas. Downloadable Ring Tones may be available at an additional cost. Other conditions and restrictions may apply. See your service provider for additional information.

## BATTERY STANDBY AND TALK TIME

Standby and talk times will vary depending on phone usage patterns and conditions. Battery power consumption depends on factors such as network configuration, signal strength, operating temperature, features selected, frequency of calls, and voice, data, and other application usage patterns.

## BATTERY PRECAUTIONS

- Avoid dropping the cell phone. Dropping it, especially on a hard surface, can potentially cause damage to the phone and battery. If you suspect damage to the phone or battery, take it to a service center for inspection.
- Never use any charger or battery that is damaged in any way.
- Use the battery only for its intended purpose.
- If you use the phone near the network's base station, it uses less power; talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the network operator.
- Follow battery usage, storage, and charging guidelines found in the user's guide.
- Battery charging time depends on the remaining battery charge and the type of battery and charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time (talk time and standby time) is noticeably shorter than normal, it is time to buy a new battery.

- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries and recharge your battery only with Samsung-approved chargers. When a charger is not in use, disconnect it from the power source. Do not leave the battery connected to a charger for more than a week, since overcharging may shorten its life.
- Do not use incompatible cell phone batteries and chargers. Some Web sites and second-hand dealers, not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers. Consumers should purchase manufacturer or carrier recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.
- Extreme temperatures will affect the charging capacity of your battery: it may require cooling or warming first.
- Do not leave the battery in hot or cold places, such as in a car in summer or winter conditions, as you will reduce the capacity and lifetime of the battery. Always try to keep the battery at room temperature. A phone with a hot or cold battery may temporarily not work, even when the battery is fully charged. Li-ion batteries are particularly affected by temperatures below 0° C (32° F).
- Do not place the phone in areas that may get very hot, such as on or near a cooking surface, cooking appliance, iron, or radiator.
- Do not get your phone or battery wet. Even though they will dry and appear to operate normally, the circuitry could slowly corrode and pose a safety hazard.
- Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object (coin, clip or pen) causes a direct connection between the + and - terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.

- Do not permit a battery out of the phone to come in contact with metal objects, such as coins, keys, or jewelry.
- Do not crush, puncture or put a high degree of pressure on the battery as this can cause an internal short-circuit, resulting in overheating.
- Dispose of used batteries in accordance with local regulations. In some areas, the disposal of batteries in household or business trash may be prohibited. For safe disposal options for Li-Ion batteries, contact your nearest Samsung authorized service center. Always recycle. Do not dispose of batteries in a fire.

## CARE AND MAINTENANCE

Your phone is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years.

- Keep the phone and all its parts and accessories out of the reach of small children.
- Keep the phone dry. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits.
- Do not use the phone with a wet hand. Doing so may cause an electric shock to you or damage to the phone.
- Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.
- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.

- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.
- Do not paint the phone. Paint can clog the device's moving parts and prevent proper operation.
- Do not put the phone in or on heating devices, such as a microwave oven, a stove, or a radiator. The phone may explode when overheated.
- If your phone is equipped with an external antenna, use only the supplied or an approved replacement antenna. Unauthorized antennas or modified accessories may damage the phone and violate regulations governing radio devices.
- If the phone, battery, charger, or any accessory is not working properly, take it to your nearest qualified service facility. The personnel there will assist you and, if necessary, arrange for service.

## SECTION 14

### WARRANTY INFORMATION

#### Topics Covered

- **Standard Limited Warranty**

#### STANDARD LIMITED WARRANTY

##### What is Covered and For How Long?

SAMSUNG TELECOMMUNICATIONS AMERICA, L.P. ("SAMSUNG") warrants to the original purchaser ("Purchaser") that SAMSUNG's Phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Phone 1 Year

Batteries 1 Year

Leather Case/ Pouch 90 Days

Holster 90 Days

Other Phone Accessories 1 Year

##### What is Not Covered?

This Limited Warranty is conditioned upon proper use of Product by Purchaser. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abuse, neglect, unusual physical, electrical or electromechanical stress, or modification of any part of Product, including antenna, or cosmetic damage; (b) equipment that has the serial number removed or made illegible; (c) any plastic surfaces or other externally exposed parts that are scratched or damaged due to normal use; (d) malfunctions resulting from the use of Product in conjunction with accessories, products, or ancillary/peripheral equipment not furnished or approved by SAMSUNG; (e) defects or damage from improper testing,

operation, maintenance, installation, or adjustment; (f) installation, maintenance, and service of Product; or (g) Product used or purchased outside the United States or Canada. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

##### What are SAMSUNG's Obligations?

During the applicable warranty period, SAMSUNG will repair or replace, at SAMSUNG's sole option, without charge to Purchaser, any defective component part of Product. To obtain service under this Limited Warranty, Purchaser must return Product to an authorized phone service facility in an adequate container for shipping, accompanied by Purchaser's sales receipt or comparable substitute proof of sale showing the date of purchase, the serial number of Product and the seller's name and address. To obtain assistance on where to deliver the Product, call Samsung Customer Care at 1-888-987-4357. Upon receipt, SAMSUNG will promptly repair or replace the defective Product. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product or replace Product with a rebuilt, reconditioned or new Product. Repaired/ replaced leather cases, pouches, and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Product will be warranted for a period equal to the remainder of the original Limited Warranty on the original Product or for 90 days, whichever is longer. All replaced parts, components, boards and equipment shall become the property of SAMSUNG. If SAMSUNG determines that any Product is not covered by this Limited Warranty, Purchaser must pay all parts, shipping, and labor charges for the repair or return of such Product.



## WHAT ARE THE LIMITS ON SAMSUNG'S WARRANTY/LIABILITY?

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED HEREIN, PURCHASER TAKES THE PRODUCT "AS IS," AND SAMSUNG MAKES NO WARRANTY OR REPRESENTATION AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO:

- THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE;
- WARRANTIES OF TITLE OR NON-INFRINGEMENT;
- DESIGN, CONDITION, QUALITY, OR PERFORMANCE OF THE PRODUCT;
- THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR
- COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION, OR CONTRACT PERTAINING THERETO.

NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. ALL IMPLIED WARRANTIES AND CONDITIONS THAT MAY ARISE BY OPERATION OF LAW, INCLUDING IF APPLICABLE THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED TO THE SAME DURATION OF TIME AS THE EXPRESS WRITTEN WARRANTY STATED HEREIN. SOME STATES/PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE, USE, OR MISUSE OF, OR INABILITY TO USE THE PRODUCT OR ARISING DIRECTLY OR INDIRECTLY FROM THE USE OR LOSS OF USE OF THE PRODUCT OR FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL, CONSEQUENTIAL OR SIMILAR DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS, OR FOR DAMAGES ARISING FROM ANY TORT (INCLUDING NEGLIGENCE OR GROSS NEGLIGENCE) OR FAULT COMMITTED BY SAMSUNG, ITS AGENTS OR EMPLOYEES, OR FOR ANY BREACH OF CONTRACT OR FOR ANY CLAIM BROUGHT AGAINST PURCHASER BY ANY OTHER PARTY. SOME STATES/PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE/PROVINCE TO PROVINCE. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT AND STATES PURCHASER'S EXCLUSIVE REMEDY. IF ANY PORTION OF THIS LIMITED WARRANTY

IS HELD ILLEGAL OR UNENFORCEABLE BY REASON OF ANY LAW, SUCH PARTIAL ILLEGALITY OR UNENFORCEABILITY SHALL NOT AFFECT THE ENFORCEABILITY FOR THE REMAINDER OF THIS LIMITED WARRANTY WHICH PURCHASER ACKNOWLEDGES IS AND WILL ALWAYS BE CONSTRUED TO BE LIMITED BY ITS TERMS OR AS LIMITED AS THE LAW PERMITS. THE PARTIES UNDERSTAND THAT THE PURCHASER MAY USE THIRD-PARTY SOFTWARE OR EQUIPMENT IN CONJUNCTION WITH THE PRODUCT. SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRDPARTY SOFTWARE OR EQUIPMENT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE, INCLUDING THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT. THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT LAY SOLELY WITH THE PURCHASER AND THE DIRECT VENDOR, OWNER, OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT, AS THE CASE MAY BE.

This Limited Warranty allocates risk of Product failure between Purchaser and SAMSUNG, and SAMSUNG's Product pricing reflects this allocation of risk and the limitations of liability contained in this Limited Warranty. The agents, employees, distributors, and dealers of SAMSUNG are not authorized to make modifications to this Limited Warranty, or make additional warranties binding on SAMSUNG. Accordingly, additional statements such as dealer advertising or presentation, whether oral or written, do not constitute warranties by SAMSUNG and should not be relied upon.

Samsung Telecommunications America, L.P.  
1301 East Lookout Drive  
Richardson, Texas 75082  
Phone: 1-800-SAMSUNG  
Phone: 1-888-987-HELP (4357)

©2007 Samsung Telecommunications America. All rights reserved.  
No reproduction in whole or in part allowed without prior written approval.  
Specifications and availability subject to change without notice.

# INDEX

## A

Abbreviated Dialing . . . . .	79
Alarm Clock . . . . .	68
Always On Numbers (Call Control) . . . . .	45
Answering a Call . . . . .	16
Applications (Entertainment) . . . . .	55
Assigning Ringtones, Themes, and Images (Entertainment) ..	51–53
Assigning Schedules (Call Control) . . . . .	45

## B

Backlight . . . . .	11, 72
Battery . . . . .	5
Charging . . . . .	6
Installing . . . . .	5
Removing . . . . .	6
Bluetooth® . . . . .	65

## C

Calculator . . . . .	70
Call Control (Family Center) . . . . .	44–46
Accessing . . . . .	45
Adding Always On and Prohibited Numbers . . . . .	46
Always On and Prohibited Numbers . . . . .	45
Assigning Schedules . . . . .	45
Creating Schedules . . . . .	45
Restricted Periods . . . . .	44
Call History . . . . .	16
Camera . . . . .	57–62
Camera Options . . . . .	59–62
Taking a Pix . . . . .	57–59
Uploading Pix to Pictureland™ . . . . .	57–58; 62–63

Contacts . . . . .	25
Adding a Contact . . . . .	26
Finding a Contact . . . . .	25
Services . . . . .	33
Speed Dial . . . . .	32

## D

Display Screen and Icons . . . . .	10
Disney Zone (Entertainment) . . . . .	56
Downloading . . . . .	
Entertainment Content . . . . .	50–51
Pix Messages . . . . .	36

## E

Emoticons . . . . .	24
End Key . . . . .	12
Entering Text . . . . .	22–24
Changing Text Entry Mode . . . . .	22
Entertainment . . . . .	49–56
Disney Zone . . . . .	56
My Applications . . . . .	55
My Games . . . . .	55
My Images . . . . .	52
My Ringtones . . . . .	51
My Subscriptions . . . . .	56
My Themes . . . . .	52
Previewing . . . . .	50
Purchasing and Downloading . . . . .	50
Shopping . . . . .	49



## F

<b>Family Alert!™</b> . . . . .	46–48
Accessing . . . . .	47
Editing Alerts . . . . .	47
Sending Alerts . . . . .	47
Viewing Alerts Received . . . . .	47–48

<b>Family Center™</b> . . . . .	40–48
Accessing . . . . .	41
Call Control . . . . .	44–46
Family Alert!™ . . . . .	46–48
Family Locator™ . . . . .	41–42
Family Member Roles . . . . .	40
Family Monitor™ . . . . .	42–44

<b>Family Locator™</b> . . . . .	41–42
Accessing . . . . .	41
Setting PIN . . . . .	41–42
Locating Kid's Phone . . . . .	41–42
Viewing Maps . . . . .	42

<b>Family Manager</b> . . . . .	40–48
---------------------------------	-------

<b>Family Monitor™</b> . . . . .	42–44
Accessing . . . . .	43
Receiving Spending Alerts . . . . .	44
Setting Allowances . . . . .	43
Viewing Usage . . . . .	43–44

## G

<b>Games (Entertainment)</b> . . . . .	55
<b>Getting Started</b> . . . . .	5

## H

<b>Health and Safety Information</b> . . . . .	83–93
--	-------

## I

<b>Icons</b> . . . . .	10–11
<b>Idle Mode</b> . . . . .	13
<b>Images (Entertainment)</b> . . . . .	52–55
<b>Inbox</b> . . . . .	37

## K

<b>Keypad Functions</b> . . . . .	8–9
-----------------------------------	-----

## L

<b>Language Option</b> . . . . .	80
<b>Location Setting (GPS)</b> . . . . .	81
<b>Lock Code</b> . . . . .	75–76
<b>Lock Mode</b> . . . . .	13
<b>Low Battery Indicator</b> . . . . .	6

## M

<b>Making a Call</b> . . . . .	15
<b>Maps (Family Locator)</b> . . . . .	42
<b>Menu Navigation</b> . . . . .	20
<b>Menu Summary</b> . . . . .	20–21
<b>Messaging</b> . . . . .	34–39
Creating and Sending Messages . . . . .	34–35
Inbox . . . . .	37
<b>Missed Calls</b> . . . . .	17
<b>Mute/Unmute</b> . . . . .	18–19
<b>My Profile</b> . . . . .	57

## N

Navigation Key (NAV KEY) . . . . .	12
Notepad . . . . .	69

## O

OK Key . . . . .	12
Outbox . . . . .	38

## P

Pictureland™ . . . . .	40; 52–55
Initial Use on Phone . . . . .	53–54; 57–58; 62–63
Receiving Pix . . . . .	55
Sending Pix . . . . .	54
Uploading Pix . . . . .	57–58; 62–63
Pix Controls . . . . .	60–62
Pix Gallery . . . . .	52–53; 62–63
Pix Messaging . . . . .	36–37
Pix, Taking with Phone's Camera . . . . .	57–59
Prohibited Numbers (Call Control) . . . . .	45–46
Purchasing and Downloading Entertainment . . . . .	50

## Q

QuickAlerts (Family Alert!) . . . . .	46–48
Quicknotes . . . . .	23; 75

## R

Receiving Pix (Pictureland™) . . . . .	55
Receiving Pix Messages . . . . .	36
Receiving Text Messages . . . . .	36
Restricted Periods (Call Control) . . . . .	44
Ringtones (Entertainment) . . . . .	51–52
Roaming . . . . .	74

## S

Saving a Number After a Call . . . . .	30
Screens and Icons . . . . .	10–11
Security . . . . .	75
Self Timer . . . . .	60
Sending Messages . . . . .	34–35
Sending QuickAlerts (Family Alert!) . . . . .	47
Setting Allowances (Family Monitor) . . . . .	43
Setting Your PIN (Family Locator) . . . . .	41–42
Settings . . . . .	71–82
Shopping (Entertainment) . . . . .	49–50
Silent Mode . . . . .	14
Softkeys . . . . .	11
Sound Settings . . . . .	72
Speakerphone . . . . .	19
Spending Alerts (Family Monitor) . . . . .	44
Stopwatch . . . . .	70
Subscriptions (Entertainment) . . . . .	56

## T

T9 Text Input Mode . . . . .	22
Taking Pix . . . . .	57–59
Text Messages . . . . .	34–36
Themes (Entertainment) . . . . .	52
TTY Options . . . . .	80–81
Toolbox . . . . .	57–70
Turning the Phone On/Off . . . . .	6

## U

Understanding Your Phone . . . . .	8–14
------------------------------------	------

## V

Vibrate Mode . . . . .	14–15
Viewing Maps (Family Locator) . . . . .	41–42
Viewing Usage (Family Monitor) . . . . .	43–44
Voicemail . . . . .	7; 39
Voice Recorder . . . . .	63–64
Volume . . . . .	14; 16

## W

Warranty Information . . . . .	94–95
--------------------------------	-------

## Z

### Zoom

In Camera Mode . . . . .	61–62
Family Locator Maps . . . . .	42