

6LX
AT Form Factor
Main Board
User's Manual

Manual version: 1.1
Published in 1998

Copyright

Copyright ©1998 by this company. No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means without prior written permission. This manual and the information contained herein are protected by copyright. All rights reserved.

Warning and disclaimer

This manual is designed to provide information about the Pentium® II Socket 370- based main board. Every effort has been made to make this manual as accurate as possible, but no warranty or fitness is implied. All the information is provided on an 'as is' basis. The author and his corresponding publishing company shall have neither liability nor responsibility to any person or entity with respect to any loss or damages arising from the information contained in this manual or from the use of the system board that accompanies it.

Information contained in this manual is subject to change without notice. The manufacturer of the system board will not be held responsible for technical or editorial omissions made herein, nor for the incidental or consequential damages resulting from its furnishing, performance, functionality or use. Subsequent changes to this manual will be incorporated into the next edition. We welcome any suggestion regarding this manual or our computer products.

Trademarks

- **Intel and Pentium are registered trademarks of Intel Corporation.**
- **IBM is a registered trademark of International Business Machines Corporation.**
- **Microsoft is a registered trademark of Microsoft Corporation.**
- **PCI is a registered trademark of PCI Special Interest Groups.**
- **AWARD is a registered trademark of Award Software Inc.**

All other trademarks are the property of their respective owners.

Table of contents

■	Chapter 1 Introduction	1
1-1	6LX Main Board Overview.....	1
1-2	Specifications	3
1-3	Notice of Hardware Installation.....	5
1-4	Notice of CD Driver Installation.....	6
1-5	XStore Pro XStore Pro IDE driver.....	7
■	Chapter 2 Installation.....	8
2-1	Layout Reference.....	8
2-2	CPU Speed Setup.....	9
2-3	Jumper Setting.....	10
2-3-1	JBAT(Clearing Content of CMOS).....	10
2-3-2	JP4 (CPU & SDRAM Working Frequencies).....	11
2-4	Connectors	12
2-4-1	Front Panel.....	12
2-4-2	Back Panel.....	16
	<i>COM1 & COM2.....</i>	<i>17</i>
	<i>PS/2 AT Keyboard Connector.....</i>	<i>18</i>
	<i>PS/2 Mouse Connector.....</i>	<i>18</i>
	<i>LPT1.....</i>	<i>19</i>
	<i>USB1 (Universal Serial Bus) Connector.....</i>	<i>20</i>
2-4-3	P1: ATX Power Supply Connector.....	21
2-4-4	P2: AT Power Supply Connector.....	22
2-4-5	CPU Fan Connectors.....	23
2-4-6	I.R. : IrDA Connector.....	24
2-4-7	FDC: Floppy Disk Connector.....	25
2-4-8	IDE1 & IDE2.....	26
2-4-9	J7: SB-Link Connector.....	27

2-4-10	Wake Up On LAN.....	27
2-4-11	Sound on Board: J1, J2,J3,J4,J5(optional).....	28
2-5	Expansion Slots.....	29
2-6	DIMM Installation.....	31
■	Chapter 3 BIOS Setup.....	33
3-1	Award BIOS CMOS Setup.....	33
3-2	Standard CMOS Setup.....	34
3-3	BIOS Features Setup.....	36
3-4	Chipset Features Setup.....	40
3-5	Power Management Setup.....	43
3-6	PNP/PCI Configuration Setup.....	46
3-7	Integrated Peripherals.....	48
3-8	Supervisor/User Password.....	51
3-9	IDE HDD Auto Detection.....	54
3-10	Load Setup Defaults.....	57
3-11	Save and Exit Setup.....	58
3-12	Quit Without Saving.....	59
■	Chapter 4 Appendix.....	60
4-1	Memory Map.....	60
4-2	I/O Map.....	61
4-3	Time & DMA Channels Map.....	62
4-4	Interrupt Map.....	63
4-5	RTC & CMOS RAM Map.....	64
4-6	Award BIOS Hard Disk Type.....	65
4-7	ISA I/O Address Map.....	67
■	Chapter 5 Q & A.....	69

5-1	Error Messages During Power on Self Test.....	69
5-2	Frequently Asked Questions.....	71
5-3	Web-site Service.....	72

Chapter 1 Introduction

1-1 6LX Main Board Overview

6LX is a new-generation Pentium® II main board which integrates the latest advances in processor, memory, I/O technologies into an AT form factor. **6LX** utilizes Intel i440LX chipsets and supports new architectures such as high-speed AGP graphic Port, SDRAM, Ultra DMA/33, Bus master IDE and USB port.

6LX accepts Intel® Mendocino PPGA processors at 66MHz which is plugged into ZIF socket 370. Mendocino PPGA processor is based on P6 core but is made in a Plastic Pin Grid Array (PPGA) package. Mendocino PPGA processor is ranked as one of the P6 family to meet low cost of basic PC market. The processor is built in 128K L2 cache, so there is no cache necessary in this main board. PPGA packaging technology is similar to the Pentium® CPU package. Coming the advantages of ZIF socket 370, it saves time and cost in hardware installation.

6LX implements ITE I/O controller utilizing with fully Plug and Play devices and keyboard password setup. It supports 2.88 MB Floppy, Dual 16550 compatible (with 16 bytes FIFO, up to 460K baud rate) serial Port, ECP (Enhanced Capabilities Port), EPP (Enhanced Parallel Port) parallel port, Infrared IrDA (HPSIR), and Amplitude Shift Keyed IR. (ASKIR) port.

6LX contains 3*PCI & 2*ISA for highest performance I/O add-on adapter cards. The main board supports Three Bus Mastering Slots for high-performance I/O add-on cards. It supports Matrix Independent PCI Routing for optimal multiple PCI adapter operations. 133MB/s data transfer rate can be compared to 33MB/s on EISA bus, or 8MB/s on ISA bus. It support back to back sequential CPU to PCI Memory writes to PCI Burst Write for full PCI throughput.

6LX has three Dual In-line Memory Modules (DIMM) which can be installed with SDRAM memory . The memory subsystem supports up to 512Mbyte SDRAM of non-buffered 3.3V using standard 168-pin DIMM sockets.

6LX is strengthened with Power Management Wake up Event such as **“PS/2 Mouse Wake Up,” “Keyboard Wake Up,” “WOL (Wake up on LAN),” “Modem ring on,”** which are the new inventions to enable PCs to be turned on over the network or modem. These are also key benefits in PC operation, asset management, new system setup and power conservation. Hardware monitoring (optional) function also offers the system a further protection through auto detection of CPU temperature, speed, voltage and fan speed.

In addition to the above hardware features, this main board is jumperless design, which allows user to set CPU frequency through BIOS. No jumper or hardware DIP switch is needed. With this design, the disadvantages of setting hardware CPU jumpers are improved to a better and easier procedure through BIOS.

In conclusion, the system chipset and design make **6LX** a high performance, cost-effective, and energy efficient main board which meets a variety of price/performance levels. **6LX** main board is an ideal platform for the increasing requirements of today’s and future’s desktop application.

1-2 Specifications

- **PCB Board size:** 22.00 cm x 24.00 cm
- **PCB layer:** 4 layers
- **Socket 370:**
Socket 370 has 370 pins and supports 66MHz F.S.B Mendocino PPGA processor.



CPU is not enclosed in the package

- **Memory DIMM:** 3 of 168-pin 3.3V DIMM
 - Synchronous DRAM (SDRAM) with 168-pin DIMM modules of 8,16, 32, 64MB, 128MB for 66MHz
 - EDO RAM with 168-pin DIMM modules of 8,16, 32, 64MB, 128MB for 66MHz (3.3V only)
- **Expansion Slot :** 2x ISA slots, 3x PCI slots and 1x A.G.P. slot
- **Chipset :** Intel® i440LX chipset-----
 - FW82443LX
 - FW82371EB
- **BIOS:**
Licensed Award® full PnP (plug & play) BIOS, flash ROM BIOS
- **Green function:** Complied with APM (Advanced Power Management)

- **I/O function**
 - 2 x PCI IDE devices
 - 1 x FDC, 2 x serial ports(16550 fast com)
 - 1x parallel port device /EPP/ECP
 - 2x USB connector
 - IrDA (infrared) connector
- **Electrical--- Typical power supply**
Below is reference for power supply requirement.

Voltage	Tolerance	Current
+5V	±5%	22 Amperes
+3.3V	±5%	3 Amperes
+12V	± 10%	800 mA
-5V	±5%	150 mA
-12V	±5%	100 mA



To support functions such as “Wake up on LAN,” “Keyboard Wake up,” or “PS/2 Mouse Wake up,” we suggest that Pin 17 signal 5VSB on ATX Power supply should be able to offer at least 750 mA driving ability.

- Power Management Wake up
 - Keyboard Wake up
 - PS/2 Mouse Wake up
 - Wake Up On LAN
- **Sound on board (optional)**
 - ESS-Solo-1 (PCI Interface)
 - Line-in
 - Line-out
 - Microphone
 - Internal CD connector
 - Game port

- **Special features**
 - Jumperless design
 - Modem ring on
 - Creative PCI sound Blaster SB-link PC/PCI
 - Windows 95 power off
 - ATX & AT power supply support
 - Optional Hardware Monitoring : auto detection of CPU voltage, fan & temperature

1-3 Notice of Hardware Installation

Before hardware installing the main board, note the following things.

1. Check the package

If any of the below items is missing or damaged, contact the dealer from whom you purchase. Leave this main board in its original package until you are ready to install it. In the package, there are:

- **6LX** main board
- manual
- cables
- driver & utility / CD


B. Make sure power is off.

C. Avoid ESD (Electrical Static Discharge)

While working with **6LX** main board, always wear a grounded wristband or ankle strap to avoid ESD (Electrical Static Discharge).

1-4 Notice of CD Driver Installation

This CD contains below drivers. The user must read “Index” (HTML format) before installing required drivers. Index offers all the information on all the drivers.



CD driver is always updated with the latest version, so the actual CD content may have some difference with the above picture.

1. **Main boards:** i440BX®, i440EX®, i440LX®, i430TX®, VIA® VPX, VP3 main boards
2. **A.G.P cards:** S- 6326 and T985
3. **Sound:** ESS-solo-1 sound driver
4. **Thermal (GL518SM):** CPU voltage/temperature and fan speed detection software
5. **Pccillin:** anti- virus protection software
6. **XStore Pro IDE driver:** new IDE bus master driver for ULTRA DMA 33

1-5 XStore Pro IDE driver

Lucky Star has integrated High Point's new-invented software technology, "XStore Pro," to our valued customers as a free service. Developing the technique of "read ahead caching after seeking," XStore Pro increases hard disk performance. More concretely, when working with hard disk of large block sizes, it effectively enhances 50% hard disk performance, and 10% system performance.

System requirement

Under the below environments, the driver will perform its best in your system. No extra computer components are required.

- Windows 95 or Windows 98 environment
- Lucky Star main boards
- Recommended system memory: 32 MB or above

CD Driver enclosed in the package

CD ver. 2.0 has included XStore Pro IDE driver. If the driver enclosed is ver.1.9 or earlier ones, please download "XStore Pro" in the following website.


Website to bundle updated "XStore Pro" IDE driver

Updated drivers will be constantly provided at High Point's website. Lucky Star website is also linked to High Point.

- <http://www.lucky-star.com.tw>
- <http://highpoint-tech.com>


Chapter 2 Installation

2-1 Layout Reference



2-2 CPU Speed Setup

Since this is a jumperless design, there is no hardware jumper setting to adjust CPU speed. Enter BIOS, and comes the below screen. BIOS can recognize CPU speed automatically. Press “+” or “-” to select.



Since over-clocking setup is not included in chipset specification, we provide no guarantee for any loss or damage resulting from this.




After installing processor, make sure actual CPU speed is the same as in BIOS.

2-3 Jumper Setting

Benefiting from jumperless design, hardware installation becomes an easier procedure to achieve. There are only jumpers **RTC1** and **JP3** required of hardware handling.

2-3-1 RTC1- CMOS status



RTC1 is a 3-pin connector. Clear CMOS if system password is forgotten. Below is details to show how to clear CMOS.

Pin	Operation
1-2	Normal setup (default)
2-3	Clear CMOS

Procedure to clear CMOS:

Step 1: Shut down the system and disconnect the power supply from AC power.

Step 2: Pull out the power supply cable from the power connector.

Step 3: Short the CMOS jumper by putting jumper cap on Pin 2-3 for a few seconds.

Step 4: Return the cap to pin 1-2 at normal setup.


Step 5: Link the power cable to the connector & connect AC power to power supply.

Step 6: Turn on system power.

if you'd like to set password, press "Del" Key during system bootup to enter CMOS setup and establish a new password.

2-3-2 JP3: Flash ROM Voltage selector

JP3 is a 3-pin connector to select flash ROM voltage.




JP3: Flash ROM voltage	5V	12V
Operation	1-2	2-3

2-4 Connectors


There are many connectors on this main board. Refer to the following pages for details.

2-4-1 Front Panel Connectors

Front panel has connectors such as “PW-LED,” “Keylock,” “Speaker,” “Reset,” “HD-LED,” “SOFTPWR,” “TB-LED,” “SMI.” Please refer to the following further information.




Power LED is a 3-pin connector. It is used to connect to the LED on the case front panel. The LED shows the status of the power.




Keylock is a 2-pin connector. It is used to connect the key lock on the case front panel (if there is). With this function, keyboard may be locked (disconnected) with the system.

Keylock	Operation
Open	Keyboard works normal
Close	Short the connector to disconnect the system




Speaker (SPK) connector is a 4-pin keyed Berg strip. It is used to connect to the case speaker to the main board for sound purpose.




Reset connector is a 2-pin keyed Berg strip connected to the push button reset switch on the case's front panel. Shorting both pin 1 & pin 2 can effect system reset function, which is similar to the power off and then on again.


Reset	Operation
Open	Normal
Close	Hardware reset




Marked as "HDD-LED," Hard Disk activity LED connector is a 2-pin keyed Berg strip. It is used to connect to front panel Hard Disk LED.



Turbo LED with a 2-pin Berg strip on front panel indicates the current speed status of system. It is used to connect to the Turbo LED on the case front panel (if there is).




ATX SOFT-PWR switch connector is Soft-PWR with 2 pins.




SMI connector is a 2-pin Berg strip, which is also called “green” or “sleep” connector. When SMI is turned from open to close and back to open, the system will enter sleep mode immediately. This function is to make sure power saving is working well. In PC system, this connector is used to connect to the push button

SMI switch located on the case front panel (if there is). The system can be forced to power saving mode by pressing the SMI switch.




2-4-2 Back Panel Connectors

Back Panel Connectors are COM1/ COM2, LPT, AT keyboard connector, and PS/2 mouse on case back panel. Refer to below details.




Pin	Signal	Pin	Signal
Pin 1	Carrier detect (CD)	Pin 5	Signal ground
Pin 2	Receive data (RXD)	Pin 6	Data set ready
Pin 3	Transmit data (TXD)	Pin 7	Request to send (RTS)
Pin 4	Data terminal ready (DTR)	Pin 8	Clear to send (CTS)
Pin 9	Ring indicator	Pin10	None

AT Keyboard Connector




PS/2 Mouse Connector

PS/2 mouse is a 5-pin connector.



LPT1


The onboard parallel port is a 25-pin female connector. **It** supports standard printer port, Enhanced Parallel Port (EPP), Extended Capabilities Port (ECP).



Pin	Signal	Pin	Signal
Pin 1	Strobe	Pin 14	Auto feed
Pin 2	Data bit 0	Pin 15	Error
Pin 3	Data bit 1	Pin 16	Init
Pin 4	Data bit 2	Pin 17	SLCT in
Pin 5	Data bit 3	Pin 18	Ground
Pin 6	Data bit 4	Pin 19	Ground
Pin 7	Data bit 5	Pin 20	Ground
Pin 8	Data bit 6	Pin 21	Ground
Pin 9	Data bit 7	Pin 22	Ground
Pin 10	ACK	Pin 23	Ground
Pin 11	Busy	Pin 24	Ground
Pin 12	PE	Pin 25	Ground
Pin 13	SLCT	Pin 26	None

USB1: USB (Universal Serial Bus) Connector

Universal Serial Bus connector, marked as “USB,” is used to connect USB devices. There are 2 USB connectors on this main board.




USB pin out			
USB 1		USB 2	
Pin1	+5V	Pin6	+5V
Pin 2	USBP0	Pin7	USBP1
Pin 3	USBP0-	Pin8	USBP+
Pin 4	Ground	Pin9	Ground
Pin 5	Ground	Pin10	Ground

2-4-3 P1: ATX Power Supply Connector

ATX power connector has 20 pins, which is designed for ATX case especially. The ATX power supply supports the function of the “**Soft Power On Momentary switch**” which connects on the front panel switch to the 2-pin **SOFT-PWR** on the system board. While the power switch on the back of ATX power is turned on, the full power will not go into the system board until the front panel switch is momentarily pressed. Push the switch again to turn off the power to the system board.

ATX Power Supply Connector



Pin	Signal	Pin	Signal
Pin 1	3.3V	Pin 2	3.3V
Pin 3	3.3V	Pin 4	-12V
Pin 5	GND	Pin 6	GND
Pin 7	5V	Pin 8	SOFT-PWRON
Pin 9	GND	Pin 10	GND
Pin 11	5V	Pin 12	GND
Pin 13	GND	Pin 14	GND
Pin 15	RAWPOWER	Pin 16	-5V
*Pin 17	5VSB	Pin 18	5V
Pin 19	+12V	Pin 20	5V




To support functions such as “Wake up on LAN,” “Keyboard Wake up,” or “PS/2 Mouse Wake up,” we suggest that Pin 17 signal 5VSB on ATX Power supply should be able to offer at least 750 mA driving ability.

2-4-4 P2: AT Power Supply Connector

This main board is AT/ATX power switch designed. AT power supply connector is a 12-pin connector.

AT Power Supply Connector




Pin	Signal	Pin	Signal
1	Power Good	7	Ground
2	+5V DC	8	Ground
3	+12V	9	-5V DC
4	-12V	10	+5V DC
5	Ground	11	+5V DC
6	Ground	12	+5V DC

2-4-5 CPU Fan Connectors

There are 2 fan connectors on this system board, and they are marked as “FAN 1,” and “FAN2.” Each fan connector has three pins.

FAN1 and FAN2 : CPU fan connector


CPU Fan Pin Out					
Pin1	sensor	Pin2	+12V	Pin3	GND



2-4-6 I.R. : IrDA Connector


IR connector supports wireless infrared module. With this module and application software like Laplink, or Win95 Direct Cable Connection, user can transfer data to or from laptops, notebooks, PDA and printers. This connector supports **HPSIR**, **ASKIR**, and **Fast IR**.

Attach Infrared module to IR connector. Be sure to put in the right orientation during attachment.



2-4-7 FDC1


Floppy Disk connector has 34 pins and is used to attach the floppy drive cable.



Pin	Signal	Pin	Signal
Pin 1	GND	Pin 2	Data rate selection
Pin 3	GND	Pin 4	NC
Pin 5	GND	Pin 6	NC
Pin 7	GND	Pin 8	FDC index
Pin 9	GND	Pin 10	FDD Motor A enable
Pin 11	GND	Pin 12	FDD Drive B enable
Pin 13	GND	Pin 14	FDD drive A enable
Pin 15	GND	Pin 16	FDD Motor enable
Pin 17	GND	Pin 18	FDC head direction
Pin 19	GND	Pin 20	FDC step pulse output to the drive during a SEEK operation
Pin 21	GND	Pin 22	FDC write enable serial data to the Drive
Pin 23	GND	Pin 24	FDC write enable identify
Pin 25	GND	Pin 26	Floppy disk track 0. Indicates that the head of the selected drive is on track zero.
Pin 27	GND	Pin 28	FDD write protect. Indicates that the disk of the selected drive is write-protected.
Pin 29	GND	Pin 30	Read disk data, serial data input from the FDD
Pin 31	GND	Pin 32	Floppy disk side 1 select
Pin 33	GND	Pin 34	Floppy disk change. This is an input pin that senses whether the drive door has been opened or a diskette has been changed.

2-4-8 IDE1 & IDE2


IDE1 and IDE2 are 40 –pin IDE connectors. **IDE1** is primary channel, and **IDE2** is secondary channel. Each channel supports 2 IDE devices, and 4 devices in total for this main board.



Pin	Signal	Pin	Signal
Pin 1	IDE reset	Pin 2	Ground
Pin 3	Data 7	Pin 4	Data 8
Pin 5	Data 6	Pin 6	Data 9
Pin 7	Data 5	Pin 8	Data 10
Pin 9	Data 4	Pin 10	Data 11
Pin 11	Data 3	Pin 12	Data 12
Pin 13	Data 2	Pin 14	Data 13
Pin 15	Data 1	Pin 16	Data 14
Pin 17	Data 0	Pin 18	Data 15
Pin 19	Ground	Pin 20	Key (NC)
Pin 21	PDREQ	Pin 22	Ground
Pin 23	I/O write	Pin 24	Ground
Pin 25	I/O read	Pin 26	Ground
Pin 27	NC	Pin 28	ALE
Pin 29	NC	Pin 30	Ground
Pin 31	IDE IRQ 14	Pin 32	IOSC15
Pin 33	Address A1	Pin 34	NC
Pin 35	Address A0	Pin 36	Address A2
Pin 37	IDE chip select 0	Pin 38	IDE chip select 1
Pin 39	IDE active	Pin 40	Ground


2-4-9 J7: SB-Link Connector

SB-LINK is used to attach any “PC/PCI” standard sound card like Creative AWE64D or Yamaha XG...for compatibility under DOS mode.




2-4-10 Wake up on LAN

Wake up on LAN, marked as “**WOL1**,” is a 3-pin connector. To support this feature, a network card is required for the system and a network management software must be installed too.




2-4-11 Sound On Board : J1, J2,J3,J4,J5, J6 (optional)

Below are positions for the chip “Ess-Solo-1” and Connectors for Game(J1), Line-in, Microphone, Line-out, and CD-IN.




Cable enclosed in the package connecting the above headers. If there is no sound on board, this cable will not be enclosed in the package.



2-5 Expansion Slots

There are one AGP slot, three PCI slots, and two ISA slots on this main board.




AGP (Accelerated Graphic Port) is the new bus standard that allows the bus speed to run at 66 MHz with up to 133 MHz data transfer capabilities, which is four times as fast as that of the PCI bus. At this speed, the AGP graphic cards can transfer data up to 528MB/second. This high transfer capabilities enables 3D graphic applications, multiple media applications, uncompressed to run smoothly and display in broadcasting quality.

There are three PCI slots on board. 133MB/s data transfer rate on PCI bus can be compared to 33MB/s on EISA bus or 8MB/s on ISA bus. Synchronous Operation CPU to PCI interface has good graphic performance.


There are two standard 32-bit ISA slots on board. All of them are bus mastering.

2-6 DIMM Installation

Please make sure DIMM is 3.3V DIMM. Either DIMM 1, DIMM2, or DIMM3 supports 8 MB, 16 MB, 32 MB, 64 MB, and 128MB. **Maximum memory for SDRAM is up to 384MB; EDO RAM is up to 768 MB.** The user may insert DIMM modules in either DIMM1, DIMM2 or DIMM3.




Insert the module as shown. Due to different number of pins on either side of the breaks, the module will only fit in the orientation as shown. DRAM SIMM modules have the same pin contact on both sides. SDRAM DIMM modules have different pin contacts on each side and therefore have a higher pin density.



Chapter 3 BIOS Setup

3-1 Award® BIOS CMOS Setup



The menu displays all the major selection items and allow user to select any of shown item. The selection is made by moving cursor (press any direction key) to the item and press <Enter> key. An on-line help message is displayed at the bottom of the screen as cursor is moving to various items which provides user better understanding of each function. When a selection is made, the menu of selected item will appear. So the user can modify associated configuration parameters.

3-2 Standard CMOS Setup

```

ROM PCI/ISA BIOS (2A69JL11)
STANDARD CMOS SETUP
AWARD SOFTWARE, INC.

Date (mm:dd:yy) : Thu, Dec 3 1998
Time (hh:mm:ss) : 15 : 1 : 19

HARD DISKS          TYPE      SIZE    CYLS  HEAD  PRECOMP  LANOZ  SECTORS  MODE
-----
Primary Master    :  0      0      0  0    0      0      0      0  AUTO
Primary Slave     :  0      0      0  0    0      0      0      0  AUTO
Secondary Master  :  0      0      0  0    0      0      0      0  AUTO
Secondary Slave   :  0      0      0  0    0      0      0      0  AUTO

Drive A : 1.44M, 3.5 in.
Drive B : None
Floppy 3 Mode Support : Disabled

Video : EGA/VGA
Halt On : All Errors

ESC : Quit          ↑ ↓ ← → : Select Item      F1/F2/←/→ : Modify
F1 : Help          (Shift)F2 : Change Color

```

The "Standard CMOS Setup" allows user to configure system setting such as **current date and time**, **type of hard disk drive** installed in the system, **floppy drive type**, and the type of **display monitor**. Memory size is auto detected by the BIOS and displayed for your reference. When a field is highlighted (direction keys to move cursor and <Enter> key to select). The entries in the field will be changed by pressing <PageDown> or <PageUp> key or user can enter new data directly from the keyboard.



Hard Disk Configurations

1. **TYPE** : select from "1" to "45" to fill remaining fields with redefined values of disk drives. Select "USER" to fill the remaining fields. Select "AUTO" to detect the HDD type automatically.
2. **SIZE** : the hard disk size. The unit is mega byte(MB).
3. **CYLS** : the cylinder number of the hard disk.
4. **HEAD** : the read/write head number of hard disk. The range is from "1" to "16".
5. **PRECOMP**: the cylinder number at which the disk drive changes the write timing.
6. **LANDZ** : the cylinder number that the disk drive heads (read/write) are seated when the disk drive is parked.
7. **SECTOR** : the sector number of each track defined on the hard disk. The range is from "1" to "64".
8. **MODE** :select "AUTO" to detect the mode type automatically. If your hard disk supports the **LBA** mode, select "**LBA**" or "**LARGE**". However, if your hard disk cylinder is more than 1024 and does not support the lba function, you have to set at "**LARGE.**" Select "**NORMAL**" if your hard disk supporting cylinder is below 1024.



Note 1: if hard disk primary master/slave and secondary master/slave were set to "auto," the hard disk size and model will be auto detected on display during POST.



Note2: "halt on" is to determine when to halt the system by the BIOS if error occurred during POST.

3-3 BIOS Features Setup

Menu below shows all of the manufacturer's default values of this main board. Move the cursor by pressing direction keys and <PageDown> or <PageUp> key to modify the parameters, pressing [F1] key to display help message of the selected item. This setup program also provide 2 convenient ways to load the default parameter data from BIOS [F6] or CMOS [F7] area if shown data is corrupted. This provides the system a capability to recover from any possible error.

ROM PCI/ISA BIOS (2A69JLI1)					
BIOS FEATURES SETUP					
AWARD SOFTWARE, INC.					
Virus Warning	:	Disabled	Video BIOS Shadow	:	Enabled
CPU Internal Cache	:	Enabled	C8000-CBFFF Shadow	:	Disabled
External Cache	:	Enabled	CC000-C7FFF Shadow	:	Disabled
Quick Power On Self Test	:	Enabled	D0000-D3FFF Shadow	:	Disabled
Boot Sequence	:	A,C,SCSI	D4000-D7FFF Shadow	:	Disabled
Swap Floppy Drive	:	Disabled	D8000-DBFFF Shadow	:	Disabled
Boot Up Floppy Seek	:	Disabled	DC000-DFFFF Shadow	:	Disabled
Boot Up NumLock Status	:	On			
Boot Up System Speed	:	High			
Gate A20 Option	:	Normal			
Typeomatic Rate Setting	:	Disabled			
Typeomatic Rate (Chars/Sec)	:	6			
Typeomatic Delay (Msec)	:	250			
Security Option	:	Setup			
PCI/ISA Palette Snoop	:	Disabled			
OS Select For ISAM > 64MB	:	Non-OS2			
			ESC	:	Quit
			F1	:	Help
			F5	:	Old Values (Shift)F2 : Color
			F7	:	Load Setup Defaults
			↑↓←→	:	Select Item
			FU/PD/+/-	:	Modify

Virus Warning

:Enabled

:Disabled (default)

CPU Internal Cache

Enabled : enable L1 cache

Disabled: disable L1 cache

External Cache**Enabled** (default): enable L2 cache**Disabled:** disable L2 cache***CPU L2 Cache ECC Checking*****Enabled** (default): enable L2 cache ECC checking**Disabled:** disable L2 cache ECC checking***Quick Power On Self Test***

This category speeds up power on self test.

Enabled (default) : BIOS will shorten or skip some check items.**Disabled:** normal speed***Boot Sequence***

This category determines which drive the system searches first. Take “**A,C,SCSI**” for example. System will search in turn for floppy disk drive; second is hard disk drive, and finally SCSI drive. Default value is “**A,C,SCSI**”. Options are as below:

A,C,SCSI; C,A,SCSI; C,CDROM,A; CDROM,C,A; D,A,SCSI; E,A,SCSI; F,A,SCSI; SCSI,A,C; SCSI,C,A; C Only; LS/ZIP,C.

Swap Floppy Drive**Enabled:** floppy A&B will be swapped.**Disabled**(default): floppy A&B will be not swapped.***Boot Up Floppy Seek***

BIOS will determine if the floppy disk drive is 40 or 80 tracks. 360k type is 40 tracks while 720K/ 1.2M and 1.44M are all 80 tracks. Default value is **enabled**.

Boot Up Numlock Status**:On**(default)**:Off**

Gate A20 Speed**:Normal** (default)**:Fast*****Typematic Rate Setting***

This determines the typematic rate.

Enabled: enable typematic rate and typematic delay programming.**Disabled** (default) : disable typematic rate and typematic delay programming. The system BIOS will use default value of this 2 items and the default is controlled by keyboard.***Typematic Rate(Chars/Sec)***

6: 6 Characters Per Second(default)

8: 8 Characters Per Second

10 : 10 Characters Per Second

12: 12 Characters Per Second

15: 15 Characters Per Second

20: 20 Characters Per Second

24: 24 Characters Per Second

30 : 30 Characters Per Second

***Typematic Delay (Msec)***

This is the interval between the first and second character displayed.

250 : 250 msec (default)**500** : 500 msec**750** : 750 msec**1000** :1000 msec

Security Option

Item	Function	Note
Setup (default)	Security protection in CMOS setup menu	After setting password in BIOS CMOS “ Supervisor Password ” or User Password ,” it protects BIOS CMOS setup.
System	Security protection in system boot-up & BIOS setup	This function secures the system under system boot-up and BIOS setup after setting password.

PCI/VGA Palette Snoop

Enabled: it allows you to install an enhanced graphics adapter card.

Disabled (default): If your graphics adapter card does not support the palette snoop function, please set at **Disabled** to avoid system malfunction.

OS Select For DRAM > 64MB

This option is especially set for OS2 operating system. Set “**Non-OS2**” for RAM memory over 64MB and set “**Non-OS2**” for other operating systems like Windows® 95/98 or NT.

:Non-OS2 (default)

:OS2

.....

Video BIOS Shadow

It determines whether video BIOS will be copied to RAM. However, it is optional from chipset design. Video shadow will increase the video speed.

Enabled : Video Shadow is enabled (default)

Disabled: Video Shadow is disabled

C8000-CBFFF Shadow, CC000-CFFF Shadow, D0000-D3FFF Shadow: D4000-D7FFF Shadow, D8000-DBFFF Shadow, DC000-DFFF Shadow

These are categories determining whether optional ROM will be copied to RAM by 16KB or 32KB per unit and the size depends on chipset.

:Enabled

:Disabled(default)

.....

3-4 Chipset Features Setup

ROM PCI/ISA BIOS (2A69JLI1) CHIPSET FEATURES SETUP AWARD SOFTWARE, INC.			
Auto Configuration	: Disabled	SDRAM CAS Latency Time	: 3
DRAM Speed Selection	: 60ns	Auto Detect DIMM/PCI Clk	: Disabled
MA Wait State	: Fast	Spread Spectrum	: Disabled
EDO RAS# to CAS# Delay	: 3	CPU Warning Temperature	: Disabled
EDO RAS# Precharge Time	: 4	Shutdown Temperature	: 60°C/140°F
EDO DRAM Read Burst	: x222	Current CPU Temperature	:
EDO DRAM Write Burst	: x222	Current CPUFAN1 Speed	:
DRAM Data Integrity Mode	: Non-ECC	Current CPUFAN2 Speed	:
CPU-to-PCI IDE Posting	: Enabled	Current Uln3(U)	:
System BIOS Cacheable	: Enabled		
Video BIOS Cacheable	: Enabled		
Video RAM Cacheable	: Disabled		
8 Bit I/O Recovery Time	: 1		
16 Bit I/O Recovery Time	: 2		
Memory Hole At 15M-16M	: Disabled		
Passive Release	: Enabled	ESC : Quit	↑↓←→ : Select Item
Delayed Transaction	: Disabled	F1 : Help	FU/PD/←/→ : Modify
AGP Aperture Size (MB)	: 256	F5 : Old Values (Shift)F2 : Color	
SDRAM RAS-to-CAS Delay	: Slow	F7 : Load Setup Defaults	
SDRAM RAS Precharge Time	: Slow		

Auto configuration

BIOS will automatically detect the CPU speed and will auto-configure the bus frequency, DRAM speed, cache and read/write cycle.

Enabled: (default)

Disabled:

EDO RAS# Precharge Time

SDRAM precharge time by RAS.

: 4

: 3 (default)

EDO RAS# to CAS delay

This controls the DRAM page miss and row miss leadoff timing.

: 2

: 3 (default)

System BIOS cacheable

define whether system BIOS area cacheable or not.

:Enabled

:Disabled (default)

Video BIOS cacheable: to define whether video BIOS area cacheable or not.

:Enabled

:Disabled (default)

Video RAM Cacheable

:Enabled --- allows caching of the video RAM, resulting in better system performance. However, if any program writes to this memory area, a system error may occur.

:Disabled (default)

8 Bit I/O Recovery Time:

This field defines the recovery time from 1 to 8 for 8-bit I/O.

16 Bit I/O Recovery Time:

To define the recovery time from 1 to 4 for 16-bit I/O.

Memory Hole at 15M-16M: this field enable a memory hole in main memory space. CPU cycles matching an enabled hold are passed on to PCI note that a selected can not be changed while the L2 cache is enabled.

:Disabled (default)

:15M-16M

AGP Aperture Size

To select the size of the Accelerated Graphics Port (AGP) aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation.

:128M(default)

:64M, 32M, 16M, 8M, 4M

Auto Detect DIMM/PCI CLK**:Disabled** (default)**:Enabled*****CPU Warning Temperature (optional)***

This function is CPU over-heat alarm. Select either of the below temperature will give an alarm when CPU temperature is over-heated.

:Disabled**:50°C/122°F, 53°C/127°F, 56°C/133°F, 60°C/140°F, 63°C/145°F,
66°C/151°F, 70°C/158°F*****Shutdown Temperature (optional)***

System will shut down automatically when CPU temperature is over-heated. Below is the boundary which system gives alarm .

:60⁰ C/140⁰ F (default)**:65⁰ C/149⁰ F, 70⁰ C/158⁰ F, 75⁰ C/167⁰ F*****Current CPU Temperature, Current CPUFAN1/CPUFAN2/ CPU FAN3 ,
Current Vin3(V)/ Vin2(V)/VIN(1)/Vdd(V) (optional)***

System will automatically detect the above items and show the status.

3-5 Power Management Setup

BIOS PCI/ISA BIOS (2A69JL11)	
POWER MANAGEMENT SETUP	
AWARD SOFTWARE, INC.	
ACPI function	: Disabled
Power Management	: Disabled
PM Control by APM	: Yes
Video Off Method	: DPMS
Video Off After	: Suspend
MIEM Use INQ	: 3
Wake Mode	: Disable
Standby Mode	: Disable
Suspend Mode	: Disable
HDD Power Down	: Disable
Throttle Duty Cycle	: 62.5%
PCI/ISA Act-Monitor	: Disabled
Soft-Off by FWR-BTTM	: Instant-Off
PowerOn by Ring	: Disabled
Resume by Alarm	: Disabled
Wake Up On LAN	: Disabled
IRQ 8 Break Suspend	: Disabled
** Select Global Timer Events ** INQ13-7,9-151,NMI : Enabled Primary IDE 0 : Disabled Primary IDE 1 : Disabled Secondary IDE 0 : Disabled Secondary IDE 1 : Disabled Floppy Disk : Disabled Serial Port : Enabled Parallel Port : Disabled	
ESC : Quit ↑↓←→ : Select Item F1 : Help F4/F5/←/→ : Modify F5 : Old Values (Shift)F2 : Color F7 : Load Setup Defaults	

ACPI function

:Disabled

:Enabled (default)

Power Management

:User Define(default)--users can configure their own power management

:Min Saving

:Max Saving

:Disabled

PM Control By APM

No : system BIOS will ignore APM.

Yes (default) : system BIOS will wait for APM's prompt before it enter any PM mode, e.g. Doze, standby or suspend.



Note 1: if APM is installed, and there is a task running, even if the timer is time out, the APM will not prompt the BIOS to put the system into any power saving mode!



Note2: If APM is not installed, this option has no effect.

Video Off Method

:DPMS (default), **Blank Screen, V/H Sync+Blank**

Video Off After:

: Suspend (default), **Doze, NA, Standby**

MODEM Use IRQ

:3 (default), **4, 5, 7, 9, 10, 11, NA**

Soft-off by PWR-BTTN

:Instant-off

:4 seconds

This allows the user to set the soft-off power button to turn off the system or set to "4 second" holding the power and system will shut down in 4 seconds .

HDD Power Down

:Disabled (default), **1 min--- 15 min.**

Doze Mode

:Disabled (default), **1 min --- 1 hour**

Suspend mode

:Disabled(default) , **1 min --- 1 hour**

PowerOn by Ring**:Disabled**(default)**:Enabled:** modem ring on function--- system can be turned on through modem.**Note: this function only works when the system is turned off from Windows mode, and Doze mode will not function.*****Resume by Alarm:*** auto power on at the appointed date and time.**Enabled:** key in the date of current month and time of the day. System will turn on then.**Disable** (default) : disble this function.**Note: this function only works when the system is turned off in Windows mode, and doze mode will not function.*****Wake Up On LAN*****:Enabled****:Disable** (default)**To support functions such as “Wake up on LAN,” “Keyboard Wake up,” or “PS/2 Mouse Wake up,” we suggest that Pin 17 signal 5VSB on ATX Power supply should be able to offer at least 750 mA driving ability.*****Primary INTR*****:on** (default)Select “on,” it adds the following functions, “**IRQ3 (COM2)- IRQ15 (Reserved).**”**:off**Select “off,” “**IRQ3 (COM2)- IRQ15 (Reserved)**” will not show.

3-6 PNP / PCI Configuration Setup

ROM PCI/ISA BIOS (2A69JL11) PNP/PCI CONFIGURATION AMIBD SOFTWARE, INC.	
PNP OS Installed : No	PCI IDE IRQ Map To : PCI-AUTO
Resources Controlled By : Manual	Primary IDE INT# : A
Reset Configuration Data : Disabled	Secondary IDE INT# : B
IRQ-3 assigned to : PCI/ISA PnP	Slot 1 Use IRQ No. : Auto
IRQ-4 assigned to : PCI/ISA PnP	Slot 2 Use IRQ No. : Auto
IRQ-5 assigned to : PCI/ISA PnP	Slot 3 Use IRQ No. : Auto
IRQ-7 assigned to : PCI/ISA PnP	Slot 4 Use IRQ No. : 5
IRQ-9 assigned to : PCI/ISA PnP	Used MEM base addr : N/A
IRQ-10 assigned to : PCI/ISA PnP	Assign IRQ For VGA : Enabled
IRQ-11 assigned to : PCI/ISA PnP	Assign IRQ For USB : Enabled
IRQ-12 assigned to : PCI/ISA PnP	
IRQ-14 assigned to : PCI/ISA PnP	
IRQ-15 assigned to : PCI/ISA PnP	
DMA-0 assigned to : PCI/ISA PnP	ESC : Quit ↑↓←→ : Select Item
DMA-1 assigned to : PCI/ISA PnP	F1 : Help F2/F3/←/→ : Modify
DMA-3 assigned to : PCI/ISA PnP	F5 : Old Values (Shift)F2 : Color
DMA-5 assigned to : PCI/ISA PnP	F7 : Load Setup Defaults
DMA-6 assigned to : PCI/ISA PnP	
DMA-7 assigned to : PCI/ISA PnP	

PNP OS Installed

:No(default)

OS will not recognize PnP devices.

:Yes

OS will arrange the setup of PnP devices.

Resources Controlled By

:Manual (default)

The table will show the below items: “Reset Configuration Data, IRQ-3 assigned to, DMA-0 assigned to.” The user can adjust the shown items as required.

:Auto

The table will not show the above items, and the system will automatically assign the above setup.

Reset Configuration Data**:Disabled**(default)**:Enabled---** to reset “**Extended System Configuration Data(ESCD)** when you exit setup if you have installed a new add-on card and the system reconfiguration has caused such a serious conflict that the operating system can not boot up.***IRQ-3 Assigned To---- IRQ-15 Assigned To*****: PCI/ISA PnP**(default)**: Legacy ISA*****DMA-0 Assigned To--- DMA-7 Assigned To*****: PCI/ISA PnP**(default)**: Legacy ISA*****PCI IRQ Activated By***

There are 2 modes in activating PCI IRQ.

:Edge (default)**:Level*****Assign IRQ for USB*****:Enable** (default)**:Disable*****Assign IRQ for VGA*****:Enable** (default)**:Disable**

3-7 Integrated Peripherals

ROM PCI/ISA BIOS (2A69JL11) INTEGRATED PERIPHERALS AWARD SOFTWARE, INC.					
IDE HDD Block Mode	:	Disabled	ECC Input Clock	:	8 MHz
IDE Primary Master PIO	:	Auto	Onboard FDC Controller	:	Enabled
IDE Primary Slave PIO	:	Auto	Onboard Serial Port 1	:	Auto
IDE Secondary Master PIO	:	Auto	Onboard Serial Port 2	:	
IDE Secondary Slave PIO	:	Auto	USB Mode	:	
IDE Primary Master UDMA	:	Auto	USB Duplex Mode	:	Half
IDE Primary Slave UDMA	:	Auto	Onboard Parallel Port	:	
IDE Secondary Master UDMA	:	Auto	Parallel Port Mode	:	
IDE Secondary Slave UDMA	:	Auto	ECP Mode Use DMA	:	3
On-Chip Primary PCI IDE	:	Enabled			
On-Chip Secondary PCI IDE	:	Enabled			
USB Keyboard Support	:	Disabled			
Init Display First	:	ASB			
POWER ON Function	:				
KB Power ON Password	:	Enter	ESC : Quit		F1-- : Select Item
Hot Key Power ON	:	Ctrl-F1	F1 : Help		FU/PD/+- : Modify
			F5 : Old Values (Shift)F2 : Color		F7 : Load Setup Defaults

IDE HDD Block Mode

This feature enhances hard disk performance by making multi sector transfer instead of one sector per transfer. Most of IDE drivers, except very early designs, can use this feature.

:Enabled (default)

:Disabled

IDE Primary Master PIO IDE Primary Slave PIO

This feature detects your primary master hard disk device.

:Auto (default)

:Mode 0,1,2,3,4

IDE Primary Slave PIO

This feature detects your primary master hard disk device.

:Auto (default)

:Mode 0,1,2,3,4

IDE Secondary Master PIO

This feature detects your secondary master hard disk device.

:Auto (default)

:Mode 0,1,2,3,4

IDE Secondary Slave PIO

This feature detects your secondary master hard disk device.

:Auto (default)

:Mode 0,1,2,3,4

USB Keyboard support

:Enabled

:Disabled (default)

POWER ON FUNCTION

Item	Setup Procedure	Special note
KB power on password	<ol style="list-style-type: none"> Enter password 5 spaces allowed. Confirm password: key in the password to confirm again. 	<ol style="list-style-type: none"> System can only be turned on through password. When turning on the system, the user must press "Enter" after keying password.
Hot key power on	12 options from "CTRL+F1...CTRL+F12." The user may choose either of them by "page up" or "page down."	The system can be turned on either by hot key or pushing case power on button.
Mouse left	Mouse left (PS/2 mouse only)	The system can be turned on either by PS/2 mouse (left key) or pushing case power on button.
Mouse right	Mouse right (PS/2 mouse only)	The system can be turned on either by PS/2 mouse (right key) or pushing case power on button.
Button only	Case button	The system can be turned on by case button.



To support functions such as “Wake up on LAN,” “Keyboard Wake up,” or “Mouse Wake up,” we suggest that Pin 17 signal 5VSB on ATX Power supply should be able to offer at least 750 mA driving ability.



If password is forgotten, please clear CMOS and reset again.

Onboard FDC Controller

: **Enabled** (default)

: **Disabled**

Onboard Serial Port 1

: **3F8/IRQ4** (default)

: **2F8/IRQ3**

: **3E8/IRQ4**

: **2E8/IRQ3**

: **Auto**

: **Disabled**

On-Board Serial Port 2

: **3F8/IRQ4**

: **2F8/IRQ3**(default)

: **3E8/IRQ4**

: **2E8/IRQ3**

: **Auto**

: **Disabled**

Onboard Parallel Port

: **378/IRQ7** (default)

: **278H/IRQ5**


: **disabled**

Parallel Port Mode

SPP (Default)
EPP

Step 2: Confirm Password

Typing the password again and pressing <Enter> .



If you forget password, please clear CMOS.
(refer to jumper RTC1)

Step 3: Set “Security Option” in “BIOS Features Setup”


After setting password, enter “Security Option” in “BIOS Features Setup.” There are 2 options “Setup” & “System.” “Setup” will only secure CMOS setup through password. “System” is to secure PC sytem and password is required during system boot-up in addition to CMOS setup..

2. How to Disable “Supervisor Password” & “User Password”

Step 1: Go to CMOS Setup Menu (need to key in password first)

Step 2: Enter “Supervisor Password” or “User Password”

After enter, it shows “Enter Password.” Press the <Enter> key instead of entering a new password when "ENTER PASSWORD" appears. It will inform “PASSWORD DISABLED PRESS ANY KEY TO CONTINUE.” Thus, press any key as instructed to disable the password.



3-9 IDE HDD Auto Detection

FOR PCI/ISA BIOS CMOS SETUP UTILITY AWARD SOFTWARE, INC.							
HARD DISK TYPE	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE
Primary Master:							
Primary Slave:							
Secondary Master:							
Secondary Slave:							
Select Primary Master Option (N: Skip): N							
OPTIONS	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE
2 (Y)	4302	523	255	0	8893	63	LBA
1	4303	8894	15	65535	8893	63	NORMAL
3	429	6555	2405	65535	8893	63	LARGE

Note: Some OSes (like SCO-UNIX) must use "NORMAL" for installation.

The "**IDE HDD AUTO DETECTION**" utility is a very useful tool especially when you do not know which kind of hard disk type you are using. You can use this utility to detect the correct disk type installed in the system automatically or you can set hard disk type to auto in the standard CMOS setup. You don't need the "**IDE HDD Auto Detection**" utility. The BIOS will auto-detect the hard disk size and model on display during post.

The Award® BIOS supports 3 HDD modes: **NORMAL, LBA & LARGE.**

1. Normal mode

Generic access mode in which neither the BIOS nor the IDE controller will make any transformations during accessing.

The maximum number of cylinders, head & sectors for normal mode are **1024, 16 & 63.**

No. Cylinder	(1024)
X No. Head	(16)
X No. Sector	(63)
<u>X No. Per Sector</u>	<u>(512)</u>
	528 MB

If user set this HDD to normal mode, the maximum accessible HDD size will be 528 MB even though its physical size may be greater than that!

2. LBA (Logical Block Addressing) Mode

A new HDD accessing method to overcome the 528 MB bottleneck. The number of cylinders, heads & sectors shown in setup may not be the number physically contained in the HDD. During HDD accessing, the IDE controller will transform the logical address described by sector, head & cylinder into its own physical address inside the HDD.

The maximum HDD size supported by LBA mode is 8.4 GB which is obtained by the following formula:

	No. Cylinder	(1024)
X	No. Head	(255)
X	No. Sector	(63)
X	No. Bytes Per Sector	(512)
		8.4 GB

3. Large Mode

Extended HDD access mode supported by Award® software. Some IDE HDDs contain more than 1024 cylinder without LBA support (in some cases, user do not want LBA). The Award® BIOS provides another alternative to support these kinds of large mode:

<u>Cyls.</u>	<u>Head</u>	<u>Sector</u>	<u>Mode</u>
1120	16	59	NORMAL
560	32	59	LARGE

BIOS tricks DOS (or other OS) that the number of cylinders is less than 1024 by dividing it by 2. At the same time, the number of heads is multiplied by 2. A reverse transformation process will be made inside int 12h in order to access the right HDD address the right HDD address!

4. Maximum HDD Size:

	No. Cylinder	(1024)
X	No. Head	(32)
X	No. Sector	(63)
X	No. Bytes Per Sector	(512)
		1 GB




To support LBA or large mode of HDDs, there must be some

values. Press the <Y> key and then press the <Enter> key . The setup defaults will then load. Press <N> if you don't want to


3-11 Save & Exit Setup

The "Save & Exit Setup" option will bring you back to boot up procedure with all the changes, you have made which are recorded in the CMOS RAM.



3-12 Quit Without Saving

The "Quit Without Saving" option will bring you back to normal boot up procedure without saving any data into CMOS RAM. All of the old data in the CMOS will not be destroyed.



Chapter 4 Appendix

4-1 Memory Map

Address range	Size	Description
00000-7FFFF	512K	Conventional memory
80000-9FBFF	127K	Extended conventional memory
9FC00-9FFFF	1K	Extended BIOS data area if PS/2 mouse is installed
A0000-C7FFF	160K	Available for hi DOS memory
C8000-DFFFF	96K	Available for hi DOS memory and adapter ROMs
E0000-EEFFF	60K	Available for UMB
EF000-EFFFF	4K	Video service routine for monochrome & CGA adapter
F0000-F7FFF	32K	BIOS CMOS setup utility
F8000-FCFFF	20K	BIOS runtime service routine (2)
FD000-FDFFF	4K	Plug and play escd data area
FE000-FFFFF	8K	BIOS runtime service routine (1)

4-2 I/O Map

000-01F	DMA controller (master)
020-021	Interrupt controller (master)
022-023	Chipset control registers, I/o posts
040-05F	Timer control registers
060-06F	Keyboard interface controller (8042)
070-07F	RTC ports & CMOS I/O ports
080-09F	DMA register
0A0-0BF	Interrupt controller (slave)
0C0-0DF	DMA controller (slave)
0F0-0FF	Math coprocessor
1F0-1FB	Hard disk controller
278-27F	Parallel port 2
2B0-2DF	Graphics adapter controller
2F8-2FF	Serial port 2
360-36F	Network ports
378-37F	Parallel port 1
3B0-3BF	Monochrome & parallel port adapter
3C0-3CF	EGA adapter
3D0-CDF	CGA adapter
3F0-3F7	Floppy disk controller
3F8-3FF	Serial port-1

4-3 Time & DMA Channels Map

Time map:

- Timer channel 0 system timer interrupt
- Timer channel 1 DRAM refresh request
- Timer channel 2 speaker tone generator

Dma channels:

- DMA channel 0 available
- DMA channel 1 onboard ecp (option)
- DMA channel 2 floppy disk (smc chip)
- DMA channel 3 onboard ECP (default)
- DMA channel 4 cascade for dma controller 1
- DMA channel 5 available
- DMA channel 6 available
- DMA channel 7 available

4-4 Interrupt Map

1. **NMI:** non-maskable interrupt

2. **IRQ(H/W):**

- 0 system timer interrupt from timer 0
- 1 keyboard output buffer full
- 2 cascade for IRQ 8-15
- 3 serial port2
- 4 serial port1
- 5 parallel port 2
- 6 floppy disk (smc chip)
- 7 parallel port 1
- 8 RTC clock
- 9 available
- 10 available
- 11 available
- 12 PS/2 mouse
- 13 math coprocessor
- 14 onboard hard disk (IDE1) channel
- 15 onboard hard disk (IDE2) channel

4-5 RTC & CMOS RAM Map

RTC & CMOS :

00 seconds
01 second alarm
02 minutes
03 minutes alarm
04 hours
05 hours alarm
06 day of week
07 day of month
08 month
09 year
0a status register a
0b status register b
0c status register c
0d status register d
0e diagnostic status byte
0f shutdown byte
10 floppy disk drive type byte
12 hard disk type byte
13 reserve
14 equipment type
15 base memory low byte
16 base memory high byte
17 extension memory low byte
18 extension memory high byte
19-2d

2e-2f
 30 Reserved for extension memory low byte
 31 reserved for extension memory high byte
 32 date century byte
 33 information flag
 34-3f reserve
 40-7f reserved for chipset setting data

4-6 Award BIOS Hard Disk Type

Type	Cylinder	Heads	Write Pre-comp	Landing Zone	Sectors	Size
1	306	4	128	305	17	10MB
2	615	4	300	615	17	21MB
3	615	6	300	615	17	32MB
4	940	8	512	940	17	65MB
5	940	6	512	940	17	49MB
6	615	4	65535	615	17	21MB
7	462	8	256	511	17	32MB
8	733	5	65535	733	17	31MB
9	900	15	65535	901	17	117MB
10	820	3	65535	820	17	21MB
11	855	5	65535	855	17	37MB
12	855	7	65535	855	17	52MB
13	306	8	128	319	17	21MB
14	733	7	65535	733	17	44MB
16	612	4	0	663	17	21MB
17	977	5	300	977	17	42MB
18	977	7	65535	977	17	59MB
19	1024	7	512	1023	17	62MB
20	733	5	300	732	17	31MB
21	733	7	300	732	17	44MB
22	733	5	300	733	17	31MB
23	306	4	0	336	17	10MB

Type	Cylinder	Heads	Write Pre-comp	Landing Zone	Sectors	Size
24	977	5	0	925	17	42MB
25	1024	9	65535	925	17	80MB
26	1224	7	65535	754	17	74MB
27	1224	11	65535	754	17	117MB
28	1224	15	65535	699	17	159MB
29	1024	8	65535	823	17	71MB
30	1024	11	65535	1023	17	98MB

Type	Cylinder	Heads	Write Pre-comp	Landing Zone	Sectors	Size
31	918	11	65535	1023	17	87MB
32	925	9	65535	926	17	72MB
33	1024	10	65535	1023	17	89MB
34	1024	12	65535	1023	17	106MB
35	1024	13	65535	1023	17	115MB
36	1024	14	65535	1023	17	124MB
37	1024	2	65535	1023	17	17MB
38	1024	16	65535	1023	17	142MB
39	918	15	65535	1023	17	119MB
40	820	6	65535	820	17	42MB
41	1024	5	65535	1023	17	44MB
42	1024	8	65535	1023	17	68MB
43	809	6	65535	852	17	42MB
44	809	9	65535	852	17	64MB
45	776	8	65535	775	17	104MB
46	AUTO	0	0	0	0	
47	USER'S	TYPE				

4-7 ISA I/O Address Map

I/O Address (HEX)	I/O device
000 - 01F	DMA Controller 1, 8237A-5
020 - 03F	Interrupt Controller 1, 8259A
040 - 05F	System Timer, 8254-2
060 - 06F	8742 Keyboard Controller
070 - 07F	real-time Clock/CMOS and NMI Mask
080 - 09F	DMA Page Register, 74LS612
0A0 - 0BF	Interrupt Controller 2, 8259A
0C0 - 0DF	DMA Controller 2, 8237A-5
0F0 - 0FF	i486 Math Coprocessor
1F0 - 1F8	Fixed Disk Drive Adapter
200 - 207	Game I/O
20C - 20D	Reserved
21F	Reserved
278 - 27F	Parallel Printer Port 2
2B0 - 2DF	Alternate Enhanced Graphic Adapter
2E1	GPIB Adapter 0
2E2 - 2E3	Data Acquisition Adapter 0
2F8 - 2FF	Serial Port 2 (RS-232-C)
300 - 31F	Prototype Card
360 - 363	PC Network (Low Address)
364 - 367	Reserved

I/O Address (HEX)	I/O device
368 - 36B	PC Network (High Address)
36C - 36F	Reserved
378 - 37F	Parallel Printer Port 1
380 - 38F	SDLC, Bisynchronous 2
390 - 393	Cluster
3A0 - 3AF	Bisynchronous 1
3B0 - 3BF	Monochrome Display and Printer Adapter

I/O Address (HEX)	I/O device
3C0 - 3CF	Enhanced Graphics Adapter
3D0 - 3DF	Color/Graphics Monitor Adapter
3F0 - 3F7	Diskette Drive Controller
3F8 - 3FF	Serial Port 1 (RS-232-C)
6E2 - 6E3	Data Acquisition Adapter 1
790 - 793	Cluster Adapter 1
AE2 - AE3	Data Acquisition Adapter 2
B90 - B93	Cluster Adapter 2
EE2 - EE3	Data Acquisition Adapter 3
1390 - 1393	Cluster Adapter 3
22E1	GPIB Adapter 1
2390 - 2393	Cluster Adapter 4
42E1	GPIB Adapter 2
62E1	GPIB Adapter 3
82E1	GPIB Adapter 4
A2E1	GPIB Adapter 5
C2E1	GPIB Adapter 6
E2E1	GPIB Adapter 7

Chapter 5 Q & A

5-1 Errors Messages During Power on Self Test

During **power on self test (post)**, BIOS will automatically detect the system devices. Below is the questions that users may always meet. The user may press “**Esc**” key to skip the full memory test.

1. Beep sound

On power on, the system make beep sound to offer different messages. If the system is configured correctly, it prompts a short beep to show correct the devices configuration is done correctly. When VGA card and DIMM modules are not plugged well, the system makes longer and constant beep sounds.

2. BIOS ROM checksum error

It indicates the checksum of the BIOS code is not right and system will always halt on power on screen. Contact the dealer to exchange a new BIOS.

3. CMOS battery fails

It indicates the CMOS battery does not work. Contact the dealer to exchange a new BIOS.

4. *CMOS checksum error*

It indicates the CMOS checksum is incorrect. Load the default values in BIOS to solve this problem. This error may result from a weak BIOS, so exchange a new BIOS if necessary.

5. *Hard disk initialize*

Please wait a moment...

Some hard drives require more time to initialize.

6. *Hard disk install failure*

The system can not find or initialize the hard drive controller or the drive. Check if the controller is set correctly. If no hard disk is installed, "**Hard drive selection**" must be set to "**none.**"

7. *Keyboard error or no keyboard present*

This means the system can not initialize the keyboard. Check if the keyboard is plugged well and be sure no keys are pressed during POST.

8. *Keyboard is lock out- Unlock the key*

Normally when this message comes out, check if there is anything mis-placed on the keyboard. Be sure nothing touches the keys.

9. *Memory test fails*

There will be more information to specify the type and location of the memory error.

10 *Primary master hard disk fail*

The BIOS find an error in the primary master hard disk drive.

11 *Primary slave hard disk fail*

The BIOS finds an error in the primary slave hard disk drive.

12 *Secondary master hard disk fail*

The BIOS finds an error in the secondary slave master hard disk drive.

13 *Secondary slave hard disk fail*

The BIOS finds an error in the secondary slave IDE hard disk drive.

5-2 Frequently Asked Questions

Below is questions users always come out with. **Q** is for question. **A** is for answer.

Q: Why can't my AGP card work under Win 95?

A: Windows 95 OSR2.0 does not support AGP function. You must install "USB support" file to enable this function. After installing, choose "enable for "ASSIGN IRQ FOR USB" in BIOS PNP/PCI configuration setup.

Q: Why can't the CPU frequency be adjusted to 100 MHz ?

A: The BIOS will automatically detect the CPU frequency (66MHz or 100 MHz). Therefore, if your CPU frequency cannot be adjusted to 100 MHz, then your CPU may be 66 MHz. In BIOS "speed setup," there are other frequencies, like 75 MHz, 83 MHz, 103 MHz, 102 MHz, 112 MHz, 133MHz. These are for internal test only. No guarantee is provided since this is not included in chipset specification.

Q: Why is my system not stable with 100 MHz CPU?

A: There are many reasons for this condition. One of the most common is that SDRAM does not match PC-100 specification. When system is operated under 100 MHz, in addition to 100 MHz CPU, SDRAM must be PC-100 DIMM too.

5-3 Web-site Service

If you have any questions this manual may not help, such as updated BIOS, or any information you need regarding our products, please visit our web-site at

■ <http://www.lucky-star.com.tw>

Website to bundle updated “XStore Pro” IDE driver

Updated drivers will be constantly provided at High Point’s website. Luck Star website is also linked to High Point.

■ <http://highpoint-tech.com>

