

# MCB3100 WiRobot Serial Bluetooth Wireless Module User Manual



Version: 1.0.2 May 2005

#### **Table of Contents**

l. Intr	Introduction			
II. Ope	Operations			
11.1.	Theory of Operation	2		
II.2.	Configuration (PC-PC for Sample)	2		
III. Connections		З		
111.1.	Board Structure	3		
III.2.	Connector Description	3		
IV. Specifications				

#### **Related Document:**

WiRobot PMS5005 Sensing and Motion Controller User Manual WiRobot PMB5010 Multimedia Controller User Manual



### I. Introduction

The MCB3100 Serial Bluetooth Wireless Module is a class II Bluetooth module with on-board communication stack. This device can be plugged into any UART or RS232 compatible serial port (requires MCR3210P RS232 Interface Module for signal change) on almost any devices without needing to install drivers. It can be considered as a "wireless cable" to replacement for any RS232 serial cable and can be used in applications for wireless audio, still image, sensing and control data communications.

#### Features

- Class 2 Bluetooth operation
- On-board communication stack
- Effective range: 15 meters indoor, 45 meters outdoor
- Support UART data rate: 921.6/460.8/115.2 kbps
- Plug-and-play in the WiRobot system

#### Applications

- Robotic systems: both run-time and development-stage communication
- General-purpose wireless data communication

### II. Operations

### II.1. Theory of Operation

The MCB3100 Serial Bluetooth Wireless Module is designed to run as part of the WiRobot system. It can be directly plugged on to the PMB5010 Robot Multimedia Controller board or the PMS5005 Robot Sensing and Motion Controller board. When connected to the MCR3210P RS232 Interface board through a cable, it can also serve as wireless links for any systems that have a standard RS232 interface (PC for example). By default, the UART data rate is pre-programmed to 115.2kbps with hardware flow control and can be adjusted according to the customer's preferred setting at the time of purchase. All wireless firmware has been embedded into the module and user simply needs to issue a "CONNECT" command to the MCB3100 in order to establish a connection with another MCB3100 wireless module.

### II.2. Configuration (PC-PC for Sample)

1. Connect MCB3100 Bluetooth modules and MCR3210P RS232 interface modules with 8pin flat cable (provided by Dr Robot), red line should be first Pin.

2. Use null-modem RS232 cable connect MCR3210P RS232 interface module to PC serial port (such as Com1), and use one USB cable to connect MCR3210P RS232 interface module to one USB port. It just provides power to RS232 module.

3. Same connection to another PC.

4. Launch Hyper Terminal program, choose a port (just connected on step2), and set port settings as:

Bits per second:	115200,		
Data bits:	8,		
Parity:	none,		
Stop bits:	1,		
Flow control:	hardware.		



5. Plug USB cable again to reset Bluetooth module, you can get a message from HyperTerminal, AT-ZV -CommandMode-, AT-ZV BDAddress xxxxxxxxxx.

6. At another PC, you need launch same configuration of HyperTerminal. Get same result, but BDaddress should be different, it just like 00043e01xxxx.

7. At one PC, type command AT+ZV SPPConnect xxxxxxxxxx. Here xxxxxxxxxx is another Bluetooth module'BDAddress. If you can get AT-ZV ConnectionUp, AT-ZV -BypassMode-, the connection between PCs is setup. You can type anything or transfer a file to another PC.

The connection command is **AT+ZV SPPConnect xxxxxxxxxx**.

The change baudrate command is **AT+ZV ChangeBaud 460800**.

### III. Connections

#### III.1. Board Structure

Figure III.1 illustrates the structure of the board



Figure III.1 MCB3100 Structure

#### III.2. Connector Description

The MCB3100 is connected to WiRobot system via an 8-pin 2.54 mm-pitch single row connector:

Pin	Name	Function	
1	VCC	+3.3 V	
2	TXD	Data transmitting	
З	RXD	Data receiving	
ц	CTS	Clear to send	
5	RTS	Request to send	
6	GND	Power supply ground	
7	COMRST	Reserved	
8	BTIN	Reserved	

#### Table III.1 Connectors



## IV. Specifications

Parameter	Conditions	MIN	ТҮР	МАХ	Unit
Power Supply Voltage (VCC)		3.0	3.3	3.6	V
Signal Pin Voltage			3.3		V
RF Frequency		2400		2483.5	MHz
Antenna Load			50		Ohm
Low-level Input Voltage	VCC = 3.3V			0.8	V
High-level Input Voltage	VCC = 3.3V	2.0			V
Low-level Output Voltage	VCC = 3.3V, IOL = 2mA			0.4	V
High-level Output Voltage	VCC = 3.3V, IOH = 2mA	2.4			V
Low-level Output Current	VCC = 3.3V, VOL = 0.4V			2.2	mА
High-level Output Current	VCC = 3.3V, VOH = 2.4V			3.1	mА
Board Size			30 x 40		ጠጠ X ጠጠ

#### Table IV.1 MCB3100 Specification

