

Pack contents




- 1 one Gigaset AS185 Base station
- 2 one mains adapter
- 3 one Gigaset AS18H handset
- 4 one phone cord
- 5 two batteries
- 6 one battery cover
- 7 this Quick start guide

If you have purchased a **model with multiple handsets** the package should contain two batteries, a battery cover, a charging cradle **8** with mains adapter **9** for each additional handset.



Connecting the base station


- ▶ Connect power adapter **1** and Phone jack **2** to the base and place the cable recesses. **Please ensure the power lead is fully inserted.**



Please note:

- ◆ The mains adapter must always be connected, as the Phone will not operate without a mains connection.
- ◆ **Always use the power adapter and Phone cord supplied.** Pin connections on Telephone cables can vary.

Connecting the charging cradle (if included)



- ▶ Connect the flat plug from the mains adapter **1**.
- ▶ Plug the mains adapter into the plug socket **2**.



If you need to disconnect the plug from the charging cradle, press the release button **3** and disconnect the plug **4**.

Preparing the handset

- ▶ **Insert the batteries the right way round.** The polarity is indicated in/on the battery compartment.
- ▶ **Then slide the battery cover back into the main casing until it clicks into place.**



If you need to open the battery cover, for instance to replace the batteries, place your fingertip in the grooved area on the top of the cover and slide down.

Initial charging and discharging of the batteries



The correct charge status can only be displayed if the batteries are first fully charged **and** discharged.




- ▶ Place the handset in the charger for 7 hours.

Then remove the handset from the charger, make and receive Phone calls, setup the Phone etc. and do not put it on the charger until the batteries are fully discharged.

Setting the date and time

Set the date and time so that the correct date and time can be assigned to incoming calls, and so that the alarm can be used.



- ▶ Press the key below **MENU** on the display screen to open the main menu.
- ▶ Press the bottom of the control key ...
- ... until the **Settings** menu item appears.
- ▶ Press the key below **OK** on the display screen to confirm your selection.
- The **Date/Time** menu item appears on the display.
- ▶ Press the key below **OK** on the display screen to open the input field.
- ▶ The active cursor position is flashing. Enter day, month and year as an 6-digit number via the handset, e.g. 0 1 10 10 for 01/10/10.

Answer machine

Message Indication Key on handset will flash to indicate one or all of the following events:

- ◆ missed calls (if caller ID is enabled for your line numbers will be shown)
- ◆ new messages on the answer machine
- ◆ new Text messages (SMS) received

Activating/deactivating the answer machine

MENU → Voice Mail → OK → Answer Mach. → OK (✓ = on)

If the answer machine is activated, the answering machine icon will be displayed in the header.

To retrieve your messages, just press the flashing key on your handset.

Dial tone

The dial tone will only be heard when pressing the call button for 2 seconds. A short press will open the redial list.

You can also use the speaker button.

Display in idle status

- ◆ **2:** internal number, if more than one handset is registered
- ◆ : answering machine is activated
- ◆ Battery charge status:
 - (empty to full)
 - : batteries almost empty
 - : charging procedure


Registration handset

Your handsets should already be registered by default, if your handset is flashing the text "No Base" then it can be that:


- ◆ Your base station is not switched on, please check if the power supply is connected properly.
- ◆ There is too much distance between the handset and base.
- ◆ Your handset has not been pre-registered in the factory.

In the case that the handset has not been pre-registered, or you want to register an additional handset to your base station, use the manual registration procedure below.

Automatic registering procedure



Place the handset with the display facing up in the base station.



The handset registers automatically. Registration can take up to 5 minutes. Do not remove the handset from the base station during this time.



Manual registration procedure

1. **On the handset:**
MENU → Settings → OK → Handset → OK → Register HS → OK → enter the system PIN for the base and press OK. Default PIN = 0000
2. **On the base station:**
Within 60 seconds of entering the system PIN, press and hold the registration/paging key (min. 3 seconds). Registration takes approx. 1 minute.

You can register up to **four** handsets to your base. You can also register other Gigaset handsets and handsets from other devices with GAP functionality.

Frequently asked questions

- Q: There is no dial tone.**
A: Press call button for 2 seconds (long press) to obtain dial tone. A short press opens the redial list.
- Q: The line is crackling / not clear.**
A: Have you used the new line cable provided? Please do not use an old cable.
- Q: The display is not clear / seems to be broken.**
A: The display is protected by a plastic film, please make sure you have removed the protective film.
- Q: The handset is not registered.**
A: If your handset is not registered, please follow the Registration handset procedure. (Described on this page)
- Q: The caller ID is not working.**
A: Have you subscribed to this service (CLIP) from your provider?
- Q: Message indicator flashing and I cannot retrieve my message.**
A: Message indicator will flash to indicate missed calls as well as new messages of text messages. (Described on this page)

- Please check:**
- Have you used the phone cord supplied
 - Have you fully inserted the power cable into the base station
 - Have you inserted the batteries correctly
 - Have you charged the batteries for 7 hours
 - Have you set up the Date/Time

To download the latest software and manuals, visit our web-site: <http://www.gigaset.com>
You have questions? As a Gigaset customer, you can take advantage of our comprehensive service offerings. You can find help quickly in this User Manual and in the service pages of our Gigaset online portal: <http://www.gigaset.com>

If you have problems setting up or operation this product please call
GIGASET UK HELPLINE 0845 3670812
GIGASET IRL HELPLINE 1850 777277

Product may not be fully compatible with the national telephone network. It is clearly specified on the box near the CE mark as well as on the bottom of the base station for which country/countries the equipment has been developed. If the equipment is used in a manner inconsistent with this advice or with the instructions of the manual and on the product itself, this may have implications on the conditions for warranty or guarantee claims (repair or exchange of product). In order to make use of the warranty, the product purchaser is asked to submit a receipt which proves the date of purchase (date from which the warranty period starts) and the type of goods that have been purchased.

