

## USER MANUAL


### LL PRO WASH VARIO OPTIC

Without optic: **LL37 104 LL37 105 LL37 106 LL37 107**

With optic: **LL37 109 LL37 110 LL37 114 LL37 115**

#### COMPLIMENTS ON YOUR PURCHASE!

All dimensions are in millimeters



#### Following items are included:

##### 1. LL PRO WASH 600/1200 without optic

- LL PRO WASH 600/1200 without optic with adjustable bracket 1 pc.
- PowerCon type "A" + "B" 1 pc.
- User manual 1 pc.

##### 2. LL PRO WASH 600 with optic

- LL PRO WASH 600 without optic with adjustable bracket 1 pc.
- LL VARIO OPTIC WASH 600 1 pc.
- PowerCon type "A" + "B" 1 pc.
- User manual 1 pc.

##### 3. LL PRO WASH 1200 with optic

- LL PRO WASH 1200 without optic with adjustable bracket 1 pc.
- LL VARIO OPTIC 400 WASH 1200 3 pcs.
- PowerCon type "A" + "B" 1 pc.
- User manual 1 pc.

#### Additional items needed:

- Data cables with XLR 5pin Female/Male 1 pc.
- Controller compatible with DMX 1 pc.

- Mounting accessories and Vario Optics as necessary

Surface mounting:

- Screws and washers 6xM12, 2xM8

#### Content:

#### 01 SAFETY INFORMATION

- 01.1 Risk of eyes damage
- 01.2 Protection from electric shock
- 01.3 Fire prevention

#### 02 PRODUCT SPECIFICATION

- 02.1 Technical Specification
- 02.2 Back panel

#### 03 INSTALLATION

- 03.1 Unpacking
- 03.2 Physical installation
- 03.3 Connecting to AC power
- 03.4 Control data connecting
- 03.5 DMX channels

#### 04 MAINTENANCE

## 01 SAFETY INFORMATION

### WARNING!!!

Carefully read before installing, powering or servicing.  
Nothing to do if anything misunderstand! Installation can be done only by a qualified professional in accordance with relevant local codes.

#### 01.1 Risk of eyes damage

- Do not look directly into LED lamps.
- Do not look into light beam from a distance of less than 40 cm (16 inches)!

#### 01.2 Protection from electric shock

- Shut down power before installation or maintenance.
- Luminaries and recommended AC power supply must be installed by a qualified professional in accordance with relevant local codes. Only acceptable source of AC power and frequency that complies with local building and electrical codes to use.
- Do not use or do not connect the products if the power cable, power plug or fixtures are any way damaged, wet, or if they are overheating.
- Do not modify, alter, or attempt to service the LeaderLight appliance. Doing so will void the warranty.
- Before removing or installing any cover or part of appliance disconnect it from AC power.
- Appliance always connect to earth (eltech.).

#### 01.3 Fire prevention

- Follow all safety consideration.
- Thermostatic switches or fuses never to bypass.
- Device never shield. Around the axis of the fitting (180°) must be maintained space for cooling. Minimum distance from the surrounding objects must be 100mm (4 in.) (figure 1.1).
- LEDs never direct cover with filters or other materials.
- Allowing max. ambient temperature is 40°C (104°F).
- Luminaries never use without mounting brackets. The housing never install directly to the surface.

## 02 PRODUCT SPECIFICATION

### 02.1 Technical Specification


<b>Lamp type:</b>	66/132xRGBAW/AW P4 *
<b>Lifetime:</b>	Long 50 000 hrs 70% degradation
<b>Vario Optic:</b>	10°, 25°, 40°, EL (Elliptical 15°x90°) and AS(Asymmetrical)
<b>Control data Input:</b>	DMX 512 In/Out with XLR 5PIN
<b>Input power:</b>	max. 102W/203W
<b>Power connection:</b>	100-260V AC 50-60Hz In/Out PowerCon
<b>Net weight:</b>	5,5kg/11kg
<b>IP:</b>	IP20
<b>Ambient temp. (Ta):</b>	Maximum 40°C
<b>Cooling:</b>	Conventional
<b>Materials and finish:</b>	Housing: powder-painted anodized aluminium in black (other colours on request) Cover: clear or frosted PMMA
<b>Installation:</b>	Surface mounting

\* P4: ■ R-Red, ■ G-Green, ■ B-Blue, ■ A-Amber,  W-White (6300°K)  
- One module RGBAW (4pcs White, 4pcs Green, 4pcs Blue, 5pcs Red, 5pcs Amber) => total 3/6 modules  
- One module AW (12pcs White, 10pcs Amber) => total 3/6 modules

## ENVIRONMENT

Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

### 02.2 Back panel



#### Control LEDs Indication

POWER ● DATA ●

LED	INDICATION	STATUS
POWER (Red)	blinking – 2Hz	OK - inside fixture is everything correct
DATA (Green)	light off	NO DMX512 signal
DATA (Green)	blinking – 4Hz	OK- income correct DMX512 signal
DATA (Green)	fast blinking	NON correct digital signal
POWER (Red)	alternate blinking	Autotest function
DATA (Green)		

## 03 INSTALLATION

### 03.1 Unpacking

- Unpack carefully.
- This is electronic equipment and should be handled carefully.
- Damaged delivered package or if are any mechanical parts broken – it must be claim immediately by the transport company. Photo pictures as evidence are valuable for future claim.

### 03.2 Physical installation

- Loading capacity of bearing area has to be at least 10 times the weight of all device clusters (luminaries, clamps, cables, ...).
- Hairbreadth from combustible materials is 0,5m.
- Before physical installation insert the optic modul on top of luminary. The optic installation is easy and fast by 2 screws (Figure Nr. 1.2).

### 03.3 Connecting to AC power

- To tackle all Safety Information- 01!
- For protection from electric shock, the device must be grounded (earthed)!
- It is not necessary to open the fixture before power supply.
- Power supply is solved simple with Neutrik PowerCon connectors.
- The fixture is equipped with auto-switching power supply that automatically adjusts to any 50-60Hz AC power source from 100-260V.

- Cord plug connections:

Symbol	Pin	Wire Colour	Screw (US)
	live	brown	yellow or brass
	neutral	blue	silver
	ground (earth)	yellow/green	green


### 03.4 Control data connecting

- Control data cable length is specified by Norm IEC929 Annex E4.
- It is not necessary to open the fixture before connecting of DMX512 control signal. Interconnections are realized by Neutrik XLR 5pin IN/Out connectors.
- Pin connections:
  - Pin 1 – ground
  - Pin 2 – signal negative
  - Pin 3 – signal positive

### 03.5 DMX channels - subject to change

- The latest version of DMX channels appendix are on the websites - [www.leaderlight.eu](http://www.leaderlight.eu)

Ch.	WASH 600 RGBAW	Ch.	WASH 600 AW	Ch.	WASH 1200 RGBAW			Ch.	WASH 1200 AW
Mode1: Dip2=Off									
1	Red 1,2,3	1	Amber 1,2,3	1	Red 1,2,3,4,5,6			1	Amber 1,2,3,4,5,6
2	Green 1,2,3	2	White 1,2,3	2	Green 1,2,3,4,5,6			2	White 1,2,3,4,5,6
3	Blue 1,2,3	3	Master (Dip1=On, Dip4=Off)	3	Blue 1,2,3,4,5,6			3	Master (Dip1=On,Dip4=Off)
4	Amber 1,2,3	4	Strobo (Dip1=On, Dip4=Off)	4	Amber 1,2,3,4,5,6			4	Strobo (Dip1=On,Dip4=Off)
5	White 1,2,3	5		5	White 1,2,3,4,5,6			5	
6	Master (Dip1=On, Dip4=Off)	6		6	Master (Dip1=On,Dip4=Off)			6	
7	Strobo (Dip1=On, Dip4=Off)	7		7	Strobo (Dip1=On,Dip4=Off)			7	
Mode4: Dip2=On									
1	Red 1	1	Amber 1	1	Red 1	18	Blue 4	1	Amber 1
2	Green 1	2	White 1	2	Green 1	19	Amber 4	2	White 1
3	Blue 1	3	Amber 2	3	Blue 1	20	White 4	3	Amber 2
4	Amber 1	4	White 2	4	Amber 1	21	Red 5	4	White 2
5	White 1	5	Amber 3	5	White 1	22	Green 5	5	Amber 3
6	Red 2	6	White 3	6	Red 2	23	Blue 5	6	White 3
7	Green 2	7	Master (Dip1=On, Dip4=Off)	7	Green 2	24	Amber 5	7	Amber 4
8	Blue 2	8	Strobo (Dip1=On, Dip4=Off)	8	Blue 2	25	White 5	8	White 4
9	Amber 2	9		9	Amber 2	26	Red 6	9	Amber 5
10	White 2	10		10	White 2	27	Green 6	10	White 5
11	Red 3	11		11	Red 3	28	Blue 6	11	Amber 6
12	Green 3	12		12	Green 3	29	Amber 6	12	White 6
13	Blue 3	13		13	Blue 3	30	White 6	13	Master (Dip1=On, Dip4=Off)
14	Amber 3	14		14	Amber 3	31	Master (Dip1=On, Dip4=Off)	14	Strobo (Dip1=On, Dip4=Off)
15	White 3	15		15	White 3	32	Strobo (Dip1=On, Dip4=Off)	15	
16	Master (Dip1=On, Dip4=Off)	16		16	Red 4			16	
17	Strobo (Dip1=On, Dip4=Off)	17		17	Green 4			17	
Extention and control functions:									
Dip4=Off, Dip1=Off =>DipBCD: use rotating switch for DMX start address (RS1-100, RS2-010, RS3-001) from 001 to 511									
Dip4=Off, Dip1=On:                    address+2channel (Master+Strobo)									
Dip4=On, Dip1=Off:                    switch on AutoRun-table functions: "100"=Prg.0-9, "10"=StepTime, "1"=FadeTime									
Dip4=On, Dip1=On:                    switch all channels on 50% - test function									
Dip2=Off: Mode 1 (5+2ch)		Dip2=Off: Mode 1 (2+2ch)		Dip2=Off: Mode 1 (5+2ch)				Dip2=Off: Mode 1 (2+2ch)	
Dip2=On: Mode 4 (15+2ch)		Dip2=On: Mode 4 (6+2ch)		Dip2=On: Mode 4 (30+2ch)				Dip2=On: Mode 4 (12+2ch)	
Dip3=Off:		standard curve							
Dip3=On:		ultraSoft curve							



#### VARIO OPTIC INSTALLATION

The optic installation is easy and fast by 2 screws.



1.2

Order code	Product name
LL37 104	LL PRO WASH RGBAW 600, without optic *
LL37 105	LL PRO WASH RGBAW 600 VO, 25° *
LL37 106	LL PRO WASH AW 600, without optic
LL37 107	LL PRO WASH AW 600 VO, 25°
LL37 109	LL PRO WASH RGBAW 1200, without optic *
LL37 110	LL PRO WASH RGBAW 1200 VO, 25° *
LL37 114	LL PRO WASH AW 1200, without optic
LL37 115	LL PRO WASH AW 1200 VO, 25°

#### Accessories:

LL37 176	LL VARIO OPTIC WASH 600 10°
LL37 177	LL VARIO OPTIC WASH 600 25°
LL37 178	LL VARIO OPTIC WASH 600 40°
LL37 179	LL VARIO OPTIC WASH 600 EL (Eliptical 15°x90°)
LL37 175	LL VARIO OPTIC WASH 600 AS (Asymetrical)
LL37 180	LL VARIO OPTIC WASH 400 10° **
LL37 181	LL VARIO OPTIC WASH 400 25° **
LL37 182	LL VARIO OPTIC WASH 400 40° **
LL37 183	LL VARIO OPTIC WASH 400 EL (Eliptical 15x90°) **
LL37 184	LL VARIO OPTIC WASH 400 AS (Asymetrical) **
LL37 910	LL BARNDOR PRO WASH 600
LL37 920	LL BARNDOR PRO WASH 1200

\* One module (4pcs White, 4pcs Green, 4pcs Blue, 5pcs Red, 5pcs Amber) => 42W.

\*\* For one luminary LL PRO WASH 1200 is necessary to order 3pieces LL VARIO OPTIC 400.

#### INSTALLATION

Ventilation space 180° free


Minimal mounting distance from surface

Ventilation space 90° free

1.1

**WARNING!!!**

Non-minimum distance and /or non-use the original brackets is at your own risk!



#### 04 MAINTENANCE

- To tackle all Safety Information- 01!
- Damage caused by inadequate cleaning or maintenance is not covered by warranty.
- Regular cleaning is demand (dust, dirt, ...)

#### Maintenance policy:

- Unplug mains before maintenance and at least 10 minutes cool off
- Appliance do not illegal open or demount
- Clean-up dust only from outer surface (for ex. scuttle, diffuser and lenses).
- Use vacuum or dumpy duster (warm water)
- Before reinstalling to check failure-free state – no wet parts!

If you have any question please, contact [support@leaderlight.sk](mailto:support@leaderlight.sk)