

ACCUSPLIT® EAGLE 602M100R

MULTI-FUNCTION STOPWATCH

STOPWATCH OPERATING INSTRUCTIONS

This watch has two modes – **TIME** and **STOPWATCH**. Press the **[MODE]** button to cycle continuously through these modes.

TIME MODE

To set current date and time of day, press **[RESET]** button. SECONDS indicator will flash to indicate you are in SET mode.

Press **[RESET]** to cycle through and set each field (SECONDS -> MINUTES -> HOURS -> YEAR -> MONTH -> DAY). Field being set will flash. Press **[START]** button to set each field.

STOPWATCH MODE

Event and Time-Out/Time-In

Press **[START]** – Start timing

Press **[STOP]** – Stop timing (Time-Out, Display shows “STOP”)

Press **[START]** – Start timing (Time-In)

Press **[STOP]** – Stop timing (Time-Out, Display shows “STOP”)

Press **[RESET]** – Reset (Display Only)

Dual Split Memory with Split Counter

Press **[START]** – Start timing (Shows Running LAP Time)

Press **[SPLIT]** – create 1st Split or Lap time (Top row shows SPLIT 1, middle shows LAP 1, and bottom row shows running Lap time)

Press **[SPLIT]** – create 2nd Split (Top row shows SPLIT 2, middle shows LAP 2)

Press **[SPLIT]** – create 3rd Split (Top row shows SPLIT 3, middle shows LAP 3)

Press **[SPLIT]** – create 4th Split (Top shows SPLIT 4, middle shows LAP 4)

Press **[STOP]** – Stop timing (Bottom shows interval time since Split 4 taken)

Press **[RESET]** – Reset display only (memories remain)

Notes:

Bottom row always shows Running LAP time. Split Counter shows the current Split being taken. Last Split must be taken at end. Stop does not Split.

Memory Recall

While stopwatch is running:

Press **[RECALL]** – Recalls Fastest Lap time.

Press **[RECALL]** – Recalls interval time at last stop, or last Lap/Split times.




Press **[RECALL]** – Recalls previous Lap/Split/Stop time each time **[RECALL]** is pressed.

While stopwatch is stopped:

Press **[RECALL]** – Recalls Fastest Lap time.

Press **[RECALL]** – Recalls interval time at first stop, or first Lap/Split times.

Press **[RECALL]** – Recalls next Lap/Split/Stop time each time **[RECALL]** is pressed.



Notes:

Hold down **[RECALL]** for rapid review.

Whenever the storage is full, “FULL” icon will be lit, and extra Split times will not be stored into memory (but will still be shown on the display). You can clear the memories by stopping and resetting the watch.

NO-PROOF-OF-PURCHASE LIMITED WARRANTY

See label on back of unit for details, or check

<http://support.ACCUSPLIT.com>

ACCUSPLIT, Inc.

3090 Independence Drive

Suite 148

Livermore, CA 94551 USA

800-935-1996 • 925-290-1900

FAX 925-290-1930

www.ACCUSPLIT.com

support@ACCUSPLIT.com