



EXCELLENCE IN MACHINE VISION

Coreco Inc. • 6969 Trans-Canada Hwy., Suite 142 • St-Laurent, Quebec, H4T 1V8 • Canada
<http://www.imaging.com>

Viper-CamLink

User's Manual

Part number OC-VIPM-CLU00

Edition 1.00



NOTICE

© 2001 Coreco Inc. All rights reserved.

This document may not be reproduced nor transmitted in any form or by any means, either electronic or mechanical, without the express written permission of Coreco Inc. Every effort is made to ensure the information in this manual is accurate and reliable. Use of the products described herein is understood to be at the user's risk. Coreco Inc. assumes no liability whatsoever for the use of the products detailed in this document and reserves the right to make changes in specifications at any time and without notice.

Microsoft and MS-DOS are registered trademarks; Windows, Windows NT, and Windows 2000 are trademarks of Microsoft Corporation.

All other trademarks or intellectual property mentioned herein belong to their respective owners.

Printed on: October 15, 2001

Document Number: OC-VIPM-CLU00

Printed in Canada

Contents

INTRODUCTION	1
OVERVIEW OF THE MANUAL	1
ABOUT THE MANUAL	2
USING THE MANUAL	2
 THE VIPER-CAMLINK	 3
ABOUT THE VIPER-CAMLINK	3
<i>PCI Interface</i>	3
<i>Area or Line-Scan Camera</i>	3
<i>Pixel Processor</i>	3
<i>TAP Reversal</i>	3
<i>CAB Architecture & System Topologies</i>	4
<i>Shaft-Encoder & Frame Reset I/O</i>	5
<i>Event Driven Captures</i>	5
<i>Software Development</i>	5
<i>System Requirements</i>	5
WHAT'S IN THE PACKAGE	6
DEVELOPMENT SOFTWARE OVERVIEW	7
<i>Sapera Library</i>	7
<i>Sapera ActiveX Controls</i>	7
 INSTALLING THE VIPER-CAMLINK	 9
WARNING! (GROUNDING INSTRUCTIONS)	9
SAPERA LIBRARY INSTALLATION	9
INSTALLING VIPER-CAMLINK HARDWARE AND DRIVER	10
<i>Board Connection Interface</i>	10
<i>In Windows NT</i>	10
<i>In Windows 2000</i>	10
<i>Viper-CamLink Firmware Loader</i>	11
CONFIGURING THE VIPER-CAMLINK	13
DISPLAYING VIPER-CAMLINK ONBOARD INFORMATION	13
<i>Viper-CamLink Viewer Windows</i>	13
CONNECTING EMBEDDED PROCESSORS VIA CAB	16
CAMERA TO VIPER-CAMLINK CONNECTIONS	16

THE SAPERA DEMO APPLICATION	17
ACQUISITION DEMO OVERVIEW	17
<i>Using the Acquisition Demo</i>	17
<i>Acquisition Demo Main Window</i>	18
CONFIGURING SAPERA	21
<i>Viewing Installed Sapera Servers</i>	21
VIPER-CAMLINK REFERENCE	23
VIPER-CAMLINK BLOCK DIAGRAM	23
ACQUISITION	24
<i>Acquisition Modes</i>	24
<i>Pixel Processor</i>	24
<i>Viper-CamLink Acquisition Constraints</i>	25
<i>Shaft Encoder Interface</i>	26
<i>Virtual Frame Sync Interface</i>	27
APPENDIX A: VIPER-CAMLINK SERVERS & RESOURCES	29
SERVERS AND RESOURCES	29
TRANSFER RESOURCE LOCATIONS	30
APPENDIX B: TECHNICAL SPECIFICATIONS	31
VIPER-CAMLINK SPECIFICATIONS	31
CONNECTOR AND SWITCH LOCATIONS	33
<i>Connector List-CamLink Module</i>	34
<i>Connector List-Main Board</i>	34
CONNECTOR AND SWITCH SPECIFICATIONS	34
<i>Camera Link Connector View</i>	34
<i>J1: Camera Link Connector 1</i>	35
<i>J2: Camera Link Connector 2</i>	35
<i>J3: CamLink Module - RS-232 Port - Reserved</i>	36
<i>J14: CamLink Module - I/O (LVDS)</i>	36
<i>SW1: Configuration & Test Switch</i>	36
<i>J7, J8, J13, J14: Not Applicable</i>	37
<i>J3: Pixel Processor Connector</i>	37
<i>J19, J21: Cab Interface</i>	37
<i>J500: General I/O</i>	38
<i>J22: Microcontroller Serial Port</i>	38
<i>Brief Description of Standards RS-232, RS-422, & RS-644 (LVDS)</i>	39
APPENDIX C: CAMERA LINK INTERFACE	41
CAMERA LINK OVERVIEW	41
<i>Rights and Trademarks</i>	41
DATA PORT SUMMARY	42
CAMERA SIGNAL SUMMARY	42
CAMERA LINK CABLES	43

APPENDIX D: TROUBLESHOOTING	45
PCI CONFIGURATION	45
WINDOWS NT CONTROL PANEL DEVICES.....	46
LOG VIEWER	48
OTHER TOOLS FOR WINDOWS NT	49
SOLVING INTERRUPT ASSIGNMENT PROBLEMS (SWITCH 3 OF SW1)	49
 CORECO IMAGING CONTACT INFORMATION	 51
SALES INFORMATION	51
<i>Corporate Headquarters</i>	<i>51</i>
<i>US Sales Office</i>	<i>51</i>
TECHNICAL SUPPORT	52
 GLOSSARY OF TERMS	 53
 INDEX	 55

Introduction

Overview of the Manual

The *Viper-CamLink User's Manual* covers the following topics:

- **The Viper-CamLink**
Description of the Viper-CamLink package and a brief summary of its capabilities.
- **Installing the Viper-CamLink**
Installation procedures for the Viper-CamLink board and driver under Windows NT or Windows 2000, as well as information pertaining to camera connectivity.
- **The Spera Demo Application**
Using the Spera Acquisition demo program to test the Viper-CamLink installation.
- **Viper-CamLink Reference**
Descriptions of Viper-CamLink hardware, block diagram, capabilities, optional components available, and configuration details.
- **Appendix A: Viper-CamLink Servers & Resources**
Specifications specific to the Spera Imaging Library.
- **Appendix B: Technical Specifications**
Viper-CamLink and connector specifications.
- **Appendix C: Camera Link Interface**
Overview of the Camera Link specification.
- **Appendix D: Troubleshooting**
Tips for solving potential problems with the Viper-CamLink or software.
- **Coreco Imaging Contact Information**
Phone numbers, web site, and important email addresses.

About the Manual

This manual exists in printed, compiled HTML help, and Adobe Acrobat (PDF) formats. The help and PDF formats make full use of hypertext cross-references and include links to the Coreco Imaging home page on the Internet, located at **<http://www.imaging.com>**, accessed using any web browser.

For information specific to the Viper-CamLink, visit the Coreco Imaging web site at **www.imaging.com/Viper-CamLink**.

Using the Manual

File names, directories, and Internet sites will be in bold text (e.g., **image2.bmp**, **c:\sapera**, **<http://www.imaging.com>**).

Text that must be entered using the keyboard will be in typewriter-style text (e.g., **c:\temp**).

Menu and dialog actions will be indicated in bold text in the order of the instructions to be executed, with each instruction separated by bullets. For example, going to the **File** menu and choosing **Save** would be written as **File•Save**.

The Viper-CamLink

About the Viper-CamLink

The Viper-CamLink is a single PCI slot, high-performance acquisition and pre-processing board that captures images from digital cameras utilizing the industry standard Camera Link interface. Viper-CamLink supports all three Camera Link modes of operation (Base, Medium, and Full), allowing it to acquire images from one, two, four, or eight tap area and line-scan digital, monochrome, or RGB cameras. For additional Camera Link information see "[Appendix C: Camera Link Interface](#)" [on page 41](#).

PCI Interface

The Viper-CamLink utilizes the Intel i960 RISC embedded processor and PCI interface device (PCI 2.1 compliant). An intelligent I/O controller, the i960 processor supports PCI bus master and scatter-gather for maximum PCI performance. Additionally, onboard memory allows images to be buffered during busy cycles on the PCI bus, ensuring no image data is ever lost.

Area or Line-Scan Camera



Capable of acquiring at rates up to 200 MB/sec, the Viper-CamLink features two 32-bit wide input channels providing 8, 16, or 32 bit/pixel formats. Acquiring pixels at 50MHz, the Viper-CamLink can transfer images directly into host computer system memory or to the Mamba via the CAB. The Viper-CamLink supports input resolutions from 32x32 to 64K pixels x 256K lines.

Pixel Processor

The Pixel Processor optional daughter card provides optimized hardware based image processing functions. The board features up to 64 MB of memory and a firmware programmable processor core. Acquired image data is pre-processed (filter, average, compress) before transfer to the host computer or a Mamba-100 (via the CAB).

TAP Reversal

Viper-CamLink supports a variety of multi-tap, tap reversal, and 4 quadrant cameras. Two variations on such data output formats are illustrated in the figure below.



CAB Architecture & System Topologies

The Coreco Auxiliary Bus (CAB) is an independent high-speed 32-bit wide data transfer bus that facilitates connections to the Mamba-100, Coreco Imaging's embedded vision processor, or to our dedicated hardware accelerator, the Pixel Processor.

The CAB system on the Viper-CamLink is designed to operate in two different configurations. These topologies allow developers to adapt their image processing algorithms to leverage multiple parallel processors or pipeline processing techniques to gain a significant increase in processing performance. For information concerning configuring and programming CAB transfers, see the Sopera *CAB User's Manual* (OC-SAPM-CABU0).

Multicast Mode

The CAB multicast mode sends images for concurrent processing from the Viper-CamLink to several Mamba-100 boards simultaneously. Multicast mode is also used for pipeline processing.

Round Robin Mode

The CAB Round Robin mode sends successive images from a Viper-CamLink to different Mamba-100 boards in the system for concurrent processing. For example, the Viper-CamLink while grabbing continuously transfers the first image to the first Mamba, the second image to the second Mamba, and so on, so that each Mamba has more than one frame time to complete the required processing.

For information concerning configuring and programming CAB transfers, see the Sopera *CAB User's Manual* (OC-SAPM-CABU0).

Shaft-Encoder & Frame Reset I/O

Viper-CamLink features LVDS quadrature-shaft encoder inputs that facilitate accurate imaging using linescan cameras. Applications such as web inspection often require use of synchronization signals that match acquisitions to web speed.

A LVDS or TTL Frame Reset input is available for camera control of event driven imaging.

Viper-CamLink additionally provides TTL signal general-purpose I/Os for external process control and synchronization.

Event Driven Captures

Machine vision systems do not tolerate delayed operating system responses to real-world trigger events. The Viper-CamLink i960 system controller initiates command sequences providing an immediate response to external events. For example, on a trigger, the Viper-CamLink can reset the camera, grab the image data, and notify the host of the image in memory.

Software Development

Viper-CamLink applications are developed under Windows NT, Windows 2000, and Windows NT Embedded using the Coreco Imaging Sopera software development libraries. Coreco Imaging software development tools allow users to develop applications with C language DLLs, C++ classes, or ActiveX controls on Microsoft Visual C/C++ 6.0 (or higher) or Visual Basic 6.0 (or higher) development platforms.

System Requirements

The Viper-CamLink requires an Intel Pentium II/III or compatible computer system with 128MB of system memory and one free full-length PCI local bus slot (5 volt). The PCI bus must comply with the PCI 2.1 specification, supporting bus master devices and PCI burst mode data transfers.

What's in the Package

Viper-CamLink Package

Item	Product Number
Viper-CamLink Frame Grabber - 8MB	OC-VIP0-D0300
Sapera version 4.00 Sapera Imaging Development Library includes: <ul style="list-style-type: none">1. Sapera LT: Provides everything you will need to build your imaging application2. Sapera: Over 600 optimized image processing routines3. Current Sapera compliant board hardware drivers & documentation	

Option Modules

Item	Product Number
Pixel Processor: A multi-function processing engine capable of processing pixel data at rates up to 200MB/sec for realtime point-to-point, neighborhood, statistical, and morphological operations.	OC-COB1-PP000

Cables

Item	Product Number
Camera Link Video Input Cable: <ul style="list-style-type: none">1 meter2 meter	OC-COMC-CLNK0 OC-COMC-CLNK6
LVDS I/O cable assembly (26-pin header to bracket assembly)	OC-VIPC-CLGIO
CAB interconnect cable for interfacing a Viper series board to a Mamba-100 or a Python.	OC-COMC-CAB52
CAB interconnect cable for interfacing a Viper series board to two Mamba-100s.	OC-COMC-CAB03
Contact Coreco Imaging for more supported CAB device combinations.	

Development Software Overview

Sapera Library

Sapera is a high-level library of functions dedicated to image processing and machine vision. The library API (Application Programming Interface) is composed of a set of C-callable functions classified into different modules that belong to one of three categories:

- Basic Modules
- Processing Modules
- Board Specific Modules

The **Basic Modules** constitute the core Sapera API and are board device independent. The modules provide everything needed to acquire, display, and access images.

The optional **Processing Modules**, also board device independent, provide the image processing functionality of Sapera.

The Sapera hardware independent modules allow for one application to control different Coreco Imaging boards through the same API. It also guarantees seamless migration to any future Coreco Imaging hardware product supported by Sapera. The modular architecture provides the user with programming flexibility and readability.

The **Board Specific Modules** provide support functions that are board hardware specific.

Refer to the *Sapera User's Manual* (OC-SAPM-USER0) for detailed information.

Sapera ActiveX Controls

ActiveX controls (originally called OLE controls) are software components with a binary standard interface. They can be compared to dynamic link libraries (DLL) with a standardized method of accessing their implementation.

An ActiveX control must be contained within an application called an ActiveX Container. Typically, ActiveX controls are inserted into a form or a dialog window and used as a standard control such as a button or an edit box. They are represented by icons depicting their respective functions.

Refer to the *Sapera ActiveX Controls Manual* (OC-SAPM-AXCP0) for detailed information.

Installing the Viper-CamLink

Warning! (Grounding Instructions)

Static electricity can damage electronic components. Please discharge any static electrical charge by touching a grounded surface, such as the metal computer chassis, before performing any hardware installation.

If you do not feel comfortable performing the installation, please consult a qualified computer technician.

Never remove or install any hardware component with the computer power on.

Installing Modules on the Viper-CamLink

Any add-on modules, such as the Pixel Processor, must be installed on the Viper-CamLink board before being installed into a computer system.

Sapera Library Installation

Note: to install Sapera and the Viper-CamLink device driver, logon to the workstation as an administrator or with an account that has administrator privileges.

The Sapera Development Library (or ‘runtime library’ if application development is not being performed) must be installed before the Viper-CamLink device driver.

- Insert the Coreco Imaging Sapera CD-ROM. If **AUTORUN** is enabled on your computer, the Coreco Imaging installation menu is presented.
- If **AUTORUN** is not enabled, use Windows Explorer and browse to the root directory of the CD-ROM. Execute **launch.exe** to start the Coreco Imaging installation menu and install the required Sapera components.
- The installation program will prompt you to reboot the computer.

Refer to *Sapera User's Manual* for additional details about Sapera.

Installing Viper-CamLink Hardware and Driver

Board Connection Interface

The Viper-CamLink is sold with one interface bracket providing two Camera Link MDR-26 female connectors. See "Connector and Switch Specifications" on page 34.

In Windows NT

1. Turn the computer off and open the computer chassis to allow access to the expansion slot area.
2. Install the Viper-CamLink into a free full-length PCI expansion slot. Viper-CamLink supports the plug and play automatic configuration of the PCI specification.
3. Close the computer chassis and turn the computer on. Driver installation requires administrator rights for the current user of the computer.
4. Insert the Coreco Imaging Sopera CD-ROM. If **AUTORUN** is enabled on your computer, the Coreco Imaging installation menu is presented. Install the Viper-CamLink driver.
5. If **AUTORUN** is not enabled, use Windows Explorer and browse to the root directory of the CD-ROM. Execute **launch.exe** to start the Coreco Imaging installation menu and install the Viper-CamLink driver.
6. The driver installation program prompts you to select a **Full Installation** (needed for application development), or a **Run Time** installation (minimal installation required for target systems).
7. Reboot the computer when prompted. Continue the installation as described in "Viper-CamLink Firmware Loader" on page 11.

In Windows 2000

1. Turn the computer off and open the computer chassis to allow access to the expansion slot area.
2. Install the Viper-CamLink into a free full-length PCI expansion slot. The Viper-CamLink supports the plug and play automatic configuration of the PCI specification.
3. Close the computer chassis and turn the computer on. Driver installation requires administrator rights for the current user of the computer.
4. Windows 2000 will find the Viper-CamLink and start its **Found New Hardware Wizard**. Click on the **Cancel** button to close the Wizard Application.
5. Insert the Coreco Imaging Sopera CD-ROM. If **AUTORUN** is enabled on your computer, the Coreco Imaging installation menu is presented. Install the Viper-CamLink driver.
6. If **AUTORUN** is not enabled, use Windows Explorer and browse to the root directory of the CD-ROM. Execute **launch.exe** to start the Coreco Imaging installation menu and install the Viper-CamLink driver.


7. The driver installation program prompts you to select a **Full Installation** (needed for application development), or a **Run Time** installation (minimal installation required for target systems).
8. Reboot the computer when prompted. During the early stages of the Windows 2000 reboot, the Viper-CamLink firmware loader application starts. This is described in detail in the following section. Allow Windows to complete its reboot before proceeding.
9. Windows will display its **Digital Signature Not Found** message. Click on **Yes** to continue the Viper-CamLink driver installation.
10. Continue the installation as described in “Viper-CamLink Firmware Loader” on [page 11](#).

Viper-CamLink Firmware Loader

After Windows boots, the Firmware Loader program automatically executes. Click **OK** to automatically update the Viper-CamLink firmware.

Note: if you are certain that the Viper-CamLink firmware is of the same version as the driver being installed, click on **Cancel** to bypass the update procedure.

Choose a manual firmware upgrade when you have multiple Viper-CamLink boards installed and you want to select which board (from all installed in the computer) gets the firmware update.




Firmware Loader Status Window

The figure below shows the Firmware Loader program’s status screen (with one Viper-CamLink installed). Information on all installed Viper-CamLink boards, their serial numbers, and their firmware components are represented. Additionally, a progress bar shows firmware programming status and a report tab lets the user view or print the firmware loader status report.


When selecting a manual firmware update, the status windows permit selections via check boxes (shown below each board) allowing the installed Viper-CamLink to be reprogrammed.

Note: the Firmware Loader status report may be requested by Coreco Imaging Technical Support to aid in troubleshooting installation or operational problems.



Executing the Firmware Loader from the Start Menu

If required, the Viper-CamLink Firmware Loader program is executed via the Windows Start Menu shortcut **Start•Programs•Coreco Imaging•Viper-CamLink Device Driver•Firmware Update**. Run the Firmware Loader when adding or changing Viper-CamLink boards that do not have the current firmware.




Configuring the Viper-CamLink

The Viper-CamLink has no configuration program per se. Refer to the *Sapera User's Manual* (OC-SAPM-USER0) for more information on configuring and developing applications with the Sapera library.

Displaying Viper-CamLink onboard information

The Viper-CamLink viewer program (**VCamLinkView.exe**) displays information about the firmware and hardware components of the Viper-CamLink board detected in your system. Run the program via the Windows Start Menu shortcut

Start•Programs•Coreco Imaging•Viper-CamLink Device Driver•Viewer.



Viper-CamLink Viewer Windows

If multiple Viper-CamLink boards are installed, each one is represented by a different 1st level tab. The figure below shows one detected Viper-CamLink board identified as 'Viper-CamLink 1'.

Buttons located at the bottom of the window are common for all sub-tabs. The **Save Settings Now** button stores the file path of custom firmware components manually installed (as described in following sections on the accompanying sub-tabs). The **Save Settings on Exit** check box performs similarly when the Viewer program is closed. The **Save Board Info** button saves all board information into a text file. Finally, the **Reset button** allows you to reset the board currently selected. Close all Sapera applications using resources from the board before resetting it.

Note: the Viper-CamLink Viewer report generated by the **Save Board Info** button may be requested by Coreco Imaging Technical Support to aid in troubleshooting installation or operational problems.

Main Info

Coreco Viper-CamLink Viewer 1.00

Viper-CamLink 1

Main Info | Main Board

Template Version	Issue	Revision	Last ECO
3	A	4	764
Drawing Number	Extension	Vendor ID	Optional ECO
830	0	0x11EC	0x0001
Serial Number	Components Revision	CMI	
\$1183002	0	0x0000	

Additional Information


Sub-Template Version	: 1
i960 DRAM (MB)	: 8
CAB Revision	: 0x20
CAB ID	: 0x3
CAB Arbitrator	: 0
CAB Clk (MHz)	: 50
User-Defined ID	: 0x0

☒ Save Settings on Exit

Save Settings Now | Save Board Info | Reset | Close

For each board, the **Main Info** tab displays information relating to the Viper-CamLink board issue, revision, and ECO (engineering change order) level, along with the board serial number and optional ECO or CMI (customer modification instruction) applied. The **Additional Information** window displays supplemental design data about the Viper-CamLink.


Main Board



The **Main Board/Info** tab displays information relating to the Viper-CamLink onboard firmware. The scroll window named **Content** provides firmware details such as version, release date, etc.

Other tabs, such as **Main Board/i960**, provide the mechanism to manually upload custom firmware prepared by Coreco Imaging engineering for particular client solutions. The **Browse** button allows selecting custom firmware (path saved by the **Save Settings** button), while the **Program** button uploads the firmware to the Viper-CamLink. The **Verify** button checks the firmware checksum relative to its stored value.

PixPro Info




For Viper-CamLink boards with the optional Pixel Processor module installed, the **PixPro Info** tab displays information such as serial number and board revision of the Pixel Processor.

Connecting Embedded Processors via CAB

For information concerning the installation and connection between a Mamba-100 and a Viper-CamLink via the CAB, see the *Mamba-100 User's Manual* (OC-MAMM-USER0). For information concerning configuring and programming CAB transfers, see the *Sapera CAB User's Manual* (OC-SAPM-CABU0).

Camera to Viper-CamLink Connections



The hardware installation process is completed with the connection of a supported camera to the Viper-CamLink board. The camera will have one or two Camera Link MDR-26 connectors plus a connector for an external power supply. Connect the camera to the Viper-CamLink J1 connector with a Camera Link cable. If required, connect the second camera connector to Viper-CamLink J2. Refer to section "Connector and Switch Locations" on page 33.

Contact Coreco Imaging or browse our web site (www.imaging.com) for the latest information on Viper-CamLink supported cameras.

The Sapera Demo Application


Acquisition Demo Overview

Program	Start•Programs•Coreco Sapera Library•Demos•Acquisition Demo
Program file	<code>\sapera\demos\standard\vc\sacqdemo\release\sacqdemo.exe</code>
Project file	<code>\sapera\demos\standard\vc\sacqdemo\sacqdemo.dsp</code>
Description	This program demonstrates the basic acquisition functions included in the Sapera library. The program allows you to acquire images, either in continuous or in one-shot mode, while adjusting the acquisition parameters. The program code may be extracted for use within your own application.
Remarks	This demo is built using Visual C++ 6.0 using the MFC library. It is based on the Sapera standard API and Sapera C++ classes. See the Sapera User's and Reference manuals for more information.


Using the Acquisition Demo

Server Selection

Run the acquisition demo program from
Start•Programs•Coreco Imaging•Sapera•Demos•Acquisition Demo.



The Acquisition Demo program starts by displaying the acquisition parameters menu. The first drop menu displayed permits selecting from any installed Sapera acquisition servers (installed Coreco Imaging acquisition hardware using Sapera drivers). The second drop menu permits selecting from the available input devices present on the selected server. In the following figure, the Viper-CamLink is the selected server along with itsand selected input device.



CAM and VIC file Selection


The acquisition parameters menu is also used to select the required camera file pair for the connected camera. Sapera camera files are composed of ***.cam** files for timing parameters and ***.cvi** files for video conditioning parameters. Use the **Browse** button to select a ***.cam** file that is either provided by Coreco Imaging or one generated by the Sapera CamExpert Utility program.

Additionally, select a ***.vic** file for the required operating mode of your camera. If no ***.vic** file is available, click on the **Generate Default** button. A vic file with corresponding default parameters for the selected camera and acquisition hardware is generated.

Note that the Sapera CamExpert Utility can later be used to adjust cvi parameters for the required camera mode.

Acquisition Demo Main Window

The Acquisition Demo main window provides control buttons and a central area for displaying the grabbed image. Developers can use the demo source code as a foundation to quickly create and test the desired imaging application.



The following sections describe the various functions:

File Control

Three controls are provided for image file transfers.

1. **New:** Clear the current image frame buffer.
2. **Load:** Retrieves images in BMP, TIF, CRC, JPG, and RAW formats.
3. **Save:** Prompts for a file name, file save location, and image format.

Acquisition Options

Note that unsupported functions are grayed out and not selectable. Function support is dependent on the frame grabber hardware in use.

General – Acquisition Settings: Allows enabling Viper-CamLink external trigger mode.

Area Scan – Camera Control: Provides trigger, reset, and integrate control when supported by the current hardware and driver.

Line Scan – Camera Control: Provides Line Scan camera controls such as external line/frame trigger selection, shaft encoder input selection, etc. when supported by the current hardware and driver.

Composite - Conditioning: This dialog is not applicable to the Viper-CamLink.

Load CAM/VIC: Opens the dialog window **Acquisition Parameters** allowing the user to load a new set of camera files. This is the same window as when the Sopera Acquisition demo is started.

Acquisition Control

Click **Grab** - you will now see live digitized video from your video source. If your source is a camera, focus and adjust the lens aperture for the best exposure. Use a video generator as a video source to acquire reference images.

Click **Freeze** - the Viper-CamLink will stop live grab mode. The grabbed image can be saved to disk via the **File Control**•**Save** control.


Click **Snap** – a single video frame is grabbed.

Abort – exits the current grab process immediately. If any video signal problem prevents the freeze function from ending the grab, click on the **Abort** button.

General Options

Buffer: Select from supported frame buffer counts, size, and types.

Note: functions grayed out are not currently supported by the acquisition hardware.



Count and Size: Provides selection of the number of frame buffers and the image size.

Type – **Contiguous:** Frame buffers are allocated in contiguous system memory (single memory block - no segmentation).

Type – **Scatter-Gather:** Frame buffers are allocated throughout system memory in noncontiguous memory (paged pool). Pages are locked in physical memory so a scatter-gather list can be constructed. This type allows the allocation of very large size buffers or large buffer count.


Type – **Off-screen Video**: The buffer is allocated in off-screen video memory and uses the display adapter hardware to perform a fast copy from video memory to video memory.

Type – **Overlay**: The frame buffer is allocated in video memory where the display adapter overlay hardware uses color-keying to view the overlay buffer.

Format: Allows selection of the frame buffer pixel type as supported by the hardware and driver.

Configuring Sapera



Viewing Installed Sapera Servers



The Sapera configuration program (**Start•Programs•Coreco Imaging•Sapera•Sapera Configuration**) allows the user to see all available Sapera servers for the installed Sapera-compatible boards.


The **System** entry represents the system server. It corresponds to the host machine (your computer) and is the only server that should always be present. As shown in the following screen image, server index 1 is the Viper-CamLink board installed. To update the server list, the **Refresh** button can be utilized at any time.

The **Contiguous Memory** tab lets the user specify the total amount of contiguous memory to be reserved for **Sapera objects** allocation and **Sapera messaging**. The **Requested** value displays what has been requested while the **Current** value displays the amount of contiguous memory that has been allocated successfully. The current value for **Sapera objects** determines the total amount of contiguous memory reserved at boot time for the allocation of dynamic resources (e.g., buffers, lookup tables, kernel). Adjust this value according to your application's need for contiguous memory. The current value for **Sapera messaging** determines the total amount of contiguous memory reserved at boot time for the allocation of messages. This memory space is used to store arguments when a Sapera function is called. Increase this value if you are using functions with large arguments, such as arrays.



Viper-CamLink Reference

Viper-CamLink Block Diagram



Acquisition

Acquisition Modes

The Viper-CamLink acquires at rates up to 200 MB/sec and features two 32-bit wide input channels providing 8, 16, or 32 bit/pixel formats. Acquiring pixels at 50MHz, the Viper-CamLink can transfer images directly into host computer system memory or to the Mamba via the CAB. The Viper-CamLink supports input resolutions from 4 pixels per tap by 32 lines to a maximum of 32K pixels by 256K lines.


Variable frame rate capability allows data capture from high or slow frame rate cameras, where images are later analyzed or viewed. The Viper-CamLink is programmable, interfacing easily to a wide range of pixel clocks, vertical refresh rates, horizontal line rates, and scan type cameras.

Viper-CamLink can reverse the data order acquired from each independent tap (or it can also reverse an entire image). Data reversal supports multi-tap cameras whose data output is reversed.

Pixel Processor

The Pixel Processor is an optional processing module designed for the Viper line of products as well as the Cobra/C6. It performs point-to-point and neighborhood operations on live images. Reference images can be acquired and stored in the pixel processor's onboard frame buffer for further operations. It also features a re-programmable processor unit with frame buffer memory that is used to buffer reference images, incoming images, and intermediate results. The Pixel Processor operates on pixels at rates up to 200 MB/sec.

Viper-CamLink Acquisition Constraints



- ¹ The setup times for LVAL and FVAL are the same. Both must be high and stable before the rising edge of the Pixel Clock.
- ² Pixel Clock must always be present.
- ³ LVAL must be active high to acquire camera data.
- ⁴ For line-scan cameras, the number of image lines must be a multiple of 32.
- ⁵ HB - Horizontal Blanking:

Minimum:	4 clocks/cycle
Maximum:	no limits
- ⁶ VB - Vertical Blanking:

Minimum:	1 line
Maximum:	no limits
- ⁷ First Active Pixel (unless otherwise specified in the CCA file – "Horizontal Back invalid = x" where 'x' defines the number of pixels to be skipped).
- ⁸ Last Active Pixel – defined in the CCA file under "Horizontal active = y" – where 'y' is the total number of active pixels per tap.
Note: 'y' must be a multiple of 4.
- ⁹ Maximum Valid Data:
 - 8-bits/pixel x 32K Pixels/line (LVAL)
 - 16-bits/pixel x 16K Pixels/line (LVAL)
 - 32-bits/pixel x 8K Pixels/line (LVAL)
 - 64-bits/pixel x 4K Pixels/line (LVAL)
 - 262,144 lines (FVAL)

Shaft Encoder Interface


Connector J14, dual balanced shaft encoder inputs:

- Input 1: Pin 1 (PH0 +) & Pin 2 (PH0 -)
- Input 2: Pin 3 (PH1+) & Pin 4 (PH1-)

Web inspection systems with variable web speeds typically provide one or two synchronization signals from a web mounted encoder to coordinate trigger signals. These trigger signals are used by the acquisition line scan camera. The Viper-CamLink supports single or dual shaft encoder signals. Dual encoder signals are typically 90 degrees out of phase relative to each other and provide greater web motion resolution.

When enabled, the camera is triggered and acquires one scan line for each shaft encoder pulse edge. To optimize the web application, a second Sapera parameter defines the number of triggers to skip between valid acquisition triggers.

The figure below depicts a system where a valid camera trigger is any pulse edge from either shaft encoder signal. After a trigger the two following triggers are ignored (as defined by a Sapera parameter).



Note that camera file parameters are best modified by using the Sapera CamExpert program.

CVI File Parameters Used

Shaft Encoder Enable = X, where:

- If X = 1, Shaft Encoder is enabled
- If X = 0, Shaft Encoder is disabled

Shaft Encoder Pulse Drop = X, where:

- X = number of trigger pulses ignored between valid triggers


For information on Sapera Camera files (*.cam & *.cvi) see the *Sapera Acquisition Modules Reference Manual* (document number: OC-SAPM-AMR00).

Virtual Frame Sync Interface

The Virtual Frame Sync, when enabled, defines the start of a line scan acquisition into a frame buffer. Virtual Frame Sync is typically used with motion detectors or web object detectors.

After receiving the frame sync, the Viper-CamLink starts the line scan acquisition and captures the number of lines specified by the frame buffer height. The Virtual Frame Sync can be TTL or RS-422 and be rising or falling edge active. The Virtual Frame Sync balanced inputs are on the Viper-CamLink connector J14 pin 5 (+) and 6 (-).

The figure below depicts the synchronization signals for a virtual frame of 10 lines.



Note: In this example, 10 lines are acquired

The Maximum frame rate = Max. Line Rate / nb lines (Hz)

Note that camera file parameters are best modified by using the Sapera CamExpert program.

CVI File Parameters Used

External Frame Trigger Enable = X, where:

- If X = 1, External Frame Trigger is enabled
- If X = 0, External Frame Trigger is disabled

External Frame Trigger Detection = Y, where

- If Y = 4, External Frame Trigger is active on rising edge
- If Y = 8, External Frame Trigger is active on falling edge

External Frame Trigger Level = Z, where

- If Z = 2, External Frame Trigger is a RS-422/LVDS signal

For information on Sapera Camera files (*.cam & *.cvi) see *the Sapera Acquisition Modules Reference Manual* (document number: OC-SAPM-AMR00).

Appendix A: Viper-CamLink Servers & Resources

Servers and Resources

Servers			Resources	
Name	Description	Type	Index: Name	Description
Viper_CamLink_1	Viper-CamLink server	Acquisition	0: Viper-CamLink Interface	Digital acquisition device
		CAB	0: Coreco Auxiliary Bus	Coreco Auxiliary Bus
		Pixel Processor	0: Pixel Processor	Pixel Processor device

Transfer Resource Locations

The following table illustrates all possible source/destination pairs in a transfer. The sources and destinations are presented vertically and horizontally respectively.

Note: The transfer resource must always be located on the Viper-CamLink_1 server.

Source	Destination			
	Acquisition (Viper-CamLink_1)	CAB (Viper-CamLink_1)	Buffer (System)	Pixel Processor (Viper-CamLink_1)
Acquisition (Viper-CamLink_1)	no	yes	yes	yes
CAB (Viper-CamLink_1)	no	no	no	no
Buffer (System)	no	no	no	no
Pixel Processor (Viper_Digital_1)	no	yes	yes	no

Appendix B: Technical Specifications

Viper-CamLink Specifications

General System Requirements for the Viper-CamLink

- Pentium II/III or compatible computer systems with one free full-length PCI local bus slot supporting bus master devices (5 volt).
- 33 MHz PCI bus clock for best performance.
- Support of PCI burst mode for realtime acquisition into system memory.
- Support of the PCI plug and play specification.

Operating System Support

Windows NT 4.0 SP6 and Windows 2000 SP1

Digital Video Input

Number	<ul style="list-style-type: none">• 1 digital input (Camera Link – up to Full Mode)
Pixel Format	<ul style="list-style-type: none">• Monochrome<ul style="list-style-type: none">Up to 8 x 8-bit/pixelUp to 4 x 10-bit/pixelUp to 4 x 12-bit/pixelUp to 4 x 14-bit/pixel1 x 16-bit/pixel• RGB<ul style="list-style-type: none">24-bit/pixel30-bit/pixel
Scanning	<ul style="list-style-type: none">• Progressive<ul style="list-style-type: none">Multi-TapMulti-ChannelFour quadrantTap reversal

Resolution

- Horizontal Minimum:
4 Pixels per tap
- Horizontal Maximum:
8-bits/pixel x 32K Pixels/line
16-bits/pixel x 16K Pixels/line
32-bits/pixel x 8K Pixels/line
64-bits/pixel x 4K Pixels/line
- Vertical Minimum:
32 lines
- Vertical Maximum:
up to 256K lines (262,144 lines)

Sync and Control

- Pixel clock range**
- 20 MHz to 50 MHz for 32 bits total input
20 MHz to 25 MHz for 64 bits total input

Viper-CamLink Physical Dimensions

Approximately 12.25" W×4.125" H (31 cm W×10.5 cm H)
[requires a full length PCI slot]

Power Requirements

+5 volts, 2.5 A


Environment

Ambient Temperature: 10° to 50° C (operation)
0° to 70° C (storage)

Relative Humidity: 5% to 90% non-condensing (operating)
0% to 95% (storage)


Connector and Switch Locations

Viper-CamLink Connectors



Note that CamLink is shown attached to the main board with the connector side down.

Viper-CamLink Main Board Connectors



Connector List-CamLink Module


Connector	Description	Connector	Description
J1	Camera Link connector 1	J3	RS-232 port – Reserved
J2	Camera Link connector 2	J4, J5	Reserved
J6, J9, J10, J11, J12	Digital Camera Data transfer connectors to main board.	J14	Shaft Encoder/Frame Reset connector (right angle mount)
J7, J8	Reserved	J17, J18	Reserved

Connector List-Main Board

Connector	Description	Connector	Description
J3	Pixel Processor Module Connector	J16, J20, J24, J15	Reserved
J7, J8, J13, J14	Reserved	J19, J21	CAB Interface
J6	Camera Control Signals	J22	Microcontroller Serial Port
J9, J10, J11, J12	Digital Camera Data	J500	General I/O
SW1	Configuration & Test Switch	J504, J505	Reserved

Connector and Switch Specifications

Camera Link Connector View



J1: Camera Link Connector 1

Name	Pin #	Type	Description
BASE_X0-	25	Input	Neg. Base Data 0
BASE_X0+	12	Input	Pos. Base Data 0
BASE_X1-	24	Input	Neg. Base Data 1
BASE_X1+	11	Input	Pos. Base Data 1
BASE_X2-	23	Input	Neg. Base Data 2
BASE_X2+	10	Input	Pos. Base Data 2
BASE_X3-	21	Input	Neg. Base Data 3
BASE_X3+	8	Input	Pos. Base Data 3
BASE_XCLK-	22	Input	Neg. Base Clock
BASE_XCLK+	9	Input	Pos. Base Clock
SERTC-	20	Output	Neg. Serial Data to Camera
SERTC+	7	Output	Pos. Serial Data to Camera
SERTFG-	19	Input	Neg. Serial Data to Frame Grabber
SERTFG+	6	Input	Pos. Serial Data to Frame Grabber
CC1-	18	Output	Neg. Camera Control 1
CC1+	5	Output	Pos. Camera Control 1
CC2-	17	Output	Neg. Camera Control 2
CC2+	4	Output	Pos. Camera Control 2
CC3-	16	Output	Neg. Camera Control 3
CC3+	3	Output	Pos. Camera Control 3
CC4-	15	Output	Neg. Camera Control 4
CC4+	2	Output	Pos. Camera Control 4
GND	1, 13, 14, 26		Ground

J2: Camera Link Connector 2

Name	Pin #	Type	Description
MEDIUM_X0-	25	Input	Neg. Medium Data 0
MEDIUM_X0+	12	Input	Pos. Medium Data 0
MEDIUM_X1-	24	Input	Neg. Medium Data 1
MEDIUM_X1+	11	Input	Pos. Medium Data 1
MEDIUM_X2-	23	Input	Neg. Medium Data 2
MEDIUM_X2+	10	Input	Pos. Medium Data 2
MEDIUM_X3-	21	Input	Neg. Medium Data 3
MEDIUM_X3+	8	Input	Pos. Medium Data 3
MEDIUM_XCLK-	22	Input	Neg. Medium Clock

MEDIUM_XCLK+	9	Input	Pos. Medium Clock
TERM	20		Term Resistor
TERM	7		Term Resistor
FULL_X0-	19	Input	Neg. Full Data 0
FULL_X0+	6	Input	Pos. Full Data 0
FULL_X1-	18	Input	Neg. Full Data 1
FULL_X1+	5	Input	Pos. Full Data 1
FULL_X2-	17	Input	Neg. Full Data 2
FULL_X2+	4	Input	Pos. Full Data 2
FULL_X3-	15	Input	Neg. Full Data 3
FULL_X3+	2	Input	Pos. Full Data 3
FULL_XCLK-	16	Input	Neg. Full Clock
FULL_XCLK+	3	Input	Pos. Full Clock
GND	1, 13, 14, 26		Ground

J3: CamLink Module - RS-232 Port - Reserved


Pin Number	Description
5	Serial IN
3	Serial OUT
9	Ground
1, 2, 4, 6, 7, 8, 10	not connected

J14: CamLink Module - I/O (LVDS)

Name	Pin Number	Type	Description
Shaft Encoder 0 +	1	Input	SE0+
Shaft Encoder 0 -	2	Input	SE0-
Shaft Encoder 1 +	3	Input	SE1+
Shaft Encoder 1 -	4	Input	SE1-
¹ Frame Reset +	5	Input	Frame_Reset+
Frame Reset -	6	Input	Frame_Reset-
Reserved	7,8,9,10,11,12,15,16,17,18,19,20,21,22,23,25		
	13, 14, 24, 26	Ground	GND

¹. LVDS Frame Reset input is mutually exclusive with TTL Frame Reset input.

SW1: Configuration & Test Switch



Note: switch settings shown in factory default position.

Switch Number	Name	Position	Description	Function
4	CFG0	ON	Boot mode	i960 boots from boot block
		OFF		i960 boots from application (default)
3	CFG1	ON	PCI class	Bridge device (default)
		OFF		Multimedia device
2	CFG2	OFF	Reserved	
1	TEST	ON	Reserved	
		OFF		Normal operation

J7, J8, J13, J14: Not Applicable

J3: Pixel Processor Connector

See: Pixel Processor (page 24).

J19, J21: Cab Interface

See: The *CAB User's Manual* OC-SAPM-CABU0.

J500: General I/O

2	4	...	14	16
1	3	...	13	15

Pin Number	Name	Type	Description
1	GIO_1	Output/Input	General IO
2, 4, 6, 8, 10, 12, 14, 16	GND		Ground
3	GIO_2	Output/Input	General IO
5	GIO_3	Output/input	General IO
7	GIO_4	Output/Input	General IO
9	FRAME RESET	Output	Frame Reset Output
11	EXSYNC	Output	Control Frame Rate / Control Line Rate $V_{OH}=2.4V$, $V_{OL}=0.4V$, $I_{OH}=-4mA$, $I_{OL}=12ma$
13	¹ FRAME_RESET	Input	Frame Reset - TTL level $V_{IH} = 2.0V$, $V_{IL} = 0.8V$ $I_{IH} = 20\mu A$, $I_{IL} = -0.6mA$
15	FORWARD/ REVERSE	Output	TDI Control (scan direction) $V_{OH} = 2.4V$, $V_{OL} = 0.4V$ $I_{OH} = -4mA$, $I_{OI} = 12mA$

¹. TTL Frame Reset input is mutually exclusive with LVDS Frame Reset input.

J22: Microcontroller Serial Port

10-pin male header connector.

9	7	5	3	1
10	8	6	4	2

Pin Number	Description
1, 2, 4, 6, 7, 8, 10	Not connected
3	Receive*
5	Transmit*
9	Ground

* RS232 standard

Brief Description of Standards RS-232, RS-422, & RS-644 (LVDS)

RS-232

Short for *recommended standard-232C*, a standard interface approved by the Electronic Industries Association (EIA) connecting serial devices.

The standards for RS-232 and similar interfaces usually restrict RS-232 to 256kbps or less and line lengths of 15M (50 ft) or less.

Transmitted Data (TxD) This signal is active when data is transmitted from the DTE device to the DCE device. When no data is transmitted, the signal is held in the mark condition (logic '1', negative voltage).

Received Data (RxD) This signal is active when the DTE device receives data from the DCE device. When no data is transmitted, the signal is held in the mark condition (logic '1', negative voltage).

DTE (Data Terminal Equipment)

DCE (Data Communication Equipment)

RS-422

RS-422 uses a twisted-pair wire (i.e., 2 wires) for each signal. The differential drive voltage swing is 0 to +5V. RS-422 does not have tri-state capability (its driver is always enabled) and it is therefore usable only in point-to-point communications.

Although RS-422 is noise resistant, due to being differential data can still be damaged by EMI/RFI. A shielded cable can protect the transmitters/receivers from EMI/RFI.

RS-664 (LVDS)

LVDS (Low-Voltage Differential Signaling): method to communicate data using a very low voltage swing (about 350mV) over two differential PCB traces or a balanced cable. LVDS allows single channel data transmission at hundreds of Megabits per second (Mbps).

Appendix C: Camera Link Interface

Camera Link Overview

Camera Link is a communication interface for vision applications developed as an extension of National Semiconductor's Channel Link technology. The advantages of the Camera Link interface are that it provides a standard digital camera connection specification, a standard data communication protocol, and simpler cabling between camera and frame grabber.

The Camera Link interface simplifies the usage of increasingly diverse cameras and high signal speeds without complex custom cabling. For additional information concerning Camera Link, see <http://www.pulnix.com/CameraLink.html>.



Rights and Trademarks

Note: The following text is extracted from the Camera Link Specification (October 2000).

PULNiX America, Inc., as chair of this ad hoc Camera Link committee, has applied for U.S. trademark protection for the term "Camera Link" to secure it for the mutual benefit of industry members. PULNiX will issue a perpetual royalty-free license to any industry member (including competitors) for the use of the "Camera Link" trademark on the condition that it is used only in conjunction with products that are fully compliant to this standard. PULNiX will not require licensed users of the trademark to credit PULNiX with ownership.

3M™ is a trademark of the 3M Company.

Channel Link™ is a trademark of National Semiconductor.

Flatlink™ is a trademark of Texas Instruments.

Panel Link™ is a trademark of Silicon Image.

Data Port Summary

The Camera Link interface has three configurations. A single Camera Link connection is limited to 28 bits requiring some cameras to have multiple connections or channels. The naming conventions for the three configurations are:

- Base: Single Channel Link interface, single cable connector.
- Medium: Two Channel Link interface, two cable connectors.
- Full: Three Channel Link interface, two cable connectors.

A Camera Link port is defined as an 8-bit word. The "Full" specification supports 8 ports labeled as A to H.

Camera Signal Summary

Video Data

Four enable signals are defined as:

- FVAL Frame Valid (FVAL) is defined HIGH for valid lines.
- LVAL Line Valid (LVAL) is defined HIGH for valid pixels.
- DVAL Data Valid (DVAL) is defined HIGH when data is valid.
- Spare A spare has been defined for future use.

All four enables must be provided by the camera on each Channel Link. All unused data bits must be tied to a known value by the camera.

Camera Controls

Four LVDS pairs are reserved for general-purpose camera control, defined as camera inputs and frame grabber outputs.

- Camera Control 1 (CC1)
- Camera Control 2 (CC2)
- Camera Control 3 (CC3)
- Camera Control 4 (CC4)

Note: the Viper-CamLink by default implements the control lines as follows (using DALSA Corporation terminology).

- (CC1) EXYNC
 - (CC2) PRIN
 - (CC3) FORWARD
 - (CC4) HIGH
-

Communication

Two LVDS pairs have been allocated for asynchronous serial communication to and from the camera and frame grabber. Cameras and frame grabbers should support at least 9600 baud.

- SerTFG Differential pair with serial communications to the frame grabber.
- SerTC Differential pair with serial communications to the camera.

The serial interface protocol is one start bit, one stop bit, no parity, and no handshaking.

Camera Link Cables


For additional information on Camera Link cables and their specifications, visit the following web sites:

- | | |
|-----------------|---|
| 3 M | http://www.3m.com/us/electronics_mfg/interconnects/
<i>(enter Camera Link as the search keyword)</i> |
| Nortech Systems | http://www.nortechsys.com/intercon/CameraLinkMain.htm |


Appendix D: Troubleshooting

PCI Configuration


The first item to verify when there is a problem with any PCI board is to examine the system PCI configuration and ensure that there are no conflicts with other PCI or system devices. The *Coreco Imaging PCI Diagnostic* program (**cpctdiag.exe**) allows examination of the PCI configuration registers and can save this information to a text file. Run the program via the Windows Start Menu shortcut **Start•Programs•Coreco Imaging•Sapera•Tools•Coreco PCi Diagnostics**



As shown in the image below, a PCI device is selected in the first drop menu. Select the device Viper-CamLink PPB and Viper-CamLink ATU.



Click on the **Diagnostic** button to view an analysis of your PCI configuration. The **Information** message box contains the diagnostic report. If there is a problem, click on the **Save** button. A file named ‘**pcidiag.txt**’ is created with a full dump of the PCI configuration registers. Email this file to the Coreco Imaging Technical Support group with a full description of your computer. For contact information see “Technical Support” on page 52.




The most common problem is an invalid interrupt assigned to the Viper-CamLink. See “Solving Interrupt Assignment Problem” (page 49) for a possible solution.

Windows NT Control Panel Devices

The next step is to inspect *Windows NT Control Panel Devices* to make certain the appropriate Coreco Imaging drivers have started successfully during the boot sequence. Click on the **Start•Settings•Control Panel**, then double-click on the **Devices** item. Make certain the following drivers have started for the Viper-CamLink driver:

Device	Description
CorVCamLink	<i>Viper-CamLink messaging</i>
CorLog	<i>Log viewer</i>
CorMem	<i>Memory manager</i>
CorPci	<i>PCI configuration</i>


The **Devices** dialog box should resemble the following screenshot. All other devices, except the ones mentioned in the table above, may differ on individual systems. The example below shows the driver for the Coreco Imaging Viper-CamLink is active.



Coreco Imaging Technical Support may request that you check the status of these Coreco Imaging drivers as part of the troubleshooting process.

Log Viewer


The third step in the verification process is to save in a text file the contents of the Coreco Log Viewer. Run the program via the Windows Start Menu shortcut **Start•Programs•Coreco Imaging•Sapera•Coreco Log Viewer**.



The Coreco Log Viewer lists information about Coreco Imaging drivers installed. Click on **File•Save** and you will be prompted for a text file name to save the Log Viewer contents. Email this text file to Coreco Imaging Technical Support when requested or as part of your initial contact email.

Although the information collected by the Log Viewer seems complicated, you can make some initial diagnostics by checking the status of the Coreco Imaging driver. In the screen shot below, note the line:

[... CORVCAMLINK.SYS INITDEVICES => Number of Viper_Cam_Link boards found: 1].



Other Tools for Windows NT

Windows NT Event Viewer, under **Start•Programs•Administrative Tools•Event Viewer**, lists various events that have taken place during the Operating System (OS) boot sequence. If a driver generates an error, it will normally log an entry in the event list.

Windows NT Diagnostics is an additional source for accessing system information. It is located under **Start•Programs•Administrative Tools•Windows NT Diagnostics**. This tool lists information related to a specific system. Coreco Imaging Technical Support may request this information.

Solving Interrupt Assignment Problems (Switch 3 of SW1)

With the switch set to **ON** (default), PCI function 0 of the i960 controller is set to *PCI-PCI bridge* device. In general, there is no reason to change this setting.

With some older computers this configuration will cause the computer's BIOS to assign an invalid interrupt to PCI function 1 of the i960. By setting the switch to **OFF**, PCI function 0 of the i960 is set to *Multimedia Device*, and the computer BIOS should assign a valid interrupt. Possible side effects may be that the PCI diagnostic program may falsely detect a conflict.

PCI-PCI
Bridge
Device



Multimedia
Device

Coreco Imaging Contact Information

Sales Information

Corporate Headquarters

Coreco Imaging Inc.
6969 Trans-Canada Hwy. Suite #142
St. Laurent, Quebec
H4T 1V8
Canada

Tel: (514) 333-1301
Fax: (514) 333-1388

US Sales Office

Coreco Imaging Inc.
55 Middlesex Turnpike
Bedford, Ma. 01730

Tel: (781) 275-2700
Fax: (781) 275-9590

Visit our web site:

www.imaging.com

Email:

info@corecoimaging.com

Technical Support

Technical support requests for imaging product installations and help with imaging applications can be made at:

United States: (781) 275-2700

International: (514) 333-1301

Technical support requests for all camera related questions can be made at:

US & International: (514) 333-1301

Or all requests can be submitted via our web site: www.imaging.com/support

For product literature and driver updates: www.imaging.com/download

Glossary of Terms

Bandwidth

Describes the measure of data transfer capacity. A computer system's PCI expansion bus is rated for a maximum peak data bandwidth of 132 MB/sec. PCI devices must share the maximum PCI bus bandwidth when transferring data to and from system memory or other devices.

CAM

Sapera camera file that uses the file extension CCA by default.

Channel

Camera data path that includes all parts of a video line.

checksum

A value used to ensure data is stored without error. It is created by calculating the binary values in a block of data using some algorithm and storing the results with the data.

CMI

Client Modification Instruction. A client requested engineering change applied to a Coreco Imaging board product to support either a non-standard function or custom camera.

Contiguous memory

A block of physical memory, occupying consecutive addresses.

CRC

Proprietary Sapera raw image data file format that supports any Sapera buffer type and utilizes an informative file header. Refer to the *Sapera Basic Modules Reference Manual* "Buffer File Formats" section.

Firmware

Software such as a board driver that is stored in nonvolatile memory mounted on that board.

Frame buffer

An area of memory used to hold a frame of image data. A frame buffer may exist on the acquisition hardware or be allocated by the acquisition hardware device driver in host system memory.

Grab

Acquiring an image frame by means of a frame grabber.

Host

Refers to the computer system that supports the installed frame grabber.

Host buffer

Refers to a frame buffer allocated in the physical memory of the host computer system.

LSB

Least Significant Bit in a binary data word.

MSB

Most Significant Bit in a binary data word.

PCI

Peripheral Component Interconnect. The PCI local bus is a 32-bit high-performance expansion bus intended for interconnecting add-in boards, controllers, and processor/memory systems.

Pixel

Picture Element. The number of pixels describes the number of digital samples taken of the analog video signal. The number of pixels per video line by the number of active video lines describes the acquisition image resolution. The binary size of each pixel (i.e., 8-bits, 15-bits, 24-bits) defines the number of gray levels or colors possible for each pixel.

RAW

A Sapera data file format where there is no header information and that supports any Sapera buffer type. Refer to the *Sapera Basic Modules Reference Manual* “Buffer File Formats” section.

RISC

(Reduced Instruction Set Computer) A computer architecture that reduces chip complexity by using simpler instructions.

Scatter Gather

Host system memory allocated for frame buffers that is virtually contiguous but physically scattered throughout all available memory.

Tap

Data path from a camera that includes a part of or whole video line. When a camera tap outputs a partial video line, the multiple camera tap data must be constructed by combining the data in the correct order.

VIC

Sapera camera parameter definition file that uses the file extension CVI by default.

Index

A

Abort 20
acquisition parameters 17–18, 17–18, 20
ActiveX 5
add-on modules 9
administrator 9–10, 9–10
Area Scan 19
AUTORUN 9–10, 9–10

B

BIOS 49
buffer 19–20, 19–20, 24, 27
buffer count 20
bus master 3, 5, 31

C

CAB 3–4, 24
Camera file 18, 26–27, 26–27
Camera Link 3, 10, 16, 31, 41–42
Camera Link modes 3
CamExpert 18, 26–27
connectors 16, 27
Contiguous 20–21
Coreco Imaging web site 2

D

development libraries 5
Digital Signature 11

F

file transfers 19
Found New Hardware Wizard 10
frame buffer 19–20, 24, 27
freeze 20
Full Installation 10–11

H

HTML help 2

I

image format 19
interface bracket 10
Internet 2

L

Line Scan 19, 26–27
LVDS 5, 27, 42–43

M

MAMBA-100 3–4, 16
MDR-26 10, 16
memory 3, 5, 20–21, 24, 31

N

National Semiconductor 41

O

overlay 21

P

PDF 2
Pixel Processor 4, 9, 15

Q

quadrature-shaft encoder 5

R

Run Time installation 10–11

S

Sapera ActiveX Controls manual 7
Sapera CAB User's manual 4, 16
Sapera CD-ROM 9–10
Sapera messaging 21
Sapera objects 21
Sapera User's manual 7, 9, 13

Scatter-Gather 3, 20
serial numbers 12
server list 21
shaft encoder 5, 19, 26
Static electricity 9

T

technical support 12, 14, 46–49
trigger 5, 19, 26

V

Variable frame rate 24
viewer program 13–14
Viper-CamLink viewer 13

W

Web inspection 5, 26
workstation 9