

Saleae Logic Software Users Guide

Updated December 29, 2014

Contents

- Wire Harness & Test Clips 2**
- Logic Software - Installation..... 6
- Collecting Data & Device Settings..... 8
- Navigating Your Data (zooming, panning, re-arranging, re-sizing etc) 12
- Measurements, Timing Markers, and Bookmarks 20
- Using the Trigger 26
- Using Protocol Analyzers 29
- Saving, Loading, and Exporting Data..... 34
- Keyboard Shortcuts..... 37
- Connecting to your Circuit 38
- Protecting Against Ground Loops 39

Wire Harness & Test Clips

Wire Harness

There are two types of wire harnesses. A 1x9 wire harness is used by Logic and Logic16 (1st generation products). A 2x4 wire harness is used by Logic 4, Logic 8, Logic Pro 8, and Logic Pro 16 (2nd generation products).



Generation 2, 2x4 Wire Harness



Generation 1, 1x9 Wire Harness

Connecting the 2x4 harness

If you have Logic 4, Logic 8, or Logic Pro 8/16, then you have one or more 2x4 wire harnesses.

The four black leads are ground, and these should be on the bottom. The four colored leads are the signal inputs, and they should be on the top. There is also an indication of this orientation on the back side of the device.



Note that the test lead color matches the channels in the software. The colors reflect the resistor color code for numbers 0-7. The numerical channel number is written on the white heat shrink at the ends of the leads. The lead ends are terminated with a Molex 0016020086 crimp connector for connection to typical .100-inch spaced headers/pins. The 2x4 plastic housing is Molex 0022552081.

Signal Integrity with the 2x4 Harness

The 2x4 harness has a ground lead for each signal. When signal integrity is a concern -- such as when working with high speed digital or analog in the presence of cross-talk sources, connect a ground for each signal. Connect noisy digital inputs to leads as far as possible from leads connected to sensitive analog measurements.

Connecting the 1x9 harness

If you have the original Logic or Logic16, then you have one or more 1x9 wire harnesses. These harnesses are colored according to the resistor color code for 0-7. These colors match the channel colors in the software. The ground wire is grey and has a GROUND label on white heat shrink. Turn the device over for a ground symbol - and make sure the grey test lead aligns with this symbol.



Signal Integrity with the 1x9 Harness

When using Logic16 with more than 8 inputs, we recommend connecting the second ground line - especially if using higher voltages (5V). This will help reduce cross-talk during any simultaneous switching events.

Test Clips

All Logic products come with enough test clips for every test lead. These test clips have two metal pins that can be inserted into the connector at the end of each test lead.



Connecting to headers

If your PCB has .100-inch headers that break out signals you need to examine, you can connect the test leads to these pins directly.

Ultra-fine pitch and other difficulties

In many situations it may be difficult to connect Logic directly to your signal. Generally in these situations you'll want to solder a wire (typically wire-wrap wire) to an exposed pin, trace, or via, and then use Logic's test clip to connect to that wire.

Logic Software - Installation


Downloading the Latest Software

The latest Logic software can be found at <https://www.saleae.com/downloads>. You can install this software on as many machines as you like.

Note: beta software may also be available, and this can also be found at <https://www.saleae.com/downloads>

Checking if You Have the Latest Version

With the Logic Software open, click the Options button at the top right of the software. There is a menu item, 3rd from the bottom, containing update availability information.



Installing for Windows

Simply download and run the installer - it is the same as other software you have installed in the past. During the installation, you will be prompted if you want to trust software from Saleae (you do). This is because we install a driver for the Logic hardware.

Installing for Mac

Simply download, double click, and drag the Logic software into the Application Folder - the same as you would when installing other Mac software.



Installing for Linux

Download the zip file and extract it. The software will run from this folder. You can leave this folder on your desktop, or move it anywhere you like that has write permissions. Launch the Logic software by opening the folder and double-clicking the Logic executable. You may wish to make a shortcut to this executable for more convenient access.


Installing for Linux - Driver

Before using the software with the Logic hardware, you'll need to give the application permission to access the device (otherwise you'll have to launch the application with `sudo`). To do this, unplug any attached Logic device(s), and from the command line, navigate to the *Driver* folder and run the script `install_driver.sh`.

Collecting Data & Device Settings

Demo Mode

When no Logic device is connected, the software will work in a demo mode - which is virtually identical to how it will function when a device is connected. This way you can become familiar with the software before your Logic device arrives.




Collecting Data

To start collection data, just press the big Start button. After the capture has started you can stop it before it finishes if you like - this will retain the data to that point.



Device Settings

To access the device settings, click the up/down arrow next to the Start button.



Start

Logic 8

Speed (Sample Rate) Duration (Record data for)


50 MS/s 20 MS/s 1 Seconds

Channels	0	1	2	3	4	5	6	7
	0	1	2	3	4	5	6	7

Performance 100% 50% 33% 25%


Logic 8

Speed (Sample Rate)




The sample rate drop-down lets you select how fast to sample data - how many times per second your signal is measured. The available options depend on your device, the channels being used, and the performance level selected. Digital data is compressed - no additional memory is used when sampling faster. Rather, memory usage is proportional to the number of transitions in the digital data. Analog data is not compressed, and consumes roughly 4 bytes/sample. At 50Msps, this is 200MB per second, per channel.

Duration



The duration text box allows you to enter the duration of your capture.


Channels



The channels controls lets you quickly enable and disable the channels you would like. You can click and drag over the control to change a number of channels at the same time.

Using fewer channels uses less memory and allows for faster sampling.

Voltages



For devices that support it, you can edit the voltage level of your digital signals. This affects the voltages at which an input is considered a one or a zero.

Performance




Not all computers / USB host controllers will be able to capture at top speed. If this happens you can throttle back the performance setting with this control. This will update the sample rates that are available.

Device



If you have more than one Logic attached, you can toggle between them here. You also can control the LED color here - just click the gear icon.



Closing the Device Settings Popover

To close the Device Settings, click on something outside the popover.


Navigating Your Data (zooming, panning, re-arranging, re-sizing etc)

Zooming in and Out

To zoom in and out, use your mouse wheel.



You can also use the up/down arrow keys, or the plus/minus keys.




Panning Left and Right

To pan right and left, click and drag the display.




You can also use the right/left arrow keys, or use the scroll bar at the bottom of the display.



Jumping between Digital Edges


Sometime digital data comes in packets, with long periods of idle in between.

To jump over idle periods, move your mouse to the far right or far left of a particular channel - a jump button will appear.



Click this button to jump to the next digital transition on that channel.


You can also use the keyboard shortcuts N and P (next and previous). The keyboard shortcut applied to the channel whose jump button was last pressed.



Scrolling Through Channels


Sometimes you may have more channels displayed than can fit on the screen at the same time.

Move your mouse over the channel labels on the left side of the software, and scroll up and down with your mouse wheel.




Alternatively, there is a slider bar at the right side of the channel graphs.

You can also use the Page Up and Page Down keys.




Using Tabs


After you've captured some data, the Capture tab at the bottom left of the screen will have a button with a double-arrow on it.



Click this arrow to move the data into its own tab. To capture more data, go back to the Capture tab.




To edit the text shown on a tab, click the text.



Re-Arranging Channels

To re-arrange channels, drag them by their grip icon at the far left of the channel.




To drag more than one channel, select the first channel by clicking anywhere in the channel label area.



Then control-click additional channels - selecting them as well. You can use shift-select to select a range of channels.


Then drag one of the channels by its grip icon - all the selected channels will move together.

To reset the channel order, click the channel settings icon (gear) on any channel and select Reset All Channels.




Changing Channel Size

To change the channel size, click the channel settings icon (gear) on the desired channel and select a new size.




To change multiple channels to the same size, select them (control-click) and then set one of the selected channel's size. All the selected channels will change their size.



To select all channels, select one, and then press CTRL-A.


Hiding Channels

To hide a channel, click the channel settings icon (gear) and select Hide Channel.



You can hide multiple channels at the same time by selecting multiple channels and then selecting Hide Channel on one of them.


To restore this and other hidden channels, click on a channel's settings icon and select Reset All Channels.




Measurements, Timing Markers, and Bookmarks

Digital Measurements (temporary)

To see digital measurements, place your mouse over pulses in the waveform.




To edit the measurements shown, right-click to get a menu. For advanced measurements, see Using Measurements (persistent) below.




Analog Measurements (temporary)

To see analog measurements, place your mouse over the analog waveform.




To edit the measurements shown, right-click to get a menu. For advanced measurements, see Using Measurements (persistent) below.



Using Annotations


All annotations are listed in the Annotations sidebar at the top right of the software. By default, the Annotations sidebar will contain a Timing Marker annotation.




Using Timing Markers

Timing markers can be used to measure elapsed time between any two locations in your data. By default, the Annotations sidebar will contain a Timing Marker annotation.

To place a timing marker, first press the A1 or A2 buttons.




Move your mouse to the desired location, and click to place the marker.




To cancel placing a timing marker, right-click.

You can also place timing markers with the keyboard 1 and 2 keys.




To place additional markers, click the Plus button on the Annotations panel and select Timing Marker Pair.



To zoom to a particular timing marker pair, click its icon -- which appears at the left side of the Annotation panel.




To delete a timing marker, select its settings icon (gear) and choose Delete Annotation.




Using Bookmarks

A Bookmark is simply a recording of your exact position and zoom level in your data. By making a bookmark, you can quickly zoom back to this area again later.


To add a Bookmark, click the Plus button on the Annotations panel and select Bookmark.




To edit the name of the bookmark, click the Bookmark's label (which by default will be 'Bookmark').



To zoom to a Bookmark, click its icon at the left side of the Annotations panel.




To delete a bookmark, select its settings icon (gear) and choose Delete Annotation.



Using Measurements (persistent)

Adding a Measurement allows you to add a permanent annotation to your data, for later reference. In addition, Measurement Annotations allow for more sophisticated computations than the temporary measurements that always appear at the mouse cursor. For example, you can compute the average duty cycle across thousands of pulses. On analog channels, you can compute the RMS voltage of a given selection.

To add a Measurement Annotation, click the Plus button on the Annotations panel and select Measurement.




Use your mouse to click the starting point of your measurement.




Next, click the desired ending point.




To change which measurements are displayed, right click anywhere inside the measurement area.




The Measurement appears in the Annotations side bar at the right of the software.




Click on the text to edit the name of the Measurement.




To zoom in on the measurement, click its icon on the left side.



To delete a measurement, click on its Gear button and select Delete Annotation.



You can also delete a Measurement by right-clicking anywhere in the Measurement area and selecting Delete Measurement.



Using the Trigger

Using the Trigger

The trigger can be used to start capturing data after a specified digital event occurs.


Two types of trigger are supported: Trigger on Edge, and Trigger on Pulse Width.

Triggering on an Edge


To trigger on an edge (high to low, or low to high digital transition), click the +Trigger button on the desired channel, and select the positive or negative edge.




After setting the trigger, you can press the start button to begin searching for the trigger. If and when the trigger condition is identified, data collection will start.



If desired, you can also require other channels to be either high or low during a the previously selected edge. After selecting an edge, note that other channels will display a button with an 'X'. 'X' indicates 'don't care'.




To require a high or low, click this button and select high or low.




Triggering on a Pulse Width

You can also trigger on a pulse width condition - where a particular channel is high or low for a specified amount of time.

To add a pulse width trigger, click the +Trigger button on the desired channel, and select the positive or negative edge. Next, enter the desired time range to search for.




If desired, you can also require other channels to be either high or low during a the previously selected pulse. After selecting an edge, note that other channels will display a button with an 'X'. 'X' indicates 'don't care'. To require a high or low, click this button and select high or low.



Searching with a Trigger



After data has been collected, you can search for events within the data using the trigger. The trigger can be added or modified after data has been collected.

After the trigger has been set up (see above), and data has been collected, left and right arrows will appear next to the trigger button on the channel used for the edge or pulse width condition. Click these arrows to advance to sections of the data that satisfy the trigger condition.



Turning off the Trigger

To remove the trigger, deselect the trigger type button.




Using Protocol Analyzers

Protocol Analyzers decode data that has been encoded according to a particular protocol, such as SPI or I2C. The Logic software currently offers 23 different protocol analyzers.

Adding Protocol Analyzers


To add a Protocol Analyzer, click the Plus button on the Analyzers sidebar on the right of the software.




Analyzer Settings

Different Analyzers require different settings.


All protocol analyzers require you to specify which channels should be used for specific inputs used by the protocol.



If, after running a protocol analyzer, you notice that it doesn't work or doesn't display correctly, you may want to try editing the settings. For example, the SPI Analyzer must be set up to match the data exactly for correct decoding.



To edit the settings for an existing analyzer, find that analyzer in the Analyzers panel on the right of the software. Click the Gear button, and select Edit Settings.




After editing your analyzer settings, the analyzer will re-run against any data you have collected, and will update all results.

Changing the Global Radix (Hex, Decimal, etc)

By default, all protocol analyzers will use the global radix settings.


To change the global radix, click the Options button at the top right of the software, and then click the desired radix: Ascii, Ascii & Hex, Binary, Decimal, or Hexadecimal.



You can also use the keyboard shortcuts **CTRL-A**, **CTRL-B**, **CTRL-D**, or **CTRL-H** for Ascii, Binary, Decimal or Hexadecimal respectively.


Changing Analyzer-Specific Radix (Hex, Decimal, etc)

Sometimes you need to specify a different radix for different analyzers. To do this, locate the analyzer you would like to change in the Analyzers panel on the right of the software. Click the Gear button and select the desired radix button.



Edit the Analyzer Name


If you like you can edit the name of the analyzer to help keep track of what it is connected to. On the desired analyzer, click on the text to re-name.




Starting an Analyzer at a specific point in the software

Sometimes it is desirable to start the analyzer only at a specified location in your data. A common use for this is if you are using SPI without an enable line. A transition on the enable line is normally required to synchronize the analyzer and allow it to start decoding.

When using SPI with no enable line (and in other desired instances) it is possible that the capture will start in the middle of a byte transition, and it will not have a means to properly find the beginning of a byte. In this case, you can manually set the starting location by first setting the A1 timing marker at the desired starting location.




Then click the analyzer's Gear button and select Re-run starting at timing marker.



Viewing Protocol Analyzer Results

When a protocol analyzer successfully decodes data, colored regions will appear above the digital waveform where a byte or other bit-field is transmitted. Be sure to zoom in far enough to see the transitions making up a particular byte or bit-field.




In addition to displaying results over the digital waveform (in context), results are displayed in a list in the Decoded Protocols panel on the right of the software.



Clicking an individual item in this list will zoom to that location in the digital waveform.


Searching Analyzer Results

To search for a specific result, type the exact text you would like to match. For example, if you would like to find transactions involving the I2C address 0x42, type '0x42' -- assuming the display radix is hexadecimal.




Exporting Analyzer Results

To export the results of a particular protocol analyzer, click the Gear button on that analyzer and select Export as text/csv file.



To export more than one protocol analyzer, or a only results that match your search, click the Gear button on the Decoded Protocols panel and select Export search results.




Saving, Loading, and Exporting Data

Saving Captures


Note: Saving a capture only saves the currently selected tab

To save your current capture, click the Options menu on the top right of the software and select Save Capture. You can also press CTRL-S.



Opening Captures

To open a previously saved capture, click the Options menu on the top right of the software and select Open Capture. You can also press CTRL-O.




You can also drag a capture file into the Logic software.

On Windows, you can double-click a capture file to open it in the Logic software.

Exporting Data

If you need to view, manipulate, or process data in another application, you can export it.


To begin exporting, click the Options button at the top right of the software and select Export data.



Note: for exporting protocol analyzer data see the Protocol Analyzer section.

Export Settings

When exporting data, you can select which channels to export, and over what time period.




Lastly, you can select the format of the exported data.

Exporting in CSV Format

Csv format is a text format suitable for opening in a spreadsheet application or loading from a script. You can choose to include column headings, and choose commas or tabs as the delimiter.

When exporting digital data only, you can choose to use timestamps or sample numbers, to output the digital as a single value or as a bit per column, and choose to record only when the value changes or to record every sample.




Exporting in VCD format

VCD stands for value change dump, and is a text-based format used for saving digital data (it can't be used with analog data).



Exporting in Binary format

The binary format is provided primarily for those interested in loading data into a script or custom application. You can choose to export every sample, or only record when the value changes. You can also select the number of bytes used per sample.



The image shows a software interface for selecting export options. It features two main sections: 'Export Format' and 'Binary Settings'. The 'Export Format' section has a dropdown menu with 'Binary' selected. The 'Binary Settings' section contains two more dropdown menus. The first is 'Output data only when data changes (Each sample preceded by 64-bit sample number)' and the second is 'Output each sample in 8-bit byte'. A mouse cursor is visible over the 'Binary' dropdown.

Exporting in MATLAB format

To use data in MATLAB, you can export a .mat file which can be loaded by MATLAB.



The image shows a software interface for selecting export options. It features a single dropdown menu labeled 'Export Format' with 'Matlab' selected. A mouse cursor is visible over the 'Matlab' dropdown.

Keyboard Shortcuts

Start a Capture: CTRL-R

Stop a Capture: ESC, or Enter (presses the Stop button)

Move right/left: Right/Left arrow Keys (Add CTRL to move faster.)

Zoom in/out. Up/Down Arrow Keys (Add CTRL to move faster.)

Place timing markers: All numbers 1=A1, 2=A2, 3=B1, and so on.

Save Session: CTRL-S

Open Session: CTRL-O

Export Data: CTRL-E

Change Radix: CTRL-A (Ascii) CTRL-H (Hex) CTRL-B (Binary) CTRL-D (Decimal). Note that this changes the global radix.

Jump left/right to next edge: N (Next), P (Previous). Note that this applies to the channel where you last clicked the Next/Previous button (appears at the beginning/end of a channel).

Scroll Channels Up/Down: Page Up/Page Down. Note this applies when more channels are visible than fit vertically on the screen.

Connecting to your Circuit

Logic comes with a wire harness and a set of nine plastic micro-grippers (clips). Logic16 comes with two pairs of both.

The micro-grippers are best used for connecting Logic to large IC pins, discrete components, metal pins and test points.

If you're fortunate enough to be connecting to 0.1" male pins or a header, you can connect the wire harness without the clip directly to your pins.

If you don't have test points, and either the pins on the parts you're looking at are too small for the micro-grippers or there are no other accessible contact points large enough for the clips, you will need to take extra steps to connect Logic. We recommend soldering wire-wrap wire (#30 gauge) to an exposed trace or pin, and then connecting that wire to a micro-gripper clip.

In the best case, you can design in a 1x9 0.1" pitch male header, and then purchase a 1x9 header accessory from us to directly connect your Logic or Logic16.

Connect Logic to the PC before connecting it to your device. When Logic is not connected to a USB port, its inputs will load any device you connect them to. While this loading will not damage Logic or your device, it may cause issues with its operation. This can interfere with the operation of I2C buses and other open drain interfaces. Logic16 does not have as strong of an effect.

Protecting Against Ground Loops

The Saleae Logic & Logic16 User's Guide contains more information about the potential dangers of ground loops when using test and measurement equipment. See the section titled "Safety and Equipment Protection."

<http://downloads.saleae.com/Logic+Guide.pdf>

Ground loops are situations where there is more than one path between the grounds of two electric circuits.

It is important to keep in mind that Logic and Logic16 are NOT electrically isolated from the host PC or the device under test. This means that Logic or Logic16 share the same ground reference, and that there is a low impedance path between the grounds of the three components.

It's considered best practice to make sure that the ground wire on Logic is the only ground path between it and the device under test.

This way, when Logic's ground wire is removed, there is no more current return path between the devices.

However, it is possible for there to be another ground connection between the device under test and Logic. In most cases, this is through earth ground, or mains ground. Most desktop and laptop PCs will connect their grounds to earth ground through their power supply. Depending on how your device under test is powered, it might also share earth ground. In this case, even if you remove the ground pin between Logic and your device, there is still a ground return path between them.

The most important thing to note in this case is that Logic's ground and your device's ground are at the same potential level, even when disconnected. If you accidentally touch Logic's ground wire to a voltage rail on your device, it will create a short circuit – using Logic and your host PC as the ground return path.

Logic's ground connection to the USB port includes a re-settable fuse; however, this may not trip fast enough to prevent damage.

If you can, avoid creating a secondary ground path between your device and Logic.

If you need to operate under conditions where a ground loop is present, keep it in mind and use extra care when connecting or removing the ground pin.

See the user's manual for more information.