

# RIDE-ST7

---

*Raisonance Tools for the ST7 family*



Overview and  
Getting Started

March 2005

# RAISONANCE

---

# Table of Contents

<b><u>1. INTRODUCTION</u></b>	<b><u>4</u></b>
1.1 RIDE-ST7	5
1.2 Raisonance tools for the ST7 family	5
1.3 Third party tools that can be used in conjunction with RIDE-ST7	6
1.4 List of supported derivatives	6
<b><u>2. CREATING A PROJECT USING THE RAISONANCE TOOLS</u></b>	<b><u>7</u></b>
2.1 Using the example project	8
2.2 Creating a new project	8
<b><u>3. CREATING A PROJECT USING THE COSMIC C TOOLCHAIN</u></b>	<b><u>10</u></b>
3.1 About Cosmic Tools for ST7	11
3.2 Integration with RIDE	11
3.3 Configuring RIDE and the COSMIC C toolchain to work together	11
3.4 Creating a new project	11
<b><u>4. CREATING A PROJECT USING THE METROWERKS C TOOLCHAIN</u></b>	<b><u>15</u></b>
4.1 About Metrowerks Tools for ST7	16
4.2 Integration with RIDE	16
4.3 Configuring RIDE and the Metrowerks C toolchain to work together	16
4.4 Creating a new project	16
<b><u>5. BUILDING AN APPLICATION WITH RBUILDER</u></b>	<b><u>20</u></b>
5.1 About RBuilder for ST7	21
5.2 Configure a project using RBuilder	21
5.3 Configuring your project	22
5.4 Generating your project	23
5.5 Adding your application code	23
5.5.1 The main file	24
5.5.2 The interrupt file	26
5.6 Adding your code to the project	27

<b>6. DEBUGGING WITH THE SIMULATOR</b>	<b>28</b>
6.1 About the simulator for ST7	29
6.2 Launching the simulator	29
6.3 Using the simulator	31
6.4 Simulating a peripheral	31
6.5 Using breakpoints	32
<b>7. DEBUGGING WITH HARDWARE TOOLS</b>	<b>34</b>
7.1 Selecting hardware debugging tools	35
7.2 RLink-ST7 programming (ICP) and debugging (ICD) features	36
7.2.1 Configuring the RLink	37
7.2.1.1 RLink jumpers	39
7.2.1.2 Option Bytes	40
7.2.1.3 Instant actions	41
7.2.2 Advanced breakpoints	42
7.2.3 Hints and Troubleshooting	43
7.2.3.1 Example projects	43
7.2.3.2 Testing USB driver, connections and power supplies	43
7.2.3.3 ICCCLK and ICCDATA pins	43
7.2.3.4 Handling option bytes	43
7.2.3.5 Command-line programming tool	44
7.2.3.6 Limitations of RLink compared to the emulators	44
7.3 ST7-DVP3 and EMU3 series emulator features	46
7.3.1 Configuration	46
7.3.2 Trace Recording	46
7.4 EMU3 series emulator special features	48
<b>8. BUILDING AN ICC-COMPLIANT APPLICATION BOARD</b>	<b>49</b>
8.1 ICC Connector	50
8.1.1 ICCDATA and ICCCLK pins	50
8.1.2 RESET pin	50
8.1.3 ICCSEL/VPP pin	50
8.1.4 ICCOSC pin	51
8.1.5 VDD_APPLI pin	51

---

## 1. Introduction

---

RIDE-ST7 is an integrated development environment (IDE), designed for the development of ST7 projects from the beginning to the end. To help users get started building their applications from scratch with minimum knowledge of the ST7 architecture and peripherals, RIDE-ST7 includes RBuilder, which walks users through peripheral configuration and generates the necessary code in a startup project. RIDE-ST7 can be used with a range of development tools including the software-based simulator, the RLink, and the ST7-EMU3 and ST7-DVP3 series emulators.

This chapter gives an overview of the various tools that can be used in conjunction with RIDE-ST7.

## 1.1 RIDE-ST7

RIDE is Raisonance Integrated Development Environment. It features: an editor/debugger/project manager that is common to several ST microcontroller families, including ST5, ST6 and uPSD.

In its ST7 version, RIDE-ST7 is different from all other RIDE products in that it supports (or it can drive) a larger than usual number of development tools for ST7, from Raisonance, ST and other third party developers.

The following table shows the set of tools composing RIDE-ST7:

Integrated Development Environment	RIDE					
Application Builder	RBuilder					
Assembler	AST7	Metrowerks C toolchain	CAST7	Cosmic C toolchain	MAST7	Raisonance toolchain
Compiler	CST7		CXST7			
Linker	SmartLinker		CLINK		RLST7	
Post-Linker Optimizer			CodeCompressor			
Simulator	SIMICE ST7					
Debugger	DVP3 - EMU3 - RLINK					

## 1.2 Raisonance tools for the ST7 family

RIDE-ST7 comes with a number of ST7-specific tools from Raisonance:

- **RIDE:** this integrated development environment, which is the interface for all the other tools, provides an editor, a project manager (no need for a makefile) and a debugging user interface that can be used either with the simulator or with most available hardware-debugging tools.
- **Assembler and Linker:** they allow you to write applications in assembler. They are similar to their existing ST5 and ST6 counterparts. They are not compatible with the other ST7 toolchains. (e.g. ST, Cosmic or Metrowerks)
- **Simulator:** simulates core (including the entire memory space) and most peripherals. Complex peripherals (USB, CAN) and some less common peripherals are not simulated.
- **CodeCompressor:** this is a post linker optimization tool that can be used to reduce code size. It accepts as input any executable code, whether from assembler, C or any other source (libraries...). It does not support code generated by the Metrowerks C toolchain.

- RBuilder: a graphical user interface that guides the user through the configuration of the ST7 peripherals to be used by the application, and generates the corresponding source code for the peripherals.
- RLink-ST7: this USB hardware dongle allows the user to program the ST7 on an application board and debug the application while it runs on the ST7. It uses the ICC protocol. See more information in the ICC section of this document. For more information on using the RLink, refer to this chapter: "Debugging with Hardware Tools".

Each tool mentioned above has its dedicated user manual (please refer to it for more details) apart from RIDE, the simulator and RLink-ST7.

### 1.3 Third party tools that can be used in conjunction with RIDE-ST7

RIDE-ST7 can be used together with a number of third party tools including:

- The Cosmic C toolchain (compiler, linker, assembler) has been fully integrated so that it can be used without ever leaving RIDE. This makes it possible to use RBuilder to start creating your ST7 application. To start using RIDE with the Cosmic C toolchain, refer to the chapter, "Creating a project using the Cosmic C toolchain".
- The Metrowerks C toolchain versions 1 and 2 (compiler, linker, assembler) have been fully integrated so that they can be used without ever leaving RIDE. This makes it possible to use RBuilder to start creating your ST7 application. To start using RIDE with the Metrowerks C toolchain, refer to the chapter, "Creating a project using the Metrowerks C toolchain".
- ST Emulators: the RIDE debugger can drive ST emulators (EMU3 and DVP3 series emulators), including all the emulator specific features such as trace and advanced breakpoints. For more information on using the ST emulators, refer to the chapter, "Debugging with Hardware Tools".

RBuilder is a 100% Raisonance product, however it uses the ST7 Library for most of the code it generates. This implies that:

- As the ST library evolves, so will the code generated by RBuilder (starting from the same set of options).
- As the library is written in C, using RBuilder will require the use of a C Compiler.

### 1.4 List of supported derivatives

RIDE-ST7 supports most of the existing ST7 derivatives to various degrees. The up-to-date list of supported derivatives and the limitations to the software simulation can be seen in the Target Options in RIDE.

---

## **2. Creating a project using the Raisonance tools**

---

Assembly applications can be written using the Raisonance free assembler. CodeCompressor can be used with this toolchain. This chapter gives an overview of how to create an ST7 assembler project with RIDE-ST7.

Note: Using RBuilder requires the use of a C compiler and therefore is not possible with the Raisonance toolchain. For information about creating projects when using a C toolchain, refer to these Chapters: **"Creating a project using the Cosmic C toolchain"** or **"Creating a project using the Metrowerks C toolchain"**.

## 2.1 Using the example project


RIDE-ST7 is provided with an example project written in assembler that is ready to run. To open this project, use "Project" -> "Open" in RIDE and select the project ASM\_DEMO.PRJ. For standard installation of RIDE, this file is found in C:\RIDE\EXAMPLES\ST7\ASM.

This example is described either in the comments in the source file and in the MAST7 manual.


## 2.2 Creating a new project

To create a new project in Raisonance assembler for ST7 (MAST7):

- In RIDE, choose "Project" -> "New...".




- Choose the Application name, enter the path of the application and select the ST7 target family (this only applies if you have other versions of RIDE installed) and click on "Next".






- Select the derivative you want to work with.



- To use Raisonance tools for the project, click on "Properties", and select "Raisonance Tools" and click on "Next".



- Click on "Finish", do not choose "RBuilder" (RBuilder would generate C code and you need a third party compiler to be able to use it).
- Add files to the project, build and debug it as explained in the RIDE manual. (common to all targets) To open this manual, click on "Help"->"PDF"->"Ride General"->"Ride".

---

### **3. Creating a project using the Cosmic C toolchain**

---

RIDE-ST7 integrates the Cosmic C toolchain (C Compiler, Assembler and Linker) in such a way that it is possible to use it without ever leaving RIDE. This environment allows the use of RBuilder and CodeCompressor. This chapter explains how to install and use the Cosmic C toolchain together with RIDE.

### 3.1 About Cosmic Tools for ST7

The Cosmic C toolchain for ST7 is composed of a C Compiler, an Assembler and a Linker. The ST7-specific extensions to the ANSI C language are somewhat different from those used by Raisonance compilers, so beware if you are a user of RIDE for ST5 or ST6. Note also that Cosmic assembler and linker are not compatible with those from Raisonance. The Cosmic C toolchain is compatible with both RBuilder and CodeCompressor.

**Important note:** CodeCompressor requires a special version of the Cosmic linker. RIDE will ask you if you want to install it.

### 3.2 Integration with RIDE

RIDE provides a convenient way to drive Cosmic tools via its graphical user interface. When used in conjunction with the Cosmic C toolchain RIDE allows you to:

- Set the main compiler and other tool options graphically, via user-friendly dialog boxes.
- Automatically produce the link file (.lkf file) adapted to the chosen derivative.
- Automatically manage file dependencies so that no makefile is necessary.
- Display errors in a dialog box where a double click on the error automatically opens the editor with the corresponding source file at the line that is the source of the error.

Please refer to Cosmic's manuals and documentation (not included in RIDE) for details about the Cosmic tools.

### 3.3 Configuring RIDE and the COSMIC C toolchain to work together

In order to use RIDE together with the Cosmic C toolchain, you need to install the two software packages on your computer.

The Cosmic tools are not included in the distribution of RIDE-ST7. The evaluation version is available for download at [www.cosmic-software.com](http://www.cosmic-software.com)


Note that both RIDE and the Cosmic tools require registration to unlock some functionalities: you need to register RIDE if you want to use CodeCompressor and you need to register the Cosmic tools if you want them to be able to generate more than 1kb of code.

Once you have the two packages properly installed and registered, you need to tell RIDE where the Cosmic tools are located: by default, RIDE looks for the Cosmic tools under c:\cosmic\cxst7, which is the default directory proposed by the Cosmic installation program. If you change this directory during the Cosmic tools installation, this must be indicated to RIDE. To do this, select "Options" -> "Target" -> "Properties" -> "Cosmic Tools Path".

In order to check your tools, open one of the examples for Cosmic (by default in "C:\RIDE\examples\ST7\C\COSMIC"). Eventually, modify the Cosmic tools path as explained just above. Then, build the example, just to check that the tools are correctly installed and configured to work together.

### 3.4 Creating a new project


To create a new RIDE project, select "Project" -> "New...". The screen shown below will be displayed:



Enter your application name, the directory where you want your application to be generated, and make sure the target family is ST7. When you are done, click on "Next".

Note that you can click on "Cancel" to cancel the creation of your project at any time when using the wizard. The Help button may also be used to get some help on the creation of a new project.

Once you have clicked on the "Next" button, you will see the following window:




In the Device tab, select the ST7 derivative that you want to use.

In the Properties tab, select the Cosmic C toolchain. You must now specify top-level choices that impact the whole toolchain including:

- The Memory model to use.
- Whether you will use floating point libraries.

For more information about these options, refer to the Cosmic manuals.


Click on "Next" when you are done and the following screen will appear:



Here, you can choose to use RBuilder to help you configure your ST7 application, or you can click on "Finish" and create your application manually.

If you choose to use the RBuilder, refer to Chapter 5 for more information about configuring the project and your ST7s peripherals.

In both cases at least two files are generated (more if you use RBuilder, see the illustration below).



The last two files (vector.c and master.lkf) are always generated. The others depend on the options set in RBuilder.

- vector.c contains the reset vector definition (and possibly other interrupt vectors definitions if it has been generated by RBuilder)
- <projectname>.lkf is the linker file and is generated by RIDE according to the derivative chosen and the structure of the project.

The gray icons for vector.c and the link file indicate that these files are not handled by the linker as the other files are. vector.c is linked in a special place. The .lkf file is the linker script. See Cosmic documentation for more information about it. They are present in the project for fast and easy display of their contents. **These files should only be edited to meet very precise requirements.** This requires an advanced understanding of the Cosmic toolchain.

**Warning:** the vector definition file and the link file are created automatically after you have chosen your derivative. Changing derivative on an existing project might lead to the regeneration of these files, with possible loss of any information you might have added manually

---

## **4. Creating a project using the Metrowerks C toolchain**

---

RIDE-ST7 integrates the Metrowerks C toolchain (C Compiler, Assembler and Linker) in such a way that it is possible to use it without ever leaving RIDE. This environment allows the use of RBuilder but not of CodeCompressor. This chapter explains how to install and use the Metrowerks C toolchain together with RIDE.

## 4.1 About Metrowerks Tools for ST7

The Metrowerks C toolchain for ST7 is composed of a C Compiler, an Assembler and a Linker. The ST7-specific extensions to the ANSI C language are somewhat different from those used by Raisonance compilers, so beware if you are a user of RIDE for ST5 or ST6. Note also that Metrowerks assembler and linker are not compatible with those from Raisonance. The Cosmic C toolchain is compatible with RBuilder but not with CodeCompressor.

## 4.2 Integration with RIDE

RIDE provides a convenient way to drive Metrowerks tools via its graphical user interface. When used in conjunction with the Metrowerks C toolchain RIDE allows you to:

- Set the main compiler and other tool options graphically, via user-friendly dialog boxes.
- Automatically produce the linker configuration file (.prm file) adapted to the derivative chosen.
- Automatically manage file dependencies so that no makefile is necessary.
- Display errors in a dialog box where a double click on the error automatically opens the editor with the corresponding source file at the line that is the source of the error.

Please refer to Metrowerks' manuals and documentation (not included in RIDE) for details about the Metrowerks tools.

## 4.3 Configuring RIDE and the Metrowerks C toolchain to work together

In order to use RIDE together with the Metrowerks C toolchain, you need to install the two software packages on your computer. Note that RIDE is compliant with either version 1 or version 2 of the Metrowerks compiler.

The Metrowerks tools are not included in the distribution of RIDE-ST7. The evaluation version is available for download at [www.metrowerks.com](http://www.metrowerks.com)


Once you have the two packages properly installed (and eventually registered), you need to tell RIDE where the Metrowerks tools are located: by default, RIDE looks for the Metrowerks tools under the default directory proposed by the installation program (which is not the same if you are using version 1 or version 2). If you change this directory during the Metrowerks tools installation, this must be indicated to RIDE. To do this, select "Options" -> "Target" -> "Properties" -> "Metrowerks Tools Path".

In order to check your tools, open one of the examples for Metrowerks (by default in "C:\RIDE\examples\ST7\C\METROWERKS\"). Eventually, modify the Metrowerks tools path as explained just above. Then, build the example, just to check that the tools are correctly installed and configured to work together.

## 4.4 Creating a new project

To create a new RIDE project, select "Project" -> "New...". The screen shown below will be displayed:







Enter your application name, the directory where you want your application to be generated, and make sure the target family is ST7. When you are done click on "Next".

Note that you can click on "Cancel" to cancel the creation of your project at any time when using the wizard. The Help button may also be used to get some help on the creation of a new project.

Once you have clicked on the "Next" button, you will see the following window:



Here is a screenshot of the equivalent window for Metrowerks version 2:




In the Device tab, select the ST7 derivative that you want to use.

In the Properties tab, select the Metrowerks C toolchain. You must now specify top-level choices that impact the whole toolchain including:

- The Memory model to use.
- Whether you will use floating point libraries.
- For the Version 2, you must specify which overlap you want.

For more information about these options, refer to the Metrowerks manuals.


Click on “Next” when you are done and the following screen will appear:



Here, you can choose to use RBuilder to help you configure your ST7 application, or you can click on Finish and create your application manually.

If you choose to use the RBuilder, refer to Chapter 5 for more information about configuring the project and your ST7s peripherals.

In both cases, at least one file is generated (more if you use RBuilder, see the illustration below).



The file always generated is the last one, <projectname>.prm, and is colored in grey. (all the others are part of the sample example).

<projectname>.prm is the link file and is generated by RIDE according to the derivative chosen and the structure of the project.

The gray icon for sample.prm indicates that this file is not handled by the linker as the other files are. It is the link file. See Metrowerks documentation for more information about it. It is present in the project for fast and easy display of its contents. **This file should only be edited to meet very precise requirements.** This requires an advanced understanding of the Metrowerks toolchain.

**Warning:** the link file is created automatically after you have chosen your derivative. Changing derivative on an existing project might lead to the regeneration of this file, with possible loss of any information you might have added manually

---

## **5. Building an application with RBuilder**

---

To help you start developing your application from scratch, RIDE-ST7 includes RBuilder – an application builder that allows you to select and configure the peripherals of the target ST7 that are used by your application. RBuilder then generates all the peripheral related application code with a prototype main function that can be compiled and run without you writing a single line of code.

This chapter tells you how to use RBuilder to configure peripherals and generate related the project code.

## 5.1 About RBuilder for ST7


RBuilder is an application builder based on the ST7 Software Library. It guides you through the configuration of your project, allowing you to choose the peripherals you want to use and configure the options for each peripheral.

Once you are done with configuration, RBuilder generates you a project skeleton containing all the code related to the peripheral initialization. You just need to add your application code and it is ready to execute.

In the two following sections, we will show you how to use RBuilder.

## 5.2 Configure a project using RBuilder

To configure a project using RBuilder, you must have installed a C compiler and started creating a C project. How to do this is described in these Chapters: "Creating a project using the Cosmic C toolchain" and "Creating a project using the Metrowerks C toolchain". In the last step of the procedure, select RBuilder and the window shown below will appear:




You are now in RBuilder. The screen is divided in 5 different parts:

1. The tree in area 1 shows you the different peripherals associated with the microcontroller you are using. It is called the project tree. To use and configure a peripheral, select it in the tree. The options associated with the selected peripheral will be displayed in area 4.


2. Area 2 shows you which file will be added to your project. This list changes while you are adding/removing peripherals to your project.
3. This area displays the datasheet of your microcontroller and the ST7 Software Library manual.
4. This area displays the options related to the selected peripheral. This view is called the Option View.
5. This part is the online help which guides you through the configuration of your project.

### 5.3 Configuring your project


Once you are in RBuilder, you can configure the peripherals for your project. For example, to add I/Os support to your project, click on I/Os in the project tree as shown in the following picture:



Then, click on “Configure and Use IO” in the option view:



The available options for the peripheral will appear and for I/Os, the list of ports available is added in the project tree. If no port is selected, only one option is available for I/Os. However when a specific port is selected in the project tree, more options are displayed:



As you can see, each PIN of the PORT can be easily configured using a combo box which lets you specify if the PIN is either a floating INPUT, a pull-up interrupt INPUT, an open-drain OUTPUT or a push-pull OUTPUT.


Configuring the peripherals is the big part of the process, but you should take care to also configure the other parts of the project:

- Core (be sure to specify the correct clock speed)
- Memory
- Peripherals
- Interrupts
- Preferences

Some peripherals, like the I/O ports, offer the option to generate sample code. If you check the option, this sample code will be placed in the main function. This code provides a simple example of how to use the basic library functions related to the associated peripheral(s).

## 5.4 Generating your project

Once you are done configuring your project, select Project Generation in the "Actions" menu:




After doing this, RBuilder generates the sample/prototype application code based on the project configuration, and notifies you when generation is complete. Then RBuilder closes, returning you to the RIDE-ST7 main window. You can compile the project right away.

**Warning:** Once the project is generated, there is no way to go back to modify one option and generate it again. If you find out that you were mistaken about one option, then you have to restart the project creation process from the beginning.

## 5.5 Adding your application code

Once you are back in RIDE, source files will be added to your project. Most of the files in your project are generated from the ST7 Software Library according to the configuration options that you specified in RBuilder. These files should not need to be edited. Two additional files are generated:



- myprojectmain.c is the main file of the project. In this file, RBuilder generates the initialization function for all peripherals, the "main()" function and any user requested functions (for example putchar and getchar for the SCI).
- myprojectint.c contains all the interrupt functions. This file is generated only if the user selected the use of interrupts in RBuilder. Otherwise it is not part of the project.

### 5.5.1 The main file

The following is an example of a main file for which the following peripherals have been selected:

- I/Os
- Timer
- SCI
- ADC

The whole file is generated by RBuilder.

In this file, you can see:

- The "PeriphInit" function (blue arrow) performs initialization for all peripherals according to the options you selected in RBuilder.
- The "main" function (green arrow) is made of a call to "PeriphInit" to initialize all peripherals, followed by an infinite loop that contains the application code. RBuilder gives you the possibility to generate sample code for almost each peripheral. This example contains code for the ADC, the SPI and I/Os. You just need to add your specific code at the end of the function. (look for the red arrow)
- The "TERMIO\_PutChar" function (brown arrow) is generated when you select "Generate a putchar function" in RBuilder's SCI options section. Since we use Metrowerks tools in our example, the function is named "TERMIO\_PutChar". Using Cosmic tools we would have "putchar".



```

/* ===== */
/* Project:      MyProject */
/* File:         MyProjectMain.c */
/* Organization:  */
/* Author:       (initial version generated by RBuilder) */
/* Date:         11/23/2004 */
/* ===== */

#include "ST7lib_config.h"
#include <stdio.h>

/*-----*/
/*Function:      PeriphInit*/
/*Purpose:       Periph configuration at RESET*/
/*Date:          11/23/2004 */
/*-----*/
void PeriphInit ( void ) {

    EnableInterrupts;

    /* A/D Converter initialization */
    ADC_Init(ADC_DEFAULT);
    ADC_Select_Channel(0);

    /* SCI initialization */
    SCI_Init(SCI_DEFAULT_PARAM1, SCI_DEFAULT_PARAM2);
    SCI_Select_Baudrate(0xd2);
    SCI_Mode(SCI_TX_ENABLE|SCI_RX_ENABLE);

    /* 16-bit timers initialization */
    TIMERA_Init(TIMER_FCPU_4); /* Timer A */
    TIMERA_IT_Enable(TIMER_OVF_IT_ENABLE);

    /* Interrupt controller initialization */
    ITC_Init();

    /* I/O Port initialization */
    IO_Init();

}/*end of PeriphInit*/

/*-----*/
/*Function:      main()*/
/*Purpose:       main routine*/
/*Date:          11/23/2004 */
/*-----*/
void main ( void ) {

    /*Configure the internal peripherals*/
    PeriphInit();

    while ( 1 ){

        {
            /* Sample code for ADC */

```

```

        int Conv_Data1;

        /* Select channel 5 CS2:CS1:CS0=101 */
        ADC_Select_Channel(5);
        /* Start conversion ADON bit is set */
        ADC_Enable();
        /* Wait till conversion completes */
        while(!ADC_Test_Conversn_Complete());
        /* Read converted value */
        Conv_Data1 = ADC_Conversn_Read();
        ADC_Disable();
    }

    /* Sample code for SCI */
    puts("Hello world");

    {
        /* Sample code for IO */
        int read_Data;

        /* Read Port A */
        read_Data = IO_Read(IO_PORT_A);
        /* Set Port A Pin 6 and 7 to high state */
        IO_Write(IO_PORT_A, IO_PIN_6|IO_PIN_7 , IO_DATA_HIGH);
    }

    /*Insert your code here...*/
}
}/*end of main*/

/*-----*/
/*Function:      TERMIO_PutChar*/
/*Purpose:      Puchar in polling mode on SCI*/
/*Date:         11/23/2004 */
/*-----*/
void TERMIO_PutChar(char c){
    if (c == '\n'){
        SCI_PutByte ('\r');
        while (!SCI_IsTransmitCompleted());
    }
    SCI_PutByte (c);
    while (!SCI_IsTransmitCompleted());
}

```

### 5.5.2 The interrupt file

The following is the interrupt file generated in our example. We selected the use of TIMER A overflow interrupt.

```

/* ===== */
/* Project:      MyProject */
/* File:         MyProjectInt.c */
/* Organization:  */
/* Author:       (initial version generated by RBuilder) */
/* Date:         11/23/2004 */

```

```
/* ===== */
#include "ST7lib_config.h"
/* ----- */
/* Function:      TIMERA_IT_Routine(void) */
/* Purpose:      Interrupt Subroutine for TIMERA Interrupt */
/* Date:         11/23/2004 */
/* ----- */
#ifdef _HIWARE_          /* Test for HIWARE Compiler */
#pragma TRAP_PROC SAVE_REGS /* Additional reg will be saved */
#else
#ifdef _COSMIC_          /* Test for Cosmic Compiler */
@interrupt              /* Cosmic interrupt handling */
#else
#error "Unsupported Compiler!" /* Compiler Defines not found! */
#endif
#endif

void TIMERA_IT_Routine(void) {
    /* Insert your code here... */
} /* end of TIMERA_IT_Routine(void) */
```

The interrupt framework is generated; you only need to fill it in. Keep in mind that an interrupt needs a flag to be reset when it has been handled.

## 5.6 Adding your code to the project

Now that you have a project with configured peripherals, you need to add your application code.

To add your source files, select "Project" -> "Add node source/application". This will open a file selection window that you can use to add your source files in C or assembler.

To rebuild the application, just press "F9" or select "Project" -> "Make All".

Now you are ready to debug your application. If you will be using the simulator, refer to the chapter, "Debugging with the Simulator". For information about debugging with RLink or an EMU3 or DVP3 series emulator, go on to the chapter, "Debugging with Hardware Tools".

---

## **6. Debugging with the Simulator**

---

RIDE-ST7 provides a simulator capable of simulating the most common ST7 peripherals. The simulator lets you check your code as well as the interaction between your code and the peripheral before going on to debug with an in-circuit debugger or emulator.

## 6.1 About the simulator for ST7

RIDE-ST7 supports most of the existing ST7 derivatives to various degrees. The up-to-date list of supported derivatives and the limitations to the software simulation can be seen in the Target Options in RIDE.

For the rest of the getting started, we will use a project that uses the following peripheral:

- I/Os
  - PORT A Pin 1 → Output (push/pull)
  - PORT A Pin 2 → Output (push/pull)
  - PORT A Pin 3 → Output (push/pull)
  - PORT A Pin 4 → Output (push/pull)


The following code has been written in the main function:

```
int toggle = 0; /*This declaration goes at the beginning of the main*/  
IO_Write(IO_PORT_A, IO_PIN_0, (toggle == 0)?IO_DATA_HIGH:IO_DATA_LOW);  
IO_Write(IO_PORT_A, IO_PIN_0, (toggle == 1)?IO_DATA_HIGH:IO_DATA_LOW);  
IO_Write(IO_PORT_A, IO_PIN_0, (toggle == 2)?IO_DATA_HIGH:IO_DATA_LOW);  
IO_Write(IO_PORT_A, IO_PIN_0, (toggle == 3)?IO_DATA_HIGH:IO_DATA_LOW);  
  
if(++toggle==4)  
    toggle = 0;
```

So you can easily build this project to use the simulator as described in the chapter, "Building an application with RBuilder".


## 6.2 Launching the simulator

To launch the simulator, type CTRL-F9. If your project has not been built, it will be done automatically before launching the simulator. Otherwise the simulator is launched directly. The following window appears to set the debug options:



Make sure that "Virtual Machine" is selected and click OK.

You are now in the simulator. Your RIDE window looks like the following:



The illustration above shows:


1. The source file as edited in C language or in assembly language. The green circles at the left indicate lines that contain instructions where you can place breakpoints. The line highlighted in blue indicates the current PC. That's the next instruction to be executed.
2. The Debugger tab that shows you all the peripherals that are simulated on a given microcontroller. To see a specific peripheral, double-click on its name. Note the blue line as in the source window.
3. The Watch tab which allows to see the watched variables and the local variables.
4. The toolbar which allows the user to control the simulation. (see more information in the next section)
5. The Code window that shows you the instruction to be executed by the simulator. It is a dump of the memory where the code is located. (see more information below)
6. The debug tab is a tree where the simulator displays message for the user.

The following columns are available in the Code window:

- Address: The address where the instruction is located.
- Symbol: The name of the symbol, if a symbol is located at this address.
- Code: The byte-code located at this address.
- Mnemonic: The mnemonic corresponding to the byte-code.
- Code Coverage: The number of times the byte-code at this address has been executed

### 6.3 Using the simulator


The simulation is controlled by the simulator toolbar:




1. Animated mode → The simulator will execute the application slowly with a short pause at each source line.
2. Display executed lines → When you have executed your application, pressing this button will change the color of the green circle to blue for each line that has been executed.
3. Refresh → While debugging, pressing this button will refresh the different debug views.
4. Reset → Pressing this button resets the application.
5. Step into → On a function call in a line of the C source code, this button steps into the called function. If it is not a function call, it goes to the next line in the source code.
6. Step over → On a function call in a line of the C source code, this button steps over the called function.
7. Add watch → Add a variable to the list of watched variables.
8. Toggle breakpoint → If there is no breakpoint on the current line, RIDE will set a breakpoint on it. If there is one, the breakpoint will be removed.
9. Toggle trace → If there is no trace breakpoint on the current line, RIDE will set one. If there is one, the trace breakpoint will be removed.
10. Select application → In multi-application simulation, this combo box lets you select which application you control.
11. Run → Pressing this button launches the application. When the application is running, the GO button becomes a STOP button. Pressing it will stop the application.
12. Speed → Select the speed at which the simulation must be done.

### 6.4 Simulating a peripheral

To simulate a peripheral, you must open it by clicking on the corresponding item in the peripheral tree. For example, to simulate the Port A, double click on the following icon:



The PORT A view will appear:



This view lets you see the state of each pin of the port. Green indicates a value of one and red a value of zero. It is possible to connect each pin of the port to a Net, to VCC, the Ground or no connection. This is done by clicking on the led. The registers also let you control the peripheral.

Once you have created the application described above, start the simulator, open the PORT A and click on the refresh button as the application is running, you will see the LED blinking.


## 6.5 Using breakpoints

You can set a breakpoint either in the source file or in the code view. In the code view, first select the line on which you want to stop. The line will become gray:






Then click on the Toggle Breakpoint button and the line will become red, which means that a breakpoint has been set on this line:



The application will stop running when this line is reached.

You can use the same procedure to set a breakpoint on a line of source code, or you can click on the green circle in the margin next to the instruction. When you click on the green circle the line will turn red, indicating that a breakpoint has been set:



---


## **7. Debugging with Hardware Tools**

---

In addition to the Raisonance simulator, RIDE-ST7 can be used with a number of hardware debugging tools. These tools include the RLink for in-circuit debugging and the ST7-EMU3 and ST7-DVP3 series emulators. From a user interface point of view, basic debugging functions (setting a breakpoint, single-stepping and checking memory and registers) are identical whether you are using the simulator or a hardware debugging tool. This chapter tells how to use the available drivers and the specificity of each.

## 7.1 Selecting hardware debugging tools

Within RIDE, you can choose your target hardware debugger in the "Options" -> "Debug" menu.



When you check the “Real Machine” radio button, a list of available emulators and other hardware-based debug tools appears in the drop down “Tools” list.

RIDE-ST7 supports RLink for in-circuit debugging and in-circuit programming and the EMU3 and DVP3 Series emulators.

Select the tool corresponding to your debugging hardware:

RLINK_ST7	If you have an RLink connected to the target ST7 on your application board via an ICC connector, or if you are using the REva evaluation board, which includes an embedded RLink.
DVP3_ST7	If you have an ST7-DVP3 series emulator
EMU3_ST7	If you have an ST7-EMU3 series emulator

Then, configure the tool using the "Advanced Options".

If you are using the RLink dongle (or the REva board), continue with the section, "RLink-ST7 programming (ICP) and debugging (ICD) features".

If you are using an EMU3 or DVP3 series emulator, go on to the section, "ST7-DVP3 and EMU3 series emulator features".

## 7.2 RLink-ST7 programming (ICP) and debugging (ICD) features

RLink is a USB interface device designed by RAISONANCE. It allows In-Circuit-Programming (ICP) and In-Circuit-Debugging (ICD) of various microcontrollers, including all the ST7 devices supported by RIDE-ST7. Some devices with HDFLASH and no debug module do not support ICD, but you can still use the RLink for programming them (ICP).

With the ST7 devices, RLink uses the In-Circuit-Communication (ICC) protocol from ST to perform ICP and ICD. RLink uses the standard 10-points ICC connector defined by ST.

In order to use RLink, be sure that you have installed the associated USB driver. Unless you have specified otherwise, it is installed along with RIDE. If the USB driver has not been installed, launch the program RLinkUSBInstall.exe. For standard installations of RIDE-ST7, it is located at:

`C:\RIDE\DRIVER\RLINKDRV\RLinkUSBInstall.exe`

You can also find it on the installation CD-ROM:

`\DRIVER\RLINKDRV\RLinkUSBInstall.exe`

After running this program, when you plug RLink in, Windows will recognize it automatically.


RLink supports all the devices that are supported by RIDE. See the up-to-date list in the Target Options.

Note that the devices with HDFlash and no debug module can be programmed, but not used for debugging through ICC.


The REva board is a demonstration board that includes a detachable RLink. The whole board can be powered by the USB through the RLink. The target chip is placed on a interchangeable daughter board that can include different targets. For RIDE, there is no difference between operating the REva or using an RLink with another hardware with the ICC connector. For more information about the demo board itself (schemes, etc.), see its dedicated documentation.

### 7.2.1 Configuring the RLink

After selecting RLink as your debugging tool (see the section, "Selecting hardware debugging tools"), click on the "Advanced Options" button to open the Advanced Options dialog box shown below.




In the **Advanced Options**, it is critical to check that the selected target corresponds to your chip:



If not, then you must go in the target options to change it. Go back to the RIDE main screen and select "Target" -> "Options".


Next, indicate the preferred reset method to use when establishing in-circuit communication with the target ST7:



See the ICC section of your ST7xxxx Datasheet for more information about this. If you do not know, just leave the default: If the first method fails, then RIDE will try the other and the only drawback for you is that the reset will take a little more time than needed (less than half a second more).

Be careful that the external clock is provided (from RLink or another external source) if both your device's default option bytes and current option bytes select the external clock.


To debug your application, confirm that Debug is checked as shown below.



Uncheck the **Debug** option if you want to use RLink as a simple programmer, e.g. if you want to try the application on the ST7 without debugging it. Note that if the **Debug** option is checked, the application will be patched (to add code such as reset and trap vectors for debugging) and is only executed if it is driven by RIDE through RLink. If the Debug option is unchecked, then launching the debug session will simply program the unpatched code to your ST7 and start execution. This is useful when using RLink and you don't have the source code.

### 7.2.1.1 RLink jumpers

Make sure that your jumpers are set correctly on the RLink. To do this, click on "View RLink jumpers configuration for ST7". The following illustrations showing the ST7 configuration for the RLink jumpers is displayed:




Note: Should the pictures in this documentation and in RIDE be different, assume that those shown in RIDE are correct.

If you purchased RLink as part of an ST7 kit (such as the REva board for ST7), then the jumpers should already be correctly set. For this reason, you should only need to adjust these jumpers if they were accidentally unplugged, or if you are using an RLink that was configured for another protocol, such as JTAG.

### 7.2.1.2 Option Bytes

Next, you need to configure how the ST7's option bytes will be handled.




- "Leave as is": the option bytes are not programmed. They retain their current values.
- "Restore default" tells RIDE to erase the option bytes and restore the default value before loading the FLASH and debugging. If you want to know what value will be loaded when selecting this option, then click the "Default" button, and you will see the default values in the "Value to program" section.
- "Program" tells RIDE to erase the options bytes prior to programming the Flash memory, and to program the option bytes with the value that you have specified in the "Value to program" section. The option bytes are programmed after the Flash memory has been programmed.

#### Value to program:

This is the value that will be written in the option bytes if the "Program" option is selected.

You can change the value by typing the value that you want in the Option Byte 0 and the Option Byte 1 fields (refer to your ST7xxxx Datasheet for the meanings of these values), or by selecting "Change value" and configuring the options controlled by each option byte in the "Options" dialog box (shown below).

**Warning:** Some option byte values such as those controlling read-out, debug and re-write protection will prevent any further re-programming of your ST7. Be careful when setting the option byte values and refer to your ST7xxxx Datasheet for complete descriptions of the options byte values for your ST7.



The "Options" dialog box shows the meaning of each bit of the option bytes. This can help prevent errors resulting from typing the wrong value to program to the option bytes. Click on the field on the right to select option byte settings from a drop-down list of possible settings.




Finally, clicking "Default" will restore the default value in the edit fields if you think that you might have typed in an incorrect value.

Note: "Restore default" is the same as "Program" with the default value, but it's faster!

### 7.2.1.3 Instant actions

This section of the "RLink\_ST7 options" dialog box allows to carry out the instant actions listed below without leaving this dialog box. This is useful for testing connections and retrieving information from the RLink and your ST7, as well as for programming the ST7 and its option bytes.




- "Connect to RLink and read serial number" is useful for checking that RLink is working and properly connected and that the USB driver is correctly installed. It also allows you to read the RLink serial number, which you will be asked for if you contact our support team.
- "Read target option bytes" allows you to read the option bytes currently written in the chip. Use this also to test the connections and power of the target ST7.
- "Write target option bytes now!" allows to program the option bytes without leaving the configuration window. When programming them, RIDE takes into account the settings in the "Option bytes options" section of the dialog box (see the previous section). It will do nothing if the "Leave as is" option is selected. It will erase and write the default value if the "Restore default" option is selected. And it will program the value displayed in the edit fields if "Program" is selected.
- "Erase target now!" allows you to completely erase the target's FLASH (writing 0xFF), option bytes (restoring the default value) and EEPROM (if any). This is the correct way to remove the read-out protection from a protected device.
- "Dump target FLASH to hex file" reads the contents of the FLASH and writes it in a file in hex format whose name is derived from the current application's name with the extension .hex (<application name>.hex).
- "Write target FLASH now!" programs the FLASH with the current application's hex file generated by the linker. Then, launches the execution in user mode. When using this instant action, the code is not patched for debug, even if the "Debug" option is checked.

## 7.2.2 Advanced breakpoints


The interface for operating the debugger is exactly the same as for the simulator. However, there is one feature that is specific to the ST7 devices with a Debug Module: the advanced breakpoints.

Once the debug session has started, if your ST7 device features a Debug Module, you can click on "Debug" -> "RLINK\_ST7" -> "Advanced Breakpoints ...":



If this option does not appear, then your device probably does not have a debug module. You can check this on the ST7xxx Datasheet.

This will open the Advanced breakpoints window:



This window allows you to select the break mode and addresses.

Note that if you use the Debug Module to set advanced breakpoints, the debugger will not be able to use them and, in some cases, will not be able to set standard breakpoints. For instance, if the target ST7 has HDFSflash or if the breakpoint is in sector 0 of an XFlash device, then RIDE will not be able to set the breakpoint. To allow RIDE to use the Debug Module for standard breakpoints again, you must go back to the Advanced breakpoints window and disable them.

The advanced breakpoints configuration is discarded at reset.

## 7.2.3 Hints and Troubleshooting

### 7.2.3.1 Example projects

The examples in the REVA folder of the RIDE directory are configured for use with the REva evaluation board, which includes the RLink. For standard installations they are found at C:\RIDE\EXAMPLES\ST7\REVA. These examples can also be used with other demonstration and evaluation boards with a standard ICC connector and the RLink. These are very simple examples that, for the most part, can be compiled with the demo version of the associated toolchain (COSMIC, METROWERKS or RAISONANCE) available for download on their maker's website. Some examples are too big to be compiled with the demo versions. These particular examples include a precompiled version of the application that you can download, run and debug, but you will not be able to modify it and recompile it. Before using an example, look at it and make sure that the jumpers on the REVA board are set correctly. (enables for the LEDs, buttons, SCI, EEPROM, etc.) Usually, there is some important information in comments at the beginning of the main file. (i.e. the file that contains the "main" function)

### 7.2.3.2 Testing USB driver, connections and power supplies

To test the USB driver installation and the operation of RLink, use the "Connect to RLink" instant action. The RLink appears in Windows' device manager under the "Jungo" section when it is correctly recognized.

To test the connections and power of the target board and ST7, use the "Read option bytes" instant check. This operation requires RLink to connect to the target ST7, ensuring that it is powered, correctly connected to RLink, and that the rest of the application board does not interfere with the communication between RLink and the ST7. (see below)

### 7.2.3.3 ICCCLK and ICCDATA pins

These two pins are used to communicate between RLink and the target ST7. This means that you must ensure that the rest of the system (i.e. the other components on the board and the application in the target chip) does not use them. This also means that your application cannot use these pins if you plan to debug it with RLink.

These pins' addresses depend on the target ST7. Please refer to the ST7xxx device Datasheet for more information.

For more information about this, refer to the section, "Building an ICC-compliant application board".

### 7.2.3.4 Handling option bytes

Here are the suggested ways to handle the option bytes depending on your project's state:

- While you are still debugging the application, you will probably re-program the target ST7 quite often, but the option bytes values will not change much. Since you are always using the same device, there is no need to re-program the option bytes every time. In this case, program them once using the "Write target option bytes now!" instant action, and then select the "Leave as is" option for the debugging sessions.
- When you are in the pre-production phase (debugging is complete and you are programming multiple ST7s), select "Program", so as to program the option bytes for each ST7 device. (and uncheck the "Debug" option in the actions for debug session)


Also, remember that if you protect the FLASH memory against read-out (or write) with the option bytes, then you will not be able to debug. So even if you already know that your final application will be protected against read-out, you should not do so during the development phases of the project when you still need to debug.

### 7.2.3.5 Command-line programming tool

In the RIDE binaries directory (for standard installations C:\RIDE\BIN), you will find a program named "ST7\_pgm.exe". This is an executable file that allows to erase and program the ST7 connected to the RLink. Call it in a DOS prompt with no arguments in order to see the command line arguments.

### 7.2.3.6 Protected addresses

You will notice, in the Code view, that some values have a red square with a white dash next to them. See the picture below. These values are never updated, and you cannot modify them. These are "protected addresses". This means that RIDE will not read them because they are special peripheral registers that are modified whenever they are read. RIDE never accesses them because it would interfere with the execution of the application.



### 7.2.3.7 Limitations of RLink compared to the emulators

The debugging through ICC uses 5 bytes of stack, 2 I/O pins (ICCDATA and ICCCLK). It also uses about 195 bytes of Flash memory for HDFlash devices and these XFlash devices that do not feature the advanced version of the ROM-monitor (like the ST7Lite0).

Limitations for XFLASH Targets WITHOUT Debug Module (ST72F26x, ST7FLITE0x, ST7FLITESx):

- ICCCLK and ICCDATA lines are used for communication between the RLink and the target ST7. These lines are reserved and should not be used by the application being debugged.
- 5 stack bytes are used for communication between the RLink and the target. These stack bytes cannot be used by the application.
- A TRAP vector points to the dedicated RLink-loaded code that is used to manage breakpoints. A breakpoint is a TRAP instruction patched into the application code. For this reason, the TRAP vector and TRAP instruction are reserved for RLink.
- During debugging, peripherals continue to run even when the application has been stopped.
- It is not possible to set a breakpoint in sector 0. For this reason, sector 0 should be configured to its smallest size (0.5Kb) with the option byte.

- Pressing "Stop" while debugging in RIDE is the same as a reset, and returns the program counter to the main function.
- Additional Limitation for ST7FLITE0x and ST7FLITES2/5: 195 bytes in Flash memory are reserved for code that manages communication between RLink and the target ST7. These bytes cannot be used by the application. This code is loaded when the application is programmed to the ST7. The programming algorithm places the code as high as possible in Flash memory. This code never overwrites the interrupt vectors. If there is not enough space for it, RIDE returns an error message indicating that the user cannot debug the application.

Limitations for XFLASH Targets WITH Debug Module (ST7FLITE1x, ST7FLITE2x, ST7FLITE3x):

- ICCCLK and ICCDATA lines are used for communication between the RLink and the target ST7. These lines are reserved and should not be used by the application being debugged.
- 5 stack bytes are used for communication between the RLink and the target. These stack bytes cannot be used by the application.
- A TRAP vector points to the dedicated RLink-loaded code that is used to manage breakpoints. A breakpoint is a TRAP instruction patched into the application code. For this reason, the TRAP vector and TRAP instruction are reserved for RLink.
- During debugging, peripherals continue to run even when the application has been stopped.
- It is possible to set up to 2 breakpoints on sector 0, or 1 advanced breakpoint.

Limitation for HDFLASH Targets:


- 5 stack bytes are used for communication between the RLink and the target. These stack bytes cannot be used by the application.
- 195 bytes in Flash memory are reserved for code that manages communication between RLink and the target ST7. These bytes cannot be used by the application. This code is loaded when the application is programmed to the ST7. The programming algorithm places the code as high as possible in Flash memory. This code never overwrites the interrupt vectors. If there is not enough space for it, RIDE returns an error message indicating that the user cannot debug the application.
- If the device does not have a debug module (see the ST7xxxx Datasheet), In-Circuit Debugging is not possible.

### 7.3 ST7-DVP3 and EMU3 series emulator features

RIDE-ST7 also supports the entry-level ST7-DVP3 and full-featured ST7-EMU3 series emulators. These emulators connect your PC to your application board in place of the target ST7, for debugging. Emulators are available for all target ST7s supported by RIDE. For complete information about emulator features, refer to the ST7-DVP3 Emulator User Manual or the ST7-EMU3 Emulator User Manual.

#### 7.3.1 Configuration

In the **Advanced Options** dialog box, select the communication port (parallel, USB or Ethernet) that your debugging hardware is connected to. For Ethernet connection, you can type the emulator's IP address directly in the Connection Port field:



Note: Information about assigning an IP address is found in the ST7-EMU3 Emulator User Manual.


Use the "Debug" -> "Start" command to connect and configure the microcontroller according to your project's Target Settings.

#### 7.3.2 Trace Recording


For both DVP3 and EMU3 series emulators, you can use the Trace window to control and view the contents of the trace buffer.

To turn the trace on and off, select "Debug" -> "Trace" -> "Options" and click on the appropriate radio button in the Trace dialog box:

- Off to disable trace
- Continual to enable trace



To open the trace window, from the main menu select the command "Debug" -> "Trace" -> "View".



N°	t	dt	PC	Source	Memor...	Data	Event	Trigger...	Analyz...
#11	1250ns	100	0x20a7	CLR 53	EMU	0x3f	Operation c	TIN=0	AI=0xff
#12	1350ns	150	0x20a8	db 53h ; 'S	EMU	0x53	Operand fet	TIN=0	AI=0xff
#13	1500ns	100	0x0053	db 0FFh	EMU	0xff	Data read	TIN=0	AI=0xff
#14	1600ns	150	0x0053	db 0FFh	EMU	0xff	Discarded	TIN=0	AI=0xff
#15	1750ns	100	0x0053	db 0FFh	EMU	0x00	Data write	TIN=0	AI=0xff
#16	1850ns	150	0x20a9	CLR 54	EMU	0x3f	Discarded	TIN=0	AI=0xff
#17	2000ns	100	0x20a9	CLR 54	EMU	0x3f	Operation c	TIN=0	AI=0xff
#18	2100ns	150	0x20aa	db 54h ; 'T	EMU	0x54	Operand fet	TIN=0	AI=0xff
#19	2250ns	100	0x0054	db 0FFh	EMU	0xff	Data read	TIN=0	AI=0xff
#20	2350ns	150	0x0054	db 0FFh	EMU	0xff	Discarded	TIN=0	AI=0xff
#21	2500ns	100	0x0054	db 0FFh	EMU	0x00	Data write	TIN=0	AI=0xff
#22	2600ns	150	0x20ab	LD A, 5	EMU	0xb6	Discarded	TIN=0	AI=0xff
#23	2750ns	150	0x20ab	LD A, 5	EMU	0xb6	Operation c	TIN=0	AI=0xff
#24	2900ns	100	0x20ac	db 50h ; 'P	EMU	0x50	Operand fet	TIN=0	AI=0xff
#25	3000ns	150	0x0050	db 0FFh	EMU	0xff	Data read	TIN=0	AI=0xff
#26	3150ns	100	0x20ad	LD A, 5	EMU	0xb6	Discarded	TIN=0	AI=0xff
#27	3250ns	150	0x20ad	LD A, 5	EMU	0xb6	Operation c	TIN=0	AI=0xff
#28	3400ns	100	0x20ae	db 51h ; 'Q	EMU	0x51	Operand fet	TIN=0	AI=0xff
#29	3500ns	150	0x0051	db 0FFh	EMU	0xff	Data read	TIN=0	AI=0xff
#30	3650ns		0x20af	CLR 51	EMU	0x3f	Discarded	TIN=0	AI=0xff

The **Trace** window contains a table with several columns, which together form a single trace record. The following types of information can be recorded and displayed:

- **N°**: corresponds to the number of the trace record in the buffer. The oldest record in the trace buffer is always record number "1".
- **PC**: the memory location accessed.
- **Source**: the instruction in assembly language mnemonics, if this is a Fetch instruction cycle.
- **Data**: the hexadecimal value on the data bus.
- **Events**: the type of microprocessor event-for example, stack read, stack write, data read, data write, etc.

For DVP3 series emulator these additional columns are available:

- **Memory**: the type of memory access (i.e. either read/write/fetch or invalid).
- **Trigger Input**: the value of the TRIGIN signal (input pin located on the DVP).
- **Probe**: The values of the signals output from the probe pins located on the DVP.

For EMU3 series emulator the additional columns are:


- **t**: the value in nanoseconds of the time marker at this event.
- **dt**: the delta time between this recording and the next one.
- **Timestamp Event**: signals the occurrence of events that affect the validity of the value in the time column-in particular
- **Trace discontinuity**: indicates that the trace record in the buffer is not continuous. This is the case when the trace is turned on or off using an advanced breakpoint or from the **stand-alone viewer**, to record only certain events.
- **TIN (Trigger IN)**: external Trigger input.

- **AI (Analyzer Input):** input from the Analyzer input connector on the EMU3 probe.
- **Advanced Breakpoints:** shows the level and the logic states of the **Bus Event Machine (BEM)** as they become **TRUE**. These are reported in the form **BEM I[1-4] [e1 / e2 / if / e3 / e4 / else]**. For example: *BEM I2 e1 if* indicates that on *Level 2* of the sequencer, *Event 1* is TRUE and at the same time the condition *IF* is TRUE (i.e. only one event is necessary to fulfill the *IF* condition in this case).

## 7.4 EMU3 series emulator special features

The EMU3 series emulators provided Performance Analysis and Advanced Breakpoint capabilities.

These special features are available during the debug session from the popup menu command "Debug" -> "EMU3\_ST7":



For more information about these features that are specific to the ST7-EMU3 series emulators, please refer to the help files:

addonperf.chm (for Performance Analysis) and addonbem.chm (for Advanced Breakpoints). For standard installations of RIDE, these are found in the directory: C:\RIDE\BIN\EMU3\HELP



---

## **8. Building an ICC-compliant application board**

---

In-Circuit Debugging (ICD) and In-Circuit Programming (ICP) are applications of the In-Circuit Communication (ICC) protocol developed by ST for ST7 microcontrollers. With the necessary connection hardware, this protocol allows you to read and write to your ST7's Flash memory, and control the running of your application on your microcontroller.

This protocol is used by RLink and the other ST7 in-circuit debuggers and programmers.

To take advantage of ICC, you must integrate an ICC connector into your application hardware when you start developing your application. To help you implement ICP and ICD in the development of your application, this chapter provides a summary of points you should consider when installing an ICC connector.

The REva board features an ICC connector. Refer to its schematics in the REva User Guide for an example of a correct connection.

## 8.1 ICC Connector

To connect to your application board for ICP and ICD, you need to install a 10-pin, HE-10 type connector (also called an ICC Connector) and ensure the appropriate connections to your ST7. This connector receives the ICC cable and relays the signals required for ICP and ICD to your ST7.

The table below describes the ICC connector and its pins usage:

Connector Pin (and pin number)	ST7 Pin (see pin number on device datasheet)	Function
GND (1, 3, 5, 10)	GND	Ground
VDD_APPLI (7)	VDD	Device power supply
ICCDATA (2)	ICCDATA	ICC input/output serial data pin
ICCCLK (4)	ICCCLK	ICC input serial clock pin
ICCRESET (6)	RESET	Device reset
ICCSEL/VPP (8)	ICCSEL/VPP	Programming voltage and ICC selection
ICCOSC (9)	OSC1 or OSCIN	Main clock input for external clocking (optional)

### 8.1.1 ICCDATA and ICCCLK pins

These pins are used to transfer data between the RLink and the target microcontroller.

As soon as the programmer's ICC connector is connected to the application board, the ICCDATA and ICCCLK pins must not be used by other application devices, even if an ICC session is not in progress. If the application uses these pins as inputs, isolation such as a serial resistor must be implemented to prevent other application devices from forcing a signal on either of these pins. The application board must not drive current in excess of 1mA. If the ICCDATA and ICCCLK pins are only used as outputs by the application, no signal isolation is necessary.

For ST7 without an ICCSEL pin, during normal operation the ICCCLK pin must be pulled-up internally or externally (10K $\Omega$  pull-up required in noisy environments). This is to avoid entering ICC mode unintentionally during a reset.

### 8.1.2 RESET pin

This pin is used to reset the target microcontroller from the host PC through the RLink.

During an ICC session, you must ensure that the RLink controls the ST7's RESET pin so that no external reset is generated by the application board. This can lead to a conflict if the application reset circuitry signal exceeds 5mA (push-pull output or pull-up resistor <1K $\Omega$ ). To avoid such conflicts, a Shottky diode can be used to isolate the application reset circuit.

### 8.1.3 ICCSEL/VPP pin

This pin is used on certain ST7 derivatives for supplying a 12V programming voltage and/or for entering ICC (program) mode.

The application should include a pull-down resistor not lower than 10K $\Omega$ .

#### **8.1.4 ICCOSC pin**

This pin is used for the RLink to provide an external clock to the target microcontroller.

The ICCOSC pin of the ICC connector must be connected to the ST7's OSC1 or OSCIN pin if the clock is not provided by the application, or if the application clock source is not programmed in the option byte. This connection allows you start communication with your ST7 for in-circuit debugging and/or programming using the "Ignore Option Bytes" option. When doing so, your RLink provides a clock source to initiate communication with the ST7.

The RLink provides a clock source at a frequency of 12MHz.

For ST7 devices with multi-oscillator capability, when the ICCOSC pin is connected, the OSC2 pin should be grounded.

#### **8.1.5 VDD\_APPLI pin**

This pin is used by tools with a power supply follower, such as RLink. This connection is needed by the power supply follower to detect the supply voltage and power the RLink's I/Os accordingly.