

User's Manual

BioFACE



www.BioTrackSoftware.com

CONTENT TABLE

1	INSTRUCTION FOR USE	1
1.1	FINGER PLACEMENT	1
1.2	USE OF TOUCH SCREEN.....	1
1.3	TOUCH OPERATIONS	2
1.4	BIOFACE DEVICE.....	4
1.5	MAIN INTERFACE.....	5
1.6	VERIFICATION MODES	6
1.6.1	Fingerprint Verification.....	6
1.6.2	Facial Verification.....	8
1.6.3	Password Verification.....	11
1.6.4	ID Card Verification	13
2	MAIN MENU	15
3	USER MANAGEMENT	18
3.1	ADDING A USER	19
3.1.1	Entering a User ID.....	20
3.1.2	Entering a Name.....	21
3.1.3	Enrolling a Fingerprint.....	22
3.1.4	Enrolling a Password	24
3.1.5	Enrolling a Face	25
3.1.6	Entering a Group No.....	26
3.1.7	Enrolling an ID Card.....	28
3.1.8	Modify User Rights	30
3.2	EDIT A USER	31
3.3	DELETE A USER.....	32
3.4	QUERY A USER	33
3.4.1	Query by User ID.....	33
3.4.2	3.4.2 Query by Name.....	33
4	COMMUNICATION-RELATED SETTINGS.....	35
4.1	NETWORK SETTINGS.....	35
4.2	SERIAL PORT SETTINGS	36
4.3	WIEGAND OUTPUT	37
4.3.1	Wiegand 26-bits Output Description	38
4.3.2	Wiegand 34-bits Output Description	39
4.3.3	Customized Format.....	40
5	SYSTEM CONFIGURATION.....	44
5.1	BASIC PARA METERS.....	44
5.2	INTERFACE PARAMETERS	46
5.3	FINGERPRINT PARAMETERS.....	47
5.4	FACE PARAMETERS	48
5.5	LOG SETTINGS.....	50


5.6	UPDATE	51
6	DATA MANAGEMENT	52
6.1	QUERY A RECORD	53
6.2	WORK CODE.....	54
7	USB DISK MANAGEMENT.....	57
8	KEYBOARD DEFINITIONS.....	59
9	AUTO TEST.....	61
10	SCREEN CALIBRATION	63
11	BELL SETTING.....	64
12	ACCESS CONTROL SETTING	66
13	DATE/TIME SETTING	67
13.1	SET DATE/TIME.....	67
13.2	SET DAYLIGHT SAVING TIME (DST)	68
14	SYSTEM INFORMATION	71
14.1	RECORDS	71
14.2	TERMINAL	71
15	APPENDIX.....	72
15.1	TEXT INPUT INSTRUCTIONS	72
15.2	RULES FOR UPLOADING PROMOTIONAL PICTURES.....	75
15.3	INTRODUCTION TO WIEGAND.....	76
15.4	PHOTO ID FUNCTION	77
15.5	ATTENDANCE STATUS SELECTION FUNCTION.....	78

1 INSTRUCTION FOR USE

1.1 FINGER PLACEMENT


Recommended fingers: The index finger, middle finger or the ring finger; the thumb and little finger are not recommended (because they are usually clumsy on the fingerprint collection screen).

Proper press:




Make finger center pressed on the sensor window


Improper press




Too lean



Too downward



Slant



Upright

1.2 USE OF TOUCH SCREEN

Touch the screen with one of your fingertips or the top of the forward edge of a fingernail, as shown in the following figure. A broad point of contact may lead to inaccurate pointing.



When the touch screen is less sensitive to the touch, you can perform screen calibration through menu operations. Press [Menu] [Calibration] on the screen and a cross icon will be displayed. After you touch the center of the cross at five locations on the screen correctly, the system automatically returns to the main menu.


Press [Return] to return to the initial interface. For details, see 10 Screen Calibration in this manual.

Smear or dust on the touch screen may affect the performance of the touch screen.

Therefore, try to keep the screen clean and dust-free.

1.3 TOUCH OPERATIONS

1) Enter numbers. Press the [User ID] key. The system automatically displays the number input interface. After entering the user ID, press [OK] to save and return to the previous interface.




2) Enter Text. Press the [Name] key. The system automatically displays the text input interface. After entering the user name, press [X] to save and return to the previous interface.




3) Modify parameters. Press the default value of a parameter and the system automatically switches to another value of this parameter.



1.4 BIOFACE DEVICE



1.5 MAIN INTERFACE



Menu: You can enter the main menu by touching this key.

Time: Current time is displayed. Both the 12-hour and 24-hour time systems are supported.

Date: Current date is displayed.

1:1 or 1:G Function Key: You can enter the digital input interface of 1:1 or 1:G verification mode. You can set the "1:1/1:G" shortcut key through Screen Shortcut Keys. This key is automatically hidden if the [Toolbar Style] is set to "Permanent Display".

Facial/Fingerprint Switch Key: By pressing this key, you can switch between the facial and fingerprint recognition modes. You can set the "Facial/Fingerprint Switch Key" shortcut key through Screen Shortcut Keys. This key is automatically hidden if the [Toolbar Style] is set to "Permanent Display".

Current Group No.: When the terminal is currently in the facial recognition mode, users in current group can perform facial comparison directly, while users of another group need to enter the group No. before performing the facial comparison.

Facial/Fingerprint Image: If a facial image is displayed, the terminal is currently in the facial recognition mode; if a finger print image is displayed, the terminal is currently in the fingerprint recognition mode. You can change current recognition mode of the terminal through Facial/Fingerprint Switch Key, the Facial/Fingerprint Key in Screen Shortcut Keys or related key in Keyboard Shortcut Keys.

Attendance Status: Current attendance status is displayed. This key is hidden when Screen Shortcut Keys are displayed.

Screen Shortcut Keys: Press related shortcut keys to display the attendance status or enter the functional interface quickly. Users can customize the function of each shortcut key. For details, see 8 Keyboard.

Keyboard Shortcut Keys: The Keyboard Shortcut Keys have a one-to-one relationship with Screen Shortcut Keys. Press related shortcut keys to display the attendance status or enter the functional interface quickly.

1.6 VERIFICATION MODES

1.6.1 FINGERPRINT VERIFICATION

(1) 1:N fingerprint verification

In the fingerprint verification mode, the terminal compares current fingerprint collected by the fingerprint collector with all fingerprint data on the terminal.

1. To enter the fingerprint verification mode (Figure 1 on the right), you can:

- A) Press [Facial/Fingerprint Switch Key] on the screen, or
- B) Press [Facial/Fingerprint] shortcut key on the screen, or
- C) Press the keyboard shortcut key [F6].

2. Press your finger on the fingerprint collector by adopting the proper finger placement. For details, see 1.1 Finger Placement.

3. If the verification is successful, an interface as shown in Figure 2 on the right will be displayed.

4. If the verification is not successful, an interface as shown in Figure 3 on the right will be displayed.

(2) 1:1 fingerprint verification

In the 1:1 fingerprint verification mode, the terminal compares current fingerprint collected through the fingerprint collector with that in relation to the user ID entered through keyboard. Adopt this mode only when it is difficult to recognize the fingerprint.



1. To enter the 1:1 recognition mode, you can:

A) Press [1:1/1:G] on the screen, as shown in Figure 1 on the right, or

B) Press [1:1/1:G] shortcut key on the screen, or

C) Press relate d shortcut key on the keyboard.

Note: You can enter the 1:1 recognition mode through B) and C) only after setting a shortcut key for "1:1/1:G". For details, see 8 Keyboard.



2. Enter user ID and then press the "Fingerprint" icon (Figure 2 on the right) to

enter 1:1 fingerprint recognition mode. If the prompt "Unregistered user !" is displayed, the user ID is nonexistent or the user ID bearer has not enrolled his/her fingerprint.



3. Press your finger on the fingerprint collector by adopting the proper finger placement. For details, see 1.1 Finger Placement.

4. If the verification is successful, an interface as shown in Figure 3 on the right will be displayed. 4. If the verification is not successful, an interface as shown in Figure 4 on the right will be displayed.



1.6.2 FACIAL VERIFICATION

(1) 1:G facial verification

Current group No. is displayed on the facial recognition interface. Users in current group can perform facial comparison directly. Users of another group can perform facial comparison only after entering the group No. or selecting it using the shortcut key. And the system will set the group entered or selected by users to be the current group instantly.



1. To enter the 1:G recognition mode, you can:


- A) Press [1:1/1:G] on the screen, as shown in Figure 1 on the right, or:
- B) Press [1:1/1:G] shortcut key on the screen, or
- C) Press related shortcut key on the keyboard.

Note: You can enter the 1:1 recognition mode through B) and C) only after setting a shortcut key for "1:1/1:G".

2. Enter user Group No. and then press the "1:G" icon (Figure 2 on the right) to enter 1:G fingerprint recognition mode.



3. Compare the facial in a proper way.



Current Group No. is displayed on the comparison interface, as shown in Figure 3 on the right.


Note: Check whether you are in current group; if not, return to Step 1.

4. If the verification is successful, an interface as shown in Figure 4 on the right will be displayed.



(2) 1:1 facial verification

In the 1:1 facial verification mode, the terminal compares current facial collected through the facial collector with that in relation to the user ID entered through keyboard. Adopt this mode only when it is difficult to recognize the facial.



1. To enter the 1:1 recognition mode, you can:

- A) Press [1:1/1:G] on the screen, as shown in Figure 1 on the right, or
- B) Press [1:1/1:G] shortcut key on the screen, or
- C) Press related shortcut key on the keyboard.

Note: You can enter the 1:1 recognition mode through B) and C) only after setting a shortcut key for "1:1/1:G".

2. Enter user ID and then press the "1:1 Facial" icon (Figure 2 on the right) to enter 1:1 facial recognition mode. If the prompt "Unregistered user!" is displayed, the user ID is nonexistent or the user ID bearer has not enrolled his/her face in the system.



3. Compare the facial in a proper way.

Current Group No. is displayed on the comparison interface, as shown in Figure 3 on the right.

4. If the verification is successful, an interface as shown in Figure 4 on the right will be displayed. The system will return to the main interface if the verification is not passed within 20 seconds.



1.6.3 PASSWORD VERIFICATION

In the password verification mode, the terminal compares the password entered with that in relation to the user ID.



1. To enter the password verification mode, you can:

- A) Press [1:1/1:G] on the screen, as shown in Figure 1 on the right, or
- B) Press [1:1/1:G] shortcut key on the screen, or
- C) Press related shortcut key on the keyboard.

Note: You can enter the 1:1 recognition mode through B) and C) only after setting a shortcut key for "1:1/1:G".

2. Enter the user ID and then press the "Key" icon (Figure 2 on the right) to enter password verification mode. If the prompt "Unregistered user!" is displayed, the user ID is nonexistent or the user ID bearer has not enrolled his/her password in the system.



3. Enter the password and press the "OK" icon to start the password comparison, as shown in Figure 3 on the right.



4. If the verification is successful, an interface as shown in Figure 4 on the right will be displayed.



1.6.4 ID CARD VERIFICATION

Only the products with a built-in ID card module support the ID card verification. The products with a built-in ID card module support the following two verification modes:

ID Card Only: Users only need to swipe their ID cards for verification.

ID + Facial Verification: After passing the ID card verification, you also need to perform facial verification.

1) ID Card Only

1. If you have your ID card number enrolled in the system, you can pass the verification by swiping your ID card at the swiping area in a proper way.
2. If the verification is successful, an interface as shown in Figure 1 on the right will be displayed.



3. If the verification is not successful, an interface as shown in Figure 2 on the right will be displayed.




2) ID + Facial Verification

1. Swipe your ID card properly at the swiping area to enter the 1:1 facial verification mode, as shown in Figure 1 on the right:



2. Compare the facial in a proper way.




3. If the verification is successful, an interface as shown in Figure 3 on the right will be displayed. The system will return to the main interface if the verification is not passed within 20 seconds.



2 MAIN MENU


There are two types of rights respectively granted to two types of users: the ordinary users and administrators. Ordinary users are only granted the rights of facial, fingerprint, password or card verification, while administrators are granted the access to the main menu for various operations apart from having all the privileges granted to ordinary users.

Press [Menu] on the initial interface to access the main menu, as shown in the following figure:



Any user can access the main menu by pressing the [Menu] key if the system is free from administrators. After administrators are configured on the terminal, the terminal needs to verify the administrators' identity before granting them access to the main menu. To ensure terminal security, it is recommended to set an administrator when using the terminal initially.

The main menu includes ten submenus and three shortcut keys, as shown in the following figure:



User Mgt.: Through this submenu, you can browse the user information stored on the terminal, including the user ID, name, fingerprint, facial, card, password, rights and group No.; add, modify or delete the user information.

Comm.: Through this submenu, you can set related parameters for communication between the FFR terminal and PC, including the IP address, gateway, subnet mask, baud rate, equipment No. and communication password.

System: Through this submenu, you can set system-related parameters, including the basic parameters, interface parameters, fingerprint, facial and attendance parameters, to enable the FFR terminal to meet user requirements to the greatest extent in terms of functions and display.

Data Mgt.: Through this submenu, you can perform management of data stored on the FFR terminal, for example, deleting the attendance record, all data and promotional pictures, purging management rights and resetting the FFR terminal to factory defaults.

Dn/Upload: Through this submenu, you can import user information and attendance data stored in a USB disk to related software or other fingerprint recognition equipment.


Keyboard: Through this submenu, you can customize six shortcut keys. Related status will be displayed by pressing related status key.

Auto Test: This submenu enables the system to automatically test whether functions of various modules are normal, including the screen, collector, voice, facial, keyboard and clock tests.

Calibration: When the touch screen is less sensitive to the touch, you can calibrate the screen on the calibration interface through this submenu.

Bell: Through this submenu, you can set the alarm time and duration.

Access: Through this submenu, you can set the parameters of the electronic locks and related access control devices.



The user is an administrator.



The user has enrolled his/her fingerprint.



The user has enrolled his/her facial image.




The user has enrolled his/her ID card.



The user has enrolled his/her password.

3 USER MANAGEMENT

Browse the user information, including the user ID, name, fingerprint, face, ID card, password, rights and the group that the user belongs to. Add, edit or delete the basic information of users. Press [User Management] on the main menu interface to display the user management interface.



The user is an administrator.



The user has enrolled his/her fingerprint.



The user has enrolled his/her facial image.



The user has enrolled his/her ID card.



The user has enrolled his/her password.

Note:

- 1) In User List Area, users are listed in alphabetical order by last name. If you select a user in User List Area, you can access the editing interface of this user to edit or delete related user information.
- 2) In Character Selection Bar, users are listed in alphabetical order by last name by default and you can locate the desired user quickly. You can press [Query] to locate and query a user through the user ID.

3.1 ADDING A USER

Press [Add] on the [User Mgt.] interface to display the [Add User] interface as shown below.

The image displays two screenshots of the 'Add User' interface. The top screenshot shows the initial form with fields for User ID (8), Name, Fingerprint, Password, Face, Card, and Group No. (1). The bottom screenshot shows the 'Role' field set to 'User' and a 'Photo' field.

User ID: Enter a user ID. 1- to 9-digit user IDs are supported by default.

Name: Enter a user name. 12-character user names are supported by default.

Fingerprint: Enroll a user's fingerprint and the FFR terminal displays the number of enrolled fingerprints. A user can enroll 10 fingerprints at maximum.

Face: Enroll a user's face.

Card: Enroll a user's ID card.

Password: Enroll a user's password. 1- to 8-digit passwords are supported by default.

Role: Set the rights of a user. A user is set to ordinary user by default and can also be set to Administrator . Ordinary users are only granted the rights of facial, fingerprint or password verification, while administrators are granted the access to the main menu for various operations apart from having all the privileges granted to ordinary users.


Group No.: Set the group that the user belongs to. Valid group No.: 1– 24.

3.1.1 ENTERING A USER ID

The FFR terminal automatically allocates an ID starting from 1 for every user in sequence. If you use the ID allocated by the FFR terminal, you may skip this section.


1. Press [User ID] on the [Add User] interface to display the user ID management interface, as shown in

Figure 1 on the right.



Tip: The user ID can be modified during initial enrollment, but once enrolled, it cannot be modified.

2. On the displayed keyboard interface, enter a user ID and press <O K> as shown in Figure 2 on the right. If a prompt message "The user ID already exists!" is displayed, enter another ID.



Tip: The FFR terminal supports 1- to 9-digit user IDs by default. If you need to extend the length of current user ID numbers, please consult our commercial representatives or fore-sale technical support personnel.

3. After the user ID is entered, an interface is displayed as shown in Figure 3 on the right. Press [Save] to save current information and return to the previous interface. Press [User Mgt.] to return to the previous interface without saving current information.



3.1.2 ENTERING A NAME

Enter a user name through the keyboard.

1. Press [Name] on the [Add User] interface to display the name input interface, as shown in Figure 1 on the right.



2. On the displayed keyboard interface, enter a user name and press [X] as shown in Figure 2 on the right. For details of operations on keyboard interface, see "Keyboard Instructions".




Tip: The FFR terminal supports the 1- to 12-character names by default.

3. After the user name is entered, the interface is displayed as shown in Figure 3 on the right. Press [Save] to save current information and return to the previous interface. Press [User Mgt.] to return to the previous interface without saving current information.



3.1.3 ENROLLING A FINGERPRINT

1. Press [Fingerprint] on the [Add User] interface to display the [Enroll Fingerprint] interface, as shown in Figure 1 on the right.



2. On the displayed [Enroll Fingerprint] interface (as shown in the Figure 2 on the right), place your finger on the fingerprint collector properly according to the system prompt. For details, see "Finger Placement".



3. Place the same finger on the fingerprint collector for three consecutive times correctly. If the enrollment succeeds, the system will display a prompt message "Enrolled Successfully" and automatically return to the [Add User] interface (as shown in Figure 4 on the right). If the enrollment fails, the system will display a prompt message and return to the [Enroll Fingerprint] interface. In this case, you need to repeat the operations of step 2.




4. You can back up the enrolled fingerprint of a user by pressing [Fingerprint]. A user can enroll 10 fingerprints at maximum.



5. Press [Save] to save current information and return to the previous interface.
Press [User Mgt.] to return to the previous interface without saving current information.

3.1.4 ENROLLING A PASSWORD

1. Press [Password] on the [Add User] interface to display the password management interface, as shown in Figure 1 on the right.



2. On the displayed keyboard interface, enter a password and press <OK> as shown in Figure 2 on the right. Re-enter the password according to the system prompt and then press <OK>.




Tip: The FFR terminal supports the 1- to 8-digit passwords by default.

3. After the password is entered, an interface is displayed as shown in Figure 3 on the right. Press [Save] to save current information and return to the previous interface. Press [User Mgt.] to return to the previous interface without saving current information.




3.1.5 ENROLLING A FACE

1. Press [Face] on the [Add User] interface to display the face enrollment interface, as shown in Figure 1 on the right.



2. On the displayed face enrollment interface (as shown in Figure 2 on the right), turn your head to the left and right slightly, raise and lower your head according to the voice prompts, so as to enroll different parts of your face into the system to assure accurate verification.



3. If your facial image is enrolled successfully, the system will display a prompt message and automatically return to the [Add User] interface (as shown in Figure 4 on the right).



4. Press [Save] to save current information and return to the previous interface.
Press [User Mgt.] to return to the previous interface without saving current information.

3.1.6 ENTERING A GROUP NO.

The FFR terminal enables the facial comparison function by default. During face enrollment, the FFR automatically allocates a group No. starting from 1 for every user in sequence. When the number of users in Group No.1 reaches the upper limit, the rest users fall under Group No.2 automatically. Up to 100 facial images can be enrolled in Group No.1 and only 50 facial images can be enrolled in other groups. If you use the group No. allocated by the FFR terminal, you may skip this section.

1. Press [Group No.] on the [Add User] interface to display the group No. management interface, as shown in Figure 1 on the right.



2. On the displayed keyboard interface, enter your group No. and press <OK> as shown in Figure 2 on the right.



Tip: A valid group No. contains 1–24 digits.

3. After the group No. is entered, an interface is displayed as shown in Figure 3 on the right. Press [Save] to save current information and return to the previous interface. Press [User Mgt.] to return to the previous interface without saving current information.

The screenshot shows a user management interface with a dark background and green text. At the top, there are four buttons: 'User Mgt.', 'Add User', 'Continue', and 'Save'. Below these are seven input fields arranged in two columns. The left column contains 'User ID: 9', 'Fingerprint: 1', 'Face', and 'Card'. The right column contains 'Name', 'Password', and 'Group No.: 1'. Each field has a small green indicator light to its left. At the bottom of the interface, there are two speaker icons.

Tip: Please remember your own group No.

3.1.7 ENROLLING AN ID CARD

1. Press [Card] on the [Add User] interface to display the [Enroll Card] interface, as shown in Figure 1 on the right.



2. The [Punch Card!] interface pops o ut as shown in Figure 2 on the right. Swipe your ID card properly in the swiping area.



3. If the card passes the verification, the FFR terminal displays a prompt message "Read Successfully! Card No.: *****", as sho wn in Figure 3 on the right, and returns to the [Add User] interface. Press [Card] to display the enrolled card number as shown in Figure 4 on the right.




4. Press [Save] to save current information and return to the previous interface.
Press [User Mgt.] to return to the previous interface without saving current information.

User Mgt.		Add User	Continue	Save
User ID: 9		Linda		
Fingerprint: 1	Password			
Face	Group No.: 1			
0005639308				

www.BioTrackSoftware.com

3.1.8 MODIFY USER RIGHTS

1. On the [Add User] interface, press [Role:User] to change the user into an administrator, as shown in Figure 1 on the right.



Note: There are two types of rights respectively granted to two types of users: the ordinary users and administrators. Ordinary users are only granted the rights of facial, fingerprint, or password verification, while administrators are granted the access to the main menu for various operations apart from having all the privileges granted to ordinary users.


2. After the modification is done, the interface is as shown in Figure 2 on the right. Press [Save] to save current information and return to previous interface; press [User Mgt.] to directly return to previous interface without saving current information.



3.2 EDIT A USER

Select a user from the User List to enter [User Info] interface.

The User ID cannot be modified, and the other operations are similar to those performed to add a user. You can re-enroll your fingerprint and facial image, change your password and modify the management rights and group No.



3.3 DELETE A USER

On the [User Info] interface, you can delete all or partial user information.

1. Press [Delete] to delete a user, as shown in Figure 1 on the right.



2. On the interface displayed (as shown in Figure 2 on the right), click [YES] to delete current user and [NO] to return to previous interface.



3. On the [User Info] interface, press [Name], [Fingerprint], [Face] or [Password] to delete related user information.

3.4 QUERY A USER

To facilitate administrators to locate a user quickly from a large number of enrolled users, the FFR terminal enables user query by his/her "User ID" and "Name".

(Location Search)



3.4.1 QUERY BY USER ID

1. Press [Query] on the [User Management] interface to display the User ID query interface, as shown in Figure 1 on the right.




2. Enter the user ID on the displayed interface, and click [OK] (as shown in Figure 2 on the right) to locate the cursor to the desired user (as shown in Figure 3 on the right).



3.4.2 QUERY BY NAME


On the [User Management] interface, enter the user name through the "Character Selection Bar" to locate the cursor to the desired user, as shown in the following figure:



By selecting a character from the "Character Selection Bar", you can quickly locate the users whose names start with this character. Users are listed in alphabetical order by last name by default.

4 COMMUNICATION-RELATED SETTINGS

You can set related parameters for the communication between the FFR terminal and PC, including the IP address, gateway, subnet mask, baud rate, equipment No. and communication password.



4.1 NETWORK SETTINGS

When the FFR terminal communicates with the PC over Ethernet, you need to check the following settings:



IP Address: The IP address is 192.168.1.201 by default and can be changed as required; the IP address of the FFR terminal and that of the PC cannot be duplicated.

Subnet Mask: The subnet mask is 255.255.255.0 by default and can be changed as required.

Gateway: The gateway is 0.0.0.0 by default. If the FFR terminal and the PC are not located in the same network segment, you need to set the gateway.

4.2 SERIAL PORT SETTINGS

When the FFR terminal communicates with the PC over serial ports (RS232/RS485), you need to check the following settings:

Menu	Communication	Save
TCP/IP	RS232	ON
RS232/RS485	RS485	OFF
Wiegand Output	Baud Rate	115200
	Device ID	1
	Comm Key	0

RS232: This parameter is used to enable or disable the RS232 communication. If the RS232 communication cables are used, set this parameter to "ON".

RS485: This parameter is used to enable or disable the RS485 communication. If the RS485 communication cables are used, set this parameter to "ON".

Baud Rate: This parameter is used to set the baud rate for the communication between the FFR terminal and the PC. It includes five options: 9600, 19200, 38400, 57600, and 115200.

The high baud rate is recommended for the RS232 communication to achieve high communication speed, while the low baud rate is recommended for the RS485 communication to achieve stable low-speed communication.

Device ID: This parameter is used to set the ID of device from 1 to 254. If the RS232/RS485 communication is adopted, you need to enter the device ID on the software communication interface.

Comm Key: To enhance the security of attendance data, you can set a password for the connection between the FFR terminal and PC. Once the password is set, you can connect the PC with the FFR terminal to access the attendance data only after entering the correct password. The default password is 0 (that is, no password). Once a password is set, you need

to enter this password before connecting the PC software with the FFR terminal; otherwise, the connection is unsuccessful. 1- to 6-digit passwords are supported.

Considering the massive data including the finger print and facial templates stored in the FFR terminal, it is recommended to transfer the data between the FFR terminal and PC over network to enhance the transfer speed.

4.3 WIEGAND OUTPUT

Wiegand Format: The system has two built-in formats Wiegand 26-bits and Wiegand 34-bits, and also supports the format customization function to meet individualized requirements.

Failed ID: refers to the value output by the system upon verification failure. The output format is subject to the setting of "Wiegand Format". The default value scope of Failed ID is 0–65535.

Site Code: The site code is used for customized Wiegand format. The site code is similar to the device ID, but the site code is customizable and can be duplicated among different devices. The default value scope of the site code is 0–255.

Pulse Width: refers to the width of the Wiegand pulse in microseconds. The default value scope of the pulse width is 1–1000.

Pulse Interval: refers to the interval of the Wiegand pulse in microseconds. The default value scope of the pulse width is 1–10000.

Output: refers to the contents output upon successful verification. You can select the "User ID" or "Card Number" as the output.

4.3.1 WIEGAND 26-BITS OUTPUT DESCRIPTION

The system has a built-in Wiegand 26-bits format. Press [Wiegand Format], and select "Standard Wiegand 26-bits".

The composition of the Wiegand 26-bits format contains 2 parity bits and 24 bits for output contents ("User ID" or "Card Number"). The binary code of 24-bits represent up to 16,777,216 (0–16,777,215) different values.

1 2 25 26

Even parity - User ID/Card Number - Odd parity bit

Definition of Fields:

Even parity bit: Judged from bit 2 to bit 13. The even parity bit is 1 if the character has an even number of 1 bits; otherwise, the even parity bit is 0.

User ID/Card: User ID/Card Number (Card Code, 0–16777215) Number (bit 2- bit 25) Bit 2 is the Most Significant Bit (MSB).

Odd parity bit: Judged from bit 14 to bit 25. The odd parity bit is 1 if the character has an even number of 1 bits; otherwise, the odd parity bit is 0.

For example, for a user with user ID of 12345, the enrolled card number is 0013378512 and the failed ID is set to 1.

1) When the output is set to "User ID", the Wiegand output is as follows upon successful verification: 0 0 0 0 0 0 0 0 0 0 1 1 0 0 0 0 0 1 1 1 0 0 1 1

Even parity bit User ID = Binary code of 12345 Odd parity bit

2) When the output is set to "Card Number", the Wiegand output is as follows upon successful verification: 1 1 1 0 0 1 1 0 0 0 0 1 0 0 0 1 1 1 1 0 1 0 0 0 0

Even parity bit User ID = Binary code of 0013378512 Odd parity bit

3) The Wiegand output is as follows upon verification failure:

0 1 0

Even parity bit Failed ID = Binary code of 1 Odd parity bit

Note: If the output contents exceed the scope allowed for the Wiegand format, the last several bits will be adopted and first several bits are automatically discarded. For example, the user ID 888 888 888 is 110 100 111 110 110 101 111 000 111 000 in binary format. Wiegand26 only supports 24 bits, that is, it only outputs the last 24 bits, and first 6 bits "110 100" are automatically discarded.

The composition of the Wiegand 34-bits format contains 2 parity bits and 32 bits for output contents ("User ID" or "Card Number"). The binary code of 32-bits represent up to 4,294,967,296 (0–4,294,967,295) different values.

Field Meaning

User ID/Card: User ID/Card Number (Card Code, 0-4,294,967,295) Number (bit 2- bit 33)

Odd parity bit: Judged from bit 18 to bit 33. The **odd parity bit** is 1 if the character has an even number of 1 bits; otherwise, the odd parity bit is 0.

1) When the output is set to "User ID", the Wiegand output is as follows upon successful verification:

Even parity bit User ID = Binary code of 123456789 Odd parity bit

Even parity bit User ID = Binary code of 0013378512 Odd parity bit

Even parity bit Failed ID = Binary code of 1 Odd parity bit

4.3.3 CUSTOMIZED FORMAT

Apart from the two built-in formats **Wiegand 26-bits** and **Wiegand 34-bits**, the system also supports the format customization function to meet individualized requirements.

The customized format consists of two character strings: the **data bits** and **parity bits**. These two character strings need to be defined separately.

Data bits define the number of binary bits output by Wiegand as well as the meaning of each bit. The data bits output by Wiegand can be a card number (C), site code (s), facility code (f), manufacturer code (m) and parity bits (p).

Parity bits

define the check mode of each bit in data bits and ensure the correctness of data bits during transfer through the parity check. The parity bits can be set to odd check (o), even check (e) and both odd check and even check (b). There exists a one-to-one correspondence relationship between the data bits and parity bits.

For example, the Wiegand26 can be customized as follows:


Definition of data bits: psssssssscccccccccccccccp

Definition of parity bits: eeeeeeeeeeeeeo000000000000

Note: Wiegand26 consists of 26 bits. The first bit is the even parity bit of bits 2 to 13; the 26th bit is the odd parity bit of bits 14 to 25; the second to the ninth bits are the site code; the 10th to the 25th bits are the card number.

To customize Wiegand format, proceed as follows:

- 1) Select [Define Format] and the [Set] key is then enabled.
- 2) Press [Set] to display the [User Define Format] interface, as shown in the following figure:



- 3) Click the entry box below "Card Format" to display the following interface:



Characters used to define data bits and their meanings:

c: indicates the card number, that is, the output contents, it can be set to User ID/Card Number through menu operations.

f: indicates the facility code which is 0 by default. It is not configurable. To modify it, please contact the equipment supplier.

m: indicates the manufacturer code which is 0 by default. It is not configurable. To modify it, please contact the equipment supplier.

p: indicates the parity position.

s: indicates the site code which can be set from 0 to 255 by default.

4) Click the entry box below "Parity Format" to display the following interface:

Characters used to define parity bits and their meanings:



o: indicates the odd check, that is, there is an odd number of 1's in the bit sequence (including one parity bit). For example, for 1000110(0), the parity bit is 0 and there are already three 1's. After 0 is suffixed to 1000110, there is still an odd number of 1's.

e: indicates the even check, that is, there is an even number of 1's in the bit sequence (including one parity bit). For example, for 1000110(1), the parity bit is 1 and there are already three 1's. After 1 is suffixed to 1000110, there is an even number of 1's.

Wiegand34

```
eee eeeeeeeeeeeeeeeoooooooooooooooooooo
```

Wiegand37a

Note: Wiegand37a consists of 37 bits. The first bit is the odd parity bit of bits 3, 4, 6, 7, 9, 10, 12, 13, 15, 16, 18, 19, 21, 22, 24, 25, 27, 28, 30, 31, 33, 34 and 36; the 37th bit is the odd parity bit of bits 2, 4, 5, 7, 8, 10, 11, 13, 14, 16, 17, 19, 20, 22, 23, 25, 26, 28, 29, 31, 32, 34 and 35; bits 4, 7, 10, 13, 16, 19, 22, 25, 28, 31 and 34 participate in both odd and even parity check. Bits 2 to 5 are manufacturer code; bits 6 to 17 are the site code; bits 18 to 36 are the card number.

Wiegand37

eee eee

bits are facilitate code; the 15 to the 20 bits are the site code; the 21 to the 36 bits are the card number.

Wiegand50

42

Parity bits:

eee eee

Note: Wiegand50 consists of 50 bits. The first bit is the even parity bit of bits 2 to 25; the 50 bit is the odd parity bit of bits 26 to 49; the second to the 16 bits are the site code; the 17 to the 49 bits are the card number.


www.BioTrackSoftware.com

5 SYSTEM CONFIGURATION

Through the [System] menu, you can set system-related parameters, including the basic parameters, interface parameters, fingerprint, facial and attendance parameters, to enable the terminal to meet user requirements to the greatest extent in terms of functions and display.



5.1 BASIC PARA METERS



Date/Time:

This parameter is used to set the date and time of the FFR terminal.

Date Format:

This parameter is used to set the format of the date displayed on the initial interface of the FFR terminal.

Keyboard Beep:

This parameter is used to set whether to generate beep sound in response to every keyboard touch. Select "ON" to enable the beep sound, and select "OFF" to mute.

Voice:

This parameter is used to set whether to play voice prompts during the operation of the FFR terminal. Select "ON" to enable the voice prompt, and select "OFF" to mute.

Volume (%):

This parameter is used to adjust the volume of voice prompts.

Power Key:

This parameter is used to set whether to lock the power key. Select "ON" to disable the power key. If you select "OFF" and press the power key, the FFR terminal will be shut down in three seconds.

www.BioTrackSoftware.com

5.2 INTERFACE PARAMETERS

Menu	System		Save
General	Language	▶ English	
Display	Display Style	▶ Full-Screen	
Fingerprint	Toolbar Style	▶ Auto Hide	
Face	Default Verify Mode	▶ Face	
Attendance	Picture Delay(S)	10	
Update	Sleep Time(S)	▶ 30	

Language:

This parameter is used to display the current language used by the FFR terminal. For multilingual-capable FFR terminals, you can switch between different languages through this parameter.

Display Style:

This parameter is used to set the time display mode of the initial interface. Select "ON" to adopt the 24-hour display mode. Select "OFF" to adopt the 12-hour display mode.

Toolbar Style:

This parameter is used to display style of the shortcut keys on the initial interface. It can be set to "Auto Hide" and "Permanent Display". By selecting "Auto Hide", you can manually display or hide the toolbar. By selecting "Permanent Display", you can permanently display the toolbar on the initial interface.

Default Verify Mode: This parameter is used to set the default verification mode, that is, the "Fingerprint" or "Face" verification mode.

Picture Delay (S): This parameter is used to set the picture cycle interval (value scope: 3-999 seconds).

Sleep Time (S): This parameter is used to specify a period after which the FFR terminal is put in sleep mode if not operated within this period. You can bring up the FFR terminal from sleep by pressing any key or touching the screen.

5.3 FINGERPRINT PARAMETERS

1: 1 Threshold:

This parameter is used to set the threshold of matching between current fingerprint and the fingerprint template enrolled in the FFR terminal in the 1:1 verification mode. If the similarity between current fingerprint and the fingerprint template enrolled in the FFR terminal is larger than this threshold, the matching is successful; otherwise, the matching is not successful.

1:N Threshold:

This parameter is used to set the threshold of matching between current fingerprint and the fingerprint template enrolled in the FFR terminal in the 1:N verification mode. If the similarity between current fingerprint and the fingerprint template enrolled in the FFR terminal is larger than this threshold, the matching is successful; otherwise, the matching is not successful.

The recommended thresholds are as follows:

Threshold		1: N	1:1
False Rejection Rate (FRR)			
False Acceptance Rate (FAR)			
High	- Low	45	25
Medium	- Medium	35	15
Low	- High	25	10

1:1 Retry Times: This parameter is used to set the retry times in the event of failure of 1:1 verification or password verification due to absence of fingerprint enrollment or improper finger placement, so as to avoid repetitive operations.

Algorithm Version: This parameter is used to select the fingerprint algorithm version between 9.0 and 10.0. Please select the algorithm version with caution because the fingerprint templates of these two algorithm versions are incompatible.

Fingerprint Image: This parameter is used to set whether to display the fingerprint image on the screen during fingerprint enrollment or comparison. It has two values: Permanent Display and No Display.

5.4 FACE PARAMETERS

Menu

System

Save

General	1:1 Threshold	60
Display	1:N Threshold	75
Fingerprint	Enroll Mode	► Combined Enroll
Face	Exposure	300
Attendance	Gain	100
Update	Quality	80

1:1 Threshold:

This parameter is used to set the threshold of matching between current face and the facial template enrolled in the FFR terminal in the 1:1 verification mode. If the similarity between current face and the facial template enrolled in the FFR terminal is larger than this threshold, the matching is successful; otherwise, the matching is not successful. The valid value scope is 55-120. The higher the threshold, the lower the FAR and the higher the FRR, and vice versa.

1:1:N Threshold:

This parameter is used to set the threshold of matching between current face and the facial template enrolled in the FFR terminal in the 1:N verification mode. If the similarity between current face and the facial template enrolled in the FFR terminal is larger than this threshold, the matching is successful; otherwise, the matching is not successful. The valid value scope is 65-120. The higher the threshold, the lower the FAR and the higher the FRR, and vice versa.

The recommended thresholds are as follows:

			1: N	1:1
Threshold False Rejection Rate (FRR)- False Acceptance Rate (FAR)				
High	-	Low	90	80
Medium	-	Medium	80	70
Low	-	High	75	75

Enroll Mode: This parameter is used to select the facial enrollment mode between "Combined Enroll" and "Face". In the "Combined Enroll" mode, users need to enroll their fingerprints or passwords after facial enrollment; in the "Face" mode, users only need to enroll their facial images. The "Face" mode is unavailable for the administrators because the "Combined Enroll" mode is mandatory for them by default.

Exposure: This parameter is used to set the exposure value of the camera.

Gain: This parameter is used to set the gain value of the camera.

Quality: This parameter is used to set a quality threshold for the facial images obtained. The FFR terminal accepts the facial images and processes them by adopting the facial algorithm when their quality is higher than the threshold; otherwise, it filters these facial images.

Note: Improper adjustment of the Exposure, Gain and Quality parameters may severely affect the performance of the FFR terminal. Please adjust the Exposure parameter only under the guidance of the after-sales service personnel from our company.

www.BioTrackSoftware.com

5.5 LOG SETTINGS

The screenshot shows the 'Settings' menu with a 'Log Settings' option highlighted in green. The 'Log Settings' screen displays four parameters: 'Log Alert' set to 99, 'Dup. Punch Period (m)' set to 0, 'Workcode Mode' set to None, and 'Card Only' set to NO. A 'Save' button is visible in the top right corner of the settings screen.

Menu	Settings	Save
General	Log Alert	99
Display	Dup. Punch Period (m)	0
Fingerprint	Workcode Mode	None
Face	Card Only	NO
Log Settings		
Update		

Log Alert: When the available space is insufficient to store the specified number of attendance records, the FFR terminal will automatically generate an alarm. (Value scope: 1-99)

Dup. Punch Period (m): If a user's attendance record already exists and the user punches in again within the specified period (unit: minute), his/her second attendance record will not be stored. (Value scope: 1-60 minutes)


Workcode Mode: This parameter is used to select the work code input mode among Mode 1, Mode 2 and None during attendance verification. If you select Mode 1, the attendance verification starts after you input the work code on the initial interface; if you select Mode 2, the attendance verification starts before you input the work code on the initial interface; if you select None, you do not need to input the work code during attendance verification on the initial interface. For the input of the work code.

Card Only: If this parameter is set to "YES", you pass the verification only after card verification. If this parameter is set to "NO", you need to verify your face or fingerprint after card verification.

5.6 UPDATE

You can upgrade the firmware program of the FFR terminal by using the upgrade file in the USB disk through this parameter.

If you need the firmware upgrade file, please contact our technical support personnel. Generally the firmware upgrade is not recommended.



6 DATA MANAGEMENT

Through the [Data Mgt.] menu, you can perform management of data stored on the FFR terminal, for example, deleting the attendance record, all data and promotional pictures, purging management rights and resetting the FFR terminal to factory defaults.



Delete Transactions: Delete all the attendance records.

Delete All Data: Delete all the information of enrolled personnel, including their fingerprints, facial images and attendance records.

Clear Administrator: Change all administrators to ordinary users.

Delete Picture: Purge the promotional pictures uploaded from USB disks to the FFR terminal.

Restore to Factory Settings: Restore all parameter settings on the FFR terminal to factory settings.

Record: Query the attendance records of employees within a specified time range.

WorkCode: Add, edit or delete the work codes of employees.

The employee information and attendance records will not be deleted during restoration to factory

6.1 QUERY A RECORD

After check-in successfully, the employee's attendance records are saved in the FFR terminal. You can easily query these attendance records.

User ID: Enter the user ID of the employee to query. If this field is left blank, you can query the attendance records of all the employees. If you enter a user ID, you can query the attendance record of the employee with this user ID.

Query Time Period: Select a time period to query, including the customized time period, yesterday, this week, last week, this month, last month, and all time periods.

Date	Att Log	User ID	Name	Time
01/10	11:12	11:12	11:12	11:12
	11:11	11:11	11:11	11:11
	11:11	11:11	11:10	11:10
01/19	11:12	11:12	11:00	11:00
	11:08	11:07		

Start and End: When you select a customized time period, you need to input a start time and an end time. When you select other options for time period, the start and end time will be automatically adjusted to the related time.

After setting the query conditions, press [Query] and the records that meet the specified query conditions will be displayed on screen.


Select the row where the desired record is located, you can query the detailed information of this record, for example, the detailed attendance record of the employee with user ID

2 on January 7

User ID	Name	Time	WorkCode
9	Linda	01-19 11:12	0
9	Linda	01-19 11:12	0
9	Linda	01-19 11:12	0
9	Linda	01-19 11:00	0
9	Linda	01-19 11:08	0
9	Linda	01-19 11:08	0
9	Linda	01-19 11:08	0
9	Linda	01-19 11:08	0

6.2 WORK CODE

Employees' salaries are subject to their attendance records. Employees may be engaged in different types of work which may vary with time periods. Considering the salaries vary with work types, the FFR terminal provides a parameter to indicate the corresponding work type for every attendance record to facilitate rapid understanding of different attendance situations during the handling of attendance data.



1. Add a work code


1) Press [Add] on the [WorkCode] interface (as shown in Figure 1 on the right) to display the [Add] interface. No.: A digital code of the work code.

Label: The meaning of the work code.




2) Press the corresponding entry button of [No.] on the [Add] interface (as shown in Figure 2 on the right) to display the No. entry interface. On this interface, enter a No.

3) Press the corresponding entry button of [Label] on the [WorkCode] interface (as shown in Figure 3 on the right) to display the text entry interface. On this interface, enter a label of work code.



2. Edit and delete a work code


1) Press the row of a work code on the [WorkCode] interface (as shown in Figure 1 on the right) to display the [Edit] interface.



2) To edit this work code, enter a new No. and label with the same operation steps as described in "Add a work code".



3) To delete this work code, press [Delete] (as shown in Figure 3 on the right).



4) On the displayed prompt interface, press <YES> to confirm the deletion of this work code, and press <NO> to cancel the deletion operation (as shown in Figure 4 on the right).




7 USB DISK MANAGEMENT

Through the [Dn/Upload] menu, you can import user information and attendance data stored in a USB disk to related software or other fingerprint recognition equipment.



Download Transactions: Import all the attendance data from the FFR terminal to a USB disk.



Download User: Import all the user information, fingerprints and facial images from the FFR terminal to a USB disk.

Download user photos: Import the employees' photos from the FFR terminal to a USB disk.

Only several types of the FFR terminals support the download of user photos.

Upload User: Upload the user information, fingerprints and facial images stored in a USB disk to the FFR terminal.

Upload User Photo: Upload the JPG documents that are named after the user IDs and stored in a USB disk to the FFR terminal, so that user photos can be displayed after the employees pass the verification. See Appendix 4 Photo ID Function.

Upload Picture: Upload the JPG documents with “ad_” as initial letters of document names stored in a USB disk to the FFR terminal. After the upload, these pictures can be displayed on the initial interface of the FFR terminal. (For details on picture specifications, see Appendix 2.)


www.BioTrackSoftware.com

8 KEYBOARD DEFINITIONS

You can define six shortcut keys as attendance status shortcut keys or functional shortcut keys. On the main interface of the FFR terminal, press corresponding keys and the attendance status will be displayed or the function interface will be rapidly displayed.



1. Press [Keyboard] on the main menu interface to display the [Keyboard] interface, as shown in Figure 1 on the right.



2. All the defined shortcut keys and their functions are listed on the [Keyboard] interface (as shown in Figure 2 on the right). Press [Add] to display the shortcut key adding interface. Press a shortcut key in the list to display the shortcut key editing interface.



3. Add and edit the functional introduction of Interface



Shortcut Key: Options include: F1–F6.

Note: When the FFR terminal supports both fingerprint and face recognition modes, F6 is defined as a recognition mode switch key by default and cannot be modified.

Function: You can set the functions of different shortcut keys, such as functional shortcut keys, attendance status shortcut key and work code shortcut key.

Functional shortcut status include: 1:1/1:G, Face Group No.1, Face Group No.2, Face Group No.3, Face Group No.4 and Face Group No.5. The setting interface is shown in Figure 3 on the right.




The status shortcut keys include: Check-In, Check-Out, Leave, Back, Overtime Check-In, and Overtime Check-Out. The setting interface is shown in Figure 4 on the right. When setting the attendance status shortcut keys, you can also set the “Auto Switch” parameter. When “Auto Switch” is enabled, the FFR terminal automatically switches the attendance status at the specified time. The “Auto Switch” setting interface is as shown in Figure 5 on the right.



The work code shortcut key setting interface is as shown in Figure 6 on the right.

9 AUTO TEST

The auto test enables the system to automatically test whether functions of various modules are normal, including the screen, collector, voice, facial, keyboard and clock tests.



Screen Test: The FFR terminal automatically tests the display effect of the color TFT display by displaying full color, pure white and pure black and checks whether the screen displays properly. You can continue the test by touching the screen or exit it by pressing [Auto Test].

Voice Test: The FFR terminal automatically tests whether the voice files are complete and the voice quality is good by playing the voice files stored in the terminal. You can continue the test by touching the screen or exit it by pressing [Auto Test].

Keyboard Test: The FFR terminal tests whether every key on the keyboard works normally. Press any key on the [Keyboard Test] interface to check whether the pressed key matches the key displayed on screen. The keys are dark-gray before pressed, and turn blue after pressed. Press [Auto Test] to exit the test.

Fingerprint Test: The FFR terminal automatically tests whether the fingerprint collector works properly by checking whether the fingerprint images are clear and acceptable. When the user places his/her finger in the fingered guide, the collected fingerprint image is displayed on the screen in real-time. Press [Auto Test] to exit the test.

Face Test: The FFR terminal automatically tests whether the camera works properly by checking whether the collected facial images are clear and acceptable. Press [Auto Test] to exit the test.

Time Test: The FFR terminal tests whether its clock works properly by checking the stopwatch of the clock. Touch the screen to start counting, and touch it again to stop to check whether the counting is accurate. Press [Auto Test] to exit the test.

www.BioTrackSoftware.com

10 SCREEN CALIBRATION

You can perform all the menu operations by touching the screen with one of your fingers or a touch pen. When the touch screen is less sensitive to the touch, you can perform screen calibration through menu operations.



1. Press [Menu] on the initial interface to display the main menu interface.
2. Press [Calibration] on the main menu interface to display the screen calibration interface.



3. Touch the center of the cross "+".
4. Repeat Step 3 following the move of the "+" icon to different locations on the screen.

Calibrating screen, pls wait.....

5. Touch the center of the cross at five locations on the screen correctly. When the message "Calibrating screen, pls wait....." is displayed on screen, the calibration succeeds and the system automatically returns to the main menu.

If the calibration fails, the system will request recalibration starting from Step 3.


11 BELL SETTING

Lots of companies need to ring their bells to signal the start and end of work shifts, and they usually manually ring their bells or use electric bells. To lower costs and facilitate man agement, we integrate the time bell function into the FFR terminal. You can set the alarm time and duration for ringing the bell based on your requirements, so that the FFR terminal will automatically p lay the selected ring tone and trigger the rela y at the alarm time, and stop playing the ring tone after the set duration.



Press [Bell] on the main menu interface to display the bell setting interface, as shown in Figure 1 on the right.

1. Add a bell
 - 1) The displayed bell setting interface (as shown in Figure 2 on the right) lists all the bells. Click [Add] to display the [Add] interface.



- 2) On the [Add] interface, set the following



parameters:

Bell Time: This parameter is used to set a time point when the FFR terminal automatically plays a bell ring tone everyday.

Ring Tone: This parameter is used to set the bell ring tone.

Volume: This parameter is used to set the volume of ring tone.

Repeat: This parameter is used to set the alarm times.

State: This parameter is used to set whether to enable the bell.

Bell Type: You can select between internal ringing or external ringing. For internal ringing, the ring tone is played by the loudspeaker of the FFR terminal.

For external ringing, the ring tone is played by an external electric bell that is wired with the FFR terminal.

The alarm sounds of the bell and the access control cannot be concurrently generated by the loudspeaker of the FFR terminal or externally connected relay. Therefore, when the bell is set to the external ringing mode, the access limit alarm will automatically change to the internal ringing mode, and vice versa.

2. Edit and delete a bell

Press a bell in the list on the bell setting interface to display the [Edit] interface, with the similar operation as "Add a bell".




Press [Delete] on the [Edit] interface and the system displays a prompt window as shown in the figure on the right. In the prompt window, press <YES> to delete the current bell and <NO> to cancel the deletion.



12 ACCESS CONTROL SETTING

Through the [Access] menu, you can set the parameters of the electronic locks and related access control devices.



Lock Delay: indicates the duration for the FFR terminal to place the electric lock in open state. (Value scope: 1–10 seconds)

DoorSensor Delay: indicates the delay in checking the door sensor after the door is open. If door sensor state is inconsistent with the normal state set by the door sensor switch, an alarm will be generated, and this period of time is regarded as the "door sensor delay". (Value scope: 1-99 seconds)

DoorSensor Mode: includes the None, Normally Open (NO), and Normally Closed (NC) modes. "None" indicates that the door sensor switch is not used. "NO" indicates that the door sensor is open in the normal state. "NC" indicates that the door sensor is closed in the normal state.

Alarm Delay: indicates the duration from the detection of door sensor exceptions to the generation of alarm signals. (Value scope: 1-99 seconds)

13 DATE/TIME SETTING

13.1 SET DATE/TIME

The date and time of the FFR terminal must be set accurately to ensure the accuracy of attendance time.



1. Press [Menu] on the initial interface to display the main menu interface.



2. Press [Time/Date] on the main menu interface to display the time setting interface.



3. Select the desired date and time by pressing or , or enter the related values into the date and time entry boxes through the keyboard (as shown in Figures 3 and 4 on the right).
4. Press [Save] to save current information and return to the previous interface. Press [Cancel] to return to the previous interface without saving current information.



13.2 SET DAYLIGHT SAVING TIME (DST)

The Daylight Saving Time (DST) is a widely used system of adjusting the official local time forward to save energy. The uniform time adopted during the implementation of this system is known as the DST. Typically clocks are adjusted forward one hour in the summer to make people early to bed and early to rise so as to make full use of illumination resources and save electricity. Clocks are adjusted backward in autumn. The specific DST regulations vary with countries.



To meet the DST requirement, the FFR terminal supports the DST function to adjust forward one hour at $\times\times$ (Hour): $\times\times$ (Minute) $\times\times$ (Day) $\times\times$ (Month) and backward one hour at $\times\times$ (Hour): $\times\times$ (Minute) $\times\times$ (Day) $\times\times$ (Month).

1. Press [Menu] on the initial interface to display the main menu interface.



2. Press [Time/Date] on the main menu interface to display the time setting interface.



3. Press [DLST] on the time setting interface to display the DST setting interface.

4. Set the following parameters on the DST setting interface:

DST Settings: This parameter is used to enable or disable the DST.

Mode: You can select between Mode 1 and Mode 2. In Mode 1 (the default mode), the DST is set in the "Month-Day Hour: Minute" format; in Mode 2, the DST is set in the "Month-Week-Day Hour: Minute" format.

The value scope of week (WS): 1 – 6. 1 means the first week, 2 the second week and so on and so forth. The value scope of day (WK): 0 – 6. 0 means Sunday, 1 means Monday and so on and so forth.



Start and End: These two parameters are respectively used to set the start and end time of the DST.

For example, adjust the clock forward one hour at 08: 00 on April 1, and backward one hour at 08: 00 on October 15. After setting the DST, press [Done] to return to the time setting interface.

Press [Save] on the time setting interface to save current settings and return to the previous interface; press [Cancel] to directly return to previous interface without saving current information.




14 SYSTEM INFORMATION

You can check the storage status as well as version information of the FFR terminal through the [System Information] option.



14.1 RECORDS

The number of enrolled users, administrators and passwords is displayed on the [Records] interface; the total fingerprint storage capacity and occupied capacity as well as the total attendance storage capacity and occupied capacity are graphically displayed respectively, as shown in the following figure:



14.2 TERMINAL


The terminal name, serial number, version information, vendor and date of manufacture are displayed on the [Terminal] interface.

15 APPENDIX

15.1 TEXT INPUT INSTRUCTIONS


The FFR terminal supports the input of Chinese and English characters, numbers and symbols. Press related button to input text. For example, press [Name] to display the text input interface, as shown in the following figure:

www.BioTrackSoftware.com



To enter a name, proceed as follows:

1. Press [Name] on the [Add] interface, as shown in Figure 1 on the right.



2. Enter the Pinyin characters, and a list of Chinese characters in relation to the Pinyin is presented in the text display area, as shown in Figure 2 on the right.



3. If the desired character is displayed in the text display area, press this character. And this character is at the same time displayed on the [Name] button, as shown in Figure 3 on the right.

Enter next character by repeating Step



4. After finishing the entry of name, press [X] to exit keyboard interface and return to the previous interface.

15.2 RULES FOR UPLOADING PROMOTIONAL PICTURES

1. All pictures must be in JPG format as other formats are not supported.
2. The file name of a promotional picture must be ad_0 - ad_9. For example, ad_1.jpg is a valid file name.
3. After a picture is uploaded to the FFR terminal, its name does not change. To replace this picture, you need to upload a new picture with the same file name to overwrite it.
4. The size of each picture cannot exceed 20K; otherwise, the upload will be unsuccessful.
5. The recommended resolution of the picture is 320×240 . Pictures with resolution higher or lower than 320×240 are not recommended.
6. A maximum of 10 promotion pictures can be uploaded.

15.3 INTRODUCTION TO WIEGAND

Wiegand26 is an access control standard protocol established by the Access Control Standard Subcommittee affiliated to the Security Industry Association (SIA). It is a non-contact IC card reader interface and output protocol.

Wiegand26 defines the interface between the card reader and controller used in the access control, security and other related industrial fields. Wiegand26 helps standardize the work of the card reader designers and controller manufacturers. The access control products manufactured by our company are also designed by following this protocol.

Digital Signals

Figure 1 is a sequence diagram in which the card reader sends digital signals in bit format to the access controller. In this sequence diagram, Wiegand follows the SIA's access control standard protocol for the 26-bit Wiegand card reader (one pulse time ranges between 20us and 100us, and the pulse jump time ranges between 200us and 20ms). Data1 and Data0 are high level (larger than V_{oh}) signals till the card

reader prepares to send a data stream. The asynchronous low-level pulse (smaller than V_{ol}) generated by the card reader is sent to the access control panel (The saw-tooth wave as shown in Figure 1) through Data1 or Data0. Data1 and Data0 pulses will neither overlap nor be generated synchronously. Table 1 lists the maximum and minimum pulse width (a consecutive pulse) and pulse jump time (time between pulses) allowed by the F series fingerprint access control terminal.

Table 1 Pulse Time

Symbol	Definition	Typical Value of Reader
Tpw	Pulse Width	100 μ s
Tpi	Pulse Interval	1 ms





Figure 1 Sequence Diagram

15.4 PHOTO ID FUNCTION

Some FFR terminals also support the Photo ID function. The Photo ID function is used to display the photo enrolled by a user or stored in a USB disk on the screen in addition to such information as the user ID and name.



[Operation Steps]

1. When the photo taken by the FFR terminal is used, the photo can be displayed upon successful verification.
2. To use a photo stored in a USB disk, proceed as follows:
 - 1) Create a folder with the name of "photo" in the USB disk, and store users' photos under this folder.
 - 2) The user photos must be in JPG format and named after their IDs. For example, for the user with user ID of 154, the photo name must be 154.jpg.
 - 3) Insert the USB disk into USB slot on the FFR terminal, and select USB Disk Management -> Upload -> Upload Photos. Then user photos can be displayed upon successful verification.

Note:

- 1) The length of a user name cannot exceed 24 digits.
- 2) The recommended size of a user photo is less than 30K.
- 3) The uploaded new user photo will overwrite the existing photo in related to the user ID.
- 4) To download user photos, select USB Disk Management -> Download -> Down load User Photos. A folder with the name of "photo" will be automaticall y created on the USB disk, and all downloaded user photos are stored under this folder.

15.5 ATTENDANCE STATUS SELECTION FUNCTION

Some FFR terminals also support the attendance status selection function which requires users to select attendance status prior to verification. If verification is performed without selection of the attendance status, the record is "No Work Status", that is, the record is not used as the attendance record, as shown in the following figure:

