



# **Dialogic® AG 2000C CompactPCI Media Board Installation and Developer's Manual**

## Copyright and legal notices

---

Copyright © 2001-2009 Dialogic Corporation. All Rights Reserved. You may not reproduce this document in whole or in part without permission in writing from Dialogic Corporation at the address provided below.

All contents of this document are furnished for informational use only and are subject to change without notice and do not represent a commitment on the part of Dialogic Corporation or its subsidiaries ("Dialogic"). Reasonable effort is made to ensure the accuracy of the information contained in the document. However, Dialogic does not warrant the accuracy of this information and cannot accept responsibility for errors, inaccuracies or omissions that may be contained in this document.

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH DIALOGIC® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN A SIGNED AGREEMENT BETWEEN YOU AND DIALOGIC, DIALOGIC ASSUMES NO LIABILITY WHATSOEVER, AND DIALOGIC DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF DIALOGIC PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY INTELLECTUAL PROPERTY RIGHT OF A THIRD PARTY.

Dialogic products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or in nuclear facility applications.

Due to differing national regulations and approval requirements, certain Dialogic products may be suitable for use only in specific countries, and thus may not function properly in other countries. You are responsible for ensuring that your use of such products occurs only in the countries where such use is suitable. For information on specific products, contact Dialogic Corporation at the address indicated below or on the web at [www.dialogic.com](http://www.dialogic.com).

It is possible that the use or implementation of any one of the concepts, applications, or ideas described in this document, in marketing collateral produced by or on web pages maintained by Dialogic may infringe one or more patents or other intellectual property rights owned by third parties. Dialogic does not provide any intellectual property licenses with the sale of Dialogic products other than a license to use such product in accordance with intellectual property owned or validly licensed by Dialogic and no such licenses are provided except pursuant to a signed agreement with Dialogic. More detailed information about such intellectual property is available from Dialogic's legal department at 9800 Cavendish Blvd., 5th Floor, Montreal, Quebec, Canada H4M 2V9. Dialogic encourages all users of its products to procure all necessary intellectual property licenses required to implement any concepts or applications and does not condone or encourage any intellectual property infringement and disclaims any responsibility related thereto. These intellectual property licenses may differ from country to country and it is the responsibility of those who develop the concepts or applications to be aware of and comply with different national license requirements.

Any use case(s) shown and/or described herein represent one or more examples of the various ways, scenarios or environments in which Dialogic® products can be used. Such use case(s) are non-limiting and do not represent recommendations of Dialogic as to whether or how to use Dialogic products.

Dialogic, Dialogic Pro, Brooktrout, Diva, Cantata, SnowShore, Eicon, Eicon Networks, NMS Communications, NMS (stylized), Eiconcard, SIPcontrol, Diva ISDN, TruFax, Exnet, EXS, SwitchKit, N20, Making Innovation Thrive, Connecting to Growth, Video is the New Voice, Fusion, Vision, PacketMedia, NaturalAccess, NaturalCallControl, NaturalConference, NaturalFax and Shiva, among others as well as related logos, are either registered trademarks or trademarks of Dialogic Corporation or its subsidiaries. Dialogic's trademarks may be used publicly only with permission from Dialogic. Such permission may only be granted by Dialogic's legal department at 9800 Cavendish Blvd., 5th Floor, Montreal, Quebec, Canada H4M 2V9. Any authorized use of Dialogic's trademarks will be subject to full respect of the trademark guidelines published by Dialogic from time to time and any use of Dialogic's trademarks requires proper acknowledgement.

Windows is a registered trademark of Microsoft Corporation in the United States and/or other countries. The names of actual companies and product mentioned herein are the trademarks of their respective owners.

This document discusses one or more open source products, systems and/or releases. Dialogic is not responsible for your decision to use open source in connection with Dialogic products (including without limitation those referred to herein), nor is Dialogic responsible for any present or future effects such usage might have, including without limitation effects on your products, your business, or your intellectual property rights.

## Revision History

| Revision                          | Release date  | Notes                           |
|-----------------------------------|---------------|---------------------------------|
| 9000-60089-10                     | June 2001     | SRG                             |
| 9000-60089-11                     | August 2001   | SRG                             |
| 9000-60089-12                     | November 2001 | MVH                             |
| 9000-60089-13                     | May 2002      | NBS, Natural Access 2002-1      |
| 9000-60089-14                     | November 2002 | MVH, Natural Access 2003-1 Beta |
| 9000-60089-15                     | April 2003    | MVH, Natural Access 2003-1      |
| 9000-60089-16                     | April 2004    | SRG, Natural Access 2004-1      |
| 64-0489-01                        | October 2009  | LBG, NaturalAccess R9.0         |
| Last modified: September 12, 2009 |               |                                 |

Refer to [www.dialogic.com](http://www.dialogic.com) for product updates and for information about support policies, warranty information, and service offerings.



# Table Of Contents

|   |           |
|---|-----------|
| <b>Chapter 1: Introduction .....</b>                          | <b>9</b>  |
| <b>Chapter 2: Terminology .....</b>                           | <b>11</b> |
| <b>Chapter 3: Overview of the AG 2000C board .....</b>        | <b>13</b> |
| AG 2000C board features .....                                 | 13        |
| Software components .....                                     | 15        |
| Natural Access .....  | 16        |
| NMS OAM .....   | 16        |
| Configuration files .....                                     | 17        |
| Runtime software .....  | 18        |
| Trunk control programs (TCPs) .....                           | 18        |
| <b>Chapter 4: Installing the hardware .....</b>               | <b>19</b> |
| Installation summary .....                                    | 19        |
| AG driver software .....                                      | 19        |
| System requirements .....                                     | 20        |
| Keying the chassis .....                                      | 20        |
| Installing the board .....                                    | 23        |
| Using the Hot Swap features .....                             | 24        |
| Connecting to the telephone network .....                     | 25        |
| Ferrite block .....   | 27        |
| Developer's cable kit .....                                   | 28        |
| <b>Chapter 5: Configuring the board .....</b>                 | <b>29</b> |
| Adding board configurations to the NMS OAM database .....     | 29        |
| Configuring and starting the system with oamsys .....         | 30        |
| Using board keyword files .....                               | 30        |
| Creating a system configuration file for oamsys .....         | 32        |
| Sample system configuration file .....                        | 33        |
| Running oamsys .....  | 33        |
| Changing configuration parameter settings .....               | 34        |
| .leo files .....  | 34        |
| Specifying configuration file locations .....                 | 34        |
| QSLAC files and trunk control programs .....                  | 35        |
| Naming conventions for QSLAC files .....                      | 35        |
| Trunk control programs .....                                  | 36        |
| QSLAC files and TCPs for loop start .....                     | 36        |
| Configuring board clocking .....                              | 36        |
| AG 2000C clocking capabilities .....                          | 37        |
| Clock configuration methods .....                             | 39        |
| Configuring AG 2000C boards using board keywords .....        | 39        |
| Multiple board system example .....                           | 41        |
| Enabling echo cancellation .....                              | 42        |
| <b>Chapter 6: Verifying the installation .....</b>            | <b>43</b> |
| Status indicator LEDs .....                                   | 43        |
| Verifying board installation .....                            | 44        |
| Retrieving AG board configuration information: boardinf ..... | 44        |
| Interactive test program: ctatest .....                       | 45        |

|   |           |
|---|-----------|
| Using swish for a standalone board .....              | 45        |
| Using ctatest with an AG 2000C loop start board ..... | 46        |
| Demonstration programs .....                          | 47        |
| <b>Chapter 7: AG 2000C switching .....</b>            | <b>49</b> |
| AG 2000C switch model .....                           | 49        |
| H.110 streams .....                                   | 49        |
| Local streams .....                                   | 49        |
| Switch model .....                                    | 50        |
| Lucent T8100A switch blocking .....                   | 50        |
| Signaling modules and logical timeslots .....         | 51        |
| Default connections .....                             | 51        |
| <b>Chapter 8: Configuration parameters .....</b>      | <b>53</b> |
| Using the Switching service .....                     | 53        |
| Function information .....                            | 53        |
| Line gain configuration .....                         | 54        |
| Getting the line gain .....                           | 54        |
| Setting the line gain .....                           | 56        |
| <b>Chapter 9: Keyword summary .....</b>               | <b>59</b> |
| Using keywords .....                                  | 59        |
| Setting keyword values .....                          | 60        |
| Retrieving keyword values .....                       | 60        |
| Editable keywords .....                               | 61        |
| Informational keywords .....                          | 62        |
| Retrieving board information .....                    | 62        |
| Retrieving EEPROM information .....                   | 62        |
| Retrieving board driver information .....             | 63        |
| Plug-in keywords .....                                | 63        |
| <b>Chapter 10: Keyword reference .....</b>            | <b>65</b> |
| Using the keyword reference .....                     | 65        |
| AutoStart .....                                       | 66        |
| AutoStop .....  | 67        |
| Boards[x] .....                                       | 68        |
| BootDiagnosticLevel .....                             | 69        |
| Buffers[x].Num .....                                  | 72        |
| Buffers[x].Size .....                                 | 73        |
| Clocking.HBus.AutoFallBack .....                      | 74        |
| Clocking.HBus.ClockMode .....                         | 76        |
| Clocking.HBus.ClockSource .....                       | 77        |
| Clocking.HBus.FallBackClockSource .....               | 78        |
| Clocking.HBus.NetRefSource .....                      | 79        |
| Clocking.HBus.NetRefSpeed .....                       | 80        |
| Clocking.HBus.Segment .....                           | 81        |
| DLMFiles[x] .....                                     | 82        |
| DSP.C5x.Lib .....                                     | 83        |
| DSP.C5x.Loader .....                                  | 84        |
| DSP.C5x[x].Files[y] .....                             | 85        |
| DSP.C5x[x].Image .....                                | 88        |
| DSP.C5x[x].Os .....                                   | 89        |
| Echo.AutoSwitchingRefSource .....                     | 90        |

|  |            |
|--|------------|
| Echo.EnableExternalPins.....                                   | 91         |
| LoadFile .....   | 92         |
| LoadSize .....   | 93         |
| Location.PCI.Bus .....   | 94         |
| Location.PCI.Slot.....   | 95         |
| MaxChannels .....  | 96         |
| Name .....   | 97         |
| NetworkInterface.Analog[x].ConfigFile.....                     | 98         |
| Number .....   | 99         |
| Products[x] .....  | 100        |
| RunFile .....  | 101        |
| SignalIdleCode.....  | 102        |
| SwitchConnections .....  | 103        |
| SwitchConnectMode.....   | 104        |
| TCPFiles[x].....   | 105        |
| Version.Major .....  | 106        |
| Version.Minor .....  | 107        |
| VoiceIdleCode.....   | 108        |
| Xlaw.....  | 109        |
| <b>Chapter 11: Hardware specifications .....</b>               | <b>111</b> |
| General hardware specifications .....                          | 111        |
| Mechanical specifications .....                                | 111        |
| H.110 compliant interface.....                                 | 111        |
| Host interface .....   | 112        |
| Environment.....   | 112        |
| Power requirements.....  | 112        |
| Common electrical specifications (United States version) ..... | 113        |
| High impedance recording and caller ID mode .....              | 114        |
| QSLAC files and impedances .....                               | 114        |
| Compliance and regulatory certification .....                  | 115        |
| EMC .....  | 115        |
| Safety.....  | 115        |
| Telecom .....  | 115        |
| EU R&TTE statement.....  | 115        |
| <b>Chapter 12: Managing resources .....</b>                    | <b>117</b> |
| Functions for managing resources.....                          | 117        |
| Default functions .....  | 117        |
| Custom functions.....  | 118        |
| DSP/task processor files and processing power.....             | 119        |
| AG 2000C board processing .....                                | 126        |
| <b>Chapter 13: Loop start signaling .....</b>                  | <b>127</b> |
| Signaling overview .....                                       | 127        |
| Loop start transmit signaling.....                             | 128        |
| Loop start receive signaling .....                             | 129        |
| <b>Chapter 14: Natural Access migration .....</b>              | <b>131</b> |
| Migration overview .....                                       | 131        |
| NMS OAM.....   | 131        |
| Configuration file changes .....                               | 131        |
| Keyword changes .....  | 132        |





---

# 1

## Introduction

---

The *Dialogic® AG 2000C CompactPCI Media Board Installation and Developer's Manual* explains how to configure and install an AG 2000C board, and how to verify that it has been installed correctly and is operating correctly. It also provides general information about developing an application that uses the AG 2000C board.

This manual targets developers of telephony and voice applications who are using the AG 2000C board with Natural Access. This manual defines terms where applicable, but assumes that readers are familiar with telephony concepts, switching, and the C programming language.



# 2

## Terminology

**Note:** The product to which this document pertains is part of the NMS Communications Platforms business that was sold by NMS Communications Corporation (“NMS”) to Dialogic Corporation (“Dialogic”) on December 8, 2008. Accordingly, certain terminology relating to the product has been changed. Below is a table indicating both terminology that was formerly associated with the product, as well as the new terminology by which the product is now known. This document is being published during a transition period; therefore, it may be that some of the former terminology will appear within the document, in which case the former terminology should be equated to the new terminology, and vice versa.

| Former terminology            | Dialogic terminology  |
|-------------------------------|---|
| CG 6060 Board                 | Dialogic® CG 6060 PCI Media Board                             |
| CG 6060C Board                | Dialogic® CG 6060C CompactPCI Media Board                     |
| CG 6565 Board                 | Dialogic® CG 6565 PCI Media Board                             |
| CG 6565C Board                | Dialogic® CG 6565C CompactPCI Media Board                     |
| CG 6565e Board                | Dialogic® CG 6565E PCI Express Media Board                    |
| CX 2000 Board                 | Dialogic® CX 2000 PCI Station Interface Board                 |
| CX 2000C Board                | Dialogic® CX 2000C CompactPCI Station Interface Board         |
| AG 2000 Board                 | Dialogic® AG 2000 PCI Media Board                             |
| AG 2000C Board                | Dialogic® AG 2000C CompactPCI Media Board                     |
| AG 2000-BRI Board             | Dialogic® AG 2000-BRI Media Board                             |
| NMS OAM Service               | Dialogic® NaturalAccess™ OAM API                              |
| NMS OAM System                | Dialogic® NaturalAccess™ OAM System                           |
| NMS SNMP                      | Dialogic® NaturalAccess™ SNMP API                             |
| Natural Access                | Dialogic® NaturalAccess™ Software                             |
| Natural Access Service        | Dialogic® NaturalAccess™ Service                              |
| Fusion                        | Dialogic® NaturalAccess™ Fusion™ VoIP API                     |
| ADI Service                   | Dialogic® NaturalAccess™ Alliance Device Interface API        |
| CDI Service                   | Dialogic® NaturalAccess™ CX Device Interface API              |
| Digital Trunk Monitor Service | Dialogic® NaturalAccess™ Digital Trunk Monitoring API         |
| MSPP Service                  | Dialogic® NaturalAccess™ Media Stream Protocol Processing API |
| Natural Call Control Service  | Dialogic® NaturalAccess™ NaturalCallControl™ API              |
| NMS GR303 and V5 Libraries    | Dialogic® NaturalAccess™ GR303 and V5 Libraries               |

| <b>Former terminology</b>                  | <b>Dialogic terminology</b>                              |
|--|--|
| Point-to-Point Switching Service           | Dialogic® NaturalAccess™ Point-to-Point Switching API    |
| Switching Service                          | Dialogic® NaturalAccess™ Switching Interface API         |
| Voice Message Service                      | Dialogic® NaturalAccess™ Voice Control Element API       |
| NMS CAS for Natural Call Control           | Dialogic® NaturalAccess™ CAS API                         |
| NMS ISDN                                   | Dialogic® NaturalAccess™ ISDN API                        |
| NMS ISDN for Natural Call Control          | Dialogic® NaturalAccess™ ISDN API                        |
| NMS ISDN Messaging API                     | Dialogic® NaturalAccess™ ISDN Messaging API              |
| NMS ISDN Supplementary Services            | Dialogic® NaturalAccess™ ISDN API Supplementary Services |
| NMS ISDN Management API                    | Dialogic® NaturalAccess™ ISDN Management API             |
| NaturalConference Service                  | Dialogic® NaturalAccess™ NaturalConference™ API          |
| NaturalFax                                 | Dialogic® NaturalAccess™ NaturalFax™ API                 |
| SAI Service                                | Dialogic® NaturalAccess™ Universal Speech Access API     |
| NMS SIP for Natural Call Control           | Dialogic® NaturalAccess™ SIP API                         |
| NMS RJ-45 interface                        | Dialogic® MD1 RJ-45 interface                            |
| NMS RJ-21 interface                        | Dialogic® MD1 RJ-21 interface                            |
| NMS Mini RJ-21 interface                   | Dialogic® MD1 Mini RJ-21 interface                       |
| NMS Mini RJ-21 to NMS RJ-21 cable          | Dialogic® MD1 Mini RJ-21 to MD1 RJ-21 cable              |
| NMS RJ-45 to two 75 ohm BNC splitter cable | Dialogic® MD1 RJ-45 to two 75 ohm BNC splitter cable     |
| NMS signal entry panel                     | Dialogic® Signal Entry Panel                             |

---

# 3

## Overview of the AG 2000C board

---

### AG 2000C board features

---

The AG 2000C board is part of the Alliance Generation family of telephony boards. It provides 8, 16, or 24 analog loop start interfaces with call control and switching in a single CompactPCI slot.

Refer to the NMS web site ([www.nmscommunications.com](http://www.nmscommunications.com)) for a list of available AG 2000C board configurations, for a list of countries where NMS has obtained approval for the AG 2000C board, and for product updates.

An AG 2000C board contains the following main features:

- DSP resources

Each board has four high-performance digital signal processors (DSPs). The following table provides information about the different AG 2000C models:

| Model       | Ports | Capabilities   |
|-------------|-------|--|
| AG 2000C-8  | 8     | Eight universal ports (Call control, IVR, fax, and VoIP).<br><b>Note:</b> Conferencing can be substituted for fax or VoIP. |
| AG 2000C-16 | 16    | Call control, switching, IVR, and fax or conferencing  |
| AG 2000C-24 | 24    | Call control and switching   |

IVR is defined as play or record and DTMF detection.

- CompactPCI bus connectivity

Each AG 2000C board is designed to reside in a single CompactPCI bus slot. Each board contains a 5 volt CompactPCI bus interface compliant with the *CompactPCI Specification PICMG 2.0 R2.1*. The CompactPCI interface is a 33 MHz, 32-bit target device.

- H.110 bus connectivity

The AG 2000C board fully supports the H.110 bus specification. The H.110 bus enables boards to share data and signaling information with other boards on the H.110 bus. For example, you can connect two or more AG 2000C boards for applications that perform trunk-to-trunk switching. You can add additional DSP resources, analog station interfaces, or loop start line interfaces using other AG boards. You can also use H.110 compatible products from other manufacturers with the AG 2000C board.

- Telephony bus switching

Switching for the AG 2000C board is implemented with the T8100A chip. The T8100A is a single chip that offers full support for the H.110 bus within the H.110 architecture providing access to all 4096 slots.

On the AG 2000C board, switch connections are allowed for up to 128 full duplex connections between local devices and the H.110 bus.

- Loop start line interface signaling modules

The AG 2000C board has two to six loop start line interface signaling modules which are circuits that connect a bidirectional transmission channel to separate receive and transmit channels. Each line interface signaling module has four ports. This allows you to monitor and control at least 8 channels of signaling information.

The loop start line interface signaling module replaces a telephone, modem, or fax machine at the end of a standard telephone line or PBX extension.

The loop start interface can also be a trunk interface to the telephone network. With loop start trunks, you may want to segregate incoming calls from outgoing calls to avoid collisions between the two.


Changing the interface model has no impact on applications that you have already written.

The loop start interface:


- Has very high tolerance to common mode power line interfaces.
- Detects loop current reversals and interruptions in the off-hook mode.
- Receives called party identification in some countries.
- Records calls in on-hook mode where permitted by regulations.

Do not change any of the settings on the line interface signaling modules or attempt to remove the modules. These settings are factory installed and tested.

The following illustration shows where various components are located on an AG 2000C board:



The following illustration shows the rear I/O transition board:



*Rear I/O transition board*


## **Software components**

---

AG 2000C boards require the following software components:

- Natural Access development environment that provides services for call control, voice store and forward, switching, and other functions.
- NMS OAM (Operations, Administration, and Maintenance) software and related utilities.
- Configuration files that describe how the board is set up and initialized.
- Runtime software that controls the AG 2000C board.
- One or more trunk control programs (TCPs) that enable applications to communicate with the telephone network using the signaling schemes (protocols) used on the trunk.

The following illustration shows how these software components relate to one another:



*Software components*

**Natural Access**

Natural Access is a complete software development environment for voice applications. It provides a standard set of functions grouped into logical services. Each service has a standard programming interface. For more information about standard and optional Natural Access services, refer to the *Natural Access Developer's Reference Manual*.

**NMS OAM**


NMS OAM manages and maintains telephony resources in a system. These resources include hardware components (including AG boards) and low-level board management software modules (such as clock management).

Using NMS OAM, you can:

- Create, delete, and query the configuration of a component
- Start, stop, and test a component
- Receive notifications from components



NMS OAM maintains a database containing records of configuration information for each component as shown in the following illustration. This information consists of parameters and values.



NMS OAM components

Each parameter and value is expressed as a keyword name and value pair (for example, AutoStart = NO). You can query the NMS OAM database for keyword values for any component. Keywords and values can be added, modified, or deleted.

To use NMS OAM or any related utility, ensure that the Natural Access Server (*ctdaemon*) is running. For more information about *ctdaemon*, refer to the *Natural Access Developer's Reference Manual*. For more information about NMS OAM, refer to the *NMS OAM System User's Manual*.

### AG board plug-in

NMS OAM uses the AG board plug-in software module to communicate with AG boards. The name of the AG plug-in is *agplugin.bpi*. This file must reside in the `\nms\bin` directory (or `/opt/nms/lib` for UNIX) for NMS OAM to load it when it starts up.

### Configuration files

NMS OAM uses two types of configuration files:

| File type            | Description   |
|----------------------|---|
| System configuration | Contains a list of boards in the system and the name of one or more board keyword files for each board.   |
| Board keyword        | Contains parameters to configure the board. These settings are expressed as keyword name and value pairs. |

Several sample board keyword files are installed with Natural Access. Each of these files configures the board to use a different protocol (for example, Wink Start or Off-Premises Station). You can reference these files in your system configuration file or modify them.

When you run the NMS OAM *oamsys* utility, it creates NMS OAM database records based on the contents of the specified system configuration file and board keyword files. *oamsys* directs NMS OAM to start the boards and configure them according to the specified parameters. For more information, refer to *Configuring and starting the system with oamsys* on page 30.

## Runtime software

---

The runtime software consists of runfiles and DSP files. The runfile is the basic low-level software that an AG board requires to operate. DSP files enable the AG on-board digital signal processors to perform certain tasks, such as DTMF signaling, voice recording, and playback.

Several runfiles and DSP program files are installed with Natural Access. Specify the files to use for your configuration in the board keyword file. Refer to *Using board keyword files* on page 30 for more information. When NMS OAM boots a board, the runfiles and DSP program files are transferred from the host into on-board memory. For more information about the DSP files shipped with Natural Access, refer to the *ADI Service Developer's Reference Manual*.

## Trunk control programs (TCPs)

---

AG 2000C boards are compatible with a variety of signaling schemes called protocols. To program an AG board for a specific protocol, a trunk control program (TCP) is loaded on the board. The TCP performs all of the signaling tasks to interface with the protocol used on the line.

Several different protocol standards are used throughout the world. These standards differ considerably from country to country. For these reasons, different TCPs are supplied with Natural Access for various protocols and country-specific variations.

You can load more than one TCP at a time for applications that support multiple protocols simultaneously. TCPs are specified in the configuration file and are downloaded to the board by *oamsys*. TCPs run on the board, relieving the host computer from the task of processing the protocol directly. For more information about TCPs, refer to the *NMS CAS for Natural Call Control Developer's Manual*.

---

# 4

## Installing the hardware

---

### Installation summary

---

The following table summarizes the procedure for installing the hardware and software components:

| Step | Description   |
|------|---|
| 1    | Ensure that your PC system meets the <i>system requirements</i> on page 20.   |
| 2    | Install the board into one of the computer's CompactPCI bus slots.  |
| 3    | Install Natural Access, which also installs the AG 2000C board driver and runtime software, and NMS CAS protocols. Select the country where NMS CAS protocols is installed. This configures loop start products for local compliance. For more information, refer to the <i>NMS CAS for Natural Call Control Developer's Manual</i> . |
| 4    | Add configuration information for each board to the NMS OAM database. For more information, refer to the <i>NMS OAM System User's Manual</i> .  |
| 5    | Direct the OAM service to start the boards. For more information refer to <i>Configuring and starting the system with oamsys</i> on page 30 and to the <i>NMS OAM System User's Manual</i> .  |
| 6    | Verify that the installation is operational.  |

**Note:** If your system is powered down, you can install the board before you install the software. It does not matter if you install the board or the software first.

The `BootDiagnosticLevel` keyword in the board keyword file determines the type of board diagnostic tests that take place when you boot the board. If a test fails, the test number is reported back as an error code. You must be running `oammon` to view diagnostic results. For more information about board level error messages, refer to the *NMS Board and Driver Errors Manual*.

### AG driver software

---

The following drivers for operating AG boards are installed with Natural Access software:

| Operating system | Driver names   |
|------------------|--|
| Windows          | <i>aghwwin2k</i><br><i>agwin2k</i>                         |
| UNIX             | <i>aghw</i><br><i>agsw</i><br><i>ag95sw</i><br><i>agmx</i> |
| Red Hat Linux    | <i>aghw.o</i>  |

## System requirements

---

To install and use AG 2000C boards, your system must have:

- Natural Access installed.
- A CompactPCI chassis with an H.110 compliant backplane and an available CompactPCI bus slot.

**Note:** The AG 2000C board can power up and function only in a chassis with a telephony backplane.

- A grounded chassis (with a three-prong power cord).

NMS recommends an uninterruptible power supply (UPS) for increased system reliability. The UPS does not need to power the PC video monitor except in areas prone to severe lightning storms.

## Keying the chassis

---

An AG 2000C has several mechanical interlocks, called keys, that prevent the board from being inserted in an incompatible chassis. Keying protects the board and other devices in the chassis from damage by ensuring that you will not accidentally insert an incompatible board in the chassis.

Before you install AG 2000C boards, configure the keying of your chassis to be compatible with the AG 2000C keying.

For detailed information on CompactPCI chassis keying, refer to the *CompactPCI Computer Telephony Specification PICMG 2.5 R1.0*, to *Keying of CompactPCI Boards and Backplanes PICMG 2.10 R1.0*, and to the *IEEE 1101.10*.


**Warning:**



To protect yourself and your equipment, use only qualified personnel to install keying. The personnel must be familiar with the *CompactPCI Computer Telephony Specification PICMG 2.5, R1.0* document.


**Note:** An AG 2000C board does not function in a chassis that does not have a telephony backplane.

The following illustration shows how the AG 2000C board keys are configured:



AG 2000C key configuration



The following illustration shows the keying chambers in a CompactPCI chassis that you must configure or verify for an AG 2000C board. You must also key rear panel keying chambers A through F that are not shown.



*Keying chamber locations on chassis front and backplane*

Chambers A, D, E, and F are defined by backplane wiring and network signaling levels. Chambers B and C are manufacturer-specific.

Configure keying in the chassis as described in the following table:


| Keying chambers on chassis             | Configuration   |
|--|---|
| A, B, and C<br>(Front and rear panels) | Configure as shown in this illustration:<br>Chamber: A B C<br><br>Position: 1 1 2 |
| D, E, and F<br>(Front and rear panels) | Configure as shown in this illustration:<br>Chamber: D E F<br><br>Position: 1 1 1 |


P1 and P4 are installed by the backplane vendor.

## Installing the board

**Caution:** The AG 2000C board is shipped in a protective anti-static container. Leave the board in its container until you are ready to install it. Handle the board carefully and hold it only by its handles. NMS recommends that you wear an anti-static wrist strap connected to a good earth ground whenever you handle the board.

Complete the following steps to initially install an AG 2000C board:

| Step | Action   |
|------|--|
| 1    | Turn off the computer and disconnect it from the power source. (This step is suggested for new configurations.)<br><b>Note:</b> If you are replacing a board that is currently in the system, refer to the <i>NMS OAM System User's Manual</i> for any restrictions.   |
| 2    | Choose a chassis slot for the AG 2000C board. Remove the access panels to the chassis slot (both rear and front).  |
| 3    | Verify that the chassis slot has the appropriate keying.   |
| 4    | Slide the rear I/O transition board into the rear of the chassis.<br><br><div style="border: 1px solid black; padding: 5px; display: inline-block;"> <p><b>Warning:</b>  Some older CompactPCI chassis may not have a rear I/O connector alignment feature. The rear I/O transition board requires this feature to allow insertion. Contact the chassis manufacturer to find out if your chassis supports this rear alignment feature. Use caution when inserting the board into the backplane mating connector.</p> </div> |
| 5    | Seat the rear I/O transition board by rotating the top and bottom handles.   |
| 6    | Fasten the board to the chassis with the screws on the upper and lower handles.  |
| 7    | Slide the AG 2000C board into the corresponding slot in the front of the chassis.  |
| 8    | Seat the board into the backplane by rotating the top and bottom handles toward each other.  |
| 9    | Fasten the board to the chassis with the screws on the upper and lower handles. Refer to the following illustration for a view of how the AG 2000C board and the rear I/O transition board sit in the chassis.   |
| 10   | Replace the covers, and connect the computer to its power source (if you turned it off in Step 1).   |



AG 2000C board installed with a rear I/O transition board

## Using the Hot Swap features

Hot Swap operates only if the Hot Swap Driver and Hot Swap Manager are started. To learn how to start these modules, refer to the *NMS OAM System User's Manual*.

Under Windows, you must also install additional drivers to enable NMS Hot Swap drivers to interact properly with Windows Plug and Play functionality. These drivers are available with Natural Access.

Once the Hot Swap Driver and Hot Swap Manager are started, boards defined in the NMS OAM database may be booted, extracted, and reinserted. Boards inserted into a PCI bus and slot for which no logical board definition exists in the database are not recognized. For more information about configuring Hot Swap, refer to the *NMS OAM System User's Manual*.



## Connecting to the telephone network

This topic provides instructions for connecting to the telephone network.


**Warning:**



**Important safety notes for telephony connections**


- Allow only qualified technical personnel to install this board and associated telephone wiring.
- Make sure the PC chassis is grounded through the power cord or by other means before connecting the telephone line.
- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations.
- Telephone companies provide primary lightning protection for their telephone lines. However, if a site connects to private lines that leave the building, make sure that external protection is provided.

As shown in the following illustration, the end bracket on the AG 2000C rear I/O transition board has an RJ-21 connector. The connector has 25-pair interfaces:




*RJ-21 connector*

The connector is designed to accommodate a 25-pair cable. As shown in the following illustration, this cable is commonly wired to a punch-down block or breakout box.




### Connecting the board

The RJ-21 connector on the cable must be the 180-degree design. The common 90-degree RJ-21 connector is not compatible with the AG 2000C board.



### 90-degree versus 180-degree RJ-21 connector

The following illustration shows the pin locations for the RJ-21 connector on an AG 2000C rear I/O transition board:



### Connector pinout


The following table describes the pinouts for the RJ-21 connector:

| Trunk | Ring pin | Tip pin |  | Trunk | Ring pin | Tip pin |
|-------|----------|---------|--|-------|----------|---------|
| 1     | 1        | 26      |  | 13    | 13       | 38      |
| 2     | 2        | 27      |  | 14    | 14       | 39      |
| 3     | 3        | 28      |  | 15    | 15       | 40      |
| 4     | 4        | 29      |  | 16    | 16       | 41      |
| 5     | 5        | 30      |  | 17    | 17       | 42      |
| 6     | 6        | 31      |  | 18    | 18       | 43      |
| 7     | 7        | 32      |  | 19    | 19       | 44      |
| 8     | 8        | 33      |  | 20    | 20       | 45      |
| 9     | 9        | 34      |  | 21    | 21       | 46      |
| 10    | 10       | 35      |  | 22    | 22       | 47      |
| 11    | 11       | 36      |  | 23    | 23       | 48      |
| 12    | 12       | 37      |  | 24    | 24       | 49      |

**Note:** Pins 25 and 50 are not used.

### Ferrite block

The AG 2000C board is shipped with a ferrite block (P/N 33210). Attach the ferrite block to the RJ-21 cable with one loop as shown in the following illustration. The AG 2000C board passes FCC Part 15, Class A without this ferrite block.



*Ferrite block*

### **Developer's cable kit**

---

To help you get started, NMS provides an optional developer's cable kit (P/N 80659). The kit contains two 10-foot RJ-21 cables and two breakout boxes. Each breakout box connects one RJ-21 to 24 standard RJ-11 (POTS) jacks for individual phones. You can use the cables to connect to the breakout boxes or to standard 66 or 110 blocks.

All components of the developer's cable kit sold by NMS are also commercially available from telephone product distributors such as Graybar and Anixter. These distributors can provide variations in cable lengths.

---

# 5

## Configuring the board

---

### Adding board configurations to the NMS OAM database

---

Each board that NMS OAM configures and starts must have a separate set of configuration parameters. Each parameter value is expressed as a keyword name and value pair (for example, AutoStart = NO). You can use NMS OAM to retrieve parameters for any component. These parameters (set through board keywords) can be added, modified, or deleted.

Before using NMS OAM, make sure that the Natural Access Server (*ctdaemon*) is running. For more information about the Natural Access Server (*ctdaemon*), refer to the *Natural Access Developer's Reference Manual*.

The following utilities are shipped with NMS OAM:

| Utility        | Description  |
|----------------|--|
| <i>oamsys</i>  | Configures and starts up boards on a system-wide basis. Attempts to start all specified boards based on system configuration files you supply. |
| <i>oamcfg</i>  | Provides greater access to individual NMS OAM configuration functions.   |
| <i>oaminfo</i> | Displays keywords and settings for one or more components. Can also set individual keywords.   |

Refer to the *NMS OAM System User's Manual* for more information about *oamsys* and *oamcfg*.

An application can control NMS OAM using OAM service functions. For more information about the OAM service functions and about *oaminfo*, refer to the *NMS OAM Service Developer's Reference Manual*.

## Configuring and starting the system with oamsys

To configure and start a system using the *oamsys* utility:

| Step | Action  |
|------|---|
| 1    | Install the boards and software as described in the <i>installation summary</i> on page 19.   |
| 2    | Determine which board keyword file you will use, or edit one of the sample AG 2000C board keyword files, to specify appropriate configuration information for each board. For more information, refer to <i>Using board keyword files</i> on page 30.   |
| 3    | Determine the PCI bus and slot locations of the boards using the <i>pciscan</i> utility. <i>pciscan</i> identifies the NMS PCI boards installed in the system and returns each board's bus, slot, interrupt, and board type.  |
| 4    | Create a system configuration file, or edit a sample system configuration file, to point to all the board keyword files for your system. Specify a unique name and board number for each board.   |
| 5    | Start <i>oammon</i> to monitor the NMS OAM system and all NMS boards. For more information about <i>oammon</i> , refer to the <i>NMS OAM System User's Manual</i> .<br>Start <i>oammon</i> before running <i>oamsys</i> . Keep <i>oammon</i> running to see the status of all boards in your system and to view error and tracing messages. |
| 6    | Use <i>oamsys</i> to start all of the installed boards ( <i>ctdaemon</i> must be running when you use <i>oamsys</i> ) according to the configuration information specified in the system configuration file and any associated board keyword files. For more information, refer to <i>Running oamsys</i> on page 33.                        |

To determine the physical slot location of a specific board:

| Operating system | Procedure   |
|------------------|---|
| Windows          | Use <i>pciscan</i> to associate the PCI bus assignment to a physical board by flashing an LED on the board. To flash the LED on a board, call <i>pciscan</i> with the PCI bus and PCI slot locations. |
| UNIX             | Use <i>blorate</i> to associate the PCI bus assignment to a physical board by flashing an LED on the board. To flash the LED on a board, call <i>blorate</i> with the PCI bus and PCI slot locations. |

For information about *pciscan* and *blorate*, refer to the *NMS OAM System User's Manual*.

## Using board keyword files

A board keyword file contains a list of parameters and values to configure a board. The board keyword file for each board is assigned to the board in another file, called a system configuration file. When *oamsys* runs, it creates a record for each board in the NMS OAM database, and stores the parameters and values of the board. It then starts the board, configured as described in the database.

A sample set of board keyword files are installed by the Natural Access installation. You can copy these files and modify them. The sample board keyword files are located in the `\ag\cfg` subdirectory under the Natural Access installation directory.

The following sample board keyword file (*agpi2000c.cfg*) shows the set of board keywords necessary to configure and start an AG 2000C board:

```
#
#   AG Plug-in Config File for AG 2000C
#
# TCP files are shipped with the AG-CAS sub-package of Natural Access.
# Be sure that you installed the protocols that are specified below before
# trying to start a board with this configuration file.
TCPFiles[0] = nocc.tcp           # "no trunk control" protocol
TCPFiles[1] = lps0.tcp          # AG-CAS Loopstart protocol
# The SLAC file controls the line impedance.  This is the SLAC file for
# U.S. installations.
NetworkInterface.Analog[0..23].ConfigFile = a2usals6.slc
# This configures the board as stand alone - see documentation for options
# to use when the board needs to connect to the H.110 bus.
Clocking.HBus.ClockSource = OSC
Clocking.HBus.ClockMode = STANDALONE
# DSP (.m54) files to link in
DSP.C5x[0..3].Files = callp.m54 dtmf.m54 mf.m54 ptf.m54 signal.m54 tone.m54 voice.m54
XLaw = MU-LAW
# Runtime loadable modules
DLMFiles[0] = gtp.leo
DLMFiles[1] = voice.leo
DLMFiles[2] = svc.leo
```

For general information about NMS OAM board keyword files, refer to the *NMS OAM System User's Manual*.

## Creating a system configuration file for oamsys

When your board keyword files are complete, create a system configuration file describing all of the boards in your system. *oamsys* creates the records, and then directs NMS OAM to start the boards, configured as specified. The system configuration file is typically named *oamsys.cfg*. By default, *oamsys* looks for a file with this name when it starts up. Refer to the *NMS OAM System User's Manual* for specific information on the syntax and structure of this file.

**Note:** You can use the *oamgen* utility (included with the NMS OAM software) to create a sample system configuration file for your system. The system configuration file created by *oamgen* may not be appropriate for your configuration. You may need to make further modifications to the file before running *oamsys* to configure your boards based on the file. For more information about *oamgen*, refer to the *NMS OAM System User's Manual*.

The following table describes the AG board-specific settings to include in the system configuration file for each AG board:

| Keyword         | Description  | Allowed values for AG boards  |
|-----------------|--|---|
| [ <i>name</i> ] | Name of the board to be used to refer to the board in the software. The board name must be unique.   | Any string, in square brackets [ ].   |
| Product         | Name of the board product.   | AG_2000C  |
| Number          | Board number you use in the Natural Access application to refer to the board.  | Any integer from 0 to 31. Each board's number must be unique.   |
| Bus             | PCI bus number. The bus:slot location for each board must be unique.   | Values returned by <i>pciscan</i> .   |
| Slot            | PCI slot number. The bus:slot location for each board must be unique.  | Values returned by <i>pciscan</i> .   |
| File            | Name of the board keyword file containing settings for the board.<br>Several board keyword files are installed with the AG software, one for each country or region. | For information about creating a custom board keyword file, refer to <i>Changing configuration parameter settings</i> on page 34.<br>You can specify more than one file after the File keyword:<br><pre>File=mya.cfg myb.cfg myc.cfg</pre><br>Alternatively, you can specify the File keyword more than once:<br><pre>File = mya.cfg<br/>File = myb.cfg<br/>File = myc.cfg</pre><br>Board keyword files are applied in the order in which they are listed. The value for a given keyword in each file overrides any value specified for the keyword in earlier files. |



## Sample system configuration file

---

The following system configuration file describes two AG 2000C boards, both to be configured for the United States:

```
[First AG 2000C]
Product = AG_2000C
Number  = 0
Bus     = 0
Slot    = 15
File    = agpi2000c.cfg

[Second AG 2000C]
Product = AG_2000C
Number  = 1
Bus     = 0
Slot    = 16
File    = agpi2000c.cfg
```

## Running oamsys

---

To run *oamsys*, enter the following command:

```
oamsys -f filename
```

where *filename* is the name of an NMS OAM system configuration file.

**Note:** If you invoke *oamsys* without command line options, NMS OAM searches for a file named *oamsys.cfg* in the paths specified in the AGLOAD environment variable.

When you invoke *oamsys* with a valid file name, *oamsys* performs the following tasks:

- Checks the syntax of the system configuration file to make sure that all required keywords are present. *oamsys* discards any unrecognized keywords and reports any syntax errors it finds. *oamsys* verifies the file syntax of configuration files, but not of board keyword files.
- Checks for uniqueness of board names, board numbers, and board bus and slot numbers.
- Shuts down all boards recognized by NMS OAM (if any).
- Deletes all board configuration information currently maintained for the recognized boards (if any).
- Sets up the NMS OAM database and creates all records as described in the system configuration file.
- Attempts to start all boards as specified in the system configuration file and the board keyword files it references.

The Natural Access Server (*ctdaemon*) must be running for *oamsys* to operate. For more information about the Natural Access Server, refer to the *Natural Access Developer's Reference Manual*.

## Changing configuration parameter settings

---

When you run *oamsys*, the utility starts all boards according to the configuration parameters specified in their associated board keyword files.

To change a parameter:

- Use of modify one of the sample board keyword files corresponding to your country and board type. Specify the name of this new file in the File statement in *oamsys.cfg* and run *oamsys* again. Refer to the *NMS OAM System User's Manual* for information about the syntax of NMS OAM board keyword files.
- Specify parameter settings with *oamcfg*. Refer to the *NMS OAM System User's Manual* for information about *oamcfg*.
- Create a new board keyword file, either with additional keywords or with keywords whose values override earlier settings.
- Specify the settings using OAM service functions. Refer to the *NMS OAM Service Developer's Reference Manual* for more information.

You can *oamsys* to:

- Change which software module files are downloaded to the board at startup. Refer to *Specifying configuration file locations* on page 34 for more information.
- Specify board switching.
- Configure CT bus clocking.

### .leo files

---

A *.leo* (loadable extensible object) file is a run module, a modular extension to the core file. The core file and the run modules make up the software that runs on the board's coprocessor.

The following *.leo* files are included with AG 2000C:

| File             | Description             |
|------------------|-------------------------|
| <i>svc.leo</i>   | DSP function manager    |
| <i>gtp.leo</i>   | Trunk protocol engine   |
| <i>voice.leo</i> | Play and record manager |

## Specifying configuration file locations

---

Files to be downloaded to the AG boards are specified with keywords in the AG board's keyword file. For example:

```
DLMFiles[0] = filename
```

If *filename* contains a path specification, NMS OAM searches for the file in the specified directory. Otherwise, NMS OAM searches for the file in the current working directory of *ctdaemon*. If the file does not exist in the current working directory, NMS OAM searches for the file in the search path defined by the AGLOAD environment variable.

## QSLAC files and trunk control programs

The QSLAC files (quad subscriber line audio - processing circuit) on an AG 2000C board control:

- The 2 wire impedance matching
- Frequency response and equalization
- Trans-hybrid balancing

Each port on the AG 2000C board can be configured separately. The configuration is contained in a QSLAC file. Each QSLAC file is customized for a specific line interface signaling module and for a certain country's two wire return loss requirements.

Refer to *Line gain configuration* on page 54 for information on controlling the gain.

### Naming conventions for QSLAC files

All QSLAC files have an extension of *.slc* and adhere to the following naming convention:

***pp cty ss i.slc***

| Where...          | Represents the...                                | For example...  |
|-------------------|--|---|
| <b><i>pp</i></b>  | Two-character NMS product field.                 | <i>a2</i> = AG 2000C board  |
| <b><i>cty</i></b> | Three-character ISO country code or region code. |   |
| <b><i>ss</i></b>  | Two-character signaling type.                    | <i>ls</i> = loopstart   |
| <b><i>i</i></b>   | One character line impedance field.              | <i>6</i> = short 600 Ohm lines<br><i>9</i> = short 900 Ohm lines<br><i>n</i> = lines longer than 2000 feet<br><i>c</i> = complex (used in some international markets) |

For example, *a2usals6.slc* represents the AG 2000C board/USA/loop start/600 Ohm line QSLAC file.

Natural Access configures the system for the QSLAC file that is intended for your country. Do not change the configuration unless you are confident that a change is required and is allowed by the regulatory agencies.

For more information about QSLAC files, refer to the *NMS CAS for Natural Call Control Developer's Manual*.

If the default file is not used, an entry is made in the error log file at boot time. If echo cancellation is enabled, there is no benefit in changing from the default QSLAC file.

For example, add the following statement to the board keyword file to load a QSLAC file:

```
NetworkInterface.Analog[0..23].ConfigFile = a2usals9.slc
```

## Trunk control programs

---

Trunk control programs (TCPs) perform all the signaling tasks necessary to interface with the telephony protocol used on the line or trunk. TCPs are loaded onto an AG 2000C board at board initialization. After a TCP has been loaded to the AG 2000C board, the application must start up its protocol before it can use the TCP to perform call control on a specific port.

## QSLAC files and TCPs for loop start

---

The following table lists the QSLAC files for loop start that can be selected for the United States and Canada:

| File                | Description  |
|---------------------|--|
| <i>a2usals6.slc</i> | This is the default file that is used when you have a 600 Ohm PBX. |
| <i>a2usals9.slc</i> | Optimizes performance interfacing to a 900 Ohm PBX.                |
| <i>a2usalsn.slc</i> | Optimizes performance interfacing to long lines (> 2000 feet).     |

Other QSLAC files are used in other parts of the world. Natural Access configures the correct files for the countries that are supported.

For European countries that are not supported in the installation, use the *a2eurlsc.slc* file when connecting to the PSTN. Refer to the `NetworkInterface.Analog[x].ConfigFile` keyword for more information about QSLAC files. Refer to the *NMS CAS for Natural Call Control Developer's Manual* for information on changing network tone descriptions.

The following table lists the TCPs that are applicable to AG 2000C loop start boards:

| Trunk control program | Description             |
|-----------------------|-------------------------|
| <i>nocc.tcp</i>       | No call control.        |
| <i>lps0.tcp</i>       | Loop start on AG 2000C. |

## Configuring board clocking

---

When multiple boards are connected to the CT bus, you must set up a bus clock to synchronize timing between them. In addition, you can configure alternative (or fallback) clock sources to provide the clock signal if the primary source fails.

This topic describes:

- AG 2000C clocking capabilities
- Clock configuration methods
- Configuring board clocking using keywords
- Example

To create a robust clocking configuration, you must understand basic clocking concepts such as clock mastering and fallback. This topic assumes that you have a basic understanding of CT bus clocking. For a complete overview of CT bus clocking, refer to the *NMS OAM System User's Manual*.

## AG 2000C clocking capabilities

This topic describes the rules and limitations that apply to setting up CT bus clocking on AG 2000C boards.

When an AG 2000C board is configured as the system primary clock master, the board's first timing reference must be set to OSC. Clock fallback should be disabled.

**Warning:**



If there is a digital T1 or E1 board in the system, configure one of the digital boards as the master and configure the AG 2000C board as the slave. Refer to the *NMS OAM System User's Manual* for information about assessing clocking priorities in a mixed-board system.

When an AG 2000C board is configured as the system secondary clock master:

- The board's first timing reference must be the system's primary clock master.
- The board's fallback timing reference must be set to OSC.

When an AG 2000C board is configured as a clock slave:

- The board's first timing reference must be the system's primary clock.
- The board's fallback timing reference must be the system's secondary clock.
- If there is no secondary clock master for the system, the board's fallback timing reference must be set to OSC. In this case, if clock fallback occurs, the board is not synchronized with the system until you reconfigure the board's clocking.

The following tables summarize the CT bus clocking capabilities of AG 2000C boards:

**Note:** NETREF refers to NETREF1 on the H.110 bus.

### Clocking capabilities as primary master

| Capability  | Yes/No | Comments  |
|---|--------|---|
| Serve as primary master                           | Yes    | Use this board as a master only if no boards with digital trunks are present on the CT bus. |
| Drive A_CLOCK                                     | Yes    |   |
| Drive B_CLOCK                                     | Yes    |   |
| Available primary timing references:              |        |   |
| Local trunk                                       | No     | Only digital trunks carry timing reference signals.   |
| NETREF  | No     | This board cannot use NETREF as a timing reference.   |
| NETREF2   | No     | This board does not support NETREF2.  |
| OSC   | Yes    |   |
| Fallback to secondary timing reference            | No     | There is no timing reference to fallback to.  |
| Slave to secondary master if both references fail | No     |   |

### Clocking capabilities as secondary master

| Capability                             | Yes/No | Comments  |
|--|--------|---|
| Serve as secondary master              | Yes    | Use this board as a master only if no boards with digital trunks are present on the CT bus. |
| Drive A_CLOCK                          | Yes    | If the primary master drives B_CLOCK, the secondary master drives A_CLOCK.                  |
| Drive B_CLOCK                          | Yes    | If the primary master drives A_CLOCK, the secondary master drives B_CLOCK.                  |
| Available secondary timing references: |        |   |
| Local trunk                            | No     | Only digital trunks carry timing reference signals.   |
| NETREF                                 | No     | This board cannot use NETREF as a timing reference.   |
| NETREF2                                | No     | This board does not support NETREF2.  |
| OSC                                    | Yes    |   |

### Clocking capabilities as slave

| Capability                            | Yes/No | Comments  |
|---------------------------------------|--------|---|
| Serve as slave                        | Yes    |   |
| Slave to A_CLOCK                      | Yes    |   |
| Slave to B_CLOCK                      | Yes    |   |
| Available fallback timing references: |        |   |
| A_CLOCK                               | Yes    |   |
| B_CLOCK                               | Yes    |   |
| OSC                                   | Yes    | The board is not synchronized until the application reconfigures the clock. |

### Other clocking capabilities

| Capability                 | Yes/No | Comments                             |
|----------------------------|--------|--------------------------------------|
| Drive NETREF               | Yes    |                                      |
| Drive NETREF2              | No     | This board does not support NETREF2. |
| Operate in standalone mode | Yes    |                                      |

## Clock configuration methods

You can configure clocking in your system in one of two ways:

| Method  | Description   |
|---|---|
| Using <i>clockdemo</i> application model                        | <p>Create an application that assigns each board a clocking mode, monitors clocking changes, and reconfigures clocking when clock fallback occurs.</p> <p>A sample clocking application, <i>clockdemo</i>, is provided with Natural Access. <i>clockdemo</i> provides a robust fallback scheme that suits most system configurations. <i>clockdemo</i> source code is included, allowing you to modify the program if your clocking configuration is complex. For more information about <i>clockdemo</i>, refer to the <i>NMS OAM System User's Manual</i>.</p> <p><b>Note:</b> Most clocking applications (including <i>clockdemo</i>) require that all boards on the CT bus be started in standalone mode.</p>   |
| Using board keywords (with or without application intervention) | <p>For each board on the CT bus, set the board keywords to determine the board's clocking mode and to determine how each board behaves if clock fallback occurs.</p> <p>This method is described in this topic. Unlike the <i>clockdemo</i> application, which allows you to specify several boards to take over mastery of the clock when another board fails, the board keyword method allows you to specify only a single secondary clock master. For this reason, the board keyword method is best used to implement clock fallback in your system, or in test configurations where clock reliability is not a factor.</p> <p>The board keyword method does not create an autonomous clock timing environment. If you implement clock fallback using this method, an application must still intervene when clock fallback occurs to reset system clocking before other clocking changes occur. If both the primary and secondary clock masters stop driving the clocks, and an application does not intervene, the boards default to standalone mode.</p> |

Choose only one of these configuration methods across all boards on the CT bus. Otherwise, the two methods can interfere with one another and board clocking may not operate properly.

### Configuring AG 2000C boards using board keywords

AG 2000C board keywords enable you to configure the board in the following ways:

- System primary clock master
- System secondary clock master
- Clock slave
- Standalone mode

You can also use board keywords to establish clock fallback sources.

The following sections describe how to use board keywords to specify the clocking role of each AG 2000C board in a system.

## Primary clock master

Use the following board keywords to configure an AG 2000C board as a primary clock master:

| Keyword                    | Description  |
|----------------------------|--|
| Clocking.HBus.ClockMode    | Specifies the CT bus clock that the board drives. This keyword must reference either A clock (MASTER_A) or B clock (MASTER_B). |
| Clocking.HBus.ClockSource  | Specifies the source from which this board derives its timing. Set this keyword to OSC.  |
| Clocking.HBus.AutoFallback | Set this keyword to NO.  |

**Note:** If the primary master's first source fails and then returns, the board's timing reference (and consequently, the references for any slaves) switches back to the first timing source. This is not true for the secondary timing master.

## Secondary clock master

Use the following board keywords to configure an AG 2000C board as a secondary clock master:

| Keyword                           | Description   |
|-----------------------------------|---|
| Clocking.HBus.ClockMode           | Specifies the CT bus clock that the secondary master drives. This keyword must reference the clock (MASTER_A or MASTER_B) not driven by the primary clock master.   |
| Clocking.HBus.ClockSource         | Specifies the source from which this board derives its timing. Set this keyword to the clocks driven by the primary clock master. For example, if the primary master drives A clock, set this keyword to A_CLOCK. |
| Clocking.HBus.AutoFallback        | Enables or disables clock fallback on the board. Set this keyword to YES.   |
| Clocking.HBus.FallBackClockSource | Specifies the alternate timing reference to use when the master clock does not function properly. Set this keyword to OSC.  |

**Note:** If the primary master's timing reference recovers, the secondary master continues to drive the clock referenced by all clock slaves in the system until the application intervenes.

## Clock slave

Use the following board keywords to configure an AG 2000C board as a clock slave:

| Keyword                           | Description   |
|-----------------------------------|---|
| Clocking.HBus.ClockMode           | Specifies the CT bus clock from which the board derives its timing. Set this keyword to SLAVE to indicate that the board does not drive any CT bus clock.   |
| Clocking.HBus.ClockSource         | Specifies the source from which this clock derives its timing. Set this keyword to reference the clock driven by the primary clock master.  |
| Clocking.HBus.AutoFallback        | Enables or disables clock fallback on the board.  |
| Clocking.HBus.FallBackClockSource | Specifies the alternate clock reference to use when the master clock does not function properly. For clock slaves, set this keyword to reference the clock (A_CLOCK or B_CLOCK) driven by the secondary clock master. |



### Standalone mode

To configure an AG 2000C board in standalone mode so the board references its own clocking information, set `ClkMode.HBus.ClockMode` to `STANDALONE` and set `ClkMode.HBus.ClockSource` to `OSC`. The board then uses its own oscillator as a timing signal reference. The board cannot make switch connections to the CT bus.

### Multiple board system example


The following example assumes a system configuration where three AG 2000C boards reside in a single chassis. The boards are configured in the following way using board keywords:

| Board   | Configuration                                     |
|---------|---|
| Board 0 | System primary bus master (driving the A clock)   |
| Board 1 | System secondary bus master (driving the B clock) |
| Board 2 | Clock slave (clock fallback enabled)              |

This configuration assigns the following clocking priorities:

| Priority | Timing reference          |
|----------|---------------------------|
| First    | Board 0, local oscillator |
| Second   | Board 1, local oscillator |

The following illustration shows a multiple-board system with a primary and secondary clock master:



Sample board clocking configuration

The following table shows board keywords used to configure the boards according to the configuration shown in the preceding illustration:

| Board | Role                   | Clocking keyword settings   |
|-------|------------------------|---|
| 0     | Primary clock master   | Clocking.HBus.ClockMode = MASTER_A<br>Clocking.HBus.ClockSource = OSC<br>Clocking.HBus.AutoFallBack = NO  |
| 1     | Secondary clock master | Clocking.HBus.ClockMode = MASTER_B<br>Clocking.HBus.ClockSource = A_CLOCK<br>Clocking.HBus.AutoFallBack = YES<br>Clocking.HBus.FallBackClockSource = OSC  |
| 2     | Clock slave            | Clocking.HBus.ClockMode = SLAVE<br>Clocking.HBus.ClockSource = A_CLOCK<br>Clocking.HBus.AutoFallBack = YES<br>Clocking.HBus.FallBackClockSource = B_CLOCK |

In this configuration, Board 0 is the primary clock master and drives A\_CLOCK. All slave boards on the system use the A clock as their first timing reference. Board 0 references its timing from its local oscillator.

If the clocking signal used by Board 0 fails, then Board 0 stops driving A\_CLOCK. The secondary clock master (Board 1) then falls back to a timing reference based on its local oscillator and uses this signal to drive B\_CLOCK. B\_CLOCK then becomes the timing source for all boards that use B\_CLOCK as their backup timing reference.

**Note:** For this clock fallback scheme to work, all clock slaves must specify A\_CLOCK as the clock source and B\_CLOCK as the clock fallback source.

## Enabling echo cancellation

Echo cancellation improves the input signal-to-noise ratio during play which improves the performance of operations such as tone detection and speech recognition.

To enable echo cancellation:

| Step | Action  |
|------|---|
| 1    | Include the following statement in the board keyword file:<br><pre>DSP.C5x[x].Files = echo.m54</pre> where <b>x</b> = the next available index. |
| 2    | Set the appropriate ADI service parameters in your application and in your system.  |

Refer to the *ADI Service Developer's Reference Manual* for information about configuring echo cancellation on the AG 2000C board.

---

# 6


## Verifying the installation

---

### Status indicator LEDs

---

The AG 2000C board has indicators (LEDs) on the end bracket of the board as shown in the following illustration:



*LEDs on the end bracket*

The following table describes each of the LEDs:

| LED  | Description   |
|------|---|
| DIAG | The LED is on after the board is booted.  |
| HBAT | LED on verifies -48 V DC is available to the board from the external power supply (for future use). |
| LBAT | LED on verifies -30 V DC is available to the board from the external power supply (for future use). |

| LED      | Description   |
|----------|---|
| Hot Swap | <p>Illuminates when it is safe to remove the AG 2000C board from the system. The LED illuminates under one of the following conditions:</p> <ul style="list-style-type: none"> <li>• If the board is fully inserted when the backplane is powered up, the blue LED momentarily flashes. This is a normal part of the initialization process.</li> <li>• After opening the handles (during the extraction process), the LED illuminates to indicate that it is safe to remove the board. Do not remove the board until the LED illuminates. <b>This occurs only if Hot Swap software is present.</b></li> <li>• If the LED remains illuminated during insertion of a board, the board failed to successfully perform its primary hardware initialization. While it is safe to remove the board, this condition indicates a problem.</li> </ul> <p>For more information about Hot Swap, refer to the <i>NMS OAM System User's Manual</i>.</p> |

## Verifying board installation

Complete the following steps to verify that the board is installed correctly:

| Step | Action  |
|------|---|
| 1    | Create a board keyword file to boot an AG 2000C board by copying or editing one of the sample board keyword files to match your specific configuration. Refer to <i>Configuring and starting the system with oamsys</i> on page 30 for more information. For example, use the <i>agpi2000c.cfg</i> file to configure the board for the loop start protocol. |
| 2    | Run <i>oammon</i> to monitor the status of all boards.  |
| 3    | Use <i>pciscan</i> to determine the bus and slot number. For more information about <i>pciscan</i> , refer to the <i>NMS OAM System User's Manual</i> .   |
| 4    | Edit the <i>oamsys.cfg</i> file to reflect the board locations in your system.  |
| 5    | Boot the board using the command:<br><pre>oamsys</pre>  |

## Retrieving AG board configuration information: boardinf

*boardinf* is a program that reports the board number, address, type, number of ports, memory, and DSP timeslot assignments for each AG board in a system.

*boardinf* opens the AG driver and retrieves the configuration information for up to 16 AG 2000C boards. If an AG 2000C board exists and is properly initialized, its configuration is displayed and its DSP port addresses are displayed as one or more timeslot ranges.

To run *boardinf*:

| Step | Action  |
|------|---|
| 1    | Ensure that the AG 2000C boards were initialized.   |
| 2    | Open a command window.  |
| 3    | Enter the following command:<br><pre>boardinf</pre><br><i>boardinf</i> displays the configuration information for each AG 2000C board in the system that has been loaded and initialized.                   |
| 4    | If no boards are detected, verify that the AG 2000C board(s) is loaded and initialized and repeat the command. If the AG 2000C configuration information is not as expected, review the board keyword file. |

## Interactive test program: ctatest

---

*ctatest* is a menu-driven interactive program. Enter one- and two-letter commands to execute Natural Access and ADI service functions. Some commands prompt the user for additional input. For example, running a tone generator requires the user to specify frequencies and amplitudes. For more information about *ctatest*, refer to the *Natural Access Developer's Reference Manual*.

*ctatest* can execute more than one asynchronous function concurrently. For example, you can run a tone detector (ET) and record voice (RF) simultaneously. You can abort any function by entering the respective stop command (DT and RS for tone and record).

If Clocking.HBus.ClockMode = STANDALONE, then default local connections between the DSP resources and the line interfaces are nailed up as described in *Default connections* on page 51.

To experiment with output and input functions simultaneously, execute two instances of *ctatest*. Use the *swish* **MakeConnection** command to make quad connections between two ports, one bound to each *ctatest* instance. Refer to the *Switching Service Developer's Reference Manual* for information about *swish*.

For example, to interactively experiment with tone generation and detection, start a tone detector in the first *ctatest* instance and a tone generator in the second *ctatest* instance.

### Using swish for a standalone board

---

No default connections are made for a standalone board if CT bus connectivity is enabled in the board keyword file. Use *swish* to connect the local network interface to the local DSP resource. You can use *swish* interactively, or create a script in a flat text file.

The following example of *swish* commands nails up the voice and signaling streams for all 24 line interfaces of an AG 2000C board that has been configured as board 0.

```
openswitch ag2000C = agsw 0

resetswitch ag2000C

# make voice and signaling connections
makeconnection ag2000C local:0:0..23 to local:5:0..23 QUAD

closeswitch ag2000C

exit
```

## Using ctatest with an AG 2000C loop start board

Connect a loop start line from a PBX or the public network as a test line to your system so you can call the test line from a telephone connected to another line.

To use *ctatest*:

| Step | Action  |
|------|---|
| 1    | <p>Make sure that the board keyword file includes the following statement for the board that you will be using:</p> <pre>TCPFiles[x] = lps0.tcp</pre> <p>where <b>x</b> = the next available index.</p> <p>If necessary, edit the board keyword file.</p>                         |
| 2    | <p>Start <i>ctatest</i>.</p> <p>The initial <i>ctatest</i> menu appears.</p>  |
| 3    | <p>Enter <b>OP</b> to create a context and open the ADI service.</p> <p>CTAEVN_OPEN_SERVICES_DONE is displayed on your screen.</p>  |
| 4    | <p>Start a protocol by entering <b>SP</b>.</p> <p>The following message appears:</p> <pre>Enter protocol name ['nocc']:</pre> <p>Enter the loop start protocol: lps0.</p> <p>The following message appears:</p> <pre>Event: NCCEVN_START_PROTOCOL_DONE, CTA_REASON_FINISHED</pre> |
| 5    | <p>Place a call to the line connected to the AG 2000C board.</p> <p>The following message appears:</p> <pre>Event: NCCEVN_INCOMING_CALL</pre>   |
| 6    | <p>Initiate answering the call by entering <b>AC</b>.</p> <p>The following message appears:</p> <pre>Number of rings [1]:</pre>   |
| 7    | <p>Press <b>Enter</b>.</p> <p>You should hear a single ring tone.</p> <p>The following messages appear:</p> <pre>Event: NCCEVN_ANSWERING_CALL Event: NCCEVN_CALL_CONNECTED, NCC_CON_ANSWERED</pre>  |
| 8    | <p>Begin recording to memory by entering <b>RM</b>.</p> <p>You should hear a beep on the handset.</p>   |
| 9    | <p>Say "Hello World," and wait.</p> <p>The following message appears on the screen (you may see a different number of bytes):</p> <pre>Event: VCEEVN_RECORD_DONE, Voice End, msec=3820.</pre>   |
| 10   | <p>Play back your voice by entering <b>PM</b>.</p> <p>You should hear "Hello World," and <i>ctatest</i> displays:</p> <pre>Event: VCEEVN_PLAY_DONE, Finished, msec=3820.</pre>  |
| 11   | <p>Quit the test program by entering <b>Q</b>.</p>  |

## Demonstration programs

The following demonstration programs are provided with Natural Access and can be used to verify that the AG 2000C board is operating correctly:

| Program        | Demonstrates...  |
|----------------|--|
| <i>ctatest</i> | Natural Access functions.  |
| <i>incta</i>   | Handling inbound calls.  |
| <i>outcta</i>  | Establishing outbound calls.   |
| <i>prt2prt</i> | Transferring calls from an incoming line to an outgoing line and using the Switching service to make connections and to send patterns. |
| <i>vceplay</i> | Using the Voice Message service to play messages in voice files.   |
| <i>vcerec</i>  | Recording one or more messages to a voice file.  |

**Note:** Executables for *incta*, *outcta*, and *prt2prt* are in the respective sub-directories under `\nms\ctaccess\demos`.

To run these demonstration programs on the AG 2000C board, specify the slot number of the local DSP resource on which to run the program. If `Clocking.HBus.ClockMode = STANDALONE`, then default switching connections between the on-board DSP resources and signaling modules are initialized as described in *Default connections* on page 51.

To run *ctatest* on DSP port 0, enter:

```
ctatest -s0
```

To run *ctatest* on DSP port 2, enter:

```
ctatest -s2
```

Switching connections must be made between DSP resources and signaling modules using the Natural Access Switching service or the *swish* utility. Refer to the AG 2000C switching section for more information.

Refer to the *Natural Access Developer's Reference Manual* for details about Natural Access demonstration programs.





---

# 7

## AG 2000C switching

---

### AG 2000C switch model

---

This topic describes:

- The specific use of each stream, as shown for H.110 streams and local streams
- An illustration of the AG 2000C switch model
- Lucent T8100A switch blocking

### H.110 streams

---

| H.110 streams |   |
|---------------|---|
| H.110 bus     | Streams clocked at 8 MHz: timeslots 0..127 for all 32 streams |


### Local streams

---

| Local stream                        |   |
|-------------------------------------|---|
| Line interface voice in and out     | Streams 0 and 1, timeslot 0..7, 0..15, or 0..23 |
| Line interface signaling in and out | Streams 2 and 3, timeslot 0..7, 0..15, or 0..23 |
| DSP voice in and out                | Streams 4 and 5, timeslot 0..7, 0..15, or 0..23 |
| DSP signaling in and out            | Streams 6 and 7, timeslot 0..7, 0..15, or 0..23 |

## Switch model

The following illustration shows the AG 2000C switch model:



AG 2000C switch model

## Lucent T8100A switch blocking

Switching on the AG 2000C board is implemented by the Lucent T8100A chip (HMIC). The Lucent T8100A chip can perform local bus to local bus switching in full non-blocking fashion.


The number of H.110 connections is limited to a maximum of 128 full duplex or 256 simplex (or half-duplex) connections, in any combination, from either:

- H.110 bus to the local bus, or
- H.110 bus to H.110 bus

There are no restrictions on local switching. Any local device can be connected to any other local device.

## Signaling modules and logical timeslots

On AG 2000C boards, each signaling module is hardwired to a specific logical timeslot on the local bus. Each signaling module supports four ports of telephone network connectivity and is permanently connected to four pairs in the RJ-21 connector. Each pair is therefore bound to a corresponding timeslot on the local bus. The following illustration shows the relationship between signaling modules, timeslots, and the connector for AG 2000C boards:



Logical timeslots, signaling modules, and RJ-21 connector

## Default connections

Refer to the following table to determine how default connections occur on the AG 2000C board:

|                        | If Clocking.HBus.ClockMode = |       |                   |
|------------------------|------------------------------|-------|-------------------|
|                        | STANDALONE                   | SLAVE | MASTER_A/MASTER_B |
| If SwitchConnections = |                              |       |                   |
| Yes                    | Yes                          | Yes   | Yes               |
| No                     | No                           | No    | No                |
| Auto                   | Yes                          | No    | No                |

If SwitchConnections = Yes, default connections are made regardless of the Clocking.HBus.ClockMode setting.

If SwitchConnections = No, default connections are not made regardless of the Clocking.HBus.ClockMode setting.

If SwitchConnections = Auto and Clocking.HBus.ClockMode = STANDALONE, default connections are made.

If SwitchConnections = Auto and Clocking.HBus.ClockMode = SLAVE, MASTER\_A, or MASTER\_B, default connections are not made.

The following default local connections are nailed up at board initialization:

| Switch connection  | MVIP-95  |
|--|--|
| Full duplex connection between line interface voice information and DSP resources.     | local:0:0..23 =><br>local:5:0..23<br>local:4:0..23 =><br>local:1:0..23 |
| Full duplex connection between line interface signaling information and DSP resources. | local:2:0..23 =><br>local:7:0..23<br>local:6:0..23 =><br>local:3:0..23 |

You can control switching using the Natural Access Switching service. Refer to the *Switching Service Developer's Reference Manual* for more information.

# 8

## Configuration parameters

### Using the Switching service

Local device configuration on the AG 2000C board is controlled by the Switching service. The Switching service provides functions for accessing device configuration parameters defined by the underlying hardware and device driver.

**swiConfigLocalTimeslot** and **swiGetLocalTimeslotInfo** enable applications to configure a device on a given local stream and timeslot by specifying a particular parameter and providing a data structure specific to that parameter. The prototypes for these functions are repeated here for convenience.

For more information about the Switching service, refer to the *Switching Service Developer's Reference Manual*.

### Function information

The syntax of **swiConfigLocalTimeslot** and **swiGetLocalTimeslotInfo** is:

#### Prototype

DWORD **swiConfigLocalTimeslot** (SWIHD *swihd*, SWI\_LOCALTIMESLOT\_ARGS \**args*, void \**buffer*, unsigned *size*)

DWORD **swiGetLocalTimeslotInfo** ( SWIHD *swihd*, SWI\_LOCALTIMESLOT\_ARGS \**args*, void \**buffer*, unsigned *size*)

| Argument      | Description   |
|---------------|---|
| <i>swihd</i>  | Switch handle returned by <b>swiOpenSwitch</b> .  |
| <i>args</i>   | Pointer to a SWI_LOCALTIMESLOT_ARGS structure. This structure indicates the specific parameter to be configured on the device indicated by localstream and localtimeslot.<br><pre>typedef struct {     DWORD localstream;     DWORD localtimeslot;     DWORD deviceid;     DWORD parameterid; } SWI_LOCALTIMESLOT_ARGS;</pre> |
| <i>buffer</i> | Pointer to a structure that is specific to the parameterid.   |
| <i>size</i>   | Size of <i>buffer</i> , in bytes.   |

#### Return Values

SUCCESS, or an error code from *ctaerr.h* or *swidef.h*.

#### Details

Applications using **swiConfigLocalTimeslot** and **swiGetLocalTimeslotInfo** must open the Switching service. Refer to the *Natural Access Developer's Reference Manual* for more information about opening services.

## Line gain configuration

The AG 2000C supports input and output gain configuration on network voice ports (timeslots) from -6 dB to +6 dB in one dB increments.

Input gain is applied to the signal received from the network. Output gain is applied to the signal transmitted to the network. The default value for both input line gain and output line gain on the AG 2000C loop start board is nominal 0 dB.

This topic describes:

- Getting the line gain
- Setting the line gain

|                 |  |
|-----------------|--|
| <b>Caution:</b> | Increasing gain can also increase noise, echo, and possibly cause oscillations on the telephone network. There also may be regulatory authority implications. Use gain with caution. |
|-----------------|--|

Decreasing gain may reduce echo and other noise.

### Getting the line gain

Use **swiGetLocalTimeslotInfo** to query the input or output line gain. Set the arguments for this function as follows:

| Argument      | Field         | Value   |
|---------------|---------------|---|
| <b>swihd</b>  |               | Handle returned by <b>swiOpenSwitch</b> .                     |
| <b>args</b>   | localstream   | 0 or 1. Refer to the <i>AG 2000C switch model</i> on page 49. |
|               | localtimeslot | 0..23. Refer to the <i>AG 2000C switch model</i> on page 49.  |
|               | deviceid      | MVIP95_ANALOG_LINE_DEVICE                                     |
|               | parameterid   | MVIP95_INPUT_GAIN or MVIP95_OUTPUT_GAIN                       |
| <b>buffer</b> |               | Points to the NMS_LINE_GAIN_PARDS structure.                  |
| <b>size</b>   |               | Size of buffer, in bytes.                                     |

The NMS\_LINE\_GAIN\_PARDS structure is:

```
typedef struct
{
    INT32 gain;
} NMS_LINE_GAIN_PARDS;
```

The value returned in the gain component of NMS\_LINE\_GAIN\_PARDS represents the gain in dB multiplied by 1000. For example, if the input gain on a particular network timeslot is currently set to -3 dB, after calling **swiGetLocalTimeslotInfo** for parameter MVIP95\_INPUT\_GAIN, the gain field is -3000.

The following sample code shows how to retrieve line gain applied to a signal received from the network:

```
#include "swidef.h" /* CT Access Switching service */
#include "mvip95.h" /* MVIP-95 definitions */
#include "nmshw.h" /* NMS hardware-specific definitions */

DWORD myGetReceiveGain ( SWIHD swihd, SWI_TERMINUS terminus, INT32* gain_dB )
{
    SWI_LOCALTIMESLOT_ARGS args;
    NMS_LINE_GAIN_PARAMS device ;
    DWORD rc ;

    args.localstream = terminus.stream ;
    args.localtimeslot = terminus.timeslot ;
    args.deviceid = MVIP95_ANALOG_LINE_DEVICE ;
    args.parameterid = MVIP95_INPUT_GAIN ;

    rc = swiGetLocalTimeslotInfo(
        /* CT Access switch handle */ swihd,
        /* target device and config item */ & args,
        /* buffer (defined by parameterid) */ (void*) & device,
        /* buffer size in bytes */ sizeof(device));

    *gain_dB = device.gain / 1000 ;

    return rc ;
}
```

The following sample code shows how to retrieve line gain applied to a signal transmitted to the network:

```
#include "swidef.h" /* CT Access Switching service */
#include "mvip95.h" /* MVIP-95 definitions */
#include "nmshw.h" /* NMS hardware-specific definitions */

DWORD myGetTransmitGain ( SWIHD swihd, SWI_TERMINUS terminus, INT32* gain_dB )
{
    SWI_LOCALTIMESLOT_ARGS args ;
    NMS_LINE_GAIN_PARAMS device ;
    DWORD rc ;

    args.localstream = terminus.stream ;
    args.localtimeslot = terminus.timeslot ;
    args.deviceid = MVIP95_ANALOG_LINE_DEVICE ;
    args.parameterid = MVIP95_OUTPUT_GAIN ;

    rc = swiGetLocalTimeslotInfo(
        /* CT Access switch handle */ swihd,
        /* target device and config item */ & args,
        /* buffer (defined by parameterid) */ (void*) & device,
        /* buffer size in bytes */ sizeof(device));

    *gain_dB = device.gain / 1000 ;

    return rc ;
}
```

## Setting the line gain

Use **swiConfigLocalTimeslot** to set the the input or output line gain. Set the arguments for this function as follows:

| Argument      | Field         | Value   |
|---------------|---------------|---|
| <b>swihd</b>  |               | Handle returned by <b>swiOpenSwitch</b> .                     |
| <b>args</b>   | localstream   | 0 or 1. Refer to the <i>AG 2000C switch model</i> on page 49. |
|               | localtimeslot | 0..23. Refer to the <i>AG 2000C switch model</i> on page 49.  |
|               | deviceid      | MVIP95_ANALOG_LINE_DEVICE                                     |
|               | parameterid   | MVIP95_INPUT_GAIN or MVIP95_OUTPUT_GAIN                       |
| <b>buffer</b> |               | Points to the NMS_LINE_GAIN_PARMS structure.                  |
| <b>size</b>   |               | Size of buffer, in bytes.                                     |

The NMS\_LINE\_GAIN\_PARMS structure is:

```
typedef struct
{
    INT32 gain;
} NMS_LINE_GAIN_PARMS;
```

Multiply the desired gain setting in dB by 1000. For example, to set the input line gain on a network voice port to -4 dB, set the gain field of NMS\_LINE\_GAIN\_PARMS to -4000.

The following sample code shows how to configure gain applied to a signal received from the network:

```
#include "swidef.h" /* CT Access Switching service */
#include "mvip95.h" /* MVIP-95 definitions */
#include "nmshw.h" /* NMS hardware-specific definitions */

DWORD mySetReceiveGain ( SWIHD swihd, SWI_TERMINUS terminus, INT32 gain_dB )
{
    SWI_LOCALTIMESLOT_ARGS args;
    NMS_LINE_GAIN_PARMS device ;

    args.localstream = terminus.stream ;
    args.localtimeslot = terminus.timeslot ;
    args.deviceid = MVIP95_ANALOG_LINE_DEVICE ;
    args.parameterid = MVIP95_INPUT_GAIN ;

    device.gain = gain_dB * 1000 ;

    return swiConfigLocalTimeslot (
        /* CT Access switch handle */ swihd,
        /* target device and config item */ & args,
        /* buffer (defined by parameterid) */ (void*) & device,
        /* buffer size in bytes */ sizeof(device));
}
```



The following sample code shows how to configure line gain applied to a signal transmitted to the network:

```
#include "swidef.h" /* CT Access Switching service */
#include "mvip95.h" /* MVIP-95 definitions */
#include "nmshw.h" /* NMS hardware-specific definitions */
*/
DWORD mySetTransmitGain ( SWIHD swihd, SWI_TERMINUS terminus, INT32 gain_dB )
{
    SWI_LOCALTIMESLOT_ARGS args;
    NMS_LINE_GAIN_PARAMS device ;

    args.localstream      = terminus.stream ;
    args.localtimeslot    = terminus.timeslot ;
    args.deviceid         = MVIP95_ANALOG_LINE_DEVICE ;
    args.parameterid      = MVIP95_OUTPUT_GAIN ;

    device.gain = gain_dB * 1000 ;

    return swiConfigLocalTimeslot (
        /* CT Access switch handle */ swihd,
        /* target device and config item */ & args,
        /* buffer (defined by parameterid) */ (void*) & device,
        /* buffer size in bytes */ sizeof(device));
}
```



---

# 9

## Keyword summary

---

### Using keywords

---

The keywords for an AG 2000C board describe that board's configuration. Some keywords are read/write; others are read-only:

| Keyword type              | Description   |
|---------------------------|---|
| Read/write (editable)     | Determines how the board is configured when it starts up. Changes to these keywords become effective after the board is rebooted. |
| Read-only (informational) | Indicates the board's current configuration. Read-only keywords cannot be modified.   |

This topic describes:

- Setting keyword values
- Retrieving keyword values

**Note:** To learn how to use NMS OAM utilities such as *oamsys* and *oamcfg*, refer to the *NMS OAM System User's Manual*. To learn about setting and retrieving keywords using OAM service functions, refer to the *NMS OAM Service Developer's Reference Manual*.

AG plug-in keywords exist in a separate record in the NMS OAM database. They indicate certain board family-level information.

A keyword has the general syntax:

***keyword = value***

Keywords are not case sensitive except where operating system conventions prevail (for example, file names under UNIX). All values are strings, or strings that represent integers. An integer keyword can have a fixed numeric range of legal values. A string keyword can support a fixed set of legal values, or can accept any string.

## Setting keyword values

---

There are several ways to set the values of read/write keywords:

- Use or modify one of the sample board keyword files corresponding to your country and board type. Specify the name of this new file in the File statement in *oamsys.cfg*, and run *oamsys* again. Refer to the *NMS OAM System User's Manual* for information about the syntax of board keyword files.

**Note:** Using *oamsys* reboots all boards in the system.

- Create a new board keyword file, either with additional keywords or keywords whose values override earlier settings.
- Specify parameter settings using the *oamcfg* utility. Refer to the *NMS OAM System User's Manual* for information about *oamcfg*.
- Specify the settings using OAM service functions. Refer to the *NMS OAM Service Developer's Reference Manual* for more information.

To set board keywords, specify the board name in the system configuration file or on the *oamcfg* command line. To set AG plug-in level keywords, specify the AG plug-in name (*agplugin.bpi*).

**Note:** Keyword values take effect after the board is rebooted.

## Retrieving keyword values

---

To retrieve the values of read/write and read-only keywords:

- Run the *oaminfo* sample program. On the command line, specify the board using either its name (with the `-n` option) or number (with the `-b` option):

```
oaminfo -n boardname  
oaminfo -b boardnum
```

To access AG plug-in level keywords, specify the AG plug-in name on the command line:

```
oaminfo -n agplugin.bpi
```

*oaminfo* returns a complete list of keywords and values. For more information about *oaminfo*, refer to the *NMS OAM Service Developer's Reference Manual*.

- Use the OAM service. Refer to the *NMS OAM Service Developer's Reference Manual* for more information.

## Editable keywords

The following table summarizes the keywords that you can change:

| If you want to...   | Use these keywords...   |
|---|---|
| Specify whether the board is started or stopped automatically | AutoStart<br>AutoStop   |
| Specify the board location                                    | Location.PCI.Bus (set in the <i>oamsys.cfg</i> file)<br>Location.PCI.Slot (set in the <i>oamsys.cfg</i> file)   |
| Specify information about the board                           | LoadFile<br>LoadSize<br>Name (set in the <i>oamsys.cfg</i> file)<br>Number (set in the <i>oamsys.cfg</i> file)<br>DLMFiles[x]<br>RunFile<br>TCPFiles[x] |
| Change the QSLAC file   | NetworkInterface.Analog[x].ConfigFile   |
| Set up test level information                                 | BootDiagnosticLevel   |
| Modify memory allocation                                      | Buffers[x].Num<br>Buffers[x].Size<br>MaxChannels  |
| Set up clocking information                                   | Clocking.HBus.ClockMode<br>Clocking.HBus.ClockSource<br>Clocking.HBus.Segment   |
| Configure clock automatic fallback                            | Clocking.HBus.AutoFallBack<br>Clocking.HBus.FallBackClockSource   |
| Set up information specific to NETREF                         | Clocking.HBus.NetRefSource<br>Clocking.HBus.NetRefSpeed   |
| Set up switching information                                  | SwitchConnections<br>SwitchConnectMode  |
| Control switching on the echo canceller reference stream      | Echo.AutoSwitchingRefSource<br>Echo.EnableExternalPins  |
| Configure DSPs  | DSP.C5x[x].Image<br>DSP.C5x.Lib<br>DSP.C5x.Loader<br>DSP.C5x[x].Os<br>DSP.C5x[x].Files[y]<br>SignalIdleCode<br>VoiceIdleCode<br>Xlaw                    |

## Informational keywords

---

You cannot edit the keywords listed in this topic. Use these keywords for retrieving information about the:

- Board
- EEPROM
- Board driver

### Retrieving board information

---

| Keyword       | Type   | Description  |
|---------------|--------|--|
| Location.Type | String | Host system's bus type.  |
| Product       | String | At the board level, the product type of the board.                         |
| State         | String | State of the physical board. Expected values are IDLE, BOOTED, or TESTING. |

### Retrieving EEPROM information

---

| Keyword                      | Type    | Description  |
|------------------------------|---------|--|
| Eeprom.AssemblyRevision      | Integer | Hardware assembly level.   |
| Eeprom.BoardSpecific         | Integer | Board-specific data.   |
| Eeprom.BusClkDiv             | Integer | Bus speed is equal to 2 x CPU speed busclkdiv.                         |
| Eeprom.CheckSum              | Integer | EEPROM checksum.   |
| Eeprom.CPUSpeed              | Integer | Coprocessor speed in MHz.  |
| Eeprom.DRAMSize              | Integer | DRAM size in kilobytes.  |
| EEprom.DSPSpeed              | Integer | DSP processor speed in MHz.  |
| EEprom.Family                | Integer | Board family.  |
| Eeprom.MFGWeek               | Integer | Week of the last full test.  |
| Eeprom.MFGYear               | Integer | Year of the last full test.  |
| Eeprom.MSBusType             | Integer | Media stream bus type. H.110 = 1                                       |
| Eeprom.NumDSPCores           | Integer | Total number of DSP cores on the motherboard.                          |
| Eeprom.SerialNum             | Integer | Serial number unique to each board. This number is factory configured. |
| Eeprom.SoftwareCompatibility | Integer | Minimum software revision level.                                       |
| Eeprom.SRAMSize              | Integer | SRAM size in kilobytes.  |
| Eeprom.SubType               | Integer | AG family variant information.   |

## Retrieving board driver information

---

| Keyword           | Type   | Description   |
|-------------------|--------|---|
| Driver.BoardID    | String | Board driver ID for the current board. Each board accessed by a driver has a unique ID. However, two boards accessed by different drivers can have the same driver ID number. |
| Driver.Name       | String | Operating system independent root name of the driver, for example, ag.  |
| SwitchDriver.Name | String | Operating system independent root name of the switching driver. Expected value is AGSW.   |

## Plug-in keywords

---

The AG plug-in keywords are:

- Boards[x]
- LoadSize
- Products[x]
- Version.Major
- Version.Minor





---

# 10 Keyword reference

---

## Using the keyword reference

---

The keywords are presented in detail in the following topics. Each keyword description includes:

|                       |   |
|-----------------------|---|
| <b>Syntax</b>         | The syntax of the keyword                                 |
| <b>Access</b>         | Read/write or read-only                                   |
| <b>Type</b>           | The data type of the value: string, integer, or file name |
| <b>Default</b>        | Default value   |
| <b>Allowed values</b> | A list of all possible values                             |
| <b>Example</b>        | An example of usage                                       |
| <b>Details</b>        | A detailed description of the keyword's function          |
| <b>See also</b>       | A list of related keywords                                |

## AutoStart

---

Specifies whether the board automatically starts when *ctdaemon* is started or the board is Hot Swap inserted.

### Syntax

AutoStart = **setting**

### Access

Read/Write

### Type

String

### Default

NO

### Allowed values

YES | NO

### Example

```
AutoStart = NO
```

### Details

The Supervisor keyword `AutoStartEnabled` enables or disables the autostart feature. If `AutoStartEnabled` is set to YES, the Supervisor starts each board whose `AutoStart` keyword is set to YES when *ctdaemon* is started. If `AutoStartEnabled` is set to NO, no boards are started automatically, regardless of the setting of the `AutoStart` keyword.

For more information, refer to the *NMS OAM System User's Manual*.

### See also

AutoStop

## AutoStop

---

Specifies whether the board automatically stops when *ctdaemon* is stopped.

### Syntax

AutoStop = **setting**

### Access

Read/Write

### Type

String

### Default

NO

### Allowed values

YES | NO

### Example

```
AutoStop = NO
```

### Details

The Supervisor keyword `AutoStopEnabled` enables or disables the autostop feature. If `AutoStopEnabled` is set to YES, the Supervisor stops each board whose `AutoStop` keyword is set to YES when *ctdaemon* is stopped. If `AutoStopEnabled` is set to NO, no boards are stopped automatically, regardless of the setting of the `AutoStop` keyword.

For more information, refer to the *NMS OAM System User's Manual*.

### See also

AutoStart

## **Boards[x]**

---

Specifies the name of the board object that is managed by the AG plug-in.

### **Syntax**

Boards[x] = ***boardname***

**x** = the index of the Board array keyword.

### **Access**

Read-only (AG plug-in level)

### **Type**

String

### **Allowed values**

Any board name.

### **See also**

Name, Number

## BootDiagnosticLevel

---

Specifies the level of diagnostics during initialization of the board.

### Syntax

BootDiagnosticLevel = ***level***

### Access

Read/Write

### Type

Integer

### Default

2

### Allowed values

0 | 1 | 2 | 3

### Example

```
BootDiagnosticLevel = 2
```

### Details

This value takes precedence over the corresponding value of the BootDiagnosticLevel keyword set in the system configuration file.

The valid values for ***level*** are 0, 1, 2, and 3. Zero (0) indicates that no diagnostics are performed, and 3 is the maximum level. The trade-off for higher levels of diagnostics is the increased time needed to initialize each AG board at load time.

If a test fails, the test number is reported back as the error code. Some tests can pass back more than one error code depending on the options selected, the mode of failure, or both. Some tests report additional information.

The following tests are performed during the boot diagnostics:

| Test number | Description  | Error code | # WDS | Error number  |
|-------------|--|------------|-------|---|
| 1           | Coprocessor booted by writing 11h to SRAM base address.  |            |       |   |
|             | <ul style="list-style-type: none"> <li>Coprocessor never booted at all.</li> </ul>   | 1          |       |   |
|             | <ul style="list-style-type: none"> <li>Coprocessor booted but crashed after writing to SRAM base address.</li> </ul>                     | 11h        |       |   |
|             | <ul style="list-style-type: none"> <li>aaaah option switch selected and coprocessor crashed after updating SRAM base address.</li> </ul> | aaaah      |       |   |
| 2           | Verifies the board type.   | 2          | 1     |   |
| 3           | Checks the DRAM size and BUSCLK programmed in the EEPROM, and sets up the part accordingly if valid EEPROM choice.                       | 3          | 1     |   |
| 4           | Tests DSP control and status registers.  | 4          | 2     |   |
| 6           | Tests DRAM.  | 6          | 4     |   |
| 7           | Tests DSPs.  | 7          | 5     |   |
| 8           | Serial port test.  |            |       |   |
|             | <ul style="list-style-type: none"> <li>Failed internal loopback test. Wrote a 49h and received something else back.</li> </ul>           | 8          | 2     |   |
| 9           | HMIC tests   |            |       | Refer to the following tables for an explanation of the error number. |
|             | <ul style="list-style-type: none"> <li>Failed I/O test.</li> </ul>   | 9          | 5     | 1   |
|             | <ul style="list-style-type: none"> <li>Failed register test.</li> </ul>  | 9          | 5     | 1   |
|             | <ul style="list-style-type: none"> <li>Failed CAM test.</li> </ul>   | 9          | 5     | 2   |
|             | <ul style="list-style-type: none"> <li>Failed local connections test.</li> </ul>   | 9          | 5     | 3   |
| 12          | DSP HPI tests.   | 12         | 4     |   |

The following information is reported back to the host when there is a diagnostic failure:

| Error code |       | WORD1   | WORD2                 | WORD3   | WORD4                 | WORD5                      |
|------------|-------|---|-----------------------|---------|-----------------------|----------------------------|
|            | # WDS | Additional data                               |                       |         |                       |                            |
| 1          | None  |   |                       |         |                       |                            |
| 2          | 1     | EEPROM board type                             |                       |         |                       |                            |
| 3          | 1     | EEPROM DRAM size word                         |                       |         |                       |                            |
| 4          | 2     | written                                       | read (masked by 0xfh) |         |                       |                            |
| 6          | 4     | address lo                                    | address hi            | written | read                  |                            |
| 7          | 5     | # DSPs booted                                 | Number expected       | test ID | memory failed address | contents of failed address |
| 8          | 2     | written                                       | read                  |         |                       |                            |
| 9          | 5     | See the following table for more information. |                       |         |                       |                            |
| 12         | 4     | 00 = HPIA test<br>01 = HPI memory test        | DSP number            | Written | Read                  |                            |

The following information is reported back to the host for error code 9 when there is a diagnostic failure:

| # WDS | HMIC ID | Error number | Address                   | Write | Read |
|-------|---------|--------------|---------------------------|-------|------|
| 5     | 0       | 1            | 5aa5                      | Write | Read |
| 5     | 0       | 1            | Register number           | Write | Read |
| 5     | 0       | 2            | CAM address               | Write | Read |
| 5     | 0       | 3            | Local connections address | Write | Read |

## Buffers[x].Num

---

Specifies the number of buffers available for play and record.

Buffers[2].Num is required for NMS Fusion systems.

### Syntax

Buffers[x].Num = **buffercount**

x = 0 - 2

### Access

Read/Write

### Type

Integer

### Default

| Index 0 large | Index 1 medium | Index 2 small |
|---------------|----------------|---------------|
| 48            | 0              | 96            |

### Allowed values

Based on the available board memory.

### Details

By default, two buffers are allocated per channel. For simultaneous play and record, you must configure four buffers per channel.

### Example

```
Buffers[0].Num = 16
```

### See also

Buffers[x].Size, MaxChannels



## Buffers[x].Size

---

Specifies the size, in bytes, of buffers used for play and record.

### Syntax

Buffers[x].Size = **size**

### Access

Read/Write

### Type

Integer

### Default

| Index | Default value |
|-------|---------------|
| 0     | 16400         |
| 1     | 1024          |
| 2     | 92            |

### Allowed values

0 - 1000000

### Example

```
Buffers[0].Size = 16400
```

### Details

The default buffer size is 16400.

Buffers[1].Size affects ISDN and some NMS Fusion systems. The default is 1024.

Small buffers (index[2]) cannot be configured.

### See also

Buffers[x].Num

## Clocking.HBus.AutoFallback

---

Enables or disables clock fallback on the board.

For information about setting up CT bus clocking, and rules and restrictions for configuring CT bus clocking, refer to *Configuring board clocking* on page 36.

### Syntax

Clocking.HBus.AutoFallback = *mode*

### Access

Read/Write

### Type

String

### Default

NO

### Allowed values

YES | NO

### Example

```
Clocking.HBus.AutoFallback = YES
```

### Details

When set to YES, this keyword specifies whether or not the board automatically switches between the two clock timing references specified by the Clocking.HBus.ClockSource and Clocking.HBus.FallBackClockSource keywords. The Clocking.HBus.AutoFallback keyword applies for all modes specified by the Clocking.HBus.ClockMode keyword.

The fallback timing reference clock is selected by the Clocking.HBus.FallBackClockSource keyword. Both of the physical timing references specified by the Clocking.HBus.ClockSource and Clocking.HBus.FallBackClockSource keywords must be present and not in alarm when the board's clocking is set up.

NO indicates that the system does not fallback to the backup timing reference.

Specify the primary clock and fallback clock with the Clocking.HBus.ClockSource and Clocking.HBus.FallBackClockSource keywords.

If the board is configured as the primary master or in standalone mode, this keyword enables the board to switch to the secondary timing reference when the first source goes into an alarm state. If the primary source returns, the board's timing reference switches back to the primary source. The *showclks* utility program can be used to determine what timing reference the board is actively using.

For an AG board configured as a secondary clock master or as a clock slave, this keyword enables the board to switch to an alternative timing reference when the first source goes into an alarm state. The board does not return to the first timing reference if the timing reference recovers. The host application must perform any further clock configuration operations.

For more information about clock fallback, refer to the *Switching Service Developer's Reference Manual*.

To support clock fallback on an AG board, refer to the NMS web site ([www.nmscommunications.com](http://www.nmscommunications.com)) for application notes and other updates.

## Clocking.HBus.ClockMode

---

Specifies the board's control of the H.110 clock.

For information about setting up CT bus clocking, and rules and restrictions for configuring CT bus clocking, refer to *Configuring board clocking* on page 36.

### Syntax

Clocking.HBus.ClockMode = *clockmode*

### Access

Read/Write

### Type

String

### Default

STANDALONE

### Allowed values

MASTER\_A | MASTER\_B | SLAVE | STANDALONE

### Example

```
Clocking.HBus.ClockMode = MASTER_A
```

### Details

Valid entries for the keyword include:

| Value      | Description  |
|------------|--|
| MASTER_A   | The board is used to drive the CT bus A clock based on the timing information derived from a clocking source.  |
| MASTER_B   | The board is used to drive the CT bus B clock based on the timing information derived from a clocking source.  |
| SLAVE      | The board acts as a clock slave, deriving its timing from the primary bus master.<br><b>Note:</b> Connections are allowed to the board's CT bus timeslots.   |
| STANDALONE | The board references its timing signal from its own oscillator and does not drive any CT bus timing signal clocks.<br><b>Note:</b> Connections are not allowed to the board's CT bus timeslots in standalone mode. |

For more information, refer to *Default connections* on page 51.

### See also

Clocking.HBus.AutoFallback, Clocking.HBus.ClockSource

## Clocking.HBus.ClockSource

---

Specifies the clock reference origin.

For information about setting up CT bus clocking, and rules and restrictions for configuring CT bus clocking, refer to *Configuring board clocking* on page 36.

### Syntax

Clocking.HBus.ClockSource = ***clock\_source***

### Access

Read/Write

### Type

String

### Default

OSC

### Allowed values

OSC | A\_CLOCK | B\_CLOCK

### Example

```
Clocking.HBus.ClockSource = OSC
```

### Details

Valid entries for the keyword include:

| Value   | Description   |
|---------|---|
| OSC     | Uses the on-board oscillator as a reference.  |
| A_CLOCK | Causes the board to act as a clock slave to the H.110 bus A clock by deriving the local clock from the bus. Another H.110 board (or H.100 board) must drive the clock on the bus. |
| B_CLOCK | Causes the board to act as a clock slave to the H.110 bus B clock by deriving the local clock from the bus. Another H.110 board (or H.100 board) must drive the clock on the bus. |

## Clocking.HBus.FallBackClockSource

---

Specifies the alternate clock reference to use when the master clock does not function properly.

For information about setting up CT bus clocking, and rules and restrictions for configuring CT bus clocking, refer to *Configuring board clocking* on page 36.

### Syntax

Clocking.HBus.FallBackClockSource = **clock\_source**

### Access

Read/Write

### Type

String

### Default

OSC

### Allowed values

OSC | A\_CLOCK | B\_CLOCK

### Example

```
Clocking.HBus.FallBackClockSource = OSC
```

### Details

If the Clocking.HBus.AutoFallBack keyword is set to NO, this keyword is ignored.

For more information about clock fallback, refer to the *Switching Service Developer's Reference Manual*.

To support clock fallback on an AG board, refer to the NMS web site ([www.nmscommunications.com](http://www.nmscommunications.com)) for application notes and other updates.

## Clocking.HBus.NetRefSource

---

Specifies a source to drive the NETREF timing signal on the CT bus.

For information about setting up CT bus clocking, and rules and restrictions for configuring CT bus clocking, refer to *Configuring board clocking* on page 36.

### Syntax

Clocking.HBus.NetRefSource = **source**

### Access

Read/Write

### Type

String

### Default

STANDALONE

### Allowed values

OSC | STANDALONE

### Example

```
Clocking.HBus.NetRefSource = OSC
```

### Details

| Value      | Description   |
|------------|---|
| OSC        | The clock uses the board's local oscillator (for diagnostics only). |
| STANDALONE | The NETREF clock is not driven by this board.                       |

### See also

Clocking.HBus.NetRefSpeed

## Clocking.HBus.NetRefSpeed

---

Indicates the speed of the NETREF timing signal on the CT bus.

For information about setting up CT bus clocking, and rules and restrictions for configuring CT bus clocking, refer to *Configuring board clocking* on page 36.

### Syntax

Clocking.HBus.NetRefSpeed = *speed*

### Access

Read/Write

### Type

String

### Default

8K

### Allowed values

8K

### Example

```
Clocking.HBus.NetRefSpeed = 8K
```

### See also

Clocking.HBus.NetRefSource



## **Clocking.HBus.Segment**

---

Specifies the CT bus segment into which the board is connected. In most cases, the chassis contains only one segment.

### **Syntax**

Clocking.HBus.Segment = *number*

### **Access**

Read/Write

### **Type**

Integer

### **Default**

1

### **Allowed values**

Non-zero integer

### **Example**

```
Clocking.HBus.Segment = 1
```

## DLMFiles[x]

---

Specifies a runtime component (modular extension to the core file) to be transferred to the board by the configuration file.

### Syntax

DLMFiles[x] = **filename**

x = 0..63

### Access

Read/Write

### Type

String

### Default

None.

### Allowed values

A valid file name.

### Example

```
DLMFiles[0] = ag2fax.leo
```

### Details

A *.leo* (loadable extensible object) file is a type of run module. For AG boards, the software that runs on the board coprocessor consists of the core file and any run modules.

The following *.leo* files are included with and need to be configured with AG 2000C boards:

| File name        | Description              |
|------------------|--------------------------|
| <i>svc.leo</i>   | DSP function manager.    |
| <i>gtp.leo</i>   | Trunk protocol engine.   |
| <i>voice.leo</i> | Play and record manager. |

To use NaturalFax, you must specify the NaturalFax run module to be downloaded to the board.

DLMFiles[x] is required for AG 2000C boards.

### See also

RunFile

## **DSP.C5x.Lib**

---

Specifies the DSP library file for all DSPs on the board.

### **Syntax**

DSP.C5x.Lib = ***filename***

### **Access**

Read/Write

### **Type**

File name

### **Default**

*ag2liba.r54* if Xlaw = A-LAW

*ag2libu.r54* if Xlaw = MU-LAW

### **Allowed values**

A valid file name.

### **Example**

```
DSP.C5x.Lib = ag2liba.r54
```

### **See also**

DSP.C5x[x].Os

## DSP.C5x.Loader

---

Specifies the module to load DSP functions for boards.

### Syntax

DSP.C5x.Loader = **filename**

### Access

Read/Write

### Type

File name

### Default

*ag2boot.b54*

### Allowed values

A valid file name.

### Example

```
DSP.C5x.Loader = special.b54
```

### Details

The naming convention for DSP loader files is **filename.b54**.

### See also

DSP.C5x.Lib

## DSP.C5x[x].Files[y]

Specifies the name or the ID of a DSP file that targets a specific DSP.

### Syntax

DSP.C5x[x].Files[y] = **filename**

**x** = 0..3

**y** = file number

### Access

Read/Write

### Type

File name

### Default

None.

### Allowed values

A valid file name.

### Example

```
DSP.C5x[0..3].Files[0] = callp.m54
```

### Details

These files are automatically distributed among the various DSPs by the AG plug-in according to internal rules. The naming convention for files is **filename.m54**.

The following DSP files are available:

| DSP file             | Description   |
|----------------------|---|
| <i>adsir(_j).m54</i> | Contains the caller ID function that decodes the modem burst that occurs between the first and second rings on a loop start line. In addition, it contains the FSK data receiver. ( <i>_j</i> ) is the V.23 variant.  |
| <i>adsix(_j).m54</i> | Contains the FSK data transmitter. ( <i>_j</i> ) is the V.23 variant.   |
| <i>callp.m54</i>     | Contains voice and tone detectors used for call progress detection. Use for any outgoing or two-way trunk protocol and for call progress analysis.  |
| <i>dtmf.m54</i>      | Contains the DTMF receiver, energy and silence detector, and precise tone filter typically used for clear-down.   |
| <i>dtmfe.m54</i>     | A variant of <i>dtmf.m54</i> , optimized for use with the echo canceller ( <i>echo.m54</i> ). It yields better talk-off resistance but requires the echo canceller to achieve the best cut-through performance.<br><b>Note:</b> You must use the echo canceller with this function. |

| DSP file              | Description  |
|-----------------------|--|
| <i>echo.m54</i>       | <p>Contains the echo cancellation function. The echo canceller removes reflected transmit channel energy from the incoming signal, which improves DTMF detection and voice recognition while playing.</p> <p>NMS echo functions are characterized by two parameters: tail length and adaptation rate. Tail length represents the maximum duration of the echo that can be cancelled, in ms. The adaptation rate specifies the percentage of the echo canceller filter coefficients that are adapted every period.</p> <p>The echo function has an adapt period of 2 ms. Therefore, an echo function with a 20 ms tail length and 100% rate adapts all the coefficients in 2 ms while the same function with a 25% rate adapts in 8 ms.</p> |
| <i>echo_v3.m54</i>    | <p>Contains an improved echo cancellation function. This echo canceller presents a higher performance than the one in <i>echo.m54</i>. It also has a maximum tail length of 64 ms.</p> <p><b>Note:</b> Substitute <i>dtmf.m54</i> for <i>dtmf.m54</i> when using this echo canceller.</p>  |
| <i>echo_v4.m54</i>    | <p>Contains the improved echo cancellation functions available in <i>echo_v3.m54</i>, and also provides comfort noise generation and tone disabling features.</p>  |
| <i>g726.m54</i>       | <p>Contains ITU G.726 ADPCM play and record functions. G.726 is a standard for 32 kbit/s speech coding.</p> <p>These functions require considerably more DSP processing time than the functions in <i>voice.m54</i>.</p> <p><i>g6726.m54</i> is required if you start play and record with an encoding type of ADI_ENCODE_G726.</p>  |
| <i>gsm_ms.m54</i>     | <p>Contains MS-GSM play and record functions. The 13 kbit/s full rate GSM speech codec is in Microsoft formatted frames.</p>   |
| <i>gsm_mspl.m54</i>   | <p>Contains identical play and record functions as <i>gsm_ms.m54</i> except that the maximum output power of the play function is limited.</p>   |
| <i>ima.m54</i>        | <p>Contains IMA ADPCM play and record functions. IMA is a standard for 32 kbit/s speech encoding.</p>  |
| <i>mf.m54</i>         | <p>Contains the multi-frequency receiver which is required for any trunk protocol (TCP) that uses MF signaling, and required by the MF detector.</p>   |
| <i>ptf.m54</i>        | <p>Contains precise tone filters. Typically used for CNG, CED, or custom tone detection.</p>   |
| <i>oki.m54</i>        | <p>Contains play and record functions for OKI ADPCM speech encoding, at 24 kbit/s or 32 kbit/s (used to play and record compatible voice files).</p>   |
| <i>rvoice.m54</i>     | <p>Contains PCM play and record functions.</p> <p><i>rvoice.m54</i> is required to play or record with an encoding of ADI_ENCODE_MULAW, ADI_ENCODE_ALAW, or ADI_ENCODE_PCM8M16.</p>  |
| <i>rvoice_vad.m54</i> | <p>Contains PCM play and record functions. Record functions can enable the voice activity detection (VAD) capability.</p> <p><i>rvoice_vad.m54</i> is required to play or record with an encoding of ADI_ENCODE_MULAW, ADI_ENCODE_ALAW, or ADI_ENCODE_PCM8M16.</p>   |
| <i>signal.m54</i>     | <p>Contains signaling, ring detector, and pulse functions. These are out of band functions which typically operate on the MVIP signaling stream. This file is required for:</p> <ul style="list-style-type: none"> <li>• Any trunk protocol except NOCC</li> <li>• The signal detector</li> <li>• Sending a pulse</li> </ul>   |

| DSP file         | Description  |
|------------------|--|
| <i>tone.m54</i>  | Contains the tone generation function. This file is required for any trunk protocol except NOCC. It is also required for generating tones, generating DTMF tones, MF tones, initiating dialing, and for generating a beep tone with any second record function.  |
| <i>voice.m54</i> | Contains NMS ADPCM play and record functions. The compressed speech is in a framed format with 20 milliseconds of data per frame. Speech is compressed to 16, 24, or 32 kbit/s or stored as uncompressed mu-law or A-law (64 kbit/s). This file is required to play or record with encoding values of ADI_ENCODE_NMS_16, ADI_ENCODE_NMS_24, ADI_ENCODE_NMS_32, or ADI_ENCODE_NMS_64. |
| <i>wave.m54</i>  | Contains play and record functions for PCM speech in formats commonly used in WAVE files, including 8 and 16 bit 11 kHz sampling.  |

Refer to *Functions for managing resources* on page 117 for information about the DSP resources available on each board and the DSP requirements for each ADI service function.

Refer to *DSP/task processor files and processing power* on page 119 to estimate the DSP requirements for your application and for instructions for re-configuring DSP resources if necessary.

## DSP.C5x[x].Image

---

Specifies the DSP image file for the processor.

### Syntax

DSP.C5x[x].Image = **filename**

**x** = 0..3

### Access

Read/Write

### Type

File name

### Default

None.

### Allowed values

A valid file name.

### Example

```
DSP.C5x[1].Image = ag2fax.c54
```

### Details

Specifies a pre-linked DSP image file for AG boards used by developers to develop their own DSP images.

The naming convention for DSP image files is **filename.c54**.

Setting DSP.C5x[x].Image = NULL leaves the specified DSP(s) in an unbooted state.



## **DSP.C5x[x].Os**

---

Defines the different operating systems per DSP.

### **Syntax**

DSP.C5x[x].Os = ***filename***

**x** = 0..3

### **Access**

Read/Write

### **Type**

File name

### **Default**

*dspos2f.k54* on all DSPs

### **Allowed values**

A valid file name.

### **Example**

```
DSP.C5x[1].Os = dspos2f.k54
```

## Echo.AutoSwitchingRefSource

---

Determines if the on-board switching manager performs automatic switching of the echo canceller reference stream.

### Syntax

Echo.AutoSwitchingRefSource = **setting**

### Access

Read/Write

### Type

String

### Default

NO

### Allowed values

NO | YES

### Example

```
Echo.AutoSwitchingRefSource = NO
```

### Details

Echo.EnableExternalPins must be set to YES to use the Echo.AutoSwitchingRefSource keyword.

Automatic switching occurs when a connection is made to a line from another line (or any other source) and when the destination line is also connected to a DSP that has echo cancellation enabled.

For example, using *swish*:

```
swish> openswitch b = agsw 0
swish> makeconnection b local:0:0 to local:17:0          # line 0 to DSP
swish> makeconnection b local:0:0 to local:1:1 duplex    # line 0 to/from line 1
```

The first connection connects DSP 0 to listen to line 0.

The second connection connects lines 0 and 1 together. The remote parties on line 0 and line 1 are able to talk to each other. DSP 0 is still monitoring line 0. This configuration is referred to as tromboning.

The switching manager automatically makes the following connection:

```
local:0:1 --> local:35:0
```

This connects line 1 to the echo canceller reference. It enables cancellation of echoes that occur on line 0 from energy originating on line 1.

## Echo.EnableExternalPins

---

Determines if the echo canceller reference and output can be switched.

### Syntax

Echo.EnableExternalPins = **setting**

### Access

Read/Write

### Type

String

### Default

NO

### Allowed values

NO | YES

### Example

```
Echo.EnableExternalPins = NO
```

### Details

Setting this keyword to YES enables the echo canceller reference input and the echo canceller output to be switched. They appear on output stream 34 and reference stream 35.

### See also

Echo.AutoSwitchingRefSource

## LoadFile

---

Specifies the boot loader for the board.

### Syntax

LoadFile = ***filename***

### Access

Read/Write

### Type

File name

### Default

*ag2000.lod*

### Allowed values

A valid file name.

### Example

Windows:

```
LoadFile = c:\nms\ag\load\ag2000.lod
```

UNIX:

```
LoadFile = /opt/nms/ag/load/ag2000.lod
```

### See also

LoadSize

## LoadSize

---

Indicates the coprocessor software download specified in the system configuration file.

### Syntax

LoadSize = *size*

### Access

Read/Write (AG plug-in level)

### Type

Integer

### Default

0x7500

### Allowed values

0 - 0xFFFF

### Example

```
LoadSize = 0x7500
```

### See also

LoadFile

## Location.PCI.Bus

---

Specifies the PCI logical bus location of the board.

### Syntax

Location.PCI.Bus = *busnum*

### Access

Read/Write

### Type

Integer

### Default

0

### Allowed values

0 - 255

### Example

```
Location.PCI.Bus = 0
```

### Details

Every PCI slot in the system is identified by a unique PCI logical bus and slot number. A CompactPCI board is identified in the system configuration file by specifying its logical bus and slot number.

This statement along with the Location.PCI.Slot keyword assigns the board number to the physical board.

Use *pciscan* to determine the PCI logical bus and slot assigned for all NMS PCI boards in the system. For more information, refer to the *NMS OAM System User's Manual*.

## Location.PCI.Slot

---

Defines the logical slot location of the board on the PCI bus.

### Syntax

Location.PCI.Slot = *slotnum*

### Access

Read/Write

### Type

Integer

### Default

0

### Allowed values

0 - 255

### Example

```
Location.PCI.Slot = 1
```

### Details

Every PCI slot in the system is identified by a unique PCI bus and slot number. A CompactPCI board is identified in the system configuration file by specifying its bus and slot number.

This statement along with Location.PCI.Bus assigns the board number to the physical board.

Use *pciscan* to determine the PCI bus and slot assigned for all NMS PCI boards in the system. For more information, refer to the *NMS OAM System User's Manual*.

## MaxChannels

---

Specifies the maximum number of channels to allocate on the board.

### Syntax

MaxChannels = *numChannels*

### Access

Read/Write

### Type

Integer

### Default

24

### Allowed values

1 - 255

### Example

```
MaxChannels = 128
```

### Details

The number of channels affects memory requirements. If Buffers[0].Num is not configured, two buffers are allocated per channel.

### See also

Buffers[x].Num



## **Name**

---

Specifies the name of the board.

### **Syntax**

Name = ***boardname***

### **Access**

Read/Write

### **Type**

String

### **Default**

None.

### **Allowed values**

Not applicable. The name can be up to 64 characters long.

### **Example**

```
Name = AG_2000C
```

### **See also**

Number

## NetworkInterface.Analog[x].ConfigFile

---

Specifies the country-specific file for AG 2000C loop start boards. Refer to *QSLAC files and trunk control programs* on page 35 for more information.

### Syntax

NetworkInterface.Analog[x].ConfigFile = **filename**

**x** = line number 0..23

### Access

Read/Write

### Type

Filename

### Default

| Filename            | Where used   |
|---------------------|--|
| <i>a2usals6.slc</i> | Default. Loop start for 600 Ohm PBXs in North America and South America. |
| <i>a2canls6.slc</i> | Loop start for 600 Ohm PBXs in Canada.                                   |
| <i>a2jpnl6.slc</i>  | Loop start for 600 Ohm PBXs in Japan.                                    |
| <i>a2usals9.slc</i> | Loop start for 900 Ohm PBXs in North America and South America.          |
| <i>a2canls9.slc</i> | Loop start for 900 Ohm PBXs in Canada.                                   |
| <i>a2jpnl9.slc</i>  | Loop start for 900 Ohm PBXs in Japan.                                    |
| <i>a2usalsn.slc</i> | PSTN connections in North America and South America.                     |
| <i>a2canlsn.slc</i> | PSTN connections in Canada.  |
| <i>a2jpnl9.slc</i>  | PSTN connections in Japan.   |
| <i>a2eurlsc.slc</i> | PSTN connections in the EU countries.                                    |
| <i>a2auslsc.slc</i> | PSTN connections for Australia.  |

### Allowed values

Valid QSLAC file name.

### Example

```
NetworkInterface.Analog[0..23].ConfigFile = a2usals9.slc
```

## Number

---

Specifies the logical board number for this board.

### Syntax

Number = **xxx**

### Access

Read/Write

### Type

Integer

### Default

0

### Allowed values

0 - 31

### Example

```
Number = 0
```

### Details

NMS OAM creates a board number that is guaranteed to be unique within a chassis. You can override this value.

### See also

Name

## **Products[x]**

---

At the AG plug-in level, indicates the product types supported by the plug-in.

### **Syntax**

Products[x] = ***product\_type***

### **Access**

Read-only (AG plug-in level)

### **Type**

String

### **Allowed values**

Not applicable.

### **Details**

The contents of the Products[x] keyword in the AG plug-in (and all other installed plug-ins) are added to the Supervisor array keyword Products[x] at startup. You can retrieve the values in the Supervisor keyword Products[x] to determine all products supported by all installed plug-ins.

### **See also**

Name

## RunFile

---

Specifies the runtime software to be transferred to the board.

### Syntax

RunFile = ***filename***

### Access

Read/Write

### Type

File name

### Default

*ag2000.cor*

### Example

```
RunFile = ag2000.cor
```

### Details

The RunFile is the core file that is used with module extension files (specified by DLMFiles[x]).

RunFile is not mandatory.

## SignalIdleCode

---

Specifies the signal bit patterns transmitted by an idle DSP or to an unconnected line interface. In general, a DSP is considered to be idle when no application is using it.

### Syntax

SignalIdleCode = ***signal\_idlecode***

### Access

Read/Write

### Type

Integer

### Default

0

### Allowed values

0x00 - 0xFF

### Example

```
SignalIdleCode = 0xd
```

### See also

VoiceIdleCode, Xlaw

## SwitchConnections

---

Specifies whether or not to nail up default connections.

### Syntax

SwitchConnections = **setting**

### Access

Read/Write

### Type

String

### Default

Auto

### Allowed values

Yes | No | Auto

### Example

```
SwitchConnections = Yes
```

### Details

Valid entries include the following values:

| Setting | Description   |
|---------|---|
| Yes     | Nails up connections independent of the Clocking.HBus.ClockMode setting.    |
| No      | Does not nail up connections.   |
| Auto    | Nails up connections automatically if Clocking.HBus.ClockMode = STANDALONE. |

When running the Point-to-Point Switching service, set SwitchConnections = No. Use the *ppx.cfg* file to define default connections. For more information, refer to the *Point-to-Point Switching Service Developer's Reference Manual*.

### See also

SwitchConnectMode

## SwitchConnectMode

---

Specifies the HMIC switch connect mode.

### Syntax

SwitchConnectMode = **setting**

### Access

Read/Write

### Type

String

### Default

ByChannel

### Allowed values

ByChannel | AllDirect | AllConstantDelay

### Example

```
SwitchConnectMode = AllConstantDelay
```

### Details

Valid entries include the following values:

| Option           | Description  |
|------------------|--|
| ByChannel        | The mode for each board connection depends on whether the connection is made using <b>swiMakeConnection</b> or <b>swiMakeFramedConnection</b> .  |
| AllDirect        | For all board connections, data is transferred directly from the source timeslot to the destination timeslot. For forward connections, (from lower-numbered timeslots to higher-numbered timeslots), data is transferred in the same time frame. For backward connections (from higher-numbered timeslots to lower-numbered timeslots), data is transferred in the next frame. |
| AllConstantDelay | Data is delayed so that the destination timeslot is always in the next frame regardless of whether it is a forward connection.   |

This keyword is used for configurations that transfer non-voice data in multiple timeslots (for example, HDLC in TDM).

For more information, refer to **swiMakeConnection** and **swiMakeFramedConnection** in the *Switching Service Developer's Reference Manual*.

### See also

SwitchConnections



## TCPFiles[x]

---

Specifies a trunk control program for the current boards.

### Syntax

TCPFiles[x] = **filename**

**x** = the number of the TCP file.

### Access

Read/Write

### Type

String

### Default

None.

### Allowed values

A valid file name.

### Example

```
TCPFiles[0] = nocc.tcp
```

### Details

Trunk control programs perform all signaling tasks necessary to interface with the telephony protocol used on the line or trunk. TCPs are loaded onto an NMS board during initialization. After a TCP is loaded, applications must start the protocol before they can use the TCP to perform call control on specific ports.

For more information about starting protocols on NMS boards, refer to the *ADI Service Developer's Reference Manual*. For more information about loading and running TCP files, refer to the *NMS CAS for Natural Call Control Developer's Manual* or to the *NMS ISDN for Natural Call Control Developer's Manual*.

**Note:** The TCPFiles[x] keyword is required for configurations that run CAS signaling protocols.

## **Version.Major**

---

Specifies the major version number of the AG plug-in. The Version.Major number is incremented if a change is made to the plug-in.

### **Syntax**

Version.Major = ***number***

### **Access**

Read-only (AG plug-in level)

### **Type**

Integer

### **Allowed values**

Not applicable.

### **See also**

Version.Minor

## **Version.Minor**

---

Specifies the minor version number of the AG plug-in. The Version.Minor value is changed when a change is made to the AG plug-in.

### **Syntax**

Version.Minor = ***number***

### **Access**

Read-only (AG plug-in level)

### **Type**

Integer

### **Allowed values**

Not applicable.

### **See also**

Version.Major

## VoiceIdleCode

---

Sets the voice bit pattern transmitted by an idle DSP or to an unconnected line interface.

### Syntax

VoiceIdleCode = ***voice\_idlecode***

### Access

Read/Write

### Type

Integer

### Default

If Xlaw = MU-LAW, default = 0x7f.

If Xlaw = A-LAW, default = 0xd5.

### Allowed values

0x00 - 0xFF

### Example

```
VoiceIdleCode = 0xd5
```

### Details

In general, a DSP is considered to be idle when no application is using it.

On digital trunks, the idle code is determined by local regulations and should not be altered.

### See also

SignalIdleCode

## **Xlaw**

---

Defines the switch idle codes.

### **Syntax**

Xlaw = ***compandmode***

### **Access**

Read/Write

### **Type**

String

### **Default**

MU-LAW

### **Allowed values**

A-LAW | MU-LAW

### **Example**

```
XLaw = MU-LAW
```

### **See also**

DSP.C5x[x].Files[y], SignalIdleCode, VoiceIdleCode



---

# 11 Hardware specifications

---

## General hardware specifications

---

This topic describes:

- Mechanical specifications
- H.110 compliant interface
- Host interface
- Environment
- Power requirements

## Mechanical specifications

---

The AG 2000C board has:

- 64K x 16 of SRAM
- A T8100A, which provides CT bus switching
- 4 MB of DRAM
- 100 MIPS C549 parts
- NS486SXL-25

|                      |   |
|----------------------|---|
| TDM bus              | Features one complete H.110 bus interface   |
| DSP processing power | Four Texas Instruments TMS320VC549GGU-100 DSPs at 100 MIPS  |
| Microprocessor       | One 25 MHz 80486-compatible embedded processor  |
| Board weight         | Main board: .80 lb (.36 kg)<br>Daughterboard: .05 lb (.02 kg)<br>Rear transition board: .35 lb (.16 kg) |
| Software             | Natural Access for Windows, UNIX, or Red Hat Linux  |

The AG 2000C board has indicators (LEDs) on the end bracket of the board as shown in Status indicator LEDs.

## H.110 compliant interface

---

- Flexible connectivity between line interfaces, DSPs, and H.110 bus.
- Switchable access to any of 4096 H.110 timeslots.
- H.110 clock master or clock slave (software-selectable).
- Compatible with any H.110-compliant telephony interface.

## Host interface

---

| Feature    | Specification   |
|------------|---|
| Electrical | CompactPCI bus designed to CompactPCI PICMG specification revision 2.1                |
| Mechanical | Designed to the <i>CompactPCI PICMG specification revision 2.1</i> for 6U style cards |
| Bus speed  | 33 MHz, 32-bit master or slave  |
| Memory     | 128 K on-board interface memory   |

## Environment

---

| Feature               | Description               |
|-----------------------|---------------------------|
| Operating temperature | 0 to 50 degrees C         |
| Storage temperature   | -20 to 70 degrees C       |
| Humidity              | 5% to 80%, non-condensing |

## Power requirements

---

### AG 2000C-24

+12V @ 200 mA

-12V @ 250 mA

+5 V @ 1.5 A (400 MIPS)

+3.3 V @ 0.5 A



## Common electrical specifications (United States version)

| Specification  | Description  |
|--|--|
| Connectors   | RJ-21x   |
| Return loss (ref. 600 Ohms +2.2 uF standard)               | 20 dB min. (ERL)   |
| 4 to 2 wire gain Tolerance                                 | +/- 1 dB   |
| 4 to 2 wire gain range                                     | +6 to -6 dB  |
| 2 to 4 wire gain Tolerance                                 | +/- 1 dB   |
| 2 to 4 wire gain range                                     | +6 to -6 dB  |
| Frequency response<br>300 Hz - 3200 Hz. Reference to 1 kHz | +/- 1 dB   |
| Trans-hybrid loss  | 17 dB min. @ 300 Hz-3.0 KHz into 600 Ohms + 2.2 uF   |
| Signal overload level                                      | +3 dBm at 0 dB gain  |
| CMRR   | > 80 dB  |
| T-R input impedance<br>(300 - 3200 Hz)                     | Voice band 600 Ohms +2.2 uF standard   |
| Idle channel noise through connection                      | < 20 dB rnC  |
| Crosstalk transmit to receive channels                     | < -70 dB @ 1 kHz   |
| T-R isolation to SELV                                      | >1500V <sub>RMS</sub>  |
| Off-hook detect  | Guaranteed Detect : Current > 10 mA<br>Guaranteed No Detect: Current < 3.3 mA                              |
| Operating loop current                                     | 18 mA to 70 mA   |
| Loop current and polarity detect                           | Single bit indicates if the current is flowing from Tip to Ring or Ring to Tip.                            |
| Ring detection   | Guaranteed Detect: 30 VRMS 17 - 33 Hz (US version)<br>Guaranteed No Detect: No detect <15 VRMS (0 - 5 kHz) |

## High impedance recording and caller ID mode

---

The loop start interface can be used in applications to record live telephone calls such as emergency calls or financial transactions. Special regulations require that parties be notified that they are being recorded. Check with authorities in the locality where the application is to be installed to determine what is permitted in that area.

The system cannot generate tones in this mode. The notification must be verbal.

|  |             |
|--|-------------|
| DC tip to ring resistance  | > 1 M Ohms  |
| Audio tip to ring impedance  | > 10 k Ohms |
| Typical receive audio loss<br>@ 0 dB line gain and 600 termination | 11 dB       |

The impedance of the agent's telephone and length of loop cable will affect the audio loss.

## QSLAC files and impedances

---

The QSLAC files that start with the characters *a2usa* provide an input impedance of 600 Ohms + 2.2 uF. However, a selection of files is provided to permit applications that do not use echo cancellation, to reduce echo. The default file is sufficient for most applications. For more information, refer to *Configuring and starting the system with oamsys* on page 30.

## Compliance and regulatory certification

---

In addition to the approval obtained by NMS for the board and its associated software, some countries require a system level approval before connecting the system to the public network. To learn what approvals you require, contact the appropriate regulatory authority in the target country.

This topic describes the following compliance and regulatory information:

- EMC
- Safety
- Telecom
- EU R&TTE statement

### EMC

---

|                 |   |
|-----------------|---|
| US              | FCC Part 15, Subpart J. Class A with unshielded cable   |
| Canada          | IECS- 003. Class A with unshielded cable  |
| EU countries    | EN 55022: (1998)<br>EN 55024: (1998)  |
| Other countries | Refer to the NMS web site ( <a href="http://www.nmscommunications.com">www.nmscommunications.com</a> ). |

### Safety

---

|                 |   |
|-----------------|---|
| US              | UL Std No. 60950, 3rd Ed.   |
| Canada          | CSA C22. 2 No. 60950-00, 3rd Ed.  |
| EU countries    | EN 60950: (1992 + Amendments 1 to 4)  |
| Other countries | Refer to the NMS web site ( <a href="http://www.nmscommunications.com">www.nmscommunications.com</a> ). |

### Telecom

---

|                 |   |
|-----------------|---|
| US              | FCC Part 68   |
| Canada          | ISC CS-03   |
| EU countries    | TBR 21 and EG 201 121   |
| Other countries | Refer to the NMS web site ( <a href="http://www.nmscommunications.com">www.nmscommunications.com</a> ). |

### EU R&TTE statement

---

This equipment has been approved in accordance with Council Decision 1999/5/ EC (R&TTE) for pan-European single terminal connection to the public switched telephone network (PSTN). However, due to differences between the individual PSTNs provided in different countries, the approval does not, of itself, give an unconditional assurance of successful operation on every PSTN network termination point. In the event of problems, contact your equipment supplier.

A copy of the R&TTE Declaration of Conformity is shipped with the board.



---

# 12 Managing resources

---

## Functions for managing resources

---

Most Natural Access functions implicitly use processes that run on the DSP resources. For example, **adiStartToneDetector** starts the tone detector function running on a DSP. **adiStartRecording** starts one of many voice compression functions running on a DSP. AG boards are shipped with default configurations that make the most commonly used functions available.

**Note:** It is not feasible or practical to make every possible function simultaneously available to an application.

This topic lists default functions and custom functions available for AG 2000C boards.

### Default functions

---

The following functions are available in the default configuration files shipped with AG 2000C boards:

- DTMF detection
- MF tone detection
- Tone detection
- Cleardown detection
- Signal detection
- NMS speech
- Call progress detection
- Tone generation

## Custom functions

---

The following functions can be loaded on AG 2000C boards with NMS OAM:

- Caller ID
- Echo cancellation
- ADSI
- NMS speech normal
- NMS speech 1.5X
- NMS speech 2.0X
- OKI speech normal
- OKI speech 1.5X
- OKI speech 2.0X
- IMA/DVI speech
- WAVE speech
- G.726 speech
- MS-GSM speech

The following functions can also reduce the board's standard port count of 24:

- Echo cancellation
- NMS speech 1.5X
- NMS speech 2.0X
- OKI speech 1.5X
- OKI speech 2.0X
- G.726 speech
- MS-GSM speech

## DSP/task processor files and processing power

The binary code for running functions is contained in DSP files. One or more functions are contained in each file. NMS boards differ in the total number of DSPs they contain and the speed of their DSPs on the board.

DSP speed is measured in millions of instructions per second (MIPS). Each function that runs on a DSP consumes MIPS. If the total MIPS consumption for all the requested functions on all the ports of a given board exceeds the total MIPS available for that board, an error event occurs. If MIPS-intensive functions are required, you can reduce the total number of ports on a board, which makes more MIPS per port available.

The following table shows the MIPS usage for all the available functions shipped with Natural Access:

| DSP file            | Function                         | MIPS | Related API function          | Related arguments                      |
|---------------------|----------------------------------|------|-------------------------------|--|
| <i>adsir.m54</i>    | ADSI receiver                    | 3.13 | <b>adiStartReceivingFSK</b>   |  |
| <i>adsix.m54</i>    | ADSI transmitter                 | 1.13 | <b>adiStartSendingFSK</b>     |  |
| <i>callp.m54</i>    | Call progress                    | 1.06 | <b>adiStartCallProgress</b>   |  |
| <i>dtmf.m54</i>     | DTMF only                        | 1.94 | <b>adiStartDTMFDetector</b>   |  |
| <i>dtmf.m54</i>     | Post- and pre-tone silence       | 0.69 | <b>adiStartEnergyDetector</b> |  |
| <i>dtmf.m54</i>     | DTMF, post- and pre-tone silence | 1.94 | <b>adiStartProtocol</b>       |  |
| <i>gsm_ms.m54</i>   | MS-GSM Play 8 kHz                | 2.13 | <b>adiStartPlaying</b>        | <b>encoding =</b><br>ADI_ENCODE_GSM    |
| <i>gsm_ms.m54</i>   | MS-GSM Record 8 kHz              | 4.44 | <b>adiStartRecording</b>      | <b>encoding =</b><br>ADI_ENCODE_GSM    |
| <i>gsm_mspl.m54</i> | MS-GSM Play limit 8 kHz          | 2.82 | <b>adiStartPlaying</b>        | <b>encoding =</b><br>ADI_ENCODE_GSM    |
| <i>gsm_mspl.m54</i> | MS-GSM Record 8 kHz              | 4.44 | <b>adiStartRecording</b>      | <b>encoding =</b><br>ADI_ENCODE_GSM    |
| <i>ima.m54</i>      | IMA/DVI ADPCM Play 6 kHz         | 2.06 | <b>adiStartPlaying</b>        | <b>encoding =</b><br>ADI_ENCODE_IMA_24 |
| <i>ima.m54</i>      | IMA/DVI ADPCM Play 8 kHz         | 1.81 | <b>adiStartPlaying</b>        | <b>encoding =</b><br>ADI_ENCODE_IMA_32 |
| <i>ima.m54</i>      | IMA/DVI ADPCM Record 6 kHz       | 2.19 | <b>adiStartRecording</b>      | <b>encoding =</b><br>ADI_ENCODE_IMA_24 |
| <i>ima.m54</i>      | IMA/DVI ADPCM Record 8 kHz       | 2.00 | <b>adiStartRecording</b>      | <b>encoding =</b><br>ADI_ENCODE_IMA_32 |

| DSP file          | Function                            | MIPS | Related API function        | Related arguments  |
|-------------------|-------------------------------------|------|-----------------------------|--|
| <i>mf.m54</i>     | Forward detect, backward compelling | 2.56 | <b>adiStartMFDetector</b>   |  |
| <i>mf.m54</i>     | Backward detect, forward compelling | 2.56 | <b>adiStartMFDetector</b>   |  |
| <i>mf.m54</i>     | MF detection                        | 1.81 | <b>adiStartMFDetector</b>   |  |
| <i>mf.m54</i>     | MF forward detection                | 1.81 | <b>adiStartMFDetector</b>   |  |
| <i>mf.m54</i>     | MF backward detection               | 1.81 | <b>adiStartMFDetector</b>   |  |
| <i>oki.m54</i>    | OKI Play<br>6 kHz                   | 2.19 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_OKI_24,<br><b>maxspeed</b> = 100 |
| <i>oki.m54</i>    | OKI Play<br>8 kHz                   | 2.13 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_OKI_32,<br><b>maxspeed</b> = 100 |
| <i>oki.m54</i>    | OKI Play<br>6 kHz 1.5X              | 4.19 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_OKI_24,<br><b>maxspeed</b> = 150 |
| <i>oki.m54</i>    | OKI Play<br>8 kHz 1.5X              | 3.63 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_OKI_32,<br><b>maxspeed</b> = 150 |
| <i>oki.m54</i>    | OKI Play<br>6 kHz 2.0X              | 5.50 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_OKI_24,<br><b>maxspeed</b> = 200 |
| <i>oki.m54</i>    | OKI Play<br>8 kHz 2.0X              | 4.81 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_OKI_32,<br><b>maxspeed</b> = 200 |
| <i>oki.m54</i>    | OKI Record<br>6 kHz                 | 2.25 | <b>adiStartRecording</b>    | <b>encoding</b> =<br>ADI_ENCODE_OKI_24                           |
| <i>oki.m54</i>    | OKI Record<br>8 kHz                 | 2.00 | <b>adiStartRecording</b>    | <b>encoding</b> =<br>ADI_ENCODE_OKI_32                           |
| <i>g726.m54</i>   | G.726 Play                          | 7.44 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_G726                             |
| <i>g726.m54</i>   | G.726 Record                        | 7.00 | <b>adiStartRecording</b>    | <b>encoding</b> =<br>ADI_ENCODE_G726                             |
| <i>ptf.m54</i>    | 2 single freq or<br>1 tone pair     | 1.25 | <b>adiStartToneDetector</b> |  |
| <i>ptf.m54</i>    | 4 single freq or<br>2 tone pair     | 1.81 | <b>adiStartCallProgress</b> | <b>precmask</b> !=0  |
| <i>rvoice.m54</i> | mu-law Play                         | 0.63 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_MULAW                            |
| <i>rvoice.m54</i> | A-law Play                          | 0.63 | <b>adiStartPlaying</b>      | <b>encoding</b> =<br>ADI_ENCODE_ALAW                             |



| DSP file              | Function                      | MIPS | Related API function   | Related arguments  |
|-----------------------|-------------------------------|------|--|--|
| <i>rvoice.m54</i>     | WAVE Play,<br>8 kHz, 16-bit   | 0.63 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_PCM8M16                          |
| <i>rvoice.m54</i>     | mu-law Record                 | 0.63 | <b>adiStartRecording</b>   | <b>encoding</b> =<br>ADI_ENCODE_MULAW                            |
| <i>rvoice.m54</i>     | A-law Record                  | 0.63 | <b>adiStartRecording</b>   | <b>encoding</b> =<br>ADI_ENCODE_ALAW                             |
| <i>rvoice.m54</i>     | WAVE Record,<br>8 kHz, 16-bit | 0.63 | <b>adiStartRecording</b>   | <b>encoding</b> =<br>ADI_ENCODE_PCM8M16                          |
| <i>rvoice_vad.m54</i> | mu-law Play                   | 0.63 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_MULAW                            |
| <i>rvoice_vad.m54</i> | A-law Play                    | 0.63 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_ALAW                             |
| <i>rvoice_vad.m54</i> | WAVE Play,<br>8 kHz, 16-bit   | 0.63 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_PCM8M16                          |
| <i>rvoice_vad.m54</i> | mu-law Record                 | 0.88 | <b>adiCommandRecord</b><br><b>adiStartRecording</b>                | <b>encoding</b> =<br>ADI_ENCODE_MULAW                            |
| <i>rvoice_vad.m54</i> | A-law Record                  | 0.88 | <b>adiCommandRecord</b><br><b>adiStartRecording</b>                | <b>encoding</b> =<br>ADI_ENCODE_ALAW                             |
| <i>rvoice_vad.m54</i> | WAVE Record,<br>8 kHz, 16-bit | 0.88 | <b>adiCommandRecord</b><br><b>adiStartRecording</b>                | <b>encoding</b> =<br>ADI_ENCODE_PCM8M16                          |
| <i>signal.m54</i>     | Pulse                         | 0.38 | <b>adiStartDial</b><br><b>adiStartPulse</b><br><b>nccPlaceCall</b> |  |
| <i>signal.m54</i>     | Bit Detector                  | 0.44 | <b>adiStartProtocol</b><br><b>adiStartSignalDetector</b>           |  |
| <i>tone.m54</i>       | Tone Generator                | 0.75 | <b>adiStartDial</b><br><b>adiStartDTMF</b><br><b>adiStartTones</b> |  |
| <i>voice.m54</i>      | NMS Play<br>16 Kbit/s         | 3.13 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_16,<br><b>maxspeed</b> = 100 |
| <i>voice.m54</i>      | NMS Play<br>24 Kbit/s         | 3.13 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_24,<br><b>maxspeed</b> = 100 |
| <i>voice.m54</i>      | NMS Play<br>32 Kbit/s         | 3.13 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_32,<br><b>maxspeed</b> = 100 |
| <i>voice.m54</i>      | NMS Play 64<br>Kbit/s         | 0.63 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_64,<br><b>maxspeed</b> = 100 |
| <i>voice.m54</i>      | NMS Play 16<br>6 kHz 1.5X     | 5.63 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_16,<br><b>maxspeed</b> = 150 |
| <i>voice.m54</i>      | NMS Play 24<br>6 kHz 1.5X     | 5.81 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_24,<br><b>maxspeed</b> = 150 |

| DSP file         | Function                     | MIPS | Related API function     | Related arguments  |
|------------------|------------------------------|------|--------------------------|--|
| <i>voice.m54</i> | NMS Play 32<br>6 kHz 1.5X    | 5.81 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_32,<br><b>maxspeed</b> = 150 |
| <i>voice.m54</i> | NMS Play 64<br>6 kHz 1.5X    | 2.31 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_64,<br><b>maxspeed</b> = 150 |
| <i>voice.m54</i> | NMS Play 16<br>6 kHz 2.0X    | 7.19 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_16,<br><b>maxspeed</b> = 200 |
| <i>voice.m54</i> | NMS Play 24<br>6 kHz 2.0X    | 7.50 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_24,<br><b>maxspeed</b> = 200 |
| <i>voice.m54</i> | NMS Play 32<br>6 kHz 2.0X    | 7.44 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_32,<br><b>maxspeed</b> = 200 |
| <i>voice.m54</i> | NMS Play 64<br>6 kHz 2.0X    | 2.81 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_NMS_64,<br><b>maxspeed</b> = 200 |
| <i>voice.m54</i> | NMS Record<br>16 Kbit/s      | 3.38 | <b>adiStartRecording</b> | <b>encoding</b> =<br>ADI_ENCODE_NMS_16                           |
| <i>voice.m54</i> | NMS Record<br>24 Kbit/s      | 3.38 | <b>adiStartRecording</b> | <b>encoding</b> =<br>ADI_ENCODE_NMS_24                           |
| <i>voice.m54</i> | NMS Record<br>32 Kbit/s      | 3.38 | <b>adiStartRecording</b> | <b>encoding</b> =<br>ADI_ENCODE_NMS_32                           |
| <i>voice.m54</i> | NMS Record<br>64 Kbit/s      | 0.63 | <b>adiStartRecording</b> | <b>encoding</b> =<br>ADI_ENCODE_NMS_64                           |
| <i>wave.m54</i>  | WAVE Play<br>11 kHz 8-bit    | 1.56 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_PCM11M8                          |
| <i>wave.m54</i>  | WAVE Play<br>11 kHz 16-bit   | 1.44 | <b>adiStartPlaying</b>   | <b>encoding</b> =<br>ADI_ENCODE_PCM11M16                         |
| <i>wave.m54</i>  | WAVE Record<br>11 kHz 8-bit  | 1.5  | <b>adiStartRecording</b> | <b>encoding</b> =<br>ADI_ENCODE_PCM11M8                          |
| <i>wave.m54</i>  | WAVE Record<br>11 kHz 16-bit | 1.13 | <b>adiStartRecording</b> | <b>encoding</b> =<br>ADI_ENCODE_PCM11M16                         |

The following table shows the correspondence between the filter and adapt values used for the echo canceller, and MIPS consumption:

| DSP file        | Filter length (ms) | Adapt time (ms) | MIPS |
|-----------------|--------------------|-----------------|------|
| <i>echo.m54</i> | 2                  | 100             | 2.75 |
| <i>echo.m54</i> | 2                  | 200             | 2.38 |
| <i>echo.m54</i> | 2                  | 400             | 2.25 |
| <i>echo.m54</i> | 2                  | 800             | 2.13 |
| <i>echo.m54</i> | 4                  | 100             | 3.13 |
| <i>echo.m54</i> | 4                  | 200             | 2.63 |

| <b>DSP file</b>    | <b>Filter length (ms)</b> | <b>Adapt time (ms)</b> | <b>MIPS</b> |
|--------------------|---------------------------|------------------------|-------------|
| <i>echo.m54</i>    | 4                         | 400                    | 2.38        |
| <i>echo.m54</i>    | 4                         | 800                    | 2.25        |
| <i>echo.m54</i>    | 6                         | 100                    | 3.50        |
| <i>echo.m54</i>    | 6                         | 200                    | 2.88        |
| <i>echo.m54</i>    | 6                         | 400                    | 2.63        |
| <i>echo.m54</i>    | 6                         | 800                    | 2.50        |
| <i>echo.m54</i>    | 8                         | 100                    | 3.88        |
| <i>echo.m54</i>    | 8                         | 200                    | 3.13        |
| <i>echo.m54</i>    | 8                         | 400                    | 2.88        |
| <i>echo.m54</i>    | 8                         | 800                    | 2.75        |
| <i>echo.m54</i>    | 10                        | 100                    | 4.25        |
| <i>echo.m54</i>    | 10                        | 200                    | 3.50        |
| <i>echo.m54</i>    | 10                        | 400                    | 3.00        |
| <i>echo.m54</i>    | 10                        | 800                    | 2.88        |
| <i>echo.m54</i>    | 16                        | 100                    | 5.25        |
| <i>echo.m54</i>    | 16                        | 200                    | 4.25        |
| <i>echo.m54</i>    | 16                        | 400                    | 3.63        |
| <i>echo.m54</i>    | 16                        | 800                    | 3.38        |
| <i>echo.m54</i>    | 20                        | 100                    | 5.63        |
| <i>echo.m54</i>    | 20                        | 200                    | 4.50        |
| <i>echo.m54</i>    | 20                        | 400                    | 3.88        |
| <i>echo.m54</i>    | 20                        | 800                    | 3.38        |
| <i>echo_v3.m54</i> | 24                        | 100                    | 8.56        |
| <i>echo_v3.m54</i> | 24                        | 200                    | 6.13        |
| <i>echo_v3.m54</i> | 24                        | 400                    | 4.88        |
| <i>echo_v3.m54</i> | 24                        | 800                    | 4.25        |
| <i>echo_v3.m54</i> | 32                        | 100                    | 10.75       |
| <i>echo_v3.m54</i> | 32                        | 200                    | 7.56        |
| <i>echo_v3.m54</i> | 32                        | 400                    | 5.94        |
| <i>echo_v3.m54</i> | 32                        | 800                    | 5.13        |
| <i>echo_v3.m54</i> | 40                        | 100                    | 13.00       |
| <i>echo_v3.m54</i> | 40                        | 200                    | 9.00        |
| <i>echo_v3.m54</i> | 40                        | 400                    | 7.00        |

| DSP file    | Filter length (ms) | Adapt time (ms) | MIPS  |
|-------------|--------------------|-----------------|-------|
| echo_v3.m54 | 40                 | 800             | 6.00  |
| echo_v3.m54 | 48                 | 100             | 15.25 |
| echo_v3.m54 | 48                 | 200             | 10.44 |
| echo_v3.m54 | 48                 | 400             | 8.06  |
| echo_v3.m54 | 48                 | 800             | 6.88  |
| echo_v3.m54 | 64                 | 100             | 19.69 |
| echo_v3.m54 | 64                 | 200             | 13.31 |
| echo_v3.m54 | 64                 | 400             | 10.19 |
| echo_v3.m54 | 64                 | 800             | 8.56  |
| echo_v4.m54 | 2                  | 100             | 4.125 |
| echo_v4.m54 | 2                  | 200             | 3.938 |
| echo_v4.m54 | 2                  | 400             | 3.875 |
| echo_v4.m54 | 2                  | 800             | 3.813 |
| echo_v4.m54 | 4                  | 100             | 4.438 |
| echo_v4.m54 | 4                  | 200             | 4.188 |
| echo_v4.m54 | 4                  | 400             | 4.063 |
| echo_v4.m54 | 4                  | 800             | 4.000 |
| echo_v4.m54 | 6                  | 100             | 4.750 |
| echo_v4.m54 | 6                  | 200             | 4.438 |
| echo_v4.m54 | 6                  | 400             | 4.313 |
| echo_v4.m54 | 6                  | 800             | 4.188 |
| echo_v4.m54 | 8                  | 100             | 5.063 |
| echo_v4.m54 | 8                  | 200             | 4.688 |
| echo_v4.m54 | 8                  | 400             | 4.500 |
| echo_v4.m54 | 8                  | 800             | 4.438 |
| echo_v4.m54 | 10                 | 100             | 5.375 |
| echo_v4.m54 | 10                 | 200             | 4.938 |
| echo_v4.m54 | 10                 | 400             | 4.750 |
| echo_v4.m54 | 10                 | 800             | 4.625 |
| echo_v4.m54 | 16                 | 100             | 6.313 |
| echo_v4.m54 | 16                 | 200             | 5.688 |
| echo_v4.m54 | 16                 | 400             | 5.375 |
| echo_v4.m54 | 16                 | 800             | 5.188 |

| <b>DSP file</b> | <b>Filter length (ms)</b> | <b>Adapt time (ms)</b> | <b>MIPS</b> |
|-----------------|---------------------------|------------------------|-------------|
| echo_v4.m54     | 20                        | 100                    | 6.938       |
| echo_v4.m54     | 20                        | 200                    | 6.188       |
| echo_v4.m54     | 20                        | 400                    | 5.813       |
| echo_v4.m54     | 20                        | 800                    | 5.625       |
| echo_v4.m54     | 24                        | 100                    | 10.375      |
| echo_v4.m54     | 24                        | 200                    | 7.938       |
| echo_v4.m54     | 24                        | 400                    | 6.750       |
| echo_v4.m54     | 24                        | 800                    | 6.125       |
| echo_v4.m54     | 32                        | 100                    | 12.625      |
| echo_v4.m54     | 32                        | 200                    | 9.375       |
| echo_v4.m54     | 32                        | 400                    | 7.813       |
| echo_v4.m54     | 32                        | 800                    | 7.000       |
| echo_v4.m54     | 40                        | 100                    | 14.813      |
| echo_v4.m54     | 40                        | 200                    | 10.875      |
| echo_v4.m54     | 40                        | 400                    | 8.875       |
| echo_v4.m54     | 40                        | 800                    | 7.875       |
| echo_v4.m54     | 48                        | 100                    | 17.063      |
| echo_v4.m54     | 48                        | 200                    | 12.313      |
| echo_v4.m54     | 48                        | 400                    | 9.938       |
| echo_v4.m54     | 48                        | 800                    | 8.750       |
| echo_v4.m54     | 64                        | 100                    | 21.500      |
| echo_v4.m54     | 64                        | 200                    | 15.188      |
| echo_v4.m54     | 64                        | 400                    | 12.000      |
| echo_v4.m54     | 64                        | 800                    | 10.438      |

## AG 2000C board processing

---

In most applications, all DSP functions can run on all DSPs on the board. Complex functions such as WAVE speech, echo cancellation, and variable speech rates can result in reduced number of ports.

Use the following table as a guideline for determining board functionality. There are additional constraints such as memory and queue sizes in determining required MIPS:

| AG board     | Total DSPs | MIPS per DSP | Operating system overhead per DSP (MIPS) | Available MIPS |
|--------------|------------|--------------|--|----------------|
| AG 2000C/400 | 4          | 100          | 10                                       | 360            |

AG 2000C boards can run six ports of 16-bit, 11 kHz PCM (ADI\_ENCODE\_PCM11M16) per available DSP.

---

# 13 Loop start signaling

---

## Signaling overview

---

This section describes how to interpret signaling to and from the AG 2000C loop start board.

The telephony protocol, embodied by a TCP running on the AG 2000C board, automatically controls and monitors the line signaling bits. This information is provided for reference only. Controlling the signaling bits manually may violate local telecommunications regulations.

The following table describes the two signaling directions:

| Signaling type | Description   |
|----------------|---|
| Transmit       | The signaling that the board sends out onto the phone line through the line interface. The transmit signal is used to control the line or phone.            |
| Receive        | This signaling comes from the phone line through the line interface to the board. An application can monitor this signal to detect loop current or ringing. |

The line interfaces on the board convert the signaling into the line condition appropriate for the loop start line. They also convert incoming information into digital signals recognizable by AG 2000C-based applications.


## Loop start transmit signaling

With loop start interfaces, the transmitted signaling A bit in the signaling timeslot causes the interface to seize the line (go off-hook) or release the line (go on-hook).

If the A bit is set to 1, the line goes off-hook. If the A bit is set to 0, the line goes on-hook.

Bits B, C, and D are reserved, and should be set to 0.

The following illustration shows transmit signaling for loop start line interfaces:



### Loop start transmit signaling

This table summarizes the transmit signaling for loop start line interfaces:

| Bit   | Hex bitmask | To take line off-hook | To put line on-hook |
|-------|-------------|-----------------------|---------------------|
| A bit | 0x08        | 0x08                  | 0                   |

If you reset the switch, all bits are set to 0.




## Loop start receive signaling

Depending on how the transmitted signaling A bit is set, the line has been placed on-hook or off-hook. Depending on the hook state, the received signaling A bit acts either as a ring signal detector or a loop current indicator. When the line is on-hook, monitoring the A bit tells you if the line is ringing. When the line is off-hook, monitoring the A bit indicates whether there is loop current flowing. The B bit indicates the polarity of tip and ring. If the B bit is set to 1, the loop current direction is reverse. Bits C and D are reserved, and should be ignored.

Regulations require that loop start equipment must function regardless of idle state polarity. The B bit normal state is undefined. The information in the B bit is in the change of state.

The following illustration shows receive signaling for loop start line interfaces:



### Loop start receive signaling

The following table summarizes the receive signaling for loop start line interfaces:

| Bit   | Hex bitmask | If line is off-hook  | If line is on-hook                                    |
|-------|-------------|--|---|
| A bit | 0x08        | Detects loop current:<br>0 = No loop current.<br>0x08 = Current is flowing.                                    | A bit toggles with ring frequency.<br>Idle state = 0. |
| B bit | 0x04        | Loop current direction:<br>0 = Tip positive with respect to ring.<br>0x04 = Tip negative with respect to ring. | 0   |
| C bit | N/A         | Reserved (should be ignored).  | Reserved (should be ignored).                         |
| D bit | N/A         | Reserved (should be ignored).  | Reserved (should be ignored).                         |



---

# 14 Natural Access migration

---

## Migration overview

---

This section describes migration from earlier versions of AG software.

With the 2000-1 release of Natural Access, changes were made in the configuration and monitoring aspects of AG software including:

- The introduction of NMS OAM
- Configuration file changes
- Keyword changes

## NMS OAM

---

NMS OAM performs configuration, monitoring, and testing functions across the telephony resources, including the AG boards.

NMS OAM manages a central database of configuration information. Every board in the system has a record in the database describing its configuration. NMS OAM can start boards based on the information in the database.

You can control NMS OAM using functions from the OAM service. You can also control it using various utilities. One of these utilities, *oamsys*, effectively takes the place of the *agmon* configuration and booting function. It loads a configuration file into the NMS OAM database and then starts the boards.

Another utility, *oammon*, takes the place of the *agmon* monitoring function. After running *oamsys*, you can run *oammon* to monitor board errors and other board-level events. For details on using these utilities to configure the AG system, refer to *Configuring and starting the system with oamsys* on page 30.

For more information about loading, configuring, and monitoring boards in an NMS OAM system, refer to the *NMS OAM System User's Manual*.

For more information about the OAM service, refer to the *NMS OAM Service Developer's Reference Manual*.

## Configuration file changes

---

*agmon* used a single configuration file, *ag.cfg*, that contained configuration information for each board. Each board was referenced using a board number. *oamsys* uses a system configuration file that assigns each board:

- A board name, used to refer to the board in software.
- A board number, used to refer to the board in legacy software.
- A board keyword file, containing the configuration information for the board.

The internal structure of the system configuration file and the board keyword file is very different from *agmon* configuration files. For details on creating a file for your system, refer to *Configuring and starting the system with oamsys* on page 30. For more general information on NMS OAM configuration files, refer to the *NMS OAM System User's Manual*.

## Keyword changes

The statements used in configuration files have also changed. Most configuration statements are specified in the board keyword file. They are expressed in keyword name and value pairs. Keywords have type definitions; for example, some keywords can take integer values, whereas others take string values. Some keywords represent arrays of values, or structures of other keywords or arrays.

The following table lists *agmon* keywords and NMS OAM board keyword equivalents. For details on AG-specific keywords and values, refer to *Using keywords* on page 59. For more general information on NMS OAM keywords, refer to the *NMS OAM System User's Manual*.

| Old keyword      | New keyword                | Notes  |           |                |        |                  |          |           |       |        |      |    |
|------------------|----------------------------|--|-----------|----------------|--------|------------------|----------|-----------|-------|--------|------|----|
| AG2DSP_Lib       | DSP.C5x.Lib                |  |           |                |        |                  |          |           |       |        |      |    |
| AG2DSP_Loader    | DSP.C5x.Loader             |  |           |                |        |                  |          |           |       |        |      |    |
| AG2DSP_OS        | DSP.C5x[x].Os              | <b>x</b> = the number specified in the AG2DSP_OS keyword.  |           |                |        |                  |          |           |       |        |      |    |
| AG2DSPFile       | DSP.C5x[x].Files[y]        | <b>x</b> = running count of files from the Common section and from the board-specific section.<br>Ensure that this list contains: <i>callp</i> , <i>dtmf</i> , <i>signal</i> , <i>ptf</i> , <i>mf</i> , and <i>tone</i> .            |           |                |        |                  |          |           |       |        |      |    |
| AG2DSPImage      | DSP.C5x[x].Image           | <b>x</b> = the number specified in the AG2DSPImage keyword.  |           |                |        |                  |          |           |       |        |      |    |
| AG2TaskProcessor | DSP.C5x[x].Files[y]        | If a DSP processor range is specified, then it converts to <b>x</b> . Otherwise, it applies to all processors from 0 to number of DSPs.  |           |                |        |                  |          |           |       |        |      |    |
| Buffers          | Buffers[x].Num             | <b>x</b> = 0   |           |                |        |                  |          |           |       |        |      |    |
| BufferSize       | Buffers[x].Size            | <b>x</b> = 0   |           |                |        |                  |          |           |       |        |      |    |
| ClockRef         | Clocking.HBus.ClockSource  | <table> <tr> <td><b>AG</b></td> <td><b>NMS OAM</b></td> </tr> <tr> <td>OSC</td> <td>OSC</td> </tr> <tr> <td>H100</td> <td>A_CLOCK</td> </tr> <tr> <td>SEC8K</td> <td>NETREF</td> </tr> <tr> <td>MVIP</td> <td>C4</td> </tr> </table> | <b>AG</b> | <b>NMS OAM</b> | OSC    | OSC              | H100     | A_CLOCK   | SEC8K | NETREF | MVIP | C4 |
| <b>AG</b>        | <b>NMS OAM</b>             |  |           |                |        |                  |          |           |       |        |      |    |
| OSC              | OSC                        |  |           |                |        |                  |          |           |       |        |      |    |
| H100             | A_CLOCK                    |  |           |                |        |                  |          |           |       |        |      |    |
| SEC8K            | NETREF                     |  |           |                |        |                  |          |           |       |        |      |    |
| MVIP             | C4                         |  |           |                |        |                  |          |           |       |        |      |    |
| ConnectMode      | SwitchConnectMode          | <table> <tr> <td><b>AG</b></td> <td><b>NMS OAM</b></td> </tr> <tr> <td>FRAMED</td> <td>AllConstantDelay</td> </tr> <tr> <td>UNFRAMED</td> <td>AllDirect</td> </tr> </table>  | <b>AG</b> | <b>NMS OAM</b> | FRAMED | AllConstantDelay | UNFRAMED | AllDirect |       |        |      |    |
| <b>AG</b>        | <b>NMS OAM</b>             |  |           |                |        |                  |          |           |       |        |      |    |
| FRAMED           | AllConstantDelay           |  |           |                |        |                  |          |           |       |        |      |    |
| UNFRAMED         | AllDirect                  |  |           |                |        |                  |          |           |       |        |      |    |
| Diagnostics      | BootDiagnosticLevel        | All boards   |           |                |        |                  |          |           |       |        |      |    |
| DriveSec8K       | Clocking.HBus.NetRefSource | If DriveSec8K = OSC, set Clocking.HBus.NetRefSource = OSC.<br>If DriveSec8K is set to NONE, omit Clocking.HBus.NetRefSource.   |           |                |        |                  |          |           |       |        |      |    |
| DSP_OS           | DSP.C5x[x].Os              |  |           |                |        |                  |          |           |       |        |      |    |

| Old keyword   | New keyword                           | Notes   |           |                |        |        |       |       |
|---------------|---------------------------------------|---|-----------|----------------|--------|--------|-------|-------|
| EnableMVIP    | Clocking.HBus.ClockMode               | <p>If there is no EnableMVIP setting in <i>agmon</i>, refer to the ClockRef value. If ClockRef is equal to either H100 or MVIP, set Clocking.HBus.ClockMode = SLAVE. If ClockRef is equal to a value other than H100 or MVIP, set Clocking.HBus.ClockMode = STANDALONE.</p> <p>If EnableMVIP was set to NO in <i>agmon</i>, set Clocking.HBus.ClockMode = STANDALONE.</p> <p>If EnableMVIP = YES, determine the ClockRef setting in the <i>ag.cfg</i> file. If the ClockRef setting was H100 or MVIP, set to SLAVE.</p> <p>If the ClockRef setting was not H100 or MVIP, set to MASTER_A.</p> <p>There is no migration for the MASTER_B option.</p> |           |                |        |        |       |       |
| IdleCode      | SignalIdleCode<br>VoiceIdleCode       | <p>If IdleCode = number, use this number for both SignalIdleCode and for VoiceIdleCode.</p> <p>If IdleCode is equal to two numbers, use the first number for VoiceIdleCode and use the second number for SignalIdleCode.</p>  |           |                |        |        |       |       |
|               | Xlaw                                  | <p>If IdleCode = string, set Xlaw as follows:</p> <table border="0"> <tr> <td><b>AG</b></td> <td><b>NMS OAM</b></td> </tr> <tr> <td>Mu-LAW</td> <td>MU-LAW</td> </tr> <tr> <td>A-LAW</td> <td>A-LAW</td> </tr> </table>   | <b>AG</b> | <b>NMS OAM</b> | Mu-LAW | MU-LAW | A-LAW | A-LAW |
| <b>AG</b>     | <b>NMS OAM</b>                        |   |           |                |        |        |       |       |
| Mu-LAW        | MU-LAW                                |   |           |                |        |        |       |       |
| A-LAW         | A-LAW                                 |   |           |                |        |        |       |       |
| LoadFile      | LoadFile                              |   |           |                |        |        |       |       |
| MaxChannels   | MaxChannels                           |   |           |                |        |        |       |       |
| MedBuffers    | Buffers[x].Num                        | <b>x</b> = 1  |           |                |        |        |       |       |
| MedBufferSize | Buffers[x].Size                       | <b>x</b> = 1  |           |                |        |        |       |       |
| PCIbus        | Location.PCI.Bus                      |   |           |                |        |        |       |       |
| PCIslot       | Location.PCI.Slot                     |   |           |                |        |        |       |       |
| Qslac         | NetworkInterface.Analog[x].ConfigFile | <b>x</b> = the analog port number supplied with the Qslac keyword or 0..23 if no port number was specified.   |           |                |        |        |       |       |
| RunFile       | RunFile                               |   |           |                |        |        |       |       |
| RunModule     | DLMFiles[x]                           | <b>x</b> = DLM file number.   |           |                |        |        |       |       |
| SmallBuffers  | Buffers[x].Num                        | <b>x</b> = 2  |           |                |        |        |       |       |
| TCP           | TCPFiles[x]                           | <b>x</b> = TCP number.  |           |                |        |        |       |       |



# Index

## A

AG board plug-in 17  
AG driver software 19  
AutoStart 66  
AutoStop 67

## B

board information keywords 82, 92, 93, 97, 99, 101, 105  
board location keywords 94, 95  
board physical slot location 30  
boardinf 44  
Boards[x] 68  
BootDiagnosticLevel 69  
Buffers[x].Num 72  
Buffers[x].Size 73

## C

clocking 36  
Clocking.HBus.AutoFallback 74  
Clocking.HBus.ClockMode 76  
Clocking.HBus.ClockSource 77  
Clocking.HBus.FallBackClockSource 78  
Clocking.HBus.NetRefSource 79  
Clocking.HBus.NetRefSpeed 80  
Clocking.HBus.Segment 81  
compliance 115  
configuring 30  
    .leo files 34  
    adding configurations 29  
    board clocking 36  
    board keyword files 30  
    boardinf 44  
    configuration file location 34  
    default connections 51  
    echo cancellation 42

line gain 54  
local devices 53  
parameter settings 34  
system configuration file 32  
ctatest 45, 47

## D

debugging information 69  
default connections 51  
demonstration programs 47  
DLMFiles[x] 82  
Driver.BoardID 63  
Driver.Name 63  
DSP processing power 119, 126  
DSP.C5x.Lib 83  
DSP.C5x.Loader 84  
DSP.C5x[x].Files[y] 85  
DSP.C5x[x].Image 88  
DSP.C5x[x].Os 89

## E

echo cancellation 42  
echo canceller reference stream  
    keywords 90, 91  
Echo.AutoSwitchingRefSource 90  
Echo.EnableExternalPins 90  
Eeprom.AssemblyRevision 62  
Eeprom.BoardSpecific 62  
Eeprom.BusClkDiv 62  
Eeprom.CheckSum 62  
Eeprom.CPUSpeed 62  
Eeprom.DRAMSize 62  
Eeprom.DSPSpeed 62  
Eeprom.Family 62  
Eeprom.MFGWeek 62  
Eeprom.MFGYear 62

- Eeprom.MSBusType 62
- Eeprom.NumDSPCores 62
- Eeprom.SerialNum 62
- Eeprom.SoftwareCompatibility 62
- Eeprom.SRAMSize 62
- Eeprom.SubType 62
- EMC 115
- environment 112
- F**
- ferrite block 25
- H**
- H.110 streams 49
- hardware specifications 111
  - board features 13
  - cable kit 27
  - electrical 113
  - environment 112
  - LEDs 43
- Hot Swap 24
- I**
- incta 47
- installing 23
  - AG driver software 19
  - connecting to the telephone network 25
  - summary 19
  - system requirements 20
  - verifying board installation 44
- K**
- keying 20
- keywords 59
  - AG plug-in 63
  - board information 82, 92, 93, 97, 99, 101, 105
  - board keyword files 30
  - board location 94, 95
  - clocking 74, 76, 77, 78, 79, 80, 81
  - configuring debugging information 69
  - configuring DSPs 83, 84, 85, 88, 89, 102, 108, 109
  - configuring memory 72, 73, 96
  - configuring switching 103, 104
  - echo canceller reference stream 90, 91
  - editable 61
  - informational 62
  - migration changes 132
  - plug-in 63
  - QSLAC file 98
  - read/write 61
  - read-only 62
  - retrieving values 60
  - setting values 60
  - stopping or starting a board 66, 67
- L**
- leo files 34
- line gain configuration 54
- LoadFile 92
- LoadSize 93
- local streams 49
- Location.PCI.Bus 94
- Location.PCI.Slot 95
- Location.Type 62
- loop start 127
  - ctatest with a loop start board 46
  - receive signaling 129
  - recording and caller ID mode 114
  - transmit signaling 128
- M**
- managing resources 117
- MaxChannels 96
- memory keywords 72, 73, 96
- migration 131
- MIPS usage 119, 126



## N

Name 97  
Natural Access 16  
NetworkInterface.Analog[x].ConfigFile 98  
NMS OAM 131  
Number 99

## O

OAM 131  
oamcfg 29  
oamgen 32  
oamsys 30, 32, 33  
outcta 47

## P

parameters 34  
    board keyword files 30  
    configuration file location 34  
physical slot location 30  
pinouts 25  
plug-in keywords 63  
power requirements 112  
Product 62  
Products[x] 100  
prt2prt 47

## Q

QSLAC files 35, 114

## R

regulatory certification 115  
RJ-21 connectors 25  
RunFile 101  
runtime software 18

## S

safety 115  
sample configuration files 30, 32  
SignalIdleCode 102  
signaling 127  
    loop start receive signaling 129  
    loop start transmit signaling 128

    signaling modules and logical timeslots 51  
software components 15  
specifications 111  
    compliance and regulatory certification 115  
    electrical 113  
    system requirements 20  
standalone mode 41  
State 62  
stopping or starting a board 66, 67  
streams 49  
swish 45  
switch model 49  
SwitchConnections 103  
SwitchConnectMode 104  
SwitchDriver.Name 63  
switching keywords 103, 104  
Switching service 51, 53  
system configuration file 32  
system requirements 20

## T

T8100A switch blocking 50  
task processor files 119  
TCPFiles[x] 105  
Telecom 115  
telephone network connection 25  
temperature 111  
tromboning 90, 91  
trunk control programs (TCPs) 18

## V

vceplay 47  
vcerec 47  
verifying board installation 44  
    board configuration information 44  
    ctatest 45  
    demonstration programs 47  
LEDs 43

swish 45  
Version.Major 106  
Version.Minor 107  
VoiceIdleCode 108

**W**  
weight 111  
**X**  
Xlaw 109