

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.



User's Manual

Phase-out/Discontinued

IE-70000-MC-NW-A

In-Circuit Emulator

Document No. U16348EJ1V0UM00 (1st edition)
Date Published November 2002 N CP(K)

© NEC Electronics Corporation 2002
Printed in Japan

[MEMO]

Windows is either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries.

PC/AT is a trademark of International Business Machines Corporation.

• **The information in this document is current as of August, 2002. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC Electronics data sheets or data books, etc., for the most up-to-date specifications of NEC Electronics products. Not all products and/or types are available in every country. Please check with NEC Electronics sales representative for availability and additional information.**

• No part of this document may be copied or reproduced in any form or by any means without prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.

• NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such NEC Electronics products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.

• Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of customer's equipment shall be done under the full responsibility of customer. NEC Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.

• While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.

• NEC Electronics products are classified into the following three quality grades: "Standard", "Special" and "Specific".

The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics product before using it in a particular application.

"Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.

"Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).

"Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact NEC Electronics sales representative in advance to determine NEC Electronics's willingness to support a given application.

(Note)

(1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.

(2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

Regional Information

Some information contained in this document may vary from country to country. Before using any NEC Electronics product in your application, please contact the NEC Electronics office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- Ordering information
- Product release schedule
- Availability of related technical literature
- Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

NEC Electronics America, Inc. (U.S.)

Santa Clara, California
Tel: 408-588-6000
800-366-9782
Fax: 408-588-6130
800-729-9288

NEC Electronics (Europe) GmbH

Duesseldorf, Germany
Tel: 0211-65 03 01
Fax: 0211-65 03 327

• Sucursal en España

Madrid, Spain
Tel: 091-504 27 87
Fax: 091-504 28 60

• Succursale Française

Vélizy-Villacoublay, France
Tel: 01-30-67 58 00
Fax: 01-30-67 58 99

• Filiale Italiana

Milano, Italy
Tel: 02-66 75 41
Fax: 02-66 75 42 99

• Branch The Netherlands

Eindhoven, The Netherlands
Tel: 040-244 58 45
Fax: 040-244 45 80

• Tyskland Filial

Taeby, Sweden
Tel: 08-63 80 820
Fax: 08-63 80 388

• United Kingdom Branch

Milton Keynes, UK
Tel: 01908-691-133
Fax: 01908-670-290

NEC Electronics Hong Kong Ltd.

Hong Kong
Tel: 2886-9318
Fax: 2886-9022/9044

NEC Electronics Hong Kong Ltd.

Seoul Branch
Seoul, Korea
Tel: 02-528-0303
Fax: 02-528-4411

NEC Electronics Shanghai, Ltd.

Shanghai, P.R. China
Tel: 021-6841-1138
Fax: 021-6841-1137

NEC Electronics Taiwan Ltd.

Taipei, Taiwan
Tel: 02-2719-2377
Fax: 02-2719-5951

NEC Electronics Singapore Pte. Ltd.

Novena Square, Singapore
Tel: 6253-8311
Fax: 6250-3583

INTRODUCTION

Target Readers This manual is intended for users who design and develop application systems using the IE-70000-MC-NW-A. It is assumed that the target readers are familiar with the functions and usage methods of the devices and have knowledge of debuggers.

Purpose The purpose of this manual is to describe the proper operation of the IE-70000-MC-NW-A and its basic specifications.

Organization This manual is divided into the following parts.

- Overview
- Names and functions of components
- Cautions on designing target system

How to Read This Manual It is assumed that the reader of this manual has general knowledge in the fields of electrical engineering, logic circuits, and microcontrollers.

This manual explains the basic setup procedure and switch settings.

To learn about the basic specifications and operation methods

→ Read this manual in the order of the **CONTENTS**.

To learn the operation methods and command functions, etc., of the IE-70000-MC-NW-A

→ Read the user's manual of the debugger (sold separately) that is used.

Conventions **Note:** Footnote for item marked with **Note** in the text

Caution: Information requiring particular attention

Remark: Supplementary information

Numeral representation: Binary ··· xxxx or xxxxB

Decimal ··· xxxx

Hexadecimal ··· xxxxH

Prefix indicating the power of 2 (address space, memory capacity):

K (kilo): $2^{10} = 1024$

M (mega): $2^{20} = 1024^2$

Terminology The meanings of terms used in this manual are listed below.

Target device	The device that is targeted for emulation.
Target system	The system (user-built system) that is targeted for debugging. This includes the target program and user-configured hardware.

Related Documents

When using this manual, refer to the following manuals.

The related documents indicated in this publication may include preliminary versions. However, preliminary versions are not marked as such.

○ **Documents related to development tools (user's manuals)**

Document Name		Document Number
IE-70000-MC-NW-A In-Circuit Emulator		This manual
CA850 C Compiler Package Ver. 2.40	Operation	To be prepared
	C Language	U16054E
	PM Plus	To be prepared
	Assembly Language	U16042E
ID850NW Integrated Debugger Ver. 1.10 or Later	Operation (Windows™ Based)	U14891E

Caution The documents listed above are subject to change without notice. Be sure to use the latest documents when designing.

CONTENTS

CHAPTER 1 OVERVIEW 10

- 1.1 Hardware Configuration 10**
- 1.2 Features 11**
- 1.3 Function Specifications 11**
- 1.4 System Configuration 13**
- 1.5 Contents in Carton 14**

CHAPTER 2 NAMES AND FUNCTIONS OF COMPONENTS 15

- 2.1 Names and Functions of Components 15**
- 2.2 Connection 17**
- 2.3 Switch Settings 19**
- 2.4 Startup/Termination 20**

CHAPTER 3 CAUTIONS ON DESIGNING TARGET SYSTEM 21

- 3.1 IE Connector (Target System Side) 22**
 - 3.1.1 Recommended circuit example when NB85E Type.B core is used 22
 - 3.1.2 Recommended circuit example when NB85E Type.C core is used 23
 - 3.1.3 IE connector (target system side) 24
- 3.2 ROM on Target System 26**
 - 3.2.1 ROM connector 26
 - 3.2.2 ROM probe setting 27
 - 3.2.3 Interface Circuit and Cautions for ROM Probe 28

APPENDIX PACKAGE DRAWINGS 29

LIST OF FIGURES

Figure No.	Title	Page
1-1	System Configuration	13
1-2	Contents in Carton	14
2-1	Names of Components	15
2-2	Connection to Target System	17
2-3	Connection to ROM on Target System (1 ROM)	18
2-4	Connection to ROM on Target System (2 ROMs)	18
3-1	Recommended Connection Circuit Example (NB85E Type.B)	22
3-2	Recommended Connection Circuit Example (NB85E Type.C)	23
3-3	Pin Assignment of IE Connector (Target System Side)	25
3-4	Pin Assignment of ROM Probe (EP-16000C (Sold Separately) and EP-16384C (Sold Separately))	26
3-5	Voltage Setting of ROM Probe (EP-16000C (Sold Separately) and EP-16384C (Sold Separately))	27
3-6	Interface Circuit Outline of ROM Probe	28


LIST OF TABLES

<u>Table No.</u>	<u>Title</u>	<u>Page</u>
1-1	Function Specifications	11
2-1	Setting DIP Switches for ROM Mode.....	19
3-1	Pin Functions of IE Connector (Target System Side).....	24

CHAPTER 1 OVERVIEW

The IE-70000-MC-NW-A is an external in-circuit emulator to be connected to a target device in which a debug control unit is mounted to efficiently debug hardware and software.

1.1 Hardware Configuration



Note Cannot be used for PC98-NX series

1.2 Features

- General-purpose usage available in V850E series products in which a debug control unit is mounted
- Debug control unit control interface mounted
- Branch PC trace via the trace packet data method (including on-chip cache execution)
- Data access trace via the trace packet data method
- ROM emulation function
- The dimensions of the IE-70000-MC-NW-A are as follows.

Parameter		Value
Operating voltage		5 V \pm 5%
Current consumption		500 mA (TYP.)
External dimensions (refer to APPENDIX PACKAGE DRAWINGS)	Height	26 mm
	Width	160 mm
	Depth	162 mm
Weight		250 g

1.3 Function Specifications

Table 1-1. Function Specifications (1/2)

Parameter	Specification	
Target device	Device in which a debug control unit is mounted Operating voltage of target device: 3.0 to 3.6 V	
Debug control unit interface (execution control block)	Interface clock (DCK)	25 MHz
	Number of interface signal pins	5
	Functions of interface signal pins	<ul style="list-style-type: none"> • DCK: Interface clock input • DMS: Interface mode select output • DDI: Interface data input • DDO: Interface data output • DRST(-): Debug control unit reset output
Debug control unit interface (trace control block)	Trace clock (TRCLK)	100 MHz (max.)
	Number of trace signal pins	6
	Functions of trace signal pins	<ul style="list-style-type: none"> • TRCLK: Trace clock input • TRCDATA[3:0]: Trace data input • TRCEND: Trace data end point indication input
	Trace packet data length	8 to 256 bits (in 8-bit units)
	Trace memory capacity	<ul style="list-style-type: none"> • 3 MB (including 1 MB of time stamp storage memory) Number of trace packet data ... Approximately 200 K (min.) to 2 M (max.) • Any size between 24 and 3 MB specifiable in 24-byte units
	Trace start	<ul style="list-style-type: none"> • Trace event (Incorporated in debug control unit) • Trace forcible start (Incorporated in debug control unit)


Table 1-1. Function Specifications (2/2)

Parameter	Specification	
Debug control unit interface (trace control block)	Trace end	<ul style="list-style-type: none"> Trace memory full Trace end status of debug control unit detected
	Trace mode	<ul style="list-style-type: none"> 3 types <ul style="list-style-type: none"> <1> Trace from trace event to trace end <2> Trace around match event (delay trace) <ul style="list-style-type: none"> Delay counter: Any value between 0 and 32 K counts specifiable (1 count equals 24 bytes of trace memory) <3> Trace termination by trace event (incorporated in debug control unit)
ROM emulation function	ROM emulation memory capacity	2 MB × 2 banks (access time: 60 ns (min.))
	Supported ROM	<ul style="list-style-type: none"> 4 /8/16 Mb ROM 3 V/5 V 16-bit bus mode only Page access supported
	ROM probe	<ul style="list-style-type: none"> Up to 2 probes connectable (sold separately) 40-pin/42-pin DIP package type
Break function	Incorporated in debug control unit of target device	
Pin mask function	Incorporated in debug control unit of target device	
Connector for mounting target system (recommended)	<ul style="list-style-type: none"> 26-pin straight type: 8830E-026-170S (by KEL Corporation) 26-pin right-angle type: 8830E-026-170L (by KEL Corporation) 	
Operating environment	Temperature	10 to 40°C
	Humidity	10 to 80%RH (no condensation)
Storage environment	Temperature	-15 to +40°C
	Humidity	10 to 80%RH (no condensation)

1.4 System Configuration

The following shows the system configuration when connecting the IE-70000-MC-NW-A.

Figure 1-1. System Configuration



1.5 Contents in Carton

The carton of the IE-70000-MC-NW-A contains the following. Check for any missing items. If there are missing or damaged items, please contact an NEC Electronics sales representative or an NEC Electronics distributor.

Return the guarantee card included in the carton after filling in all the items.

Figure 1-2. Contents in Carton

The diagram illustrates the contents of the IE-70000-MC-NW-A carton. It includes:

- <1> IE-70000-MC-NW-A**: A rectangular printed circuit board with two long integrated circuits and a smaller component.
- <2> IE connection cable (26-pin)**: A cable with two 26-pin connectors.
- <3> Host interface cable (36-pin)**: A cable with two 36-pin connectors.
- <4> Users' Manual (J/E)**: Two manuals, one in Japanese and one in English.
- <5> Guarantee card**: A single card.
- <6> Data Sheet (J/E)**: Two data sheets, one in Japanese and one in English.
- <7> Cautions on Use (J/E)**: Two caution sheets, one in Japanese and one in English.


<1> IE-70000-MC-NW-A	... 1
<2> IE connection cable	... 1
<3> Host interface cable	... 1
<4> Users' Manual (Japanese version, English version)	... One each (this manual)
<5> Guarantee card	... 1
<6> Data Sheet (Japanese version, English version)	... One each
<7> Cautions on Use (Japanese version, English version)	... One each

CHAPTER 2 NAMES AND FUNCTIONS OF COMPONENTS

This chapter describes the names and functions of components, switch settings, and connections with related devices of the IE-70000-MC-NW-A.

2.1 Names and Functions of Components

Figure 2-1. Names of Components



<1> IE connector

This is a connector for connecting the IE connection cable.

<2> ROM1 probe connector

This is a connector for connecting the ROM probe EP-16000C (sold separately) or EP-16384C (sold separately).

When configuring a 32-bit bus using two ROMs, connect the ROM corresponding to the lower 16 bits and this connector using the ROM probe. When emulating one ROM, connect the ROM to this connector.

<3> ROM2 probe connector (42-pin DIP package supported)

This is a connector for connecting the ROM probe EP-16000C (sold separately) or EP-16384C (sold separately).

When configuring a 32-bit bus using two ROMs, connect the ROM corresponding to the higher 16 bits and this connector using the ROM probe.

<4> DIP switch for ROM mode

This is a DIP switch for setting whether or not to use the ROM1 probe connector and ROM2 probe connector.

The factory setting of the ROM1 probe connector and ROM2 probe connector is "not use".

<5> Reset switch

This is a switch for testing the product itself.

Do not use this switch. When this switch is pressed during debugging, the debugger will malfunction.

<6> Host interface connector

Connect the attached host interface cable to this connector.

However, when connecting the IE-70000-CD-IF-A, use the cable that is supplied with the IE-70000-CD-IF-A.

<7> Power supply jack

Connect the plug of the power supply adapter IE-70000-MC-PS-B (sold separately) to this jack.

<8> Power switch

Use this switch to turn on/off the power of the IE-70000-MC-NW-A.

<9> Power LED

This LED is lit while the IE-70000-MC-NW-A is on.

2.2 Connection

The following describes the connection between the IE-70000-MC-NW-A and related devices.

(1) Connection to the interface board

Use the host interface cable (supplied) to connect the host interface connector of the IE-70000-MC-NW-A to the “CH0” connector^{Note} of the interface board.

When connecting the interface board to the IE-70000-CD-IF-A, use the cable supplied with the IE-70000-CD-IF-A (sold separately).

Note IE-70000-PCI-IF-A (sold separately), IE-70000-PC-IF-C (sold separately), or IE-70000-98-IF-C (sold separately)

(2) Connection to the target system


Use the IE connection cable (supplied) to connect the IE connector of the IE-70000-MC-NW-A to the IE connector^{Note} on the target system.

Note IE connector (recommended)

8830E-026-170S (manufactured by KEL corporation): 26-pin straight type

8830E-026-170L (manufactured by KEL corporation): 26-pin right-angle type

Figure 2-2. Connection to Target System



(3) Connection to the ROM on the target system

Use the ROM probe^{Note} to connect the ROM1 or ROM2 probe connector of the IE-70000-MC-NW-A to the ROM socket on the target system and set the switch. For how to set the switch, refer to **2.3 Switch Settings**.

Note EP-16000C (sold separately) or EP-16384C (sold separately)

Figure 2-3. Connection to ROM on Target System (1 ROM)





Figure 2-4. Connection to ROM on Target System (2 ROMs)




**(4) Connection to power supply adapter**

Connect the IE-70000-MC-PS-B plug to the power supply jack of the IE-70000-MC-NW-A.


2.3 Switch Settings

The following describes the switch settings of the DIP switches for ROM mode.
Set these switches when using the ROM emulation function via the ROM probe.

Table 2-1. Setting DIP Switches for ROM Mode

Purpose	Setting of DIP Switch for ROM Mode		
	SW1	SW2	Status
Not using ROM emulation function (factory setting)	OFF	OFF	
To enable only ROM1 probe connector	ON	OFF	
To enable ROM1 probe connector and ROM2 probe connector	ON	ON	

Caution The combination of SW1 OFF and SW2 ON is prohibited.



2.4 Startup/Termination

The following describes the procedures for startup and termination.

To operate the IE-70000-MC-NW-A, a dedicated debugger is required. For details, refer to the **ID850NW Integrated Debugger Ver.1.10 or Later Operation (Windows Based) User's Manual (U14891E)**.

(1) Startup procedure

- <1> Turn on the host machine.
- <2> Turn on the IE-70000-MC-NW-A.
- <3> Turn on the target system.
- <4> Start the debugger.

(2) Termination procedure

- <1> Terminate the debugger.
- <2> Shut down the power to the target system.
- <3> Shut down the power to the IE-70000-MC-NW-A.
- <4> Terminate the host machine (power off).

CHAPTER 3 CAUTIONS ON DESIGNING TARGET SYSTEM

To debug the target system with the IE-70000-MC-NW-A connected, a circuit to connect the IE-70000-MC-NW-A is required on the target system.

This chapter describes the circuit to connect the IE-70000-MC-NW-A and cautions.


3.1 IE Connector (Target System Side)

The following shows the recommended circuit example of the target system required when connecting the IE-70000-MC-NW-A and the pin assignment of the IE connector (on the target system side).

3.1.1 Recommended circuit example when NB85E Type.B core is used

Figure 3-1 shows the recommended circuit example of the IE connector (on the target system side).


Figure 3-1. Recommended Connection Circuit Example (NB85E Type.B)



3.1.2 Recommended circuit example when NB85E Type.C core is used

Figure 3-2 shows the recommended circuit example of the IE connector (on the target system side).

Figure 3-2. Recommended Connection Circuit Example (NB85E Type.C)




3.1.3 IE connector (target system side)

Table 3-1 and Figure 3-3 show the function list and pin assignment of the IE connector (on the target system side).

Recommended connectors: KEL Corporation 8830E-026-170S: 26-pin straight type
 KEL Corporation 8830E-026-170L: 26-pin right-angle type

Table 3-1. Pin Functions of IE Connector (Target System Side)

Pin No.	Pin Name	I/O	Description
A1	TRCCLK	O	Trace clock output
A2	TRCDATA[0]	O	Trace data 0 output
A3	TRCDATA[1]	O	Trace data 1 output
A4	TRCDATA[2]	O	Trace data 2 output
A5	TRCDATA[3]	O	Trace data 3 output
A6	TRCEND	O	Trace data end output
A7	DDI	I	Data input for debug serial interface
A8	DCK	I	Clock input for debug serial interface
A9	DMS	I	Transfer mode selection input for debug serial interface
A10	DDO	O	Data output for debug serial interface
A11	DRST(-)	I	Debug control unit (DCU) reset input
A12	(Reserved)	-	(Leave open)
A13	(Reserved)	-	(Leave open)
B1	GND	-	-
B2	GND	-	-
B3	GND	-	-
B4	GND	-	-
B5	GND	-	-
B6	GND	-	-
B7	GND	-	-
B8	GND	-	-
B9	GND	-	-
B10	GND	-	-
B11	(Reserved)	-	(Leave open)
B12	(Reserved)	-	(Leave open)
B13	V _{DD}	-	+3.3 V input (for monitoring target power)

Figure 3-3. Pin Assignment of IE Connector (Target System Side)

3.2 ROM on Target System

The following describes the pin assignment of the ROM probe (sold separately) and cautions when connecting the target system using the ROM probe.

3.2.1 ROM connector

Figure 3-4 shows the pin assignment of the ROM probe (sold separately).

The ROM probe (sold separately) supports ROM with two types of pin layouts.

Figure 3-4. Pin Assignment of ROM Probe (EP-16000C (Sold Separately) and EP-16384C (Sold Separately))

(600 mil DIP)				(600 mil DIP)			
A18	1	42	A19	A18	1	42	A19
A17	2	41	A8	(NC)	2	41	V _{CC}
A7	3	40	A9	CE(-)	3	40	A17
A6	4	39	A10	015	4	39	A16
A5	5	38	A11	014	5	38	A15
A4	6	37	A12	013	6	37	A14
A3	7	36	A13	012	7	36	A13
A2	8	35	A14	011	8	35	A12
A1	9	34	A15	010	9	34	A11
A0	10	33	A16	09	10	33	A10
CE(-)	11	32	(NC)	08	11	32	A9
GND	12	31	GND	GND	12	31	GND
OE(-)	13	30	015	07	13	30	A8
00	14	29	07	06	14	29	A7
08	15	28	014	05	15	28	A6
01	16	27	06	04	16	27	A5
09	17	26	013	03	17	26	A4
02	18	25	05	02	18	25	A3
010	19	24	012	01	19	24	A2
03	20	23	04	00	20	23	A1
011	21	22	V _{CC}	OE(-)	21	22	A0


- Remarks**
1. The pin assignment of the EP-16000C (sold separately) is equivalent to that of the 27C4000/27C8000/27C16000, except for pin 32, which is an NC pin.
 2. The pin assignment of the EP-16384C (sold separately) is equivalent to that of the 27C4096 for pins from 2 to 41, but pin 2 is an NC pin. Note that the pin assignments of pins 1 and 42 are exclusive to the EP-16384C (sold separately).

3.2.2 ROM probe setting

Figure 3-5 shows the jumper setting of the ROM probe.

The ROM probe supports 3.3 V ROM and 5 V ROM, so set the jumper in accordance with the voltage of the ROM to be mounted on the target system.

Figure 3-5. Voltage Setting of ROM Probe (EP-16000C (Sold Separately) and EP-16384C (Sold Separately))




3.2.3 Interface Circuit and Cautions for ROM Probe

The interface circuit of the ROM probe is shown in Figure 3-6.

When using the ROM probe, note the cautions on designing the target system.

Figure 3-6. Interface Circuit Outline of ROM Probe



Cautions 1. The bus load of the target system when the ROM probe is connected may be higher than that when an actual ROM is connected. Caution must be paid when designing the bus of the target system. It is recommended to mount a bus buffer in the ROM of the target system.

2. A18 and A19 are pulled down (50 kΩ) inside the ROM probe, so they must be NC (no connection) on the target system when they are not used on the target system.
3. When using the ROM emulation function, set the size of the ROM area set by the mapping command of the debugger to the same size as the size of the ROM on the target system. If these settings are different, the ROM emulation memory cannot be read with a correct address from the target device.
4. Data cannot be written to the ROM emulation memory form the target device.
5. The access time of the ROM emulation memory is 60 ns. Set the wait count of the target device to an appropriate value when using the ROM emulation memory.

APPENDIX PACKAGE DRAWINGS

IE-70000-MC-NW-A (Unit: mm)

