# **STANLEY**

# Stanley TLM660





## Table of Contents

| Instrument Set-up 2   Introduction 2   Overview 2   Basic measuring screen 3   Selection screen 3   Pointfinder (Viewscreen) 4   Insert batteries 4  |
|--|
| <b>Operations</b> 5<br>Switching ON/OFF 5  |
| Clear 5   Message Codes 5   Multifunctional endpiece 5   Permament / Minimum-Maximum measuring 5   Add / Subtract 6   Pointfinder (Viewscreen) 6   |
| Settings   7     Overview   7     Tilt units   7     Distance units   8     Beep ON/OFF   8     Digital level ON/OFF   8     De-/Activate keylock   9     Switch on with keylock   9     De-/Activate Bluetooth Smart   9     Calibration of tilt sensor (Tilt Calibration)   10     Personalized favorites   11     Illumination   11     Offset   12 |
| <b>Functions</b> 13  |
| Overview 13   Timer 13   Calculator 13   Adjusting measuring reference/tripod 14   |

| Memory                              | <br>14 |
|-------------------------------------|--------|
| Measuring single distance           | <br>15 |
| Smart Horizontal Mode               | <br>15 |
| Inclination tracking                | <br>15 |
| Area                                | <br>16 |
| Volume                              |        |
| Triangular area                     | <br>18 |
| Long range mode                     |        |
| Height-profile measurement          | <br>19 |
| Sloped objects                      | <br>20 |
| Height tracking                     |        |
| Trapezium                           | <br>22 |
| Stake out                           | <br>23 |
| Pythagoras (2-point)                |        |
| Pythagoras (3-point)                | <br>25 |
| Technical Data                      |        |
|                                     |        |
| Message Codes                       | <br>27 |
| Care                                | <br>27 |
|                                     |        |
| Warranty                            | <br>27 |
| Safety Instructions                 | <br>27 |
| Areas of responsibility             |        |
| Permitted use                       |        |
| Prohibited use                      |        |
| Hazards in use                      |        |
|                                     |        |
|                                     |        |
| Electromagnetic Compatibility (EMC) |        |
| FCC statement (applicable in U.S.)  | <br>29 |
| Use of the product with Bluetooth®  | <br>29 |
| Laser classification                |        |
| Labelling                           |        |
|                                     |        |

П

#### **Instrument Set-up**

#### Introduction



The safety instructions and the user manual should be read through carefully before the product is used for the first time.

The person responsible for the product must ensure that all users understand these directions and adhere to them.

The symbols used have the following meanings:

## 

Indicates a potentially hazardous situation or an unintended use which, if not avoided, will result in death or serious injury.

## 

Indicates a potentially hazardous situation or an unintended use which, if not avoided, may result in minor injury and/or appreciable material, financial and environmental damage.


important paragraphs which must be adhered to in practice as they enable the product to be used in a technically correct and efficient manner.

#### Overview




#### **Instrument Set-up**

#### **Basic measuring screen**




#### **Selection screen**




#### **Instrument Set-up**

#### **Pointfinder (Viewscreen)**



#### **Insert batteries**




To ensure a reliable use, do not use zinccarbon batteries. We recommend using high quality batteries. Change batteries when battery symbol is flashing.




#### Operations


EN



#### **Multifunctional endpiece**



#### Permament / Minimum-Maximum measuring



The minimum and maximum distance measured is displayed (min, max.). The last value measured is displayed in the main line.






Stops permanent / minimummaximum measuring.

Stanley TLM660

#### Operations

#### Add / Subtract




This is a great help for outdoor measuring. The integrated pointfinder (viewscreen) shows the target on the display. The device measures in the middle of the cross hair, even if the laser dot is not visible.

Parallax errors occur when the pointfinder camera is used on close targets, with the effect that the laser appears displaced in the crosshair. In this case rely on the real laser dot.

1




#### Overview




|                   | Tilt units       |
|-------------------|------------------|
|                   | Distance units   |
| 5                 | Веер             |
| М                 | Digital level    |
|                   | Keypad lock      |
| *                 | Bluethooth®      |
| Ť,                | Tilt calibration |
|                   | Favorites        |
| <b>\$</b>         | Illumination     |
|                   | Offset           |
| <b>C</b><br>RESET | Reset            |
| i                 | Information      |

**Tilt units** 







| 360.0°   | 0.00 %     |
|----------|------------|
| ± 180.0° | 0.0 mm/m   |
| ± 90.0°  | 0.00 in/ft |



Confirm setting.



Exit settings.

Stanley TLM660



#### **Distance units**

2





Switch between the following units:

| 0.00 m   | 0.00 ft    |  |
|----------|------------|--|
| 0.000 m  | 0.00 in    |  |
| 0.0000 m | 0 1/32 in  |  |
| 0.0 mm   | 0'00" 1/32 |  |






Confirm setting.

Exit settings.

Beep ON/OFF




🖬 Digital level ON/OFF



Stanley TLM660

## EN



Exit settings.

Switch on Bluetooth Smart in Settings.

ÔN

Connect the device with your smart phone, pad, laptop,...

The actual measurement is transferred automatically if Bluetooth connection is established. To transfer a result from the main line, press =. Bluetooth switches off as soon as the laser distance meter is switched off.

To switch ON,

repeat procedure.


The efficient and innovative Bluetooth Smart module (with the new Bluetooth standard V4.0) works together with all Bluetooth Smart Ready devices. All other Bluetooth devices do not support the energy saving Bluetooth Smart Module, which is integrated in the device.

We accept no liability whatsoever arising from the use of the free software and we are not obliged to provide corrections nor to develop upgrades. Apps for Android<sup>®</sup> or Mac iOS can be found in special internet shops.


played if device is connected with

Bluetooth.


#### Calibration of tilt sensor (Tilt Calibration)



EN










Exit settings.

An offset adds or subtracts a specified value automatically to or from all measurements. This function allows tolerances to be taken into account. The offset icon is displayed.

G Reset






1


Exit settings.

Reset returns the instrument to the factory settings. All customized settings and memories are lost.


#### Overview



#### 🧭 Timer




#### Calculator




Stanley TLM660

#### Adjusting measuring reference/tripod




#### Memory




i C


Short cut

### Measuring single distance






🔬 Inclination tracking




Stanley TLM660

#### → Area




#### 📦 Volume




EN

#### 📐 Triangular area




#### Long range mode




The long range mode allows measuring of difficult targets in unfavorable conditions e.g. bright ambient light or bad target reflectivity. The measuring time is increased. An icon in the status line shows if the function is active.

#### Height-profile measurement




#### Sloped objects





Indirect distance measuring between 2 points with additional results. Ideal for applications such as length and slope of roof, height of chimneys,...

It is important, that the instrument is positioned in the same vertical plane as the 2 measured points. The plane is defined of the line between the 2 points.

#### 🖞 Height tracking








## Pythagoras (2-point)

#### **Pythagoras (3-point)**



#### **Technical Data**

| Distance measurement                      |                                       |
|---|---------------------------------------|
| Accuracy at favourable<br>conditions *    | ± 1.0 mm / ~1/16" ***                 |
| Accuracy at unfavourable<br>conditions ** | ± 2.0 mm / 0.08 in ***                |
| Range at favourable<br>conditions *       | 200 m / 660 ft                        |
| Range at unfavourable<br>condition **     | 80 m / 260 ft ****                    |
| Smallest unit displayed                   | 0.1 mm / 1/32 in                      |
| Power Range Technology <sup>™</sup>       | yes                                   |
| Ø laser point<br>at distances             | 6 /30 / 60 mm<br>(10 / 50 / 100 m)    |
| Tilt measurement                          |                                       |
| Measuring tolerance to laser beam****     | ± 0.2°                                |
| Measuring tolerance to housing*****       | ± 0.2°                                |
| Range                                     | 360°                                  |
| General                                   |                                       |
| Laser class                               | 2                                     |
| Laser type                                | 635 nm, < 1 mW                        |
| Protection class                          | IP54                                  |
| Autom. laser switch off                   | after 90 s                            |
| Autom. power switch-off                   | after 180 s                           |
| Bluethooth® Smart                         | Bluethooth v4.0                       |
| Range of Bluethooth®                      | 10 m                                  |
| Battery durability (2 x AA)               | up to 5000 measure-<br>ments          |
| Dimension (H x D x W)                     | 49 x 6  x 3  mm<br>5.9 x 2.4 x 1.2 in |
| Weight (with batteries)                   | 209 g / 7.22 oz                       |
| Temperature range:<br>- Storage           | -25 to 70 °C<br>-13 to 158 °F         |
| - Operation                               | -10 to 50 °C<br>14 to 122 °F          |

\* favourable conditions are: white and diffuse reflecting target (white painted wall), low background illumination and moderate temperatures.

\*\* unfavourable conditions are: targets with lower or higher reflectivity or high background illumination or temperatures at the upper or lower end of the specified temperature range.

\*\*\* Tolerances apply from 0.05 m to 10 m with a confidence level of 95%.

With favourable conditions the tolerance may deteriorate by 0.05 mm/m for distances between 10 m to 30 m, by 0.10 mm/m between 30 m and 100 m and by 0.20 mm/m for distances above 100 m.

With unfavourable conditions the tolerance may deteriorate by 0.10 mm/m for distances between 10 m to 30 m, by 0.20 mm/m between 30 m and 100 m and by 0.30 mm/m for distances above 100 m.

\*\*\*\* after user calibration. Additional angle related deviation of  $+/-0.01^{\circ}$  per degree up to  $+/-45^{\circ}$  in each quadrant. Applies at room temperature. For the whole operating temperature range the maximum deviation increases by  $+/-0.1^{\circ}$ .

For accurate indirect results, the use of a tripod is recommended. For accurate

tilt measurements a transverse tilt should be avoided.

| Functions                                      |                  |
|--|------------------|
| Distance measuring                             | yes              |
| Min/Max measuring                              | yes              |
| Permanent measuring                            | yes              |
| Stake-out                                      | yes              |
| Addition/Subtraction                           | yes              |
| Area   | yes              |
| Triangle area                                  | yes              |
| Volume   | yes              |
| Trapezium                                      | yes              |
| Painter function (area with partial measurem.) | yes              |
| Pythagoras                                     | 2-point, 3-point |
| Smart Horizontal Mode /<br>Indirect height     | yes              |
| Height-profile measurement                     | yes              |
| Inclination tracking                           | yes              |
| Sloped objects                                 | yes              |
| Height tracking                                | yes              |
| Memory   | 30 displays      |
| Веер   | yes              |
| Illuminated colour display                     | yes              |
| Multifunctional endpiece                       | yes              |
| Pointfinder (Viewscreen)                       | 4xZoom           |
| Digital Level                                  | yes              |
| Bluetooth® Smart                               | yes              |
| Personalized Favorites                         | yes              |
| Timer  | yes              |
| Long Range Mode                                | yes              |
| Calculator                                     | yes              |

#### Message Codes

If the message **Error** does not disappear after switching on the device repeatedly, contact the dealer.

If the message **InFo** appears with a number, press the Clear button and observe the following instructions:

| No. | Cause   | Correction   |
|-----|---|--|
| 156 | Transverse tilt greater than 10°                        | Hold the instrument without any transverse tilt.   |
| 162 | Calibration mistake                                     | Make sure, the device is<br>placed on a absolutely<br>horizontal and flat surface.<br>Repeat the calibration<br>procedure. If the mistake<br>still occurs, contact your<br>dealer. |
| 204 | Calculation error                                       | Perform measurement again.   |
| 240 | Data transfer error                                     | Repeat procedure.  |
| 252 | Temperature too high                                    | Let device cool down.  |
| 253 | Temperature too low                                     | Warm device up.  |
| 255 | Received signal too<br>weak, measuring time<br>too long | Change target surface (e.g. white paper).  |
| 256 | Received signal too<br>high                             | Change target surface<br>(e.g. white paper).   |
| 257 | Too much back-<br>ground light                          | Shadow target area.  |
| 258 | Measurement outside of measuring range                  | Correct range.   |
| 260 | Laser beam inter-<br>rupted                             | Repeat measurement.  |

#### Care

- Clean the device with a damp, soft cloth.
- Never immerse the device in water.
- Never use aggressive cleaning agents or solvents.

#### Warranty

The Stanley TLM has a two-year warranty. For further information on this, contact your dealer.

Subject to change (drawings, descriptions and technical data).

#### **Safety Instructions**

The person responsible for the instrument must ensure that all users understand these directions and adhere to them.

#### Areas of responsibility

# Responsibilities of the manufacturer of the original equipment:

Stanley Tools 701 E. Joppa Road Towson, Maryland 21286 www.STANLEYLASERS.com www.STANLEYTOOLS.com www.STANLEYTOOLS.eu

The company above is responsible for supplying the product, including the User Manual in a completely safe condition.

The company above is not responsible for third party accessories.

# Responsibilities of the person in charge of the instrument:

- To understand the safety instructions on the product and the instructions in the User Manual.
- To be familiar with local safety regulations relating to accident prevention.
- Always prevent access to the product by unauthorised personnel.

EN

#### **Safety Instructions**

#### **Permitted use**

- Measuring distances
- Tilt measurement
- Data transfer with Bluetooth<sup>®</sup>

#### **Prohibited use**

- Using the product without instruction
- · Using outside the stated limits
- Deactivation of safety systems and removal of explanatory and hazard labels
- Opening of the equipment by using tools (screwdrivers, etc.)
- · Carrying out modification or conversion of the product
- Use of accessories from other manufacturers without express approval
- Deliberate dazzling of third parties; also in the dark
- Inadequate safeguards at the surveying site (e.g. when measuring on roads, construction sites, etc.)
- Deliberate or irresponsible behaviour on scaffolding, when using ladders, when measuring near machines which are running or near parts of machines or installations which are unprotected
- · Aiming directly in the sun

#### Hazards in use

## 

Watch out for erroneous measurements if the instrument is defective or if it has been dropped or has been misused or modified. Carry out periodic test measurements.

Particularly after the instrument has been subject to abnormal use, and before, during and after important measurements.

## 

Never attempt to repair the product yourself. In case of damage, contact a local dealer.

## 

Changes or modifications not expressly approved could void the user's authority to operate the equipment.

#### Limits of use

Refer to section "Technical data".

The device is designed for use in areas permanently habitable by humans. Do not use the product in explosion hazardous areas or in aggressive environments.

# Disposal

## CAUTION

Flat batteries must not be disposed of with household waste. Care for the environment and take them to the collection points provided in accordance with national or local regulations.

The product must not be disposed with household waste.

Dispose of the product appropriately in accordance with the national regulations in force in your country.



Adhere to the national and country specific regulations.

Product specific treatment and waste management can be downloaded from our homepage.

#### **Electromagnetic Compatibility** (EMC)

## 

The device conforms to the most stringent requirements of the relevant standards and regulations.

Yet, the possibility of causing interference in other devices cannot be totally excluded.

EN

#### **Safety Instructions**

# FCC statement (applicable in U.S.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- This device may not cause interference and
- this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme à la section 15 des règlements FCC. Son fonctionnement est soumis aux deux conditions suivantes :

- cet appareil ne doit pas causer d'interférences nuisibles, et
- cet appareil doit accepter toute autre interférence reçue, y compris les interférences pouvant entraîner un fonctionnement non désiré.

Ce dispositif est conforme à la norme RSS-210 d'Industrie Canada. L'utilisation est sujette aux deux conditions suivantes :

• ce dispositif ne pas doit pas être la source d'interférences nuisibles, et

 ce dispositif doit accepter toutes les interférences, y compris les interférences pouvant induire des opérations non souhaitées.

# Use of the product with Bluetooth ${}^{\ensuremath{\mathbb{R}}}$


## 

Electromagnetic radiation can cause disturbances in other equipment, in installations (e.g. medical ones such as pacemakers or hearing aids) and in aircraft. It can also affect humans and animals.

#### Precautions:

Athough this product conforms to the most stringent standards and regulations, the possibility of harm to people and animals cannot totally excluded.

- Do not use the product near petrol stations, chemical plants, in areas with a potentially explosive atmosphere and where blasting takes place.
- Do not use the product near medical equipment.
- Do not use the product in airplanes.
- Do not use the product near your body for extended periods.



The device produces visible laser beams, which are emitted from the instrument: It is a Class 2 laser product in accordance with:

 IEC60825-1 : 2014 "Radiation safety of laser products"

#### Laser Class 2 products:

Do not stare into the laser beam or direct it towards other people unnecessarily. Eye protection is normally afforded by aversion responses including the blink reflex.

## 


Looking directly into the beam with optical aids (e.g. binoculars, telescopes) can be hazardous.

## 

Looking into the laser beam may be hazardous to the eyes.

| Maximum peak radiant output power: | 0.95 mW            |
|------------------------------------|--------------------|
| Wavelength:                        | 635 nm             |
| Pulse duration:                    | >400ps             |
| Pulse repetition frequency:        | 320 MHz            |
| Beam divergence:                   | 0.16mrad x 0.6mrad |

#### Labelling



Subject to change (drawings, descriptions and technical data) without prior notice.