

User Manual

SR100i....LAN+

**No-Break™ DC UPS with SNMP communications port
100W**



Please refer to separate user manual for full SNMP instructions

Safety

The user is responsible for ensuring that input and output wiring segregation complies with local standards and that in the use of the equipment, access is confined to operators and service personnel. A low resistance earth connection is essential to ensure safety and additionally, satisfactory EMI suppression (see below).

HAZARDOUS VOLTAGES EXIST WITHIN A POWER SUPPLY ENCLOSURE AND ANY REPAIRS MUST BE CARRIED OUT BY A QUALIFIED SERVICEPERSON.

Electrical Strength Tests

Components within the power supply responsible for providing the safety barrier between input and output are constructed to provide electrical isolation as required by the relevant standard. However EMI filtering components could be damaged as result of excessively long high voltage tests between input, output and ground. Please contact our technicians for advice regarding electric strength tests.

Earth Leakage

The EMI suppression circuits causes earth leakage currents which may be to the maximum allowable of 3.5mA.

Ventilation

High operating temperature is a major cause of power supply failures, for example it has been well documented that a 10°C rise in the operating temperature of a component will halve its expected life. Therefore always ensure that there is adequate ventilation for the equipment. Batteries and cooling fans also suffer shortened lifetimes if subjected to high ambient temperatures - both should be included in a routine maintenance schedule to check for signs of reduced efficiency.

Water / Dust

Every effort must be made in the installation to minimise the risk of ingress of water or dust. Water will almost always cause instant failure. The effects of dust are slower in causing failure of electronic equipment but all electrical equipment should be cleaned free of any dust accumulation at regular intervals. This is particularly important where internal fans are fitted.

Electromagnetic Interference (EMI)

Switching power supplies and converters inherently generate electrical noise. All wiring should be as short as practicable and segregated from all equipment wiring which is sensitive to EMI. Residual noise can be reduced by looping DC wiring through ferrite cable sleeves. These are most effective as close to the power supply as possible and as many turns of the wire taken through the core (+ and - in the same direction) as the core will accommodate.

Fuse ratings

Check that the wiring and fuses or MCBs match the rating of the PSU or converter. Adequate fuse protection of battery circuits is very important owing to the large potential currents available from batteries. Our **No-Break DC** series has an internal ECB for protection of the battery circuit but for all other charging situations should have an external fuse or circuit breaker fitted in the battery circuit.

Connection polarity

It is critical to check the polarity carefully when connecting batteries and equipment to DC power supplies and chargers. Boost chargers (and some float chargers) made by Innovative Energies have reverse polarity protection, which can be by an electronic switch (non-destructive) or an internal fuse which needs to be replaced if a battery is connected in reverse.

Glossary of terms used in our user manuals

PSU = power supply unit

BCT = battery condition test

ECB = electronic circuit breaker

ELVD = electronic low voltage disconnect

RPP = reverse polarity protection


EMI = electromagnetic interference

SNMP = Simple Network Management Protocol


LAN = local area network

The **No-Break™ DC** power supply is designed to provide DC power to lead acid batteries for critical back up applications. In addition to the normal features of the standard **SR100C..** model, the **SR100i....-LAN+** has an ethernet communication interface using SNMP protocol to enable user monitoring of the power supply and battery parameters and control of the battery condition test function.

No-Break™ SYSTEM BLOCK DIAGRAM



OPERATION OF ELECTRONIC CIRCUIT BREAKER (ECB)




The ECB is activated under the following conditions:

1. battery voltage drops below the V_{disco} (1.66V/cell)
2. battery current overload (refer to graphs above)

The ECB will latch open only when there is no input power present. It will reset when input power is restored or can be manually reset by briefly shorting the **BAT-** and **LOAD-** terminals together when there is no input power.

CONNECTION DIAGRAM



CONNECTION & INITIAL TESTING


- 1 Check input and output voltages of system, ensure that they match the equipment. All loads should be isolated.
- 2 Check polarity of all wiring. Place temperature sensor probe near or on batteries.
- 3 Plug in input power. **"POWER OK"** and **"BATT OK"** LEDs will light up. **"BATT OK"** will go out in about 10 secs as there is no battery connected. DC output voltage should appear at both load and battery outputs.
- 4 Turn off input power.
- 5 Connect battery.
- 6 Check that ECB (internal electronic circuit breaker) closes by shorting together the **BATTERY -ve** and **LOAD -ve** terminals briefly. Both LEDs will light up. If this does not happen, there is a fault in the wiring or the internal battery protection fuse is ruptured (see Note 2 below). The battery voltage will then appear at the load terminals and the **"BAT LOW"** alarm relay energises. The **"POWER OK"** LED stays on for about 30 seconds and then goes out
- 7 Connect load wiring to **LOAD+** and **LOAD-** terminals.
- 8 Turn on input power for the system to be operational.
- 9 Please refer to separate user manual for setting up the SNMP web interface.
- 10 Connect network cable to monitor power supply parameters (refer to separate instructions for SNMP setup)

NOTES

- 1 **Maximum current available**
 with input power present: 2.5 x rated PSU current
 with no input power: 1.5 x rated PSU current
- 2 **Reverse polarity protection**
 If the battery is connected in reverse, the internal battery protection fuse may be ruptured and the unit should be returned to the manufacturer for repair. If the fuse is good, the voltage measured as at step 3 above should be exactly the same on both the load and battery outputs.
- 3 **Battery Condition Test (BCT)**
 BCT function is disabled on start up and is controlled via the SNMP interface.
- 4 **BCT fail reset**
 If the system fails a BCT the **BAT LOW** alarm latches (de-energized state) until

either: both the mains power input and the battery are disconnected briefly
or: the system passes the next BCT.

ALARM CONNECTIONS



ALARMS

POWER:

Relay is energized when input power and DC output are present

BATT:

Relay is de-energized when either:

1. battery voltage = 1.8V/cell (for 2V cells) - operates only when no input power present or
2. battery missing or fault in battery circuit wiring (alarm does not activate for up to battery detection interval time).




AUX:

Relay is energized when a BCT is in progress.

LED INDICATION

Power OK LED	Battery OK LED	Power Alarm	Battery Low Alarm	Condition
		Normal	Normal	System Normal: Input power on, battery circuit is OK
		Normal	Normal	Battery detection test in progress
		Normal	Alarm	Input power on, battery system fault: 1. Internal battery fuse has opened or 2. Battery circuit wiring open circuit, battery missing, ECB has tripped
		Alarm	Normal	Input power off or PSU has failed. Battery system is OK (battery volts > Vbatl)
		Alarm	Alarm	Input power off or PSU has failed and battery has discharged to < V batl
		Alarm	Alarm	Input power off, ELVD has activated and disconnected battery from load
		Normal	Normal	BCT is in progress: LEDs flash slowly
		Normal	Alarm	Input power on, battery voltage < Vpres during a BCT

LEGEND :



Default Settings (at 20°C)

Parameter	Nominal Voltage					Default Value
	12V	24V	30V	36V	48V	
*1 V out = Output voltage	13.8	27.6	34.5	41.4	55.2	2.3V/cell
V pres = Voltage threshold for battery detection & battery condition test (BCT). If voltage drops to this level during BCT then the test is aborted and BATT SYS OK relay de-energises	12.2	24.4	30.5	36.6	48.8	2.03V/cell
V shutd = Output voltage of PSU during battery detection & BCT	11.5	23	28.8	34.5	46	1.92V/cell
V batl = Battery low alarm voltage during mains fail. (BATT SYS OK alarm relay de-energises)	11	22	27.6	33	44	1.84V/cell
V disco = Battery disconnect voltage during mains fail	10	20	25	30	40	1.66V/cell
Bccl = Maximum charge current as % of rated PSU rated current						*2
Comms = communications mode of PSU: F = continuous data stream of status M = responds only to request made by a controller						M
BatDetect = Battery detection interval time, active only when no battery charge current is detected (the unit may not detect a missing battery for up to this time)						60 min
BCT = length of battery condition test						20 min
Ret = retest option: N = after a failed BCT further scheduled BCTs are inhibited Y = after a failed BCT further scheduled BCTs will be allowed						Y
CC = Length of charge cycle in minutes/hours/days. ie. time between battery condition tests						40m/23h/ 027d
MfiBCT = time before mains fail check during BCT. A mains fail during a BCT will stop the BCT. If set longer than BCT time no mains fail check will occur.						30 min

NOTES:

***1** Output voltage is set by an internal potentiometer.

***2** Refer to model table or label at the front of this manual if non-standard

Notes



SR100 *i* with ethernet communication port

◆ 24 Month Warranty

- Serial or Ethernet options available
- Separate load and battery outputs
- Battery detection - regular battery presence and battery circuit integrity checks
- Deep discharge protection
- Adjustable charge current limit
- Battery circuit protected against overload, short circuit & reverse polarity
- Temperature compensated float charging
- Automated or manually controlled battery condition test
- No transition switching to backup battery
- Alarm contacts & LEDs for precise fault indication
- Suitable for use with all lead acid batteries (batteries external to power supply)

SPECIFICATIONS All specifications are typical at nominal input, full load and at 20°C unless otherwise stated.

ELECTRICAL

Input Voltages	
▪ standard	180V - 264VAC 45-65Hz
▪ optional	88V - 132VAC 45-65Hz
Fusing / Protection	AC input fuse DC battery output fuse
Isolation	1KV DC input - output / earth
Efficiency	≥ 85%
Inrush current	<30A, 1.8ms
Output Power	100W continuous (0 - 50°C)
Output Voltages	13.8V, 27.6V, 41.4V, 55.2V Other voltages by request.
Voltage adj. range	85 - 105% of Vout
Temp. Compensation	Temperature sensor on 1.7m lead with adhesive pad: -4mV / °C / cell ±10%
Current Limit	Output current limit set at rated FLC
Line Regulation	<0.04% over AC input range
Load Regulation	<0.5% open circuit to 100% load
Noise	<0.3%
Transient response	200mV over / undershoot, load step 20-100%, 400us settling time
Thermal Protection	Automatic current de-rating if >50°C. Self-resetting.
Hold-up time	15 - 20 ms (nom. - max. Vin) without battery

No-Break™ FUNCTIONS AND ALARMS

Battery Charge Current Limit	See Model Table for default settings. (25% & 50% settings available on request)
Reverse Polarity	Battery reverse connection will open internal fuse (and produce alarm)
Battery Monitoring	Detects for presence of battery on start up, then every 60 minutes when charge current < 200mA
Battery Protection	Electronic Circuit Breaker (ELCB) operates under the following conditions:
- battery discharged	ELVD (electronic low voltage disconnect) activates when battery voltage drops to 1.67V/cell (adjustable) - auto reset
- overload	Allows ~150% load from battery without acting, operates within 300ms for total load > 600%
- short circuit	Acts within 2ms, backed up by fuse
LED Indication	Green: Input power on & PSU working Green: Battery system intact
Alarms	<ul style="list-style-type: none"> • Power OK (Mains or PSU fail) • Battery System OK - alarms when battery voltage low (on mains fail), battery missing, battery circuit wiring faulty, BCT fail
Alarm Relay contacts	C - NO - NC full changeover rated 30VDC, 2A / 110VDC, 0.3A / 125VAC, 0.5A
Battery Condition Test (BCT)	Default setting: 20mins every 28days

PHYSICAL

AC Input connector	IEC320 input socket (similar to PCs etc.)
DC Connections	Plug-in style socket & mating screw terminal block: (max. wire 2.5mm ² / way)
Alarm Connections	Plug in screw terminal block
Enclosure	Zinc plated steel / powder coated lid
Dimensions	147W x 177D x 62H mm
Weight	0.95 Kg

STANDARDS

EMI	to CISPR 22 / EN55022 class A
Safety	to IEC950 / EN60950 / AS/NZS3260

100 Watt No-Break™ DC UPS

SR100i

STANDARD PREFERRED MODEL TABLE

MODELS	DC Output			
	Output Voltage (Load & Charger)	Max. Recomm.*1 Load Current (I _{LOAD})	Charge Current limit*2 (I _{CHARGE})	PSU Rated Current (I _{PSU})
SR100i 12	13.8V	6.0A	7.5A	7.5A
SR100i 24	27.6V	3.0A	3.7A	3.7A
SR100i 36	41.4V	1.9A	2.4A	2.4A
SR100i 48	55.2V	1.5A	1.9A	1.9A

*1 to allow for adequate charging current

*2 25% & 50% settings available on request

ENVIRONMENTAL

Operating temperature	0 - 50 °C ambient at full load De-rate linearly >50 °C to no load @ 70 °C
Storage temperature	-10 to 85 °C ambient
Humidity	0 - 95% relative humidity non-condensing

ACCESSORIES SUPPLIED

Mounting Feet together with screws
AC power cord Standard 1.5m lead with IEC320 socket / local plug
DC connector with mating screw-terminal plug
Alarm connector with mating screw-terminal plug

OPTIONS

Communication Port for -i & V versions	Choice of RS485, RS232, Ethernet
+PROTOCONMB-x	Protocol Converter (RS485 to MODBUS) with programming port for PC. Power MBLink setup software supplied -x = blank x = -OE for above plus Ethernet Port
Parallel Redundancy	Use external output diode: eg. +P15 or any suitably rated diode bridge rectifier.



SR100i with RS485 comms port

CABINET OPTIONS

19" Rack Mount	2U sub rack option: add SR-RM2U Optional V/I meter for subrack: SR-METER
Wall Mount Enclosure	PSU may be fitted into enclosure with MCBs and terminals. Code: SEC-SR

MODEL CODING AND SELECTION CHART


SR100i12 T X G-LAN+

Communications Interface Port 485 = RS485 232 = RS232 LAN = ethernet (ASCII code)
LAN+ = Ethernet (SNMP) Blank = no comm. port

Input voltage	230V AC = blank 110V AC = G
Plug-in /screw terminal connector	
Temperature Compensation:	Yes = T No = blank
DC output: Nominal battery voltage:	12, 24, 30, 36, 48
Function:	C = No-Break™ i = No-Break™ with comms interface

#1 1 x No-Break™ DC charger and 1 x battery bank

This is the basic connection which is most commonly used, and provides adequate protection for the majority of systems requiring DC back up in the event of a mains power failure.




**Single battery DC
backup system**

Alarms Available

Power OK	YES
Battery Missing	YES
Battery Low	YES
Battery Condition Test Fail	YES

#2 1 x No-Break™ DC charger and 2 x battery banks

The SR250xxxV No-Break™ DC UPS is designed to provide superior battery backup availability without having to use two power supplies. Dual battery banks and automatic battery condition testing reduce the risk of battery failure for critical applications.




**N+1 redundancy for
batteries**

Alarms Available

Power OK	YES
Battery Missing (B1&B2)	YES
Battery Low (B1&B2)	YES
Battery Condition Test Fail (B1 & B2)	YES

#3 2 x No-Break™ DC chargers and 2 x battery banks

2 x No-Break™ DC chargers connected in parallel with separate battery banks & output diodes. This solution provides an extremely high level of redundancy for very critical applications, with redundancy of the battery in addition to the power supply. The diodes isolate the units from one another in the event of a short circuit appearing at the other output and aid current sharing.



**N+1 redundancy for
charger and batteries**


Alarms Available

Power OK	YES
Battery Missing	YES
Battery Low	YES
Battery Condition Test Fail*1	YES

*1 interlock circuit required for automated BCT

#4 No-Break™ DC Connection for high peak loads

This is a basic connection which is used when there is a connected load with a peak current greater than 1.5 times the rated current of the charger. Standing loads are connected normally and an optional external low voltage disconnect may be used for the peak load.



**Single battery DC
backup system for
peak loads**


Alarms Available

Power OK	YES
Battery Missing	YES
Battery Low	YES
Battery Condition Test Fail	YES

No-Break DC connections (continued)

#5 N+1 for No-Break™ DC charger and single battery bank

This connection provides for redundancy of the charger and retains most of the No-Break functions.




*1 interlock circuit required for automated BCT

Alarms available

Power OK	YES
Battery missing	NO
Battery low	YES
Battery condition test fail*1	YES

#6 N+1 for No-Break™ DC charger and N+1 for battery bank (use this connection for high peak loads)

All No-Break alarms are available and the low voltage disconnect for the peak load is optionally implemented with an external relay.




*2 interlock circuit required for automated BCT

Alarms available


Power OK	YES
Battery missing	YES
Battery low	YES
Battery condition test fail *2	YES


Standard N+1 redundant DC connections

#7 Standard AC/DC power supplies with alarms and external diodes



#8 Standard AC/DC power supplies with internally fitted diodes (applies only to SR100P and SR250P models with outputs >12VDC)





TERMS OF WARRANTY

Innovative Energies Ltd warrants its power supplies for 24 months (two years) from date of shipment against material and workmanship defects.

Innovative Energies' liability under this warranty is limited to the replacement or repair of the defective product as long as the product has not been damaged through misapplication, negligence, or unauthorized modification or repair.

Thank you for purchasing from Innovative Energies.

We trust your power supply will exceed your expectations and perform for years to follow.

Sincerely,
The Innovative Energies team.

Innovative Energies Limited

Phone: +64 9 835 0700
Freephone: 0800 654 668 (New Zealand)
1800 148 494 (Australia)
Fax: +64 9 837 3446
Email: info@innovative.co.nz
Online: www.innovative.co.nz or www.innovative-energies.com
In Person: 1 Heremai Street, Henderson, Auckland, New Zealand
By Post: PO Box 19-501, Auckland 1746, New Zealand