



H425V3
User manual

Contents

| | |
|---------------------------------|---|
| Contents | 2 |
| 1 Parameter list | 3 |
| 2 Parameter remarks | 7 |
| 3 Alarm list | 7 |
| 4 Slave alarm list | 7 |
| 5 Button list | 8 |
| 6 Led list | 8 |
| 7 Soft command list | 8 |
| 8 How to ... | 8 |
| 9 Shortcut list | 8 |
| 10 Led and push button location | 9 |

1 Parameter list

| Rem. | Parameter | Description | Minimum | Maximum | Default | Unit |
|------|-----------|---|---------|-------------|---------------------|------|
| | M__ | Functions about compressor | | | | |
| | MU__ | Functions about pressure switches | | | | |
| | ML0 | suction low pressure regulation (similar to Danfoss RT1AL set point minus half of neutral zone) | 0.0 | 99.0 | 2.8 (gauge) bar | |
| | MLb | suction pressure regulation dead band (ML0 +/- MLb are the upper/lower limits) | 0.0 | 99.0 | 0.5 bar | |
| | MLd | suction pressure regulation differential (loading at ML0+MLb+MLd / unl at ML0-MLb-MLd) | 0.0 | 99.0 | 0.2 bar | |
| 1 | Md0 | minimum HP-LP-difference to unload last compressor still running | 0.0 | 99.0 | 2.0 bar | |
| 1 | Md1 | minimum HP-LP-difference to leave all the compressors off | 0.0 | 99.0 | 0.5 bar | |
| | MH0 | discharge (HP) pressure limit forcing the timed compressor unload | 0.0 | 99.0 | 24.0 (gauge) bar | |
| 2 | MLH | low pressure safety restart (similar to Danfoss KP15 lp set point) | 0.0 | 99.0 | 1.2 (gauge) bar | |
| | MLL | low pressure safety stop (similar to Danfoss KP15 lp set point - differential) | 0.0 | 99.0 | 0.2 (gauge) bar | |
| | MHH | high pressure safety stop (similar to Danfoss KP15 hp set point) | 0.0 | 99.0 | 28.0 (gauge) bar | |
| | MHL | high pressure safety restart (similar to Danfoss KP15 hp set point - differential) | 0.0 | 99.0 | 24.0 (gauge) bar | |
| 3 | MU1 | minimum oil differential pressure of compressor nr. 1 | 0.0 | 99.0 | 1.0 bar | |
| | MU2 | minimum oil differential pressure of compressor nr. 2 | 0.0 | 99.0 | 1.0 bar | |
| 4 | MU3 | minimum oil differential pressure of compressor nr. 3 | 0.0 | 99.0 | 1.0 bar | |
| | Mut | minimum oil receiver temperature before opening the oil solenoid | -55.0 | 145.0 | 25.0 °C | |
| 5 | MM1 | usage of mc nr. 1 output: 0=off / 1=on / 2=auto / 3=slave no / 4=slave nc / 5=kriwan | 0 | 5 | 2 / | |
| | MM2 | usage of mc nr. 2 output: 0=off / 1=on / 2=auto / 3=slave no / 4=slave nc / 5=kriwan | 0 | 5 | 2 / | |
| | MM3 | usage of mc nr. 3 output: 0=off / 1=on / 2=auto / 3=slave no / 4=slave nc / 5=kriwan | 0 | 5 | 2 / | |
| 6 | MMH | enable external load override on INP-4 | oFF | _on | oFF / | |
| 7 | MMd | external load override delay | 0 | 194 4:20:15 | 1:00:00 dd hh:mm:ss | |
| | n__ | Functions about fans | | | | |
| | nc__ | Functions about condenser fans | | | | |
| | ncH | enable condenser fans when compressor is off and discharge pressure is over maximum | oFF | _on | _on / | |
| 8 | ncr | enable condenser fans speed regulation | oFF | _on | _on / | |
| 9 | ncU | fan minimum speed | 0 | 255 | 40 / | |
| | ncd | minimum HP-LP-difference to keep on fans | 0.0 | 99.0 | 2.0 (gauge) bar | |
| | n1H | fan 1 start pressure (similar to Danfoss KP5 set point) - active just when ncr is oFF | 0.0 | 99.0 | 6.0 (gauge) bar | |
| | n1L | fan 1 stop pressure (similar to Danfoss KP5 set point - differential) | 0.0 | 99.0 | 2.0 (gauge) bar | |
| | n2H | fan 2 start pressure | 0.0 | 99.0 | 7.0 (gauge) bar | |
| | n2L | fan 2 stop pressure | 0.0 | 99.0 | 5.0 (gauge) bar | |
| | n3H | fan 3 start pressure | 0.0 | 99.0 | 8.0 (gauge) bar | |
| | n3L | fan 3 stop pressure | 0.0 | 99.0 | 6.0 (gauge) bar | |
| | n4H | fan 4 start pressure | 0.0 | 99.0 | 9.0 (gauge) bar | |
| | n4L | fan 4 stop pressure | 0.0 | 99.0 | 7.0 (gauge) bar | |
| | b__ | Functions about probe calibration | | | | |
| | b1__ | Probe nr. 1 | | | | |
| | b1C | oil receiver temperature | -99.0 | 99.0 | 0.0 K | |
| | b1A | enable probe | oFF | _on | _on / | |
| | b2__ | Probe nr. 2 | | | | |
| | b2C | discharge temperature | -99.0 | 99.0 | 0.0 K | |
| | b2A | enable probe | oFF | _on | _on / | |
| | b3__ | Probe nr. 3 | | | | |
| | b3C | suction temperature | -99.0 | 99.0 | 0.0 K | |
| | b3A | enable probe | oFF | _on | _on / | |
| | b4__ | Probe nr. 4 | | | | |
| | b4C | mc1 oil pressure | -99.0 | 99.0 | 0.0 bar | |
| | b4A | enable probe | oFF | _on | _on / | |
| | b5__ | Probe nr. 5 | | | | |
| | b5C | mc2 oil pressure | -99.0 | 99.0 | 0.0 bar | |
| | b5A | enable probe | oFF | _on | _on / | |
| | b6__ | Probe nr. 6 | | | | |
| | b6C | mc3 oil pressure | -99.0 | 99.0 | 0.0 bar | |
| | b6A | enable probe | oFF | _on | _on / | |
| | b7__ | Probe nr. 7 | | | | |
| | b7C | high pressure (HP) | -99.0 | 99.0 | 0.0 bar | |
| | b7A | enable probe | oFF | _on | _on / | |
| | b8__ | Probe nr. 8 | | | | |
| | b8C | low pressure (LP) | -99.0 | 99.0 | 0.0 bar | |
| | b8A | enable probe | oFF | _on | _on / | |
| | L__ | Functions about alarm and stand-by | | | | |
| | L1__ | Other alarm inputs | | | | |
| | L1H | enable mc1 alarm | oFF | _on | _on / | |
| | L1d | mc1 alarm delay | 0 | 194 4:20:15 | 30:00 dd hh:mm:ss | |
| | L2H | enable mc2 alarm | oFF | _on | _on / | |
| | L2d | mc2 alarm delay | 0 | 194 4:20:15 | 30:00 dd hh:mm:ss | |
| | L3H | enable mc3 alarm | oFF | _on | _on / | |
| | L3d | mc3 alarm delay | 0 | 194 4:20:15 | 30:00 dd hh:mm:ss | |
| | L4H | enable external override alarm | oFF | _on | _on / | |
| | L4d | override alarm delay | 0 | 194 4:20:15 | 1:00:00 dd hh:mm:ss | |

| Rem. | Parameter | Description | Minimum | Maximum | Default | Unit |
|------|-----------|---|---------|-------------|-------------------|------|
| | L5H | enable digital input 5 alarm (compressor phase monitor / thermal overload relay) | oFF | _on | _on / | |
| | L5d | digital input 5 alarm delay | 0 | 194 4:20:15 | 1 dd hh:mm:ss | |
| | Lo_ | On / stand-by status | | | | |
| 10 | Loo | actual status: stand-by or on | oFF | _on | oFF / | |
| | d_ | Functions about delays | | | | |
| | dF_ | Delay from previous stop | | | | |
| | dF4 | mc1 start delay | 0 | 194 4:20:15 | 5:00 dd hh:mm:ss | |
| | dF5 | mc2 start delay | 0 | 194 4:20:15 | 10:00 dd hh:mm:ss | |
| | dF6 | mc3 start delay | 0 | 194 4:20:15 | 15:00 dd hh:mm:ss | |
| | dS4 | mc1 stop delay | 0 | 194 4:20:15 | 45 dd hh:mm:ss | |
| | dS5 | mc2 stop delay | 0 | 194 4:20:15 | 30 dd hh:mm:ss | |
| | dS6 | mc3 stop delay | 0 | 194 4:20:15 | 15 dd hh:mm:ss | |
| | F_ | Functions about cooling capacity boost | | | | |
| | FP_ | Functions about boost preference | | | | |
| | FPP | boost mode: 0=off / 1=on / 2=auto | 0 | 255 | 2 / | |
| | FPM | boost mode when not enough info is received: 0=off / 1=on | 0 | 255 | 1 / | |
| | FPd | delay before establishing that not enough info is received | 0 | 194 4:20:15 | 5:00 dd hh:mm:ss | |
| | FM_ | Functions about pressure switches in boost mode | | | | |
| | FM0 | suction low pressure regulation | 0.0 | 99.0 | 1.8 (gauge) bar | |
| | FMb | suction pressure regulation dead band | 0.0 | 99.0 | 0.5 bar | |
| | FMd | suction pressure regulation differential | 0.0 | 99.0 | 0.2 bar | |
| | FF_ | Delays in boost mode | | | | |
| | FF4 | mc1 start delay | 0 | 194 4:20:15 | 1:00 dd hh:mm:ss | |
| | FF5 | mc2 start delay | 0 | 194 4:20:15 | 5:00 dd hh:mm:ss | |
| | FF6 | mc3 start delay | 0 | 194 4:20:15 | 10:00 dd hh:mm:ss | |
| | FS4 | mc1 stop delay | 0 | 194 4:20:15 | 5:00 dd hh:mm:ss | |
| | FS5 | mc2 stop delay | 0 | 194 4:20:15 | 1:00 dd hh:mm:ss | |
| | FS6 | mc3 stop delay | 0 | 194 4:20:15 | 30 dd hh:mm:ss | |
| | H_ | Functions about hot gas mode | | | | |
| | HP_ | Functions about hot gas preference | | | | |
| | HPP | hot gas mode: 0=off / 1=on / 2=all / 3=auto | 0 | 255 | 3 / | |
| | HPM | hot gas mode when not enough info is received: 0=off / 1=on / 2=all | 0 | 255 | 1 / | |
| | HPd | delay to enter hot gas mode = on | 0 | 194 4:20:15 | 5:00 dd hh:mm:ss | |
| | HPE | delay to enter hot gas mode = all | 0 | 194 4:20:15 | 1:00 dd hh:mm:ss | |
| | H1_ | Functions about condenser fans when hot gas mode = on | | | | |
| | H1H | fan 1 start pressure | 0.0 | 99.0 | 12.0 (gauge) bar | |
| | H1L | fan 1 stop pressure | 0.0 | 99.0 | 6.0 (gauge) bar | |
| | H2H | fan 2 start pressure | 0.0 | 99.0 | 13.0 (gauge) bar | |
| | H2L | fan 2 stop pressure | 0.0 | 99.0 | 11.0 (gauge) bar | |
| | H3H | fan 3 start pressure | 0.0 | 99.0 | 14.0 (gauge) bar | |
| | H3L | fan 3 stop pressure | 0.0 | 99.0 | 12.0 (gauge) bar | |
| | H4H | fan 4 start pressure | 0.0 | 99.0 | 15.0 (gauge) bar | |
| | H4L | fan 4 stop pressure | 0.0 | 99.0 | 13.0 (gauge) bar | |
| | HA_ | Functions about condenser fans when hot gas mode = all | | | | |
| | A1H | fan 1 start pressure | 0.0 | 99.0 | 26.0 (gauge) bar | |
| | A1L | fan 1 stop pressure | 0.0 | 99.0 | 20.0 (gauge) bar | |
| | A2H | fan 2 start pressure | 0.0 | 99.0 | 25.0 (gauge) bar | |
| | A2L | fan 2 stop pressure | 0.0 | 99.0 | 23.0 (gauge) bar | |
| | A3H | fan 3 start pressure | 0.0 | 99.0 | 26.0 (gauge) bar | |
| | A3L | fan 3 stop pressure | 0.0 | 99.0 | 24.0 (gauge) bar | |
| | A4H | fan 4 start pressure | 0.0 | 99.0 | 27.0 (gauge) bar | |
| | A4L | fan 4 stop pressure | 0.0 | 99.0 | 25.0 (gauge) bar | |
| | HS_ | Delays in hot gas mode | | | | |
| | HS0 | minimum stop delay for the last mc still running | 0 | 194 4:20:15 | 2:00 dd hh:mm:ss | |
| | P_ | Functions about master preferences | | | | |
| | Pd_ | Functions about network address | | | | |
| | PdM | master address for global network communication | 0 | 254 | 1 / | |
| | PdS | number of slaves connected to this master | 1 | 2 | 2 / | |
| | Pb_ | Suction pressure broadcast | | | | |
| | PbH | enable suction pressure periodic broadcast over the PC net | oFF | _on | _on / | |
| | Pbd | delay between pressure broadcast messages | 0 | 194 4:20:15 | 30 dd hh:mm:ss | |
| | Pbb | delay between latest received message and broadcasting start | 0 | 194 4:20:15 | 2:00 dd hh:mm:ss | |
| | PbO | specify originating address in the pressure message | oFF | _on | _on / | |
| | Pb1 | broadcast a packet with low pressure and without additional info | oFF | _on | oFF / | |
| | Pb2 | broadcast a packet with low pressure and additional info | oFF | _on | _on / | |
| | PPM | become network master after Pbb delay | oFF | _on | oFF / | |
| | P2H | poll periodically second central unit for pressure broadcast | oFF | _on | oFF / | |
| | P2M | master address of second central unit | 0 | 254 | 2 / | |
| | P2d | delay between pressure broadcast messages of second central unit | 0 | 194 4:20:15 | 30 dd hh:mm:ss | |
| | P3H | poll periodically third central unit for pressure broadcast | oFF | _on | oFF / | |
| | P3M | master address of third central unit | 0 | 254 | 3 / | |
| | P3d | delay between pressure broadcast messages of third central unit | 0 | 194 4:20:15 | 30 dd hh:mm:ss | |
| | PO_ | Output assignment | | | | |
| 11 | PO3 | assign out-3 relay to: 0=condenser fan / 1=oil receiver solenoid / 2=alarm / 3=oil heater / 4=subcooler / 5=off | 0 | 3 | 0 / | |

| Rem. | Parameter | Description | Minimum | Maximum | Default | Unit |
|------|-----------|---|---------|-------------|---------|-------------|
| | I_ | Functions about input-output and machine state (read only) | | | | |
| | IA_ | Analog inputs | | | | |
| | IA1 | oil receiver temperature | -55.0 | 145.0 | -55.0 | °C |
| | IA2 | discharge temperature | -55.0 | 145.0 | -55.0 | °C |
| | IA3 | suction temperature | -55.0 | 145.0 | -55.0 | °C |
| | IA4 | oil pressure of mc1 | 0.0 | 30.0 | 0.0 | (gauge) bar |
| | IA5 | oil pressure of mc2 | 0.0 | 30.0 | 0.0 | (gauge) bar |
| | IA6 | oil pressure of mc3 | 0.0 | 30.0 | 0.0 | (gauge) bar |
| | IA7 | high pressure (HP) | 0.0 | 30.0 | 0.0 | (gauge) bar |
| | IA8 | low pressure (LP) | 0.0 | 30.0 | 0.0 | (gauge) bar |
| | Id_ | Digital input | | | | |
| | Id1 | mc1 hardware safety | oFF | _on | oFF | / |
| | Id2 | mc2 hardware safety | oFF | _on | oFF | / |
| | Id3 | mc3 hardware safety | oFF | _on | oFF | / |
| | Id4 | external override | oFF | _on | oFF | / |
| | Id5 | phase software safety | oFF | _on | oFF | / |
| | OA_ | Analog output | | | | |
| | OA1 | condenser | 0 | 255 | 0 | / |
| | OA2 | humidity - 4...20 mA | 0 | 255 | 0 | / |
| | Od_ | Digital output | | | | |
| 12 | Od1 | condenser fan 2 | oFF | _on | oFF | / |
| | Od2 | condenser fan 3 | oFF | _on | oFF | / |
| | Od3 | condenser fan 4 | oFF | _on | oFF | / |
| | Od4 | compressor 1 | oFF | _on | oFF | / |
| | Od5 | compressor 2 | oFF | _on | oFF | / |
| | Od6 | compressor 3 | oFF | _on | oFF | / |
| | Od7 | oil receiver solenoid - eventually connected to OUT-3 | oFF | _on | oFF | / |
| | Od8 | alarm - eventually connected to OUT-3 | oFF | _on | oFF | / |
| | Od9 | mc1 oil heater - eventually connected to OUT-3 | oFF | _on | oFF | / |
| | Od0 | digital output 3 | oFF | _on | oFF | / |
| | OS_ | Machine status | | | | |
| | OL0 | actual set point | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | OLb | actual dead band | -999.0 | 999.0 | -999.0 | bar |
| | OLd | actual differential | -999.0 | 999.0 | -999.0 | bar |
| | O1H | fan 1 start pressure | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | O1L | fan 1 stop pressure | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | O2H | fan 2 start pressure | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | O2L | fan 2 stop pressure | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | O3H | fan 3 start pressure | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | O3L | fan 3 stop pressure | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | O4H | fan 4 start pressure | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | O4L | fan 4 stop pressure | 0.0 | 999.0 | 0.0 | (gauge) bar |
| | LLA | actual alarm - read only (0 means no alarm) | 0 | 255 | 0 | / |
| | OM0 | suction low pressure regulation: 0=unload/1=neutral/2=load | 0 | 255 | 0 | / |
| | OM1 | number of running compressors | 0 | 255 | 0 | / |
| | OM2 | number of available compressors | 0 | 255 | 0 | / |
| | OML | low pressure is insufficient to load the first compressor | oFF | _on | oFF | / |
| | OMM | low pressure is insufficient and is going to unload the compressors | oFF | _on | oFF | / |
| | OMH | high pressure is excessive to load further compressors | oFF | _on | oFF | / |
| | OMi | high pressure is excessive and is going to unload the compressors | oFF | _on | oFF | / |
| 1 | OMF | compressor forcing for extreme winter conditions | oFF | _on | oFF | / |
| | OSF | boost mode | 0 | 255 | 0 | / |
| | OSH | hot gas mode | 0 | 255 | 0 | / |
| | OHd | timer to enter hot gas mode = on (in countdown-mode) | 0 | 194 4:20:15 | 0 | dd hh:mm:ss |
| | OHE | timer to enter hot gas mode = all (in countdown-mode) | 0 | 194 4:20:15 | 0 | dd hh:mm:ss |
| | OFM | not enough info is received | oFF | _on | oFF | / |
| | OFd | timer for not enough info (in countdown-mode) | 0 | 194 4:20:15 | 0 | dd hh:mm:ss |
| | ObH | autonomous pressure broadcast over the PC net | oFF | _on | oFF | / |
| | Obb | autonomous broadcast timer (in countdown-mode) | 0 | 194 4:20:15 | 0 | dd hh:mm:ss |
| | OF4 | mc1 timer (in countdown-mode) | 0 | 194 4:20:15 | 0 | dd hh:mm:ss |
| | OF5 | mc2 timer (in countdown-mode) | 0 | 194 4:20:15 | 0 | dd hh:mm:ss |
| | OF6 | mc3 timer (in countdown-mode) | 0 | 194 4:20:15 | 0 | dd hh:mm:ss |
| | OF0 | timer of first scheduled compressor (in countdown-mode) | 0 | 194 4:20:15 | 0 | dd hh:mm:ss |
| | OC0 | number of active rooms connected to this central unit, and not lost | 0 | 255 | 0 | / |
| | OC1 | number of rooms requiring liquid refrigerant | 0 | 255 | 0 | / |
| | OCH | number of rooms requiring hot gas | 0 | 255 | 0 | / |
| | OCt | number of rooms in turbo mode | 0 | 255 | 0 | / |
| | OCF | number of rooms in boost mode | 0 | 255 | 0 | / |
| | E_ | Functions about slave preferences | | | | |
| | EY_ | Functions about display | | | | |
| | EYY | input to show on display: 1=IA1 / 2=IA2 ... | 0 | 255 | 8 | / |
| | EYr | enable display rotation: 0=off / 1=all / 2=selected | 0 | 2 | 0 | / |
| | E0_ | Functions about display rotation, when EYr=1 | | | | |
| | E0d | duration of label display during rotation | 0 | 255 | 1 | / |

| Rem. | Parameter | Description | Minimum | Maximum | Default | Unit |
|------|-----------|--|---------|---------|---------|------|
| | E0E | duration of value display during rotation | 0 | 255 | 2 | / |
| | E1 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E1d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E1t | label text during rotation | 000 | yyy | ot= | / |
| | E1E | duration of value display during rotation | 0 | 255 | 0 | / |
| | E2 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E2d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E2t | label text during rotation | 000 | yyy | di= | / |
| | E2E | duration of value display during rotation | 0 | 255 | 0 | / |
| | E3 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E3d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E3t | label text during rotation | 000 | yyy | SU= | / |
| | E3E | duration of value display during rotation | 0 | 255 | 0 | / |
| | E4 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E4d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E4t | label text during rotation | 000 | yyy | o1= | / |
| | E4E | duration of value display during rotation | 0 | 255 | 0 | / |
| | E5 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E5d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E5t | label text during rotation | 000 | yyy | o2= | / |
| | E5E | duration of value display during rotation | 0 | 255 | 0 | / |
| | E6 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E6d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E6t | label text during rotation | 000 | yyy | o3= | / |
| | E6E | duration of value display during rotation | 0 | 255 | 0 | / |
| | E7 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E7d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E7t | label text during rotation | 000 | yyy | HP= | / |
| | E7E | duration of value display during rotation | 0 | 255 | 4 | / |
| | E8 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E8d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E8t | label text during rotation | 000 | yyy | LP= | / |
| | E8E | duration of value display during rotation | 0 | 255 | 4 | / |
| | E9 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | E9d | duration of label display during rotation | 0 | 255 | 1 | / |
| | E9t | label text during rotation | 000 | yyy | L0= | / |
| | E9E | duration of value display during rotation | 0 | 255 | 4 | / |
| | F0 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F0d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F0t | label text during rotation | 000 | yyy | Lb= | / |
| | F0E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F1 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F1d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F1t | label text during rotation | 000 | yyy | Ld= | / |
| | F1E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F2 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F2d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F2t | label text during rotation | 000 | yyy | 1H= | / |
| | F2E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F3 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F3d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F3t | label text during rotation | 000 | yyy | 1L= | / |
| | F3E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F4 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F4d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F4t | label text during rotation | 000 | yyy | 2H= | / |
| | F4E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F5 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F5d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F5t | label text during rotation | 000 | yyy | 2L= | / |
| | F5E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F6 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F6d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F6t | label text during rotation | 000 | yyy | 3H= | / |
| | F6E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F7 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F7d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F7t | label text during rotation | 000 | yyy | 3L= | / |
| | F7E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F8 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |
| | F8d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F8t | label text during rotation | 000 | yyy | 4H= | / |
| | F8E | duration of value display during rotation | 0 | 255 | 0 | / |
| | F9 | Functions about display rotation, when EYr=2 (repeated for each parameter) | | | | |

| Rem. | Parameter | Description | Minimum | Maximum | Default | Unit |
|------|-----------|--|---------|---------|---------|------|
| | F9d | duration of label display during rotation | 0 | 255 | 1 | / |
| | F9t | label text during rotation | 000 | yyy | 4L= | / |
| | F9E | duration of value display during rotation | 0 | 255 | 0 | / |
| | Eb | Functions about buzzer | | | | |
| | EbH | enable buzzer | 0 | 1 | 1 | / |
| | EF | Functions about slave default | | | | |
| | EFF | reload slave default parameters from EEPROM, at next restart | 0 | 1 | 0 | / |

2 Parameter remarks

| Nr. | Remark |
|-----|--|
| 1 | To ensure operation in extreme winter conditions, respect to normal ones, compressors may be switched on sooner, and off later. |
| 2 | When $MLH < MLL$, there is a delay of $10 * (MLL - MLH)$ seconds on Ip switch. Eventual pumpdown restart is over $MLH + 1$ bar. |
| 3 | Fixed time 120 s and manual reset. |
| 4 | In H425V3, starting from revision 03, when MU1 and MU3 are 5.0 and b4A and b6A are oFF, use 5NTC controller for compressors without oil pump; connect HP probe on AN-6 and LP on AN-7. |
| 5 | Caution! Selection by manual override forces compressor to run whatever the high and low pressure; no safety is left except hardware ones. In slave mode the output is used for partialization. In kriwan mode output is off for reset during stand-by. |
| 6 | Caution! The external override drives the compressors ignoring high and low pressure; no safety is left except hardware ones. It is recommended to close this contact passing through both contacts of a low pressure and high pressure switch like a kp15. The closed contact is interpreted as "load" while the open contact is neutral. The delays dF4 through dF6 are respected. |
| 7 | After the delay elapsed, the override forces a load. Automatic reset. |
| 8 | When speed regulation is off the fan is operated on-off. |
| 9 | Caution! Speed regulation can cause fan fault or electronic board fault. Low and average minimum speed can increase the risk. |
| 10 | Passing from stand-by to on and at power on, there is a 5 second delay spent in a virtual stand-by. |
| 11 | In H425V3, starting from revision 02, when PO3 is 4, OUT-3 drives the subcooler liquid solenoid; AN-1 input is the subcooler suction temperature; Mut is the wanted overheating, where 8.0 °C means 8.0 °C; maximum overheating is fixed at 99.0 °C; minimum overheating is fixed at 6.0 °C; n4H is the refrigerant type, where 0.1 bar means R404A; n4L is the cycle period, where 0.8 bar means 8 s; H4H is the initial on-time, where 0.5 bar means 5 s; H4L is the adaptation speed, where 0.8 bar means 8. To turn off the subcooler solenoid, set PO3 to 5. The subcooler is enabled just when all of the available motorcompressors are on. |
| 12 | The minus sign on display ("-") signals that output is going to start after a delay. |

3 Alarm list

| Display | Alarm | |
|---------|--------------------|--|
| A01 | mc 1 alarm | Pressure switch, thermistors, or any other compressor safety device has disconnected. |
| A02 | mc 2 alarm | Pressure switch, thermistors, or any other compressor safety device has disconnected. |
| A03 | mc 3 alarm | Pressure switch, thermistors, or any other compressor safety device has disconnected. |
| A04 | external override | The external override contact is driving the controller. |
| A05 | mc phase | Compressor overload/thermal relay disconnected, or missing mains phase - manual reset. |
| A06 | mc 1 oil pressure | Oil differential pressure remained under minimum value for 120 seconds - manual reset. |
| A07 | mc 2 oil pressure | Oil differential pressure remained under minimum value for 120 seconds - manual reset. |
| A08 | mc 3 oil pressure | Oil differential pressure remained under minimum value for 120 seconds - manual reset. |
| A09 | EEPROM invalid | EEPROM invalid. |
| A10 | EEPROM read start | EEPROM read start failure |
| A11 | EEPROM read end | EEPROM read end failure |
| A12 | EEPROM write start | EEPROM write start failure. |
| A13 | EEPROM write end | EEPROM write end failure. |
| A14 | EEPROM write max | EEPROM failure - reached the maximum number of writing attempts. |

4 Slave alarm list

| Display | Alarm | |
|---------|--------------|---|
| A96 | slave EEPROM | Failed write operation onto the slave EEPROM. |
| A97 | out of range | The slave address EdS might be out of the master range, the latter going from 1 to PdS. |
| A98 | no link | The slave does not receive any message from the master. |
| A99 | lost link | The slave lost the communication with the master. |

5 Button list

| Push button | Function |
|-----------------------|---|
| B1 esc - silence | Exit without saving from any menu - alarm buzzer silence. |
| B2 up | Up navigation in the menu. |
| B3 on / stand-by | Toggle between on and stand-by. |
| B4 left | Left navigation in the menu. |
| B5 down | Down navigation in the menu. |
| B6 right - menu - set | Right navigation in the menu - display and modify the set point - enter menu. |

6 Led list

| Led | Function |
|--------------------|--|
| L1 compressor 1 | On during compressor run - blinking slowly during activation and deactivation delay. |
| L2 compressor 2 | On during compressor run - blinking slowly during activation and deactivation delay. |
| L3 compressor 3 | On during compressor run - blinking slowly during activation and deactivation delay. |
| L4 condenser fan 1 | On during condenser run. |
| L5 condenser fan 2 | On during condenser run. |
| L6 condenser fan 3 | On during condenser run. |
| L7 condenser fan 4 | On during condenser run. |

7 Soft command list

| Soft command | Function |
|-----------------|------------------------|
| 4 skip mc delay | Skip compressor delay. |

8 How to ...

| How to ... | Function |
|---------------------------------|--|
| Switch between on and stand-by. | Keep pressed B3 button, to activate and deactivate stand-by. In stand-by every output is, leds from L1 to L7 blink, timers continue to count. |
| Program the menu. | Keep pressed B6 to enter the menu. Navigate up and down with B2 and B5. Select the submenu by B6. Change the parameter by B2 and B5, press B6 to confirm, or B4 to go back without saving. The changes will have effect after the exit from programming pressing B4 repeatedly. Press B1 to exit immediately without saving any parameter. |
| Show or change pressure set. | Press shortly B6 - the display shows the current set point - change it by B2 and B5, and confirm it by B6. As alternative, enter the menu program as explained above, modify the parameter ML0, then confirm it. |

9 Shortcut list

| Buttons to press | Shortcut description - keep pressed 5 seconds |
|------------------|---|
| / | This instrument has no further shortcuts. |

10 Led and push button location

