


Fisher-Price®

INTERACTV™

DVD BASED LEARNING SYSTEM

User's Manual



How many of
our friends are on
the screen?

**Keep this MANUAL, SET-UP DISC, PROGRAMMING CARD,
and TEST CARD for future reference as
they contain important information.**

TABLE OF CONTENTS

1. BATTERY INSTALLATION	2
2. SETTING UP THE CONTROLLER	3
• METHOD 1 - PROGRAMMING THE UNIT USING THE MANUFACTURER CODES	4
• METHOD 2 - PROGRAMMING THE UNIT USING MANUAL SEARCH	7
3. HOW TO PLAY	9
4. MANUFACTURERS CODES	11
5. CONSUMER INFORMATION	back cover


BATTERY INSTALLATION

- The battery compartment is located on the back of the unit.
- Unscrew and lift the cover away from the battery compartment.
- Insert 3 “AA” batteries as shown.
- For longest life and best performance use only alkaline batteries.
- Replace the battery compartment cover.

BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your toy (product). To avoid battery leakage;

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged (if designed to be removable).
- Rechargeable batteries are only to be charged under adult supervision (if designed to be removable).
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.




NOTE:

- If your DVD player does not respond properly to the controller, you may have to replace the batteries.
- After replacing the batteries, you do NOT have to re-program the codes into your controller- the codes you programmed will be automatically saved.

SETTING UP THE CONTROLLER

Your InteracTV unit can be set-up to be played with 3 different DVD players. There is a 3-position memory switch and a blank label located on the back of the unit to indicate which DVD player you want to program.



Before programming the unit slide the switch to position 1, 2, or 3.
Don't forget to mark the label for easy reference.
Remember - you must perform the following steps for each DVD player you wish to use with the controller.

Now you are ready to program the controller.

There are 2 methods that can be used to set-up the controller for each DVD player.
Begin with method 1.

METHOD 1 - PROGRAMMING THE UNIT USING THE MANUFACTURER CODES

Step 1 – PREPARING YOUR CONTROLLER

- Remember to slide the 3-position memory switch to the desired memory slot.
- Turn your TV and DVD player ON.
- Insert the InteracTV disc into your DVD player.
- You will watch a brief message and tutorial, which is then followed by a PROGRAMMING SCREEN.




Step 2 – PROGRAMMING YOUR CONTROLLER

- Insert the blue PROGRAMMING CARD into the InteracTV controller. When the card is properly inserted, the green light on the bottom right of your controller will blink twice.



- Refer to the list of MANUFACTURER'S CODES listed in the enclosed USER'S MANUAL and find the correct code number(s) for your DVD player.
- Point the controller directly at your DVD player and enter the first code number using the number keys. Use the forward arrow button to enter zero.
- After entering a 4-digit code, the light on your controller will blink one long blink.



Step 3 – TESTING YOUR CONTROLLER



- Remove the PROGRAMMING CARD from the InteracTV controller and insert the yellow TEST CARD into the InteracTV controller.
- The yellow TEST CARD should appear on your TV screen. If not, go back to Step 2 and input the next code.
- Test all nine letter buttons and both arrow buttons to make sure they respond properly by lighting up on your TV screen when pressed. Press each button slowly and wait for a response.
- If your TEST CARD works successfully for all 9 letters and both arrow buttons, proceed to STEP 4.

IMPORTANT: If your test card does NOT work successfully for ALL the buttons, return to STEP 2 by switching back to the PROGRAMMING CARD and trying the next code.

If you have entered all the codes listed for your DVD player and your test card still does not work successfully, refer to “METHOD 2 - PROGRAMMING THE UNIT USING MANUAL SEARCH”.

Step 4 – READY TO PLAY!

- Remove the TEST CARD from the InteracTV controller and insert an ACTIVITY CARD.
- Now you can begin play!



METHOD 2 - PROGRAMMING THE UNIT USING MANUAL SEARCH


Step 1 – PREPARING YOUR CONTROLLER

- Remember to slide the 3-position memory switch to the desired memory slot.
- Remove the InteracTV disc from your DVD player and turn the power OFF.

Step 2 – PROGRAMMING YOUR CONTROLLER

- Insert the blue PROGRAMMING CARD into your InteracTV controller. When the card is properly inserted, the light on the bottom of your controller will blink twice.
- Point the unit directly at the DVD player and press the backwards arrow button slowly.
- As you press the button, your InteracTV unit will search through all its codes to find a proper code for your DVD player.
- Each time you press the backwards arrow button the light will flash. Keep pressing the backwards arrow button until the power to your DVD player automatically goes ON, indicating that a proper code has been found.

NOTE: THIS STEP MAY TAKE SEVERAL MINUTES - PLEASE BE PATIENT.



Step 3 – TESTING YOUR CONTROLLER

- Insert the InteracTV disc into your DVD player.
- Remove the PROGRAMMING CARD from the InteracTV controller and insert the yellow TEST CARD into the InteracTV controller.
- The yellow TEST CARD should appear on your TV screen. If not, call the 1-800 number found in the back of this MANUAL for further assistance.
- Test all nine letter buttons and both arrow buttons to make sure they respond properly by lighting up on your TV screen when pressed.

If your TEST CARD works successfully for all 9 letters and both arrow buttons, proceed to STEP 4.

- If your TEST CARD does NOT work successfully for all 9 letters and both arrow buttons, call the 1-800 number found in the back of this MANUAL for further assistance.

Step 4 – READY TO PLAY!

- Insert the InteracTV DVD into your DVD player and make sure your TV is turned ON.
- Now remove the programming card and insert one of the play cards.

NOTE: If you experience continued difficulty, call the 1-800 number found in the back of this MANUAL.


HOW TO PLAY

InteracTV comes with a Controller, a DVD, 3 Activity Cards, and a storage case.



Additional DVD'S and Activity Cards are sold separately.

- Insert the DVD into your DVD player.
- Insert an Activity Card, picture side up, into the slot on the face of the InteracTV controller. When the Activity Card is properly inserted, the light on the bottom of the controller blinks twice and the show begins! The game displayed on your TV should be the same as the card you just inserted.



- There are key points throughout the show that will prompt your child to respond to interactive questions. When your child is asked a question, various answers -- including the correct one -- appear on the screen.



- Your child selects an answer by pressing the picture or symbol on the Activity Card that corresponds with the same picture or symbol on screen. InteracTV is so simple to use, that after a little help from you, your child will be able to play for hours.



- At anytime, your child can replay or skip sections using the controller's arrow buttons.

InteracTV turns television from an inactive to an inter-active experience!

FCC NOTE (UNITED STATES ONLY)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

FISHER-PRICE and MATTEL shall not be liable for operational, technical, or editorial errors/omissions made in this manual.

The information in this manual may be subject to change without prior notice.

©2003, 2004 Sesame Workshop. "Sesame Street," "Sesame Workshop" and their logos are trademarks of Sesame Workshop. All rights reserved.

Watch Sesame Street on PBS and 123 Sesame on Noggin. ©2003, 2004 Viacom International Inc. All Rights Reserved.

Nickelodeon, Nick Jr., Dora the Explorer and all related titles, logos and characters are trademarks of Viacom International Inc.

©2003, 2004 Viacom International Inc. All Rights Reserved.

Nickelodeon, Nick Jr., Blue's Clues and all related titles, logos and characters are trademarks of Viacom International Inc.

©2003, 2004 Viacom International Inc. All Rights Reserved.

Nickelodeon, SpongeBob SquarePants and all related titles, logos, and characters are trademarks of Viacom International Inc. Created by Stephen Hillenburg.

InteractTV is a mark of Beep Telecommunications and Computing, L.L.C. Used under license.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., New York, New York 10010 U.S.A.

PRINTED IN CHINA.

Manufactured for Fisher-Price. ©2003, 2004 Mattel, Inc. All Rights Reserved.

Fisher-Price and the Fisher-Price logo are U.S. trademarks of Mattel, Inc.

Packaging and address should be retained for future reference.

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-888-892-6123.

Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628500303.

Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.

Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Dilimport & Dledarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe,

Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.

Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Affairs 1 (800) 524-Toys.



Questions or Comments?
1-888-892-6123

Fisher-Price®

ITEM NO. B9376