

CAN-AC2 SOLUTION FOR REAL-TIME SIMULATION WITH RT-LAB



This document explains how to use the CAN-AC2 (PCI) Softing card in a real-time simulation using RT-LAB. It describes what are the steps in order to send a CAN message, to receive a CAN message, to monitor a CAN bus and what are the hardware requirements to communicate with an external device.


All the blocks referred to in this document can be found under the following Simulink library: [RT-LAB I/O / Softing / CANAC2-PCI](#)

Detailed example models can be found under:
[C:\Opal-rt\RT-LABx.x.x\Examples\IO\Softing\CANAC2-PCI](#)

Send a CAN message

- Add an **OpCanAc2-PCI_Ctl** block in your model. This is the “controller” block. The OpCanAc2 Controller block is used to define the settings of a CANbus physical port. Only one controller is allowed per port and a controller is necessary in order for a port to work with RT-LAB. Therefore, if the CAN card used has 2 ports, 2 controllers are required in order to set them and make them functional. They can both have different settings as each controller block is unique.
- Open the controller block and set its parameters depending on your specific application. Most top parameters are basic fields that allow the user to select to which card / which port he wants to assign this controller block. These settings are roughly defined by the hardware specs of the card (model, location in the target PC, etc) in the system and they are already defined in the System Integration documentation provided with the customer’s system at delivery. More detailed parameters are available for those who need to implement a specific HIL solution with the CAN card. See Appendix A.

Note: All inputs/outputs of the Controller block are available or not depending only on the parameters set inside the block. If all parameters are unchecked, the block has no I/O.




- Add an **OpCanAc2 Send** block in your model. This is the “send” block. This block allows transmission of a CAN message. The block refers to a physical port that is configured in the controller block through the “Controller ID” parameter.
- Open the send block and set its parameters depending on your specific application. The “Controller ID” parameter of the send block must match the “Controller ID (shared with RECV and SEND blocks)” from the controller block.

This allows RT-LAB to associate a send block with a controller, and therefore a send block with a physical port of the card. More detailed parameters are available on how to set the width or the data packing of the messages to send. See Appendix B.

- Connect the inputs and outputs of the send block.

Vector containing the values of the message to be sent in the format specified in the "Input line width list" parameter of the block. For example, if the format specified is [32 32], the vector must contain 2 elements. Those 2 elements must be muxed in a single signal line.



Send error values returned by the send block. See Help file for association between error values and error definition. Default = 0 (No error).


Send status value. Returns 0 or the transmission FIFO level if enabled.

Message identifier value (message ID). Expected form is decimal (ie the user must connect a constant of 291 to this input if he wants to send on ID 0x123 in hex for example).

- As one send block per message ID is required, the user must/can insert multiple send blocks if there is a need to send messages on various IDs. They must all be associated to the same controller if the user expects to send all those messages on the same physical port of the card.

Receive a CAN message


- Add an **OpCanAc2-PCI_Ctl** block in your model. This is the “controller” block. Open the controller block and set its parameters depending on your specific application. See more detailed information about this block in the “Send a CAN message” section or in Appendix A. Note that if a physical port of a card is meant to send AND to receive data, only one controller block can be assigned to this port. Both the send and the receive blocks will refer to a single controller ID as they are all associate with the same port.
- Add an **OpCanAc2 Recv** block in your model. This is the “receive” block. Open the receive block and set its parameters depending on your specific application. The “Controller ID” parameter of the receive block must match the “Controller ID (shared with RECV and SEND blocks)” from the controller block. This allows RT-LAB to associate a receive block with a controller, and therefore a receive block with a physical port of the card. More detailed parameters are available on how to set the width of the data received and how to do some scaling on it. See Appendix C.
- Connect the outputs of the receive block.



- As one receive block per message ID is required, the user must/can insert multiple receive blocks if there is a need to receive messages on various IDs. They must all be associated to the same controller if the user expects to receive all those messages on the same physical port of the card.

Monitor a CAN bus

- Add an **OpCanAc2-PCI_Ctl** block in your model. Open the controller block and set its parameters depending on your specific application. See more detailed information about this block in the “Send a CAN message” section or in Appendix A.
- Add an **OpCanAc2 Monitor** block in your model. This is the “monitoring” block. It monitors all transactions on a CAN port of a CAN-AC2 card. Open the monitoring block and set its parameters depending on your specific application. The “Controller ID” parameter of the receive block must match the “Controller ID (shared with RECV and SEND blocks)” from the controller block. This allows RT-LAB to associate a monitoring block with a controller, and therefore a monitoring block with a physical port of the card. Basic parameters allow the user to choose the expected number of packet to receive and in what format should the data be unpacked. More detailed parameters are available on how to use a log file for monitoring. See Appendix D.
- Connect the outputs of the receive block.




- As one monitoring block per physical port is required, the user must/can insert two monitoring blocks if there is a need to monitor both ports of the card.

Hardware Requirements


Once the modeling side is done and the card is ready to send/receive, the user must make sure he meets the CAN communication hardware requirements in order to exchange data on a CAN bus. In a classic configuration:

- 120 resistors must be placed at each end of the network.
- CAN-AC2 PCI from Softing already contains these resistors for both ports. The DIP switches located on the PCI bracket must be turned on to insert the onboard resistor into the circuit. There is one DIP switch per port. Such a CAN network can be represented as:



The CAN-AC2 Softing PCI card has DB9 connectors for each channel. The associated pinout is the following:

Pin	Signal
1	N.C.
2	CAN_L
3	GND (DCDC)
4	N.C.
5	Drain (1M/100n to PC GND)
6	GND (DCDC)
7	CAN_H
8	N.C.
9	N.C.



More information is available on the hardware requirements for users of the [Single Wire mode](#). See Help file of the OpCanAc2-PCI_Ctl block.

Technical Specifications Example

This example shows the link between CAN bus specs and how to implement a real-time solution using the CAN-AC2 PCI Softing card and RT-LAB. Here is a table containing fictive customer specs about what he needs to send, receive and monitor on a CAN bus. The RT-LAB Simulink model attached with this document (TSE.mdl) contains multiple comments so the user can quickly get the relation between the specs and how the model is parameterized.

Physical Port #1 (Baud Rate = 250kBauds)

Messages to SEND	ID (hex)	Rate (ms)
[10000 20000]	0x200	10
Messages to RECEIVE	ID (hex)	Rate (ms)
[65000 55 45 35]	0x300	5

Physical Port #2 (Baud Rate = 500 kBauds)

Messages to SEND	ID (hex)	Rate (ms)
[1 2 3 4 5 6 7 8]	0x400	20
Messages to RECEIVE	ID (hex)	Rate (ms)
None	N/A	N/A
Additional Requirements		
Would like to have a saved log file of data packets of the sent messages. These packets should be saved only when a specified condition is met. The file should contain the 17 consecutive data packets following the trigger and 3 packets before.		

APPENDIX A - Controller Block

The following appendix contains detailed information taken from the Help file of the OpCanAc2-PCI_Ctl block.

Baud Rate page allows the user to set the communication baud rate on the selected channel. It is possible to select either predefined values or CUSTOM. When selecting CUSTOM, the following presc, sjw, tseg1, tseg2 and same are used for defining a specific baud rate. See Can-Ac2 User Manual for more information.

Acceptance Mask/Code page allows the user to define the reception filter for standard (Std, 11 bits) or Extended (Xtd, 29bits) messages on the selected channel. The reception filter follows the following condition:

Accept message if $((\text{MsgID} \wedge \text{Acc.Code}) \& \text{Mask}) == 0$
where “ \wedge ” is a bitwise exclusive OR and “ $\&$ ” is a bitwise AND.

Examples: For accepting all messages, use Std and Xtd Acceptance Code=0, Std and Xtd Acceptance Mask=0 (Default value). For accepting only Standard and Extended message with an identifier equal to 1, use Std Acceptance Code = 0x7ff, Std Acceptance Mask = 0x001, Xtd Acceptance Code = 0x1ffffff, Xtd Acceptance Mask = 0x00000001.

Advanced page contains integrated options that can serve to monitor or control the application:

Show error frame count: Creates an additional output which produces the number of error frames detected since the beginning of the execution.

Show bus load: Creates an additional Error Frame Count output which indicates the number of packets per second which went through the bus (includes incoming and outgoing messages). This value is refreshed continuously at the rate specified in the Bus Load Refresh Rate parameter.

Bus load refresh rate: Specifies the refresh rate in seconds of the Bus Load output.

Show bus state: Creates an additional Bus State output which indicates the current bus state (error passive, error active or bus off).

Show application status: Creates an additional Status output which indicates the current status of the CAN application.

Use send enable inport: This option activates the Enable inport which allows the user to disable all the send blocks related to this controller. This is mainly useful if a model uses both channel but the setup has only one of them actually connected to active devices. In such a situation, the CanAc2 will go into an error mode and transmission on both channels will stop. Deactivating transmission on the unused channel is the solution in

such circumstances. Communication will resume as soon as the cards FIFO gets full and is cleared by the software.

Use the chip reset inport: Creates an additional Reset inport which allows to trigger a reset operation of the Can-Ac2 board. This is useful to recover from the BUS OFF state.

Purge the transmission FIFO on error frame detection: Indicates to perform a purge of the transmission FIFO when an error frame is detected.

Perform automatic chip reset after several consecutive error frames: A chip reset is automatically performed after several error frames. Warning: This feature may disappear from future versions of RT-LAB.

Number of consecutive error frames to tolerate: The number of error frames that will be tolerated before performing a chip reset.

APPENDIX B - Send Block

The following appendix contains detailed information taken from the Help file of the OpCanAc2 Send block.

Identifier Type: Normal type allows 11 bits identifier while extended allows 29 bits.

Input Line Width: List that defines how the data from the CAN message is supplied on the Data input pin. The list is handled from left to right and starts at Byte 0 of the CAN message. ie. A list of [4 4 8] means that the first (MSB) 4 bits of CAN message Byte 0 will be supplied on the Data input pin followed by the next 4 bits of Byte0 and the 8 bits forming Byte1.

Use resynchronization: Creates an additional inport which can be used to resynchronise cyclic transmission.

Allow data length override: Creates an additional inport which allows to specified how many bytes of the message are to be shipped. If this option is not used, the complete packet is transmitted.

Use input frequency: Creates an additional inport which can be used to specify message retransmission rate in milliseconds.

Data packing: This option allows to format data packing for compatibility with other devices. 2 notions are implied:

The first specifies if the packing of the signal should be started from the start or end of the packet. If Signal 1 to N is selected, packing will start from the less significant bits of the first transmitted byte. If Signal N to 1 is selected, packing will start from the most significant bits of the last transmitted byte and progress backward into the packet.

The second specifies if groups of 8, 16 or 32 bits must be permuted within the packet with respect to its middle boundary. Swapping is performed after signal packing.

Signal 1 to N - No swapping corresponds to the Intel format while Signal N to 1 - Swap 8-bit corresponds to the Motorola format.

Set message priority: When multiple send blocs are used, this parameter allows to force the order in which transmissions will occur. Valid priorities range between 0 and 2147483648 with 0 being the topmost priority. More than one block can have the same priority and priorities do not have to be consecutive numbers. For instance, it is possible to use: priorities 10, 15, 100, which will act the same as 0 ,1 and 2. Effective only in FIFO mode.

APPENDIX C – Receive Block

The following appendix contains detailed information taken from the Help file of the OpCanAc2 Recv block.

Identifier Type: Specifies the length of the data frame identifier. Normal type is 11 bits long while extended is 29 bits long.

Output Line Width: List that defines how the data from the data frame is supplied on the Data output pin. The list is handled from left to right and starts with byte 0 of the CAN data frame. For instance, a list of [4 4 8] means that the first (MSB) 4 bits of CAN data Byte 0 will be supplied on the Data output pin followed by the next 4 bits of Byte0 and the 8 bits forming Byte1.

FIFO internal Buffer Size: Specifies the number of frames the block may store before producing values to Simulink.

Max number of packet: Specifies the maximum number of frames that the block may produce to Simulink per calculation step. For instance, with a FIFO Internal Buffer Size of 10 and a Max number of packet of 3, up to 10 frames can be saved in the internal buffer but the block will only output from 0 to 3 frames whenever it is called. Assuming 4 frames have been received, the block will output the first 3 frames and keep the remaining one for the next execution.

Sample Time: Sample time of the block. A value of 0 represents fastest sample time of the model.

Show timestamps: Creates an additional output which returns the timestamp of incoming data frames in seconds.

Show DLC: Creates an additional output which returns data length in bytes.

Show scaled vales: Creates an additional output which returns the Data values with applied Gains and Offset (Scaled value=DATA*GAIN+OFFSET).

Gain: Vector the same length as Output line width specifying gain values to be applied.

Offset: Vector the same length as Output line width specifying offset values to be applied.

Data unpacking: This option allows to format data unpacking for compatibility with other devices. Two notions are implied:

The first specifies if the unpacking of the signal should be started from the start or end of the data frame. If Signal 1 to N is selected, packing will start from the less significant bits of the first transmitted byte. If Signal N to 1 is selected, unpacking will start from the

most significant bits of the last transmitted byte and progress backward into the data frame.

The second specifies if groups of 8, 16 or 32 bits must be permuted within the data frame with respect to its middle boundary. Swapping is performed before extracting signals. Signal 1 to N - No swapping corresponds to the Intel format while Signal N to 1 - Swap 8-bit corresponds to the Motorola format.

APPENDIX D – Monitoring Block

The following appendix contains detailed information taken from the Help file of the OpCanAc2 Monitor block.

Data unpacking: This option allows to format data unpacking for compatibility with other devices. 2 notions are implied:

The first specifies if the unpacking of the signal should be started from the start or end of the packet. If Signal 1 to N is selected, packing will start from the less significant bits of the first transmitted byte. If Signal N to 1 is selected, unpacking will start from the most significant bits of the last transmitted byte and progress backward into the packet.

The second specifies if groups of 8, 16 or 32 bits must be permuted within the packet with respect to its middle boundary. Swapping is performed before extracting signals. 'Signal 1 to N - No swapping' corresponds to the Intel format while 'Signal N to 1 - Swap 8-bit' corresponds to the Motorola format.

Create log file: When this option is checked, all messages are logged into a matfile, which is written at runtime by a low priority thread. This option is not supported in XHP mode.

Log memory buffer size: Number of entries that the application can log into memory before placing data into the file. Since a RT-LAB model is executed real-time, writing into a file has to be done by a lower priority thread to avoid overruns. This thread writes data when time is available and in case time be missing, it is important to have a memory buffer large enough to keep messages in memory until time is available to write to the file. This value should never be less than twice the Number of samples between writes or twice the sum of Packets Before and after Trigger when using trigger model. It should be much larger than those limits to prevent data loss.

The matfile contains 1 variable in which each column represents one message and rows contain the following values:

1. Timestamp of the message (derived from the timestamp provided by the board)
2. Message identifier
3. DLC
4. Data byte 1
5. Data byte 2
6. Data byte 3
7. Data byte 4
8. Data byte 5
9. Data byte 6
10. Data byte 7
11. Data byte 8

12. Error.
13. Rx/Tx: 0=>message was received, 1=>message was transmitted)
14. Model time when the message was processed by the model
15. Identifier type: 0=>standard identifier, 1=>extended identifier.

Log file name: Name of the file, including the path. If no path is selected, the file will be placed in the model directory on the target node.

Log variable name: Name of the matlab variable created for the matfile.

Number of samples between writes: Minimum number of log entries (packets) that are cumulated into memory before writing to a file. This number should be smaller than half of Log memory buffer size.

Maximum file size (Mb): Maximum size of the log file. When this size is reached, file logging stops and file-logging overrun messages may appear in the RT-LAB display.

Use trigger: This option allows the user to trigger when the logging starts and end. Selecting this option make a block inport appears. Logging tot he file then starts when a rising edge (0 to 1) is detected at the inport. This allows users to narrow the file logging around some desired time value, and thus save disk space.

Packets to save before trigger: Specifies the number packets that came in before the trigger signal that are to be saved into the log file. The logging may not start at the exact step when the trigger was requested so it safer to set this value large enough to obtain packets for several steps before the trigger.

Packets to save after trigger: Specifies the number packets that came in after the trigger signal that are to be saved into the log file. The logging may not start at the exact step when the trigger was requested.