

**Read Me Before Usage!**



**Manual of 1502**

# Table of Contents

<b>Chapter 1 Content Description</b>	—1
Section 1 On-Lap Monitor and Accessories	—1
Section 2 Notices of Touch Screen Monitor	—2
Section 3 Safety Precautions	—3
Section 4 Safety Instructions	—3
Section 5 Product Maintenance	—3
Section 6 LCD Pixel Statement	—3
Section 7 Disposal of Electronic Equipment	—4
<b>Chapter 2 Installation Instructions</b>	—4
Section 1 Install Stand 4	—4
Section 2 Connect the Video Cable and USB Touch Output and Power Cable	—4
Section 3 Connect the 5V 2A Charger (Optional)	—6
Section 4 Install the VESA 100 Mount (Optional)	—6
<b>Chapter 3 Power On and Off the On-Lap Monitor</b>	—7
Section 1 Power On and Off the On-Lap Monitor	—7
Section 2 Monitor Display Setting	—7
Section 3 Windows 8 Touch Gesture Description	—8
<b>Chapter 4 Hot Keys, LED lights and OSD Instructions</b>	—8
Section 1 Hot Keys & LED lights Description	—8
Section 2 OSD Description	—9
Section 3 Low Power Protection Warning	—11
<b>Chapter 5 Specification</b>	—11
Section 1 Plug and Play	—11
Section 2 Pin Assignment and Standard Default Modes	—11
Section 3 Specification	—12
Section 4 Troubleshooting	—13

# Chapter 1 Content Description

## Section 1 On-Lap Monitor and Accessories

### 1. Parts Description




Fig.: 1502 parts, buttons and LED light Description




Fig.: On-Lap 1502 input/output ports




Fig.: Part description of Stand 4

## 2. Package & Accessories

Accessories	1502 T	1502 I
Micro HDMI Video Cable x1	Yes	Yes
VGA Video Cable x1	No (Optional)	No (Optional)
Micro USB to USB Touch Power Cable	Yes x 1	Yes x 2
Charger (5V,Max.2A) x1	No (Optional)	Yes
Stand 4	Yes	Yes
User Manual x1	Yes	Yes

## Section 2 Notice of On-Lap Monitor

1. Please do not use sharp objects to touch the screen. Gently use the finger to touch or swipe on the screen.
2. Please do not press the arm or other item to the screen or apply heavy pressure onto the screen.
3. Please keep fingers clean and dry when performing touch. If the finger has water drops it may result in the touch screen unable to determine touch location. Use finger to touch the screen, do not use fingertip to perform touch.
4. Touch signal needs to communicate through USB cable to Windows 8 or Windows 7 installed computer. Need to first make sure the Micro USB to USB Touch Power Cable is inserted into the correct port in order to have touch function capability.
5. Unstable power input will interfere with touch signal, resulting in inaccurate or failed touch function. It is suggested to use the USB port on laptop or manufacturer's 5V 2A Charger.
6. Disconnect power source before cleaning. Please use soft cloth to clean touch screen monitor. When difficult to clean, wet the cloth then perform cleaning again. Please do not use chlorine, alcohol, ammonia, detergent or other corroding solvents. These solvents may cause damage to the touch screen monitor or leave unremovable residue.

7. Avoid LCD monitor become exposed to direct sunlight for a long period of time, which may result in damage. When monitor displays different images, image brightness may become slightly uneven.
8. Monitor may be broken when heavy pressure or sharp object is applied to it. Please properly cover the monitor and make sure the monitor glass will not be pressed if need to carry it outdoors. Placing touch screen monitor inside carrying bag may result in monitor glass damaged by pressing, dropping or colliding with laptop and other items.

### Section 3 Safety Precautions

1. The Product may be severely damaged from overturning or falling. Please do not place on a shaky or unstable table, cupboard or trolley. Do not use the On-Lap Monitor on a moving vehicle.
2. Do not place the items on a vibrating surface, vibration may cause damage to the internal components.
3. The product is not waterproof. Do not use the Product at or near a place with water.
4. Do not insert any object into the Product' s slots or gaps.
5. Loudness warning! Avoid volume levels that may be harmful to your hearing. Please check the volume setting before you use the Audio Jack.

### Section 4 Safety Instructions

Please read this Manual carefully and observe the operation instructions and precautionary notes. Do retain this document for future reference.

### Section 5 Product Maintenance

Do not attempt to repair the Product yourself. Should any of the following conditions occur, please contact our maintenance personnel for service:

- 1) Unable to operate the Product after following the instructions in the Manual.
- 2) The Product falls and the outer casing is damaged.
- 3) Power cable or video cables is damaged.
- 4) Liquid infiltrated into the Product.

**Any normal wear and misuse, including but not limited to product failure due to normal usage, is not covered under warranty. Accident, damage, software or hardware changes, force majeure, or become in contact with liquid that result in product malfunction is not covered under warranty.**

### Section 6 LCD Pixel Statement

The On-Lap Monitor uses a high quality LCD panel. Nevertheless, there might be instances where defective pixels may occur; however, this will not affect the normal functioning of the Product.

### Section 7 Disposal of Electronic Equipment

The electronic equipment and batteries should not be disposed of with household waste but should be left at an appropriate collection point for recycling.



## Chapter 2 Installation Instructions

### Section 1 Install Stand 4


#### Step 1 Assemble Stand 4

Select the desired angle placement to assemble Stand 4. Before assembly, check if X plate is properly inserted onto slot.



#### Step 2: Place On-Lap 1502 onto Stand 4

Place On-Lap 1502 onto Stand 4. Stand 4 is positioned at the bottom center of monitor.



### Section 2 Connect the Video Cable and USB Touch Output and Power Cable

#### Step 1: Connect the Video Cables

Choose ① or ② based on the type of connection port

① Connect Micro HDMI Video Cable's Micro HDMI (-D) type connector to Micro HDMI port of On-Lap 1502. Connect the other end, HDMI-A type connector to laptop, tablet, game console, or DVD player's HDMI port.

Or ② connect VGA Video Cable's VGA connector to VGA port of On-Lap 1502. Connect the other end, D-Sub connector to D-Sub/VGA connector port on the laptop. (Need to purchase VGA Video Cable designed for On-Lap 1502 in order to use)

**\*The two On-Lap 1502 video cables look similar in appearance, match with the diagram before connecting to avoid connecting to the wrong port. If wrongly connect Micro HDMI Video Cable to VGA port, or wrongly connect VGA Video Cable to HDMI port, the monitor will not display.**

**\*\*Only when Micro HDMI Video Cable is connected will the monitor have sound. VGA Video Cable is not able to transmit audio signal**




Fig.: Connect VGA or Micro HDMI Video Cable

### Step2: Connect USB Touch Output and Power Cable

① Connect USB Touch Output and Power Cable' s Micro USB (B type) connector to On-Lap 1502' s Micro USB port. Connect the other end, USB connector to USB port of laptop. With this connection, laptop will provide power and touch signal to On-Lap 1502.

② If one USB port on laptop is unable to provide enough power, please connect the two USB connectors to two USB ports on laptop, this can provide twice the power.




Fig.: Connect USB Touch Power Cable


\*On-Lap 1502 has two Micro USB ports:

🔌 USB port can transmit touch signal and power, DCIN DC IN port can only transmit power. If USB Touch Output and Power Cable connect to DC IN port, touch function cannot be used.

### Section 3 Connect the 5V 2A Charger (Optional)

If wish to have On-Lap 1502 use independent power source, use 5V 2A Charger to provide 5V DC and not use power from laptop, please refer to diagram. Connect 5V 2A Charger to Micro USB port (DC IN) of On-Lap 1502. At this time, On-Lap 1502 will only use power from DC IN port.

**\*Do not disconnect the USB Touch Output and Power Cable from On-Lap 1502 USB port, or else touch function cannot be used.**



### Section 4 Install the VESA 100 Mount (Optional)

From diagram below, place VESA 100 mount to mount arm or wall mount, use four screws to secure the holes.





Fig.: Place the VESA 100 onto

Place On-Lap 1502 onto VESA 100 mount, secure with four screws.

**\* If need to adjust monitor position, please use two hands to hold VESA 100 mount to adjust, do not apply force onto On-Lap 1502 body. Excessive force onto On-Lap 1502 body may result in monitor glass become broken.**

Fig.: Place On-Lap 1502 onto VESA 100 mount



## Chapter 3 Power On and Off the On-Lap Monitor


### Section 1 Power On and Off the On-Lap

1. From Off state to On state: Press Power Button to activate On/Off.
2. First time use: When Micro USB to USB touch signal and power connect to USB port on computer or 5V DC Charger, On-Lap will automatically start and detect video signal to automatically display video. (Connection method can refer to Chapter 2 Section 2)

### Section 2 Monitor Display Setting

1. Set Extended Display Mode – Windows 8

Select directly from right side of screen [Devices] ->select [2<sup>nd</sup> Monitor] -> select [Extend Mode]




2. Resolution setting – Windows 7 system

- Click on
- Click on **Control Panel > Appearance and Personalization**
- Click on **Display > Connect to an external display.**

Normally Display ① is the laptop' s monitor, Display ② is the external monitor. Click on **Detect** if you are unsure.

- At **Display**, select "2.HDMI" (digital video) or "2. display device: VGA" (analog video) for **Display**
- Select "1366x768" for **Resolution**, On-Lap 1502I has IPS panel, with resolution up to 1920x1080
- Select "Landscape" or "Portrait" for **Orientation**.
- Select "Extend these displays" for **Multiple display**, and drag Display 2 to the right side of Display 1. For Duplicated mode, select "Duplicate these displays".
- Select OK and exit after saving the settings.




## Section 3 Windows 8 Touch Gesture Description

Common Touch Gesture Introduction:

- Use finger to swipe in from edge:
  - Swipe in from the right edge of the screen (Arrow 1) : Open the five charms – Search, Share, Start, Devices, and Settings
  - Swipe in from the left edge of the screen (Arrow 2) : Switch between apps
  - Swipe in from the left edge of the screen then out toward the left edge of the screen (Arrow 3): Display all apps
  - Swipe in from the top edge (Arrow 4) or bottom edge (Arrow 5): Display commands of app, like Add New, Reminder, etc.
  - With touch, drag the app from the top edge of screen (Arrow 6) to the bottom of the screen: Close app

Fig.: Finger touch illustration, arrow indicates movement direction



- Select item: Tap on the item to open. This function is similar to clicking on mouse.
- Press and hold the item for a few seconds then release: Display item information. This function is similar to right-clicking on mouse.
- Zoom in and out: Touch the item with two fingers then move fingers toward each other (pinch) or away from each other (stretch).
- Slide finger on the screen, horizontally or vertically, to move through content. This function is similar to scrolling with a mouse.

## Chapter 4 Hot Keys and OSD Instructions

### Section 1 Hot Keys and LED Light Description

\* The buttons are capacitive touch module. Please touch the buttons by the fingertip gently. Do not press the buttons with stress or continuously, which may cause them fail to response. "Increase/up" or "Decrease/down" continuously shall be done by touching the button and holding. Do not touch two buttons at the same time, due it may cause no response or fault response.

#### LED Lights Description :

It shows green light when turn on On-Lap Monitor and shows red light when shut down.

## Hot Keys Description


**Power:** Touch the Power Button can power on/off the Monitor.

**Exit/Auto Adjustment:** In the OSD panel, touch the Exit Button to exit and back to the previous page. When there is no OSD menu, touch this Button will activate automatic adjustment function (only pertains to analog VGA signal)

**Increase Volume/UP:** Touch this Button to increase the volume of speakers. If the OSD menu is launched, touch this button will move up the list. Touch and hold for automatic continuous increase.

**Menu/Select:** Touch the Menu Button to launch OSD panel.

**Decrease Volume/Down:** Touch this Button to decrease the volume of speakers. If the OSD menu is launched, touch this button will move down the list. Touch and hold for automatic continuous decrease.



## Section 2 OSD Description

### 1. Basic Button Operation

Press button to launch the OSD panel. Press or to view the functions. To adjust a certain function, press to launch it. If the selected function consists of sub-menu, press or again to view the sub-menu. When the desired function is highlighted, press to launch it. Press or to change the setting. To exit, press to exit. Repeat the preceding steps to adjust other setting.


### 2. Color Setting – Contrast

Press to launch the OSD panel. Press or to select , press to enter. Press or to select Contrast sub-menu and press to enter; press or to proceed with the contrast adjustment → adjust the display contrast from 0-100. Press to exit.



### 3. Color Setting – Brightness

Press to launch the OSD panel. Press or to select , press to enter. Press or to select Brightness sub-menu and press to enter; press or to proceed with the brightness adjustment → adjust the backlight from 0-100. Press and hold for automatic continuous decrease. Press to exit.




## 5. Color Setting – Color Temperature adjustment

Press  to launch the OSD panel. Press  or  to select , press  to enter. Press  or  to select Color temperature adjustment sub-menu and press  to enter; press  or  to adjust color saturation for R/G/B.

**Red** → increase / decrease the red saturation of the image. **Green** → increase / decrease the green saturation of the image. **Blue** → increase / decrease the blue saturation of the image.

Press  to exit.



## 6. Color Setting – Color Temperature


Press  to launch the OSD panel. Press  or  to select , press  to enter. Press  or  to select Color Temperature sub-menu, press  to enter. Press  or  to proceed with the adjustment.

**Warm color** → Revert to warm color.

**Cold color** → Revert to cold color.

**User** → Revert to user's color adjust settings.

Press  to exit.



## 7. Image Adjustment (Applicable only for VGA input signal)

Press  to launch the OSD panel. Press  or  to select , press  to enter. Press  or  to select the sub-menu, press  to enter. Press  or  to adjust

**Clock** → Adjust the horizontal scan rate. If the rate is incorrectly set, the vertical lines on screen and screen width will not be properly displayed.


**Phase** → Adjust the phase of pixel clock signal. If the position is incorrectly adjusted and when the screen displays bright image, it will be affected by horizontal interference.

**Sharpness** → Adjust the sharpness of the image.

**H Position** → Adjust the image' s horizontal position.

**V Position** → Adjust the image' s vertical position.

Press  to exit.



## 8. Menu Adjustment

Press  to launch the OSD panel. Press  or  to select , press  to enter.  
Press  or  to select sub-menu, press  to enter, press  or  to adjust.

**OST Timer** → adjust OSD time

**Language** → select language

**Reset** → restore to factory settings

**Version** → factory version

Press  to exit.

## 9. Signal Selection


Press  to launch the OSD panel. Press  or  to select , press  to enter.  
Press  or  to select sub-menu, press  to enter, press  or  to select input source, which are :

**VGA** → select analog signal as source of input

**HDMI** → select digital signal as source of input

**Auto Search** → auto search for input signal.

Press  to exit.



## Section 3 Low Power Protection Warning

If the volume setting is too high, the power requirement may be greater than the power provided by computer or external 5V DC Charger. At this time, the Low Power Protection Warning will appear. Please reduce the volume immediately. Connect the two USB connectors of Micro USB Touch Output and Power Cable to the two USB ports on computer. If the volume is not reduced in time, the Monitor will decrease the volume and brightness automatically.

Fig.: Low voltage warning shown at upper right corner on screen.



## Chapter 5 Specification


### Section 1 Plug and Play

The On-Lap Monitor conforms to VESA DDC standard and supports VESA DDC2. DDC2B is a bi-directional data channel based on I<sup>2</sup>C protocol. The host can request EDID information over the DDC2B channel. The On-Lap Monitor is able to inform the host system of its identity, and depending on the level of DDC used, communicate additional information about its display capabilities.

### Section 2 Pin Assignment

#### 1. HDMI Connector Pinout

Fig.: HDMI-A Connector (Connect to HDMI port)



Pin	Name	Pin	Name
1	TMDS Data2+	11	TMDS Clock Shield
2	TMDS Data2 Shield	12	TMDS Clock -
3	TMDS Data2 -	13	CEC
4	TMDS Data1+	14	Reserved
5	TMDS Data1 Shield	15	SCL (I <sup>2</sup> C Serial Clock for DDC)
6	TMDS Data1 -	16	SDA (I <sup>2</sup> C Serial Data Line for DDC)
7	TMDS Data0+	17	DDC/CEC Ground
8	TMDS Data0 Shield	18	+5 V Power
9	TMDS Data0 -	19	Hot Plug Detect
10	TMDS Clock+		

## 2. VGA Connector Pinout

Pin No.	Name	Pin No.	Name	Pin No.	Name
1	RED	6	RGND	11	NC
2	GREEN	7	GGND	12	SDA
3	BLUE	8	BGND	13	HSYNC
4	NC	9	+5V	14	VSYNC
5	GND	10	SGND	15	SCL




Fig.: VGA connector (connect to PC's VGA port)

## 3. USB Connector Pinout

Pin No.	Name
1	Vcc(+5V)
2	D+
3	D-
4	Ground




Fig.: USB Connector

## Section 3 Specification

	1502 I	1502 T
Panel type	15.6" TFT IPS (LED Back-light)	15.6" TFT TN (LED Back-light)
Resolution / Color Depth	1920 x 1080 /262K colors	1366 x 768 /262K colors
Pixel Pitch	0.179mm	0.252mm
Viewing Angle (Typical)	(U/D/R/L) 80°/80°/80°/80°	(U/D/R/L) 15°/35°/45°/45°
Contrast Ratio	400:1(Typical)	400:1(Typical)
Response Time	17.5 (ms) (Typical)	8 (ms) (Typical)
Brightness	220 (cd/m <sup>2</sup> )(Maximum)	180(cd/m <sup>2</sup> )(Maximum)
Horizontal Scan Range	30KHz to 83KHz(automatic)	30KHz to 83KHz(automatic)
Vertical Scan Range	56Hz to 76Hz(automatic)	56Hz to 76Hz(automatic)
Preset Resolution	1920x1080(at 60Hz)	1366x768(at 60Hz)

	1502 I	1502 T
Video Format	480p ; 576p ; 720p ; 1080p ; 480i ; 576i ; 1080i	
Touch Type	Projected capacitive touch screen; 10-point multi-touch; Input by fingers	
Operation System	Windows 7/ Windows 8	
Screen Coating	Touch screen hardness $\geq$ 7H ; Removable anti-glare film:3H	
Speakers	2x 1.0W(Max.) (Rated Impedance 8 $\Omega$ at 2KHz)	
Rating Voltage	5V  DC	
Rating Current	1.8A (Brightness100, Audio level 0)	1.2A (Brightness100, Audio level 0)

## Section 4 Trouble Shooting

### 1. Image or Audio output troubles

Problem	Solution
No response when finger touches on monitor	<ol style="list-style-type: none"> <li>1. Check if Micro USB Touch Output and Power Cable is properly connected between the computer and On-Lap 1502' s USB port.</li> <li>2. Check if Micro USB Touch Output and Power Cable is mistakenly connected to DC IN port. If so, it only power is transmitted and no touch is available.</li> </ol>
No image	<ol style="list-style-type: none"> <li>1. Check if Power On/Off Indicator shows green light. If not, it means no power connection. Please refer to user manual instruction to connect power.</li> <li>2. Check if VGA/HDMI Video Cable is connected between On-Lap' s connector port and computer' s connector port.</li> <li>3. Check if Micro HDMI Video Cable connector is accidentally connected to the VGA port on On-Lap.</li> </ol>
OSD displays " No Signal" warning	Please check if the Video Cable is correctly connected to On-Lap Monitor' s video input port and laptops' video output port.
Image disappears, or image size is too big, too small, or image is not centered.	The trouble may be caused by VGA video input. Please adjust resolution, clock, horizontal position and vertical position via OSD.
Monitor has image but no sound	<ol style="list-style-type: none"> <li>1. Press UP Button to increase audio level.</li> <li>2. Use of VGA input will not have audio signal.</li> </ol>
Monitor displays Low Power Protection Warning	Because the output current is greater than the input current, please lower the audio and brightness level. Connect the two USB connectors of Micro USB Touch Output and Power Cable to the two USB ports on the computer to increase power. Or using 5V 2A Charger to supply power.

2. The unavailability of " Duplicate these displays" or " Extend these displays" in Display setting may be limited by the graphics chip of the laptop or have the graphic chip features limited due to the power saving mode of the laptop or have the graphic chip driver updated. Please consult your laptop manufacturer or graphic chip manufacturer.



GeChic Corporation  
5F-3, No. 138, Zhongming S. Rd.,  
West Dist., Taichung, Taiwan (R.O.C.)  
Customer Service: [service@gechic.com](mailto:service@gechic.com)  
[www.gechic.com](http://www.gechic.com)