

Get started _

All you need to know to get going.





Welcome! _



Get Your Phone Ready _

Sprint is committed to developing technologies that give you the ability to get what you want when you want it, faster than ever before. This booklet introduces you to the basics of getting started with Sprint and your new Samsung M240.

Only on the Now Network.™

Insert the Battery

- Remove the battery compartment cover on the back of the phone by pressing down and sliding the cover in the direction of the arrow on the back cover.
- 2. Insert the battery into the battery compartment and gently press down until it clicks into place.
- 3. Replace the battery cover.

Charge the Battery

- 1. Plug the phone charger into an outlet.
- Plug the other end of the charger into the phone's charger or accessory jack.

Turn the Phone On

• Press and hold to turn the phone on.

Activate Your Phone _



Activate Your Phone

- If you purchased your phone at a Sprint Store, it is probably activated and ready to use.
- If you received your phone in the mail, and it is a new Sprint account or a new phone number, your phone is designed to activate automatically when you first turn it on. To confirm your activation, make a phone call.
- If you received your device in the mail and it is going to be activated on an existing number (you're swapping phones), go to <u>sprint.com/activate</u> and follow the instructions.

When you have finished, make a phone call to confirm your activation. If your phone is still not activated or you do not have access to the Internet, contact Sprint Customer Service at 1-888-211-4727 for assistance.

- Switch to Spanish Menus (optional)
 - 1. Press > Settings > Display > Language.
 - 2. Select Español and press .

Make Your First Call



Make Your First Phone Call

- 1. Enter a phone number using your keypad. (If you make a mistake while dialing, press (to erase.)
- 2. Press TOLK.
- **3.** When you're finished, press or close the phone.

Voicemail



Set Up Your Voicemail

All unanswered calls are automatically transferred to your voicemail, even if your phone is in use or turned off. You should set up your voicemail and personal greeting as soon as your phone is activated:

- Press and hold ...
- 2. Follow the system prompts to create your passcode and record your name and greeting.

Retrieve Your Voicemail

From your phone:

- To use One Touch Message Access, press and hold ...
- To use the phone's menu, press > Messages > Voicemail > Call Voicemail.

From any other phone:

- 1. Dial your wireless phone number.
- 2. When your voicemail answers, press *.
- 3. Enter your passcode.

Contacts _



Save a Phone Number

- Enter a phone number and press Options (right softkey) > Save.
- 2. Select New Entry or Existing Entry.
- For New Entry, select a type for the number (such as Mobile, Home, Work, Pager, Fax, Other), enter a name, and add other information as needed.
 For Existing Entry, select the entry, select a type, and add other information.
- 4. Press Done (left softkey).

Retrieve a Phone Number

- 1. Press CONTACTS (right softkey).
- Use your navigation key to scroll through the entries, or use your keypad to enter the first few letters of the contact entry.
- 3. To display an entry, highlight it and press . To call the entry's default phone number, highlight it and press

Messaging _



- Send a Text Message
 - Press > Messages > Send Message > Text Message.
 - -or-

Press **TEXT** (left softkey).

- Select Go To Contacts to select a contact, or New Addr (right softkey) and then press or Continue (left softkey).
- Use your keypad to enter a message or press Options (right softkey) to choose from preset messages or emoticons.
- 4. Press Send (left softkey).

Settings _



- Select Ringer Types for Voice Calls
 - Press > Settings > Sounds > RingerType > Incoming Calls and then select With Caller ID or Without Caller ID. (A list of ringer type categories will be displayed.)
- Select a category (for example, Ring Tones, Melodies, My Stuff), and then use your navigation key to scroll through the available ringers. A sample ringer will sound as you highlight each option.
- 3. Press to assign a ringer.
- Select Ringer Types for Messages
 - Press > Settings > Sounds > Ringer Type >
 Messages and then select Voicemail or Text Messages.
 (A list of ringer type categories will be displayed.)
 - Select a category (for example, Ring Tones, Melodies, My Stuff), and then use your navigation key to scroll through the available ringers. A sample ringer will sound as you highlight each option.
 - 3. Press to assign a ringer.
- Get New Ringers
 - Press > My Stuff > Ringers > Get New Ringers.
 (The browser starts and displays the Ringers menu.)
 - Use your navigation key and keypad to search through available ringers. When you find one you want, highlight it and press
 - 3. To make a purchase, highlight **Buy** and press . (Your phone automatically downloads the ringer.)

Note: Additional charges may apply, but some are free.

Manage Your Account _



Online: www.sprint.com

- · make a payment, see your bills, enroll in online billing
- · check minute usage and account balance
- see or modify the details of your Sprint service plan
- · get detailed instructions and download content

From Your Sprint Phone

- press to check minute usage and account balance
- press 🐃 🔤 to make a payment
- press to access a summary of your Sprint service plan or get answers to other questions

From Any Other Phone

- Sprint Customer Service: Dial 1-888-211-4727
- Business Customer Service: Dial 1-800-927-2199

Helpful Sprint Information _

Total Equipment Protection

The protection you need so you can be worry free

Should anything happen to your phone, you'll have a worry-free way to ensure that you get connected again soon.

· Coverage includes:

Loss, Theft, Routine maintenance, Physical or liquid damage, Mechanical or electrical problems, Failure from normal wear and tear.

· For more information:

See the Total Equipment Protection brochure available at any participating retail location or go to sprint.com/tep for more details. To enroll within 30 days of activation, call **1-800-584-3666**.

Total Equipment Protection is a service provided by Asurion Protection Services, LLC, Continental Casualty Company's (a CNA company) licensed agent for the customers of Sprint.

Sprint 411

Dial 411 for nationwide listings, movie show times, restaurant reservations, driving directions and more. Spanish-speaking operators are available. See <a href="mailto:speaking-speaki

Resources _



For Your Phone

- This Get Started Guide to get you up and running.
- User Guide View the comprehensive User Guide to the Samsung M240.
- Web Go to <u>sprint.com/support</u> to download the latest version of the *User Guide*, and to access troubleshooting and other resources.

For the Environment

Recycle your old phone safely and conveniently using the addressed recycling envelope packaged with your new phone. Visit <u>sprint.com/recycle</u> for more details.

sprint.com/begin _

Visit <u>sprint.com/begin</u> to discover all you can do with your phone and Sprint service. Explore all your options, find ways to personalize your experience, even vote for your favorite features. It's a whole new beginning.