

What can I do with my T-Mobile phone
style Social networking
Want to set up instant messaging?
Having Fun
Listening to music?
What's a SIM card?
text messaging?
How do I check my voicemail?
Sending text messages?
Photos
Surfing the web
Accessories for your phone
Enjoy

Start Guide



LG

| **GS170**

OVERVIEW

This guide provides you with everything you need to get started. For more information and support, please visit **www.t-mobile.com/support** where you can:

- Register for **my.t-mobile.com** to check your minutes, pay your bill, upgrade your phone, and change your rate plan.
- Review the User Manual and troubleshooting FAQs.
- View the latest troubleshooting solutions in the Support Forums or ask a question of your own.

You can also access Help information on your phone by selecting **Menu > Help**.

TABLE OF CONTENTS

Service Activation.....	1
Introducing Your Phone.....	2
SIM Card	3
Battery	4
Power	5
Call Functions	5
Voicemail.....	6
Contacts	7
Text Messaging	8
Camera	10
Bluetooth®.....	12
Web Browsing.....	13
Accessories for Your Phone.....	15
Emergency Dialing	16
Caring for Your Phone	17
Tips for Safety	18
Additional Information.....	20





SERVICE ACTIVATION

If you are a new T-Mobile customer and your service has not been activated, simply call Customer Care at **1-800-937-8997** from your landline phone and a T-Mobile Activations representative will assist you.

You will need the following information when activating service:

- Service Agreement and agent code on your Agreement
- Your name, home address, home phone, and billing address

NOTE: For business and government accounts, please provide the name of your company or government agency, address, and tax ID.

- Your Social Security number, current driver's license number, and date of birth for credit check purposes
- Your choice of T-Mobile rate plan and services (see www.t-mobile.com for latest plan information)
- SIM serial number and IMEI number (located on the box bar code label)

By activating service, you acknowledge that you have read, understand, and agree to be bound by each of T-Mobile's Terms and Conditions and your Service Agreement.

INTRODUCING YOUR PHONE

 **LG** | GS170



- Left Soft key
- Volume key
- Messaging key
- Send key
- Clear key
- Navigation key w/Center Select
- Right Soft key
- Charger Port
- Camera key
- End key

SIM CARD

Your Subscriber Identity Module (SIM) card identifies you to the wireless network. Your phone will not work without the SIM card.

To insert the SIM card and battery:

1. Detach your SIM card from its packaging.



2. Press down on the battery cover and slide it away. Remove the battery.



3. Slide the SIM card into the SIM card slot as shown.



4. Align the gold contacts on the battery with the contacts in the battery compartment. Push the battery into place and replace the battery cover.



BATTERY

Lift the charger port cover on the right side of your phone. Insert the small end of charger into the charging port on your phone. Plug the other end of the charger into a wall outlet.



POWER

To turn on the phone, open the flip and press and hold the red **End** key.

To turn it off, press and hold the red **End** key again.

CALL FUNCTIONS

Make a call

1. From the main screen, enter the phone number.
2. Press the green **Send** key.

Answer and end calls

To answer a call, open the flip or press the **Send** key if the flip is already open.

To end the call, press the red **End** key or close the flip.

Adjust call volume

While on an active call, press the **Volume** key up or down to adjust the call volume.


Adjust ring volume

From the main screen, press the **Volume** key up or down to adjust ring volume.

VOICEMAIL

To call and set up voicemail:

1. From the main screen, press and hold **1** to call voicemail.



2. Follow the tutorial to set up your voicemail account.


To reset the voicemail password to the last four digits of your phone number:

1. From the main screen, enter **#793#**.
2. Press the green **Send** key.

CONTACTS

Add new contact

1. From the main screen, enter the phone number.
2. Select **Options**.
3. Select **Save number**.
4. Select **New contact**.
5. Enter the first name and last name.
6. Select **Done**.



Call contact from the contact list

1. From the main screen, press the **Navigation** key down.
2. Scroll to the contact.
3. Press the green **Send** key to call.

TEXT MESSAGING

Your phone supports the following text input modes:

- **T9® Predictive Mode**

T9 mode predicts as you type. To enter **run**, press **7**, **8**, and **6**. To switch between **T9** and **ABC mode**, press and hold the **# (Pound)** key.

- **ABC Mode**

With this mode, you press the key until the desired letter appears. For example, to enter **run**, press **7** three times, **8** twice, and **6** twice. To switch between **T9** and **ABC mode**, press and hold the **# (Pound)** key.

- **Numbers Mode**

This mode allows you to enter numbers. To access Numbers mode, while in the text entry screen, select **Options > Input method > 123 mode** or quickly press the **# (Pound)** key until you see 123 in the top right corner.

- **Symbols Mode**

This mode allows you to insert symbols. To insert symbols, while in the text entry screen, select **Options > Insert Symbol**.

Read a message

Your phone notifies you when it receives a new message. Select **View** or

1. From the main screen, select **Menu**.
2. Select **Messaging**.
3. Scroll to and select **Inbox**.
4. Scroll to and select the message to view.

Send a message

1. From the main screen, select **Menu**.
2. Select **Messaging**.
3. Select **Create Message**.
4. Select **Message**.
5. At the **To** field, enter the phone number or select **Add** to select a contact in the contact list or call logs.
6. Enter your message.
7. Select **Send**.



CAMERA

Take picture

Pictures are saved to **Menu > Media > Pictures**.

1. Press the **Camera** key on the phone.
2. Frame your subject.
3. Press the **Camera** key again to capture the picture.



Send picture

1. Take a picture.
2. Press the **Navigation** key left to the **Send** icon.
3. Press the **Center Select** key.
4. Select **Message**.
5. At the **To** field, enter the phone number or select **Add** to select a contact in the contact list or call logs.
6. Scroll down to the **Text** field and enter your message.
7. Select **Send**.



BLUETOOTH®


Your phone comes with Bluetooth technology, a wireless technology that enables a data connection between your phone and a Bluetooth wireless headset and other Bluetooth devices (sold separately).

Prepare Bluetooth headset

To pair your phone with a Bluetooth headset, make sure that your headset is fully charged and that you set the headset into pairing mode. See your Bluetooth headset's manual for more information.

Turn on Bluetooth and pair with headset

1. From the main screen, select **Menu**.
2. Scroll to and select **Settings**.
3. Scroll to and select **Connectivity**.
4. Select **Bluetooth**.
5. Select **Turn On**.
6. Scroll to and select **Search New Device**.
7. Select the headset.
8. Enter the PIN or passcode if requested.
9. Select **OK**.



WEB BROWSING

Experience the mobile Web like never before with T-Mobile's web2goSM experience. Features include a phone browser optimized for the Web, a customizable start page for easy, one-click access to information, a powerful built-in Web search engine, and the ability to manage your account right from your phone.

For more information about these services visit www.t-mobile.com/shop/addons.

Visit a Web site

1. From the main screen, select **Menu**.
2. Scroll to and select **web2go**.
3. Scroll to and select **Enter URL**.
4. Enter the desired Web address.
5. Select **Open**.

Bookmark a favorite

1. In the Web browser, go to the Web address that you want to bookmark.
2. Select **Options**.
3. Scroll to and select **Bookmarks**.
4. Select **Add to Bookmark**.
5. Enter a new name for the bookmark if desired.
6. Select **Done**.
7. Select **Add**.

Full access to Web requires the purchase of a qualifying data plan. Separate additional charges may apply for downloads; actual content available for download may vary.

ACCESSORIES FOR YOUR PHONE

Whether you are looking for a charger, a fashionable carrying case, a Bluetooth® headset or just want to browse for fun extras for your phone, T-Mobile is the place to shop for accessories. Here are a few examples...



Bluetooth Headset



Car Charger

To purchase accessories for your phone, visit T-Mobile.com, call 1.800.204.2449 or visit your nearest T-Mobile store.

Accessory selection subject to change and may vary by location.

EMERGENCY DIALING

While all phones are equipped with 911 emergency calling, this phone may or may not permit its location to be approximated during a 911 call.*

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 911 calling system that are required to be installed by the local 911 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped or refused. The phone's approximate location is transmitted to the local 911 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

CARING FOR YOUR PHONE

MAKING IT LAST

Your phone is a complex electronic device; think of it as a mini-computer. Here are some hints that should help you extend the life of your new phone.

Store your phone in a protective case. The touch screen of your phone is delicate and should be protected from scratches.

Phones aren't cheap, so keep yours in a safe place—away from children who may find it fun to see if the phone sinks or floats, and away from dogs that find plastic-coated products to be irresistible chew toys.

Water will damage your phone and accessories—even a small amount such as water droplets from a soda in your car cup-holder, melting snowflakes, tears of joy, squirt-gun crossfire or steam from hot water in the kitchen or bathroom.

Use only batteries and accessories from the original manufacturer of your phone. Non-approved accessories can cause damage to you or your phone and shorten the phone's life. Hint: If it's being sold out of someone's car trunk, walk away.

If your charger or any other accessory is damaged, replace it or take it to a qualified service dealer. Do not attempt to operate your phone charger if it has received a sharp blow, been dropped, thrown from a speeding motorcycle or is otherwise damaged; doing so may damage your phone.

TIPS FOR SAFETY

Check with your doctor if you have a pacemaker or hearing aid in order to ensure that cell phone usage is safe with your phone. If you have questions about the interaction of cellular radio frequency and any other electronic equipment, ask the manufacturer of the equipment if cell phone radio frequencies will disrupt the equipment's performance.

When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner. Here are a few tips:

- Assess road conditions before answering. Your safety is more important than any call.

- Prepare your hands-free headset, if you have one, or turn on your speakerphone option before you start moving.
- Keep your phone close. If it rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.
- Program frequently used numbers into your speed dial for easy one-touch dialing.
- Remember that laws prohibiting or restricting the use of a mobile phone while driving may apply in your area.

ADDITIONAL INFORMATION

Use of some features or services may incur separate, additional charges and/or require a qualifying data plan.

Messaging/Data: You will be charged for all data sent by or to you through the network, regardless of whether received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications.

Downloads: Additional charges apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited; may be stored solely for use with your phone. T-Mobile is not responsible for any download lost due to your error; T-Mobile is not responsible for any third party content or Web site you may be able to access using your phone. See brochures and **Terms and Conditions (including arbitration provision)** at T-Mobile.com, for additional information. The Bluetooth® word mark and logo are owned by the Bluetooth SIG, Inc. and are used by T-Mobile under license. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. web2go is a service mark of T-Mobile USA, Inc. © 2010 T-Mobile USA, Inc.

Get CallerTunes Now!

Choose from the hottest songs, movie lines, and sound effects – over 50,000 ways to please your callers.

Sign up for CallerTunes with the first month of service FREE and a low monthly charge for the service thereafter. You'll also get a Bonus CallerTune at no additional charge! Separate charges apply for each additional CallerTune.

Subscription options:

- Text **CTUNES6** to **7368**
- Select CallerTunes from the Downloads section of web2goSM on your T-Mobile phone
- Dial ***TUNE** (*8863) from your T-Mobile phone

Personalize CallerTunes

Once active, access your CallerTunes from the Downloads section of your phone's browser or go to My.T-Mobile.com to personalize your CallerTunes settings and shop for CallerTunes.

Limited-time offer; subject to change. Taxes and fees additional. Free month applies to monthly service fee only; each CallerTune you download is an additional charge. After first thirty days, you will be charged a set amount per month for the CallerTunes service, plus a separate charge per CallerTune purchased. CallerTunes will expire 12 months from the date of purchase. Compatible device and qualifying voice/data plan required; not available for Prepaid. Content and Applications are licensed to you for personal, lawful, non-commercial use on your device only; nontransferable. Additional terms apply. See your plan terms and **T-Mobile's Terms & Conditions (including arbitration provision)** at www.t-mobile.com for additional information, restrictions and details.

CallerTunes[♪]

T-Mobile

Let 'em rock before you talk!


YOU decide what your friends hear when they call you. Sign up today – your first month of service is FREE, and a low monthly charge applies thereafter. Text **CTUNES6** to **7368** to start now. Look inside to learn more.



Lil' Wayne



Lady Gaga



Trey Songz