


Display Description



- A** VOIce client registered
- B** New unread messages
- C** Handset in use
- D** Headsets in use
- E** Speakerphone in use
- F** Incoming call (Lower Arrow) or outgoing call (Upper Arrow)
- G** Inbound/Outbound Number
- H** Incoming (IN) or Outgoing (OUT) call present in the list
- I** Time
- J** Weekday
- K** Date

How to...

Accept an incoming call

- Lift the handset (12) and speak in the microphone or alternatively use the headset when enabled.
- Press the speakerphone button (9) and speak through the external microphone of the telephone.

Refuse a call

- Press the EXIT button (4).

Place a call on hold / recover a queued call

- Press the HOLD button (11).

Transfer a call

- Place the active call on hold by pressing the HOLD button (11), dial the new destination number (internal or external) and press DIAL (8). When the call starts, press TRANSFER (13) to forward the call to the new destination number.

End a call

- If you are using the handset (12) you can end a call by simply replacing the handset.
- Press the speakerphone button (9) in case the speakerphone is active.

Displaying the list of calls

- Press the CALL LIST button (14) to list all incoming/outgoing/missed calls from the VOIce client. Use up/down arrows to browse the list (3).

Enable/Disable the speakerphone

- Pick-up an incoming call by pressing the speakerphone button (9) and press again to end the call.
- Alternatively, you can answer a call using the handset (12) and then transfer the audio to the speakerphone by pressing the speakerphone button (9).

Enable/Disable the analogue headsets connected to the V-6014 phone

- Press the HEADSET button (16) to enable the headsets. Press again to disable it and transfer the audio to the handset.



List of components in the package

- USB Telephone V-6014
- Telephone handset with cable (to be connected to the telephone)
- USB cable
- Installation manual

How to install the V-6014

The V-6014 USB phone must be connected directly to the USB port of the computer using the cable provided. The same port is used to power the equipment.


- Logout and shut-down the VOIce Client software
- Plug the V-6014 USB phone to the PC using the cable provided
- Wait for Windows to install and configure the new USB device

Note: following this step you will be required to select Windows default audio device ('Control Panel' → 'Sounds and Audio Devices' → 'Audio').

1. Restart VOIce Client software. The software will automatically detect the new USB device and configure the V-6014 as default audio device.

The phone will only be fully operational when connected to a PC with VOIce Client running.

Telephone Description



- | | |
|--|--|
| 1 Main Display | 10 Alphanumeric Keypad |
| 2 Function Keys | 11 HOLD: Place a call on hold/Restart a conversation with call on-hold |
| 3 Menu Option Keys | 12 Handset |
| 4 EXIT: Exit/Refuse incoming call | 13 TRANSFER: Trasfer an active call |
| 5 MUTE: Disable ringtone of an active call/disable microphone | 14 CALL LIST: Display list of inbound/outbound/misssed calls |
| 6 REC: Start/Stop call recording during an active call | 15 VOC.BOX: Voicemail and call recording management |
| 7 VOL: Pressing this key will enable the Menu Option Keys (3) to increase/decrease the volume of an active call or the ringtone. | 16 HEADSET: Enable/Disable headsets |
| 8 DIAL: Starts a call to the number entered/Calls the last number dialled. | 17 PHONE BOOK: Display contact list |
| 9 Enable/Disable speaker during an active call | 18 MENU: Access to main settings menu |

To find out more about the V-6014 or to access our technical support, please go to www.prontopbx.com or www.voispeedltd.com

