

## Scavenger Transmitter Module STM 330 / STM 331 / STM 330C

January 21, 2013



**Observe precautions! Electrostatic sensitive devices!**

Patent protected:

WO98/36395, DE 100 25 561, DE 101 50 128,  
WO 2004/051591, DE 103 01 678 A1, DE 10309334,  
WO 04/109236, WO 05/096482, WO 02/095707,  
US 6,747,573, US 7,019,241

## REVISION HISTORY

The following major modifications and improvements have been made to the first version of this document:

No	Major Changes
0.55	Initial version
0.90	New drawings added; Agency certifications added; Charging circuitry modified; editorial changes
0.91	Drawings updated
0.95	Parameters of A/D converter corrected and specified in more detail; Charging circuitry modified.
0.99	Pin for connection of backup battery changed; ICHAR modified in 2.4 and 2.5; section 3.5 inserted; drawings updated
1.00	Block diagram and pin description modified.
1.01	Table in 2.11 modified
1.02	Remark added in 3.5; additional remarks in 2.11; label information modified in chapter 5; Shelf life added in 1.4; supply voltage for programming added in 2.2; Conducted output power replaced by radiated output power in 1.2; programming interface added in 2.3.2; other editorial changes
1.03	Support for HSM 100 humidity sensor module added
1.04	Specification of shelf life improved; figure added in 3.3.1; Chapter Related Documents added.
1.05	STM 331 with helix antenna added (naming + helix antenna description), hints to update module via STMSSEN

**Published by EnOcean GmbH, Kolpingring 18a, 82041 Oberhaching, Germany  
 www.enocean.com, info@enocean.com, phone ++49 (89) 6734 6890**

© EnOcean GmbH  
 All Rights Reserved

### Important!

This information describes the type of component and shall not be considered as assured characteristics. No responsibility is assumed for possible omissions or inaccuracies. Circuitry and specifications are subject to change without notice. For the latest product specifications, refer to the EnOcean website: <http://www.enocean.com>.

As far as patents or other rights of third parties are concerned, liability is only assumed for modules, not for the described applications, processes and circuits.

EnOcean does not assume responsibility for use of modules described and limits its liability to the replacement of modules determined to be defective due to workmanship. Devices or systems containing RF components must meet the essential requirements of the local legal authorities.

The modules must not be used in any relation with equipment that supports, directly or indirectly, human health or life or with applications that can result in danger for people, animals or real value.

Components of the modules are considered and should be disposed of as hazardous waste. Local government regulations are to be observed.

Packing: Please use the recycling operators known to you.

**TABLE OF CONTENT**

1 RELATED DOCUMENTS .....4

2 GENERAL DESCRIPTION .....5

    2.1 Basic functionality .....5

    2.2 Technical data .....6

    2.3 Physical dimensions .....6

    2.4 Environmental conditions .....8

    2.5 Ordering Information .....8

3 FUNCTIONAL DESCRIPTION .....9

    3.1 Simplified firmware flow chart and block diagram .....9

    3.2 Pin out .....10

    3.3 Pin description and operational characteristics.....11

        3.3.1 GPIO supply voltage .....12

        3.3.2 Analog and digital inputs .....13

        3.3.3 Temperature sensor .....13

        3.3.4 Programming Interface.....14

    3.4 Absolute maximum ratings (non operating) .....15

    3.5 Maximum ratings (operating) .....15

    3.6 Power management and voltage regulators .....15

    3.7 Configuration .....16

        3.7.1 Configuration via pins .....16

        3.7.2 Configuration via serial interface .....17

    3.8 Radio telegram.....19

        3.8.1 Normal operation.....19

        3.8.2 Teach-in telegram .....19

    3.9 Transmit timing.....19

    3.10 Charging circuitry .....20

    3.11 Energy consumption .....20

4 APPLICATIONS INFORMATION.....22

    4.1 Using the WAKE pins.....22

    4.2 Temperature sensor.....23

    4.3 Set point control and occupancy button.....23

    4.4 Combination with humidity sensor module HSM 100 .....23

    4.5 Antenna layout.....24

        4.5.1 Whip antenna (STM 330 / STM 330C) .....24

        4.5.2 Helical antenna (STM 331).....25

    4.6 Mounting STM 330 into a housing .....26

    4.7 Transmission range .....27

5 AGENCY CERTIFICATIONS .....28

    5.1 CE Approval .....28

    5.2 FCC (United States) certification .....29

    5.3 IC (Industry Canada) certification .....31

6 Label Information .....31

## 1 RELATED DOCUMENTS

This document describes operation of STM 330 (whip antenna), STM 331 (helix antenna), 330C (whip antenna) modules with their built-in firmware.

If you want to write own firmware running on the integrated micro controller or need more detailed information on the Dolphin core please also refer to Dolphin Core Description and Dolphin API Documentation at: <http://www.enocean.com/en/knowledge-base/>

If you want to connect other generic sensors to STM 33x (former STM 310 applications), you can download STEMSEN Software from following link:  
<http://www.enocean.com/en/download/>

Module can be programmed via

- EOP 300 programmer & EVA 330 developer board or
- EOP 350 programmer

For mechanical integration please refer to our 3D drawings found at  
[http://www.enocean.com/en/enocean\\_modules/stm-330/](http://www.enocean.com/en/enocean_modules/stm-330/)

If you want to add a humidity sensor please refer to the HSM 100 data sheet at  
[http://www.enocean.com/en/enocean\\_modules/stm-330/](http://www.enocean.com/en/enocean_modules/stm-330/)

In addition we recommend following our [application notes](#), in particular

- AN102: Antenna Basics – Basic Antenna Design Considerations for EnOcean based Products

## 2 GENERAL DESCRIPTION

### 2.1 Basic functionality

The extremely power saving RF transmitter module STM 33x of EnOcean is optimized for realization of wireless and maintenance free temperature sensors, or room operating panels including set point dial and occupancy button. It requires only a minimum number of external components and provides an integrated and calibrated temperature sensor.

Power supply is provided by a small solar cell, an external energy harvester, or an external 3 V backup battery. An energy storage is installed in order to bridge periods with no supply from the energy harvester. The module provides a user configurable cyclic wake up.

After wake up, the internal microcontroller reads the status of the temperature sensor and optional set point dial. A radio telegram will be transmitted in case of a significant change of measured temperature or set point values or if the external occupancy button is pressed. In case of no relevant input change, a redundant retransmission signal is sent after a user configurable number of wake-ups to announce all current values.

In addition to the cyclic wake-up, a wake up can be triggered externally using the input for the occupancy button or the internal LRN button.

The firmware can be configured to use different EEPs according to the availability set point dial and occupancy button.


#### Features with built-in firmware

- Pre-installed solar cell
- On-board energy storage and charging circuit
- On-board LRN button
- On-board TX indicator LED
- Calibrated internal temperature sensor
- Input for external occupancy button and set point dial
- Configurable wake-up and transmission cycle
- Wake-up via Wake pins or LRN button
- Support for humidity sensor module HSM 100

#### Features accessible via API

Using the Dolphin API library it is possible to write custom firmware for the module. The API provides:

- Integrated 16 MHz 8051 CPU with 32 kB FLASH and 2 kB SRAM
- Integrated temperature sensor
- Various power down and sleep modes down to typ. 0.2  $\mu$ A current consumption
- Up to 13 configurable I/Os
- 10 bit ADC, 8 bit DAC



## 2.2 Technical data

<b>Antenna</b>	whip antenna (STM 330 / STM 330C) helix antenna (STM 331)
<b>Frequency</b>	315.0 MHz (STM 330C) / 868.3 MHz (STM 330 / STM 331)
<b>Radio Standard</b>	EnOcean 868 MHz/315 MHz
<b>Data rate/Modulation type</b>	125 kbps/ASK
<b>Radiated Output Power</b>	STM 330: +8 dBm <sup>1</sup> (EIRP) ± 2.5 dB <sup>2</sup> STM 331: +5 dBm <sup>1</sup> (EIRP) ± 2.5 dB <sup>2</sup> STM 330C: +92 dBμV/m <sup>1</sup> ± 2 dB <sup>2</sup>
<b>Power Supply @ VDD</b>	Pre-installed solar cell Illumination 50-100000 lux 2.1 V–5.0 V, 2.6 V needed for start-up
<b>Initial operation time in darkness @ 25°C</b>	typ. 4 days, min. 60 hours if energy storage fully charged, wake-up every 100 s, transmission of telegram every 1000 s on average <sup>3</sup>
<b>Operation start up time with empty energy store</b>	typ. 2.5 min @ 400 lux / 25 °C incandescent or fluorescent light
<b>Input Channels</b>	Internal: temperature sensor, LRN button External: occupancy button, set point dial, HSM 100
<b>Temperature sensor</b>	Measurement range 0-40 °C, resolution 0.16 K Accuracy typ. ±0.5 K between 17 °C and 27 °C typ. ±1 K between 0 °C and 40 °C
<b>EnOcean Equipment Profiles</b>	configurable EEPs: A5-02-05 (default), A5-10-05, A5-10-03 and with HSM 100: A5-04-01, A5-10-10, A5-10-12
<b>Connector</b>	20 pins, grid 1.27 mm, □ 0.4 mm
<b>Radio Regulations</b>	R&TTE EN 300 220 (STM 330) FCC CFR-47 Part 15 (STM 330C)

## 2.3 Physical dimensions


<b>PCB dimensions</b>	43±0.2 x 16±0.3 x 1±0.1 mm
<b>Module height</b>	8 mm
<b>Weight</b>	4.5 g (STM 33x), 4.9 g (STM 330C)

<sup>1</sup> Measured in test laboratory, measurement uncertainty 2.7 dB

<sup>2</sup> Tolerance of measurement in production at 50 Ω

<sup>3</sup> Full performance of the PAS614L energy storage is achieved after several days of operation (up to two weeks) at good illumination level. Performance degrades over life time, especially if energy storage is exposed to higher temperatures. Each 10 K drop in temperature doubles the expected life span.

STM 330 / STM 331 / STM 330C



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

EnOcean GmbH	A46-C01
Hersteller	S:1
Leiterplatte STMHW310C	
PC board STMHW310C	

## 2.4 Environmental conditions

<b>Operating temperature</b>	-20 °C ... +60 °C
<b>Storage temperature</b>	-20 °C ... +60 °C, recommended <sup>4</sup> : +10 °C...+30 °C, <60%r.h.
<b>Shelf life (in absolute darkness)</b>	36 months after delivery <sup>5</sup>
<b>Humidity</b>	0% ... 93% r.h., non-condensing



The module shall not be placed on conductive materials, to prevent discharge of the internal energy storages<sup>5</sup>. Even materials such as conductive foam (ESD protection) may have negative impact.

## 2.5 Ordering Information

Type	Ordering Code	Frequency
<b>STM 330</b>	<b>S3001-D330</b>	<b>868.3 MHz</b>
<b>STM 331</b>	<b>S3001-D331</b>	<b>868.3 MHz</b>
<b>STM 330C</b>	<b>S3031-D330</b>	<b>315.0 MHz</b>


<sup>4</sup> Recommended for maximum life of energy storage capacitor


<sup>5</sup> Deep discharge of the PAS614L energy storage leads to degradation of performance. Therefore products have to be taken into operation after 36 months. At least the PAS614L needs to be recharged to 2.1 V.



### 3 FUNCTIONAL DESCRIPTION


#### 3.1 Simplified firmware flow chart and block diagram





### 3.2 Pin out

UVDDext	1	2	WAKE0
WAKE1	3	4	VGC
GND	5	6	VCHAR
PROG_EN	7	8	SWPWR
ADIO0	9	10	ADIO3
ADIO1	11	12	ADIO4
ADIO2	13	14	ADIO6
RESET	15	16	ADIO7
RSDADIO3	17	18	SCLKDIO1
WSDADIO2	19	20	SCSEDIO0



The figure above shows the pin out of the STM 33x hardware. The pins are named according to the naming of the EO3000I chip to simplify usage of the DOLPHIN API. The table in section 3.3 shows the translation of hardware pins to a naming that fits the functionality of the built-in firmware.

### 3.3 Pin description and operational characteristics

STM 33x Hardware Symbol	STM 33x Firmware Symbol	Function	Characteristics
GND	GND	Ground connection	
VDD	VDD	Supply voltage	2.1 V – 5.0 V; Start-up voltage: 2.6 V Maximum ripple: see 3.6 Not available at pin header.
		Supply for programming I/F	Recommended supply voltage for programming 3V
VCHAR	VCHAR	Charging input	Input for an external energy harvester or a battery. See 3.10.
		Supply for programming I/F if VDD cannot be used. <sup>6</sup>	Recommended supply voltage for programming 3.3V – 3.6 V
VGC	VGC	Voltage Gold Cap	Connection of additional external energy storage possible. See 3.10.
SWPWR (= switched DVDD of EO3000I)	SWPWR	DVDD supply voltage regulator output switched via transistor controlled by EO3000I ADIO5 pin.	1.8 V. Output current: max. 5 mA. Supply for external circuitry, available while not in deep sleep mode. SWPWR is switched on 0.25 ms before sampling of inputs and is switched off afterwards.
UVDDext (=UVDD of EO3000I with 1.8MΩ in series)	UVDDext	Ultra low power supply voltage regulator output	Not for supply of external circuitry! For use with WAKE pins only, see section 4.1. Limited to max. 1 μA output current by internal 1.8 MΩ resistor!
IOVDD (not available at pin connector)	IOVDD	GPIO supply voltage	Internal connection to EO3000I DVDD (typ. 1.8 V) See 3.3.1
RESET	RESET	Reset input Programming I/F	Active high reset (1.8 V) Fixed internal 10 kΩ pull-down.
PROG_EN	PROG_EN	Programming I/F	HIGH: programming mode active LOW: operating mode Digital input, fixed internal 10 kΩ pull-down.
ADIO0	SET	Analog input	For connection of an external set point dial. See 4.3
ADIO1		Not used	Internal pull-up; do not connect
ADIO2		Not used	Internal pull-up; do not connect

<sup>6</sup> E.g. if module shall be programmed or configured via pin connector.

If a bed of nails fixture for programming is available VDD should be used instead of VCHAR.

ADIO3	HSM	Input for HSM 100	Internal pull-up; leave open or connect HSM 100
ADIO4		Not used	Internal pull-up; do not connect
ADIO6		Not used	Internal pull-up; do not connect
ADIO7		Programming I/F	Leave open
SCSEDIO0	CW_1	Encoding input for wake-up cycle	Configuration interface. Leave open or connect to GND. See 3.7.1. Internal pull-up
		Programming I/F	
SCLKDIO1	CW_0	Encoding input for wake-up cycle	Configuration interface. Leave open or connect to GND. See 3.7.1. Internal pull-up
		Programming I/F	
WSDADIO2	CP_1	Encoding input for retransmission	Configuration interface. Leave open or connect to GND. See 3.7.1. Internal pull-up
		Programming I/F	
RSDADIO3	CP_0	Encoding input for retransmission	Configuration interface. Leave open or connect to GND. See 3.7.1. Internal pull-up
		Programming I/F	
WAKE0	OCC	Wake input	Input for external occupancy button. Change of logic state leads to wake-up and transmission of a telegram if correct EEPROM selected. See 3.7.2. Must be connected to UVDDext or GND! At time of delivery WAKE0 is connected to UVDDext via a jumper at the connector. See also 4.1.
WAKE1	LRN	LRN input	Change of logic state to LOW leads to wake-up and transmission of teach-in telegram. Internal pull-up to UVDD. See also 3.8.2 and 4.1.

### 3.3.1 GPIO supply voltage


The IOVDD pin of EO3000I is internally connected to DVDD. For digital communication with other circuitry therefore a voltage of 1.8 V has to be used. While the module is in deep sleep mode the microcontroller with all its peripherals is switched off and DVDD, IOVDD, and SWPWR are not supplied.



If DVDD=0 V and IOVDD is not supplied (e.g. while in sleep mode), do not apply voltage to ADIO0 to ADIO7 and the pins of the serial interface (SCSEDIO0, SCLKDIO1, WSDADIO2, RSDADIO3). This may lead to unpredictable malfunction of the device.



For I/O pins configured as analog pins the IOVDD voltage level is not relevant! See also 3.3.2.



### 3.3.2 Analog and digital inputs

Parameter	Conditions / Notes	Min	Typ	Max	Units
<b>Analog Input Mode</b>					
Measurement range	Single ended	0.07		RVDD-0.07	V
	Internal reference RVDD/2				
	Interpreted as <sup>7</sup>	0x00		0xFF	
Input coupling			DC		
Input impedance	Single ended against GND @ 1 kHz	10			MΩ
Input capacitance	Single ended against GND @ 1 kHz			10	pF

Parameter	Conditions / Notes	Min	Typ	Max	Units
<b>Digital Input Mode</b>					
Input HIGH voltage		2/3 IOVDD			V
Input LOW voltage				1/3 IOVDD	V
Pull up resistor	@IOVDD=1.7 ... 1.9 V	90	132	200	kΩ

### 3.3.3 Temperature sensor


Parameter	Conditions / Notes	Min	Typ	Max	Units
Measurement range		0		40	°C
Accuracy	17 - 27 °C		0.5		K
	0 - 40		1		K

<sup>7</sup> For measurement of set point with external set point dial

### 3.3.4 Programming Interface

The positions of the pads needed for programming are shown in the layout below. Data are available from EnOcean as Gerber files (STM3XY(C)\_05.GTL and STM3XY(C)\_05.GK0).

Number	Symbol
1	VDD
2	GND
3	PROG_EN
4	RESET
5	SCSEDIO0
6	SCLKDIO1
7	WSDADIO2
8	RSDADIO3
9	ADIO7
10	ADIO6 Only if in addition to programming I/F a serial interface is needed



Top layer

If VDD is not accessible, e.g. because the module shall be programmed via the pin connector, please use VCHAR instead of VDD (see 3.3).

### 3.4 Absolute maximum ratings (non operating)

Symbol	Parameter	Min	Max	Units
VDD	Supply voltage at VDD	-0.5	5.5	V
VGC	Voltage gold cap	1.5	3.3	V
VCHAR	Supply voltage from external energy harvester	0	6	V
ICHAR	Supply current from external energy harvester		45	mA
GND	Ground connection	0	0	V
VINA	Voltage at every analog input pin	-0.5	2	V
VIND	Voltage at RESET, WAKE0/1, and every digital input	-0.5	3.6	V

### 3.5 Maximum ratings (operating)

Symbol	Parameter	Min	Max	Units
VDD	Supply voltage at VDD and VDDLIM	2.1	5.0	V
VGC	Voltage gold cap	1.5	3.3	V
VCHAR	Supply voltage from external energy harvester	0	6	V
ICHAR	Supply current from external energy harvester VCHAR < 4 V 4 V < VCHAR < 6 V		Limited internally 45	mA
GND	Ground connection	0	0	V
VINA	Voltage at every analog input pin	0	2.0	V
VIND	Voltage at RESET, WAKE0/1, and every digital input	0	3.6	V

### 3.6 Power management and voltage regulators

Symbol	Parameter	Conditions / Notes	Min	Typ	Max	Units
<b>Voltage Regulators</b>						
VDDR	Ripple on VDD, where Min(VDD) > VON				50	mV <sub>pp</sub>
UVDD	Ultra Low Power supply			1.8		V
RVDD	RF supply	Internal signal only	1.7	1.8	1.9	V
DVDD	Digital supply	Internal signal only	1.7	1.8	1.9	V
<b>Threshold Detector</b>						
VON	Turn on threshold		2.3	2.45	2.6	V
VOFF	Turn off threshold	Automatic shutdown if VDD drops below VOFF	1.85	1.9	2.1	V

#### Threshold detector

STM 330 provides an internal ultra low power ON/OFF threshold detector. If  $VDD > VON$ , it turns on the ultra low power regulator (UVDD), the watchdog timer and the WAKE# pins circuitry. If  $VDD \leq VOFF$  it initiates the automatic shut down of STM 330. For details of this mechanism please refer to the Dolphin Core Description documentation.

## 3.7 Configuration

### 3.7.1 Configuration via pins

The encoding input pins have to be left open or connected to GND in correspondence with the following connection schemes. These settings are checked at every wake-up.

#### Wake-up cycle time

CW_0	CW_1	Wake-up cycle time
NC	GND	1 s $\pm$ 20%
GND	NC	10 s $\pm$ 20%
NC	NC	100 s $\pm$ 20%
GND	GND	No cyclic wake-up

#### Redundant retransmission

Via CP\_0 and CP\_1 an internal counter is set which is decreased at every wake-up signal. Once the counter reaches zero the redundant retransmission signal is sent.

CP_0	CP_1	Number of wake-ups that trigger a redundant retransmission
GND	NC	Every timer wake-up signal
NC	NC	Every 7 <sup>th</sup> - 14 <sup>th</sup> timer wake-up signal, affected at random
NC	GND	Every 70 <sup>th</sup> - 140 <sup>th</sup> timer wake-up signal, affected at random
GND	GND	No redundant retransmission



A radio telegram is always transmitted after wake-up via WAKE pins! After transmission the counter is reset to a random value within the specified interval.



According to FCC 15.231a) a redundant retransmission at every timer wake-up to determine the system integrity is only allowed in safety and security applications! In this case the total transmission time must not exceed two seconds per hour, which means that a combination with a 1 s wake-up cycle time is not allowed!

If applied in other (non-safety, non-security) applications a minimum of 10 s between periodic transmissions is required. In addition the device has to comply with the lower field strength limits of 15.231e). The limited modular approval of STM 330C is not valid in this case.




### 3.7.2 Configuration via serial interface

Via the programming interface the configuration area can be modified. This provides a lot more configuration options. Values set via serial interface override hardware settings! These settings are read after RESET or power-on reset only and not at every wake-up of the module!


Parameter	Configuration via pins	Configuration via serial interface
Wake up cycle	See section 3.7.1	Value can be set from 1 s to 65534 s
Redundant Retransmission cycle	See section 3.7.1	Min...Max values for random interval If Min=Max -> random switched off
Threshold values for inputs (transmission of telegram if threshold value exceeded)	No	The default values are: Temperature measurement: ±0.5 K Set point measurement: ±10 digits
Edge of wake pin change causing a telegram transmission	No	Every change of a wake pin triggers a wake-up. For both wake pins it can be configured individually if a telegram shall be sent on rising, falling or both edges.
Manufacturer ID and EEPROM (EnOcean Equipment Profile)	No	Information about manufacturer and type of device. This feature is needed for "automatic" interoperability of sensors and actuators or bus systems. Unique manufacturer IDs are distributed by the EnOcean Alliance.

The interface is shown in the figure below:



EnOcean provides EOPx (EnOcean Programmer, a command line program) and Dolphin Studio (Windows application for chip configuration, programming, and testing) and the USB/SPI programmer device as part of the EDK 300 or EDK 350 developer's kit.

The configuration page of DolphinStudio is shown in the figure below.



Please select STM 33x and press "Read configuration" button before modifying the entries!

## 3.8 Radio telegram

### 3.8.1 Normal operation

In normal operation STM 33x transmits telegram data according to the selected EEP (EnOcean Equipment Profile).

For details please refer to the EnOcean Equipment Profiles 2.1 specification.

[http://www.enocean-alliance.org/fileadmin/redaktion/enocean\\_alliance/pdf/EnOcean\\_Equipment\\_Profiles\\_EEP2.1.pdf](http://www.enocean-alliance.org/fileadmin/redaktion/enocean_alliance/pdf/EnOcean_Equipment_Profiles_EEP2.1.pdf)

### 3.8.2 Teach-in telegram

In case of a wake-up via WAKE1 pin (LRN input) the module transmits a teach-in telegram.

- If the manufacturer code is not set, the module transmits a normal telegram according to 3.8.1 with the difference that DI\_3=0.
- If a manufacturer code is set, this teach-in telegram contains special information as described below.

With this special teach-in telegram it is possible to identify the manufacturer of a device and the function and type of a device. The following EnOcean Equipment Profiles are supported by STM 330. They have to be selected according to the availability of external occupancy button and set point control by the method described in 3.7.2:

- A5-02-05 Temperature sensor 0-40 °C (default)
- A5-10-03 Temperature sensor 0-40 °C, set point control
- A5-10-05 Temperature sensor 0-40 °C, set point, and occupancy control

If a HSM 100 module is plugged onto the connector in addition the following EEPs are supported:

- A5-04-01 Temperature and humidity sensor 0-40 °C and 0-100% r.h.
- A5-10-10 Temperature and humidity sensor 0-40 °C and 0-100% r.h., set point control, and occupancy control
- A5-10-12 Temperature and humidity sensor 0-40 °C and 0-100% r.h., set point control

For details please refer to the EnOcean Equipment Profiles 2.1 specification.


[http://www.enocean-alliance.org/fileadmin/redaktion/enocean\\_alliance/pdf/EnOcean\\_Equipment\\_Profiles\\_EEP2.1.pdf](http://www.enocean-alliance.org/fileadmin/redaktion/enocean_alliance/pdf/EnOcean_Equipment_Profiles_EEP2.1.pdf)

## 3.9 Transmit timing

The setup of the transmission timing allows avoiding possible collisions with data packages of other EnOcean transmitters as well as disturbances from the environment. With each transmission cycle, 3 identical subtelegrams are transmitted within 40 ms. The transmission of a subtelegram lasts approximately 1.2 ms. The delay between the three transmission bursts is affected at random.


### 3.10 Charging circuitry

The figure below shows the internal charging circuit. It is controlled via the WXODIO pin of EO3000I which switches according to the status of the internal threshold detector. For details please refer to our Dolphin Core Description documentation. The WXIDIO pin is used to disconnect the goldcap at voltages below VOFF to avoid deep discharge.



An external 3 V backup battery can be connected at VCHAR.

### 3.11 Energy consumption



Current Consumption of STM 33x

Charge needed for one measurement and transmit cycle: ~130  $\mu$ C  
 Charge needed for one measurement cycle without transmit: ~30  $\mu$ C  
 (current for external sensor circuits not included)

Calculations are performed on the basis of electric charges because of the internal linear voltage regulator of the module. Energy consumption varies with voltage of the energy storage while consumption of electric charge is constant.

From these values the following typical performance parameters at room temperature have been calculated:

Wake cycle [s]	Transmit interval	Operation Time in darkness [h] when storage fully charged	Required reload time [h] at 200 lux within 24 h for continuous operation	24 h operation after 6 h illumination at x lux	Illumination level in lux for continuous operation	Current in $\mu\text{A}$ required for continuous operation
1	1	0.5	storage too small	storage too small	5220	130.5
1	10	1.7	storage too small	storage too small	1620	40.5
1	100	2.1	storage too small	storage too small	1250	31.3
10	1	5.1	storage too small	storage too small	540	13.5
10	10	16	21	storage too small	175	4.4
10	100	20	16.8	storage too small	140	3.5
100	1	43	7.8	260	65	1.6
100	10	98	3.6	120	30	0.8
100	100	112	3	100	25	0.6

#### Assumptions:

- Internal storage PAS614L-VL3 (after several days of operation at good illumination level) with 0.25 F,  $U_{\text{max}}=3.2\text{ V}$ ,  $U_{\text{min}}=2.2\text{ V}$ ,  $T=25\text{ }^{\circ}\text{C}$
- Consumption: Transmit cycle 100  $\mu\text{C}$ , measurement cycle 30  $\mu\text{C}$
- Pre-installed solar cell ECS 300, operating values 3 V and 5  $\mu\text{A}$  @ 200 lux fluorescent light
- Current proportional to illumination level (not true at very low levels!)

These values are calculated, the accuracy is about +/-20%! The performance varies over temperature and may be strongly reduced at extreme temperatures or short transmit intervals.


## 4 APPLICATIONS INFORMATION

### 4.1 Using the WAKE pins

The logic input circuits of the WAKE0 and WAKE1 pins are supplied by UVDD and therefore also usable in "Deep Sleep Mode". Due to current minimization there is no internal pull-up or pull-down at the WAKE pins. When STM 330 is in "Deep Sleep Mode" and the logic levels of WAKE0 and / or WAKE1 is changed, STM 330 starts up.



As there is no internal pull-up or pull-down at the WAKE0 pin, it has to be ensured by external circuitry, that the WAKE0 pin is at a defined logic level at any time. At time of delivery a jumper is connected between WAKE0 and UVDDext. WAKE1 provides an internal 1.8 M $\Omega$  pull-up. See figure below.



When the LRN button is pressed WAKE1 is pulled to GND and a teach-in telegram is transmitted. As long as the button is pressed a small current of approximately 1  $\mu$ A is flowing. It is possible to connect an additional external button in parallel between WAKE1 and GND if a different position of the button in the device is required.

WAKE0 is connected to UVDDext via a jumper at time of delivery. If the module is mounted onto a host PCB the jumper has to be removed. The circuitry on the host PCB then has to ensure that WAKE0 is always in a defined position. There are two ways to use WAKE0:

- Connect WAKE0 to UVDDext and connect an external button between WAKE0 and GND. As long as the button is pressed a current of 1  $\mu$ A will flow.
- Connect a 3 terminal switch and switch WAKE0 to either GND or UVDDext. In this case there is no continuous flow of current in either position of the switch.

### 4.2 Temperature sensor

STM 33x provides an internal temperature sensor. The sensor is part of the EO3000I IC and measures the chip temperature. Therefore it is important to provide a good thermal connection of the IC to the environment by ensuring sufficient ventilation of air inside the housing. Only then the measurement will represent the ambient temperature. Depending on the design of the housing a delay between ambient temperature changes and measured temperature value will be seen.




Heating of the chip due to its current consumption is negligible as the chip only consumes 200 nA while in sleep mode.

Temperature measurement every second is not recommended as in this case effects of heating of the chip might become visible and accuracy is reduced.


### 4.3 Set point control and occupancy button

In order to control the set point, an external potentiometer has to be connected as shown below. In addition this figure shows how to connect the occupancy button.




### 4.4 Combination with humidity sensor module HSM 100

The humidity sensor module HSM 100 extends the functionality of STM 330 / STM 331 / STM 330C temperature sensor modules. HSM 100 contains an internal calibrated humidity sensor. It can be plugged onto STM 33x modules via the 20 pin connector. For details please refer to the data sheet of HSM 100.



## 4.5 Antenna layout


### 4.5.1 Whip antenna (STM 330 / STM 330C)




**Specification of the whip antenna; L=150 mm @ 315 MHz, L=86 mm @ 868 MHz**

Antenna layout recommendation:

STM 330 without host PCB




STM 330 with host PCB






### 4.5.2 Helical antenna (STM 331)

#### 868 MHz




Antenna recommendation:

STM 33x without host PCB




STM 33x with host PCB



#### 4.6 Mounting STM 330 into a housing

The figure below shows an example of a housing in which the module can be mounted (with antenna pointing to the left). Design data of the housing and the modules is available in .igs format.



Please make sure not to exert shear force (side force within the plane of the solar cell) onto the solar cell! The maximum vertical force onto the solar cell must not exceed 4 N and should be homogeneously distributed! Bending of the PCB must be avoided!



Please make sure that the housing covers 0.5 mm at the solar cell edges. Within 0.5 mm off the edge flaking is possible due to the cutting process.

## 4.7 Transmission range

The main factors that influence the system transmission range are type and location of the antennas of the receiver and the transmitter, type of terrain and degree of obstruction of the link path, sources of interference affecting the receiver, and “Dead” spots caused by signal reflections from nearby conductive objects. Since the expected transmission range strongly depends on this system conditions, range tests should categorically be performed before notification of a particular range that will be attainable by a certain application.

The following figures for expected transmission range are considered by using a PTM, a STM or a TCM radio transmitter device and the TCM radio receiver device with preinstalled whip antenna and may be used as a rough guide only:

- Line-of-sight connections: Typically 30 m range in corridors, up to 100 m in halls
- Plasterboard walls / dry wood: Typically 30 m range, through max. 5 walls
- Ferroconcrete walls / ceilings: Typically 10 m range, through max. 1 ceiling
- Fire-safety walls, elevator shafts, staircases and supply areas should be considered as screening.

The angle at which the transmitted signal hits the wall is very important. The effective wall thickness – and with it the signal attenuation – varies according to this angle. Signals should be transmitted as directly as possible through the wall. Wall niches should be avoided. Other factors restricting transmission range:

- Switch mounted on metal surfaces (up to 30% loss of transmission range)
- Hollow lightweight walls filled with insulating wool on metal foil
- False ceilings with panels of metal or carbon fiber
- Lead glass or glass with metal coating, steel furniture

The distance between EnOcean receivers and other transmitting devices such as computers, audio and video equipment that also emit high-frequency signals should be at least 0.5 m.

A summarized application note to determine the transmission range within buildings is available as download from [www.enocean.com](http://www.enocean.com).

## 5 AGENCY CERTIFICATIONS

The modules have been tested to fulfil the approval requirements for CE (STM 330 / STM 331) and FCC/IC (STM 330C) based on the built-in firmware.



When developing customer specific firmware based on the API for this module, special care must be taken not to exceed the specified regulatory limits, e.g. the duty cycle limitations!

### 5.1 CE Approval

The STM 330 / STM 331 module bears the EC conformity marking CE and conforms to the R&TTE EU-directive on radio equipment. The assembly conforms to the European and national requirements of electromagnetic compatibility. The conformity has been proven and the according documentation has been deposited at EnOcean. The modules can be operated without notification and free of charge in the area of the European Union and in Switzerland.



- EnOcean RF modules must not be modified or used outside their specification limits.
- EnOcean RF modules may only be used to transfer digital or digitized data. Analog speech and/or music are not permitted.
- EnOcean RF modules must not be used with gain antennas, since this may result in allowed ERP or spurious emission levels being exceeded.
- The final product incorporating EnOcean RF modules must itself meet the essential requirement of the R&TTE Directive and a CE marking must be affixed on the final product and on the sales packaging each. Operating instructions containing a Declaration of Conformity has to be attached.
- If the STM 33x transmitter is used according to the regulations of the 868.3 MHz band, a so-called "Duty Cycle" of 1% per hour must not be exceeded. Permanent transmitters such as radio earphones are not allowed.
- The module must be used with only the following approved antenna(s).

Model	Type
STM 330	Pre-installed whip antenna
STM 331	Pre-installed helix antenna

## 5.2 FCC (United States) certification

### STM 330C LIMITED MODULAR APPROVAL

This is an RF module approved for Limited Modular use operating as an intentional transmitting device with respect to 47 CFR 15.231(a-c) and is limited to OEM installation. The module is optimized to operate using small amounts of harvested energy, such as can be collected by a small solar cell exposed to ambient light. The module transmits short radio packets comprised of control signals, (in some cases the control signal may be accompanied with data) such as those used with alarm systems, door openers, remote switches, and the like. The module does not support continuous streaming of voice, video, or any other forms of streaming data; it sends only short packets containing control signals and possibly data and is typically powered by a solar cell in ambient light. The module is designed to comply with, has been tested according to 15.231(a-c), and has been found to comply with each requirement. Thus, a finished device containing the STM 330C radio module can be operated in the United States without additional Part 15 FCC approval (approval(s) for unintentional radiators may be required for the OEM's finished product), under EnOcean's FCC ID number. This greatly simplifies and shortens the design cycle and development costs for OEM integrators.

The module can be triggered manually or automatically, which cases are described below.

#### Manual Activation

The radio module can be configured to transmit a short packetized control signal if triggered manually. The module can be triggered, by pressing a switch, for example. The packet contains one (or more) control signals that is(are) intended to control something at the receiving end. The packet may also contain data. Depending on how much energy is available from the energy source, subsequent manual triggers can initiate the transmission of additional control signals. This may be necessary if prior packet(s) was (were) lost to fading or interference. Subsequent triggers can also be initiated as a precaution if any doubt exists that the first packet didn't arrive at the receiver. Each packet that is transmitted, regardless of whether it was the first one or a subsequent one, will only be transmitted if enough energy is available from the energy source.

#### Automatic Activation

The radio module also can be configured to transmit a short packetized control signal if triggered automatically, by a relevant change of its inputs, for example. Again, the packet contains a control signal that is intended to control something at the receiving end and may also contain data. As above, it is possible for the packet to get lost and never reach the receiver. However, if enough energy is available from the energy source, and the module has been configured to do so, then another packet or packets containing the control signal may be transmitted at a later, unpredictable time.



**OEM Requirements**

In order to use EnOcean’s FCC ID number, the OEM must ensure that the following conditions are met.

- End users of products, which contain the module, must not have the ability to alter the firmware that governs the operation of the module. The agency grant is valid only when the module is incorporated into a final product by OEM integrators.
- The end-user must not be provided with instructions to remove, adjust or install the module.
- The Original Equipment Manufacturer (OEM) must ensure that FCC labeling requirements are met. This includes a clearly visible label on the outside of the final product. Attaching a label to a removable portion of the final product, such as a battery cover, is not permitted. The label must include the following text:

*Contains FCC ID: SZV-STM310C*

*The enclosed device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (i.) this device may not cause harmful interference and (ii.) this device must accept any interference received, including interference that may cause undesired operation.*

When the device is so small or for such use that it is not practicable to place the statement above on it, the information required by this paragraph shall be placed in a prominent location in the instruction manual or pamphlet supplied to the user or, alternatively, shall be placed on the container in which the device is marketed. However, the FCC identifier or the unique identifier, as appropriate, must be displayed on the device.

The user manual for the end product must also contain the text given above.

- Changes or modifications not expressly approved by EnOcean could void the user's authority to operate the equipment.
- The OEM must ensure that timing requirements according to 47 CFR 15.231(a-c) are met.
- The OEM must sign the OEM Limited Modular Approval Agreement with EnOcean
- The module must be used with only the following approved antenna(s).

Model	Type	Gain
STM 330C	Pre-installed Wire/Monopole	1.0 dBi

### 5.3 IC (Industry Canada) certification

In order to use EnOcean's IC number, the OEM must ensure that the following conditions are met:

- Labeling requirements for Industry Canada are similar to those required by the FCC. The Original Equipment Manufacturer (OEM) must ensure that IC labeling requirements are met. A clearly visible label on the outside of a non-removable part of the final product must include the following text:

*Contains IC: 5713A-STM310C*

- The OEM must sign the OEM Limited Modular Approval Agreement with EnOcean

## 6 Label Information

