


SIUS

User Manual Appendix System 7



SIUS AG

BASYS7AH1ER1
Menu.mpp - 10.04.2013

Im Langhag 1
CH-8307 Effretikon

+41 (52) 354 60 60
Fax: +41 (52) 354 60 66
www.sius.com
admin@sius.com

Targets

10m

ISSF

Running Target

Biathlon

Other

Divisions

25m

ISSF

Switzerland

Russia

50m

ISSF

Switzerland

Rifle

Small Bore

Big Bore

Biathlon

Divisions

Running Target

300m

ISSF

CISM

Switzerland

A

B

Scandinavia

Norway

2

2

2

3

3

4

4

4

4

5

6

6

6

7

7

7

9

10

11

11

11

11

11

12

12

13

13

14

Belgium	15
Other	17
NRA	17
100m	18
200m	18
Danmark	18
Final	18
Italy	20
Austria	22
Hunting	32
Scandinavia	36
Military	36
Full Bore	38
Norway	39
B	39
C	40
1/x	41
Other	42
Programs	45
10m	45
ISSF	45
Running Target	45
Pentathlon	45
Other	46
25m	46
ISSF	46
CISM	47
Sui	47

	English Page
Other	47
50m	47
ISSF	47
CISM	48
Running Target	48
ISSF	48
ISSF Boar	48
(Rings)ISSF Boar	49
DJV	49
SWE	49
Sui	49
Other	49
300m	50
ISSF	50
CISM	50
Switzerland	50
OP	50
Group championship	50
A	51
B	56
Other	58
FS	58
F5	58
Scandinavia	59
Other	59
Other	59
Norway	59
50ft	60
200m	60

English

Page

C200	60
A10 Reduced 200	60
NRA	60
Full Bore	60
Austria	60
Scandinavia	63
Military	63
Hunting	63
Control	65
Zoom	65
TOTAL	66
Score	66
Print screen	66
Repeat	66
SC-Programs	66
Malfunction	66
Other	67
Abort	67
Clear target window	67
Timer	67
Set Timer	68
Start Timer	68
Reset Timer	68
Remove Timer	68
System	69
Reports	69
Reload	69

	English
	Page
Reprint	69
Shot Counter	70
Invalid shots	70
Log	71
Settings	71
Presentation	71
Shot	71
Last Shot	71
Symbol	71
Form	71
Size	72
Inverse	73
Last Shot Window	73
Screen	73
Deferred Shots	73
Display Inner ten	73
Standard	74
Symbol	74
Form	74
Size	74
Inverse	75
Print-format	75
Use Always	75
Screen-format	76
Secondary Score	76
Clear target after shots	77
Cross Shot	77
Illegal Shot	77
Best shot	78
Printing	78
Column Configuration	78
Use Always	78
Print Protocol	78
Secondary Score	79
Sighters	79
Subtotal	79

	English
	Page
Print Overtime	79
Print number of Innertens	79
Number of line feeds	79
Group	81
Reset Shot Number	81
Subtotal	82
Other	82
Control unit	82
Layout	82
Function Keys	82
Status flashing	83
Practice progress window	83
Large font in Listwindow	83
Message	83
Display Messages	83
Target Feed Message	84
Display target name	84
Display calibre	84
Indication	84
Parameter	85
MPI	85
Text	85
MPI	85
Simulator SCB	85
Divisions	85
Language	86
Language	86
Time	87
Adjust Clock	87
Date format	88
Other	88
Start	88
Enable Repeat	88
Free series start setting	88

	English
	Page
Startup program	89
SC-Programs	89
Single Execution	89
Scale Factor	89
Set Scale Factor	89
Target Alternative	89
Enable Autoreset	90
Filter	90
Distance	90
Category	91
Weapon	92
User Group	93
Function	94
Mode	95
Calibre	96
Use Always	96
Control Mode	97
Demo	97
Settings Control	98
Maintenance	98
Reports	98
Settings	98
Shot Counter	99
Invalid shots	99
Log	99
Debug	100
Self Test	100
Target test	101
Keyboard	101
Scoreboard	101
Control unit reset	101
Hardware	102

English

Page

SCB	102
SCB	102
Control unit	102
Menu	109
Set Subnet	112
RC92	112
Match Menu	112
Target	112
Target changer	112
Paper feed	112
Use Always	113
Target Lifter	113
Connect	114
Light	114
Distance Index	114
Sensitivity	115
Use Always	115
Time Control Unit	115
Time Control Unit	115
Duel mode	115
Graphic Printer Model	115
Shot sensor	116
Logon	117
Info	117
Requirements	117
Legalisation	117
Weapon required	117
Position required	118
Firer number required	118

	English
	Page
Legalisation	118
Weapon Type	119
Position	119
Firer number	120

SIUS

Targets


Free series are programs which do not prescribe any set numbers of shots. They are especially suitable for completing open training courses. With free series all official shoots can be simulated.

10m

The directory 10m is the compilation of all target images which typically are used over a distance of 10 metres.

ISSF

Official targets of the ISSF are filed in this directory.




Air Rifle

10 metre running target; ISSF Rules, Section 6.3.2.3; diameter 45.5mm; black reflector from ring 4 to 9



06000019000201(62)



Air Pistol


10 metre air pistol target; ISSF Rules, Section 6.3.2.6; diameter 155.5mm; black reflector from ring 7 to 10



06000019000203(56)

Switzerland

Targets that are used only in Switzerland are stored in this directory.




Air Rifle

10 metre target with the dimensions of the official ISSF target. But unlike the latter, with the secondary score in one hundredth rings instead of the one tenth ring score of the ISSF.



06000019000205(50)




Air Pistol

10 metre target with the dimensions of the official ISSF target. But unlike the latter, with the secondary score in one hundredth rings instead of the one tenth ring score of the ISSF.



06000019000207(44)



Volkscheibe


A10 air rifle target with large 10-er ring for public events.



06000019000209(38)

Running Target

The target pictures for the running target are filed in this directory. The discipline is also supported in the 10 metres by the ISSF.




Standard

10 metre running target; ISSF Rules, Section 6.3.2.7.2; diameter 50.5mm; black reflector from ring 5 to 10



06000019001200(72)



Final


10 metre running target; ISSF Rules, Section 6.3.2.7.2; diameter 50.5mm; black reflector from ring 5 to 10



06000019001201(69)

Biathlon

The target pictures for biathlon are filed in this directory. Biathlon targets can be found under 10 metres and 50 metres.




15

Target image with 15 millimetre circle.



06000019001302(57)




20

Target image with 20 millimetre circle.



06000019001301(60)




35
Target image with 35 millimetre circle.



06000019001300(63)


Other



Zimmerstutzen
German target



06000019000210(35)




Croatian AR Target



06000019000211(32)


Divisions



Air Rifle 10



06000019002600(43)



Air Pistol 10




06000019002601(40)

25m

The directory 25m is the compilation of all target images which typically are used over a distance of 25 metres.

ISSF

Official targets of the ISSF are filed in this directory.




Precision

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10



06000019000303(47)



Rapid Fire


25 metre rapid fire target, ISSF Rules, Section 6.3.2.4, Diameter 500mm; black reflector from ring 5 to 10



06000019000305(41)

Switzerland

Targets that are used only in Switzerland are stored in this directory.



O10


Swiss ordnance rapid fire pistol target (military); outline with ovals; Form 34.17



06000019000407(26)

Big bore pistol

Many 25 metre targets are also shot with large calibre pistols (9.65mm). In order that the calibre setting can be correctly selected, these targets are listed twice.




Precision

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10



06000019000311(23)




Rapid Fire

25 metre rapid fire target, ISSF Rules, Section 6.3.2.4, Diameter 500mm; black reflector from ring 5 to 10



06000019000313(17)




O10
*Swiss ordnance rapid fire pistol target (military);
 outline with ovals; Form 34.17*



06000019000707(96)

Russia


Targets that are used only in Switzerland are stored in this directory.



Russian No. 04
*Swiss ordnance rapid fire pistol target (military);
 outline with ovals; Form 34.17*



06000019003000(07)



Unterhebelrepetierer




06000019002702(28)

50m

The directory 50m is the compilation of all target images which typically are used over a distance of 50 metres.

ISSF


Official targets of the ISSF are filed in this directory.



Rifle
*50 metre precision rifle target; ISSF Rules, Section
 6.3.2.2; diameter 154.4mm; black reflector from one
 section of ring 3 to ring 10, diameter 112.4mm*




06000019000301(53)



Final



06000019000302(50)



Pistol

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10




06000019000303(47)

Switzerland

Targets that are used only in Switzerland are stored in this directory.

Rifle




A5

50 metre small calibre rifle target with five rings; diameter 154.4mm; black reflector from one section of ring 2 to ring 5.



06000019000307(35)




A10

50 metre precision rifle target; ISSF Rules, Section 6.3.2.2; diameter 154.4mm; black reflector from one section of ring 3 to ring 10, diameter 112.4mm



06000019000308(32)




A20

50 metre precision rifle target; diameter 154.4mm; black reflector from one section of ring 6 to 20, diameter 112.4mm



06000019000309(29)



A100


50 metre precision rifle target with a one hundred ring score instead of the ISS ten ring score; diameter 154.4mm; black reflector diameter 112.4mm



06000019000310(26)

Small Bore


Swiss pistol targets with small calibre (5.6mm) setting.



PA4
Pistol target A40; circular target with four rings.




06000019000401(44)



PA10
Pistol target A10; circular target with ten rings.




06000019000402(41)



PA100
Pistol target A100; circular target with one hundred rings.




06000019000403(38)



PB5
Pistol target B5; circular target with five equal rings and an outline whereby the outline is worth at least three points.




06000019000404(35)



PB10
Pistol target B10; circular target with ten equal rings and an outline.




06000019000405(32)



PB100
Pistol target B100; circular target with one hundred equal rings and an outline.



06000019000406(29)




O10
*Swiss ordnance rapid fire pistol target (military);
 outline with ovals; Form 34.17*



06000019000407(26)

Big Bore


Big bore pistol



PA4
Pistol target A40; circular target with four rings.




06000019000701(17)



PA10
Pistol target A10; circular target with ten rings.




06000019000702(14)



PA100
Pistol target A100; circular target with one hundred rings.




06000019000703(11)



PB5
*Pistol target B5; circular target with five equal rings
 and an outline whereby the outline is worth at least
 three points.*




06000019000704(08)



PB10
*Pistol target B10; circular target with ten equal rings
 and an outline.*




06000019000705(05)



PB100
Pistol target B100; circular target with one hundred equal rings and an outline.




06000019000706(02)



O10
Swiss ordnance rapid fire pistol target (military); outline with ovals; Form 34.17



06000019000707(96)




Morgarten
Outline target with five scores, whereby the value two is assigned to five ellipses and the value one to the rest of the outline.



06000019000410(17)

Biathlon


The target pictures for biathlon are filed in this directory. Biathlon targets can be found under 10 metres and 50 metres.



35mm
Target image with 35 millimetre circle.




06000019001306(45)



45mm
Target image with 45 millimetre circle.




06000019001305(48)



85mm
Target image with 85 millimetre circle.



06000019001304(51)




110
Target image with 110 millimetre circle.



06000019001303(54)


Divisions



Pistol



06000019002602(37)




Rifle



06000019002603(34)

Running Target

The target pictures for the running target are filed in this directory. The discipline is also supported in the 10 metres by the ISSF.



Standard




06000019001208(48)

300m

The directory 300m is the compilation of all target images which typically are used over a distance of 300 metres.

ISSF

Official targets of the ISSF are filed in this directory.




A10



06000019000002(77)

CISM

The A10 target which is used in military contests does not differ from the A10 target which is used in ISSF disciplines. So that the filter function can be better used, the category CISM was separately introduced.



A10




06000019000002(77)

Switzerland

Targets that are used only in Switzerland are stored in this directory.

A


A-targets with varied scores:



A5




06000019000001(80)



A6




06000019000005(68)



A10




06000019000002(77)



A100




06000019000003(74)



A10/FA10



06000019000014(41)




A10 final



06000019000015(38)

B


B-targets with different scores (field target B Form. 34.21.2.88):



B4




06000019000004(71)



B10




06000019000008(59)



B100



06000019000009(56)




PB5

Pistol target PB5



06000019000010(53)



F5




06000019000007(62)

Scandinavia

Targets that are used only in Scandinavia are stored in this directory. The exception is animal images (moose and reindeer) which can be found under 'Other\Hunting\Moose'.


Norway



Nor7




06000019001101(78)



Nor8




06000019001102(75)



NSF 15m




06000019001410(24)



DFS 15m




06000019001411(21)



DFS 100




06000019001103(72)



DFS 200




06000019001412(18)



DFS 300




06000019001413(15)



New Swedish target




06000019001100(81)



16FIG




06000019001105(66)



16V




06000019001106(63)



C30



06000019001104(69)




A10 Reduced 200



06000019001414(12)

Belgium


Targets from Belgium



A10



06000019000002(77)




Oly100

Oly100 Target



06000019001501(42)




Oly200

Oly200 Target



06000019001502(39)




Schijf K

Schijf K Target



06000019001503(36)




Schijf 4

Schijf 4 Target



06000019001504(33)




Schijf 5

Schijf 5 Target



06000019001505(30)




Schijf S

Schijf S Target




06000019001506(27)



NTTC4



06000019001507(24)



NTTC5




06000019001508(21)

Other

All targets that do not clearly fall under one of the preceding distances are included in the category 'Other'.


NRA



50ft Rifle Target




06000019002803(16)



SR2 200y




06000019002805(10)



Short Range




06000019002800(25)



Long Range



06000019002801(22)




Combined Range



06000019002802(19)


100m



AUT 100m KK



06000019002701(31)




Schijf Woerden



06000019002700(34)

200m




C200



06000019002703(25)

Danmark


Final



50m riffel M 90 F




06000019002906(95)



15m riffel 1984 F




06000019002907(92)



15m fripistol F




06000019002908(89)



15m lufriffel M 96/G F




06000019002909(86)



15m pistol F




06000019002910(83)



15m riffel D SkyU 1982 F




06000019002911(80)



50m riffel M 90




06000019002900(16)



15m riffel 1984




06000019002901(13)



15m fripistol




06000019002902(10)



15m lufriffel M 96/G




06000019002903(07)



15m pistol




06000019002904(04)



15m riffel DskyU 1982




06000019002905(01)



A10 Reduced 200



06000019001414(12)




C30



06000019001104(69)


Italy



Bersaglio 1




06000019002400(61)



Bersaglio 2




06000019002401(58)



Bersaglio 9




06000019002402(55)



P1




06000019002403(52)



P2



06000019002404(49)



P3




06000019002405(46)



A10 100m




06000019002406(43)



A10 200m



06000019002407(40)



A10 300m




06000019002408(37)

Austria

ASR


\ASR\Pistol



Pistol A 5m




06000019001700(27)



Pistol A 10m




06000019001701(24)



Pistol B 5m




06000019001702(21)



Pistol B 10m




06000019001703(18)



Pistol D 5m



06000019001704(15)



Pistol D 10m




06000019001705(12)



Pistol C 7m




06000019001706(09)



Pistol C 15m




06000019001707(06)



Pistol C All




06000019001708(03)



Pistol E 20m



06000019001709(97)




Pistol E All



06000019001710(94)


VASR\Rifle



Rifle A 10m vertical




06000019001602(30)



Rifle A 20m vertical




06000019001603(27)



Rifle B 10m horizontal




06000019001604(24)



Rifle B 20m horizontal




06000019001605(21)



Rifle B 10m ellipse




06000019001606(18)



Rifle B 20m ellipse




06000019001607(15)



Rifle C 15m




06000019001608(12)



Rifle C 30m




06000019001609(09)



Rifle C All




06000019001610(06)



Rifle D 40m



06000019001611(03)




Rifle D All



06000019001612(97)

Classic


\Classic\Pistol



A10




06000019001810(85)



A100




06000019001811(82)



Klein links




06000019001801(15)



Klein rechts




06000019001802(12)



Gross links




06000019001803(09)



Gross rechts




06000019001804(06)



Klein Klein




06000019001805(03)



Klein Gross




06000019001806(97)



Gross Klein




06000019001807(94)



Gross Gross



06000019001808(91)




Precision

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10



06000019001812(79)


\Classic\Rifle



R10




06000019001800(18)



A10




06000019000002(77)



A100



06000019000003(74)




Anschluss Scheibe



06000019001809(88)

\Classic\MG


\Classic\MG\A



MG Ziel A1




06000019001900(09)



MG Ziel A2




06000019001901(06)



MG Ziel A3




06000019001902(03)



MG Ziel A4




06000019001903(97)



MG Ziel A5




06000019001904(94)



MG Ziel A6




06000019001905(91)



MG Ziel A7



06000019001906(88)




MG Ziel A8



06000019001907(85)


\Classic\MG\B



MG Ziel B1




06000019001908(82)



MG Ziel B2




06000019001909(79)



MG Ziel B3




06000019001910(76)



MG Ziel B4



06000019001911(73)



MG Ziel B5




06000019001912(70)



MG Ziel B6




06000019001913(67)



MG Ziel B7



06000019001914(64)




MG Ziel B8



06000019001915(61)


\Classic\MG\C



MG Ziel C1




06000019002000(97)



MG Ziel C2




06000019002001(94)



MG Ziel C3




06000019002002(91)



MG Ziel C4




06000019002003(88)



MG Ziel C5




06000019002004(85)



MG Ziel C6




06000019002005(82)



MG Ziel C7



06000019002006(79)



MG Ziel C8



06000019002007(76)

Hunting

Moose

Summary of the moose targets:

\Moose\Left

Moose 5-5-4-3


Moose target with the scores 5-5-4-3 and 10-8-6-4.



06000019001401(51)

Moose

Moose target with tenner score.



06000019001404(42)

Moose SWE

Swedish moose target with 5-5-4-3 score.



06000019001407(33)

Moose Calf

Swedish Elk calf target with 5-5-4-3 and Hit-Score




06000019001409(27)


\Moose\Right

Moose 5-5-4-3

Moose target with the scores 5-5-4-3 and 10-8-6-4.



06000019001402(48)



Moose
Moose target with tenner score.



06000019001405(39)



Moose SWE
Swedish moose target with 5-5-4-3 score.



06000019001408(30)




Moose Calf
Swedish Elk calf target with 5-5-4-3 and Hit-Score



06000019001415(09)


\Moose\Double



Moose 5-5-4-3
Moose target with the scores 5-5-4-3 and 10-8-6-4.




06000019001400(54)



Moose
Moose target with tenner score.



06000019001403(45)



Moose SWE
Swedish moose target with 5-5-4-3 score.




06000019001406(36)

Boar

Summary of bore targets:

Wild Boar 5


Running target 50 metre (ISSF-Bore 5; DJV No. 5);
ISSF Rules Section 6.3.2.7.1
Diameter 60mm



06000019000110(44)

Wild Boar 5 Right


Running target 50 metre (ISSF-Bore 5; DJV No. 5);
ISSF Rules Section 6.3.2.7.1
Diameter 60mm



06000019000104(62)

Wild Boar 2

DJV Number 2; Bore Art. No. S100AA010V1




06000019001514(03)

Bear


Bear Target

Bear Left




06000019001213(33)

Bear Right



06000019001214(30)


Bear



06000019001215(27)

Other


Bear Target



Kronhjort




06000019002500(52)



Roebuck left




06000019002501(49)



Roebuck right



06000019002502(46)




Chamois

DJV Number 1; Chamois Art. No. S100AA008V1



06000019000108(50)




Fox

DJV Number 2; Fox Art. No. S100AA009V1



06000019000106(56)




Roe

DJV Number 4; Roebuck Art. No. S100AA007V1




06000019000102(68)



Danish Roebuck



06000019000115(29)




Reindeer

Reindeer DV-! Norway; Art. No. S100AA012



06000019000114(32)




Roe Left

Hubertus Reh linkslaufend (Spezialscheibe für Kanton St. Gallen)



06000019000112(38)




Chamois Hubertus

Hubertus Gams rechtslaufend (Spezialscheibe für Kanton St. Gallen)



06000019000113(35)



Precision

25 / 50 metre precision pistol target PP10; ISSF Rules, Section 6.3.2.5, Diameter 500mm; black reflector from ring 7 to ring 10




06000019000303(47)

Scandinavia

Targets that are used only in Scandinavia are stored in this directory. The exception is animal images (moose and reindeer) which can be found under 'Other\Hunting\Moose'.


Military



2x1/3 figure




06000019001112(45)



1/1+1/3 figure




06000019001113(42)



Full Figure




06000019001107(60)



1/8+1/2 figure




06000019001114(39)



Half Figure




06000019001108(57)



One Third Figure




06000019001109(54)



Eighth figure



06000019001110(51)




Precision



06000019001115(36)


Full Bore



300y




06000019002300(70)



500y




06000019002301(67)



600y




06000019002302(64)



300m




06000019002303(61)



500m




06000019002304(58)



600m



06000019002305(55)




Long Range



06000019002306(52)

Norway


B



B45




06000019002210(49)



B65




06000019002211(46)



B100




06000019002212(43)



Smaen



06000019002213(40)




Minismaen



06000019002214(37)


C



C15




06000019002100(88)



C20




06000019002101(85)



C25




06000019002102(82)



C30




06000019002103(79)



C35




06000019002104(76)



C40



06000019002105(73)




C50



06000019002106(70)


1/x



1/3Mini




06000019002200(79)



1/3




06000019002202(73)



1/4Mini




06000019002201(76)



1/4Figur




06000019002207(58)



1/4




06000019002203(70)



1/6




06000019002204(67)



1/8



06000019002205(64)




1/10



06000019002206(61)


Other



13x40




06000019002107(67)



30x10




06000019002108(64)



Stripe




06000019002109(61)



Prisme




06000019002110(58)



S25



06000019002111(55)



Hjul




06000019002112(52)



150Sirkel




06000019002113(49)



55Sirkel




06000019002114(46)



40Tonne




06000019002208(55)



14Tonne




06000019002209(52)



NSF 15m




06000019001410(24)



DFS 15m




06000019001411(21)



DFS100



06000019001103(72)



DFS 200



06000019001412(18)

Programs

The programs are subdivided according to the usual distance, and according to categories of additional properties (e.g. Federation programs, group championships). The individual programs are designated with the target picture (e.g. A5), the type or fire (T=Test shots, S=Single fire, D=Serial fire) and the number of shots in this type of fire (T2 = 2 test shots, S5 = single fire 5 shots, D3 = serial fire 3 shots, T0 = test free/open, i.e. an open-ended number of test shots can be fired).

10m

The directory 10m is the compilation of all programs which typically are shot over a distance of 10 metres.

ISSF

Air Rifle 40	 20000735(55)
Air Rifle 60	 20000734(58)
Air Pistol 40	 20000737(49)
Air Pistol 60	 20000736(52)

Running Target

3030	 20000760(77)
2020	 20000761(74)
Mixed	 20000762(71)

Biathlon

<div style="border: 1px solid black; padding: 5px; display: inline-block;">  </div>	15mm	 06000019001302(57)
<div style="border: 1px solid black; padding: 5px; display: inline-block;">  </div>	20mm	 06000019001301(60)

Pentathlon

Pentathlon 20	
	20000450(37)
Pentathlon 3*10	
	20000460(07)
CE	
	20000451(34)
Sighters	
	20000452(31)

Other

Air Rifle 30	
	20000756(89)
Air Rifle 20	
	20000757(86)
Air Rifle 3*10	
	20000754(95)
Air Rifle 3*20	
	20000766(59)
Air Rifle 3*40	
	20000819(94)
Air Pistol 30	
	20000749(13)
Air Pistol 20	
	20000739(43)
Zimmerstutzen 30	
	20000748(16)
Rapid Fire Pistol	
	20000765(62)

25m

The directory 25m is the compilation of all programs which typically are shot over a distance of 25 metres.

ISSF

Rapid Fire Pistol	
	20000730(70)
Sport Pistol	
	20000733(61)

Center Fire Pistol



20000731(67)

Standard Pistol



20000732(64)

CISM

Sport Pistol



20000733(61)

Center Fire Pistol



20000731(67)

Military Rapid Fire Men



20000750(10)

Military Rapid Fire Women



20000753(01)

Sui

OP



20000830(61)

FS



20000831(58)

Other

SP15



20000751(07)

Russian No. 04



20000865(53)

50m

The directory 50m is the compilation of all programs which typically are shot over a distance of 50 metres.

ISSF

Rifle 60



20000725(85)

Standard Rifle 3*20



20000726(82)

Free Rifle 3*40



20000724(88)

3 Positions Final



20000791(81)

Pistol 60



20000727(79)

Rifle 2x30



20000716(15)

CISM

Rifle 60




20000725(85)

Standard Rifle 3*20



20000726(82)


Biathlon



35mm




06000019001306(45)



45mm




06000019001305(48)



85mm



06000019001304(51)



110



06000019001303(54)

Running Target

ISSF

\\ISSF\ISSF Boar

3030



20000770(47)

2020



20000771(44)

Mixed



20000772(41)

\ISSF\ (Rings)ISSF Boar

3030



20000822(85)

2020



20000824(79)

Mixed



20000826(73)

DJV

Wild Boar 5



20000775(32)

SWE

Running Roebuck



20000851(95)

Running Moose



20000852(92)

Sui

OP



20000832(55)

FS



20000833(52)

Morgarten



20000361(13)

PB5

D4D6



20000072(07)

Other

Rifle 3*10



20000755(92)

Rifle 30



20000758(83)

300m

The directory 300m is the compilation of all programs which typically are shot over a distance of 300 metres.

ISSF

Free Rifle 3*40



20000721(97)

Free Rifle 60



20000722(94)

Standard Rifle 3*20



20000723(91)

Rifle 2x30



20000717(12)

CISM

Standard Rifle 3*20



20000723(91)

Rapid Fire 3x20

*Military Rapid Fire 3*20*



20000816(06)

Switzerland

OP

Complete



20000840(31)

OP A5 Sighters



20000839(34)

OP Part 1

A5 S5



20000838(37)

OP B4 Sighters



20000836(43)






OP Part 2

B4 S5 D2 D3 D5



20000837(40)







Group championship

A5P <i>Unlimited test shots feature on the A5 window</i>	 20000398(96)
A10P <i>Unlimited test shots feature on the A10 window</i>	 20000397(02)
Field A <i>GM Field A</i>	 20000084(68)
Field B <i>GM Field B</i>	 20000014(84)
Field D <i>GM Field D</i>	 20000083(71)



A

\A\A5

\A\A5\Shot by Shot

S0	 20011011(73)
S4	 20000019(69)
S5	 20000012(90)
S6	 20000013(87)
S8	 20000020(66)
S10	 20000015(81)

\A\A5\Deferred

D0	 20000010(96)
D5	 20000023(57)
D6	 20000024(54)
D3D3	 20000025(51)

D4D4



20000026(48)

D5D5



20000016(78)

\A\A5\Deferred\Include sighters

P2 D2 D3 D5



20000344(64)

P1 D2 D3 D4 D5



20000346(58)

P2 D2 D2 D3 D3



20000348(52)

\A\A5\Combined

S4D4



20000006(11)

S5D3



20000021(63)

S2 D3 D5



20000009(02)

S4 D3 D3



20000022(60)

S5 D3 D4



20000007(08)

S6 D3 D3



20000676(38)

S2 D2 D3 D5



20000008(05)

\A\A5\Combined\Include sighters

S6D4



20000002(23)

P2 S1 D3 D6



20000027(45)

P2 S2 D3 D3



20000668(62)

P2 S2 D3 D5



20000003(20)

P2 S5 D3 D4



20000667(65)

P3 S6 D3 D3



20000001(26)

P2 D2 D2 D3 D3



20000005(14)

P1 S2 S3 S4 S5



20000004(17)

\A\A10

\A\A10\Shot by Shot

S0



20000031(33)

S5



20000033(27)

S6



20000034(24)

S8



20000035(21)

\A\A10\Shot by Shot\Include sighters

Opening shooting



20000763(68)

P2S6



20000666(68)

P2S10



20000029(39)

P2S6S4



20000038(12)

\A\A10\Deferred

D0



20000030(36)

D5



20000043(94)

D6



20000044(91)

D3D3



20000045(88)

\A\A10\Deferred\Include sighters

P2D1



20000694(81)

P2 D2 D3 D5



20000040(06)

P2 4*D5



20000028(42)

\A\A10\Combined

S3D3



20000041(03)

S4D4



20000042(97)

S5D3



20000046(85)

S6D4



20000032(30)

S2 D3 D5



20000039(09)

S2 D3 D5



20000357(25)

S4 D3 D3



20000210(78)

S3 S4 D4 D4



20000677(35)

\A\A10\Combined\Include sighters

S4D4



















20000047(82)

S5D3



20000037(15)

S6D6	 20000048(79)
P2 S5 D2 D3	 20000356(28)
P2 4*D5	 20000695(78)
Prone 4*S10	 20000589(08)
Standing 4*S10	 20000579(38)
Kneeling 4*S10	 20000569(68)

\A\A100	
P0	 20000396(05)
\A\A100\Shot by Shot	
S0	 20000051(70)
S2 <i>Nachdoppel</i>	 20000052(67)
S3	 20000053(64)
S4	 20000054(61)
S5	 20000055(58)
S6	 20000056(55)
S10	 20000057(52)
P1S4	 20000665(71)
D0	 20000050(73)

D4D4



20000049(76)

P2 S5 D2 D3



20000058(49)

B

\B\B4

P0



20000395(08)

\B\B4\Shot by Shot

S0



20000061(40)

S6



20000062(37)

\B\B4\Deferred

D0



20000060(43)

D5



20000064(31)

D6



20000063(34)

D3D3



20000065(28)

D4D4



20000066(25)

P2 D4 D6 KOM



20000349(49)

\B\B4\Combined

S3 D3 D3



20000067(22)

S3 D3 D6



20000379(56)

S3 D3 D3 D3



20000069(16)

S4D4



20000345(61)

S6 D3 D3 D6 KOM



20000359(19)

\B\B4\Combined\Include sighters

P2 S1 S3 S6



20000668(19)

P2 S2 D3 D5



20000669(59)

S4D4



2000070(13)

P2 S6 D6 D6



2000075(95)

\B\B10

P0



20000968(35)

S0



2000076(92)

D0



2000077(89)

S2 D3 D5



20000376(65)

S2D2



2000078(86)

D3D5



2000079(83)

\B\B100

P0



20000967(38)

S0



2000081(77)

D0



2000080(80)

S10



\B\PB5

P0



S0



D0



D4D6



Other

FS



Knabenschiessen

The youth shooting practice is solely for the Zurich Youth Shoot. Therefore it has a special score (A6) and a special printout. In youth shooting 5 shots are fired at an A5 target. The innermost ring (5-er ring) is valued with 6 points. The outermost ring counts for 2 points instead of 1 point. Each hit outside the outermost ring that nonetheless hits the target counts for 1 point. Moreover at the end each target hit is further awarded 1 point and this sum is included in the total result. The maximum is therefore 5 x 6 points + 5 hits = 35 points.



Morgarten



Pfäffiker winter practice

Hit score for single firer: every 10 shots in 10-er score; for group score 2. Pass (E4) in 100-er score.



Ustertag-Scheibe



Vögelinsegg



Hans Waldmann Schiessen



F5

D0



S0



20000986(78)

Scandinavia

Swedish program

Double

P0 S5 S5 S5 S5



20000718(09)

10

P0 S5 S5



20000719(06)

25

P0 S5 S5 S5 S5 S5



20000720(03)

Swedish championship

First relay

P0 S5 S5 S5



20000705(48)

Middle relay

P0 S5 S5



20000706(45)

Final

P0 S5 S5



20000707(42)

Reserved

P0 S5 S5 S5 S5



20000708(39)

Final reserved

P0 S5 S5 S5



20000709(36)

Other

Rifle 3*10



20000728(76)

Other

All targets that do not clearly fall under one of the preceding distances are included in the category 'Other'.

Norway

Class 1



20000501(78)

Class 2



20000502(75)

Class 3-5



20000503(72)

50ft

50ft Rifle 3x40



20000845(16)

50ft Rifle 3x20



20000841(28)

200m

C200

C200 60



20000854(86)

C200 3x20



20000855(83)

A10 Reduced 200

Free Rifle 60



20000866(50)

Standard Rifle 3*20



20000867(47)

NRA

Short Range



20000920(82)

Long Range



20000921(79)

Combined Range



20000922(76)

Full Bore

3yDL



20000860(68)

5yDL



20000861(65)

6yDL



20000862(62)

LRDL



20000863(59)

Austria

Pistol

\Pistol\1

1

Pistol A 5m



20000500(81)

Pistol A 10m



20000501(78)

\Pistol\2

2

Pistol B 5m



20000502(75)

Pistol B 10m



20000503(72)

\Pistol\3

3

Pistol D 5m



20000504(69)

Pistol D 10m



20000505(66)

\Pistol\4

4

Pistol D 5m



20000504(69)

Pistol D 10m



20000505(66)

5



20000504(69)

5

6



20000504(69)

6

7



20000506(63)

7

8



20000508(57)

8

9



20000508(57)

9

10



20000507(60)

10

11

11



20000509(54)

12

12



20000510(51)

Rifle

\Rifle\5

5

Rifle A 10m vertical



20000511(48)

Rifle A 20m vertical



20000512(45)

\Rifle\6

6

Rifle B 10m horizontal



20000513(42)

Rifle B 20m horizontal



20000514(39)

\Rifle\7

7

Rifle B 10m ellipse



20000515(36)

Rifle B 20m ellipse



20000516(33)

\Rifle\8

8

Rifle B 10m ellipse



20000515(36)

Rifle B 20m ellipse



20000516(33)

9

9



20000515(36)

10

10



20000515(36)

11

11








20000515(36)

12	
12	20000519(24)
13	
13	20000519(24)
\Rifle\14	
14	
Rifle C 15m	
	20000517(30)
Rifle C 30m	
	20000518(27)
15	
15	20000520(21)
16	
16	20000521(18)

Scandinavia

Targets that are used only in Scandinavia are stored in this directory. The exception is animal images (moose and reindeer) which can be found under \Other\Hunting\Moose'.

Military

2x1/3 figure	
	20000740(40)
1/1+1/3 figure	
	20000741(37)
Full Figure	
	20000742(34)
1/8+1/2 figure	
	20000743(31)
Half Figure	
	20000744(28)
One Third Figure	
	20000745(25)
Eighth figure	
	20000746(22)
Precision	
	20000747(19)

Hunting

Moose



20000850(01)

Moose LR Running



20000853(89)

Control

The control menu contains all the functions that are necessary during a running program. The menu pops up automatically into this view after a program is selected.

Zoom

Most target pictures can be represented in three different sizes (zoom levels). The zoom command switches to the next size. When the smallest size has been reached, then the next zoom command brings up the largest size again.



990652(52)

Match

In the course of a match, by means of the Match button (RC92) the major commands for controlling the match can be carried out by the firer. Thus the setting can be changed from the test group to the first single group. So long as the single group has not yet shot, triggering this command again can enable a return to the test group. In user practices and in free series this command does not appear in the menu. In this case (if the RC92 is pressed or if the corresponding barcode is input) a group total is triggered.



990636(75)

Sighters

In free series the fire type can be restarted at any time with the commands Test, Single and Series.



99063400(49)

Shot by Shot

In free series the fire type can be restarted at any time with the commands Test, Single and Series. If the fire type is already set to single, with this command the single group can be totalised and immediately a new group can be started. In this way for example every 10 shots a group total of an ISSF shoot can be simulated.



99063401(46)

Subtotal

Closes off the current open group and prints out a group total. The function is available only when an open group (P-, S- or D-) is shot. A group where the number of shots is prescribed cannot be skipped. If shooting takes place without a shot logoff, then shots which have totally missed the target must be reported to the system with the command '\Other\Insert zero shot'.



990530(05)

Total

In a free series the group total corresponds to the intermediate total or to a position total. The current group is added up. This corresponds to a subtotal. In addition all the groups since the last group total are counted together and removed. Thereafter the group can be continued.



990531(02)

TOTAL

In a free series the match total stops the current program (program total). It triggers a subtotal and a group total. In addition all shot values (except test shots) are added together and shown as the 'large' total. Other programs than the free series (match, user practice and fixed programs) cannot be stopped prematurely. They can only be broken off



990532(96)

and filled with manual nulls. An abort can be brought about by the command '\Other\Abort' or by loading another program. In the event of an abort the shot values are also added together and displayed.

Deferred

In free series the fire type can be restarted at any time with the commands Test, Single and Series. If the fire type is already set to Series, with this command the series group can be shown and totalised. Subsequently a new series group is automatically started.



99063402(43)

Show

In a group with serial shots all shots fired up to the present moment are displayed in advance. Correspondingly at the end of the group, only those shots which have not yet been displayed are shown. In groups with the fire type Test or Single Shot the barcode has no effect.



099054(46)

Score

In free series the command Value can change the secondary score to the primary score. This is useful if first a qualifier and then a final are shot. At most official shoots the finals are scored in tenths, but the qualifiers are scored in whole tens. If the command is carried out a second time, then the original score is switched on again. With the commands '\Other\Next Primary Score' and '\Other\Next Secondary Score' the primary and secondary scores can be controlled.



990643(54)

Print screen

The current screen content is printed on the graphic printer (Only D931/CBM210). It is not possible to print out on the dot matrix printer D93.



099050(58)

Repeat

Restarts a closed off practice with the same settings (firer number, firer name, weapon and position). This command can be blocked with the setting '\Other\Start\Permit Repeat\Off'.



91(18)

SC-Programs

Practice

In programs that show a match structure, under 'Group' it is possible to select which setting you want to begin with. In this way for example only the final of a match can be shot. During the match in progress, under 'Group' the setting 'Test' can be selected. This test corresponds to the regulated exceptional test which can be permitted after weapon malfunction. If the setting 'Test' is selected, then under 'Group' only the position that was shot most recently appears. Choosing this position enables you to return to the official match.

Malfunction

In the 25m pistol disciplines, various rules are defined which lay down the procedures for weapon failures. According to the discipline and the type of weapon failure (allowable / non allowable) the fired shots must be completed and evaluated. Individual commands enable the system to correctly calculate the end result and to correctly show the individual shots on the screen as well as on the scoreboard.

Fill Series

The active group is stocked with zeros. This also happens when the group have not yet shot.



99063700(22)

Insert zero shot

Inserts a shot with the value 0 into the current program. This function is needed if shooting took place without the use of the shot sensor and the target was missed. The system itself cannot recognise the shot in this situation.



099058(34)

Allowable

A permitted weapon malfunction (decision of the referee) permits the firer to complete the group according to the discipline (sport pistol, central fire pistol in rapid fire section) or to repeat it (standard pistol, rapid fire). The execution of this command produces at least one log entry.



99063701(19)

Non-Allowable

Non allowable weapon failures normally result in the open group being completed with zero and no repeat being available to the firer. Additionally a log entry is produced.



99063702(16)

Compute series

'Calculate series' completes the handling of weapon malfunctions. Even when several repetitions have had to be shot, on this command the shots are correctly selected and counted according to the rules of the ISSF.



99063703(13)

Other

Frequently used operating elements can be found directly under the Control menu\Other.

Abort

Produces in addition to the match total an abort (log entry) in order to mark the current group as invalid.



50(44)

Insert zero shot

Inserts a shot with the value 0 into the current program. This function is needed if shooting took place without the use of the shot sensor and the target was missed. The system itself cannot recognise the shot in this situation.



099058(34)

Clear target window

Clears the shots from the target window without removing them from the score. (see also the setting 'Clear target window after shots')



099062(22)

Clear List

Clears all entries from the list window, without removing the fired shots from the score.



990630(93)

Convert last sighting shot



09906901(97)

Convert both sighters



09906902(94)

Timer

This commands are used to control the embedded Timer.

Set Timer

Sets the Timer to the entered value and displays it in the titlebar



990650(33)

Start Timer

starts the timer



990651(30)

Reset Timer

Resets the timer to the value set by the Set Timer command



990652(27)

Remove Timer

Disables the Timer and removes it from the Display



990653(24)

Fix timer values

Here is a collection of fix timer values to configure the timer via Barcode

30s

30s



9906600030(34)

40s

40s



9906600040(04)

50s

50s



9906600050(71)

60s

60s



9906600060(41)

90s

90s



9906600090(48)

300s

5 min



9906600300(97)

1h

1h



9906603600(91)

Next Primary Score

Every target image has a number of score methods installed, which can be used to evaluate the target. With the command 'Other\Next Primary Score' these different score methods can be scrolled through. These amendments can only be made for free series. It should also be observed that different score methods are not strongly compatible one with another. It is therefore not advisable to change the score method while a program is running.



9906421999(45)

Next Secondary Score

Just as for the primary score, so too can the score method for the secondary score be changed.



9906422999(52)

Edit Barcode



990646(45)

System

Settings and commands that in normal shooting operation must rarely be changed or used. Some of the functions available are also reserved for specific user groups (administrator and Sius staff).

Reports

With many reports information about past programs can be printed out.

Reload

The last ten groups can subsequently be loaded once more and considered with the discussion mode. However in a subsequently loaded group no further amendments can be carried out. The shot picture can in this way once again also be created from completed programs and displayed.

1

Load the last program that was shot in order that it can be discussed.



99063800(13)

2

Load the program before last in order that it can be discussed.



99063801(10)

3

Load the third from last program in order that it can be discussed.



99063802(07)

4

Load the fourth from last program in order that it can be discussed.



99063803(04)

5

Load the fifth from last program in order that it can be discussed.



99063804(01)

6

Load the sixth from last program in order that it can be discussed.



99063805(95)

7

Load the seventh from last program in order that it can be discussed.



99063806(92)

8

Load the eighth from last program in order that it can be discussed.



99063807(89)

9

Load the ninth from last program in order that it can be discussed.



99063808(86)

10

Load the tenth from last program in order that it can be discussed.



99063809(83)

Reprint










In the event of a paper jam or other printer problem it can happen that a score sheet does not print out as desired. Finished groups can therefore be repeatedly printed out.

1

Print out the last program again.



09905520(69)

2	
<i>Print out the program before last again.</i>	09905521(66)
3	
<i>Print out the third from last program again.</i>	09905522(63)
4	
<i>Print out the fourth from last program again.</i>	09905523(60)
5	
<i>Print out the fifth from last program again.</i>	09905524(57)
6	
<i>Print out the sixth from last program again.</i>	09905525(54)
7	
<i>Print out the seventh from last program again.</i>	09905526(51)
8	
<i>Print out the eighth from last program again.</i>	09905527(48)
9	
<i>Print out the ninth from last program again.</i>	09905528(45)
All	
<i>Reprint all programs remaining in the log.</i>	09905529(42)


Shot Counter

Mechanical shot counters:

The optional mechanical shot counter only counts the shots on your own target. It cannot be reset. Demo shots or inserted no scores are not counted. A detailed description of the whole function can be found in the user manual under 'Mechanical shot counters'.


Software shot counters:


The software shot counter counts shots in different categories. Own shots, cross shots, missed shots, demo shots etc. are differentiated and displayed separately. The shot count report is displayed in the list window and provided a printer is connected and switched on, is printed out. The shot counters are connected to the control units. If the settings are reset to factory settings, the shot counts are also reset to zero. The same occurs when the battery has to be changed. With a normal interruption to the power supply, the values are not lost. The software shot counters can also be reset independently of the settings under 'Maintenance\Reports\Shot Counters'.

Report Shot Counter	
<i>The current shot numbers are displayed on the screen and on the printer.</i>	09903608(82)

Invalid shots

Non-allowable shots (shots during the Stop, Pause or the Show Phase and cross shots) are not only counted, they are kept in the control unit as pending and can be queried at any time. The shots are then shown with the time and if possible with the score. With a warm start or with the command 'Erase' under 'Maintenance\Invalid Shots' the report can be rejected. The shots remain in the log throughout and furthermore can be documented in a log printout.

Show	
<i>The report on invalid shots is displayed in the list window.</i>	990562(06)

Print	
<i>The report on invalid shots is printed out on the connected printer. If the printer is not turned on, the report is rejected.</i>	990564(97)

Log

Events that are of relevance for the duration of a program are filed in the memory (events memory, log). This information is needed to be able to reproduce a program after a power interruption. The CU931 investigates this data at every system start-up. If it is established that the last program to be shot was not correctly ended, then a repetition process is introduced. By means of the log past programs can also be reloaded or a copy can be printed once again. The log is stored in the volatile memory of the control unit, which is buffered with a battery. The data is protected from misinterpretation by a check sum. If the check sum is not correct at system start-up, for example due to a faulty battery, the log is initialised again. The control unit communicates this by a triple beep and a report in the list window. The log is restricted in memory size. In the event of an overload, the oldest events are overwritten by the most recent on a rolling basis. Typically more than ten programs can be stored in the log. The log can also be manually erased under 'Maintenance\Reports\Log'. The format of the printout is described in the user manual.

All

All events are printed out in chronological order. The oldest events first, and the most recent events at the end. The printout can be broken off at any time by switching off the printer.



09905500(32)

10

The ten most recent events are printed out in chronological order.



09905501(29)

20

The twenty most recent events are printed out in chronological order.



09905502(26)

50

The fifty most recent events are printed out in chronological order.



09905505(17)

Inverse

All events are printed out in reverse chronological order, the most recent events first, and the oldest events at the end. The printout can be broken off at any time by switching off the printer.



09905509(05)

Settings

The performance of the control unit can be adapted to the user's own needs by means of very many different settings. Programs can behave differently according to the properties selected. On the other hand, it is possible for fixed programs to overwrite particular properties. So for example shots are printed out differently in ISSF programs to other programs. It is also possible for programs to select a setting simply as a basic setting, which subsequently (after the program has been switched on) can be changed again by the user. The printout of shots in ISSF disciplines can subsequently be changed again under 'Presentation\Shot\Standard\Print format'.

Presentation

All the settings that affect the images of objects in the wider sense are stored under 'Presentation'. This applies not only to representation on the screen, but also to forms of representation on the printer and other display equipment.

Shot

The directory 'Presentation\Shot' contains settings which alter the appearance of the shots. This affects not only the shot symbol but also the image in the shot window, in the list window and on the printer.

\Shot\Last Shot









In the directory 'Last shot' the settings which influence the depiction of the last represented shot are stored.

\Shot\Last Shot\Symbol

The symbol of a shot can be varied according to appearance, size and background.







\Shot\Last Shot\Symbol\Form

The form of the symbol can be preset individually for the last shot and jointly for all other shots.

Cross <i>The shot is displayed with a cross.</i>	 09907110(52)
Number <i>The shot is displayed with its shot number.</i>	 09907111(49)
None <i>The shot is not displayed.</i>	 09907112(46)
X <i>The shot is displayed with an X.</i>	 09907113(43)
Dot <i>The shot is displayed with a dot.</i>	 09907114(40)
Thin Cross <i>The shot is displayed with a thin cross.</i>	 09907115(37)
Circle <i>The shot is displayed with a cross.</i>	 99071106(17)
Calibre (Default) <i>The shot is represented in its true dimensions as a circle, as long as it is no smaller than 5 Pixel. When the dimensions are too small, the image changes automatically to a 'cross'.</i>	 99071107(14)

\Shot\Last Shot\Symbol\Size

The image size of the shot can be altered. The size is given in screen dots (Pixels). In the calibre form this setting has no effect.

14 <i>Dots</i>	 99073300(31)
16 <i>Dots</i>	 99073301(28)
18 <i>Dots</i>	 99073302(25)
20 <i>Dots</i>	 99073303(22)
22 (Default) <i>Dots</i>	 99073304(19)
24 <i>Dots</i>	 99073305(16)
26 <i>Dots</i>	 99073306(13)
28 <i>Dots</i>	 99073307(10)

30

Dots



99073308(07)

32

Dots



99073309(04)

\Shot\Last Shot\Symbol\Inverse

All symbols are primarily conceived as a white symbol on a dark background. Most targets are black in the centre. The graphics can be inverted. The symbol will then be depicted as a black symbol on a white background.

Off (Default)

The shot is represented normally.



09907140(59)

On

The shot is represented in inverse colours.



09907141(56)

\Shot\Last Shot\Last Shot Window

In the shot window alongside the shot value, the shot number and a secondary score are indicated. In order to make the representation still clearer, it can be worthwhile to omit the secondary score or the shot number. It is also possible to switch the shot window off altogether.

\Shot\Last Shot\Last Shot Window\Screen

In the shot window alongside the shot value, the shot number and a secondary score are indicated. In order to make the representation still clearer, it can be worthwhile to omit the secondary score or the shot number. It is also possible to switch the shot window off altogether.

Off

The display field for the last shot is faded out.



09907050(38)

Primary

In the shot window only the primary score is shown.



09907051(35)

SNr Prim

In the shot window the shot number and the primary score are shown.



09907052(32)

SNr Prim Sec (Default)

In the shot window the shot number, primary and secondary score (100-er score, ISSF tenner ring score) are displayed.



09907053(29)

Timer



09907054(26)

\Shot\Last Shot\Last Shot Window\Deferred Shots

On (Default)

On



99080701(41)

Off

Off



99080700(44)

\Shot\Last Shot\Display Inner ten

Most target pictures have a small ring defined which besides the normal score is valued as a particularly good hit. A hit in this ring (the inner ten, Mouche) can be displayed on the control unit by an animated picture on the target window.

Off

An inner ten (Mouche) hit is displayed as normal.



99074100(56)

On (Default)

In the event of a hit on the inner ten (Mouche) the control unit shows concentric circles of different sizes one after another several times in the centre of the target.



99074101(53)

\Shot\Standard

In the directory '\Standard' all the settings which affect the depiction of all shots except the last shot are stored.

\Shot\Standard\Symbol

The symbol of a shot can be varied according to appearance, size and background.

\Shot\Standard\Symbol\Form

The form of the symbol can be preset individually for the last shot and jointly for all other shots.

Cross

The shot is displayed with a cross.



09907030(01)

Number

The shot is displayed with its shot number.



09907031(95)

None

The shot is not displayed.



09907032(92)

X

The shot is displayed with an X.



09907033(89)

Dot

The shot is displayed with a dot.



09907034(86)

Thin Cross

The shot is displayed with a thin cross.



09907035(83)

Circle

The shot is displayed with a cross.



99070306(89)

Calibre (Default)

The shot is represented in its true dimensions as a circle, as long as it is no smaller than 5 Pixel. When the dimensions are too small, the image changes automatically to a 'cross'.



99070307(86)

\Shot\Standard\Symbol\Size

The image size of the shot can be altered. The size is given in screen dots (Pixels). In the calibre form this setting has no effect.

14

Dots






09907040(68)

16

Dots





09907041(65)

18 (Default)	
<i>Dots</i>	09907042(62)
20	
<i>Dots</i>	09907043(59)
22	
<i>Dots</i>	09907044(56)
24	
<i>Dots</i>	09907045(53)
26	
<i>Dots</i>	09907046(50)
28	
<i>Dots</i>	09907047(47)
30	
<i>Dots</i>	09907048(44)
32	
<i>Dots</i>	09907049(41)

\Shot\Standard\Symbol\Inverse




All symbols are primarily conceived as a white symbol on a dark background. Most targets are black in the centre. The graphics can be inverted. The symbol will then be depicted as a black symbol on a white background.

Off	
<i>The shot is represented normally.</i>	09907320(04)
On (Default)	
<i>In the event of a hit on the inner ten (Mouche) the control unit shows concentric circles of different sizes one after another several times in the centre of the target.</i>	09907321(01)

\Shot\Standard\Print-format

The print format dictates the image of a shot on the printout. Print formats are often prescribed directly by programs. So the printout at an international contest is laid out differently to that of a compulsory confederation practice in Switzerland.

\Shot\Standard\Print-format\Use Always

On	
	99073199(43)
Off (Default)	
	99073198(46)
Default (Default)	
<i>The printer prints the shot with shot number, direction arrow, primary and secondary score.</i>	99073100(49)

Xy

On the printer the primary and secondary score and the XY coordinates are printed out.



99073101(46)

t x/y

As well as the primary score, the time of the shot and its coordinates are displayed.



99073109(22)

Time

In the 'Time' format the time difference from the first shot of the group is always depicted.



99073108(25)

Debug

The debug format is only intended for test purposes. It supplies all the values which have been measured by the LON electronic measuring system. As well as register values the recorded temperature and other information is listed.



99073102(43)

\Shot\Standard\Screen-format

Default (Default)

The shot is displayed with shot number, direction arrow, primary and secondary score in the list window.



99070800(62)

Xy

In the list window the primary and secondary scores and the XY coordinates are displayed.



99070801(59)

t x/y

As well as the primary score, the time of the shot and its coordinates are displayed.



99070809(35)

Time

Display format 'Time' the time gap to the first shot of the current group will also be displayed.



99070808(38)

Debug

The debug format is only intended for test purposes. It supplies all the values which have been measured by the LON electronic measuring system. As well as register values the recorded temperature amongst others is listed.



99070802(56)

\Shot\Standard\Secondary Score

The secondary score can be always switched off.

Off

The secondary score is switched off.



09907120(22)

On (Default)

The secondary score is switched on.







09907121(19)

\Shot\Standard\Clear target after shots

In test and single groups the setting 'Clear target window after shots' enables the target window to be regularly cleared and so to remain clear. Thereby the shots are counted comprehensively by group. But this is only in test and single groups. In series groups all shots are shown one after another without shots being cleared in between. Consequently with the setting 10 in the following program: 'T2 S4 S4 S4' the target window is cleared after 2 shots

(because the test group has come to an end and the shoot will continue with a single group). Additionally the same action is carried out in the last 'S4' group after the second shot (because 10 shots have been used in the single groups).



<p>0 Clears the target window after twenty shots.</p>	 99078600(39)
<p>5 Clears the target window after five shots.</p>	 99078605(24)
<p>10 (Default) Clears the target window after ten shots.</p>	 99078610(09)
<p>20 Clears the target window after twenty shots.</p>	 99078620(76)

\Shot\Cross Shot

In the directory '\Cross shots' the settings which influence the depiction of cross shots (shots from another lane onto one's own target) are stored.



\Shot\Cross Shot\Show

Cross shots are indicated with a symbol in the right bottom corner of the target window. The symbol remains active for seven minutes. If the last cross shot is more than seven minutes old, then the symbol is extinguished again. Additionally in the list window an entry can be generated which draws attention to the cross shot.

<p>Off (Default) The showing of cross shots is suppressed in the list window. The first cross shot is displayed with a symbol in the target window in the bottom right corner.</p>	 09907060(08)
<p>On Cross shots are displayed in the list window with the entry 'cross shot'.</p>	 09907061(05)

\Shot\Cross Shot\Print

As well as being shown in the target window, cross shots can also be printed.



<p>Off (Default) Cross shots are not displayed on the printer. In particular if printing is done onto pre-printed sheets (federal programs, field shooting) cross shots may not influence the formatting.</p>	 09907170(66)
<p>On A cross shot is output on the printer.</p>	 09907171(63)

\Shot\Illegal Shot

In the directory '\Invalid shots' all the settings which affect the depiction of shots outside the permitted time, during the stop, pause or show phase, are stored.

\Shot\Illegal Shot\Show

Invalid shots can be displayed in the list window.

<p>Off The showing of non-allowable shots is suppressed in the list window.</p>	 99073400(22)
<p>On (Default) Invalid shots are indicated in the list window with 'Invalid Shot'.</p>	 99073401(19)

\Shot\Illegal Shot\Print

Invalid shots can be printed.

Off

Invalid shots are not printed.



99073500(13)

On (Default)

An non-allowable shot is printed out on the score sheet as 'non-allowable shot'.



99073501(10)

\Shot\Best shot

In serial groups the best shot (low shot) at the end can be shown once more and printed out in round brackets together with the shot number.

Off

The display of the best low shot is suppressed.



99079700(37)

On (Default)

The best low shot is displayed in series groups.



99079701(34)

Printing

In the directory '\Presentation\Printing' all the settings which control the printer can be changed.

\Printing\Column Configuration

For the matrix printer D93 printer paper which is perforated in the centre is available. With the column configuration the program can be set up to print out in two columns at once. The perforated paper can subsequently be separated down the middle. It should however be observed that certain shot print formats (e.g. with ISSF disciplines) cannot be placed on half of the paper. The information is cut off after 19 characters. This can lead to loss of information on the printout.

\Printing\Column Configuration\Use Always

On



99071399(11)

Off (Default)



99071398(14)

Left

The program is printed out aligned left. The full width of the paper is available.



09907130(89)

Right

The program is printed out on the right half of the paper. Only half the width of the paper is available.



09907131(86)

Double (Default)

The program is printed out twice in parallel. Only half the width of the paper is available in each case.



09907132(83)

\Printing\Print Protocol

The printing out of shots on the printer during a program can always be switched on and off with 'Print records'.

Off

The records are not printed.



99076300(52)

On (Default)

The records are printed.



99076301(49)

\Printing\Secondary Score

Although the secondary score is shown, the printout of the secondary score can be suppressed.

Off (Default)

The secondary score is not printed.



09907250(20)

On

The secondary score is printed.



09907251(17)

\Printing\Sighters

Test shots are usually printed out just like all other shots. However, in order that pre-printed score sheets are not overwritten with test shots, it is possible to block the printing out of test shots.

Off

Test shots are displayed only on the screen.



09907160(96)

On (Default)

Test shots are displayed on the printer. The exception to this is shooting programs consisting of only one test group. These shots are never printed. This was done so that pre-prepared score sheets could be sued correctly.



09907161(93)

\Printing\Subtotal

The shots of every group are counted together and the result is displayed in the list window and on the printer. It is possible to suppress these totals on the printout.

Off

Subtotals or group totals are not printed.



09907210(43)

On (Default)

Subtotals or group totals are printed.



09907211(40)

\Printing\Print Overtime

Off



99080600(53)

On (Default)



99080601(50)

\Printing\Print number of Innertens

Off (Default)



99081300(87)

On



99081301(84)

\Printing\Number of line feeds

After a program the printer should advance the paper so far that with continuous paper it can be torn off correctly on the cutting edge of the printer. With pre-printed score sheets it can happen that this paper feed must be altered. With 'Number of Empty Lines' it is possible to specify how many empty lines (paper feed) should be printed after a program.

0	
<i>Empty lines</i>	99074000(65)
1	
<i>Empty lines</i>	99074001(62)
2	
<i>Empty lines</i>	99074002(59)
3	
<i>Empty lines</i>	99074003(56)
4	
<i>Empty lines</i>	99074004(53)
5	
<i>Empty lines</i>	99074005(50)
6	
<i>Empty lines</i>	99074006(47)
7	
<i>Empty lines</i>	99074007(44)
8	
<i>Empty lines</i>	99074008(41)
9	
<i>Empty lines</i>	99074009(38)
10	
<i>Empty lines</i>	99074010(35)
11 (Default)	
<i>Empty lines</i>	99074011(32)
12	
<i>Empty lines</i>	99074012(29)
13	
<i>Empty lines</i>	99074013(26)
14	
<i>Empty lines</i>	99074014(23)

Number of line feeds

After a program the printer should advance the paper so far that with continuous paper it can be torn off correctly on the cutting edge of the printer. With pre-printed score sheets it can happen that this paper feed must be altered. With 'Number of Empty Lines' it is possible to specify how many empty lines (paper feed) should be printed after a program.



Shoot

With the settings '\Presentation\ Program' or '\Presentation\ Group' the form of depiction of expressions and readouts in the list window can be changed. But many programs have their own fixed format. These settings should only be changed in consultation with Sius AG.

\Shoot\Print

\Shoot\Print\Header

Empty



99075100(63)

Name (Default)



99075105(48)

Short



99075101(60)

Line feed



99075102(57)

\Shoot\Programed Timers

This settings determines if the programmed Timers for ISSF-Disziplines should be used or not.

Off (Default)

Disables the programmed Timers fo ISSF-Disziplines



99080800(35)

On

Activates the programmed Timers for ISSF-Disziplines



99080801(32)

Practice

With the settings '\Presentation\ Program' or '\Presentation\ Group' the form of depiction of expressions and readouts in the list window can be changed. But many programs have their own fixed format. These settings should only be changed in consultation with Sius AG.

\Practice\Print

\Practice\Print\Footer

Total (Default)



99075407(15)

Total with SeqNr



99075412(97)

Group

The directory '\Presentation\Group' contains settings which influence the behaviour of individual groups.

\Group\Reset Shot Number

If this option is selected, the shots within this group are always numbered beginning with a 1. Otherwise the shots within the whole practice are continuously numbered. Test shots are excluded from this.

Off (Default)

The shot numbers are continuously numbered in a program.



99073700(92)

On

The numbering of the shots begins again with '1' with every group.



\Group\Subtotal

The group totals in a program can be displayed in the program progress window. For completed groups the fire type and the number of shots (e.g. E2 S4) are replaced by the respective subtotals.

Off (Default)

The end of program window shows the types of fire and the active group.



On

In the program progress window the fire type of the concluded groups is replaced by the subtotal of the current group.



Other

In the directory '\Presentation\Other' can be found the settings which cannot be assigned to another group.

\Other\Control unit

Settings affecting the basic layout of the image are stored under '\Screen'.

\Other\Control unit\Layout

The image on the control unit can be adjusted to meet individual needs as far as possible.

Classic (Default)

The classic representation best meets the most frequent needs of firers.



Stop at Left

If the screen is mounted on the right hand side of the firer, it can be useful for the status notification to be visible by means of a small movement of the head. For this reason the status window in the layout 'Stop Left' was moved. In the layout 'Stop Left' the status window was omitted for reasons of space. Parameters that are represented in the status window are no longer displayed in the list window.



Final

If the screen of the control unit is to be made visible also for the spectators, the target image can be made as large as possible with the 'Final' layout. In the 'Final' layout the status window, the practice progress window and the selection window are not shown.



\Other\Control unit\Function Keys

The window with the menu keys is displayed on the LCD of the control unit and at the lower edge of the screen. In portable devices (handheld) the function key window should not be switched off because this device has no LCD.

Off

The bar with the function keys is concealed. Details of the keypad mode are only available on the LCD of the control unit.



On (Default)

The bar with the function keys is also overlaid on the screen.



\Other\Control unit\Status flashing

In order that the firer's attention can better be drawn to the screen, the most important status information (stop, offline) flashes in the status window. This effect, which can also be distracting, can be turned off with this setting.

Off (Default)

The status window will indicate no status by flashing.



99078800(21)

On

The most important information (stop, offline, show) is displayed flashing.



99078801(18)

\Other\Control unit\Practice progress window

The display of the program progress window can be suppressed.

Off

The end of program window is not displayed.



99074300(38)

On (Default)

The end of program window is displayed.



99074301(35)

\Other\Control unit\Large font in Listwindow

Specifies font used in list window.

Off (Default)

Normal font is used in list window.



99080200(89)

On

Large font is used in list window.



99080201(86)

\Other\Message

Under 'Messages' the way the control unit handles messages can be configured.

\Other\Message\Display Messages

The control unit displays various texts as reports in the list window. Many of these reports are laid out in such a way that they are also displayed on the LCD near the keyboard. With this setting these outputs can be limited.

Off

Reports are no longer displayed.



99073800(83)

On-screen

Only reports that are displayed in the list window are shown. The readouts on the LCD are suppressed. This setting is useful when the display screen is to be set up directly next to the control unit. In this situation readouts on the LCD can then be suppressed.



99073801(80)

On LCD

Only reports that are displayed in the LCD are shown. The readouts in the list window of the screen are suppressed. This setting is useful when the control unit is to be set up some distance away from the display screen. Usage is then mainly controlled via the LCD.



99073802(77)

On Both (Default)

All reports are displayed both on the LCD and in the list window of the screen.



99073803(74)

\Other\Message\Target Feed Message

The S10, the S25/50, the S101 and other targets have a materials handling (paper or rubber band feed). If the motors stall, the material runs out or the band jams, then the target reports a band feed error to the control unit. It is essential to correct this error as missing band feed can lead to incorrect measurements in the detection system. However, the display of the error message can be suppressed. This only serves a useful purpose when no targets with band feed have been installed or for test purposes, when no band is available, but the unit nonetheless needs to run in simulation mode.

Off

Reported line feed errors are suppressed.



On-screen (Default)

Reported line feed errors are only displayed in the list window of the screen.



On printer

Reported line feed errors are only printed.



On Both

Reported line feed errors are shown in the list window and printed.



\Other\Display target name

The target description and the names of the active score methods are displayed in the upper left corner of the target window.

Off

The target description and the score information are suppressed.



On (Default)

In the target window the target name and the score information are shown.



\Other\Display calibre

The calibre is displayed together with the measurement in the upper left corner of the target window. If the calibre is written inside round brackets, then in addition this means that the score is calculated as centre score. The advantage of score methods with central score is that they are independent of the calibre.

Off

The calibre information is suppressed.



On (Default)

The calibre information is displayed.



\Other\Indication

There are situations in which the firer should not be informed about the shot which has been fired. If the screen is switched off, then the shot situation is not relayed. No entry is made in the list window and no printout is produced. Only the shot number is displayed in the shot window.

Off

All displays (graphics window, list window, shot window and printer) are suppressed. The shot information is visible only on an associated PC and in the log. The function is used when statistical measurements need to be made and the firer must not be influenced by the result.



On (Default)

Images are no longer suppressed.



Parameter

Parameters are optional functions that can be turned on if desired. Parameters can be set in many ways. There are parameters that affect the image, parameters that calculate statistical values, and many more. Parameters must be switched on before a particular program is input.

MPI

The MPI (mean point of impact) calculates the mean point of impact of the last five shots and indicates this spot as coordinates in the statistics window and as a small square in the target window. The number of shots that were included in the calculation of the MPI can also optionally be displayed in the statistics window.

\MPI\Text

The text readout in the statistics window can be suppressed.

Off

Only the small square on the site of the mean hit point is indicated. The text readout in the statistics window is suppressed.



99079500(55)

On (Default)

In addition to the graphic square in the statistics window a text with direction and place details is displayed via the MPI.



99079501(52)

\MPI\MPI

The MPI can be turned on and off as a whole (graphics and text).

Off

The MPI is not calculated.



99078100(84)

On (Default)

The MPI is calculated.



99078101(81)

Simulator SCB

The SCB parameter (scoreboard) simulates the details of a scoreboard in the statistics window.

Off

The SCB is not copied.



99080100(01)

On (Default)

The scoreboard is replicated in the statistics window.



99080101(95)

Divisions

The divider is a score method which is used above all in Germany. It shows the distance of the point of entry of a shot from the centre of the target in 1/10 millimetre. The goal of a firer is to achieve the lowest possible number of dividers. The divider exists as a parameter and is displayed in the statistics window. In addition the divider values of all shots in one program are added up. The divider can be chosen as a score method in free series. In this way it is possible to select the divider as a primary or secondary score.

Off (Default)

The divider parameter in the statistics window is turned off.



99079300(73)

On

The divider parameter in the statistics window is turned on.



99079301(70)

Fi

The parameter Fi indicates the distance between the shots which are furthest apart in a group in the statistics window.

Off (Default)

The parameter Fi is not calculated.



99079100(91)

On

The parameter Fi is calculated.



99079101(88)

FiFi

The parameter FiFi indicates the distance between the shots which are furthest apart in an entire program in the statistics window. With very large numbers of shots, this parameter is very calculation intensive and the operating rate of the control unit can become noticeably slower.

Off (Default)

The parameter FiFi is not calculated.



99079200(82)

On

The parameter FiFi is calculated.



99079201(79)

Biathlon

Off (Default)



99079000(03)

On



99079001(97)

Spread

The distance between those shots which lie furthest apart horizontally is calculated and displayed in the statistics window. The distance between those shots which lie furthest apart vertically is similarly calculated and displayed.

Off (Default)

The X and Y ranges are not calculated.



99080000(10)

On

The X and Y ranges are calculated.



99080001(07)

Language

The control unit supports several languages. The language of the user guidance can be individually adjusted.

English (Default)

The menu operation is displayed in English.



99070200(19)

Deutsch

The menu operation is displayed in German.



99070201(16)

Language

The control unit supports several languages. The language of the user guidance can be individually adjusted.

English (Default)

The menu operation is displayed in English.



99070200(19)

Deutsch

The menu operation is displayed in German.



99070201(16)

Francais

The menu operation is displayed in French.



99070202(13)




<p>Español <i>The menu operation is displayed in Spanish.</i></p>	 99070207(95)
<p>Dansk <i>The menu operation is displayed in Danish.</i></p>	 99070204(07)
<p>Norsk <i>The menu operation is displayed in Norwegian.</i></p>	 99070205(04)
<p>Svenska <i>The menu operation is displayed in Swedish.</i></p>	 99070206(01)
<p>Italiano <i>The menu operation is displayed in Italian.</i></p>	 99070203(10)
<p>Russian</p>	 99070208(92)

Time

The clock time that is shown in the title bar can be set and the form of the representation can be changed.

Adjust Clock

The clock time can be set on every control unit. If several control units are connected together over a LON network, then every adjustment to the time will be relayed to all the control units. At best the time on the control unit is always synchronised with the lowest subnet number. The control unit with the lowest subnet number is therefore automatically responsible for ensuring that all the connected devices are synchronised. To ensure correct score of shots, above all when shooting takes place with a shot logoff, the correct clock time on all devices is most important.

<p>Year minus 1 <i>One year will be subtracted from the year set now.</i></p>	 99063100(76)
<p>Year plus 1 <i>One year is added to the year that is set now.</i></p>	 99063101(73)
<p>Month minus 1 <i>One month will be subtracted from the month set now.</i></p>	 99063102(70)
<p>Month plus 1 <i>One month is added to the month that is set now.</i></p>	 99063103(67)
<p>Day minus 1 <i>One day will be subtracted from the day set now.</i></p>	 99063104(64)
<p>Day plus 1 <i>One day will be added to the day set now.</i></p>	 99063105(61)
<p>Hour minus 1 <i>One hour will be subtracted from the hour set now.</i></p>	 99063106(58)
<p>Hour plus 1 <i>One hour is added to the hour that is set now.</i></p>	 99063107(55)

Minute minus 1

One minute will be subtracted from the minute set now.



99063108(52)

Minute plus 1

One minute is added to the minute that is set now.



99063109(49)

Set second zero

The selected minute starts afresh.



99063110(46)

Date format

The date format can be adjusted according to the circumstances of the country.

Short format

*The date in short format looks for example like this:
27.09 17:32*



99076900(95)

European (Default)

*The date in 'European' format looks for example like this:
27.09.2004 17:32*



99076901(92)

European with Seconds

*The date in 'European plus seconds' format looks for example like this:
27.09.2004 17:32:15*



99076902(89)

US

*The date in 'US' format looks for example like this:
09/27/2004 17:32*



99076903(86)

US+Seconds

*The date in 'US plus seconds' format looks for example like this:
09/27/2004 17:32:15*



99076904(83)

Other

The directory 'Other\Settings' contains all settings that cannot be unequivocally classified in any other category.

Start

Start settings concern the system startup (switching on) on the one hand, and variations in program start settings on the other hand.

\Start\Enable Repeat

After a program has been shot the control menu changes automatically. When the status changes to 'Stop', a new button 'Repeat' appears. There are occasions when a firer may shoot a program only once. In this case the permission for 'Repeat' must be denied.

Off

The function 'Repeat' is barred.



99077100(77)

On (Default)

The function 'Repeat' is permitted.



99077101(74)

\Start\Free series start setting

Free series are represented in the practice progress window with three open groups. The method of operation of the free series is described in the user manual. The start setting defines which of the three groups should be started.

Sighters (Default)

Every free series starts with the test group. In the practice progress window the test group T is on a white background.



99079400(64)

Shot by Shot

Alternatively a free series can also be started directly with the open single group S-.



\Start\Startup program

If a program has been selected this can be saved as a start-up program. The control unit will then in future automatically load the start-up program as long as no rebuild has been launched. User programs cannot be consigned as start-up programs. If the start-up program is saved after a user program has been loaded, in future the control unit will start up with a free series but with the right target.

Clear

If an autostart program has been saved, then this setting is erased. In future the control unit will not automatically select any program when turned on.



Save

The program that has currently been chosen will load automatically in future when the control unit is turned on.



\Start\SC-Programs

\Start\SC-Programs\Single Execution

Off (Default)



On



\Start\Scale Factor

In some situations targets have to be scaled because of shooting range reasons. For creating comparable shooting programs it is possible to resize targets in that way that other distances may be simulated. For example a 300 Meter target was resized to 2/3 to use it at 200 Meter distance. Scale Factor can now be set to 667 for using the original 300 meter target from the catalogue but shooting on smaller, nearer target on 200 meter.

Reset

Resets the scale factor to its standard value.



Scale Factor (600)



Set Scale Factor

Starts an editor for having the scale factor entered. Its value has to be between 100 and 9999 where 1000 is the standard value.



\Start\Target Alternative

Setting for special variants of programs.

Default

Default



Right

Used for Moving Mosse Exercise starting on right side instead of left side.



\Start\Enable Autoreset

Under certain conditions the resources of the control unit can become limited. This affects mainly the on hand working memory, its fragmentation and the working speed of the control unit. If certain limits are exceeded, the control unit can restart by itself and thus fix the resource shortage. This only occurs when the status of the control unit has been on 'Stop' for a long time or if the screen saver is activated. In these situations the control unit starts up again automatically.

Off

The control unit may not be restarted automatically.



99078400(57)

On (Default)

The control unit may restart automatically under certain conditions.



99078401(54)

Filter

With many filters the menu can be shortened to those items which the user finds most essential. For instance if a certain distance is selected, all other distances and the programs associated with them can be suppressed. Thus so-called filter dimensions are created (user groups, distance, category etc.). A filter dimension contains several filter characteristics. The dimension 'User Group' comprises the characteristics Standard, Advanced, Administrator and Sius. A comprehensive description of the filter options can be found in the user manual.

\Filter\Distance

All the targets and programs were organised as a first priority by distance. Target images that are used exclusively for one distance are filed accordingly. The distance filter is the most effective filter.

\Filter\Distance\Other

Targets and programs that cannot be assigned unequivocally to one distance, or that are regularly used for various distances.

Off (Default)

The filter characteristic is deactivated.



990635030400(49)

On

The filter characteristic is activated.



990635030401(46)

\Filter\Distance\10m

Targets and programs that are employed for 10 metre distance.

Off (Default)

The filter characteristic is deactivated.



990635030000(85)

On

The filter characteristic is activated.



990635030001(82)

\Filter\Distance\25m

Targets and programs that are employed for 25 metre distance.

Off (Default)

The filter characteristic is deactivated.



990635030100(76)

On

The filter characteristic is activated.



990635030101(73)

\Filter\Distance\50m

Targets and programs that are employed for 50 metre distance.

Off (Default)

The filter characteristic is deactivated.



990635030200(67)

On

The filter characteristic is activated.



990635030201(64)

\Filter\Distance\300m

Targets and programs that are employed for 300 metre distance.

Off (Default)

The filter characteristic is deactivated.



990635030300(58)

On

The filter characteristic is activated.



990635030301(55)

Reset

Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635039902(61)

\Filter\Category

Programs and targets are grouped in second priority after categories. This was with the intention that programs or a target could be assigned as far as possible to the most widespread category. This means for example that the pistol target for 50 metres is to be found under ISSF, although this target is also frequently used in Switzerland. But ISSF is a more general category than Switzerland. Therefore this target image was stored under ISSF.

\Filter\Category\Other

Programs or targets that do not fit into any other category.

Off (Default)

The filter characteristic is deactivated.



990635010800(67)

On

The filter characteristic is activated.



990635010801(64)

\Filter\Category\ISSF

Targets and programs that are regulated by the ISSF.

Off (Default)

The filter characteristic is deactivated.



990635010000(42)

On

The filter characteristic is activated.



990635010001(39)

\Filter\Category\CISM

Targets and programs that are regulated by the CISM.

Off (Default)

The filter characteristic is deactivated.



990635010100(33)

On

The filter characteristic is activated.



990635010101(30)

\Filter\Category\Hunting

Targets and programs that are used exclusively as hunting targets or hunting programs.

Off (Default)

The filter characteristic is deactivated.



990635010400(06)

On

The filter characteristic is activated.



990635010401(03)

\Filter\Category\Belgium

Targets and programs that are used almost exclusively in Belgium..

Off (Default)

The filter characteristic is deactivated.



990635011000(49)

On

The filter characteristic is activated.



990635011001(46)

\Filter\Category\Sui

Targets and programs that are used almost exclusively in Switzerland.

Off (Default)

The filter characteristic is deactivated.



990635010200(24)

On

The filter characteristic is activated.



990635010201(21)

\Filter\Category\Scandinavia

Targets and programs that are used almost exclusively in Scandinavia.

Off (Default)

The filter characteristic is deactivated.



990635010300(15)

On

The filter characteristic is activated.



990635010301(12)

\Filter\Category\Military

The category Military forms a subcategory in various regions. For example in Scandinavia public shoots and military contests are common. With the category 'Military' the targets and programs that are used exclusively for public sport are excluded.

Off (Default)

The filter characteristic is deactivated.



990635010900(58)

On

The filter characteristic is activated.



990635010901(55)

Reset

Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635019902(18)

\Filter\Weapon

Certain types of weapons are only employed for certain distances. For example air pressure weapons are employed only for 10 metres and 25 metres, and pistols are not used for 300 metres. For a setup where exclusively pistols are to be shot, all rifle targets and rifle programs can be masked by the use of a filter.

\Filter\Weapon\Other

All targets and programs that cannot be assigned to another weapon type.

Off (Default)

The filter characteristic is deactivated.



990635050400(92)

On

The filter characteristic is activated.



990635050401(89)

\Filter\Weapon\Rifle

Targets and programs that are shot exclusively with rifles.

Off (Default)

The filter characteristic is deactivated.



990635050000(31)

On

The filter characteristic is activated.



990635050001(28)

\Filter\Weapon\Pistol

Targets and programs that are shot exclusively with pistols.

Off (Default)

The filter characteristic is deactivated.



990635050100(22)

On

The filter characteristic is activated.



990635050101(19)

\Filter\Weapon\Air Rifle

Targets and programs that are shot exclusively with air rifles.

Off (Default)

The filter characteristic is deactivated.



990635050200(13)

On

The filter characteristic is activated.



990635050201(10)

\Filter\Weapon\Air Pistol

Targets and programs that are shot exclusively with air pistols.

Off (Default)

The filter characteristic is deactivated.



990635050300(04)

On

The filter characteristic is activated.



990635050301(01)

Reset

Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635059902(07)

\Filter\User Group

With the filter 'User Group' a simplified user authorisation can be adopted. Different levels of authority are assigned to the different user groups.

\Filter\User Group\Standard

A standard user can use only the normal shooting operation. He is forbidden to change settings or even to configure hardware components.

Off (Default)

The filter characteristic is deactivated.



990635040000(58)

On

The filter characteristic is activated.



990635040001(55)

\Filter\User Group\Advanced

An 'Advanced' user can amend the major settings and print out supplementary reports.

Off (Default)

The filter characteristic is deactivated.



990635040100(49)

On

The filter characteristic is activated.



990635040101(46)

\Filter\User Group\Administrator

Maintenance tasks and hardware settings can only be amended if at least one administrator is configured.

Off (Default)

The filter characteristic is deactivated.



990635040200(40)

On

The filter characteristic is activated.



990635040201(37)

\Filter\User Group\Sius

Special functions are reserved for Sius staff.

Off (Default)

The filter characteristic is deactivated.



990635040300(31)

On

The filter characteristic is activated.



990635040301(28)

Reset

Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635049902(34)

\Filter\Function

All the functions of the control unit were organised in function groups. By filtering individual function group the fields which are not needed can be masked.

\Filter\Function\Other

Functions which cannot be assigned to another function group.

Off (Default)

The filter characteristic is deactivated.



990635020200(94)

On

The filter characteristic is activated.



990635020201(91)

\Filter\Function\Logon

Functions which are needed for the identification of firer.

Off (Default)

The filter characteristic is deactivated.



990635020000(15)

On

The filter characteristic is activated.



990635020001(12)

\Filter\Function\Free Series

Functions which are needed only in free series.

Off (Default)

The filter characteristic is deactivated.



990635020100(06)

On

The filter characteristic is activated.



990635020101(03)

\Filter\Function\Programs

Functions which are needed only in free series.

Off (Default)

The filter characteristic is deactivated.



990635020300(85)

On

The filter characteristic is activated.



990635020301(82)

\Filter\Function\Firer number

When only the function 'Firer number' is permitted, but not the function 'Report', then the firer number can be retrieved but the other information about position, weapon, sight etc. remains invisible.

Off (Default)

The filter characteristic is deactivated.



990635020400(76)

On

The filter characteristic is activated.



990635020401(73)

Reset

Switch off all settings of this filter dimension and thereby deactivate filtering in this dimension.



990635029902(88)

\Filter\Mode

In contrast to the other settings, the Mode does not filter any menu functions. In previous Sius systems the mode was urgently needed so that the correct detection system would be recognised. In the control unit this information is no longer necessary. But the mode can be used as before as a lock. Every target and every program identify a particular mode. A group can only be loaded when the filter Mode is set to 'Off' or when the program mode corresponds to the set mode. This lock also functions when the target or the program are entered via barcodes. If for example the mode '300m' is selected, no further hunting images can be selected. The control unit always issues an appropriate error warning in the list window.

Off (Default)

All the programs can be selected.



99071899(63)

Air pressure weapons

Shooting mode for air pressure weapons and programs that are shot over a 10 metre distance. (Mode 2)



99071802(63)

25m

Mode for 25 metre and 50 metre small calibre and large calibre pistols as well as for small calibre rifles. (Mode 3)



99071803(60)

50m

Targets and programs that are shot from 50 metres. This concerns large and small calibre pistols and small calibre rifles as well as special Swiss groups (Morgarten). (Mode 4)










99071804(57)

300m <i>Targets and programs for 300 metre disciplines (Mode 0)</i>	 99071800(69)
Hunting <i>Hunting targets and hunting programs (Mode 1)</i>	 99071801(66)
Scandinavia <i>Scandinavian targets (Denmark, Norway, Sweden) (Mode 11)</i>	 99071811(36)
Running Target <i>Targets and programs for the running target for 10 and 50 metres (Mode 12)</i>	 99071812(33)
Biathlon <i>Targets and programs for biathlon disciplines (Mode 13)</i>	 99071813(30)

Calibre

With most targets and programs a certain calibre is implicitly assumed. With targets that are well known to be fired at with different weapons types and thus with different calibres, the most common selection options are already available. The calibre is used on the one hand for the image in the graphics window, and on the other hand certain score methods require the calibre to calculate the score. In the modern ISSF disciplines the score is calculated by means of the shot hole centre (centre score). The calibre is fixed (e.g. air pressure disciplines 4.5mm.) Even when a larger calibre is employed, these disciplines are evaluated with the calibre that was fixed. Such score methods are identified in the target window with the note 'centre score'. With older targets that are evaluated with edge score, the selected calibre has an effect on the score. Changes to this setting are therefore logged.

\Calibre\Use Always

On	 99079699(40)
Off (Default)	 99079698(43)
Off <i>All disciplines that are not assessed with a fixed given calibre are assessed with centre score.</i>	 990796000000(26)
450 <i>All disciplines that are not assessed with a fixed given calibre or with centre score are assessed with 4.5mm calibre.</i>	 990796000450(34)
560 <i>All disciplines that are not assessed with a fixed given calibre or with centre score are assessed with 5.6mm calibre.</i>	 990796000560(92)
800 <i>All disciplines that are not assessed with a fixed given calibre or with centre score are assessed with 8.0mm calibre.</i>	 990796000800(51)
900 <i>All disciplines that are not assessed with a fixed given calibre or with centre score are assessed with 9.0mm calibre.</i>	 990796000900(42)

965

All disciplines that are not assessed with a fixed given calibre or with centre score are assessed with 9.65mm calibre.



990796000965(41)

1158

1270



990796001158(44)



990796001270(96)

Control Mode

The control mode regulates various stages of the remote control. The control unit is configured so that for example it can be controlled remotely by Siusdata ®.

Local (Default)

All functions can be carried out via the keyboard or the barcode reader.



09907790(49)

Practice Control

*In certain ISSF disciplines (e.g. 3*40 rifle shoot) the control unit goes into a paused state. This state can be released with a command from SiusData ®. In this way a change of position can be ordered for a whole score.*



09907791(46)

Remote

If the control unit is totally remotely controlled, entries via the keyboard or the barcode reader are barred.



09907792(43)

Demo

The demo mode is displayed in the status window (small font). In demo mode shots can be created via the insert key ('Ins'). The control unit requests the connected target to create a shot at a chance coordinate and to send this back to the control unit. The demo shot implicitly tests both the connected target and the communication. Demo mode is switched off every time at startup.

Off (Default)

Turns off the demo mode.



09907000(91)

On

Selects demo mode.



09907001(88)

Activate remote barcode

This command sets the CU in the remote barcode mode. While activated all Barcodes from the connected Barcodereader will be sent to the specified Lane. To change the selected lane press the specified keys on the keyboard, to exit remotebarcode mode press escape. The configuration of the key-lane selection can be downloaded from siusdata, default setting is



099067(07)

Demonstration Mode



099068(04)

Settings Control

It is possible to store one's own setting configurations in the permanent memory of a control unit. These customer settings will not be lost even with a change of battery. Even during a 'cold start' these settings will not be overwritten by

the factory settings. So it can be guaranteed that your own settings can also be selected as standard. The settings will only be lost if a new software version is loaded. It is possible to save these settings as a file on a computer and with SiusData to load them via the LON network onto all connected control units. Warm start: A warm start is triggered by a short power failure or by the explicit command '\Maintenance\Warm-Start'. The current settings are preserved during a warm start. Cold start: A cold start can be forced if during boot-up the cold start button is pressed (above the two 1mm drillholes on the back of the control unit, on the right near the control unit socket). The control unit confirms the cold start with a beep. A cold start is also necessary if the memory content is lost due to too little battery power during an electricity failure. The control unit announces this process with the message 'crc-Failed'. In a cold start the user settings that were most recently saved are always loaded. The devices are supplied with various user settings. In particular the filters are preconfigured for the customer.

Factory Settings

With the command 'Factory Settings' all settings in the volatile memory are reset to the factory settings. The customer settings are stored. In the event of a system 'cold start' the customer settings are also reloaded with this command. In order for the factory settings to be selected as the standard settings after a 'cold start', they must be saved as customer settings following this command.



09903601(06)

Customer Settings

All settings that were changed during the current operation are reset to the customer settings. The same occurs if a cold start takes place on the control unit, or if the buffer battery is changed.



09903612(70)

Save Customer Settings

The settings in current use are saved as customer settings. This process writes data from the volatile memory into the non-volatile memory. The process only lasts a few seconds but it is very important that it is carried out completely as otherwise the control unit can be damaged. If the process is not carried out completely, it can happen that the control unit will no longer start after the next interruption to the power supply. In this event the software would have to be reinstalled. The control unit must not be switched off during the memory process. The power supply must not be interrupted. The conclusion of the memory process is signalled with a beep.



09903613(67)

Maintenance

The directory '\Maintenance' contains functions which go beyond daily use. Diagnosis, upkeep and error searches are supported through various start points. These functions should be carried out only by well trained staff.

Reports

Expanded reports are listed under '\Maintenance\Reports'. Also kept here are the functions which are available for erasing the data belonging to these reports and so to set the corresponding report to zero. For example the log can be deleted or the software shot counter can be reset to zero.

Settings

Printing out settings:

Print

Prints out a list of the current settings that differ from the factory settings. In addition the shaft settings of the target images and the filter configurations are listed, insofar as these differ from the factory settings.



09903602(03)

Shoot

Many settings are taken over into a program when the program is launched. Additionally a program use



09903610(76)

of additional settings that were stored when the program was being developed. The command '\Settings\Program' prints all the settings of the actively selected program.

Shot Counter

Mechanical shot counters:

The optional mechanical shot counter only counts the shots on your own target. It cannot be reset. Demo shots or inserted no scores are not counted. A detailed description of the whole function can be found in the user manual under 'Mechanical shot counters'.

Software shot counters:

The software shot counter counts shots in different categories. Own shots, cross shots, missed shots, demo shots etc. are differentiated and displayed separately. The shot count report is displayed in the list window and provided a printer is connected and switched on, is printed out. The shot counters are connected to the control units. If the settings are reset to factory settings, the shot counts are also reset to zero. The same occurs when the battery has to be changed. With a normal interruption to the power supply, the values are not lost. The software shot counters can also be reset independently of the settings under 'Maintenance\Reports\Shot Counters'.

Reset Shot Counter

Resets the software shot counter back to zero.



09903609(79)

Invalid shots

Non-allowable shots (shots during the Stop, Pause or the Show Phase and cross shots) are not only counted, they are kept in the control unit as pending and can be queried at any time. The shots are then shown with the time and if possible with the score. With a warm start or with the command 'Erase' under 'Maintenance\Invalid Shots' the report can be rejected. The shots remain in the log throughout and furthermore can be documented in a log printout.

Clear

The report on the latest cross shots and illegal shots is erased.



990560(12)

Log

Events that are of relevance for the duration of a program are filed in the memory (events memory, log). This information is needed to be able to reproduce a program after a power interruption. The CU931 investigates this data at every system start-up. If it is established that the last program to be shot was not correctly ended, then a repetition process is introduced. By means of the log past programs can also be reloaded or a copy can be printed once again. The log is stored in the volatile memory of the control unit, which is buffered with a battery. The data is protected from misinterpretation by a check sum. If the check sum is not correct at system start-up, for example due to a faulty battery, the log is initialised again. The control unit communicates this by a triple beep and a report in the list window. The log is restricted in memory size. In the event of an overload, the oldest events are overwritten by the most recent on a rolling basis. Typically more than ten programs can be stored in the log. The log can also be manually erased under 'Maintenance\Reports\Log'. The format of the printout is described in the user manual.

Clear

The log memory is explicitly wiped. Because this means that previous programs are irretrievably erased, this command must be authorised by a further confirmation.

Confirm



099057(37)

Log Hex

The 'Log-Hex' is an expanded log printout which prints out all events additionally in hexadecimal form. This printout allows events to be analysed at a very detailed level. The printout is exclusively used to search for software errors.



990559(15)

Debug

With the 'Debug' reports internal conditions of the control unit can be displayed. This report permits a diagnosis of the control unit in respect of the demand, the speed of operation or the load. They serve to enable the speed and

reliability of the devices to be optimised.

Report Processes

Reports the number of runs as well as the time taken by the individual processes.



09903611(73)

Classes

Prints a report that indicates for each class how many instances are presently available, how often the designer has been contacted and how high the greatest occurrence of the class was in the past.



09903605(91)

Self Test

Hardware components can be tested by some special commands. These tests are normally used to fulfill the final check of a new installation.

They can be used to filter an erroneous function while the system is running.

Shot Counter

The mechanical shot counter can be made to start counting by a self test. The chosen number triggers the corresponding number of counting pulses. Thus the fastest possible meter pulse rate can be selected. The mechanical counter cannot skip any of these pulses.

1

Counting impulse(s) on the mechanical shot counters



99035121(11)

2

Counting impulse(s) on the mechanical shot counters



99035122(08)

3

Counting impulse(s) on the mechanical shot counters



99035123(05)

4

Counting impulse(s) on the mechanical shot counters



99035124(02)

5

Counting impulse(s) on the mechanical shot counters



99035125(96)

6

Counting impulse(s) on the mechanical shot counters



99035126(93)

7

Counting impulse(s) on the mechanical shot counters



99035127(90)

8

Counting impulse(s) on the mechanical shot counters



99035128(87)

9

Counting impulse(s) on the mechanical shot counters



99035129(84)

Target test

The target test requests the most important status information from the LON electronic measuring system. Along with the software and hardware version, the temperature, the assembly alignment and the Target Index Code are conveyed. The running time of the enquiry indirectly provides information on how well synchronised the equipment is with respect to time. The target test can be used to test the network cabling to the LON electronic



99063300(58)

measuring system and the functioning of the communication chips on the control unit and the LON electronic measuring system. The target test only functions if a LON electronic measuring system is connected and linked to the control unit via the correct subnet (please refer to '\Hardware\Target\Connections').

Keyboard

The keyboard test switches the control unit into a special keyboard test mode. Every keystroke is confirmed by an entry in the list window. Hitting the Escape key permits this keyboard test to be exited.



09903505(03)

Scoreboard

The scoreboard itself has a test program available. This test program can be started from the control unit on its own scoreboard (subnet Addressing must be in agreement).



09903508(91)

Beep

The beep test issues a series of ten short beeps one after another. They must be acoustically audible from the control unit.



09903511(82)

Control unit reset

With a warm start the control unit is forced to start up again (reboot process). This corresponds to the same process as when the control unit is turned on without power for a short time. (see also '\Settings\Setting controls')

Confirm



09903600(09)

Debug

Functions that serve only for error detection are stored under '\Maintenance\Debug'.

Debug Mode

The debug mode allows all events which are being processed in the control unit also to be represented visually. This representation permits a precise search for errors. In the case of reproducible error, it can happen that you will be instructed by Sius colleagues to turn on this debug mode, so that the printout can subsequently be analysed and the error can thereby be controlled.

Off (Default)

The events processed by the control unit are not displayed.



99070700(71)

On

The events processed by the control unit are displayed in the list window.



99070701(68)

Print

The events processed by the control unit are displayed in the list window and additionally on the connected printer.



99070702(65)

Trap

This function is only used for errors that are very difficult to reproduce. In the software versions that are specially produced for this, an 'error case' can be programmed in. At the moment when the error is recognised, a special response can be triggered. Mostly the debug mode is activated as a special treatment.

Off (Default)

The control unit operates without special error recognition.



99078200(75)

On
The special treatment is activated.



Hardware

Settings that directly affect the hardware components of the control unit are stored under '\Hardware'. Some of these components are optionally available for the equipment and only have an effect when these components are running.

SCB

SCB

Communication to the scoreboard can be basically suppressed. Communication reduces the speed of execution of the control unit by several percent. It is therefore worthwhile to configure the SCB as 'Off' when it is not present. Communication to the SCB must be switched on before a program is loaded.

Off (Default)
The SCB is not responded to.



On
The SCB is responded to.



Control unit

'\Screen' contains several hardware settings that directly affect the control unit.

Set Subnet

Sius AG devices communicate with one another via the field bus LON. Each device has its own address. One part of this address is the so-called subnet. The LON electronic measuring system and the control unit with the same subnet always belong together. Different lanes must be correspondingly differentiated in the subnet. Every LON electronic measuring system sends its own detected shots to the control unit in the same subnet in which it is itself addressed. A LON electronic measuring system with subnet 5 sends its shots to the control unit with subnet 5. By setting a subnet on a control unit only the address of the control unit is affected. A previously linked LON electronic measuring system must be reconnected after this alteration (please refer to '\Hardware\Target\Connect' and instructions for use).

Insofar as a LON electronic measuring system is located in the same subnet, the status of the control unit changes from 'Offline' to 'Stop' or 'Ready' according to whether a program is selected or not.

The subnet can be selected via the 10-er keyboard. Pressing the Enter key confirms a given value. With 'Esc' the entry can be cancelled. The F5 key allows incorrect entries to be corrected in time.

\Set Subnet\1..9

1 (Default)



2



3



4



5



6



7



9907270007(40)

8



9907270008(37)

9



9907270009(34)

\Set Subnet\10..19

10



9907270010(31)

11



9907270011(28)

12



9907270012(25)

13



9907270013(22)

14



9907270014(19)

15



9907270015(16)

16



9907270016(13)

17



9907270017(10)

18



9907270018(07)

19



9907270019(04)

\Set Subnet\20..29

20



9907270020(01)

21










9907270021(95)











22













9907270022(92)

23	 9907270023(89)
24	 9907270024(86)
25	 9907270025(83)
26	 9907270026(80)
27	 9907270027(77)
28	 9907270028(74)
29	 9907270029(71)







\Set Subnet\30..39

30	 9907270030(68)
31	 9907270031(65)
32	 9907270032(62)
33	 9907270033(59)
34	 9907270034(56)
35	 9907270035(53)
36	 9907270036(50)
37	 9907270037(47)
38	 9907270038(44)
39	 9907270039(41)

\Set Subnet\40..49

40	 9907270040(38)
41	 9907270041(35)
42	 9907270042(32)
43	 9907270043(29)
44	 9907270044(26)
45	 9907270045(23)
46	 9907270046(20)
47	 9907270047(17)
48	 9907270048(14)
49	 9907270049(11)

\Set Subnet\50..59

50	 9907270050(08)
51	 9907270051(05)
52	 9907270052(02)
53	 9907270053(96)
54	 9907270054(93)
55	 9907270055(90)

56



9907270056(87)

57



9907270057(84)

58



9907270058(81)

59



9907270059(78)

\Set Subnet\60..69

60



9907270060(75)

61



9907270061(72)

62



9907270062(69)

63



9907270063(66)

64



9907270064(63)

65



9907270065(60)

66



9907270066(57)

67



9907270067(54)

68



9907270068(51)

69



9907270069(48)

\Set Subnet\70..79

70



9907270070(45)









71



9907270071(42)

72	 9907270072(39)
73	 9907270073(36)
74	 9907270074(33)
75	 9907270075(30)
76	 9907270076(27)
77	 9907270077(24)
78	 9907270078(21)
79	 9907270079(18)

\Set Subnet\80..89

80	 9907270080(15)
81	 9907270081(12)
82	 9907270082(09)
83	 9907270083(06)
84	 9907270084(03)
85	 9907270085(97)
86	 9907270086(94)
87	 9907270087(91)
88	 9907270088(88)

89



9907270089(85)

\Set Subnet\90..99

90



9907270090(82)

91



9907270091(79)

92



9907270092(76)

93



9907270093(73)

94



9907270094(70)

95



9907270095(67)

96



9907270096(64)

97



9907270097(61)

98



9907270098(58)

99



9907270099(55)

DeltaX

The absolute point of entry can be shifted in the horizontal direction. This can be used to compensate for assembly inaccuracies.

X-0.1mm
to the left



99072800(76)

X+0.1mm
to the right



99072801(73)

X-1mm
to the left



99072802(70)

X+1mm
to the right



99072803(67)

X-10mm
to the left



99072804(64)

X+10mm
to the right



DeltaY

The absolute point of entry can be shifted in the vertical direction. This can be used to compensate for assembly inaccuracies.

Y-0.1mm
downwards



Y+0.1mm
upwards



Y-1mm
downwards



Y+1mm
upwards



Y-10mm
downwards



Y+10mm
upwards



Menu

The keyboard menu can be switched off. This is especially helpful when the configuration is to be used only via the barcode reader. The barcode reader offers the advantage that the commands and programs permitted for the user can be compiled on one sheet of paper.

Off

The keyboard menu is suppressed. Use of the equipment is possible only via a barcode reader or a central computer.



On (Default)

The keyboard menu is switched on again. If the menu is switched off, it can no longer be switched on via the keyboard. Normally it must be switched on again by a barcode, from a central computer or by means of a cold start. A further possibility is to switch the menu on again by the code '282806'. The code must be entered in one go on the transparency keyboard. For this reason it should be made available only to experienced persons.



Keystroke

Escape




















Opt



Help



Next Window	 9906442004(73)
Enter	 9906442005(70)
Zoom	 9906442006(67)
Menu	 9906442007(64)
Match	 9906442008(61)
Backspace	 9906442009(58)
F1	 9906441001(75)
F2	 9906441002(72)
F3	 9906441003(69)
F4	 9906441004(66)
F5	 9906441005(63)
Right	 9906443001(89)
Up	 9906443002(86)
Left	 9906443003(83)
Down	 9906443004(80)
Home	 9906443005(77)
End	 9906443006(74)

Page Up	
	9906443007(71)
Page Down	
	9906443008(68)
Insert	
	9906443009(65)
0 (Default)	
	9906440000(71)
1	
	9906440001(68)
2	
	9906440002(65)
3	
	9906440003(62)
4	
	9906440004(59)
5	
	9906440005(56)
6	
	9906440006(53)
7	
	9906440007(50)
8	
	9906440008(47)
9	
	9906440009(44)

Set Subnet

Sius AG devices communicate with one another via the field bus LON. Each device has its own address. One part of this address is the so-called subnet. The LON electronic measuring system and the control unit with the same subnet always belong together. Different lanes must be correspondingly differentiated in the subnet. Every LON electronic measuring system sends its own detected shots to the control unit in the same subnet in which it is itself addressed. A LON electronic measuring system with subnet 5 sends its shots to the control unit with subnet 5. By setting a subnet on a control unit only the address of the control unit is affected. A previously linked LON electronic measuring system must be reconnected after this alteration (please refer to 'Hardware\Target\Connect' and instructions for use.



Insofar as a LON electronic measuring system is located in the same subnet, the status of the control unit changes from 'Offline' to 'Stop' or 'Ready' according to whether a program is selected or not. The subnet can be selected via the 10-er keyboard. Pressing the Enter key confirms a given value. With 'Esc' the entry can be cancelled. The F5 key allows incorrect entries to be corrected in time.

RC92

Optionally a RC92 (shoot box) can be connected to a control unit. The RC92 is controlled by means of three buttons (Zoom, Menu and Shoot).

Match Menu

Via the Menu button an additional window can be opened on the screen. This window lists all the functions available in the Control Menu. In this way the control unit can be remotely controlled by the firer without having to leave his position.

In official ISSF contests the firer is not permitted to carry out these functions himself. It must therefore be possible to switch off the Shoot Menu.

Off

The match menu is switched off. The Match button on the RC92 has no function.



99079900(19)

On

The match menu is switched on.



99079901(16)

Short format

Only a reduced number of functions is available (Clear Graphics).



99079902(13)

Target

Settings that must be communicated to the LON electronic measuring system are stored under '\Target'. These settings are also frequently dependent on the program selected and therefore can be overwritten if necessary.

Target changer

Some detection systems are equipped with a target changer (S101, S310). Each target image has been programmed with a basic setting or a shaft. If a program with a specific target is selected, the preselected shaft is automatically activated. If the detection system is not equipped with a changing mechanism, the command is ignored. If the target image is mounted in a different shaft or if the target image on the control unit does not correspond to the physical target image, the shaft can be changed by means of the target changer commands. The target image is hereby automatically programmed for the new choice of shaft. If the same program is selected again later, the latest shaft to be selected will again be selected in any case.

A (Default)

The 'shaft' A corresponds to the fixed frame of the detection system.



09907190(06)

B

The shaft B is the alternative frame.



09907191(03)

C

With the target S101 there are two alternative frames available. The shaft C is the second alternative frame.



09907192(97)

Paper feed

After every shot, detection systems controlling a materials handling unit (paper or rubber tape) trigger an automatic feed unit. The feed unit is measured in millimetres. Depending on the discipline and the weapon, the tape must be fed a greater or lesser distance. These distances are laid down in the target images. But every discipline can define its own actual setting values. The tape feed for a 10 metre discipline is 20 millimetres. In ISSF finals the feed distance is increased to 30 millimetres. The tape feed can be changed after a program has been selected.

\Paper feed\Use Always

On



99077899(08)

Off (Default)



99077898(11)

0

mm



99077800(14)

1

mm



99077801(11)

2

mm



99077802(08)

3

mm



99077803(05)

4

mm



99077804(02)

5

mm



99077805(96)

10

mm



99077810(81)

20 (Default)

mm



99077820(51)

30

mm



99077830(21)

40

mm



99077840(88)

50

mm



99077850(58)

Target Lifter

Standing



09906910(70)

Prone



09906911(67)

Kneeling



09906912(64)

Reference Calibration



09906919(43)

Connect

This barcode switches the control unit over to a special configuration mode. The control unit waits for a service PIN message from any LON electronic measuring system. This message can be created on the LON electronic measuring system, either when the service PIN is pressed or when shooting takes place. But a shot triggers a Service PIN message only if the LON electronic measuring system was not previously configured. Every LON electronic measuring system that first reports this Service PIN message is reprogrammed by the control unit to its own subnet address. This function is used only if the LON electronic measuring system does not have its own LNR (lane number box).



99063200(67)

Light

On



9906920000(36)

Off



9906921000(43)

Brighter



9906922000(50)

Darker



9906923000(57)

Set intensity



9906924000(64)

Distance Index

0 (Default)



99081200(96)

1



99081201(93)

2



99081202(90)

3



99081203(87)

4



99081204(84)

Sensitivity

The detection systems are fitted with various amplifier settings for the microphone. For most systems and weapons a low sensitivity is the correct setting. In the 25 metre rapid fire pistols with a very small recoil are used.

The speed of the projectile is correspondingly small and the impact on the rubber very light. For these disciplines a high sensitivity is necessary so that the shot can always be correctly picked up. But the setting must be set to high only in these disciplines because with other firearms otherwise crosstalk onto neighbouring lines could ensue. The setting is normally correctly adjusted for the programs and must not be adjusted manually.

\Sensitivity\Use Always

On



99072099(45)

Off (Default)



99072098(48)

Low (Default)

Low sensitivity is required for most bullets.



09907200(73)

High

High sensitivity is needed above all for sport shooting (25m), which is shot with high recoil weapons, typically on targets S10 and S25/50



09907201(70)

Time Control Unit

Time Control Unit

Off (Default)



99080300(80)

On



99080301(77)

Duel mode

Off (Default)



99080400(71)

On



99080401(68)

Graphic Printer Model

Undefined Printer (Default)



99080500(62)

D931-SP



99080501(59)

D931



99080502(56)

iDP3240



99080503(53)

Shot sensor

The shot sensor allows cross shots and no scores to be detected. Without the shot sensor all shots are interpreted as

own shots on the own target. Even a shot from a neighbouring lane onto the own target is interpreted as an own shot and included in the calculation of the results. With the shot sensor, within a certain timescale after the Shot Off signal the corresponding Shot On signal must be produced. If only a Shot Off signal is produced, the firer has not hit the target. The shot sensor can be connected to the control unit as an optional extra. At the moment when the control unit recognises the shot sensor, it switches this on automatically. If the shot sensor is removed, the control unit recognises this after a short period of time and automatically switches the shot sensor off again.

Off

On installations without a shot logoff, this setting will be switched off automatically. It is possible to switch off the shot logoff manually even though it is connected.



09907010(61)

On (Default)

The setting shot logoff ON is automatically cancelled if no shot logoff is connected.



09907011(58)

Logon

In order that the system can adhere to the necessary rules, under certain circumstances particular information about the firer and his weapon is needed. All this information can be recorded under the section 'Registration'.

Info

Requirements

With set assumptions the system requires information about weapon, position and/or firer number before a group can be loaded. As long as this information is missing the group cannot be input.

Legalisation

If a legalisation unequal to 0 is chosen, then both the practice and the firer must produce the same legalisation in their codes in order for it to be authorised. The legalisation of the firer is however only active if the firer number is requested at the same time. This command is not to be confused with the command firer legalisation, under which the legalisation of the firer can explicitly be provided. Fact: the settings '\Requirements\Legalisation' and '\Register\Legalisation' must agree or one or other must be set to 0 in order that a program can be started and shooting can take place.

0 (Default)

No legalisation is required.



99077000(86)

1

Demanded legalisation



99077001(83)

2

Demanded legalisation



99077002(80)

3

Demanded legalisation



99077003(77)

4

Demanded legalisation



99077004(74)

5

Demanded legalisation



99077005(71)

6

Demanded legalisation



99077006(68)

7

Demanded legalisation



99077007(65)

8

Demanded legalisation



99077008(62)

9

Demanded legalisation



99077009(59)

Weapon required

In order that in contests it can be determined which program was shot with which weapon, it is possible to force the setting 'Position required'. Before a program can be loaded, a weapon type must be declared.

Off (Default)

Weapon identification is optional.



99077300(59)

On

A weapon specification must be input before a program can be selected.



99077301(66)

Position required

In order that in contests it can be determined which program was shot in which position, it is possible to force the setting 'Position required'. Before a program can be loaded, a position must be declared.

Off (Default)

Reporting of position is optional.



99077200(68)

On

A position report must be input before a program can be selected.



99077201(65)

Firer number required

The firer number identifies the firer (see also '\Registering\Firer number'.

Off (Default)

The firer number is optional.



99077400(50)

On

A firer number must be input before a program can be selected.



99077401(47)

Legalisation

Legalisation can be loaded either individually or together with a firer number practice code. The firer must as a result input his firer number first (inclusive of legalisation) and then a program. Only when both legalisations agree, or one or other has a zero value, can the program be launched. Otherwise the screen gives the error message 'Wrong legalisation'. A firer in possession of the legalisation 0 in his practice code can shoot all programs, and a program that shows a legalisation 0 can be shot by all firers.

0 (Default)

Legalisation of the firer



99077700(23)

1

Legalisation of the firer



99077701(20)

2

Legalisation of the firer



99077702(17)

3

Legalisation of the firer



99077703(14)

4

Legalisation of the firer



99077704(11)

5

Legalisation of the firer



99077705(08)

6

Legalisation of the firer



99077706(05)

7

Legalisation of the firer



99077707(02)

8
Legalisation of the firer



9
Legalisation of the firer



Weapon Type

For the assessment of a contest, it can be important that the type of weapon used in a program that has been shot is known, for example if various rank listings are to be established for storm rifle 90 and storm rifle 57. In such a case the weapon type can be set. With the setting '\Requirements\Weapon type' the specification of a weapon type can be insisted upon before a program can be installed. Otherwise the program would be declined with a message 'weapon type needed'. The weapon type selected is displayed on the screen and on the paper printout.

Off (Default)



Rifle



Free Rifle



Carbine



Stgw 57



Stgw 90



Free Pistol



Sport Pistol



Sport Pistol Big Bore



Sport Pistol Small Bore



Ordnance pistol



Ordnance pistol 75



Position

For the assessment of a contest, it can be important that the position in which shooting took place is known. In such a case the position can be input either on the menu or via a barcode. With the setting '\Requirements\Position' the specification of a position can be insisted upon before a program can be installed. The position selected is displayed on the screen and on the paper printout.

Off (Default)



99077600(32)

Prone



99077601(29)

Prone supported



99077604(20)

Kneeling



99077603(23)

Standing



99077602(26)

Firer number



99063900(04)

The firer number identifies the firer. The firer number can also be loaded via a barcode (Sius barcode inclusive of legalisation or SSV licence card) or via the keyboard. The firer number is transferred to the central processor. From the central processor the name of the firer can be construed from the firer number. The firer number is displayed on the screen and on the printer.

Should the setting 'Firer number needed' be activated and 'Repeat allowed' be switched off, then the firer number is erased after each program. This ensures that with this configuration before every program a firer number must be introduced.

SIUS

Shortcuts

1		
10	Moose	32, 33
15FP	15m fripistol	20
15FP	15m fripistol F	20
15mP	15m pistol	20
15mP	15m pistol F	20
2		
2x30	Rifle 2x30	48, 50
3		
3*10	Air Rifle 3*10	46
3*10	Rifle 3*10	46
3*20	50ft Rifle 3x20	60
3*20	Air Rifle 3*20	60
3*20	C200 3x20	60
3*20	Standard Rifle 3*20	60
3*40	50ft Rifle 3x40	60
3*40	Air Rifle 3*40	60
3*40	Free Rifle 3*40	60
30	Rifle 30	50
3xFi	3 Positions Final	47
5		
5	Moose 5-5-4-3	32, 33
6		
60	C200 60	60
60	Free Rifle 60	60
60	Rifle 60	60
600	Scale Factor (600)	89
A		
A1	MG Ziel A1	28
A10	Precision	5, 27, 36, 38, 63
A101	A10 100m	21
A102	A10 200m	22
A103	A10 300m	22
A10m	Pistol A 10m	22, 61
A10m	Rifle A 10m vertical	22, 61
A2	MG Ziel A2	28
A20m	Rifle A 20m vertical	24, 62
A3	MG Ziel A3	28
A4	MG Ziel A4	28
A5	MG Ziel A5	28
A-5m	Pistol A 5m	22, 61
A6	MG Ziel A6	29
A7	MG Ziel A7	29
A8	MG Ziel A8	29
Abrt	Abort	67
Act	MPI	85
Act	SCB	85
AdjC	Adjust Clock	87
Admn	Administrator	94
Advn	Advanced	94
Air	Air pressure weapons	95
Allo	Allowable	67
AP20	Air Pistol 20	46
AP30	Air Pistol 30	46
AP40	Air Pistol 40	45
AP60	Air Pistol 60	45
APis	Air Pistol	2, 93
APis	Air Pistol 10	2, 93
AR20	Air Rifle 20	46
AR30	Air Rifle 30	46
AR40	Air Rifle 40	45
AR60	Air Rifle 60	45
ARif	Air Rifle	2, 93
ARif	Air Rifle 10	2, 93
ATE	Target Lifter	113
AUT	Austria	22, 60
Auto	Startup program	89
B		
B1	Bersaglio 1	21
B1	MG Ziel B1	21
B10m	Pistol B 10m	22, 61
B10m	Rifle B 10m horizontal	22, 61
B2	Bersaglio 2	21
B2	MG Ziel B2	21
B20m	Rifle B 20m horizontal	24, 62
B3	Bersaglio 9	21
B3	MG Ziel B3	21
B4	MG Ziel B4	30
B5	MG Ziel B5	30
B-5m	Pistol B 5m	22, 61
B6	MG Ziel B6	30
B7	MG Ziel B7	30
B8	MG Ziel B8	30
BesS	Best shot	78
BFrn	Bear	34

SIUS

Shortcuts

Biat	Biathlon	3, 10, 45, 48, 96	Cntr	Control	65
BigB	Big Bore	9	Comp	Compute series	67
BLft	Bear Left	34	ConB	Convert both sighters	67
BO10	Rifle B 10m ellipse	24, 62	Conf	Confirm	99, 101
BO20	Rifle B 20m ellipse	24, 62	ConL	Convert last sighting shot	67
Boar	Wild Boar 2	34	Crcl	Circle	72, 74
Boar	Wild Boar 5	34	CroA	Croatian AR Target	4
Boar	Wild Boar 5 Right	34	Cros	Cross	72, 74
Both	On Both	83, 84	CrSh	Cross Shot	77
Brcd	Edit Barcode	68	CtMo	Control Mode	97
BRgt	Bear Right	34	CtmS	Customer Settings	98

C

C1	MG Ziel C1	30
C15m	Pistol C 15m	23
C15m	Rifle C 15m	23
C2	MG Ziel C2	31
C3	MG Ziel C3	31
C30m	Rifle C 30m	25, 63
C4	MG Ziel C4	31
C5	MG Ziel C5	31
C6	MG Ziel C6	31
C7	MG Ziel C7	31
C-7m	Pistol C 7m	23
C8	MG Ziel C8	31
Cal	Calibre	72, 74, 96
Cal	Display calibre	72, 74, 96
Cal	Reference Calibration	72, 74, 96
Calf	Moose Calf	32, 33
CAI	Pistol C All	23
CAI	Rifle C All	23
Carb	Carbine	119
Catg	Category	91
CFP	Center Fire Pistol	47
CGaS	Clear target after shots	77
Cham	Chamois	35
Chmp	Swedish championship	59
Clas	Classic	25, 82
Clck	Time	87
Clmn	Column Configuration	78
Clr	Clear	89, 99
ClrG	Clear target window	67
ClrL	Clear List	67
Clss	Classes	100
Cmbn	Combined	52, 54, 56
Cmpl	Complete	50
Cnct	Connect	114

CU	Control unit	82, 102
CU	On-screen	82, 102
CURs	Control unit reset	101

D

D100	DFS100	14, 44
D10m	Pistol D 10m	23, 61
D15m	DFS 15m	14, 44
D200	DFS 200	14, 44
D300	DFS 300	15
D40m	Rifle D 40m	25
D-5m	Pistol D 5m	23, 61
DAI	Rifle D All	25
DAN	Dansk	87
Dans	Danmark	18
Dans	Final	18
Dbl	Double	33, 59, 78
DDSR	15m riffel 1984	19
DDSR	15m riffel 1984 F	19
Dbg	Debug	76, 100, 101
Dbg	Debug Mode	76, 100, 101
Defe	Deferred Shots	73
DeMo	Demonstration Mode	97
Dflt	Default	75, 76, 89
Dfrd	Deferred	51, 53, 56, 66
DisF	Screen-format	76
Disp	Screen	73
Dist	Distance	90
Dist	Distance Index	90
Divi	Divisions	4, 11, 85
DSkR	15m riffel DSKyU 1982	20
DSkR	15m riffel DSKyU 1982 F	20
D-SP	D931-SP	115
Duel	Duel mode	115

E

SIUS

Shortcuts

E20m	Pistol E 20m	23
EAll	Pistol E All	23
Emty	Empty	81
EnAR	Enable Autoreset	90
ENG	English	86
ERpt	Enable Repeat	88
ESP	Español	87
Euro	European	88
EurS	European with Seconds	88

F

FacS	Factory Settings	98
FB	Full Bore	38, 60
FB	Norway	38, 60
Fig1	Full Figure	37, 63
Fig2	Half Figure	37, 63
Fig3	One Third Figure	37, 63
Fig8	Eighth figure	37, 63
Fill	Fill Series	66
FldA	Field A	51
FldB	Field B	51
FldD	Field D	51
Fltr	Filter	90
Fnal	Final	3, 6, 18, 59, 82
FncK	Function Keys	82
Foot	Footer	81
FRA	Francais	86
Free	Free Rifle	119
Free	Free Series	119
Free	Free series start setting	119
FRes	Final reserved	59
Frmt	Date format	88
FrNo	Firer number	95, 120
FrNo	Firer number required	95, 120
Frst	First relay	59
Func	Function	94

G

GC	Group championship	50
GER	Deutsch	86
GrGr	Gross Gross	27
GrKl	Gross Klein	27
GrLi	Gross links	26
Grp	Group	81
GrRe	Gross rechts	26

H

H-	Hour minus 1	87
H+	Hour plus 1	87
Head	Header	81
hGms	Chamois Hubertus	36
Hnt	Belgium	15, 92
Hnt	Hunting	15, 92
HrdC	Print screen	66
HrdW	Hardware	102
hRoe	Roe Left	36
Hwal	Hans Waldmann Schiessen	58

I

IDP3	iDP3240	115
Ilgl	Illegal Shot	77
IncS	Include sighters	52, 53, 54, 57
Indi	Indication	84
Ins0	Insert zero shot	67
InTn	Display Inner ten	73
Invr	Inverse	71, 73, 75
InvS	Invalid shots	70, 99
ISSF	(Rings)ISSF Boar	49
ISSF	ISSF Boar	49
ITA	Italiano	87

K

KIGr	Klein Gross	26
KIKl	Klein Klein	26
KILi	Klein links	26
KIRe	Klein rechts	26
Knbn	Knabenschiessen	58
Knee	Kneeling	113, 120
Kybd	Keyboard	101

L

Lang	Language	86
Layt	Layout	82
LCD	On LCD	83
Legl	Legalisation	117, 118
LFed	Line feed	81
LfLw	Large font in Listwindow	83
Locl	Local	97
LogH	Log Hex	99
Logn	Logon	94, 117

SIUS

Shortcuts

LSht	Last Shot	71
LSW	Last Shot Window	73

M

M1	2x1/3 figure	37, 63
M2	1/1+1/3 figure	37, 63
M3	1/8+1/2 figure	37, 63
M90	50m riffel M 90	19
M90	50m riffel M 90 F	19
M96	15m luftriffel M 96/G	20
M96	15m luftriffel M 96/G F	20
MalF	Malfunction	66
Mddl	Middle relay	59
Menu	Match Menu	112
Min-	Minute minus 1	88
Min+	Minute plus 1	88
Mntn	Maintenance	98
Mon-	Month minus 1	87
Mon+	Month plus 1	87
Moos	Running Moose	49
Morg	Morgarten	10, 49, 58
MP20	Pentathlon 20	46
MP30	Pentathlon 3*10	46
Msg	Message	83
Mtch	Match	65, 110

N

N15m	NSF 15m	14, 44
NAMf	Non-Allowable	67
No	Number	72, 74
No	SNr Prim	72, 74
NoLf	Number of line feeds	80
NOR	Norsk	87
NOR	Norway	14, 39, 59
NrIn	Print number of Innertens	79
NrOI	Number of Instancies diff	
NSwe	New Swedish target	15
NTC4	NTTC4	17
NTC5	NTTC5	17
NxtP	Next Primary Score	68
NxtS	Next Secondary Score	68

O

Off	0	77, 80, 111, 113, 114, 117, 118
Oly1	Oly100	16

Oly2	Oly200	16
OP_A	OP Part 1	50
OP_B	OP Part 2	50
OPAS	OP A5 Sighters	50
OPBS	OP B4 Sighters	50
OpnS	Opening shooting	53
Or75	Ordnance pistol 75	119
OrdP	Ordnance pistol	119
Othr	Other	4, 17, 35, 42, 46, 47, 49, 58, 59, 67, 82, 88, 90, 91, 92, 94

P

P60	Pistol 60	48
PA00	PA100	8, 9
Para	Parameter	85
PB00	PB100	8, 10
Pent	Pentathlon	45
PFed	Paper feed	112
PffW	Pfäffiker winter practice	58
PiBB	Big bore pistol	5
PiBB	Sport Pistol Big Bore	5
PiSB	Sport Pistol Small Bore	119
Pist	Free Pistol	119
Pist	Pistol	119
Pos	Position	119
Pos	Position required	119
PPrW	Practice progress window	83
PrCo	Practice Control	97
Prct	Practice	66, 81
Prec	Precision	5, 27, 36, 38, 63
Pres	Presentation	71
Prim	Primary	73
PrnF	Print-format	75
PrnF	Prone supported	75
Prnt	Graphic Printer Model	115
Prnt	On printer	115
Prnt	Print	115
Prnt	Printing	115
Proc	Report Processes	100
Prog	Programs	45, 95
Prog	Swedish program	45, 95
Pron	Prone	113, 120
PrOT	Print Overtime	79
Prot	Print Protocol	78

SIUS

Shortcuts

R

R BC	Activate remote barcode	97
RapF	Rapid Fire	5
Repo	Report Shot Counter	70
Repo	Reports	70
Rept	Repeat	66
Requ	Requirements	117
Res	Reserved	59
RF3x	Rapid Fire 3x20	50
RFP	Rapid Fire Pistol	46
RFPM	Military Rapid Fire Men	47
RFPW	Military Rapid Fire Women	47
Right	Right	32, 78, 89, 110
Rifl	Rifle	6, 7, 11, 24, 27, 62, 93, 119
RLd	Reload	69
Rmot	Remote	97
Rmov	Remove Timer	68
Roeb	Running Roebuck	49
Rprn	Reprint	69
Rset	Reset	89, 91, 92, 93, 94, 95
Rset	Reset Shot Counter	89, 91, 92, 93, 94, 95
Rset	Reset Timer	89, 91, 92, 93, 94, 95
RsNo	Reset Shot Number	81
Run	Running Target	3, 11, 45, 48, 96
Rus	Russian	87
RUS4	Russian No. 04	6, 47

S

S10	P2S10	53
S6S4	P2S6S4	53
Save	Save Customer Settings	98
SbyS	Shot by Shot	51, 53, 55, 56, 65, 89
SCB	Simulator SCB	85
ScIF	Scale Factor	89
Scnd	Scandinavia	13, 36, 59, 63, 92, 96
ScNI	Save number of instances	
Scor	Score	66
SCPr	SC-Programs	66, 89
ScrB	Scoreboard	101

Sec	SNr Prim Sec	73
Sec0	Set second zero	88
SecS	Secondary Score	76, 79
SeCt	Settings Control	98
Sens	Sensitivity	115
SeqN	Total with SeqNr	81
SetS	Set Scale Factor	89
SetS	Set Subnet	89
Sett	Set Timer	68
Sett	Settings	68
Sg57	Stgw 57	119
Sg90	Stgw 90	119
Shoo	Shoot	81, 99
Show	Display Messages	83
Shrt	Short	81
Shrt	Short format	81
ShtC	Shot Counter	70, 99, 100
Shts	Shoot	81, 99
Sigh	Sighters	46, 65, 79, 89
SiSe	Single Execution	89
SjF4	Schijf 4	16
SjF5	Schijf 5	16
SjFK	Schijf K	16
SjFS	Schijf S	16
SIT	Self Test	100
SmlB	Small Bore	7
SpPi	Sport Pistol	46, 47, 119
SSns	Shot sensor	116
Star	Start	88
Stat	Status flashing	83
Stnd	Standard	3, 11, 74, 93
Stnd	Standing	3, 11, 74, 93
StPi	Standard Pistol	47
StpL	Stop at Left	82
Strt	Start Timer	68
SubT	Subtotal	65, 79, 82
Sui	Switzerland	2, 5, 7, 12, 50
SWE	Moose SWE	32, 33
SWE	Svenska	32, 33
Symb	Symbol	71, 74
Sys	System	69

T

t xy	t x/y	76
TChg	Target changer	112
TCU	Time Control Unit	115
TgAl	Target Alternative	89

SIUS

Shortcuts

TgFM	Target Feed Message	84
TgNm	Display target name	84
Tgts	Targets	2
ThiC	Thin Cross	72, 74
Timr	Programed Timers	81
Timr	Timer	81
Totl	Total	65, 66, 81
Trgt	Target	112
Trgt	Target test	112

U

UsrG	User Group	93
USSe	US+Seconds	88

V

Voeg	Vögelinsegg	58
------	-------------	----

W

Weap	Weapon	92
Weap	Weapon required	92
Weap	Weapon Type	92

X

X	DeltaX	108
X+01	X+0.1mm	108
X+1	X+1mm	108
X+10	X+10mm	109
X-01	X-0.1mm	108
X-1	X-1mm	108
X-10	X-10mm	108
XY	Spread	86

Y

Y	DeltaY	109
Y-	Year minus 1	87
Y+	Year plus 1	87
Y+01	Y+0.1mm	109
Y+1	Y+1mm	109
Y+10	Y+10mm	109
Y-01	Y-0.1mm	109
Y-1	Y-1mm	109
Y-10	Y-10mm	109

Z

Zi30	Zimmerstutzen 30	46
------	------------------	----