

GMB-AQ670-LLVA

Intel® Q67 with Core™ i7/ i5 /i3 ATX Motherboard

User's Manual



Ver. 1.0

Contents

Safety Information	4
About this guide.....	5
Typography	6
Packing List.....	7
Revision History.....	7
Specifications Summary	8
Block Diagram.....	10
Chapter 1 - Product Introduction.....	12
1.1 Product highlights.....	12
1.2 Before you Proceed	15
1.3 Motherboard Overview	16
1.3.1 Placement Direction	16
1.3.2 Screw Holes	16
1.3.3 Motherboard Layout.....	17
1.3.4 Layout Content List	17
1.3.5 Internal Connector.....	18
1.4 Central Processing Unit (CPU).....	19
1.4.1 Installing the CPU	20
1.4.2 Installing the CPU Heatsink and Fan	22
1.5 System Memory	26
1.5.1 Overview	26
1.5.2 Memory Configurations.....	26
1.5.3 Installing a DIMM	27
1.5.4 Removing a DIMM	28
1.6 Expansion Card.....	29
1.6.1 Installing an Expansion Card	29
1.6.2 Configuring an Expansion Card	29
1.6.3 PCI Express x16 slot.....	29
1.6.6 PCI slot.....	30
1.7 Jumpers	31
1.7.1 Clear CMOS (CMOS1).....	31
1.7.2 AT/ATX Power Mode Select (PSON1).....	32
1.8 Connectors.....	33
1.8.1 Rear panel connectors.....	33
1.8.2 CPU and System fan connectors (FAN 1, FAN2, FAN 3).....	34
1.8.3 System Panel (F_PANEL)	35
1.8.4 ATX power connectors (EATXPWR1)	36

1.8.5 Serial Port connectors (COM3, COM4, COM5, COM6).....	36
1.8.6 Digital IO Connector (JDIO1)	37
1.8.7 Audio Mic.-In & Line-Out Connector (FPAAUD1)	37
1.8.8 Internal KB/MS connector (KBMS2).....	38
1.8.9 Digital Audio connector (SPDIF_OUT).....	38
1.8.10 TPM Connector (TPM)	39
1.8.11 Serial ATA 3.0 Connector (SATA1, SATA2)	39
1.8.12 Serial ATA II Connector (SATA3 , SATA4 , SATA5, SATA6)	39
1.8.12 USB connectors (USB56, USB78, USB910, USB1112,)	40
Chapter 2 - BIOS Setup	42
2.1 BIOS Setup Program	42
2.1.1 Legend Box	43
2.1.2 List Box.....	43
2.1.3 Sub-menu.....	43
2.2 BIOS Menu Screen	45
2.3 Main Setup.....	46
2.4 Advanced BIOS Setup	47
2.4.1 PCI Subsystem Setting	47
2.4.2 ACPI Settings	51
2.4.3 Trusted computing.....	52
2.4.4 CPU configuration	53
2.4.5 SATA Configuration.....	55
2.4.6 Intel IGO SWSCI OpRegion.....	56
2.4.7 Intel TXT(LT) Configuration.....	57
2.4.8 USB Configuration.....	58
2.4.9 AMT Configuration	59
2.4.10 Super IO Configuration.....	60
2.4.11 Hardware Monitor.....	70
2.5 Chipset.....	71
2.5.1 North Bridge	72
2.5.2 South Bridge.....	74
2.5.3 ME Subsystem	78
2.6 Boot.....	79
2.7 Security	81
2.8 Save & Exit	82

Safety Information

Electrical safety

- To prevent electrical shock hazard, disconnect the power cable from the electrical outlet before relocating the system.
- When adding or removing devices to or from the system, ensure that the power cables for the devices are unplugged before the signal cables are connected. If possible, disconnect all power cables from the existing system before you add a device.
- Before connecting or removing signal cables from the motherboard, ensure that all power cables are unplugged.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Make sure that your power supply is set to the correct voltage in your area. If you are not sure about the voltage of the electrical outlet you are using, contact your local power company.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.

Operation safety

- Before installing the motherboard and adding devices on it, carefully read all the manuals that came with the package.
- Before using the product, make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- To avoid short circuits, keep paper clips, screws, and staples away from connectors, slots, sockets and circuitry.
- Avoid dust, humidity, and temperature extremes. Do not place the product in any area where it may become wet.
- Place the product on a stable surface.
- If you encounter technical problems with the product, contact a qualified service technician or your retailer.



The symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

Safety Declaration

This device complies with the requirements in Part 15 of the FCC rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

About this guide

This user guide contains the information you need when installing and configuring the motherboard.

How this guide is organized

This manual contains the following parts:

- **Chapter 1: Product introduction**
This chapter describes the features of the motherboard and the new technology it supports. This chapter also lists the hardware setup procedures that you have to perform when installing system components. It includes description of the jumpers and connectors on the motherboard.
- **Chapter 2: BIOS setup**
This chapter tells how to change system settings through the BIOS Setup menus. Detailed descriptions of the BIOS parameters are also provided.

Where to find more information

Refer to the following sources for additional information and for product and software updates.

1. Technical Support

If a problem arises with your system and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please try the following help resources for further guidance. Visit the Contec website:

<http://www.contec.com>

2. Optional documentation

Your product package may include optional documentation, such as warranty flyers, that may have been added by your dealer. These documents are not part of the standard package.

Conventions used in this guide

To make sure that you perform certain tasks properly, take note of the following symbols

used throughout this manual.



DANGER/WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Instructions that you **MUST** follow to complete a task.



NOTE: Tips and additional information to help you complete a task.

Typography

Bold text

Indicates a menu or an item to select

Italics

Used to emphasize a word or a phrase

<Key>

Keys enclosed in the less-than and greater-than sign means that you must press the enclosed key

Example: <Enter> means that you must press the Enter or Return key

<Key1>+<Key2>+<Key3>

If you must press two or more keys simultaneously, the key names are linked with a plus sign (+)

Example: <Ctrl>+<Alt>+<D>

Command

Means that you must type the command exactly as shown, then supply the required item or value enclosed in brackets

Example: At the DOS prompt, type the command line:

afudos /i[filename]

afudos /iP5P800VM.ROM

Packing List

Before you begin installing your single board, please make sure that the following materials have been shipped:

- 1 x GMB-AQ670-LLVA ATX Main board
- 1 x DVD-ROM contains OS drivers
- 1 x COM cable
- 2 x SATA cable
- 1 x I/O Shield
- 1 x Startup Manual



If any of the above items is damaged or missing, please contact your retailer.

Revision History


Revision	Revision History	Date
V 1.0	First release version for PCB R10	December, 2011

Specifications Summary

Specifications	
System	
CPU	Intel LGA1155 socket supports Intel Core i7/ i5/ i3 CPU
BIOS	AMI 16Mb SPI
System Chipset	Intel® Q67
I/O Chipset	Nuvoton NCT6776F
Memory	Four 240-pin UDIMM sockets support up to 16GB dual channel DDR3 1066/ 1333 SDRAM
Watchdog Timer	Reset: 1 to 255 sec/min per step
H/W Status Monitor	Monitoring temperature, voltage and cooling fan status. Auto throttling control when CPU overheats.
Expansion Slots	1 PCI-E x 16, 6 PCI
Power State	S1, S3, S4, S5
Wake up on LAN or Ring	LAN (WOL) and Ring (WO)
Smart Fan Control	Yes
Smart Fan Control	Supports 3 modes (Silent/Optimal/Performance)
I/O	
MIO	6 COM RS-232, 2 SATA 3.0, 4 SATA II, 1 HDMI, 1 VGA, 2 LAN, 1 PS/2 Keyboard, 1 PS/2 Mouse
USB	12 USB 2.0 (4 Rear, 8 Internal)
GPIO	8-bit
Display	
Chipset	Intel® GMA HD 2000/ 3000 supports DirectX 10.1, OpenGL 3.0
Display Memory	Shared Memory, up to 1GB
Dual Display	VGA + HDMI
VGA	Onboard, supports max resolution 2048 x 1536 (@60Hz)
HDMI	Onboard HDMI 1.3, supports max resolution 1920 x 1080 (@60Hz)
Audio	
Audio Codec	Realtek ALC892, 5.1 Channel HD Audio
Audio Interface	Line-in, Line-out, Mic-in, S/PDIF, Front Audio Header
Ethernet	
LAN1	Intel 82579LM
LAN2	Intel 82583V

* Specifications are subject to change without notice.

Block Diagram



This chapter describes the motherboard features and the new technologies it supports.

1

Product Introduction

Chapter 1 - Product Introduction

1.1 Product highlights

1.1.1 Product Overview

Supports latest Intel LGA 1155 CPU-socket interface processor, the 2nd Generation Intel® Core i3, i5, i7 desktop processors which are built on 32 nm technologies to provide smart performance and responsiveness on executing tasks, It combines the CPU and GPU to offer fantastic HD media and graphics, especially on 3D gaming experience. Doubles the bandwidth of your system memory up to 21GB/s and pumps up the system performance at lower power.

DMI (Direct Media Interface) architecture connects between the processor and chipset at 5.0GT/s which twice the speed of previous version. The exceptionally increased interconnect bit rate from 2.5GT/s up to 5.0GT/s would effectively eliminates the bottle neck of the system performance and brings the most terrific computing experience from the present to the future. Doubles the transfer speed of SATA 3G, running at speed up to 6.0Gb/s, and can connect with any other SATA 3.0Gb/s and 1.5Gb/s devices for backward compatibility.

Supports RAID 0(Striped disk array), RAID 1(Mirroring disk array), RAID 5(Block Interleaved Distributed Parity), RAID 10 (A Stripe of Mirrors). Provides users the performance and protection. Integrated 5.1-channel HD Audio CODEC delivering advanced multi-channel audio and bringing you the experience of home theater-quality sound. Delivers transfer speed ten times faster than conventional 10/ 100 Ethernet connections, supporting a high transfer rate up to Gigabit/s. Gigabit LAN is the networking standards for the future and is ideal for handling large amount of data such as video, audio, and voice.

Choose an environment-friendly, fully RoHS-compliant product as the foundation for keeping harmful substances out of our ecosystem.

1.1.2 Platform Features and Benefits

- Integrated Gfx (Intel® HD Graphics 3000/2000) with enhanced operating modes to enable excellent graphics performance in power and cost sensitive embedded applications
- DirectX® 10.1 & Open GL 3.0 let you enjoy awesome graphics performance, stunning 3D visual effect and dynamic interactivity
- Memory support, integrated low voltage DDR3 memory controller
- Operating system support:
 - Microsoft
 - WindRiver
 - Redhat

- Novell
- Green Hills
- QNX
- LinuxWorks

1.1.3 Key Architecture Features

- Supports Intel LGA 1155 CPU, the 2nd Generation Intel® Core i3, i5, i7 desktop processors.
 - 32nm monolithic die
 - Integrated Gfx (Intel® HD Graphics 3000/2000) & memory controller
 - 4 & 2 Cores, up to 6MB LLC
 - HW accelerated video CODECs
 - Compatible with high speed DDR3-1333
 - PCIe* (CPU): Gen 2.0, 5GT/s, up to 20 lanes (4 ctls)**
 - TDP: 17W-45W (Low Power), 65W-95W (Scalable)
- Intel® Turbo Boost Technology
 - More efficient power sharing between CPU and Graphics
- Intel® Hyper-Threading Technology
- Intel® Advanced Vector Extensions (Intel® AVX)
- Intel® AES-New Instructions
- Integrated Display Interfaces
 - Dual Independent Display Support
 - HDMI
 - Analog VGA
- Intel® HD Graphics 3000/2000
 - DirectX® 10.1
 - Improved realism for DX 3D applications. Improved rendering.
 - OpenGL 3.0
 - Improved realism for OGL 3D based application
 - UVD (Unified Video Decoder) 2.01
 - Hardware decode of most common HD codecs (MPEG-2, H.264/AVC MPEG-4 and VC-1)
 - Supports ATI Hybrid CrossFireXTM Technology2
- Intel Quick Sync Video
 - Enables faster and higher quality video editing, recording and sharing
- I/O
 - PCI Express® x 16 Gen 2 5GT/s
 - PCI 2.3 interface
 - Six SATA ports (2 port of Gen 2.0 and 4 ports of Gen 3.0) support RAID 0,1, 5, 10
 - Gigabit Ethernet Media Access Controller (GbE MAC)
 - IPv4 and IPv6 Checksum Offload

- High Definition Audio
- USB: Gen 2.0, up to 14 ports
- SMBus 2.0
- LPC Bus
 - Supports SPI devices
- Hardware Monitor
 - Fan control (Voltage, Temp)
 - Watchdog timer

1.2 Before you Proceed

Take note of the following precautions before you install motherboard components or change any motherboard settings.



- Unplug the power cord from the wall socket before touching any component.
- Use a grounded wrist strap or touch a safely grounded object or a metal object, such as the power supply case, before handling components to avoid damaging them due to static electricity
- Hold components by the edges to avoid touching the ICs on them.
- Whenever you uninstall any component, place it on a grounded anti-static pad or in the bag that came with the component.
- Before you install or remove any component, ensure that the ATX power supply is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components.

1.3 Motherboard Overview

Before you install the motherboard, study the configuration of your chassis to ensure that the motherboard fits into it. Refer to the chassis documentation before installing the motherboard.



Make sure to unplug the power cord before installing or removing the motherboard. Failure to do so can cause you physical injury and damage motherboard components.

1.3.1 Placement Direction


When installing the motherboard, make sure that you place it into the chassis in the correct orientation. The edge with external ports goes to the rear part of the chassis as indicated in the image below.

1.3.2 Screw Holes

Place eight (8) screws into the holes indicated by circles to secure the motherboard to the chassis.




Do not over tighten the screws! Doing so can damage the motherboard.



Place this side towards the rear of the chassis.

1.3.3 Motherboard Layout



1.3.4 Layout Content List

Slots & socket			
Label	Function	Note	Page
LGA1155	LGA1155 socket		19
DIMMA1	240-pin DDR3 DIMM Slot A1		26
DIMMA2	240-pin DDR3 DIMM Slot A2		26
DIMMB1	240-pin DDR3 DIMM Slot B1		26
DIMMB2	240-pin DDR3 DIMM Slot B2		26
PCIEX16	PCI-e x16 Slot		29
PCI	PCI Slot		30

Jumpers			
Label	Function	Note	Page
JCMOS1	Clear CMOS	3 x 1 header, pitch 2.54mm	31
PSON1	AT/ATX Mode Select	3 x 1 header, pitch 2.54mm	32
Rear Panel Connector			
Label	Function	Note	Page
KBMS	PS/2 Keyboard and Mouse	6-pin Mini-Din	33
COM1	COM1 Connector	D-sub 9-pin, male	33
COM2	COM2 Connector	D-sub 9-pin, male	33
VGA1	VGA Port	D-sub 15-pin, female	33
HDMI1	HDMI Port	HDMI 1.3 19-pin	33
LAN1USB12	RJ-45 Ethernet Connector x 1 USB 2.0 Connector x 2		33
LAN2USB34	RJ-45 Ethernet Connector x 1 USB 2.0 Connector x 2		33
Audio1	Audio Line-In , Line-Out , Mic.-In	5.1 Channel Audio I/O (3 jacks)	33

1.3.5 Internal Connector

Internal Connector			
Label	Function	Note	Page
FAN1	CPU Fan Connector	4 x 1 wafer, pitch 2.54mm	34
FAN2	System Fan Connector	3 x 1 wafer, pitch 2.54mm	34
FAN3	Chassis Fan Connector	3 x 1 wafer, pitch 2.54mm	34
F_PANEL	Intel Front Panel connector	5 x 2 header, pitch 2.54mm	35
EATXPWR1	ATX power connectors	10 x 2 header	36
COM3~ 6	Serial Port Connector * 4	5 x 2 header, pitch 2.54mm	36
JDIO1	Digital I/O Connector	6 x 2 header, pitch 2.54mm	37
FPAUD1	Audio Mic.-In & Line-Out Connector	5 x 2 header, pitch 2.54mm	37
KBMS2	PS2 Keyboard & mouse connector	5 x 2 header, pitch 2.54mm	38
SPDIF_OUT1	Digital Audio connector	4 x 1 header, pitch 2.54mm	38
TPM	TPM Connector	10 x 2 header, pitch 2.54mm	39
SATA1, 2	SATA3.0 Data Connector * 6	7P Male connector	39
SATA3 ~ 6	SATA II Data Connector * 6	7P Male connector	39
USB56 USB78 USB910 USB1112	USB Connector * 8	5 x 2 header, pitch 2.54mm	40

1.4 Central Processing Unit (CPU)

The motherboard comes with a surface mount LGA1155 socket designed for the Intel® Core™ i7/ i5/ i3 processor in the 1155-land package.


- Your boxed Intel® Core™ i7/ i5/ i3 LGA1155 processor package should come with installation instructions for the CPU, fan and heatsink assembly. If the instructions in this section do not match the CPU documentation, follow the latter.
- Upon purchase of the motherboard, make sure that the PnP cap is on the socket and the socket pins are not bent. Contact your retailer immediately if the PnP cap is missing, or if you see any damage to the PnP cap/socket pins/motherboard components. CONTEC SOLUTION will shoulder the cost of repair only if the damage is shipment/transit-related.
- Keep the cap after installing the motherboard. CONTEC SOLUTION will process Return Merchandise Authorization (RMA) requests only if the motherboard comes with the cap on the LGA1155 socket.
- The product warranty does not cover damage to the socket pins resulting from incorrect CPU installation/removal, or misplacement/loss/incorrect removal of the PnP cap.
- Install the CPU fan and heatsink assembly before you install motherboard to the chassis.



If you purchased a separate CPU heatsink and fan assembly, make sure that you have properly applied Thermal Interface Material to the CPU heatsink or CPU before you install the heatsink and fan assembly.

1.4.1 Installing the CPU

1. Locate the CPU socket on the motherboard.




Before installing the CPU, make sure that the socket box is facing towards you and the load lever is on your left.

2. Press the load lever with your thumb (A), then move it to the left (B) until it is released from the retention tab.


Retention tab

Load lever



To prevent damage to the socket pins, do not remove the PnP cap unless you are installing a CPU.


3. Lift the Load lever with your thumb and forefinger to around 180° angle (A), then pull the PnP cap from the CPU socket to remove (B).



4. Position the CPU over the socket, making sure that the gold triangle is on the top-left corner of the socket then fit the socket alignment key into the CPU notch.


CPU notch

Gold triangle




Alignment key

5. Pull back the load lever, then push the load lever (A) until it snaps into the retention tab.



The CPU fits in only one correct orientation. DO NOT force the CPU into the socket to prevent bending the connectors on the socket and damaging the CPU!



1.4.2 Installing the CPU Heatsink and Fan

Intel® Core™ i7/ i5/ i3 LGA1155 processor requires a specially designed heatsink and fan assembly to ensure optimum thermal condition and performance.


- Install the motherboard to the chassis before you install the CPU fan and heatsink assembly.
- When you buy a boxed Intel® Core™ i7/ i5/ i3 LGA1155 processor, the package includes the CPU fan and heatsink assembly. If you buy a CPU separately, make sure that you use only Intel® certified multi-directional heatsink and fan.
- Your Intel® Core™ i7/ i5/ i3 LGA1155 processor LGA1155 heatsink and fan assembly comes in a push-pin design and requires no tool to install.



If you purchased a separate CPU heatsink and fan assembly, make sure that you have properly applied Thermal Interface Material to the CPU heatsink or CPU before you install the heatsink and fan assembly.

To install the CPU heatsink and fan:

1. Place the heatsink on top of the installed CPU, making sure that the four fasteners match the holes on the motherboard.







Orient the heatsink and fan assembly such that the CPU fan cable is closest to the CPU fan connector.



- Make sure each fastener is oriented as shown, with the narrow groove directed outward.

2. Push down two fasteners at a time in a diagonal sequence to secure the heatsink and fan assembly in place.





3. Connect the CPU fan cable to the connector on the motherboard labeled CPU_FAN.

FAN 1

CPU FAN

- | | |
|------|---------------|
| ○ | 4. FAN_PWM1_C |
| ○ | 3. FANCPUDEC1 |
| ○ | 2. +V12 |
| 1. □ | 1. GND |



Do not forget to connect the fan cables to the fan connectors. Insufficient air flow inside the system may damage the motherboard components.


These are not jumpers! DO NOT place jumper caps on the

fan connectors.



1.4.3 Uninstalling the CPU Heatsink and Fan

To uninstall the CPU heatsink and fan:


1. Disconnect the CPU fan cable from the connector on the motherboard.
2. Rotate each fastener counterclockwise



2. Pull up two fasteners at a time in a diagonal sequence to disengage the heatsink and fan assembly from the motherboard.



4. Carefully remove the heatsink and fan assembly from the motherboard.



5. Rotate each fastener clockwise to ensure correct orientation when reinstalling.




1.5 System Memory

1.5.1 Overview

The motherboard comes with four 240-pin Double Data Rate 3 (DDR3) Dual Inline Memory Modules (DIMM) sockets.

A DDR3 module has the same physical dimensions as a DDR DIMM but has a 240-pin footprint compared to the 240-pin DDR2 DIMM. DDR3 DIMMs are notched differently to prevent installation on a DDR2 DIMM socket. The following figure illustrates the location of the sockets:



240-Pin DDR3 DIMM sockets

Channel	Socket
Channel A	DIMMA1
	DIMMA2
Channel B	DIMMB1
	DIMMB2

1.5.2 Memory Configurations

You may install 1 GB, 2 GB , and 4 GB unbuffered ECC or non-ECC DDR3 DIMMs into the DIMM sockets using the memory configurations in this section.




- IF you installed four 1GB memory modules, the system may detect less than 3GB of total memory because of address space allocation for other critical functions. This limitation applies to Windows XP 32-bit version operating system
- IF you install Windows XP 32-bit version operating system, we recommend that you install less than 3GB of total memory.
- For dual-channel configuration, the total size of memory module(s) installed per channel must be the same for better performance (DIMMA1 +DIMMA2=DIMMB1+DIMMB2).


- When using one DDR3 DIMM module, install into DIMMB1 slot only.
- When using two DDR3 DIMM modules, install into DIMMA1 and DIMMB1 slots only.
- Always install DIMMs with the same CAS latency. For optimum compatibility, it is recommended that you obtain memory modules from the same vendor. Refer to the memory Qualified Vendors List on the next page for details.
- Due to CPU limitation, DIMM modules with 128 Mb memory chips or double-sided x16 memory chips are not supported in this motherboard.

1.5.3 Installing a DIMM

1. Unlock a DIMM socket by pressing the retaining clips outward.
2. Align a DIMM on the socket such that the notch on the DIMM matches the break on the socket.



3. Firmly insert the DIMM into the socket until the retaining clips snap back in place and the DIMM is properly seated.




- A DDR3 DIMM is keyed with a notch so that it fits in only one direction. DO NOT force a DIMM into a socket to avoid damaging the DIMM.
- The DDR3 DIMM sockets do not support DDR DIMMs. DO NOT install DDR2 DIMMs to the DDR3 DIMM socket.



Make sure to unplug the power supply before adding or removing DIMMs or other system components. Failure to do so may cause severe damage to both the motherboard and the components.

1.5.4 Removing a DIMM

1. Simultaneously press the retaining clips downward to unlock the DIMM.
2. Remove the DIMM from the socket.



Support the DIMM lightly with your fingers when pressing the retaining clips. The DIMM might get damaged when it flips out with extra force.

1.6 Expansion Card

In the future, you may need to install expansion cards. The following sub-sections describe the slots and the expansion cards that they support.



Make sure to unplug the power cord before adding or removing expansion cards. Failure to do so may cause you physical injury and damage motherboard components.

1.6.1 Installing an Expansion Card

1. Before installing the expansion card, read the documentation that came with it and make the necessary hardware settings for the card.
2. Remove the system unit cover (if your motherboard is already installed in a chassis).
3. Remove the bracket opposite the slot that you intend to use. Keep the screw for later use.
4. Align the card connector with the slot and press firmly until the card is completely seated on the slot.
5. Secure the card to the chassis with the screw you removed earlier.
6. Replace the system cover.


1.6.2 Configuring an Expansion Card

After installing the expansion card, configure it by adjusting the software settings.

1. Turn on the system and change the necessary BIOS settings, if any. See Chapter 2 for information on BIOS setup.
2. Assign an IRQ to the card if needed. Refer to the tables on the next page.
3. Install the software drivers for the expansion card.



1.6.3 PCI Express x16 slot

This motherboard supports one PCI Express x16 slot that complies with the PCI Express specifications. The following figure shows a graphics card installed on the PCI Express x16 slot.



1.6.6 PCI slot

This motherboard supports one PCI slot that complies with the PCI specifications. The following figure shows a *audio* card installed on the PCI slot.



1.7 Jumpers

1.7.1 Clear CMOS (CMOS1)


This jumper allows you to clear the Real Time Clock (RTC) RAM in CMOS. You can clear the CMOS memory of date, time, and system setup parameters by erasing the CMOS RTC RAM data. The onboard button cell battery powers the RAM data in CMOS, which includes system setup information such as system passwords.

To erase the RTC RAM:

1. Turn OFF the computer and unplug the power cord.
2. Remove the onboard battery.
3. Move the jumper cap from pins 1-2 (default) to pins 2-3. Keep the cap on pins 2-3 for about 5~10 seconds, then move the cap back to pins 1-2.
4. Re-install the battery.
5. Plug the power cord and turn ON the computer.
6. Hold down the key during the boot process and enter BIOS setup to re-enter data.
- 7.



Except when clearing the RTC RAM, never remove the cap on CLRTC jumper default position. Removing the cap will cause system boot failure!



Normal (Default)




Clear CMOS



You do not need to clear the RTC when the system hangs due to overclocking. For system failure due to overclocking, use the C.P.R. (CPU Parameter Recall) feature. Shut down and reboot the system so the BIOS can automatically reset parameter settings to default values.

1.7.2 AT/ATX Power Mode Select (PSON1)

This jumper allows you to select ATX Mode or AT mode .



ATX MODE (Default)




AT MODE



1.8 Connectors


1.8.1 Rear panel connectors



1. **PS/2 mouse port (green).** This port is for a PS/2 mouse.
2. **PS/2 keyboard port (purple).** This port is for a PS/2 keyboard.
3. **Serial connector.** This 9-pin COM1 port is for serial devices.
4. **Serial connector.** This 9-pin COM2 port is for serial devices.
5. **VGA port.** This 15-pin VGA port connects to a VGA monitor.
6. **HDMI port.** This 19-pin HDMI 1.3 port connects to a HDMI monitor.
7. **LAN (RJ-45) port.** This port allows Gigabit connection to a Local Area Network (LAN) through a network hub. Refer to the table below for the LAN port LED indications.

LAN port LED indications


SPEED LED		ACT / LINK LED	
Status	Description	Status	Description
OFF	10Mbps connection	OFF	No link
Orange	100Mbps connection	Green	Link
Green	1Gbps connection	Blinking	Data activity



8. **USB 2.0 ports 1 ~ 4.** These four 4-pin Universal Serial Bus (USB) ports are available for connecting USB 2.0 devices.
9. **Line In port (light blue).** This port connects a tape, CD, DVD player, or other audio sources.
10. **Line Out port (lime).** This port connects a headphone or a speaker.
In 4-channel, 6-channel, and 8-channel configuration, the function of this port becomes Front Speaker Out.
11. **Microphone port (pink).** This port connects a microphone.


1.8.2 CPU and System fan connectors (FAN 1, FAN2, FAN 3)

The fan connectors support cooling fans of 280mA (3.36 W max.) at 4800rpm or a total of 1A~2.22A (26.64W max.) at +12V. Connect the fan cables to the fan connectors on the motherboard, making sure that the black wire of each cable matches the ground pin of the connector.




FAN 1

CPU FAN




FAN 2

System FAN



FAN 3


Chassis Fan



Do not forget to connect the fan cables to the fan connectors. Insufficient air flow inside the system may damage the motherboard components.
These are not jumpers! DO NOT place jumper caps on the fan connectors.

1.8.3 System Panel (F_PANEL)

This connector is for a chassis-mounted front panel audio I/O module that supports either HD Audio or legacy AC'97 audio standard.



- **ATX Power Button/Soft-off Button (Pin 6-8 PWRBT)**

This 2-pin connector is for the system power button. Pressing the power button turns the system on or puts the system in sleep or soft-off mode depending on the BIOS settings. Pressing the power switch and holding it for more than four seconds while the system is ON turns the system OFF.

- **Reset Button (Pin 5-7 SYS_RST)**

This 2-pin connector is for the chassis-mounted reset button for system reboot without turning off the system power.

- **Power LED (Pin 1-3 PWRLED)**


This 2-pin connector is for the system power LED. Connect the chassis power LED cable to this connector. The system power LED lights up when you turn on the system power, and blinks when the system is in sleep mode.

- **Hard Disk Drive Activity LED (Pin 1-3 HDLED)**

This 2-pin connector is for the HDD Activity LED. Connect the HDD Activity LED cable to this connector. The IDE LED lights up or flashes when data is read from or written to the HDD.

1.8.4 ATX power connectors (EATXPWR1)


The connector is for ATX power supply plugs. The power supply plugs are designed to fit these connectors in only one orientation. Find the proper orientation and push down firmly until the connectors completely fit.



- Use of a PSU with a higher power output is recommended when configuring a system with more power-consuming devices. The system may become unstable or may not boot up if the power is inadequate.
- Make sure that your power supply unit (PSU) can provide at least the minimum power required by your system. See the table below for details.


1.8.5 Serial Port connectors (COM3, COM4, COM5, COM6)

This connector is for a serial (COM) port. Connect the serial port module cable to this connector, then install the module to a slot opening at the back of the system chassis.



1.8.6 Digital IO Connector (JDIO1)

This connector is for 8-bit General purpose I/O function.




JDIO1

1	□	2	1. SIO_GPIO0	2. SIO_GPIO4
	○		3. SIO_GPIO1	4. SIO_GPIO5
	○		5. SIO_GPIO2	6. SIO_GPIO6
	○		7. SIO_GPIO3	8. SIO_GPIO7
	○		9. SMB_CLK_MAIN	10. SMB_DATA_MAIN
	○		11. GND	12. N52792386

1.8.7 Audio Mic.-In & Line-Out Connector (FPAAUD1)

This connector is for a chassis-mounted front panel audio I/O module that supports either HD Audio or legacy AC '97 (optional) audio standard.




FPAAUD1

1	□	2	1. MIC2_L	2. GND
	○		3. MIC2_R	4. PRESENSE
	○		5. LIN2_R	6. SENSE1_RTN
	○		7. SENSE_B	8. NC
	○		9. LIN2_L	10. SENSE2_RTN

1.8.8 Internal KB/MS connector (KBMS2)

This connector is for internal KB/MS.




KBMS2



1. KB CLK
2. KB DAT
3. MA DAT
4. GND
5. KBMS1 VCC
6. MS CLK

1.8.9 Digital Audio connector (SPDIF_OUT)


This connector is for the S/PDIF audio module to allow digital sound output. Connect one end of the S/PDIF audio cable to this connector and the other end to the S/PDIF module.




SPDIF_OUT




4. GND
3. SPDIF_O
1. +5V



1.8.10 TPM Connector (TPM)




TPM




- | | | | |
|----------------|---------------|----------------|--------|
| 1. PCICLK2 | 3. LPC_FRAME# | 5. PLTRST_SIO# | |
| 2. GND | 4. NC | 6. NC | |
| 7. LPC_AD3 | 9. +V3.3 | 11. LPC_AD2 | 13. NC |
| 8. LPC_AD2 | 10. LPC_AD1 | 12. GND | 14. NC |
| 15. +V3.3_DUAL | 17. GND | 19. LPCPD# | |
| 16. PCI_SERIRQ | 18. GND | 20. NC | |

1.8.11 Serial ATA 3.0 Connector (SATA1, SATA2)

These connectors support SATA 3.0 and are for the Serial ATA signal cables for Serial ATA hard disk drives.




SATA1、SATA2




1.8.12 Serial ATA II Connector (SATA3 , SATA4 , SATA5, SATA6)


These connectors support SATA 2.0 and are for the Serial ATA signal cables for Serial ATA hard disk drives.



SATA1 · SATA2




Connect the right-angle side of SATA signal cable to SATA device. Or you may connect the right-angle side of SATA cable to the onboard SATA port to avoid mechanical conflict with large graphics cards.



1.8.12 USB connectors (USB56, USB78, USB910, USB1112,)

These connectors are for USB 2.0 ports. Connect the optional USB module cable to any of these connectors, then install the module to a slot opening at the back of the system chassis. These USB connectors comply with USB 2.0 specification that supports up to 480 Mbps connection speed.



USB56, USB78, USB910, USB1112



	Never connect a 1394 cable to the USB connectors. Doing so will damage the motherboard!
	The USB module is purchased separately.

This chapter tells how to change the system settings through the BIOS Setup menus. Detailed descriptions of the BIOS parameters are also provided.

2

Chapter 2 - BIOS Setup

2.1 BIOS Setup Program

This motherboard supports a programmable firmware chip that you can update using the provided utility. Use the BIOS Setup program when you are installing a motherboard, reconfiguring your system, or prompted to “Run Setup.” This section explains how to configure your system using this utility.

Even if you are not prompted to use the Setup program, you can change the configuration of your computer in the future. For example, you can enable the security password feature or change the power management settings. This requires you to reconfigure your system using the BIOS Setup program so that the computer can recognize these changes and record them in the CMOS RAM of the firmware hub.

The firmware hub on the motherboard stores the Setup utility. When you start up the computer, the system provides you with the opportunity to run this program. Press during the Power-On-Self-Test (POST) to enter the Setup utility; otherwise, POST continues with its test routines.

If you wish to enter Setup after POST, restart the system by pressing <Ctrl+Alt+Delete>, or by pressing the reset button on the system chassis. You can also restart by turning the system off and then back on. Do this last option only if the first two failed.

The Setup program is designed to make it as easy to use as possible. Being a menu-driven program, it lets you scroll through the various sub-menus and make your selections from the available options using the navigation keys.



- The default BIOS settings for this motherboard apply for most conditions to ensure optimum performance. If the system becomes unstable after changing any BIOS settings, load the default settings to ensure system compatibility and stability. Select the **Load Optimized Defaults** from the BIOS menu screen.
- The BIOS setup screens shown in this section are for reference purposes only, and may not exactly match what you see on your screen.
- Visit the system builder's website to download the latest BIOS file for this motherboard

2.1.1 Legend Box

The keys in the legend bar allow you to navigate through the various setup menus

Key(s)	Function Description
← → ↓ ↑	Move
+ -	Value
Enter	Select
ESC	Exit
F1	General Help
F2	Previous Values
F3	Optimized Defaults
F4	Save & Exit Setup

2.1.2 List Box

This box appears only in the opening screen. The box displays an initial list of configurable items in the menu you selected.



2.1.3 Sub-menu

Note that a right pointer symbol  appears to the left of certain fields. This pointer indicates that you can display a sub-menu from this field. A sub-menu contains additional options for a field parameter. To display a sub-menu, move the highlight to the field and press <Enter>. The sub-menu appears. Use the legend keys to enter values and move from field to field within a sub-menu as you would within a menu. Use the <Esc> key to return to the main menu.

Take some time to familiarize yourself with the legend keys and their corresponding functions. Practice navigating through the various menus and submenus. If you accidentally make unwanted changes to any of the fields, press <F9> to load the optimal default values. While moving around through the Setup program, note that explanations appear in the Item Specific Help window located to the right of each menu. This window displays the help text for the currently highlighted field.

2.2 BIOS Menu Screen

When you enter the BIOS, the following screen appears. The BIOS menu screen displays the items that allow you to make changes to the system configuration. To access the menu items, press the up/down/right/left arrow key on the keyboard until the desired item is highlighted, then press [Enter] to open the specific menu.]



2.3 Main Setup

This menu gives you an overview of the general system specifications. The BIOS automatically detects the items in this menu. Use this menu for basic system configurations, such as time, date etc.



- **BIOS Information**

Displays the auto-detected BIOS information.

- **Memory Information**

Displays the auto-detected system memory

- **System Date**

The date format is <Date>,<Month>,<Day>,<Year>.

- **System Time**


The time format is <Hour>,<Minute>,<Second>.

- **Access Level**

Displays the accessory information.

2.4 Advanced BIOS Setup


Select the Advanced tab from the setup screen to enter the Advanced BIOS Setup screen. You can select any of the items in the left frame of the screen, such as Chipset configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screen is shown below. The sub menus are described on the following pages.



Take caution when changing the settings of the Advanced menu items. Incorrect field values can cause the system to malfunction.

2.4.1 PCI Subsystem Setting

The PCI PnP menu items allow you to change the advanced settings for PCI/PnP devices. The menu includes setting IRQ and DMA channel resources for either PCI/PnP or legacy ISA devices, and setting the memory size block for legacy ISA devices.



- **PCI Bus Driver Version**

Displays the information of PCI Bus Driver Version

- **PCI ROM Priority [EFI compatible ROM]**

In case of multiple option ROMs (Legacy and EFI compatible), specifies what PCI option ROM to launch.

2.4.1 1 PCI Common Settings

- **PCI Latency Timer [32 PCI Bus Clocks]**

Allows the PCI Latency Timer to be adjusted. This option sets the latency of all PCI devices on the PCI bus.

Configuration options: [32 PCI Bus Clocks] [64 PCI Bus Clocks] [96 PCI Bus Clocks] [128 PCI Bus Clocks] [160 PCI Bus Clocks] [192 PCI Bus Clocks] [224 PCI Bus Clocks] [248 PCI Bus Clocks]

- **VGA Palette Snoop [Disable]**

Enables or disables VGA palette registers snooping.

Configuration options: [Disabled] [Enabled]

- **PERR# Generation [Disable]**

Enables or disables PCI devices to Generate PERR#.

Configuration options: [Disabled] [Enabled]

- **SPERR# Generation [Disable]**

Enables or disables PCI devices to Generate SPERR#.

Configuration options: [Disabled] [Enabled]

2.4.1 2 PCI Express Device Settings

PCI Express Device Register Settings


PCI Express Link Register Settings




2.4.1 3 PCI Express GEN2 Device Settings

PCI Express GEN2 Device Register Settings

PCI Express GEN2 Link Register Settings



2.4.2 ACPI Settings



- **ACPI Sleep State [S3 (suspend to RAM)]**

Select the highest ACPI sleep state the system will enter the SUSPEND button is press.

Configuration options: [Suspend Disable][S1 (CPU Stop Clock)] [S3 (suspend to RAM)]

- **Resume On RTC Alarm [Disable]**

Enable or disable system wake on alarm even. When enabled, system will wake upon the hr/min/sec specified.

Configuration options: [Disabled] [Enabled]

2.4.3 Trusted computing

Trusted computing (TPM) settings.



TPM configuration

- **TPM SUPPORT [Disabled]**


Enable or disable TPM support.

Configuration options: [Disabled] [Enabled]

- **Current TPM Status Information**

Displays the TPM status information [No TPM Hardware]

2.4.4 CPU configuration



- **CPU configuration**

Displays the CPU information

- **Hyper-threading [Enabled]**

Enable or disable Hyper-threading support.

Configuration options: [Disabled] [Enabled]

- **Active Processor Cores [All]**

Select the numbers of cores in each processor package.

Configuration options: [All] [1] [2] [3] [4] [5] [6] [7]



It depends on each CPU type.

- **Limit CPUID Maximum [Disable]**

Disable for Windos XP.

Configuration options: [Disabled] [Enabled]

- **Execute Disable Bit [Enable]**

XD can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS (Windows Server 2003 SP1, Windows XP SP2, SuSE Linux 9.2 RedHat Enterprise 3 Update 3.)

Configuration options: [Disabled] [Enabled]

- **Hardware Prefetcher [Enable]**

To turn on/off the Mid Level Cache (L2) streamer Prefetcher

Configuration options: [Disabled] [Enabled]

- **Adjacent Chach Line Prefetcher [Enable]**

To turn on/off prefetching of adjacent chach lines.

Configuration options: [Disabled] [Enabled]

- **Intel Virtualization Technology [Disable]**

When enable, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

Configuration options: [Disabled] [Enabled]

- **Power Technology [Energy efficient]**

Enable the power management features.

Configuration options: [Disabled] [Energy efficient] [Enabled]

- **Local x2APIC [Disable]**

Enable Local x2APIC. Some OSes do not support this.

Configuration options: [Disabled] [Enabled]

2.4.5 SATA Configuration



- **SATA Mode [IDE Mode]**

Support IDE, AHCI or RAID mode

Configuration options: [Disable][IDE Mode][AHCI Mode][RAID Mode]

- **Serial-ATA Controller 0 [Compatible]**

Enabled/Disabled Serial-ATA Controller 0

Configuration options: [Disable] [Enhanced] [Compatible]


- **Serial-ATA Controller 1 [Enhanced]**

Enabled/Disabled Serial-ATA Controller 1

Configuration options: [Disable] [Enhanced] [Compatible]

2.4.6 Intel IGO SWSCI OpRegion

Intel IGO SWSCI OpRegion configuration



- **DVMT/FIXED Memory [128MB]**

Select DVMT/FIXED Mode Memory size used by Internal Graphic Device.

Configuration options: [128MB][512MB][Maximum]


- **IGO – Boot Type [VBIOS Default]**

Select the video Device which will be activated during POST. This has no effect if external graphics present.

Configuration options: [VBIOS Default][CRT][HDMI][DisplayPort]


2.4.7 Intel TXT(LT) Configuration

Display Intel Trusted Execution Technology configuration.



2.4.8 USB Configuration

USB Configuration Parameters



- **USB Device**

Display how many devices are connected.

- **Legacy USB Support [Enabled]**

Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.

Configuration options: [Enabled] [Disabled][Auto]

- **EHCI Hand-off [Disable]**

This is a workaround for OSes without EHCI hand-off support. The EHCI ownership change should be claimed by EHCI driver.

Configuration options: [Disabled] [Enabled]

- **Port 60/64 Emulation [Enabled]**

Enables I/O port 60h/64h emulation support. This should be enabled for complete USB keyboard legacy support for non-USB aware OSes.

Configuration options: [Disabled] [Enabled]

2.4.9 AMT Configuration

AMT Parameters



- **AMT [Enable]**

AMT Help

Configuration options: [Disabled] [Enabled]

- **Unconfigure AMT/ME [Disable]**

Perform AMT/ME unconfigure without password operation.

Configuration options: [Disabled] [Enabled]

- **WatchDog Timer [Disable]**


Enable/Disable WatchDog Timer.

Configuration options: [Disabled] [Enabled]

When 'Enabled', OS and BIOS WatchDog Timers can be set.

2.4.10 Super IO Configuration

System Super IO Chip Parameters.




Super IO Configuration

Super IO Chip [NCT6776F]

2.4.10.1 Serial Port 1 configuration

Set Parameters of Serial Port 1 (COMA)



Serial Port 1 Configuration

- **Serial Port [Enable]**

Enable or Disable Serial Port.

Configuration options: [Disabled] [Enabled]

- **Device Setting [IO=3F8h; IRQ=4]**


- **Change Setting[Auto]**

Select an optimal setting for Super IO device.

Configuration options: [Auto] [IO=3F8h; IRQ=4] [IO=3F8h; IRQ=3, 4, 5, 6, 7, 9, 10, 11, 12]
 [IO=2F8h; IRQ=3, 4, 5, 6, 7, 9, 10, 11, 12] [IO=3E8h; IRQ=3, 4, 5, 6, 7, 9, 10, 11, 12]
 [IO=2E8h; IRQ=3, 4, 5, 6, 7, 9, 10, 11, 12]

2.4.10.2 Serial Port 2 configuration

Set Parameters of Serial Port 1 (COMA)



Serial Port 2 Configuration

- **Serial Port [Enable]**

Enable or Disable Serial Port.

Configuration options: [Disabled] [Enabled]

- **Device Setting [IO=2F8h; IRQ=3]**

- **Change Setting[Auto]**


Select an optimal setting for Super IO device.

Configuration options: [Auto] [IO=2F8h; IRQ=3] [IO=3F8h; IRQ=3, 4, 5, 6, 7, 9, 10, 11, 12]
[IO=2F8h; IRQ=3, 4, 5, 6, 7, 9, 10, 11, 12] [IO=3E8h; IRQ=3, 4, 5, 6, 7, 9, 10, 11, 12]
[IO=2E8h; IRQ=3, 4, 5, 6, 7, 9, 10, 11, 12]

Super IO Chip [Fintek F81216]

Serial Port 3 configuration

Set Parameters of Serial Port 2 (COMA)



2.4.10.3 Serial Port 3 Configuration

- **Serial Port [Enable]**

Enable or Disable Serial Port.

Configuration options: [Disabled] [Enabled]

- **Device Setting [IO=C80h; IRQ=5]**


- **Change Setting[Auto]**

Select an optimal setting for Super IO device.

Configuration options: [Auto] [IO=C80h; IRQ=5] [IO=C80h; IRQ=5, 7, 9, 10, 11] [IO=C88h; IRQ=5, 7, 9, 10, 11] [IO=C90h; IRQ=5, 7, 9, 10, 11] [IO=C98h; IRQ=5, 7, 9, 10, 11]

2.4.10.4 Serial Port 4 configuration

Set Parameters of Serial Port 3 (COMA)



Serial Port 4 Configuration

- **Serial Port [Enable]**

Enable or Disable Serial Port.

Configuration options: [Disabled] [Enabled]

- **Device Setting [IO=C88h; IRQ=7]**


- **Change Setting[Auto]**

Select an optimal setting for Super IO device.

Configuration options: [Auto] [IO=C88h; IRQ=5] [IO=C80h; IRQ=5, 7, 9, 10, 11] [IO=C88h; IRQ=5, 7, 9, 10, 11] [IO=C90h; IRQ=5, 7, 9, 10, 11] [IO=C98h; IRQ=5, 7, 9, 10, 11]

2.4.10.5 Serial Port 5 configuration

Set Parameters of Serial Port 4 (COMA)



Serial Port 5 Configuration

- **Serial Port [Enable]**

Enable or Disable Serial Port.

Configuration options: [Disabled] [Enabled]

- **Device Setting [IO=C90h; IRQ=10]**


- **Change Setting[Auto]**

Select an optimal setting for Super IO device.

Configuration options: [Auto] [IO=C90h; IRQ=5] [IO=C80h; IRQ=5, 7, 9, 10, 11] [IO=C88h; IRQ=5, 7, 9, 10, 11] [IO=C90h; IRQ=5, 7, 9, 10, 11] [IO=C98h; IRQ=5, 7, 9, 10, 11]

2.4.10.6 Serial Port 6 configuration

Set Parameters of Serial Port 5 (COMA)



Serial Port 6 Configuration

- **Serial Port [Enable]**

Enable or Disable Serial Port.

Configuration options: [Disabled] [Enabled]

- **Device Setting [IO=C98h; IRQ=11]**

- **Change Setting [Auto]**

Select an optimal setting for Super IO device.

Configuration options: [Auto] [IO=C98h; IRQ=5] [IO=C80h; IRQ=5, 7, 9, 10, 11] [IO=C88h; IRQ=5, 7, 9, 10, 11] [IO=C90h; IRQ=5, 7, 9, 10, 11] [IO=C98h; IRQ=5, 7, 9, 10, 11]


- **Smart Fan Function [Enable]**

Enable or Disable Smart Fan Function

Configuration options: [Disabled] [Enabled]

2.4.10.7 Smart Fan Mode Configuration

Smart Fan Mode configuration



- **System Fan Mode [Manual Mode]**

Select system Fan mode

Configuration options: [Manual Mode] [Thermal Cruise Mode][SNART FAN IV Mode]

- **CPU Fan Mode [Manual Mode]**

Select CPU Fan mode

Configuration options: [Manual Mode] [Thermal Cruise Mode][SNART FAN IV Mode]

- **Chassis Fan Mode [Manual Mode]**

Select Chassis Fan mode

Configuration options: [Manual Mode] [Thermal Cruise Mode][SNART FAN IV Mode]

- **Resume on PS2 KB [Disabled]**

Enable or Disable Resume on PS2 KB Function

Configuration options: [Disabled] [Enabled]

- **Resume on PS2 MS[Disabled]**

Enable or Disable Resume on PS2 MS Function

Configuration options: [Disabled] [Enabled]

- **Resume on Ring [Disabled]**

Enable or Disable Resume on Ring Function

Configuration options: [Disabled] [Enabled]


- **Watch Dog Timer [Disabled]**

Enable or Disable Watch Dog Timer Function

Configuration options: [Disabled] [Enabled]

2.4.10.8 Digital I/O Configuration

Digital I/O Configuration



- **Digital I/O Pin 0 [Input]**

Configure Digital I/O Pin

Configuration options: [Input][Output High][Output Low]

- **Digital I/O Pin 1 [Input]**

Configure Digital I/O Pin

Configuration options: [Input][Output High][Output Low]

- **Digital I/O Pin 2 [Input]**

Configure Digital I/O Pin

Configuration options: [Input][Output High][Output Low]

- **Digital I/O Pin 3 [Input]**

Configure Digital I/O Pin

Configuration options: [Input][Output High][Output Low]

- **Digital I/O Pin 4 [Input]**

Configure Digital I/O Pin

Configuration options: [Input][Output High][Output Low]

- **Digital I/O Pin 5 [Input]**

Configure Digital I/O Pin

Configuration options: [Input][Output High][Output Low]

- **Digital I/O Pin 6 [Input]**

Configure Digital I/O Pin

Configuration options: [Input][Output High][Output Low]

- **Digital I/O Pin 7 [Input]**


Configure Digital I/O Pin

Configuration options: [Input][Output High][Output Low]

2.4.11 Hardware Monitor

● PC Health Status

Display system health status



● CPU Warning Temperature [Disable]

Enabled or Disabled CPU warning temperature Function

Configuration options: [Disable] [50 C/122 F] [55 C/131] [60 C/140 F] [65 C/149 F] [70 C/158 F] [75 C/167 F]

● ACPI Shutdown Temperature [Disable]

Enabled or Disabled CPU warning temperature Function

Configuration options: [Disable] [70 C/158 F] [75 C/167 F] [80 C/176 F] [85 C/185] [90 C/194 F] [95 C/205 F]

2.5 **Chipset**



2.5.1 North Bridge



- **Memory Information**

Display Memory Information

- **Low MMIO Align[1024M]**

Low MMIO resources align at 64MB/1024MB

Configuration options: [64MB][1024MB]

- **DMI Gen2 [Enable]**

Set DMI Gen2 Enable or Disable

Configuration options: [Disabled] [Enabled]

- **VT-d [Disable]**

Set VT-d Enable or Disable

Configuration options: [Disabled] [Enabled]

- **Internal Graphic Adapter [PEG/IGD]**

Select which graphics controller to use as the primary boot device.

Configuration options: [IGD][PCI/IGD][PCI/PEG][PEG/IGD] [PEG/PCI]

- **IGD Memory**

IGG share memory size

Configuration options: [Disable][32M] [64M] [96M] [128M] [160M] [192M] [224M] [256M]
[288M] [320M] [352M] [384M] [416M] [448M] [480M] [512M]

- **Render Standby [Enable]**

Enable/Disable Render standby by internal graphics device.

Configuration options: [Disabled] [Enabled]

- **IGD Multi-Monitor [Disable]**

Enable/Disable IGD Multi-Monitor by internal graphics device.

Configuration options: [Disabled] [Enabled]

- **PCI Express Port**

Enable/Disable PCI Express Port

Configuration options: [Disabled] [Enabled][Auto]

- **PEG Force Gen1**

PCI Express Port PEG Force Gen1

Configuration options: [Disabled] [Enabled][Auto]

- **Detect Non-Compliance**

Detect Non-Compliance PCI Express device in PEG

Configuration options: [Disabled] [Enabled][Auto]

2.5.2 South Bridge

SB Chipset Configuration



- **SMBus Controller [Enable]**

Enable/Disable SMBus controller.

Configuration options: [Disabled] [Enabled]

- **LAN1 Controller [Enable]**

Enable/Disable LAN1 Controller

Configuration options: [Disabled] [Enabled]

- **LAN1 Option-ROM [Disable]**

Enable/Disable LAN1 boot option for legacy network devices.

Configuration options: [Disabled] [Enabled]

- **Wake on LAN1 from S5 [Disable]**

Configuration options: [Disabled] [Enabled]

- **LAN2 Controller [Enable]**

Enable/Disable LAN1 Controller

Configuration options: [Disabled] [Enabled]

- **LAN2 Option-ROM [Disable]**

Enable/Disable LAN2 boot option for legacy network devices.

Configuration options: [Disabled] [Enabled]

- **Wake on LAN2 from S5 [Disable]**

Configuration options: [Disabled] [Enabled]

- **After G3 Status [Power Off]**

Specify what state to go to when power is re-applied after a power failure(G3 state).

Configuration options: [Power Off] [Power On] [Last state]

Audio Configuration

- **Azalia HD Audio [Enable]**

Enable/Disable Azalia HD Audio

Configuration options: [Disabled] [Enabled]

- **Azalia internal HDMI codec [Enable]**

Enable/Disable Azalia internal HDMI codec

Configuration options: [Disabled] [Enabled]


High Precision Event Timer Configuration

- **High Precision Timer [Enable]**

Enable/Disable the High Precision Timer

Configuration options: [Disabled] [Enabled]

2.5.2.1 PCI Express Ports Configuration



- **PCI Express Port 1**

Enable/Disable PCI Express Port 1

Configuration options: [Disabled] [Enabled][Auto]

- **PCI Express Port 7**

Enable/Disable PCI Express Port 7

Configuration options: [Disabled] [Enabled][Auto]

- **PCIe Sub Decode [Disable]**

Enable/Disable PCIe Sub Decode Port. (This option is available when subtractive decode agent Enable (PCHTrap9[14] = '1b')

Configuration options: [Disabled] [Enabled][Auto]

2.5.2.2 USB Configuration



- **EHCI controller 1 [Enabled]**

Enable/Disable USB 2.0(EHCI) support

Configuration options: [Disabled] [Enabled]


- **EHCI controller 2 [Enabled]**

Enable/Disable USB 2.0(EHCI) support

Configuration options: [Disabled] [Enabled]

2.5.3 ME Subsystem

Intel ME Subsystem Configuration



- **ME Version[]**

Display ME version

- **ME Subsystem [Enabled]**

Configuration options: [Disabled] [Enabled]

- **ME Temporary Disable [Disabled]**

Configuration options: [Disabled] [Enabled]

- **End of Post Message [Enabled]**


Configuration options: [Disabled] [Enabled]

- **Execute MEBx [Normal]**

Configuration options: [Normal] [Hidden Ctrl + P][Enter MEBx Setup]

2.6 Boot

Boot Configuration



- **Setup Prompt Timeout [1]**

Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.

- **Bootup NumLock State [On]**

Select the keyboard NumLock state

Configuration options: [On] [Off]

- **Quick Boot [Disable]**

Configuration options: [Disable] [Enable]

- **CSM16 Module Version [07.64]**

Display CSM16 Module Version.

- **GataA20 Active [Upon Request]**

Upon Request – GA20 can be disabled using BIOS services.

Always – do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.

Configuration options: [Upon Request] [Always]

- **Option ROM Messages [Force BIOS]**

Set display mode for option ROM.

Configuration options: [Force BIOS] [Keep Current]

- **Interrupt 19 Capture [Disable]**

Enabled : Allow option ROMs to trap Int19.


Configuration options: [Disabled][Enabled]

- **Boot option priorities [Built-in EFI Shell]**

Select the system boot order.

Configuration options: [Built-in EFI Shell][Disabled]

2.7 Security




- **Administrator Password**

Set setup Administrator Password

- **User Password**

Set User Password

2.8 **Save & Exit**



- **Save changes and Exit**

Exit system setup after saving the changes.

- **Discard changes and Exit**

Exit system setup without saving the changes.

- **Save changes and Reset**

Reset the system after saving the changes.

- **Discard changes and Reset**

Reset the system without saving the changes.

Save Option

- **Save changes**

Save changes done so far to any of the setup option.

- **Discard changes**

Discard changes done so far to any of the setup option.

- **Restore Defaults**

Restore/Load default values for all the setup option.

- **Save as User Defaults**

Save the changes done so far as User Defaults.

- **Restore User Defaults**

Restore the user defaults to all the setup options

BOOT Override

- **Built-in EFI Shell**