

User Manual

HDMI TV Dongle




Table of Content

ONE Product introduce

| | |
|------------------------|---|
| Interface & Connection | 2 |
| Remote Control | 3 |
| Package contents | 3 |

TWO Main Menu introduction



| | |
|----------------------------------|---|
| Main Menu | 4 |
| Main menu interface introduction | 4 |

THREE Application

| | |
|----------------------|----|
| Applications | 5 |
| Settings | 6 |
| Favorite | 11 |
| File browser | 12 |
| Web browser | 12 |
| Four Troubleshooting | 13 |
| FAQ | 14 |

Simple Explanation of housing

1.1 Interface & Connection




| | | | | |
|--|--------------|---|--|---|
| | POWER | 1.press the power button to standby or turn on. 2.keep press the power button over 3seconds it will turn off. | | left |
| | MOUSE | switch to Mouse mode to up/down/left/right | | up |
| | PaW | page down | | ok |
| | Pg UP | Page up | | right |
| | VOL+ | Vol+ | | down |
| | VOL- | Vol- | | press to choose function menu of corresponding application in Video,music,photo and website |
| | PREV | Fast backward | | Press to return back to previous menu |
| | NEXT | Fast forward | | Fast key to go back to main menu |

Accessories:

Accessory:


- ◆ HDMI TV DONGLE
- ◆ Remote Control
- ◆ IR CABLE
- ◆ MANUAL
- ◆ USB CABLE

Main Manual



The TV dongle player provides two kind of main menu interface for user to choose. After you power on , below dialog will popup, you can choose "TVD launcher" or "Launcher".

Launcher interface



TVD launcher interface



Back to previous action



Back to Main Menu




Click the icon to modify wallpaper & manage apps and system settings



Click the upper right button to find the application which you installed




Application



Choose application, to download the Apps from play store & enjoy the apps what you want




Setting




WiFi setting

Please turn on WiFi option and choose the access point you need



Data usage



More

Setup the different network



Device


Sound

Adjust the volume, click sound and audio output mode



Display

Adjust the display level and output setting




Storage

The Storage level and space



Apps

List all apps from download or SD card




Personal

Account & Sync


To create and sync google account



Location Services




Security




Language & input

Set the language and input method



Backup & reset


Backup or reset your system back to default setting



System


Date & time

Setting Date and time




Accessibility

Setup the accessibility




Developer options




About device

List the device information




Favorite

You can put your favorites into the folder



File Browser

When get in to file browser, you can search all equipment form local memory or network device, then you can play video, music and picture.



Web Browser

You can visit whatever website you want



Trouble shooting

Warning

Under no circumstances should you try to repair the box by yourself, as this will invalidate the warranty. Do not open the box as there is a risk of electric shock. If a fault occurs, first check with points listed below before taking the box for repair. If you are unable to remedy a problem by following hints, consult your dealer for help.

| problem | solution |
|---|--|
| no power | Check if the power adapter is properly connected . Check if the power adapter damaged or not. |
| No picture | Re-connect with HDMI cable or AV cable. Re-connect power adapter; Check if the output mode for TV and media box keep the same. Check if the TV is switched on. |
| No Sound or distorted sound | Adjust the volume Check if the cable connect to TV and media playfer well. Check that the speakers are connected correctly |
| No audio or digital output | check if the cable connected well. Check if your amplifier is set correctly Re-connect power adapter. Check if the output mode for TV and media box keep the same. |
| The remote control does not work | Aim the remote control directly at the sensor at the front of the box. Reduce the distance to the box. Replace the batteries in the remote control. |
| Player does not respond to some operating commands during display | Operations may not be permitted. Refer to the User manual. Possibility of system halted, re-insert with Power adaptor to restart. |
| No sound during movies display | The Audio codec may not be supported by the box. You can change to the supported audio on playing menu. Check the volume. Check if the cable connected well. Check if the output mode for TV and media box keep the same. |
| The contents of the USB flash drive&SD/MMC card cannot be read | The USB flash drive format is not compatible with the box. If one of the USB cannot read, please turn off the box and restart it. |
| No sound with HDMI connectin | Check if TV output mode is the same with media box. Check your TV system setup. Check the volume. |
| The TV screen is blank and the palyer LED is blinking | Turn off your palyer, wait 30 seconds, turn it on again, if under HDMI status, Check if HDMI connection is correct or change another HDMI cable. Set the output solution of this box into 720P. |

Warning

Do not open the box as there is a risk of electric shock and warranty will void

Frequently Asked Questions

Q1. What to do when the system crashes or buttons won't respond?

Answer: Check the indicator light at the front of the removable storage device. If the red and green lights flash quickly, please wait for a second and then resume, as the system may be reading data. If it is clear that the system crashed, power off from the remote control or press the power button on the front panel and re-power on shortly.

Q2. What to do when there's an abnormal start-up of the TV box, or no image output?

Answer: Check the system in following steps:

Check if the power indicator light of the TV box is on. If not, please check if the power is properly connected.

Check if there is signal output of TV images. If not, please check if the video output cable is properly connected and the correct video channel output (YPbPr or HD) is setup on the TV set. It should support 720P input and above.

Remove the SD card, USB or removable hard disk. Plug in after system starts.

Third party software might cause system become unstable; uninstall previously installed software.

Q3. What to do when the player cannot play?

Answer: First, please be sure that the format of video file is supported by the Smart TV Player. It is suggested to reboot the system and play again to verify. If the file still cannot be opened, then this video file may not be supported by the video player.

Q4. What to do when no network access to the main interface?

Answer:

Please check if the device has network connection.

Please check if the network cable is damaged.

Please check if the router is in normal working order.

Please check if the DHCP of the router is enabled. If not, please setup accordingly.

If a wireless network card is used, please check whether it gets access to network, And whether the DHCP of the router is enabled. If not, please setup accordingly.