

User Manual  
for  
Naviter Oudie

Naviter d.o.o., Gradnikova 89, 4240 Radovljica, Slovenia  
[www.naviter.com](http://www.naviter.com) [support@naviter.com](mailto:support@naviter.com)

## Introduction

---

Thank you for choosing Oudie. Company Naviter is dedicated to solving glider pilot's problems and Oudie is one of the answers in this challenge. Its intended use is helping glider, para-glider and hang glider pilots navigate during leisure, cross country and competition flights.

Oudie works great in combination with other Naviter products such as SeeYou for the PC, ConnectMe, Soaring Spot and others.

We sincerely hope that you will be satisfied with your purchase and would be delighted to hear back from you.

More information, latest firmware and support are available through [www.naviter.com](http://www.naviter.com)

# Index

---

Introduction .....	1
Index.....	2
What's in the box .....	3
Getting to know Oudie.....	4
Turning Oudie on and off.....	5
Charging the battery .....	6
Internal GPS reception.....	7
Mounting with the holder.....	8
Starting the navigation.....	9
Connecting to external Data source .....	10
Troubleshooting.....	11
Notice of non-liability.....	12
Limited Warranty .....	13
Technical specification .....	14

## What's in the box

---

Your Oudie was delivered in a sealed package with the following items:

1. Oudie
2. USB data cable
3. Wall charger
4. Car charger
5. Serial cable and 12V charger cable
6. Cradle
7. Suction cup mount
8. ~~CD-ROM~~
9. Getting started manual

## Getting to know Oudie

---



1. Power On/Off button
2. Power indicator
3. Earphone jack
4. microSD card slot
5. Mini USB port
6. Stylus
7. Speaker
8. Reset key

## Turning Oudie on and off

---

To turn the Oudie ON press the power button for 1 second .

To turn the Oudie OFF, press the power button for 1 second while the device is running.

To reboot press the reset button on the back of the device.

## Charging the battery

---

There are several ways to charge Oudie's internal battery.:

1. Connect the wall charger cable to AC 110-240 V power source and insert the connector to the mini USB slot on the Oudie .
2. Connect the car charger to the DC 12-24 V source and insert the connector to the mini USB slot on the Oudie.
3. Connect the Power and Serial data cable to DC 12 V power source and insert the USB connector to the mini USB slot on the Oudie.

The Power indicator light indicates charging status of the Oudie. Green light means that the device's internal battery is fully charged. Amber light indicates that the battery is charging.

## Internal GPS reception

---

Oudie has an integrated GPS receiver which delivers navigation data on COM 1 at 4800bps.

When the navigation device is turned on for the first time or after a long period of non-use, initialising the integrated GPS receiver can take up to 20 minutes.

Optimal conditions for problem-free and fast GPS receptions are: having a clear view of the open sky, no high buildings immediately close by and remaining in one place until the GPS position has been determined.

## Mounting with the holder

---

The mounting kit consists of the cradle and the suction cup mount. First insert the cradle into the suction cup mount until you hear and feel a strong click.

Then insert Oudie into the cradle so that you hear a strong click again.

Use the screw on the holder to adjust the tightness of the cradle. Turn the cradle into ideal viewing position for your use.

*Note: Do not place the Oudie in positions which obstruct pilot's movements, vision of nearby traffic or instruments.*

## Starting the navigation

---

When you turn the Oudie on for the first time or after a reset, navigation software is started automatically.

For more information about the navigation software in the Oudie please consult the documentation supplied on the CD ROM.

## **Connecting to external Data source**

---

### **Serial cable**

The supplied Serial data cable enables you to connect to external data source such as your Variometer, Flight data recorder, anti-collision device or similar.

It is important to understand that the Supplied Serial cable must be connected to 12 V direct current source in order to work.

### **Bluetooth**

Another way to connect to external data source is to connect through Bluetooth. Use the Oudie's navigation software to pair Bluetooth device with Oudie in order to receive serial data from your device.

## Troubleshooting

---

**Symptom:** *Device doesn't turn on after pressing the power button or shuts down during bootup.*

Solution: Charge the device's internal battery

**Symptom:** *Navigation software does not find my position*

Solution: Get out where the view to the sky is unobstructed and wait for up to 20 minutes. If you still cannot acquire satellites check Menu > Settings > Input options.

**Symptom:** *Navigation software displays NODATA in the GPS Fix navbox.*

Solution: Check the Menu > Settings > Input options. Internal GPS is on COM 1, external Serial port is COM 4. Other parameters depend on the connected device.

For **other problems** contact [support@naviter.com](mailto:support@naviter.com)

## **Notice of non-liability**

---

This is a personal navigation assistance device only. It is not a replacement for any legally required device, method or service. User must maintain all safety measures as if this device was not on board of the aircraft.

Before it is put to use it is the responsibility of any user who will use this device to become familiar with operation and safety aspects of this device. Using the system improperly could cause failure and lead to possible property damage and/or personal injury.

Naviter assumes no responsibility for property damage, accidents, injury or death that may result from the misuse of this device/equipment. This includes any use of this device/equipment outside the scope of common sense, the User Manual, inserts and other related documentation.

## Limited Warranty

---

Naviter company warrants your Oudie against defects in materials and workmanship for one (1) year from date of purchase invoice. The warranty is non-transferable. Should any part of the Oudie become defective within the warranty period return the Oudie with a description of what/why it is not functioning and we will repair or replace it, at our discretion, free of charge (you pay only shipping to Naviter).

**Return the unit to:**

**Naviter d.o.o.**

**Gradnikova 89**

**SI-4240 Radovljica**

**Slovenia**

The warranty is non-transferable and only valid if Naviter determines that the system and its components have not been damaged due to improper use, been submerged in fluids, dismantled or abused. Naviter reserves the right to determine if repairs are to be done under warranty or at a nominal charge. **As a proof of activated warranty you must send a copy of the purchase invoice.**

## Technical specification

---

Device	
<b>Processor</b>	ARM 11, 500 MHz
<b>RAM / Flash</b>	128 MB / 4GB
<b>Battery</b>	1800 mAh Li-Po (3 hrs)
<b>Size</b>	135 x 86 x 14 mm 5.3 x 3.4 x 0.55 inch
<b>Connectivity</b>	USB 2.0, Serial, BT
<b>Expansion slot</b>	microSD HC

Screen	
<b>Size</b>	5 inch TFT LCD
<b>Resolution</b>	480 x 272 pixels
<b>Portrait mode</b>	Yes
<b>Landscape mode</b>	Yes

Software	
<b>Preinstalled maps</b>	World-wide
<b>Installed software</b>	SeeYou Mobile SE
<b>Localization</b>	Yes (>17 languages)

