

SERENITY RELAXATION RELAXATION



MASSAGE CHAIR

Operation Manual



Before operating the unit, please read the instruction completely

IMPORTANT SAFETY INSTRUCTIONS

- Basic precautions should always be followed when using an electronic unit, including the following.
- Please ensure that you read all instructions before using the unit.

DANGER To reduce the risk of electric shock

- Always unplug the unit immediately after using.
- Always unplug the unit before cleaning.

WARNING To reduce the risk of burns, fire, electric shock, or injury to people, take the following precautions:

- Do not stand on the unit
- Always insert the power plug all the way into the outlet to reduce the risk of short-circuiting and fire.
- Close and continuous supervision is necessary when the unit is used by people who are limited in their ability to move around or to communicate with others.
- Only use the unit for the purpose described in this Operation Manual.
- The unit should never be left unattended when plugged in. Always unplug the unit when not in use.
- Do not use any accessories other than those recommended by the manufacturer.
- The unit should not be used by children. Keep children away from the unit. Always return the chair back to the upright position and retract the calfrest completely to avoid injury. Make sure that nothing is in the way when retracting the calfrest. Always switch the Lock Switch to the Lock position when the chair is not in use.
- Keep power cords away from heated surfaces. Do not carry the unit by the power cord. Do not allow pins, or moisture to get inside the plug. See Grounding Instructions.
- Always make sure all fabric covered surfaces are not damaged or ripped before using the unit. Please check other areas to ensure that the fabric has not been ripped. If you spot any damages, stop using the unit immediately no matter how small the damaged area might be, unplug the power cord and have the unit repaired at an authorized service center.

- Do not use the unit in bathrooms or other damp or humid places as it may cause electric shock or cause the unit to malfunction. Do not spill liquid onto the control panel surface.
- Do not use the unit near heating appliances or with electric blankets
- Never block the air openings during operation and make sure that all air openings are kept free of lint and hair. Do not drop or insert anything into any of the openings of the unit.
- Never operate the unit if it has a damaged power cord or plug. Return the unit to the nearest authorized service center if it is not working properly, or the unit has been dropped or damaged, or immersed in water.
- Do not use the unit outdoors.
- Do not use the unit in places where aerosol spray products are in use or where oxygen is being used.
- When unplugging the unit, turn off all controls and turn off the main power switch before removing the plug from the power outlet. Do not use the unit with a transformer as it may lead to malfunction or electric shock.
- Connect this unit to a properly grounded outlet only and use a surge protector to protect the electronics.
- To avoid electric shock or injury, do not attempt to open or disassemble any part of the unit on your own.
- Do not repair power cord on your own if it is damaged. Please contact our company or authorized service dealer.

SAVE THESE INSTRUCTIONS **SAFETY PRECAUTIONS** To avoid the risk of injury

- To prevent excessive massaging, do not use the unit for more than a total of 30 minutes each session. Exercise extreme care when you use this mode in order to avoid back pain or injury. Use only for short periods of time (no more than 30 minutes).
- Never put your fingers or feet in the space between the backrest and seat, the backrest and the armrest, the seat and the cover under the armrest. Do not place your fingers or any part of your body underneath the calfrest.
- Do not use the unit against bare skin. While thin clothing may increase effectiveness, exposing the skin directly to the massage may irritate the skin.
- Do not use the unit while wearing anything hard on your head such as hair accessories, etc.
- Do not use excessively strong massage action on the back of the neck.
- Persons with any of the conditions listed below or who are undergoing medical treatment should consult with their physicians before using the unit:
 - a) Pregnant women, people who are ill, or in poor physical shape.
 - b) People suffering from back, neck, shoulder, or hip pain.
 - c) People who have a pacemaker, defibrillator, or other personal medical devices prone to electronic interference. Consult with the manufacturer of your device before using the unit.
 - d) People with heart diseases.
 - e) People who are prohibited from receiving massages by a physician due to thrombosis or aneurism, acute varicose veins or other circulatory disorders.
 - f) People with irregular curvatures of the spine.

- While using the massager, if you start feeling sick or if the massage seems painful, stop using it immediately. While using the massager, if the pressure seems too high, or strong, press the Stop button immediately.
- Do not fall asleep while using the unit. Do not use the unit after alcohol consumption.
- Do not allow children to play on the lounger or operate the unit. The calfrest folds down upon closing so a child could possibly be injured. Always leave the lounger in an upright and closed position.
- Do not allow children or pets to play on or around the unit especially during operation.
- Do not unplug the unit during operation. Unplug the unit immediately if there is a power outage.
- Please maintain the correct sitting posture, do not sit on the calfrest or sit with your legs resting on the headrest, otherwise the unit may fall over. Never put the majority of your weight on the chair back to avoid tipping over.
- Empty your pockets of hard objects before sitting on the unit.

OPERATING PRECAUTIONS – To avoid damaging the chair, follow precautions listed below

- The chair is designed for a maximum user weight of 250lbs. Exceeding the maximum weight may cause permanent damage to the massage mechanism and/or other components of the unit. Any such damage is deemed to be user abuse and is not covered under the Limited Warranty.
- Do not treat the chair roughly, such as turning the chair on its side, turning the chair over or standing on it.
- Do not treat the covering roughly. Keep sharp or pointed objects away from the covering of the chair.
- Be careful not to drop cigarette ashes, lit cigarettes, matches or other hot objects on the chair.
- Exposure to direct sunlight can cause fading or a change in color of the covering.
- If the massager functions abnormally, immediately turn off the power and have the massager checked by an authorized service center.
- Do not attempt to repair the massager yourself.
- Do not repeatedly operate any switch at short intervals. Such action may cause the switch to malfunction.
- Certain sounds may be heard coming from the massager while in use. This is due to the structure of the massager and is normal.
- Make sure there are no obstacles behind the chair before reclining it. The chair can be reclined to a maximum angle of 155°. If the back hits a wall or pillar, the chair may malfunction. Be sure to have enough space behind the chair.
- Recline the chair slowly in order to avoid contact with an obstacle.

- After each massage, turn the power switch, which is located on the back side of the chair, to the "Off" position and turn its lock switch to the "Lock" position.
- Do not sit on the chair with wet hair/body.
- The unit must not be used in "wet rooms" (i.e. saunas and swimming pools) or outdoors.


GROUNDING INSTRUCTIONS

- The product must be grounded. If it should malfunction, grounding provides the path of least resistance for electric current to reduce the risk of electric shock.
- This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.


Danger

- Improper connection of the equipment-grounding connector can result in a risk of electric shock. Check with a qualified electrician if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product even if it does not fit the outlet. Have a proper outlet installed by a qualified electrician.
- This product is for use on a nominal 120-volt circuit and has a grounding plug that looks like the plug shown in figure A. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.

Figure A



PARTS AND FUNCTIONS



Back Cushion
with air pressure massage function

Pillow
with air pressure massage function

Massage Heads
(The massage heads are behind the fabric of the chair back)


Armrest

Control Panel
Open the control panel for massage features, USB port and headphone jack

Seat
with air pressure massage function, vibration massage and heaters


Calfrest
With vibration massage and heaters

PARTS AND FUNCTIONS



Back Cushion Zipper

Back Cover(wooden)




1-Power Switch
2-Lock Switch

Power Supply Box


Swivel Base

Power Plug

PARTS AND FUNCTIONS



OPEN the cover of remote panel




- | | | |
|--|-------------------------------|--|
| | Power | Power Switch |
| | Heat | Heat Switch
Select Full Body Heat On/Off |
| | Air Pressure Mode | Air Massage Programs
Select Program I, II, III or Off. |
| | Air Pressure Intensity | Air Massage Intensity
Select Program I, II, or III. |
| | Vibration Mode | Vibration Massage Programs
Select Program I, II, III or Off. |
| | Vibration Location | Vibration Locations
Select Program I, II or III. |
| | Lumbar Massage | Lumbar Massage Program
Select the program On/Off. |
| | Lumbar Intensity | Lumbar Massage Intensity
Select Program I, II, or III. |
| | DOWN | Down - Chair Back & Leg Rest
Push to recline the chair back and raise the leg rest. |
| | UP | Up - Chair Back & Leg Rest
Push to incline the chair back and lower the leg rest. |

BEFORE USING THE UNIT

Where to Use the Unit

Ensure there is adequate space for reclining.



CAUTION


- Do not use the unit in an area with high humidity, such as the bathroom, as this can lead to electric shock or other accidents.
- Place the unit on a completely leveled surface. Failure to do so may cause the lounger to tip over, leading to accidents.
- Do not use the massage lounger in direct sunlight or in a place where it will be exposed to high temperatures, such as in front of a heater, as this can cause discoloration or hardening of the upholstery.
- Place the unit on a mat to prevent floor damage.

ADJUST THE SEAT


Adjusting the Calfrest and Backrest

1-Turn the unit onto the Standby Mode by plugging in the Power Plug, turning on the Lock Switch and the Power Switch.

2-Press **UP** **DOWN** to adjust the angle of the backrest and calfrest.



DOWN



UP

Adjusting the Pillow Position



CLEANING AND MAINTENANCE

● **Always unplug the unit before cleaning it. Never touch a power plug with wet hands.**

-Failure to follow these instructions may lead to electrocution or burns.

Cleaning The Upholstery

- Wipe these areas with a soft, dry cloth. (Do NOT use cloths containing any kind of chemical, etc).
- If the upholstery is particularly dirty, please:
 1. Soak a soft cloth in water or a 3% - 5% solution of mild detergent, wring it out thoroughly;
 2. Wipe the surface with the wetted cloth;
 3. Next, rinse the cloth in water, wring it out thoroughly and then wipe any remaining detergent from the surface;
 4. Wipe the surfaces with a soft dry cloth;
 5. Allow them to dry naturally. (Do NOT use a hair dryer to dry the surfaces).
- Do not allow these areas to get in touch with plastic for extended periods of time as it may lead to discoloration.
- Please do NOT use paint thinners, benzene, or alcohol to clean the surface.

Cleaning Remote Panel, Wood Chair Back and Swivel Base

- Wipe the unit with a cloth that has been soaked in a mild detergent and thoroughly wrung out.
- Next, wipe the unit with a cloth that has been moistened with water only and thoroughly wrung out.
- Make sure you thoroughly wring out the cloth first when cleaning the control panel.
- Allow the unit to dry naturally.
- Please do NOT use thinners, benzene or alcohol to clean the surface.


CLEANING AND MAINTENANCE

CAUTION

- Do not move the unit while someone is sitting on it. Do not place objects on or sit, climb, or stand on the calfrest.

Lifting and Moving the Unit

- Always use two persons to lift the unit. Use one person on the left and one person on the right to hold underneath the armrests to carefully move the unit, see the picture below.
- Hold onto to the armrest tightly to prevent damage to the unit and the floor



TROUBLESHOOTING

The following sounds are perfectly normal and will not have any effect on the operation of the unit:

- Sound of the armrest and back cushion rubbing against other objects during recline
- Sound of Tapping.
- Sound when the unit is at Standby Mode by flipping the Power Switch to "On" .
- Sound when sitting down.
- Sound of air being pumped in during an Air Pressure Massage.
- Sound of air being released during an Air Pressure Massage.
- Deep Vibration sounds during Vibration Massage
- Rattling sound of the calfrest.

Problem

Problem	Possible Reasons	Solutions
Not working when plugged in.	<ul style="list-style-type: none">-The power switch is off.- The lock switch is off.-Power plug is not properly connected with the outlet.-The fuse is blown.	<ul style="list-style-type: none">-Turn on the power switch.-Turn on the lock switch.-Reconnect the power plug with the outlet.-Replace the fuse with the same specifications.
The unit makes a humming sound or clip clop clip clop noise during operation.	Sounds are made by the air pump, the electrical parts and the mechanical parts.	The sounds are normal. No need for maintenance.
You may notice an increase in noise during a session.	The unit has been used over its time limit.	Shut down the unit and turn it back on after a half an hour.
The unit stops working suddenly.	Time out.	Shut down the unit and turn it back on after a half an hour.



SERENITY RELAXATION MASSAGE CHAIR



www.omegamassage.com