
paKo

The Observer's
User Interface to the
New Control System
at the IRAM 30-Meter Telescope

Title: paKo—Observer's User Interface to the NCS at the 30-M Telescope

Identifier—MasterURL: <http://www.iram.es/IRAMES/documents/ncs30mPako>

File: pako

Revision: NIKA, E150 switch box, v 1.1.14

Revision Date: 2012-12-01

Expiration Date: 2013-11-31

Supersedes: v1.1.11

Is superseded by:

Authors: Hans Ungerechts

Contributors: Joaquín Santiago

Affiliations: IRAM, Granada

Addresses: Avenida Divina Pastora, Local 20, 18012 Granada, Spain

Audience: observers, operators, astronomers

Publisher: IRAM, Granada

Subject: NCS 30m: Observer's User Interface paKo

Keywords: NCS, Documentation, User Interface, Observer

Description - about this document:

This is the documentation of the observer's user interface to the New Control System (NCS). The user IF program is nicknamed "PAKO" = "paKo for astronomers' K(c)ontrol of observations".

Revision v 1.1.12 introduced support for GISMO and the observing mode Lissajous.

Revision v 1.1.14 supports NIKA, SUBSCAN /TUNE for NIKA, and the modification (2012-10) of the switch box for E150.

README. Observers who are new to the NCS are encouraged to read sections 1, 2, and 4. Note that much of the space in these sections is taken up by examples, so the actual text is not very long or hard to read!

References and Related Documents—Short List:

1. [New Control System for the 30m Telescope](#)

History of this Document:

1. v 0.* HU
2. v 1.0.0 2005-12-16 HU
3. v 1.0.1 2005-12-22 HU
4. v 1.0.2 2006-01-22 HU
5. v 1.0.4 2006-08-07 HU
6. v 1.0.6.3 2007-02-22 HU
7. v 1.0.7 2007-06-28 HU
8. v 1.0.9 2007-10-24 HU
9. v 1.1.1 2009-05-12 HU
10. v 1.1.4 2010-12-01 HU
11. v 1.1.5 2011-04-25 BBC HU
12. v 1.1.6 2011-07-31 FTS 32GHz HU
13. v 1.1.11 2011-11-11 EMIR E230 E330 upgrade HU
14. v 1.1.12 2012-04-01 GISMO, Lissajous HU
15. v 1.1.14 2012-12-01 NIKA, E150 switch box HU

Pending Items:

(2006-08-07) TBD: v1.2

Contents

1	paKo— Introduction and Overview	9
2	paKo — Guide of the Perplexed	10
2.1	PAKO and SIC	10
2.2	PAKO and Linux	10
2.3	Running PAKO offline and several instances of PAKO	10
2.4	Help	10
2.5	SET LEVEL for Errors, Warnings, and Infos	11
2.6	Saving and Restoring	11
2.7	Observation Queues and Starting	12
2.8	Source and Line Catalogs	13
2.9	Switching Modes	13
2.10	Observing Modes	13
2.11	Combinations of Switching and Observing Modes	14
2.12	Coordinate Systems, Map Projections, and Position Offsets	14
2.13	Receiver Setup and Calibration Parameters	16
2.14	Backends	16
2.15	Continuous Data Acquisition and Data Streams	16
2.16	Display of Parameters	16
2.17	Preview Plots	16
2.18	Defaults	18
2.19	Ranges and checks	18
2.20	Independence of Command Parameters	19
2.21	Option keywords	19
2.22	Logical (YES/NO or ON/OFF) Options	19
2.23	Example Scripts and Catalogs	20
3	PaKo’s simplest recipe	21
4	PaKo’s Cook Book	24
4.1	Set General Information	24
4.2	Specify your Source Catalog and/or Source	25
4.3	Spectral Line Observations with Heterodyne Receivers	28
4.3.1	Specify your Line Catalog	28
4.3.2	Setup of the Receivers (Frontends)	30
4.3.3	Setup of the Backends (Spectrometers and Continuum)	32
4.3.4	Switching Mode	35
4.3.5	CALIBRATE	36
4.3.6	POINTING	37
4.3.7	FOCUS	38
4.3.8	TRACK (Single Position with FREQUENCY SWITCHING)	39
4.3.9	ON-OFF (“Position Switching” and Wobbler Switching)	40
4.3.10	OTF (On-The-Fly Mapping)	42
4.4	Continuum Observations with Bolometers	45

5	NCS User's Guide	46
5.1	Set General Information	46
5.2	Specify your Source Catalog and/or Source	47
5.3	Spectral Line Observations with Heterodyne Receivers	53
5.3.1	Specify your Line Catalog	53
5.3.2	Setup of the Receivers (Frontends)	55
5.3.3	Setup of the Backends (Spectrometers and Continuum)	62
5.3.4	CALIBRATE	67
5.3.5	POINTING	67
5.3.6	FOCUS	68
5.3.7	TRACK (Single Position with FREQUENCY SWITCHING)	69
5.3.8	ON-OFF ("Position Switching" and Wobbler ON-OFF)	71
5.3.9	OTF (On-The-Fly Mapping)	73
5.3.10	RASTER (Raster Mapping)	76
5.4	Continuum Observations with Bolometers	76
5.4.1	Setup of the Bolometer	76
5.4.2	Switching Mode	76
5.4.3	POINTING	76
5.4.4	FOCUS	77
5.4.5	TIP (Antenna Tipping or "Skydip")	78
5.4.6	ON-OFF (Wobbler Switching)	78
5.4.7	OTF (On-The-Fly Mapping with Wobbler Switching)	79
6	NCS Explained	81
6.1	Coordinate Systems, Map Projections, and Position Offsets	81
6.2	Azimuth Topology	83
6.3	Switching Modes	83
6.3.1	BEAM SWITCHING	85
6.3.2	FREQUENCY SWITCHING	85
6.3.3	WOBBLER SWITCHING	85
6.3.4	TOTAL POWER	86
6.4	Observing Modes	86
6.4.1	CALIBRATE	86
6.4.2	POINTING	86
6.4.3	FOCUS	87
6.4.4	TIP	87
6.4.5	ONOFF	87
6.4.6	OTFMAP	88
6.4.7	RASTER	88
6.4.8	TRACK	88
6.4.9	VLBI	89
6.5	Receivers	89
6.6	Backends	89

7	PAKO Language Internal Help	90
7.1	Language	91
7.1.1	Language NEWS	92
7.1.2	Language HELP	94
7.2	BACKEND	95
7.2.1	BACKEND BBC	97
7.2.2	BACKEND FTS	97
7.2.3	BACKEND /DEFAULTS	99
7.2.4	BACKEND /CLEAR	99
7.2.5	BACKEND /CONNECT	100
7.2.6	BACKEND /DISCONNECT	100
7.2.7	BACKEND /FINE	100
7.2.8	BACKEND /MODE	100
7.2.9	BACKEND /LINENAME	101
7.2.10	BACKEND /PERCENTAGE	101
7.2.11	BACKEND /RECEIVER	102
7.2.12	BACKEND EXAMPLES	102
7.3	CALIBRATE	105
7.3.1	CALIBRATE /DEFAULTS	106
7.3.2	CALIBRATE /AMBIENT	106
7.3.3	CALIBRATE /COLD	106
7.3.4	CALIBRATE /GAINIMAGE	106
7.3.5	CALIBRATE /GRID	106
7.3.6	CALIBRATE /SKY	107
7.3.7	CALIBRATE /SYSTEM	107
7.3.8	CALIBRATE /TCALIBRATE	108
7.4	CATALOG	108
7.4.1	CATALOG SOURCE	109
7.4.2	CATALOG LINE	109
7.5	DISPLAY	110
7.6	DIYLIST	110
7.6.1	DIYLIST /CLEAR	110
7.6.2	DIYLIST /PURPOSE	110
7.7	FOCUS	111
7.7.1	FOCUS /DEFAULTS	111
7.7.2	FOCUS /NSUBSCANS	111
7.7.3	FOCUS /TSUBSCAN	112
7.7.4	FOCUS EXAMPLES	112
7.8	LISSAJOUS	112
7.8.1	LISSAJOUS /CENTER	113
7.8.2	LISSAJOUS /FREQUENCY	114
7.8.3	LISSAJOUS /PHASES	114
7.8.4	LISSAJOUS /SYSTEM	114
7.8.5	LISSAJOUS /TOTF	115
7.9	OFFSETS	115
7.9.1	OFFSETS /DEFAULTS	117
7.9.2	OFFSETS /CLEAR	117

7.9.3	OFFSETS /SYSTEM	117
7.10	ONOFF	118
7.10.1	ONOFF /DEFAULTS	120
7.10.2	ONOFF /NSUBSCANS	120
7.10.3	ONOFF /REFERENCE	120
7.10.4	ONOFF /SWWOBBLER	120
7.10.5	ONOFF /SYMMETRIC	121
7.10.6	ONOFF /SYSTEM	122
7.10.7	ONOFF /TSUBSCAN	123
7.10.8	ONOFF EXAMPLES	123
7.11	OTFMAP	125
7.11.1	OTFMAP /DEFAULTS	127
7.11.2	OTFMAP /CROLOOP	127
7.11.3	OTFMAP /NOTF	127
7.11.4	OTFMAP /REFERENCE	128
7.11.5	OTFMAP /STEP	128
7.11.6	OTFMAP /SPEED	128
7.11.7	OTFMAP /SYSTEM	128
7.11.8	OTFMAP /TOTF	129
7.11.9	OTFMAP /TREFERENCE	130
7.11.10	OTFMAP /ZIGZAG	130
7.11.11	OTFMAP EXAMPLES	130
7.12	POINTING	132
7.12.1	POINTING /DEFAULTS	132
7.12.2	POINTING /DOUBLEBEAM	132
7.12.3	POINTING /NOTF	133
7.12.4	POINTING /TOTF	133
7.12.5	POINTING EXAMPLES	133
7.13	RECEIVER	134
7.13.1	RECEIVER /DEFAULTS	136
7.13.2	RECEIVER /CLEAR	136
7.13.3	RECEIVER /CONNECT	136
7.13.4	RECEIVER /DEROTATOR	136
7.13.5	RECEIVER /DISCONNECT	136
7.13.6	RECEIVER /DOPPLER	137
7.13.7	RECEIVER /EFFICIENCY	137
7.13.8	RECEIVER /GAINIMAGE	137
7.13.9	RECEIVER /HORIZONTAL	137
7.13.10	RECEIVER /SCALE	138
7.13.11	RECEIVER /TEMPLOAD	138
7.13.12	RECEIVER /VERTICAL	139
7.13.13	RECEIVER /WIDTH	139
7.13.14	RECEIVER EXAMPLES	140
7.14	SAVE	141
7.14.1	SAVE /APPEND	142
7.14.2	SAVE /FILE	142
7.14.3	SAVE EXAMPLES	142

7.15	SET	143
7.15.1	SET DOSUBMIT	144
7.15.2	SET FOCUS	144
7.15.3	SET LEVEL	144
7.15.4	SET POINTING	145
7.15.5	SET 2NDROTATION	145
7.15.6	SET TOPOLOGY	145
7.15.7	SET EMIRCHECK	146
7.15.8	SET LIMITCHECK	146
7.15.9	SET USERLEVEL	147
7.15.10	SET EXAMPLES	147
7.16	SHOW	148
7.17	SOURCE	148
7.17.1	SOURCE /CATALOG	151
7.17.2	SOURCE /GREP	151
7.17.3	SOURCE /VELOCITY	151
7.17.4	SOURCE EXAMPLES	152
7.18	START	153
7.19	SUBSCAN	153
7.19.1	SUBSCAN /CROFLAG	155
7.19.2	SUBSCAN /RAMP	155
7.19.3	SUBSCAN /SYSTEM	156
7.19.4	SUBSCAN /TOTF	156
7.19.5	SUBSCAN /TSUBSCAN	157
7.19.6	SUBSCAN /TUNE	157
7.19.7	SUBSCAN /TYPE	157
7.20	SWBEAM	157
7.21	SWFREQUENCY	158
7.21.1	SWFREQUENCY /DEFAULTS	159
7.21.2	SWFREQUENCY /RECEIVER	159
7.21.3	SWFREQUENCY /TPHASE	159
7.21.4	SWFREQUENCY EXAMPLES	159
7.22	SWTOTAL	160
7.22.1	SWTOTAL /DEFAULTS	160
7.22.2	SWTOTAL /TPHASE	160
7.23	SWWOBLER	160
7.23.1	SWWOBLER /DEFAULTS	161
7.23.2	SWWOBLER /TPHASE	161
7.24	TIP	162
7.24.1	TIP /DEFAULTS	162
7.24.2	TIP /AIRMASS	162
7.24.3	TIP /TSUBSCAN	162
7.25	TRACK	163
7.25.1	TRACK /DEFAULTS	163
7.25.2	TRACK /SYSTEM	163
7.25.3	TRACK /NSUBSCANS	164
7.25.4	TRACK /TSUBSCAN	164

7.25.5 TRACK EXAMPLES	164
7.26 VLBI	165
7.27 OPTIONS	166
7.27.1 OPTIONS /AIRMASS	166
7.27.2 OPTIONS /AMBIENT	167
7.27.3 OPTIONS /APPEND	167
7.27.4 OPTIONS /CLEAR	167
7.27.5 OPTIONS /COLD	167
7.27.6 OPTIONS /CONNECT	167
7.27.7 OPTIONS /CROLOOP	167
7.27.8 OPTIONS /DEFAULTS	168
7.27.9 OPTIONS /DEROTATOR	168
7.27.10 OPTIONS /DISCONNECT	168
7.27.11 OPTIONS /DOPPLER	168
7.27.12 OPTIONS /DOUBLEBEAM	168
7.27.13 OPTIONS /EFFICIENCY	169
7.27.14 OPTIONS /FILE	169
7.27.15 OPTIONS /FINE	169
7.27.16 OPTIONS /GAINIMAGE	169
7.27.17 OPTIONS /GREP	170
7.27.18 OPTIONS /GRID	170
7.27.19 OPTIONS /HORIZONTAL	170
7.27.20 OPTIONS /MODE	171
7.27.21 OPTIONS /NOTF	171
7.27.22 OPTIONS /NSUBSCANS	171
7.27.23 OPTIONS /PERCENTAGE	171
7.27.24 OPTIONS /RECEIVER	172
7.27.25 OPTIONS /REFERENCE	172
7.27.26 OPTIONS /SCALE	172
7.27.27 OPTIONS /SKY	172
7.27.28 OPTIONS /SPEED	173
7.27.29 OPTIONS /STEP	173
7.27.30 OPTIONS /SWWOBLER	173
7.27.31 OPTIONS /SYMMETRIC	174
7.27.32 OPTIONS /SYSTEM	174
7.27.33 OPTIONS /TCALIBRATE	175
7.27.34 OPTIONS /TOTF	175
7.27.35 OPTIONS /TPHASE	176
7.27.36 OPTIONS /TREFERENCE	176
7.27.37 OPTIONS /TSUBSCAN	176
7.27.38 OPTIONS /TEMPLOAD	176
7.27.39 OPTIONS /VELOCITY	177
7.27.40 OPTIONS /VERTICAL	178
7.27.41 OPTIONS /WIDTH	178
7.27.42 OPTIONS /ZIGZAG	179

1 paKo— Introduction and Overview

After this introduction follows section 2, a “Guide for the Perplexed”. Here we briefly explain some general features of PAKO as well as differences from the previous control system for the 30-M Telescope.

In Section 3 we give a very short recipe with the bare minimum to get started with Heterodyne observations.

Section 4, is “PaKo’s Cook Book”. It is meant to evolve into a gentle step-by-step and command-by-command explanation of how to do observations with the NCS.

Next is the “NCS User’s Guide”, 5, which follows the same outline as the “Cook Book”, but includes more details. The examples included here are all in the form of PAKO command language scripts.

The section “NCS Explained”, 6, contains detailed explanations of some aspects of the NCS.

Finally, the “PAKO Language Internal Help” is reproduced in section 7.

A lot of information is intentionally duplicated in different sections of this manual, so that, e.g., the “Cook Book” and the “User’s Guide” can be read independently. It should not be necessary to read all sections in this manual! Also much space is taken up by examples, so the actual text to read is not very long!

We recommend that all users who face the NCS for the first time should read the “Guide for the Perplexed”. Beginning observers and those who like to set up their observations one command at a time can then follow the “Cook Book”, section 4.

More experienced observers may prefer the “User’s Guide”, section 5, especially those who need more advanced options and those who like to prepare scripts with the specifications of their observations (recommended!).

All users may want to consult the section 6 “NCS explained” for general information, or look up details in the HELP section, 7, which is a complete reference for all commands and options.

Before starting observations, users should also review the up-to-date notes on the NCS wiki pages at:

NCS Wiki at <https://mrt-lx1.iram.es/mainWiki/FrontPage>

```

ssh
I-BACKEND , no receiver name specified as parameter
I-BACKEND , no 2nd receiver name specified as parameter
I-BACKEND , Continuum total hardware used [%]: 0.0
I-BACKEND , 100kHz total hardware used [%]: 0.0
I-BACKEND , 1MHz total hardware used [%]: 0.0
I-BACKEND , 4MHz total hardware used [%]: 100.0
I-BACKEND , USB total hardware used [%]: 0.0
I-BACKEND , WILMA total hardware requested [%]: 100.0
I-BACKEND , VESPA total hardware used [%]: 33.3
I-BACKEND , 4MHz 1 4.000 4024.0 248.0 E090 horiz UO none 100.0 none
I-BACKEND , 4MHz 2 4.000 4024.0 -248.0 E090 verti UI none 100.0 none
I-BACKEND , WILMA 1 2.000 3720.0 265.0 E090 horiz UO none 100.0 none
I-BACKEND , WILMA 2 2.000 3720.0 -265.0 E090 verti UI none 100.0 none
I-BACKEND , WILMA 3 2.000 3720.0 265.0 E230 horiz LI none 100.0 none
I-BACKEND , WILMA 4 2.000 3720.0 265.0 E230 verti LI none 100.0 none
I-BACKEND , VESPA 1 0.040 40.0 0.0 E090 horiz UO none 90.0 CO-1-0
I-BACKEND , VESPA 2 0.040 40.0 0.0 E090 verti UI none 90.0 myLine2
I-BACKEND , VESPA 3 0.040 40.0 0.0 E230 horiz LI none 90.0
I-BACKEND , VESPA 4 0.040 40.0 0.0 E230 verti LI none 90.0 LIL0
PAKO> show
I-SHOW , paKo Revision v 1.1.1 2009-04-14
I-SHOW , Level. For standard output: 0. For file: 0
I-SHOW , Queue. doSubmit: F
I-SHOW , Project "111-22"
I-SHOW , PI "Dr. Jane D. Doe"
I-SHOW , Observer "John Doe"
I-SHOW , Operator "Pako"
I-SHOW , Topology "LOW"
I-SHOW , Pointing. azimuthCorrection: 0.0000000E+00
I-SHOW , Pointing. elevationCorrection: 0.0000000E+00
I-SHOW , Focus. focusCorrection: 0.0000000E+00
PAKO>

```

Figure 1: Screen shot of PAKO running in a terminal window.

2 paKo — Guide of the Perplexed

2.1 paKo and SIC

PAKO uses the usual SIC command line interpreter, and can be run in any X-windows terminal, see Figure 1.

It includes the GREG and GUI languages for plotting and, of course, adding GUI widgets.

2.2 paKo and Linux

PAKO and the NCS run on Linux. Any files that are prepared off-line, e.g., command scripts and source or line catalogs, should follow Linux standards. (Files prepared on other operating systems may contain non-compliant control characters.)

2.3 Running paKo offline and several instances of paKo

PAKO can run independently of the NCS. This is useful, e.g., to prepare command scripts and source or line catalogs.

Several instances of pako should not be run in the same working directory (of the same project account.) Also, at most one instance of pako should try to send observations to the observation queue; other instances should SET DOSUBMIT NO, see below.

2.4 Help

There is help available, e.g., enter at the prompt PAKO > :

```
HELP CALIBRATE
```

The display for most commands corresponds directly to the syntax of the command. E.g., for each observing mode, the display shows the syntax of all options.

The most recent command, as pako interpreted it, is usually shown at the bottom of the display window.

The keywords for commands and options try to be meaningful and, if possible, self-explanatory. As usual with SIC, minimum match is supported, so you can also write compact (and cryptic) commands, e.g., enter at the prompt PAKO > :

```
OTF /B /C CROOR /NO 12 /REF /ST -20 20 /SY PR /TO 30 /TR 22 /Z
```

2.5 SET LEVEL for Errors, Warnings, and Infos

PAKO can be very “chatty” and display many “messages” in the command line window. They are marked with “I-” for “info”, “W-” for “warning”, or “E-” for “error”. “E-” “error” is reserved for true errors, something not accepted by PAKO.

You can control the number of messages you see with with SET LEVEL, e.g.,

```
SET LEVEL 1 1
```

will enforce that you get all messages.

```
SET LEVEL 3 3
```

will suppress most “I-” infos.

```
SET LEVEL 5 5
```

will suppress most “I-” infos and “W-” warnings.

At this time (2012-12-01) PAKO still displays some debug messages, which are not flagged “I-”, “W-”, or “E-”. They will be eliminated as soon as possible.

2.6 Saving and Restoring

For most commands you can save the parameters into a file, e.g., enter at the prompt PAKO > :

```
SAVE POINTING
```

This saves the parameters of observing mode POINTING. The format of the saved files is that of a valid script in the command language. Therefore you can restore it later: enter at the prompt PAKO > :

```
@ POINTING
```

In a similar way, you can save the parameters of the source, receiver and backend setup, and of the switching mode.

```
SAVE ALL
```

saves (nearly) all current parameters, as well as the current switching and observing modes. It saves the pointing and focus corrections only if used in the form:

```
SAVE ALL C[ORRECTIONS]
```

Normally `SAVE ALL` is meant to generate a `paKo` script that can be used to re-produce the setup at a later time, when one probably wants to use different pointing and focus corrections. On the other hand the idiomatic usage:

```
SAVE ALL C /FILE LAST
```

allows to save “really everything” in order to recover it with `@ LAST`.

The parameters of “unused” (unselected) hardware, switching modes, and observing modes are never saved.

Tip: check out the options of command `save`: enter at the prompt `PAKO > :`

```
HELP SAVE /FILE
HELP SAVE /APPEND
```

After using `@ ...` to restore a saved observing mode, e.g., `otfmap`, the graphic display may look confused. To clean it up, enter at the prompt `PAKO > :`

```
CLEAR PLOT
BOX
OTFMAP      ! i.e., the observing mode.
```

2.7 Observation Queues and Starting

In the NCS, all observations are handled through an observation queue. So far this is rather simple, first-in-first-out.

The operator has to set the “current observation queue” to be that of the project account. (Submission from other projects will not be accepted by the NCS).

enter at the prompt `PAKO > :`

```
SET doSubmit yes
```

to activate submission of observing commands to the NCS observing queue. `SET doSubmit no` is useful for debugging, so that scripts including `START` can excute without actually trying to submit observations.

To start any observation in the NCS enter at the prompt `PAKO > :`

```
START
```

which actually generates an XML file with a full and detailed specification of all subscans that will be excuted by the NCS “coordinator” software. This is done by the “scanAnalyzer”, which is an integral part of the `pako` software. If you are looking for an adventure, you are encouraged to explore these XML files, e.g., using a recent version of Mozilla, the XML editor `oxygen`, or `emacs`.

Several instances of `pako` should not be run in the same working directory (of the same project account.) Also, at most one instance of `pako` should try to send observations to the observation queue.

2.8 Source and Line Catalogs

The format of the source catalog, e. g., iram.sou, is similar to source catalogs at PdB. A source catalog for the NCS can be generated from standard “old” 30m catalogs (*.cat) using ASTRO. The example source catalog, demo.sou, was generated from a historic version of IRAM.CAT using ASTRO.

The format of the line catalog, e. g., model.lin, is as in the old control system and at PdB.

NOTES. *In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.*

2.9 Switching Modes

In the NCS we distinguish the following 4 “Switching Modes”:

TOTAL POWER

BEAM SWITCHING

WOBBLER SWITCHING

FREQUENCY SWITCHING (only with heterodyne receivers)

The corresponding commands are:

SWTOTAL

SWBEAM

SWWOBBLER

SWFREQUENCY

BEAM SWITCHING, WOBBLER SWITCHING, and FREQUENCY SWITCHING are realized by a system with hardware synchronization signals that allow a precise and fast switching *within* subscans.

TOTAL POWER simply means that none of the other 3 switching modes is active.

The system switches through a regular cycle with several (1, 2, or 4) switching phases.

The 4 switching modes are mutually exclusive, i.e., at any time the system uses only one of them.

During the transitions between phases, e.g., while the Wobbler is moving between its positions, no data are taken during the short “blanking” time.

The switching mode and its parameters should normally be set before choosing an observing mode, because for some observing modes details of the setup depend on the switching mode.

2.10 Observing Modes

The NCS supports the following “Observing Modes”: CALIBRATE, POINTING, FOCUS, TIP, ONOFF, OTFMAP, <<TBD:RASTER not yet implemented >>, TRACK, VLBI.

All Observing Modes are realized by executing a sequence of 1 or more subscans. In most cases, the antenna moves between or during the subscans.

The observing modes are mutually exclusive, i.e., at any time the system executes only one of them.

Several Observing Modes can be combined with different Switching Modes, e.g., OTFMAP with TOTAL POWER, WOBBLER SWITCHING (for bolometer), or FREQUENCY SWITCHING. The Switching Mode should normally be specified before the Observing Mode.

2.11 Combinations of Switching and Observing Modes

The Switching modes and Observing modes are not fundamentally different from what they were in the old CS. However, in the NCS we try to be more explicit about this distinction in order to: (i) avoid having several commands that set up, e.g., parameters of the Wobbler, (ii) to support more combinations of Observing Modes and Switching Modes in the future.

2.12 Coordinate Systems, Map Projections, and Position Offsets

For a more detailed explanation, see Section 6.1.

The NCS will support a variety of astronomical coordinate systems and projections, as well as “descriptive” coordinate systems defined by the user. Up to now, 2012-12-01, only equatorial coordinates, J2000.0, are well tested and available for use.

Map Projections and Offsets. In general, a “map projection” describes the relation between 2 spherical coordinates, longitude l and latitude b ,¹ on the celestial sphere, and 2 Cartesian coordinates x and y , which in radio astronomy and the NCS we often call “position offsets”.

Up to now, 2012-12-01, only the “radio” projection is supported, for which:

$$x = (l - l_{source}) * \cos(b)$$

$$y = b - b_{source}$$

where l_{source} and b_{source} are the source coordinates specified with SOURCE.² Note that this is the same system of offsets as in “OBS” of the old control system.

If we want to observe several positions on the sky at or near the source position as specified with SOURCE, we often do this by requesting position offsets in the map projection. Also, the resulting data, e. g., images, are usually stored and displayed as a function of x and y .

For most observations, parameters and options of the observing mode are sufficient to specify the position offsets:

- for TRACK and VLBI x and y are fixed during the complete scan;
- for ONOFF x and y change from subscan to subscan;
- for OTFMAP x and y change continuously or “on-the-fly” (OTF) during the OTF subscans.

The PAKO commands for most Observing Modes expect fixed offsets (or start- and end-offsets for OTFMAP) as parameters. These can be either in the radio projection, specified with the option: `/SYSTEM projection` or in the true angle horizon system (see below), specified with the option: `/SYSTEM trueHorizon`

NOTES. For POINTING, the OTF offsets are always in system trueHorizon, and are specified implicitly though the angular length of the subscans.

¹ In particular for equatorial coordinates, l corresponds to Right Ascension and b to Declination.

² For the equations all angles are assumed to be in radian.

Global Offsets. On the other hand, the command `OFFSETS` can be used to specify additional position offsets in other systems. These globally defined offsets stay fixed during a complete scan. *They are only needed in special cases, e. g., the Nasmyth offsets or for ONOFF with wobbler switching, see below.*

At this time (2012-12-01), the command `OFFSETS` supports offsets in the following 3 systems:

projection Offsets in the “radio” projection (see above).

trueHorizon “true angle horizon” offsets in Azimuth and Elevation:

$$\Delta a = (a - a_{source}) * \cos(e)$$

$$\Delta e = e - e_{source}$$

where a and e are the Azimuth and Elevation of the telescope; a_{source} and e_{source} are the Azimuth and Elevation of the source, calculated from l and b (and the time and other parameters).

Nasmyth offsets in the Nasmyth (receiver cabin) system. The purpose of Nasmyth offsets is exclusively to re-position the telescope so that an off-center element of a multibeam receiver looks at the position where otherwise the center pixel would look. E. g., `OFFSETS -33 44 /SYSTEM Nasmyth` adds offsets -33 and 44 in the Nasmyth system (for all observing modes!)

Example 1 Observe a single position with offsets 10 and 20 in system radio projection; typically used with `FREQUENCY SWITCHING`:

```
TRACK 10 20 /SYSTEM projection
```

Example 2 Observe `ONOFF` (“position switching” with `TOTAL POWER`) with `ON` position at 30 40 and off-source reference at -600 -700, both in system radio projection:

```
ONOFF 30 40 /REFERENCE -600 -700 projection /SYSTEM projection
```

Example 3 Pointing with subscans of length 120:

```
POINTING 120
```

NOTES. For `POINTING`, the `OTF` offsets are always in system `trueHorizon`, and are specified implicitly though the angular length of the subscans.

Example 4 `ONOFF` observations with `WOBBLER SWITCHING` are a special case, because the offsets for the subscans must be in system `trueHorizon` and their values must be selected according to the offsets of the `WOBBLER SWITCHING`! E. g.,

```
SWWOBBLER -33 +33
ONOFF 33 0 /REFERENCE -33 0 trueHorizon /SYSTEM trueHorizon
```

This can also be achieved simply by saying

```
SWWOBBLER -33
ONOFF
```

PAKO “knows” the special requirements for onoff wobbler switching, and will set the offset parameters for ONOFF accordingly, if SWWOBBLER has been previously selected.³

In this special case, in order to map the source, the observer may add offsets on the source l and b using the command OFFSETS with the system “projection”, e. g.:

```
SWWOBBLER -33
OFFSETS 110 120 /SYSTEM projection
ONOFF
```

NOTES. *SOURCE* does not clear offsets set with *OFFSETS*.

NOTES. If you are unsure about any of this, read the additional information in Section 6.1, or ask an astronomer who is familiar with the NCS. For the time being, it is recommended not to try “fancy” combinations of offsets, which probably have not yet been fully tested and debugged.

2.13 Receiver Setup and Calibration Parameters

All parameters and options related to the setup of receivers and their calibration are specified with the command RECEIVER. This includes ambient and cold load temperatures, image sideband ratio, forward and main beam efficiencies, calibration scale antenna or (main) beam, and the HERA derotator.

2.14 Backends

Backend setup for all backends is done with the command BACKEND.

2.15 Continuous Data Acquisition and Data Streams

In the NCS, normally the data acquisition is continuous: fast independent data streams are generated by the backends as well as other subsystems, e.g., by the antenna mount drive to describe the antenna’s movements. The data processing software synchronizes the data from different streams based on time stamps in the data. Most data streams keep continuously running even between subscans.

2.16 Display of Parameters

Most parameters set by the observer are displayed by a separate program, `pakoDisplay`, in another window, see Figure 2.

Several instances of this program can run at the same time, including on different screens, “desktops”, and Linux machines.

2.17 Preview Plots

Commands for some observing modes, e.g., `otfmap`, automatically generate “preview” plots, see Figure 3.

The range of mapping offsets for these plots can be set with the usual GREG command limits, e.g., enter at the prompt `PAKO > :`

³ For special purposes, it is possible to overrule this with `/swWobbler no`, e. g., `ONOFF 44 /swWobbler no`.


```

paKo
SOURCE      name      system      longitude   latitude   velocity
           W30H      eq J2000.0 02:27:03.881 +61:52:24.57 LSR 0.000
           [h]          2.451078      [SET Topology] low [SET doSubmit] NO (F)
           [deg]       36.766172      61.873492 [SET Pointing] 0.0 0.0
           [rad]       0.64169075 1.07989616 [SET Focus] 0.00 [mm]

OFFSETS
CATALOG SOURCE iram-J2000-LSR.sou CATALOG LINE model.lin

RECEIVER lineName      frequency [GHz]  SB /doppler /width /gain [dB] /tempLoad /efficiency /scale
E090     12C0(1-0)    115.271204  U0 Doppler  /Horizontal U0 0.050 -13. L L 0.95 0.75 antenna
E230     12C0(2-1)    230.537990  LI Doppler  /Horizontal LI 0.050 -13. L L 0.91 0.52 antenna
           /Vertical UI
           /Vertical LI

OTFMAP (On-The-Fly OTF Map) [arcsec] SWFREQUENCY (Frequency Switching)
xStart yStart          -300.000 -300.000 fOffset1 fOffset2 [MHz]
xEnd   yEnd           300.000 -300.000 -3.900 3.900 /receiver E090
--> length0tf         600.000 -11.700 11.700 /receiver E230
/system projection
/reference F
xOffsetR yOffsetR     -600.000 0.000
systemNameRef         0.000
/croLoop

/n0tf 12
/step dx dy           0.000 10.000
/speed sStart sEnd   5.000 5.000
/t0tf 120.000
/tReference 10.000
/zigzag T

BACKEND nPart resolu. bandw. fShift /receiver /mod /perc /lineName
4MHz 1 4.000 4024.0 248.0 E090 hor U0
4MHz 2 4.000 4024.0 -248.0 E090 ver UI
WILMA 1 2.000 3720.0 265.0 E090 hor U0 100.0
WILMA 2 2.000 3720.0 -265.0 E090 ver UI 100.0
WILMA 3 2.000 3720.0 265.0 E230 hor LI 100.0
WILMA 4 2.000 3720.0 265.0 E230 ver LI 100.0
VESPA 1 0.040 40.0 0.0 E090 hor U0 90.0 CO-1-0
VESPA 2 0.040 40.0 0.0 E090 ver UI 90.0 myLine2
VESPA 3 0.040 40.0 0.0 E230 hor LI 90.0
VESPA 4 0.040 40.0 0.0 E230 ver LI 90.0 LIL0

PAKO\OTFMAP paKo v 1.1.1
Refresh Exit

```

Figure 2: Screen shot of the PAKO Display.




Figure 3: Screen shot of the PAKO preview plot.

```

DEVICE IMAGE W
LIMITS 500 -500 -500 500
SET BOX MATCH
BOX

```

Similarly, you can use other commands from GREG to change the color of the plotting “pens” or background of the window.

2.18 Defaults

Most commands have an option `/DEFAULT` which will set all options and parameters to meaningful default values. You can combine this option with explicit values for some parameters and options, e.g., enter at the prompt `PAKO > :`

```
OTFMAP /DEF /NOTF 12
```

means: default values for `OTFMAP`, but 12 `OTF` subscans.

2.19 Ranges and checks

Most parameters are checked to be within 2 ranges:

1. limits of allowed values. If you try to enter a value outside that range, you get an error message and the value is not accepted, e.g., enter at the prompt PAKO > :

```
POINTING /TOTF 4000
E-TOTF      /, value 4000.000 outside limits 1.000000 to 3600.000
```

2. standard range. If you enter a value outside the standard range, you get a warning message, but the value is accepted, e.g., enter at the prompt PAKO > :

```
POINTING /TOTF 3000
W-TOTF      /, value 3000.000 outside standard range 10.00000 to 600.0000
```

2.20 Independence of Command Parameters

The parameters of each observing mode are independent from the parameters of other observing modes. The same is true for the different switching modes. For example, if you first enter at the prompt PAKO > :

```
OTFMAP /NOTF 12
```

and later:

```
POINTING /NOTF 4
```

the number of OTF subscans for OTFMAP is still at 12, as you can see with:

```
OTFMAP
```

Some options exist for several observing modes. E.g., options /NOTF, and /TOTF exist for POINTING and OTFMAP. The syntax, parameters and meaning of these options is then (almost) the same for all observing modes.

2.21 Option keywords

Options that start with:

```
/t... refer to times (durations), e.g., /t0tf = time per OTF subscan;
/n... refer to number of something, e.g., /n0tf = number of OTF subscans;
/f... refer to frequency of something;
/temp... refer to temperature of something.
```

2.22 Logical (YES/NO or ON/OFF) Options

Several options of commands are “logicals” which can have only one of 2 values: TRUE = YES, shown in the display as: T, or: FALSE = NO, shown in the display as: F. The command syntax and logic for ALL these options is the same, e.g., enter at the prompt PAKO > :

```
OTFMAP /ZIGZAG          ! TURN OPTION  ON/TRUE/YES : T
OTFMAP /ZIGZAG YES      ! TURN OPTION  ON/TRUE/YES : T
OTFMAP /ZIGZAG .TRUE.  ! TURN OPTION  ON/TRUE/YES : T
OTFMAP /ZIGZAG NO       ! TURN OPTION  OFF/FALSE/NO  : F
OTFMAP /ZIGZAG .FALSE. ! TURN OPTION  OFF/FALSE/NO  : F
```

[Note: the default value for some logical options, e.g., /ZIGZAG, is T; for other logical options the default is F.]

2.23 Example Scripts and Catalogs

Examples of PAKO scripts, source and line catalogs are available on the WWW and in each project account.

3 PaKo's simplest recipe

This section gives a very short and simple overview of the steps needed to start spectral line observations. Details and more explanations are in the following sections, also in user's guides for special topics.

The following simple example is for both polarizations of one sub band, LI or UO, of one band, E090, of the EMIR receiver, see the EMIR user's guide for more information.

- Prepare a source catalog file, e.g., my.sou, with one line for each source that looks like:

```
W3OH EQ 2000 02:27:03.8812 +61:52:24.572 LSR -45.000
```

- Prepare a line catalog file, e.g., my.lin, with one text line for each line frequency like:

```
CS(2-1)          97.980968      LI
12CO(1-0)       115.271204      UO
```

LI and LO refer to sub bands of the EMIR E090 band. See the EMIR user's guide for details.

- Start up PAKO (see local information how to do this).
- Enter some general options and information.

```
SIC PRIORITY 1 PAKO          ! PAKO commands get precedence
SET LEVEL 0 0                ! to get verbose chatter from pako
SET Project 111-22           ! project ID (project number)
SET PI "Dr. Lilo D. Doe"     ! principal investigator
SET Observer "John Doe"     !
SET Operator Pako            !
SET Topology low             ! topology for azimuth
SET doSubmit YES            ! allow submission to Queue
SHOW                          ! show parameters set with set
```

- Specify the line catalog and the receiver setup.

```
CATALOG line my.lin         ! specify (your) line catalog
RECEIVER /CLEAR              ! clear any previous RX setup
RECEIVER E090 12CO(1-0) /Horizontal /Vertical
```

The options `/Horizontal` `/Vertical` mean that both polarizations will be used.

- Select your target source from your catalog; select a backend and do a calibration without sky to send the receiver setup.

```
CATALOG SOURCE my.sou       ! select your source catalog
SOURCE W3OH                  ! source W3OH from your catalog
BACKEND /CLEAR               ! clear any previous Backend setup
BACKEND WILMA /default       ! simple spectrometer setup for EMIR
BACKEND 4MHz /default        ! simple spectrometer setup for EMIR
CALIBRATE /SKY NO           ! doesn't need to move to sky position
START                         ! start
```

- Let the operator tune the receiver(s)

- Do a full calibration on the source, with default parameters:

```
CALIBRATE /DEFAULT          ! default calibration
START                       ! start
```

- Look at the results and check with the operator if the receiver noise temperature is OK.
- Select a strong compact continuum source for pointing and focussing; if possible, choose a source that is smaller than your beam!

```
SOURCE 2251+158 /catalog iram-J2000.sou ! pointing source from catalog
SOURCE Uranus                       ! OR: a 'small' planet
```

- Select the continuum backend for pointing and focus.

```
BACKEND /CLEAR
BACKEND BBC /Default
```

BACKEND BBC /Default connects one part of the continuum backend BBC to each polarization and sideband of each selected EMIR band.

- Select beam switching mode and do a pointing.

```
SWBEAM                      ! to select beam switching
POINTING /default           ! pointing
START                       ! start
```

- After a pointing the data processing software displays the results and you can enter a correction for the observed pointing offsets with the command. Let's say, the results are +3.4 and -1.2 [arc sec]

```
SET POINTING 3.4 -1.2
```

- Do a focus measurement.

```
FOCUS          2.0          ! length [mm]
START          ! start
```

- After a focus the data processing software displays the results and you can enter a new focus correction, e.g., -2.1 mm, with the command:

```
SET FOCUS -2.1
```

- Select a pointing source that is near your target source and do another pointing measurement and enter the resulting correction.

- Select the target source from your catalog; select a backend and do a calibration.

```

SOURCE W30H                ! source W30H from your catalog
BACKEND /CLEAR              ! clear any previous Backend setup
BACKEND WILMA /default      ! simple spectrometer setup for EMIR
BACKEND 4MHz /default       ! simple spectrometer setup for EMIR
CALIBRATE /DEFAULT         ! default calibration
START                       ! start

```

BACKEND WILMA /Default connects one part of the WILMA spectrometer to each EMIR sub band selected with RECEIVER. BACKEND 4MHz /Default connects one part of the WILMA spectrometer to 2 EMIR sub bands selected with RECEIVER.⁴

- Select your switching and observing mode, e.g., wobbler switching and on-off, and start observing.

```

SWOBBLER -120.0 120.0 /TPHASE 2.0      ! wobbler +/- 120 arc sec
                                         ! 2 seconds per phase
ONOFF /NSUBSCANS 12 /SYMMETRIC /TSUBSCAN 30 ! 12 subscans
                                         ! "symmetric" subscan sequence
                                         ! 30 sec per subscans

START

```

- Do a calibration at least every 15 minutes, or when you change sources, or when you change receiver and backend setups.
- Do a pointing every 2 hours or when you change to a different region of the sky.
- Do a focus every 6 hours and after sunset and sunrise.
(Before focus, do a pointing on the focus source!)
- HAVE FUN!

NOTES.

PAKO has built-in help for all commands, e. g.,

```

HELP SWOBBLER
HELP ONOFF /NSUBSCANS

```

Most commands can be abbreviated substantially, e. g., the following 2 are equivalent:

```

ON /NS 16 /SYM /TS 22
ONOFF /NSUBSCANS 16 /SYMMETRIC /TSUBSCAN 22

```

If you find that you enter the same command(s) very often, it is not necessary to type them every time! They can be put into command “scripts” either by editing a file or with PAKO’s SAVE command, see section 2.

⁴ Other spectrometers, e.g., VESPA, offer much more flexibility, but also need more parameters and more explicit BACKEND commands, see the following sections.

4 PaKo's Cook Book

This section provides a basic step-by-step cook book for standard observations in an interactive session. It only gives simple examples, details on all the parameters and options can be found in later sections.

If you only need to refresh your memory of what standard commands in a typical observation run look like, it may be sufficient to look at the examples, without reading the explanations!

Also note that a later section, "NCS User's Guide", follows the same general outline, repeats most of the information in "Pako's Cook Book", but provides more detailed explanations and more elaborate examples in the form of PAKO scripts.

This section starts with some general commands and the selection of a source catalog. The next subsection explains how to do "Spectral Line Observations with Heterodyne Receivers".

Remember that in command language scripts based on SIC:

! starts a comment.

- indicates that a command is continued on the next line.

PAUSE pauses the execution of the script, e.g., in order to allow the user to review the parameters set.

RETURN ends the execution of the script, and returns to the level from which the script was called; you have to delete or comment RETURN in order to execute the rest of the script.

Generally, the case, UPPER, lower, or Mixed, doesn't matter.

To execute a script in a file named `yoda.pako` enter at the prompt `PAKO > :`

```
@ yoda
```

4.1 Set General Information

```
!
! Id: demo-set.pako
!   basic SET EXAMPLES, v 1.1.1 2009-05-18 Hans Ungerechts
!
SIC PRIORITY 1 PAKO           ! PAKO commands get precedence
!                             ! over similar GREG commans!
!
SET Project    111-22         ! project ID (project number)
SET PI        "Dr. Lilo D. Doe" ! principal investigator
SET Observer   "John Doe"    !
SET Operator   Pako          !
SET Topology   low           ! topology for azimuth
!
SET Level      3 3           ! suppress informational messages
!                             ! ("I-messages") from paKo
!
DEVICE image w              ! for plots
!
SHOW                ! show the values set with set
!
!! NOTE: don't use special characters like <, >, &, accents in the names!
!!

!
! Id: demo-set2.pako
```



```

!      additional SET EXAMPLES, v 1.1.1 2009-05-08 Hans Ungerechts
!
!! SET doSubmit    YES                ! to allow submission to Queue
!
SET Pointing      -1.1 2.2            ! pointing corrections
SET Focus         -2.3                ! focus correction      [mm]
!
SHOW              ! show the values set with set
!

```

SIC PRIORITY 1 PAKO assures that PAKO commands have priority over similar other commands, e.g., POI will be understood as PAKO\POINTING and not as GREG1\POINTS.

With the SET commands we specify some basic information: the project number, the principal investigator (PI), the names of the observer and telescope operator.

NOTES. *In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.*

SHOW lists everything previously set with SET.

SET TOPOLOGY deserves special attention:

The 30m antenna has azimuth limits of 60 and 460 degrees. Azimuth 360 degrees is due North. Therefore there is an overlap range approximately toward East-Northeast, which the antenna can reach at a low azimuth 60 to 100 (from the South) or at a high azimuth 420 to 460 (from the North).

SET TOPOLOGY LOW selects to use the azimuth range 60 to 420 degrees.

SET TOPOLOGY HIGH selects to use the azimuth range 100 to 460 degrees.

About SET TOPOLOGY also see Section 6.2 and Figure 4 in that section.

DEVICE is a standard command to open a graphics window for plots. It is used by PAKO to provide a preview plot for some observing modes.

SET LEVEL can be used to control the amount of “messages” written by PAKO in the terminal window. SET LEVEL 3 3 is a good choice in most cases, because it suppresses many informational “I-” messages, but lets all warnings and serious errors through.

All these commands should normally be executed in the same way, each time observations for a project start. Therefore it is a good idea to put them in a script.

SET doSubmit yes is needed to activate submission of observing commands to the NCS observing queue. SET doSubmit no (default!) is useful for debugging, so that scripts including START can execute without actually trying to submit observations.

NOTE: the operator also has to set the “current observation queue” to be that of the project account. (Submission from other projects will not be accepted by the NCS).

SET POINTING and SET FOCUS are used to set pointing and focus corrections.

4.2 Specify your Source Catalog and/or Source

A “source catalog” is a special file containing information about sources to be observed, in particular their coordinates and radial velocities. The source catalog can be prepared with any text editor. Here is an example:

```

!
! Id: demo.sou,v 1.0.1 2006-01-03 by Hans Ungerechts
!
! generated by ASTRO from IRAM.CAT
!
! pointing sources:
!
0003+380    EQ  2000 00:05:57.1352  +38:20:14.869    LSR    0.000  FL    0.000    0.000  !
0048-097    EQ  2000 00:50:41.3193  -09:29:05.122    LSR    0.000  FL    0.000    0.000  !

```

0106+013	EQ	2000	01:08:38.7684	+01:35:00.421	LSR	0.000	FL	0.000	0.000	!
0112-017	EQ	2000	01:15:17.0917	-01:27:04.456	LSR	0.000	FL	0.000	0.000	!
0113-118	EQ	2000	01:16:12.5176	-11:36:15.412	LSR	0.000	FL	0.000	0.000	!
0119+041	EQ	2000	01:21:56.8557	+04:22:24.842	LSR	0.000	FL	0.000	0.000	!
0133+476	EQ	2000	01:36:58.5910	+47:51:29.164	LSR	0.000	FL	0.000	0.000	!
0135-247	EQ	2000	01:37:38.3418	-24:30:53.698	LSR	0.000	FL	0.000	0.000	!
0202+149	EQ	2000	02:04:50.4141	+15:14:11.214	LSR	0.000	FL	0.000	0.000	!
0212+735	EQ	2000	02:17:30.7735	+73:49:32.845	LSR	0.000	FL	0.000	0.000	!
0221+067	EQ	2000	02:24:28.4237	+06:59:23.499	LSR	0.000	FL	0.000	0.000	!
W3OH	EQ	2000	02:27:03.8812	+61:52:24.572	LSR	0.000	FL	0.000	0.000	!

[...]

1958-179	EQ	2000	20:00:57.0848	-17:48:57.547	LSR	0.000	FL	0.000	0.000	!
K3-50A	EQ	2000	20:01:45.6989	+33:32:43.518	LSR	0.000	FL	0.000	0.000	!
2005+403	EQ	2000	20:07:44.9340	+40:29:48.622	LSR	0.000	FL	0.000	0.000	!
2007+776	EQ	2000	20:05:30.9646	+77:52:43.294	LSR	0.000	FL	0.000	0.000	!
2013+370	EQ	2000	20:15:28.7151	+37:10:59.640	LSR	0.000	FL	0.000	0.000	!
2021+317	EQ	2000	20:23:19.0066	+31:53:02.395	LSR	0.000	FL	0.000	0.000	!
2023+336	EQ	2000	20:25:10.8256	+33:43:00.265	LSR	0.000	FL	0.000	0.000	!
2037+511	EQ	2000	20:38:37.0188	+51:19:12.687	LSR	0.000	FL	0.000	0.000	!
2059+034	EQ	2000	21:01:38.8275	+03:41:31.381	LSR	0.000	FL	0.000	0.000	!
NGC7027	EQ	2000	21:07:01.5931	+42:14:10.183	LSR	0.000	FL	0.000	0.000	!
2113+293	EQ	2000	21:15:29.3850	+29:33:38.540	LSR	0.000	FL	0.000	0.000	!
2121+053	EQ	2000	21:23:44.4941	+05:35:22.192	LSR	0.000	FL	0.000	0.000	!
2128-123	EQ	2000	21:31:35.2540	-12:07:04.725	LSR	0.000	FL	0.000	0.000	!
2131-021	EQ	2000	21:34:10.3053	-01:53:17.163	LSR	0.000	FL	0.000	0.000	!
2134+004	EQ	2000	21:36:38.5791	+00:41:54.319	LSR	0.000	FL	0.000	0.000	!
2136+141	EQ	2000	21:39:01.3021	+14:23:36.108	LSR	0.000	FL	0.000	0.000	!
2145+067	EQ	2000	21:48:05.4509	+06:57:38.710	LSR	0.000	FL	0.000	0.000	!
2200+420	EQ	2000	22:02:43.2793	+42:16:40.073	LSR	0.000	FL	0.000	0.000	!
2201+315	EQ	2000	22:03:14.9665	+31:45:38.359	LSR	0.000	FL	0.000	0.000	!
2210-257	EQ	2000	22:13:02.4963	-25:29:30.054	LSR	0.000	FL	0.000	0.000	!
2216-038	EQ	2000	22:18:52.0315	-03:35:36.837	LSR	0.000	FL	0.000	0.000	!
2223-052	EQ	2000	22:25:47.2570	-04:57:01.271	LSR	0.000	FL	0.000	0.000	!
2230+114	EQ	2000	22:32:36.4015	+11:43:50.985	LSR	0.000	FL	0.000	0.000	!
2234+282	EQ	2000	22:36:22.4627	+28:28:57.525	LSR	0.000	FL	0.000	0.000	!
2243-123	EQ	2000	22:46:18.2309	-12:06:51.110	LSR	0.000	FL	0.000	0.000	!
2251+158	EQ	2000	22:53:57.7438	+16:08:53.648	LSR	0.000	FL	0.000	0.000	!
2254+617	EQ	2000	22:56:17.9320	+62:01:49.545	LSR	0.000	FL	0.000	0.000	!
2255-282	EQ	2000	22:58:05.9656	-27:58:21.312	LSR	0.000	FL	0.000	0.000	!
NGC7538	EQ	2000	23:13:45.3867	+61:28:10.316	LSR	0.000	FL	0.000	0.000	!
2318+049	EQ	2000	23:20:44.8503	+05:13:50.085	LSR	0.000	FL	0.000	0.000	!

!

! The following sources are SiO masers and are useable for pointing ONLY

! if the receiver is tuned to the SiO line !!!!

! NOTE: MIRA does not yet support pointing on SiO masers!

!

OCET	EQ	2000	02:19:20.7066	-02:58:36.165	LS	46.800	FL	0.000	0.000	!
SPER	EQ	2000	02:22:51.7287	+58:35:12.095	LS	-38.000	FL	0.000	0.000	!
NMLTAU	EQ	2000	03:53:28.8025	+11:24:20.713	LS	33.000	FL	0.000	0.000	!
IRC+50137	EQ	2000	05:11:19.7492	+52:52:27.689	LS	3.500	FL	0.000	0.000	!
ORIA	EQ	2000	05:35:14.4740	-05:22:30.157	LS	16.000	FL	0.000	0.000	!
UORI	EQ	2000	05:55:49.2761	+20:10:30.768	LS	-40.200	FL	0.000	0.000	!


```

SOURCE Body Pako - !
    2455000.0 22.2 33.3 44.4 55.5 0.66 ! solar system body (orbital elements)
PAUSE
!
SOURCE w3oh ! will match W3OH in demo.sou
!
!! NOTES: source names must match:
!!     full source name in catalog or
!!     full name of planet or satellite
!!     the case is ignored for source name matching
!
RETURN
!
```

We use the command `SOURCE` to select a source for observations. Normally it is used after `CATALOG SOURCE` to select one of the sources from the source catalog. Alternatively, the parameters of the source can be specified directly on the command line, using the same format as in the source catalog. Pluto, the planets, and some of their Satellites are recognized directly by their name.

NOTES. *In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.*

For a full explanation of the parameters of the source command, see `HELP SOURCE`.

NOTES. IMPORTANT. *All characters of the source name in the command SOURCE must "match" those of a source name in the source catalog or a name of a special source like a planet. However, the case of the source name is ignored for matching. For example "W3OH", "w3oh", "W3oh" all match "W3OH" in the source catalog, "Mars", "Mars", and "mars" all are recognized as the planet "Mars"; however "W3O" does not match "W3OH".*

4.3 Spectral Line Observations with Heterodyne Receivers

4.3.1 Specify your Line Catalog

A "line catalog" is a special file containing information about spectral lines to be observed, in particular their frequencies. The line catalog can be prepared with any text editor. Here is an example:

```

!
! Id: demo-EMIR.lin,v 1.1.1 2009-05-06 Hans Ungerechts
!
! this is a special version for EMIR using sub bands LI, UI, and UO
!
! Line Frequency EMIR sub band
!
! E090
!
CH3OH          84.52121      LI
OCS(7-6)       85.139108     LI
SIO(V1)        86.243350     LI
H13CN          86.342274     LI
H13CO+         86.754330     LI
SIO(V0)        86.846891     LI
HCN(1-0)       88.6316024     LI
HCO+(1-0)      89.188523      LI
HNC(1-0)       90.663574     LI
HC3N(10-9)    90.9789933     LI
C34S(2-1)     96.412982     LI
```

OCS(8-7)	97.3012085	LI
CS(2-1)	97.980968	LI
HC3N(11-10)	100.076392	LI
34S02	102.031906	LI
13C180(1-0)	104.711385	LI
C180(1-0)	109.782182	UI
13C0(1-0)	110.201370	UI
C170(1-0)	112.359277	UI
CN(F1)(1-0)	113.490982	UI
12C0(1-0)	115.271204	UO
!		
! E150		
!		
HC3N(15-14)	136.464400	LI
C34S(3-2)	144.617147	LI
H2C0(146)	145.602952	LI
CS(3-2)	146.969049	LI
!		
! E230		
!		
C180(2-1)	219.560319	LI
13C0(2-1)	220.398686	LI
CH3CN220	220.747263	LI
CH3CCH222	222.166970	LI
C170(2-1)	224.714370	LI
H2C0225	225.697772	LI
12C0(2-1)	230.537990	LI
C34S(5-4)	241.016176	LI
CS(5-4)	244.935606	LI
HCN(3-2)	265.886432	LI
HCO+(3-2)	267.557625	LI
!		

To use this line catalog enter at the prompt PAKO > :

CATALOG LINE demo-EMIR.lin

```
!
! Id: demo.lin,v 1.1.1 2009-05-08 Hans Ungerechts
!
! Line Frequency Band
!
! HERA
!
```

C180(2-1)	219.560319	LSB
13C0(2-1)	220.398686	LSB
CH3CN220	220.747263	LSB
CH3CCH222	222.166970	LSB
C170(2-1)	224.714370	LSB
H2C0225	225.697772	LSB
12C0(2-1)	230.537990	LSB
C34S(5-4)	241.016176	LSB
CS(5-4)	244.935606	LSB
HCN(3-2)	265.886432	LSB


```

pause
!
!
say                " ! NOTE: E090 + E150 bands "
receiver /clear
RECEIVER E090    HCN(1-0)    - !
                  /Hor      LI    - ! LSB Inner
                  /Ver      LI    ! LSB Inner
RECEIVER E150    CS(3-2)    - !
                  /H        LI    - ! LSB Inner
                  /V        LI    ! LSB Inner
say                " ! NOTE: E090 H+V 4 GHz BW "
say                " !           E150 H+V 4 GHz BW "
pause
!
!
say                " ! NOTE: E090 + E230 bands "
receiver /clear
RECEIVER E090    HCN(1-0)    - !
                  /Hor      LI    - ! LSB Inner
                  /Ver      LI    ! LSB Inner
RECEIVER E230    12C0(2-1)   - !
                  /Horizontal LI  - ! LSB Inner
                  /Vertical  LI    ! LSB Inner
say                " ! NOTE: E090 H+V 4 GHz BW "
say                " !           E230 H+V 4 GHz BW "
pause
!
!
say                " ! NOTE: E150 + E330 bands "
receiver /clear
RECEIVER E150    CS(3-2)    - !
                  /H        LI    - ! LSB Inner
                  /V        LI    ! LSB Inner
RECEIVER E330    13C0(3-2)   - !
                  /H        LI    - ! LSB Inner
                  /V        LI    ! LSB Inner
say                " ! NOTE: E150 H+V 4 GHz BW "
say                " ! NOTE: E330 H+V 4 GHz BW "
pause
!
!!!!
!
RECEIVER          /clear          ! clear all receivers previously set
REC HERA1 12C0(2-1) 230.537990 LSB
REC HERA2 12C0(2-1) 230.537990 LSB
pause
!
```

Normally we use the `RECEIVER` command with 2 parameters: a receiver name and a line name. The line name must be the name of a line in the line catalog selected earlier. The frequency and sideband or EMIR sub band are then taken from the line catalog. Alternatively the frequency and sideband or sub band can be specified directly as the 3rd and 4th parameter.

NOTES.

For the EMIR bands, we distinguish up to 4 “sub bands”, each of 4 GHz bandwidth:

- the lower outer sub band LO from about -12 GHz to -8 GHz frequency shift relative to the local oscillator;
- the lower inner sub band LI from about -8 GHz to -4 GHz;
- the upper inner sub band UI from about $+4$ GHz to $+8$ GHz; and
- the upper outer sub band UO from about $+8$ GHz to $+12$ GHz.

If we select LO, LI, UI, UO as EMIR sub band in the line catalog or directly in RECEIVER, the localoscillator will be adjusted so that the specified line frequency goes into that EMIR sub band. For details, see the EMIR user guide. For HERA, the sideband must be “LSB” (lower sideband).

NOTES. *In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.*

One RECEIVER command is needed for each receiver, EMIR band, or part of HERA.

After the receiver is set up, and a source has been selected, the observer should enter

```
CALIBRATE [/SKY no]
```

```
START
```

to send the receiver parameters to the NCS. The telescope operator or receiver engineer will then tune the receiver.

/HORIZONTAL [sb1 [sb2]] and /VERTICAL[sb1 [sb2]] apply only to EMIR. This option informs the system about which EMIR subbands are going to be used for the horizontal and vertical polarization. (about the EMIR sub bands see above, and the EMIR user guide.)

/CLEAR completely clears the receiver setup.

RECEIVER must be specified before BACKEND.

After you enter a receiver setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE RECEIVER [/FILE receiver-1]
```

It can then at any later time be reloaded with @ receiver[-1], see HELP SAVE.

4.3.3 Setup of the Backends (Spectrometers and Continuum)

```
!
! Id: demo-backend.pako
!   basic BACKEND EXAMPLES,v 1.1.11 2011-11-24 Hans Ungerechts
!
swTotal /default           ! select a switching mode
!                           ! compatible with all backends
!
!   one example of a complex EMIR setup:
!
! pako\RECEIVER
pako\RECEIVER /clear
!
RECEIVER E090 CS(2-1) 97.980965 LI -
  /horizontal LI           -
  /vertical   LI
!
RECEIVER E230 CO(2-1) 230.537994 LI -
  /horizontal LI           -
  /vertical   LI
!
!
```



```

BACKEND /CLEAR                ! clear all backend setups
!
!
! EMIR BBC
BACKEND BBC                    /Default  ! connect 1 part
!                                     ! to both polarizations
!                                     ! of each sideband
!                                     ! of each selected EMIR band
pause
!
! EMIR NBC
backend /clear
BACKEND NBC                    /Default  ! connect 1 part to
!                                     ! each selected EMIR subband
pause
!
! EMIR WILMA
backend /clear
BACKEND WILMA                  /Default  ! connect 1 part to
!                                     ! each selected EMIR subband
pause
!
! EMIR 4MHz
! NOTE: 4MHz has only 2
!       parts with EMIR
backend /clear
BACKEND 4MHZ                    /Default  ! connect 1 part to each of
!                                     ! the first 2 EMIR subbands
pause
!
BACKEND 4MHZ 1                  /Receiver E090 Horiz LI ! connect 1 part to E090 Ho LI
BACKEND 4MHZ 2                  /Receiver E230 Verti LI !       2nd part to E230 Ve LI
pause
!
! EMIR FTS wide bandwidth mode
! /Fine is NOT present
backend /clear
BACKEND FTS                      /Default  ! connect 1 part to
!                                     ! each selected EMIR subband
!                                     ! plus 1 part to each of the
!                                     ! 4 outer subbands of E090
pause
!
backend /clear
!
! short syntax (still wide)
BACKEND FTS 1                    /Receiver E090 hor LI  !
BACKEND FTS 2                    /Receiver E090 ver LI  !
BACKEND FTS 3                    /Receiver E230 hor LI  !
BACKEND FTS 4                    /Receiver E230 ver LI  !
BACKEND FTS 5                    /Receiver E090 ver LO  !
BACKEND FTS 6                    /Receiver E230 ver LO  !
BACKEND FTS 7                    /Receiver E090 hor LO  !
BACKEND FTS 8                    /Receiver E230 hor LO  !
!
!

```

```

pause
!
!                               ! EMIR FTS fine resolution
!                               !   because /Fine is present
backend /clear
BACKEND FTS  /Fine /Default      ! connect 1 part to
!                               ! each selected EMIR subband
!                               ! plus 1 part to each of
!                               ! the 4 outer subbands of E090
pause
!
backend /clear
!                               ! short syntax (fine)
BACKEND FTS 1 /Fine /Receiver E090 hor LI !
BACKEND FTS 2 /Fine /Receiver E090 ver LI !
BACKEND FTS 3 /Fine /Receiver E230 hor LI !
BACKEND FTS 4 /Fine /Receiver E230 ver LI !
BACKEND FTS 5 /Fine /Receiver E090 ver LO !
BACKEND FTS 6 /Fine /Receiver E230 ver LO !
BACKEND FTS 7 /Fine /Receiver E090 hor LO !
BACKEND FTS 8 /Fine /Receiver E230 hor LO !
!                               !
pause
!
!                               ! EMIR WILMA + 4MHz + VESPA
backend /clear
BACKEND WILMA      /Default      !
BACKEND 4MHz       /Default      !
BACKEND VESPA  1  0.040  40.0    0.0  E090  Horiz  LI
BACKEND VESPA  2  0.040  40.0    0.0  E090  Verti  LI
BACKEND VESPA  3  0.040  40.0    0.0  E230  Horiz  LI
BACKEND VESPA  4  0.040  40.0    0.0  E230  Verti  LI
say                " ! backends can be combined"
pause
!
!
!! EMIR VESPA autocorrelator -- basic mode with fShift. optional: line name
!
backend /clear
BACKEND VESPA  1  0.040  40.0  -120.0  E090  Horiz  LI /line EOHUO-M
BACKEND VESPA  2  0.040  40.0   120.0  E090  Horiz  LI /line EOHUO-P
BACKEND VESPA  3  0.040  40.0  -100.0  E090  Verti  LI /line myLine3
BACKEND VESPA  4  0.040  40.0   110.0  E090  Verti  LI /line myLine4
BACKEND VESPA  5  0.040  80.0  -150.0  E230  Horiz  LI /line ""
BACKEND VESPA  6  0.040  80.0   150.0  E230  Horiz  LI /line apple
BACKEND VESPA  7  0.040  80.0  -200.0  E230  Verti  LI /line orange
BACKEND VESPA  8  0.040  80.0   200.0  E230  Verti  LI /line red
pause
!
!! EMIR VESPA autocorrelator -- basic and parallel modes
!
backend /clear
BACKEND VESPA  1  0.320  240.0    0.0  E090  Horiz  LI

```

```

BACKEND VESPA 2 0.320 240.0 0.0 E090 Verti LI
BACKEND VESPA 3 0.320 240.0 0.0 E230 Horiz LI /mode parallel
pause
!
!! NOTE: BACKEND VESPA ... E230 Horiz LI /mode parallel
!!       connects one VESPA part in parallel to
!!       E230 Horiz LI and E230 Verti LI
!!       (both must be selected in RECEIVER command)
!
!
!! HERA with FTS wide bandwidth
!
receiver /clear
RECEIVER HERA1 /WIDTH wide
RECEIVER HERA2 /WIDTH wide
!
backend /clear
BACKEND FTS 1      /RECEIVER HERA1
BACKEND FTS 2      /RECEIVER HERA2
!
!
!! HERA narrow bandwidth with FTS fine resolution
!
receiver /clear
RECEIVER HERA1 /WIDTH narrow
RECEIVER HERA2 /WIDTH narrow
!
backend /clear
BACKEND FTS 1  /FINE  /RECEIVER HERA1
BACKEND FTS 2  /FINE  /RECEIVER HERA2
!

```

The command BACKEND has up to 8 parameters: backend name, logical part number, resolution [MHz], bandwidth [MHz], frequency shift [MHz], receiver (band), EMIR polarization, and EMIR sub band. The receiver band and subbands must have been previously selected with RECEIVER.

For some backends the resolution, bandwidth, and/or frequency shift are fixed and a shorter syntax is possible. See the HELP BACKEND for complete information.

/CLEAR completely clears the backend setup.

Normally, the continuum backends are used (only) for POINTING, FOCUS, and TIP (antenna tipping or “skydip”).

For VESPA only a selected few (!) possibilities are shown; for more information see the VESPA user’s guide.

After you enter a backend setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE BACKEND [/FILE backend-1]
```

It can then at any later time be reloaded with @ backend[-1], see HELP SAVE.

4.3.4 Switching Mode

Always specify one of the Switching Modes, TOTAL POWER, BEAM SWITCHING, WOBBLER SWITCHING, FREQUENCY SWITCHING, before an Observing Mode.

The corresponding commands are:

```
SWTOTAL
```

```
SWBEAM
SWWOBLER
SWFREQUENCY
```

During typical observations, different switching modes are used with different observing modes, e.g., for some spectral line project we might use: BEAM SWITCHING for POINTING and FOCUS, FREQUENCY SWITCHING with TRACK or OTFMAP, and TOTAL POWER with ONOFF or OTFMAP.

The following examples for doing observations contain the specification of an appropriate Switching Mode as well as the Observing Mode.

For more details on Switching Modes see Section “NCS Explained”, subsection “Switching Modes”.

After you enter the setup of a complex switching mode like frequency switching manually, we recommend to “save” it, optionally to a named file:

```
SAVE SWITCHING [/FILE switching-1]
```

The setup can then at any later time be reloaded with @ switching[-1], see HELP SAVE.

Note that you can also “save” each switching mode specifically, e.g., SAVE SWFREQUENCY.

4.3.5 CALIBRATE

```
!
! Id: demo-calibrate.pako
!   CALIBRATE EXAMPLE,v 1.1.5 2011-04-25 Hans Ungerechts
!
CALIBRATE                               - !
  /AMBIENT                               - ! ambient load
  /COLD                                   - ! cold    load
  /SKY      -600.0  0.0                   - ! sky at offsets -600.0 0.0
  /SYSTEM      projection                   - ! system for sky offset
  /TCALIBRATE  5.0                         ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]"      ! a chance to check
!
START                                     ! start
!
!! Comments:
!! we assume here that source, receivers, and backends
!! already have been selected and setup,
!! see: demo-source, demo-receiver, demo-backend
!! NOTE: this is a generic calibrate for any heterodyne receiver(s)
!! and backends. Remember to select the appropriate backend before
!! Calibrate: normally a continuum backend for POINTING and FOCUS
!! and spectrometer(s) for TRACK, ONOFF, and (heterodyne) OTFMAPs
!
```

In a standard calibration for heterodyne receivers, we observe 3 subscans, “SAC”: on a Sky position, an Ambient temperature load (a.k.a., “hot” load), and a “Cold” load. Calibrations are always and automatically done in TOTAL POWER.

A calibration needs to be done for any heterodyne observation in order to get data with a calibrated intensity scale. It is normally done before the target observations. It must always be done after changing receiver and/or backend setups. It should also be done when changing sources and often enough to follow any variation of the atmosphere, about every 15 minutes.

After you enter a calibrate setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE CALIBRATE [/FILE calibrate-1]
```

It can then at any later time be reloaded with @ `calibrate[-1]`, see `HELP SAVE`.

4.3.6 POINTING

```

!
! Id: demo-pointing.pako
!   POINTING EXAMPLE,v 1.1.11 2011-11-25 Hans Ungerechts
!
SOURCE   Mars                               !
OFFSETS /CLEAR                             ! clear previously set offsets
!
@ demo-rx                                  ! demo setup of EMIR
!                                           ! REPLACE WITH YOUR SETUP!
!
BACKEND /CLEAR                             ! clear previous backend setup
!
BACKEND BBC           /Default              ! connect 1 part to each
!                                           ! EMIR subband selected
!
SET ANGLEUNIT arcsec                       ! make sure angle unit is arc sec
!
SWBEAM                                       ! to select beam switching
!
POINTING /DEFAULT                           ! reset all options
!
POINTING      120                            - ! pointing with subscan length 120
  /NOTF       4                             - ! 4 OTF subscans
  /TOTF      30.0                           ! 30 seconds per OTF subscan
!
PAUSE "POINTING OK to start? [c/q]"        ! a chance to check
!
START                                           ! start
!
RETURN
!
!!
!! NOTE:
!! if you use NASMYTH offsets for an off-center pixel
!! of a mutlibeam receiver don't use OFFSETS/ CLEAR.
!! If you want the intensity of the Pointing data to be
!! calibrated, you have to do a Calibrate with the same
!! receivers and (continuum) backends before the pointing.
!!

```

POINTING observations are done to optimize the positioning of the telescope in Azimuth and Elevation. This is normally done by continuum observations of a cross scan in azimuth and elevation on a point source (or at least a small source) near the intended target source.

It is normally used with BEAM SWITCHING or WOBBLER SWITCHING; it is also possible with TOTAL POWER. (With the bolometer POINTING is done with WOBBLER SWITCHING).

A calibration is not needed for POINTING, if one is only interested in the pointing corrections, and not in the source intensity.

After a pointing the data processing software displays the results and you can enter a correction for the observed pointing offsets with the command

```
SET POINTING azimuthCorrection elevationCorrection
```

Note that this is the total correction, i.e., the previous correction plus the additional offset found with the POINTING observation.

After you enter a pointing setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE POINTING [/FILE pointing-1]
```

It can then at any later time be reloaded with @ pointing[-1], see HELP SAVE.

4.3.7 FOCUS

```
!
! Id: demo-focus.pako
!   FOCUS EXAMPLE,v 1.1.1 2009-05-08 Hans Ungerechts
!
SWBEAM                               ! to select beam switching
!
FOCUS          2.0                    - ! length [mm]
  /NSUBSCANS    6                      - ! number of subscans
  /TSUBSCAN     12                     ! time per subscan
!
PAUSE "FOCUS OK to start? [c/q]"      ! a chance to check
!
START                               ! start
!
!! Comments:
!! We assume here that a pointing measurement has been done
!! immediately before the FOCUS (strongly recommended!),
!! see: demo-pointing, and therefore
!! we assume here that source, receivers, and backends
!! already have been selected and set up.
!! If you want the intensity of the Focus data to be
!! calibrated, you have to do a Calibrate with the same
!! receivers and (continuum) backends before.
```

FOCUS measurements are done to optimize the position of the subreflector (secondary) along the telescope axis by maximizing the intensity of the radiation focussed into the receiver(s). It is best done on a strong point source, e.g., on a planet if or when its angular diameter is less than the beam width at the frequency to be observed. It is strongly recommended to do a POINTING on the same source before a FOCUS.

FOCUS is normally used with BEAM SWITCHING or WOBBLER SWITCHING. (With the bolometer FOCUS is done with WOBBLER SWITCHING).

A calibration is not needed for FOCUS, anyhow it will probably already have been done before the POINTING before the FOCUS!

After a focus the data processing software displays the results and you can enter a correction for the observed focus offset with the command

```
SET FOCUS focusCorrection
```

Note that this is the total correction, i.e., the previous correction plus the additional offset found with the FOCUS observation.

The optional focus correction for different receiver bands may be slightly different, by a few times 0.1 mm, and the observer can decide to optimize for one particular band or use a compromise value.

After you enter a focus setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE FOCUS [/FILE focus-1]
```

It can then at any later time be reloaded with @ focus[-1], see HELP SAVE.

4.3.8 TRACK (Single Position with Frequency Switching)

```

!
! Id: demo-track.pako
! TRACK EXAMPLE,v 1.1.11 2011-11-25 Hans Ungerechts
!
@ demo-rx ! demo setup of receivers
!
BACKEND /CLEAR ! clear previous backends
BACKEND VESPA 1 0.040 40.0 0.0 E090 hor LI ! high spectral resolution
BACKEND VESPA 2 0.040 40.0 0.0 E090 ver LI ! with VESPA
BACKEND VESPA 3 0.080 80.0 0.0 E230 hor LI
BACKEND VESPA 4 0.080 80.0 0.0 E230 ver LI
! ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec !
!
! ! setup frequency switching
SWFREQUENCY -3.9 3.9 /receiver E090 ! for EMIR band E090
SWFREQUENCY -11.7 11.7 /receiver E230 ! for EMIR band E230
SWFREQUENCY /tphase 0.20 ! same for all receivers/bands
!
CALIBRATE - !
 /AMBIENT - ! ambient load
 /COLD - ! cold load
 /SKY -600.0 0.0 - ! sky at offsets -600.0 0.0
 /SYSTEM projection - ! system for SKY offsets
 /TCALIBRATE 5.0 ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START ! start
!
TRACK 40.0 -30.0 - ! offsets of on position
 /NSUBSCANS 5 - ! number of subscans
 /SYSTEM projection - ! system for offset
 /TSUBSCAN 60 ! time per subscan
!
PAUSE "TRACK SWFREQUENCY OK to start? [c/q]" ! a chance to check
!
START ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source

```

The TRACK observing mode simply tracks one position relative to the source. It is normally used with FREQUENCY SWITCHING and offsets in /SYSTEM projection.

The basic parameters are the offsets for the position to track; parameters of the options are the (total) number of subscans, and the time per subscan in [s].

After you enter a track setup manually, we recommend to “save” it, optionally to a named file:
 SAVE TRACK [/FILE track-1]

It can then at any later time be reloaded with @ track[-1], see HELP SAVE.

You may want to save the switching mode separately or with TRACK into the same file:

```
SAVE SWITCHING /FILE track-2
SAVE TRACK     /FILE track-2 /APPEND
```

NOTES. IMPORTANT:

FREQUENCY SWITCHING *is very powerful and efficient for some projects, e. g., mapping of narrow spectral lines in cold dark clouds outside the plane of the Milky Way. However, before deciding to use frequency switching one should consider some potential drawbacks:*

The target lines should be narrow enough so that line signals from the 2 phases of the switching cycle are well separated.

The spectral baseline will generally be less flat than in other switching modes.

Some spectral lines are also emitted in the earth's mesosphere, e.g., the mesospheric lines from (12)CO are rather strong, and they will be seen in FREQUENCY SWITCHING spectra taken toward astronomical sources with a low Doppler shift. The mesospheric lines will appear at a frequency and velocity that corresponds to the rest frame of the atmosphere, i. e., the observatory. Care must be taken that they are not confused with the lines from the astronomical source. (Information computed by the ASTRO software can help with this decision).

When observing sources near the plane of the Milky Way, line emission from clouds at other velocities than the target source, e. g., other spiral arms, can cause confusion.

In case of doubt, consult the special memo on FREQUENCY SWITCHING or ask an experienced FREQUENCY SWITCHING observer!

4.3.9 ON-OFF (“Position Switching” and Wobbler Switching)

```
!
! Id: demo-onoff.pako
!   ONOFF SWTOTAL EXAMPLE,v 1.1.1 2009-05-05 Hans Ungerechts
!   "POSITION SWITCHING"
!
@ demo-rx-spectrometers           ! demo setup of receivers
!                                 ! and spectrometers
!                                 ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec                  !
!
SWTOTAL                           - ! select total power
  /TPHASE          0.5             ! time per phase (data sample)
!
CALIBRATE                         - !
  /AMBIENT          - ! ambient load
  /COLD             - ! cold   load
  /SKY             -600.0  0.0     - ! sky at offsets -600.0 0.0
  /SYSTEM          projection      - ! system for SKY offsets
  /TCALIBRATE      5.0            ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                             ! start
!
ONOFF          40.0  -30.0          - ! offsets of on position
  /NSUBSCANS   12                  - ! number of subscans
  /REFERENCE   -600.0  0.0  projection - ! offsets of off-source reference
```



```

/SYSTEM      projection      - ! system for offsets
/SYMMETRIC   - ! "symmetric" subscan sequence
/TSUBSCAN    30              ! time per subscan
!
PAUSE "ONOFF SWTOTAL OK to start? [c/q]" ! a chance to check
!
START        ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source

```

In its first form ONOFF is used with TOTAL POWER. Subscans are taken alternating between a position that's considered to be "ON-source" and a reference position that's normally assumed to be "OFF-source", i.e., free of emission.

The source signal is then calculated as the difference between "ON" and "OFF".

The basic parameters are the offsets for the ON position, parameters of the options are the offsets for the reference position, the (total) number of subscans, and the time per subscan in [s].

After you enter an ON-OFF setup manually, we recommend to "save" it, optionally to a named file:

```
SAVE ONOFF [/FILE onoff-1]
```

It can then at any later time be reloaded with @ onoff[-1], see HELP SAVE.

You may want to save the switching mode separately or with ONOFF into the same file:

```

SAVE SWITCHING /FILE onoff-2
SAVE ONOFF      /FILE onoff-2 /APPEND

!
! Id: demo-onoff-swwobbler.pako
!   ONOFF SWWOBBLER EXAMPLE,v 1.1.6 2011-07-31 Hans Ungerechts
!   "WOBBLER SWITCHING"
!
@ demo-rx-spectrometers      ! demo setup of receivers
!                            ! and spectrometers
!                            ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec             !
!
!                            ! select wobbler switching
SWWOBBLER    -120.0  120.0   - ! wobbler -/+ 120 arc sec
  /TPHASE      1.0          ! 1 seconds per phase
!
CALIBRATE      - !
  /AMBIENT      - ! ambient load
  /COLD         - ! cold   load
  /SKY         -600.0  0.0   - ! sky at offsets -600.0 0.0
  /SYSTEM      projection   - ! system for SKY offsets
  /TCALIBRATE  5.0         ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START        ! start
!
!!          ! OPTIONAL:

```

```

!! OFFSETS 20 30 - ! mapping offsets in
!! /SYSTEM projection ! system projection
!
ONOFF /SWOBBLER - ! ONOFF for Wobbler switching
  /NSUBSCANS 12 - ! number of subscans
  /SYMMETRIC - ! "symmetric" subscan sequence
  /TSUBSCAN 30 ! time per subscan
!
PAUSE "ONOFF SWOBBLER OK to start? [c/q]" ! a chance to check
!
START ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source
!!
!! IMPORTANT NOTE: ONOFF with SWOBBLER (wobbler switching on-off)
!! requires that the subscans are offset relative to the source
!! in the trueHorizon system by -1 * the Wobbler elongations (offsets).
!! With the commands above, paKo recognizes this and automatically
!! sets the correct values.
!! In this case, OFFSETS can be used to set additional mapping
!! offsets in the "projection" of the astronomical coordinate
!! system. These mapping offsets in the projection apply
!! to all ONOFF subscans.

```

When ONOFF is used with WOBBLER SWITCHING (command SWOBBLER), the position offsets must be set to very specific values in TRUE (ANGLE) HORIZON depending on the parameters of SWOBBLER. This is achieved by using the special option /SWOBBLER of the command ONOFF.

Subscans are then taken alternating between 2 positions in such a way that: (a) in some subscans (one position of the antenna) the source is in the first of the two Wobbler phases, (b) in the other subscans (the other position of the antenna) the source is in the second of the two Wobbler phases. During the data processing, the source signal is computed as a double difference: 1st the difference of the 2 Wobbler phases; 2nd the difference between ONOFF subscans (a) and (b).

This form of ONOFF is also called "Wobbler-Onoff" or sometimes simply "Wobbler Switching".

The combination(!) of ONOFF and WOBBLER SWITCHING provides a very high sensitivity in continuum bolometer observations of compact sources, and excellent baselines for spectroscopy.

It has the disadvantage that the (emission-free?) off-source positions are very close to the source (limited by the maximum Wobbler throw). Also, the Wobbler direction is fixed in the horizontal system relative to the telescope, and therefore in the source system the off-source positions rotate around the source position.

For continuum observations, usually a short time per Wobbler phase, 0.25 s, is used with small Wobbler offsets (throws); for spectroscopy, largest possible Wobbler offsets (throws), up to $\pm 120''$ are preferred, but then the time per phase must be longer, 1 – 2 s.

4.3.10 OTF (On-The-Fly Mapping)

```

!
! Id: demo-otfmap.pako
!   OTFMAP SWTOTAL EXAMPLE,v 1.1.6 2011-07-21 Hans Ungerechts
!
@ demo-rx-spectrometers ! demo setup of receivers
!                       ! and spectrometers
!                       ! REPLACE WITH YOUR SETUP!

```

```

!
SET ANGLE arcsec          !
!
SWTOTAL                   - ! to select total power
  /TPHASE                 0.5   ! time per phase (data sample)
!
CALIBRATE                 - !
  /AMBIENT                - ! ambient load
  /COLD                   - ! cold   load
  /SKY                    -500.0 -400.0 - ! sky at offsets -500.0 -400.0
  /SYSTEM                 projection - ! system for SKY offset
  /TCALIBRATE             5.0   ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                     ! start
!
OTFMAP                   -300  -15  300  -15 - ! offsets at start and end of first OTF
  /CROLOOP                ROR   - ! subscans: reference-OTF-reference
  /NOTF                   4     - ! number of on-the-fly subscans
  /REFERENCE              -500  -400 projection - ! offsets of off-source reference
  /STEP                   0     10 - ! step (shift) between OTF subscans
  /SYSTEM                 projection - ! system for offsets
  /TOTF                   120.0 - ! time per on-the-fly subscan
  /TREFERENCE             20.0  - ! time per off-source reference
  /ZIGZAG                 ! go back and forth
!
PAUSE "OTFMAP SWTOTAL OK to start? [c/q]" ! a chance to check
!
START                     ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source
!!
!! /CROLOOP                ROR means that there will be an
!!                          off-source reference subscan (R)
!!                          before and after each OTF suscan (0).
!!                          Therefore with /NOTF 4 on-the-fly subscans the complete
!!                          subscan sequence will be:
!!                          R OTF#1 R   R OTF#2 R   R OTF#3 R   R OTF#4 R
!!                          with
!! /CROLOOP                ROOROR it would be:
!!                          R OTF#1      OTF#2   R   OTF#3      OTF#4 R
!

```

In OTFMAP (on-the-fly) observations, the antenna moves relative to the source while recording its position and taking data a high rate, thus performing “scans” in the strict sense of the word. This is a very fast mode for mapping.

The basic parameters of the command are the position offsets of the start and end of the first OTF subscan; the basic parameters of the options are: the number of OTF subscans, the offsets of an off-source reference position, the step (shift) in x- and y-offsets between subsequent OTF subscans, the time per OTF subscan in [s], and the time per off-source reference subscan [s].

This observing mode is normally used either with:

(i) TOTAL POWER with an off-source reference for spectral line observations, or
 (ii) FREQUENCY SWITCHING without off-source reference for spectral line observations (see below), or
 (iii) WOBLER SWITCHING and TRUE (ANGLE) HORIZON offsets for continuum mapping with the bolometer.

After you enter an OTF-map setup manually, we recommend to "save" it, optionally to a named file:

```
SAVE OTFMAP [/FILE otfmap-1]
```

It can then at any later time be reloaded with @ otfmap[-1], see HELP SAVE.

You may want to save the switching mode separately or with OTFMAP into the same file:

```
SAVE SWITCHING /FILE otfmap-2
```

```
SAVE OTFMAP /FILE otfmap-2 /APPEND
```

And, finally, OTFMAP with FREQUENCY SWITCHING:

```
!
! Id: demo-otfmap-swfrequency.pako
!   OTFMAP SWFREQUENCY EXAMPLE,v 1.1.11 2011-11-25 Hans Ungerechts
!
@ demo-rx          ! demo setup of receivers
!
BACKEND /CLEAR          ! clear previous backends
BACKEND VESPA 1 0.040 40.0 0.0 E090 hor LI ! high spectral resolution
BACKEND VESPA 2 0.040 40.0 0.0 E090 ver LI ! with VESPA
BACKEND VESPA 3 0.080 80.0 0.0 E230 hor LI
BACKEND VESPA 4 0.080 80.0 0.0 E230 ver LI
!                   ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec      !
!
!                   ! setup frequency switching
SWFREQUENCY  -3.9      3.9 /receiver E090 ! for EMIR band E090
SWFREQUENCY  -11.7     11.7 /receiver E230 ! for EMIR band E230
SWFREQUENCY                /tphase  0.20 ! same for all receivers/bands
!
CALIBRATE            - !
  /AMBIENT            - ! ambient load
  /COLD               - ! cold   load
  /SKY                - ! sky at offsets -600.0 0.0
  /SYSTEM             - ! system for offset
  /TCALIBRATE        5.0 ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]"      ! a chance to check
!
START          ! start
!
OTFMAP        -300 -300 300 -300 - ! offsets at start and end of first OTF
  /CROLOOP    0 - ! only OTF subscans
  /NOTF       4 - ! number of on-the-fly subscans
  /REFERENCE  no - ! no off-source reference subscans
  /STEP       0 10 - ! step (shift) between OTF subscans
  /SYSTEM     projection - ! system for offset
  /TOTF       120.0 - ! time per on-the-fly subscan
  /ZIGZAG     ! go back and forth
```

```
!  
PAUSE "OTFMAP SWFREQUENCY OK to start? [c/q]" ! a chance to check  
!  
START ! start  
!  
!! Comments:  
!! we assume here that the source already has been selected,  
!! see: demo-source
```

4.4 Continuum Observations with Bolometers

NOTES.

Most bolometer observations are done in the bolometer observing pool, which has its own special instructions. Observers in the bolometer pool should follow these special instructions.

NOTE (2011-07-14): the MAMBO bolometers are out of operation.

For other notes on bolometer observations, see section [5.4](#).

5 NCS User's Guide

This section contains an extended guide explaining how to setup and execute observations.

Also note that an earlier section, "Pako's Cook Book", already provided a good part of the information in the "NCS User's Guide". Here we provide more details and more elaborate examples in the form of PAKO scripts that can be edited and used for actual observations.

This section starts with some general commands and the selection of a source catalog. The next subsection explains how to do "Spectral Line Observations with Heterodyne Receivers".

Remember that in command language scripts based on SIC:

! starts a comment.

- indicates that a command is continued on the next line.

PAUSE pauses the execution of the script, e.g., in order to allow the user to review the parameters set.

RETURN ends the execution of the script, and returns to the level from which the script was called; you have to delete or comment RETURN in order to execute the rest of the script.

Generally, the case, UPPER, lower, or Mixed, doesn't matter.

To execute a script in a file named `yoda.pako` enter at the prompt `PAKO > :`

```
@ yoda
```

5.1 Set General Information

```
!
! Id: demo-set.pako
!   basic SET EXAMPLES, v 1.1.1 2009-05-18 Hans Ungerechts
!
SIC PRIORITY 1 PAKO           ! PAKO commands get precedence
!                             ! over similar GREG commans!
!
SET Project    111-22         ! project ID (project number)
SET PI        "Dr. Lilo D. Doe" ! principal investigator
SET Observer   "John Doe"    !
SET Operator   Pako          !
SET Topology   low           ! topology for azimuth
!
SET Level      3 3           ! suppress informational messages
!                             ! ("I-messages") from paKo
!
DEVICE image w              ! for plots
!
SHOW              ! show the values set with set
!
!! NOTE: don't use special characters like <, >, &, accents in the names!
!!

!
! Id: demo-set2.pako
!   additional SET EXAMPLES, v 1.1.1 2009-05-08 Hans Ungerechts
!
!! SET doSubmit   YES           ! to allow submission to Queue
!
SET Pointing     -1.1 2.2       ! pointing corrections
SET Focus        -2.3           ! focus correction      [mm]
!
SHOW              ! show the values set with set
!
```

SIC PRIORITY 1 PAKO assures that PAKO commands have priority over similar other commands, e.g., POI will be understood as PAKO\POINTING and not as GREG1\POINTS.

With the SET commands we specify some basic information: the project number, the principal investigator (PI), the names of the observer and telescope operator.

NOTES. *In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.*

SHOW lists everything previously set with SET.

SET TOPOLOGY deserves special attention:

The 30m antenna has azimuth limits of 60 and 460 degrees. Azimuth 360 degrees is due North. Therefore there is an overlap range approximately toward East-Northeast, which the antenna can reach at a low azimuth 60 to 100 (from the South) or at a high azimuth 420 to 460 (from the North).

SET TOPOLOGY LOW selects to use the azimuth range 60 to 420 degrees.

SET TOPOLOGY HIGH selects to use the azimuth range 100 to 460 degrees.

About SET TOPOLOGY also see Section 6.2 and Figure 4 in that section.

DEVICE is a standard command to open a graphics window for plots. It is used by PAKO to provide a preview plot for some observing modes.

SET LEVEL can be used to control the amount of “messages” written by PAKO in the terminal window. SET LEVEL 3 3 is a good choice in most cases, because it suppresses many informational “I-” messages, but lets all warnings and serious errors through.

All these commands should normally be executed in the same way, each time observations for a project start. Therefore it is a good idea to put them in a script.

SET doSubmit yes is needed to activate submission of observing commands to the NCS observing queue. SET doSubmit no (default!) is useful for debugging, so that scripts including START can excute without actually trying to submit observations.

NOTE: the operator also has to set the “current observation queue” to be that of the project account. (Submission from other projects will not be accepted by the NCS).

SET POINTING and SET FOCUS are used to set pointing and focus corrections.

5.2 Specify your Source Catalog and/or Source

```
!
! Id: demo.sou,v 1.0.1 2006-01-03 by Hans Ungerechts
!
! generated by ASTRO from IRAM.CAT
!
! pointing sources:
!
0003+380    EQ   2000 00:05:57.1352  +38:20:14.869    LSR   0.000  FL   0.000   0.000  !
0048-097    EQ   2000 00:50:41.3193  -09:29:05.122    LSR   0.000  FL   0.000   0.000  !
0106+013    EQ   2000 01:08:38.7684  +01:35:00.421    LSR   0.000  FL   0.000   0.000  !
0112-017    EQ   2000 01:15:17.0917  -01:27:04.456    LSR   0.000  FL   0.000   0.000  !
0113-118    EQ   2000 01:16:12.5176  -11:36:15.412    LSR   0.000  FL   0.000   0.000  !
0119+041    EQ   2000 01:21:56.8557  +04:22:24.842    LSR   0.000  FL   0.000   0.000  !
0133+476    EQ   2000 01:36:58.5910  +47:51:29.164    LSR   0.000  FL   0.000   0.000  !
0135-247    EQ   2000 01:37:38.3418  -24:30:53.698    LSR   0.000  FL   0.000   0.000  !
0202+149    EQ   2000 02:04:50.4141  +15:14:11.214    LSR   0.000  FL   0.000   0.000  !
0212+735    EQ   2000 02:17:30.7735  +73:49:32.845    LSR   0.000  FL   0.000   0.000  !
0221+067    EQ   2000 02:24:28.4237  +06:59:23.499    LSR   0.000  FL   0.000   0.000  !
W30H        EQ   2000 02:27:03.8812  +61:52:24.572    LSR   0.000  FL   0.000   0.000  !
0224+671    EQ   2000 02:28:50.0655  +67:21:03.123    LSR   0.000  FL   0.000   0.000  !
0234+285    EQ   2000 02:37:52.3845  +28:48:09.782    LSR   0.000  FL   0.000   0.000  !
0235+164    EQ   2000 02:38:38.9268  +16:36:59.287    LSR   0.000  FL   0.000   0.000  !
0239+108    EQ   2000 02:42:29.1773  +11:01:00.856    LSR   0.000  FL   0.000   0.000  !
```

0300+471	EQ	2000	03:03:35.2431	+47:16:16.387	LSR	0.000	FL	0.000	0.000	!
0316+413	EQ	2000	03:19:48.1540	+41:30:42.160	LSR	0.000	FL	0.000	0.000	!
0333+321	EQ	2000	03:36:30.0022	+32:18:28.762	LSR	0.000	FL	0.000	0.000	!
0336-019	EQ	2000	03:39:30.9336	-01:46:35.755	LSR	0.000	FL	0.000	0.000	!
0355+508	EQ	2000	03:59:29.7464	+50:57:50.230	LSR	0.000	FL	0.000	0.000	!
0403-132	EQ	2000	04:05:33.9795	-13:08:14.345	LSR	0.000	FL	0.000	0.000	!
0415+379	EQ	2000	04:18:21.2682	+38:01:35.574	LSR	0.000	FL	0.000	0.000	!
0420-014	EQ	2000	04:23:15.7959	-01:20:33.124	LSR	0.000	FL	0.000	0.000	!
0422+004	EQ	2000	04:24:46.8226	+00:36:08.702	LSR	0.000	FL	0.000	0.000	!
0426-380	EQ	2000	04:28:40.4231	-37:56:19.460	LSR	0.000	FL	0.000	0.000	!
0430+052	EQ	2000	04:33:11.0894	+05:21:15.549	LSR	0.000	FL	0.000	0.000	!
0439+360	EQ	2000	04:42:53.3565	+36:06:52.668	LSR	0.000	FL	0.000	0.000	!
0454-234	EQ	2000	04:57:03.1634	-23:24:52.367	LSR	0.000	FL	0.000	0.000	!
0458-020	EQ	2000	05:01:12.8003	-01:59:13.756	LSR	0.000	FL	0.000	0.000	!
0514-161	EQ	2000	05:16:15.9268	-16:03:07.614	LSR	0.000	FL	0.000	0.000	!
0521-365	EQ	2000	05:22:57.8992	-36:27:31.373	LSR	0.000	FL	0.000	0.000	!
0528+134	EQ	2000	05:30:56.4348	+13:31:55.173	LSR	0.000	FL	0.000	0.000	!
0529+075	EQ	2000	05:32:38.9895	+07:32:43.314	LSR	0.000	FL	0.000	0.000	!
0552+398	EQ	2000	05:55:30.7409	+39:48:49.125	LSR	0.000	FL	0.000	0.000	!
0605-085	EQ	2000	06:07:59.6922	-08:34:49.988	LSR	0.000	FL	0.000	0.000	!
0607-157	EQ	2000	06:09:40.9611	-15:42:40.476	LSR	0.000	FL	0.000	0.000	!
0642+449	EQ	2000	06:46:32.0222	+44:51:16.585	LSR	0.000	FL	0.000	0.000	!
0646-306	EQ	2000	06:48:14.1010	-30:44:19.569	LSR	0.000	FL	0.000	0.000	!
0716+714	EQ	2000	07:21:53.4701	+71:20:36.392	LSR	0.000	FL	0.000	0.000	!
0727-115	EQ	2000	07:30:19.1082	-11:41:12.692	LSR	0.000	FL	0.000	0.000	!
0735+178	EQ	2000	07:38:07.3910	+17:42:18.980	LSR	0.000	FL	0.000	0.000	!
0736+017	EQ	2000	07:39:18.0300	+01:37:04.580	LSR	0.000	FL	0.000	0.000	!
0745+241	EQ	2000	07:48:36.1316	+24:00:23.988	LSR	0.000	FL	0.000	0.000	!
0754+100	EQ	2000	07:57:06.6602	+09:56:34.658	LSR	0.000	FL	0.000	0.000	!
0804+499	EQ	2000	08:08:39.6704	+49:50:36.481	LSR	0.000	FL	0.000	0.000	!
0805-078	EQ	2000	08:08:15.5274	-07:51:10.051	LSR	0.000	FL	0.000	0.000	!
0814+425	EQ	2000	08:18:16.0034	+42:22:45.337	LSR	0.000	FL	0.000	0.000	!
0820+560	EQ	2000	08:24:47.2441	+55:52:42.585	LSR	0.000	FL	0.000	0.000	!
0823+033	EQ	2000	08:25:50.3546	+03:09:24.408	LSR	0.000	FL	0.000	0.000	!
0834-201	EQ	2000	08:36:39.2094	-20:16:59.530	LSR	0.000	FL	0.000	0.000	!
0836+710	EQ	2000	08:41:24.3819	+70:53:41.760	LSR	0.000	FL	0.000	0.000	!
0851+202	EQ	2000	08:54:48.8748	+20:06:30.572	LSR	0.000	FL	0.000	0.000	!
0923+392	EQ	2000	09:27:03.0102	+39:02:20.692	LSR	0.000	FL	0.000	0.000	!
0945+408	EQ	2000	09:48:55.3341	+40:39:44.446	LSR	0.000	FL	0.000	0.000	!
0953+254	EQ	2000	09:56:49.8762	+25:15:15.901	LSR	0.000	FL	0.000	0.000	!
0954+658	EQ	2000	09:58:47.2617	+65:33:54.666	LSR	0.000	FL	0.000	0.000	!
1012+232	EQ	2000	10:14:47.0622	+23:01:16.454	LSR	0.000	FL	0.000	0.000	!
1034-293	EQ	2000	10:37:16.0817	-29:34:02.914	LSR	0.000	FL	0.000	0.000	!
1039+811	EQ	2000	10:44:23.1009	+80:54:39.319	LSR	0.000	FL	0.000	0.000	!
1044+719	EQ	2000	10:48:27.6375	+71:43:35.788	LSR	0.000	FL	0.000	0.000	!
1045-188	EQ	2000	10:48:06.6157	-19:09:35.965	LSR	0.000	FL	0.000	0.000	!
1055+018	EQ	2000	10:58:29.5968	+01:33:58.860	LSR	0.000	FL	0.000	0.000	!
1116+128	EQ	2000	11:18:57.2988	+12:34:41.549	LSR	0.000	FL	0.000	0.000	!
1124-186	EQ	2000	11:27:04.3922	-18:57:17.712	LSR	0.000	FL	0.000	0.000	!
1144+402	EQ	2000	11:46:58.2966	+39:58:34.085	LSR	0.000	FL	0.000	0.000	!
1156+295	EQ	2000	11:59:31.8339	+29:14:43.608	LSR	0.000	FL	0.000	0.000	!
1213-172	EQ	2000	12:15:46.6892	-17:31:45.583	LSR	0.000	FL	0.000	0.000	!
1226+023	EQ	2000	12:29:06.6971	+02:03:08.453	LSR	0.000	FL	0.000	0.000	!
1244-255	EQ	2000	12:46:46.7983	-25:47:49.292	LSR	0.000	FL	0.000	0.000	!

1253-055	EQ	2000	12:56:11.1688	-05:47:21.695	LSR	0.000	FL	0.000	0.000	!
1308+326	EQ	2000	13:10:28.6573	+32:20:43.621	LSR	0.000	FL	0.000	0.000	!
1313-333	EQ	2000	13:16:07.9949	-33:38:59.257	LSR	0.000	FL	0.000	0.000	!
1334-127	EQ	2000	13:37:39.7841	-12:57:24.868	LSR	0.000	FL	0.000	0.000	!
1354+195	EQ	2000	13:57:04.4305	+19:19:07.251	LSR	0.000	FL	0.000	0.000	!
1413+135	EQ	2000	14:15:58.8108	+13:20:23.601	LSR	0.000	FL	0.000	0.000	!
1418+546	EQ	2000	14:19:46.5784	+54:23:14.616	LSR	0.000	FL	0.000	0.000	!
1502+106	EQ	2000	15:04:24.9752	+10:29:39.080	LSR	0.000	FL	0.000	0.000	!
1504-167	EQ	2000	15:07:04.7876	-16:52:30.238	LSR	0.000	FL	0.000	0.000	!
1510-089	EQ	2000	15:12:50.5321	-09:05:59.845	LSR	0.000	FL	0.000	0.000	!
1514-241	EQ	2000	15:17:41.8190	-24:22:19.431	LSR	0.000	FL	0.000	0.000	!
1546+027	EQ	2000	15:49:29.4326	+02:37:01.069	LSR	0.000	FL	0.000	0.000	!
1548+056	EQ	2000	15:50:35.2658	+05:27:10.400	LSR	0.000	FL	0.000	0.000	!
1606+106	EQ	2000	16:08:46.1974	+10:29:07.666	LSR	0.000	FL	0.000	0.000	!
1611+343	EQ	2000	16:13:41.0330	+34:12:47.707	LSR	0.000	FL	0.000	0.000	!
1622-297	EQ	2000	16:26:06.0237	-29:51:26.770	LSR	0.000	FL	0.000	0.000	!
1633+382	EQ	2000	16:35:15.4848	+38:08:04.423	LSR	0.000	FL	0.000	0.000	!
1637+574	EQ	2000	16:38:13.4457	+57:20:23.874	LSR	0.000	FL	0.000	0.000	!
1638+398	EQ	2000	16:40:29.6235	+39:46:45.979	LSR	0.000	FL	0.000	0.000	!
1641+399	EQ	2000	16:42:58.8001	+39:48:36.958	LSR	0.000	FL	0.000	0.000	!
1642+690	EQ	2000	16:42:07.8336	+68:56:39.698	LSR	0.000	FL	0.000	0.000	!
1655+077	EQ	2000	16:58:09.0340	+07:41:26.852	LSR	0.000	FL	0.000	0.000	!
1657-261	EQ	2000	17:00:53.1591	-26:10:51.478	LSR	0.000	FL	0.000	0.000	!
1716+686	EQ	2000	17:16:13.9209	+68:36:38.684	LSR	0.000	FL	0.000	0.000	!
1730-130	EQ	2000	17:33:02.7019	-13:04:49.502	LSR	0.000	FL	0.000	0.000	!
1732+389	EQ	2000	17:34:20.5664	+38:57:51.398	LSR	0.000	FL	0.000	0.000	!
1739+522	EQ	2000	17:40:36.9634	+52:11:43.410	LSR	0.000	FL	0.000	0.000	!
1741-038	EQ	2000	17:43:58.8510	-03:50:04.604	LSR	0.000	FL	0.000	0.000	!
SGRA	EQ	2000	17:45:40.0313	-29:00:28.591	LSR	0.000	FL	0.000	0.000	!
1749+096	EQ	2000	17:51:32.8104	+09:39:00.700	LSR	0.000	FL	0.000	0.000	!
1757-240	EQ	2000	18:00:30.4267	-24:04:01.473	LSR	0.000	FL	0.000	0.000	!
1800+440	EQ	2000	18:01:32.2950	+44:04:21.849	LSR	0.000	FL	0.000	0.000	!
1803+784	EQ	2000	18:00:45.6222	+78:28:04.022	LSR	0.000	FL	0.000	0.000	!
1807+698	EQ	2000	18:06:50.6518	+69:49:28.089	LSR	0.000	FL	0.000	0.000	!
1823+568	EQ	2000	18:24:07.0480	+56:51:01.484	LSR	0.000	FL	0.000	0.000	!
1828+487	EQ	2000	18:29:31.8047	+48:44:46.496	LSR	0.000	FL	0.000	0.000	!
1830-211	EQ	2000	18:33:39.9093	-21:03:40.049	LSR	0.000	FL	0.000	0.000	!
1842+681	EQ	2000	18:42:33.7085	+68:09:25.034	LSR	0.000	FL	0.000	0.000	!
1908-202	EQ	2000	19:11:09.6517	-20:06:54.989	LSR	0.000	FL	0.000	0.000	!
1921-293	EQ	2000	19:24:51.0545	-29:14:29.838	LSR	0.000	FL	0.000	0.000	!
1923+210	EQ	2000	19:25:59.5932	+21:06:26.106	LSR	0.000	FL	0.000	0.000	!
1928+738	EQ	2000	19:27:48.4595	+73:58:01.592	LSR	0.000	FL	0.000	0.000	!
1954+513	EQ	2000	19:55:42.7230	+51:31:48.585	LSR	0.000	FL	0.000	0.000	!
CYGA	EQ	2000	19:59:28.3546	+40:44:02.101	LSR	0.000	FL	0.000	0.000	!
1958-179	EQ	2000	20:00:57.0848	-17:48:57.547	LSR	0.000	FL	0.000	0.000	!
K3-50A	EQ	2000	20:01:45.6989	+33:32:43.518	LSR	0.000	FL	0.000	0.000	!
2005+403	EQ	2000	20:07:44.9340	+40:29:48.622	LSR	0.000	FL	0.000	0.000	!
2007+776	EQ	2000	20:05:30.9646	+77:52:43.294	LSR	0.000	FL	0.000	0.000	!
2013+370	EQ	2000	20:15:28.7151	+37:10:59.640	LSR	0.000	FL	0.000	0.000	!
2021+317	EQ	2000	20:23:19.0066	+31:53:02.395	LSR	0.000	FL	0.000	0.000	!
2023+336	EQ	2000	20:25:10.8256	+33:43:00.265	LSR	0.000	FL	0.000	0.000	!
2037+511	EQ	2000	20:38:37.0188	+51:19:12.687	LSR	0.000	FL	0.000	0.000	!
2059+034	EQ	2000	21:01:38.8275	+03:41:31.381	LSR	0.000	FL	0.000	0.000	!
NGC7027	EQ	2000	21:07:01.5931	+42:14:10.183	LSR	0.000	FL	0.000	0.000	!

2113+293	EQ	2000	21:15:29.3850	+29:33:38.540	LSR	0.000	FL	0.000	0.000	!
2121+053	EQ	2000	21:23:44.4941	+05:35:22.192	LSR	0.000	FL	0.000	0.000	!
2128-123	EQ	2000	21:31:35.2540	-12:07:04.725	LSR	0.000	FL	0.000	0.000	!
2131-021	EQ	2000	21:34:10.3053	-01:53:17.163	LSR	0.000	FL	0.000	0.000	!
2134+004	EQ	2000	21:36:38.5791	+00:41:54.319	LSR	0.000	FL	0.000	0.000	!
2136+141	EQ	2000	21:39:01.3021	+14:23:36.108	LSR	0.000	FL	0.000	0.000	!
2145+067	EQ	2000	21:48:05.4509	+06:57:38.710	LSR	0.000	FL	0.000	0.000	!
2200+420	EQ	2000	22:02:43.2793	+42:16:40.073	LSR	0.000	FL	0.000	0.000	!
2201+315	EQ	2000	22:03:14.9665	+31:45:38.359	LSR	0.000	FL	0.000	0.000	!
2210-257	EQ	2000	22:13:02.4963	-25:29:30.054	LSR	0.000	FL	0.000	0.000	!
2216-038	EQ	2000	22:18:52.0315	-03:35:36.837	LSR	0.000	FL	0.000	0.000	!
2223-052	EQ	2000	22:25:47.2570	-04:57:01.271	LSR	0.000	FL	0.000	0.000	!
2230+114	EQ	2000	22:32:36.4015	+11:43:50.985	LSR	0.000	FL	0.000	0.000	!
2234+282	EQ	2000	22:36:22.4627	+28:28:57.525	LSR	0.000	FL	0.000	0.000	!
2243-123	EQ	2000	22:46:18.2309	-12:06:51.110	LSR	0.000	FL	0.000	0.000	!
2251+158	EQ	2000	22:53:57.7438	+16:08:53.648	LSR	0.000	FL	0.000	0.000	!
2254+617	EQ	2000	22:56:17.9320	+62:01:49.545	LSR	0.000	FL	0.000	0.000	!
2255-282	EQ	2000	22:58:05.9656	-27:58:21.312	LSR	0.000	FL	0.000	0.000	!
NGC7538	EQ	2000	23:13:45.3867	+61:28:10.316	LSR	0.000	FL	0.000	0.000	!
2318+049	EQ	2000	23:20:44.8503	+05:13:50.085	LSR	0.000	FL	0.000	0.000	!

!

! The following sources are SiO masers and are useable for pointing ONLY

! if the receiver is tuned to the SiO line !!!!

! NOTE: NCS does not yet support pointing on SiO masers!

!

OCET	EQ	2000	02:19:20.7066	-02:58:36.165	LS	46.800	FL	0.000	0.000	!
SPER	EQ	2000	02:22:51.7287	+58:35:12.095	LS	-38.000	FL	0.000	0.000	!
NMLTAU	EQ	2000	03:53:28.8025	+11:24:20.713	LS	33.000	FL	0.000	0.000	!
IRC+50137	EQ	2000	05:11:19.7492	+52:52:27.689	LS	3.500	FL	0.000	0.000	!
ORIA	EQ	2000	05:35:14.4740	-05:22:30.157	LS	16.000	FL	0.000	0.000	!
UORI	EQ	2000	05:55:49.2761	+20:10:30.768	LS	-40.200	FL	0.000	0.000	!
RLMI	EQ	2000	09:45:34.1308	+34:30:44.068	LS	3.000	FL	0.000	0.000	!
RLEO	EQ	2000	09:47:33.4669	+11:25:44.288	LS	3.000	FL	0.000	0.000	!
RXBOO	EQ	2000	14:24:11.6772	+25:42:12.934	LS	1.500	FL	0.000	0.000	!
UHER	EQ	2000	16:25:47.6952	+18:53:33.188	LS	-16.800	FL	0.000	0.000	!
VXSGR	EQ	2000	18:08:04.0790	-22:13:25.313	LS	7.500	FL	0.000	0.000	!
RAQL	EQ	2000	19:06:22.2515	+08:13:49.187	LS	47.000	FL	0.000	0.000	!
WAQL	EQ	2000	19:15:23.3656	-07:02:49.766	LS	-25.500	FL	0.000	0.000	!
XCYG	EQ	2000	19:50:33.8831	+32:54:51.226	LS	8.300	FL	0.000	0.000	!
RRAQL	EQ	2000	19:57:36.7728	-01:53:04.855	LS	30.800	FL	0.000	0.000	!
NMLCYG	EQ	2000	20:46:25.5768	+40:06:59.381	LS	-1.100	FL	0.000	0.000	!
TCEP	EQ	2000	21:09:32.3331	+68:29:28.440	LS	-3.800	FL	0.000	0.000	!

To use this source catalog enter at the prompt PAKO > :

```
CATALOG SOURCE demo.sou
```

With this command we select the "source catalog", a special file, in which information about the sources is stored.

The syntax of the parameters in the source catalog is like that for the parameters of the source command, see HELP SOURCE. Lines starting with a ! are comments.

The standard file extension for source catalogs is .sou.

NOTES. In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.

Note that the format of the source catalog is (meant to be) like the source catalog format used at PLATEAU DE BURE.

```

!
! Id: demo-source.pako
!   basic SOURCE EXAMPLES,v 1.1.1 2009-05-08 by Hans Ungerechts
!
CATALOG SOURCE demo.sou           ! select source catalog
!
SOURCE NGC7027                    ! select source from catalog
!! OFFSETS /Clear                 ! optional: clear previously set offsets
!
PAUSE
!
!! OTHER WAYS TO SPECIFY A SOURCE:
!
SOURCE CALORI /catalog lines-J2000 ! select source from another catalog
PAUSE
!
SOURCE OCET EQ J2000 -
    02:19:20.71 -02:58:36.17 LSR 46.800 ! command-line specification of source
PAUSE
!
SOURCE Mars                       ! planet Mars
PAUSE
!
SOURCE Moon                       ! our Moon
PAUSE
!
SOURCE Io                         ! Jupiter's satellite "Io"
PAUSE
!
SOURCE Body Pako -                !
    2455000.0 22.2 33.3 44.4 55.5 0.66 ! solar system body (orbital elements)
PAUSE
!
SOURCE w3oh                       ! will match W30H in demo.sou
!
!! NOTES: source names must match:
!!           full source name in catalog or
!!           full name of planet or satellite
!!           the case is ignored for source name matching
!
RETURN
!
!
! Id: demo-source.pako
!   more SOURCE demos,v 1.1.1 2009-05-08 by Hans Ungerechts
!
CATALOG SOURCE demo.sou           ! select source catalog
!
SOURCE Mercury
PAUSE
!

```

SOURCE Venus
PAUSE
!
SOURCE Mars
PAUSE
!
SOURCE Jupiter
PAUSE
!
SOURCE Saturn
PAUSE
!
SOURCE Uranus
PAUSE
!
SOURCE Neptune
PAUSE
!
SOURCE Pluto
PAUSE
!
SOURCE Phobos
PAUSE
!
SOURCE Deimos
PAUSE
!
SOURCE Io
PAUSE
!
SOURCE Europa
PAUSE
!
SOURCE Ganymede
PAUSE
!
SOURCE Callisto
PAUSE
!
SOURCE Mimas
PAUSE
!
SOURCE Enceladus
PAUSE
!
SOURCE Tethys
PAUSE
!
SOURCE Dione
PAUSE
!
SOURCE Rhea
PAUSE
!

```

SOURCE Titan
PAUSE
!
SOURCE Hyperion
PAUSE
!
SOURCE Iapetus
PAUSE
!
SOURCE Miranda
PAUSE
!
SOURCE Ariel
PAUSE
!
SOURCE Umbriel
PAUSE
!
SOURCE Titania
PAUSE
!
SOURCE Oberon
PAUSE
!
RETURN
!
```

We use the command `SOURCE` to select a source for observations. Normally it is used after `CATALOG SOURCE` to select one of the sources from the source catalog. Alternatively, the parameters of the source can be specified directly on the command line, using the same format as in the source catalog. Pluto, the planets, and some of their Satellites are recognized directly by their name.

NOTES. *In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.*

For a full explanation of the parameters of the source command, see `HELP SOURCE`.

NOTES. IMPORTANT. *All characters of the source name in the command `SOURCE` must "match" those of a source name in the source catalog or a name of a special source like a planet. However, the case of the source name is ignored for matching. For example "W3OH", "w3oh", "W3oh" all match "W3OH" in the source catalog, "Mars", "Mars", and "mars" all are recognized as the planet "Mars"; however "W3O" does not match "W3OH".*

Option `/GREP` does a "grep" search for the (partial) source name or string in the source catalog. This search ignores(!) the case.

`SOURCE Body ...` has a special format, that allows to specify directly the orbital elements of a solar system body (comet).

5.3 Spectral Line Observations with Heterodyne Receivers

5.3.1 Specify your Line Catalog

```

!
! Id: demo-EMIR.lin,v 1.1.1 2009-05-06 Hans Ungerechts
!
! this is a special version for EMIR using sub bands LI, UI, and UO
!
```

```

! Line Frequency EMIR sub band
!
! E090
!
CH3OH          84.52121      LI
OCS(7-6)       85.139108      LI
SI0(V1)        86.243350      LI
H13CN          86.342274      LI
H13CO+         86.754330      LI
SI0(V0)        86.846891      LI
HCN(1-0)       88.6316024      LI
HCO+(1-0)      89.188523      LI
HNC(1-0)       90.663574      LI
HC3N(10-9)    90.9789933      LI
C34S(2-1)     96.412982      LI
OCS(8-7)      97.3012085      LI
CS(2-1)       97.980968      LI
HC3N(11-10)   100.076392      LI
34S02         102.031906      LI
13C180(1-0)   104.711385      LI
C180(1-0)     109.782182      UI
13CO(1-0)     110.201370      UI
C170(1-0)     112.359277      UI
CN(F1)(1-0)   113.490982      UI
12CO(1-0)     115.271204      UO
!
! E150
!
HC3N(15-14)   136.464400      LI
C34S(3-2)     144.617147      LI
H2CO(146)     145.602952      LI
CS(3-2)       146.969049      LI
!
! E230
!
C180(2-1)     219.560319      LI
13CO(2-1)     220.398686      LI
CH3CN220      220.747263      LI
CH3CCH222     222.166970      LI
C170(2-1)     224.714370      LI
H2CO225       225.697772      LI
12CO(2-1)     230.537990      LI
C34S(5-4)     241.016176      LI
CS(5-4)       244.935606      LI
HCN(3-2)      265.886432      LI
HCO+(3-2)     267.557625      LI
!

```

To use this line catalog enter at the prompt PAK0 > :

```
CATALOG LINE demo-EMIR.lin
```

```
!
```

```
! Id: demo.lin,v 1.1.1 2009-05-08 Hans Ungerechts
```

```

!
! Line Frequency Band
!
! HERA
!
C180(2-1)      219.560319      LSB
13C0(2-1)      220.398686      LSB
CH3CN220       220.747263      LSB
CH3CCH222      222.166970      LSB
C170(2-1)      224.714370      LSB
H2C0225        225.697772      LSB
12C0(2-1)      230.537990      LSB
C34S(5-4)      241.016176      LSB
CS(5-4)        244.935606      LSB
HCN(3-2)       265.886432      LSB
HCO+(3-2)      267.557625      LSB
!

```

To use this line catalog enter at the prompt PAKO > :

```
CATALOG LINE demo.lin
```

With this command we select the “line catalog”, a special file, in which information about the spectral lines is stored.

Each line contains 3 items: the “name” (identifier) of the line, the frequency in [GHz], and a code for the side band or EMIR sub band.

NOTES.

For the EMIR bands, we distinguish up to 4 “sub bands”, each of 4 GHz bandwidth:

- the lower outer sub band LO from about -12 GHz to -8 GHz frequency shift relative to the local oscillator;
- the lower inner sub band LI from about -8 GHz to -4 GHz;
- the upper inner sub band UI from about $+4$ GHz to $+8$ GHz; and
- the upper outer sub band UO from about $+8$ GHz to $+12$ GHz.

If we select LO, LI, UI, UO as EMIR sub band in the line catalog or directly in RECEIVER, the localoscillator will be adjusted so that the specified line frequency goes into that EMIR sub band. For details, see the EMIR user guide. For HERA, the sideband must be “LSB” (lower sideband).

Lines starting with a ! are comments.

The standard file extension for line catalogs is `.lin`.

NOTES. *In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.*

Note that this format is like the format that can be used directly with RECEIVER (see HELP RECEIVER) and also like the line catalog format used at PLATEAU DE BURE and in the “old” control system of the 30-M Telescope.

5.3.2 Setup of the Receivers (Frontends)

```

!
! Id: demo-receiver.pako
!   basic RECEIVER EXAMPLES,v 1.1.11 2011-11-24 Hans Ungerechts
!
CATALOG line    demo-EMIR.lin      ! specify line catalog

```

```

!
RECEIVER /CLEAR                ! clear all receivers previously set
!
say                             " ! NOTE: E090 band "
receiver /clear
RECEIVER E090  12C0(1-0)        - ! line (f, SB from catalog)
                        /Horizontal - ! SB from catalog
                        /Vertical   ! SB from catalog
!                               ! f = frequency
!                               ! SB = sideband / subband
pause
!
say                             " ! NOTE: E090 band "
receiver /clear
REC E090 12C0(1-0) 115.271204 U0 - ! line f SB explicit
                        /Horizontal U0 - ! SB explicit
                        /Vertical   U0  ! SB explicit
say                             " ! NOTE: E090 H&V 4 GHz BW "
pause
!
!
say                             " ! NOTE: E090 + E150 bands "
receiver /clear
RECEIVER E090  HCN(1-0)         - !
                        /Hor      LI - ! LSB Inner
                        /Ver      LI  ! LSB Inner
RECEIVER E150  CS(3-2)         - !
                        /H        LI - ! LSB Inner
                        /V        LI  ! LSB Inner
say                             " ! NOTE: E090 H+V 4 GHz BW "
say                             " !           E150 H+V 4 GHz BW "
pause
!
!
say                             " ! NOTE: E090 + E230 bands "
receiver /clear
RECEIVER E090  HCN(1-0)         - !
                        /Hor      LI - ! LSB Inner
                        /Ver      LI  ! LSB Inner
RECEIVER E230  12C0(2-1)       - !
                        /Horizontal LI - ! LSB Inner
                        /Vertical  LI  ! LSB Inner
say                             " ! NOTE: E090 H+V 4 GHz BW "
say                             " !           E230 H+V 4 GHz BW "
pause
!
!
say                             " ! NOTE: E150 + E330 bands "
receiver /clear
RECEIVER E150  CS(3-2)         - !
                        /H        LI - ! LSB Inner
                        /V        LI  ! LSB Inner
RECEIVER E330  13C0(3-2)       - !
                        /H        LI - ! LSB Inner

```



```

/V          LI    ! LSB Inner
say          " ! NOTE: E150 H+V 4 GHz BW "
say          " ! NOTE: E330 H+V 4 GHz BW "
pause
!
!!!!
!
RECEIVER    /clear          ! clear all receivers previously set
REC HERA1 12CO(2-1) 230.537990 LSB
REC HERA2 12CO(2-1) 230.537990 LSB
pause
!!
! Id: demo-receiver.pako,
!   more demos,v 1.1.11 2011-11-24 Hans Ungerechts
!
CATALOG line demo-EMIR.lin    ! specify line catalog
!
!!!!
!
say          " ! NOTE: E090 "
RECEIVER /CLEAR          ! clear previous receivers
RECEIVER E090          ! everything default
pause
!
say          " ! NOTE: E090 using line catalog "
receiver /clear
RECEIVER E090 HCN(1-0)    ! line (f, SB from catalog)
pause
!
say          " ! NOTE: E090 explicit options "
RECEIVER E090 HCN(1-0)   - ! explicit options:
                        /Horizontal LI UI - ! SBs for Hori. polar.
                        /Vertical LI UI - ! SBs for Vert. polar.
                        /dop dop - ! Doppler correction
                        /gain -13 db - ! image gain ratio
                        /temp 30 260 - ! COLD and AMB load temp.
                        /eff 0.95 0.75 - ! forward and beam eff.
                        /scale beam !
pause
!
say          " ! NOTE: E090 H+V full band "
receiver /clear
RECEIVER E090 HCN(1-0)   - !
                        /Horizontal LI UI - !
                        /Vertical LI UI !
say          " ! NOTE: E090 H+V LI+UI 2*4 GHz BW "
say          " ! ++ E090 H+V LO+UO for FTS "
!          ! for spectroscopy on full BW
!          ! enter BACKEND FTS /default
pause
!
!!!!
!
say          " ! NOTE: E150 H+V 1 subband "

```

```

receiver /clear
RECEIVER E150   CS(3-2)           - !
                  /Horizontal LI   - !
                  /Vertical  LI    !
say              " ! NOTE: E150 H+V LI      4 GHz BW "
pause
!
!!!!
!
say              " ! NOTE: E230 H+V full band "
receiver /clear
RECEIVER E230   12C0(2-1)        - !
                  /Horizontal LI UI - !
                  /Vertical  LI UI  !
say              " ! NOTE: E230 H+V LI+UI 2*4 GHz BW "
say              " ! ++ E230 H+V LO+UO    for FTS "
pause
!
!!!!
!
say              " ! NOTE: E330 H+V full band "
receiver /clear
RECEIVER E330   13C0(3-2)        - !
                  /Horizontal LI UI - !
                  /Vertical  LI UI  !
say              " ! NOTE: E330 H+V LI+UI 2*4 GHz BW "
say              " ! ++ E330 H+V LO+UO    for FTS "
pause
!
!!!!
!
say              " ! NOTE: E090+E150 H+V LI ++ E090 LO"
receiver /clear
RECEIVER E090   HCN(1-0)         - !
                  /Hor           LI   - ! LSB Inner
                  /Ver           LI    !
RECEIVER E150   CS(3-2)           - !
                  /H             LI   - !
                  /V             LI    !
say              " ! NOTE: E090 H+V LI      4 GHz BW "
say              " !           E150 H+V LI      4 GHz BW "
say              " ! ++ E090 H+V    LO    for FTS "
pause
!
say              " ! NOTE: E090 full BW + E150 LI    "
receiver /clear
RECEIVER E090   HCN(1-0)         - !
                  /Hor           UI   - ! LSB Inner
                  /Ver           LI    !
RECEIVER E150   CS(3-2)           - !
                  /H             none - !
                  /V             LI    !
say              " ! NOTE: E090 H UI + V LI 4 GHz BW "
say              " !           E150           V LI 4 GHz BW "

```

```

say                                " ! ++ E090 H UO + V LO for FTS "
pause
!
!!!
!
say                                " ! NOTE: E090+E230 H+V UI ++ 4*UO "
receiver /clear
REC E090 12C0(1-0) 115.271204 UO - ! line on UO
      /Hor          UI - ! UI on one of IF cables 1 to 4
      /Ver          UI - ! line (UO) on one of cables 5 to 8
REC E230 12C0(2-1) 230.537990 UI - !
      /Horizontal  UI - !
      /Vertical    UI - !
say                                " ! NOTE: E090 H+V UI      4 GHz BW "
say                                " ! ++ E090 H+V      UO    for FTS "
say                                " !      E230 H+V UI      4 GHz BW "
say                                " ! ++ E230 H+V      UO    for FTS "
pause
!
say                                " ! NOTE: E090+E230 H+V LI ++ 4*LO "
receiver /clear
RECEIVER E090  HCN(1-0)          - !
      /Hor          LI - !
      /Ver          LI - !
RECEIVER E230  13C0(2-1)        - !
      /Horizontal  LI - !
      /Vertical    LI - !
say                                " ! NOTE: E090 H+V LI      4 GHz BW "
say                                " ! ++ E090 H+V      LO    for FTS "
say                                " !      E230 H+V LI      4 GHz BW "
say                                " ! ++ E230 H+V      LO    for FTS "
pause
!
say                                " ! NOTE: E090          V UO          "
say                                " !      + E230 H LI+UI V UI          "
receiver /clear
REC E090 12C0(1-0) 115.271204 UO - ! line on UO
      /Hor          none - !
      /Ver          UO - ! line (UO) on one of cables 1 to 4
REC E230 12C0(2-1) 230.537990 UI - !
      /Horizontal  LI UI - !
      /Vertical    UI - !
say                                " ! NOTE: E090          V UO          "
say                                " !      E230 H LI+UI V UI          "
say                                " ! ++ E230 H LO+UO V UO for FTS "
pause
!
say                                " ! NOTE: E090          V UI          "
say                                " !      + E230 H LI+UI          "
receiver /clear
REC E090 CS(2-1) 97.980965 UI - !
      /Hor          none - !
      /Ver          UI - !
REC E230 12C0(2-1) 230.537990 UI - !

```

```

                /Horizontal LI UI - !
                /Vertical  none  !
say             " ! NOTE: E090          V UI          "
say             " !          E230 H LI+UI          "
say             " ! ++  E090          V UO for FTS "
say             " ! ++  E230 H LO+UO          for FTS "
pause
!
say             " ! NOTE: E090+E230 full BW single pol"
receiver /clear
RECEIVER E090  HCN(1-0)          - !
                /Hor          LI UI - ! LSB Inner (LI) USB Inner (UI)
                /Ver          none  !
RECEIVER E230  12C0(2-1)        - !
                /Horizontal none - !
                /Vertical  LI UI  ! LSB Inner (LI) USB Inner (UI)
say             " ! NOTE: E090 H  LI+UI 2*4 GHz BW "
say             " ! ++  E090 H  LO+UO  for FTS "
say             " ! NOTE: E230  V LI+UI 2*4 GHz BW "
say             " ! ++  E230  V LO+UO  for FTS "
pause
!
!!!
!
say             " ! NOTE: E150 LI + E330 8 GHz      "
receiver /clear
!
RECEIVER E150  CS(3-2)          - !
                /Horizontal LI   - !
                /Vertical  LI   !
RECEIVER E330  13C0(3-2)        - !
                /Horizontal LI   - !
                /Vertical  LI   !
say             " ! NOTE: E150 H+V LI   4 GHz BW "
say             " ! NOTE: E330 H+V LI   4 GHz BW "
say             " ! ++  E330 H+V LO   for FTS "
pause
!
say             " ! NOTE: E150 LI + E330 full BW      "
receiver /clear
!
RECEIVER E150  CS(3-2)          - !
                /Horizontal none - !
                /Vertical  LI   !
RECEIVER E330  13C0(3-2)        - !
                /Horizontal UI   - !
                /Vertical  LI   !
say             " ! NOTE: E150          V LI 4 GHz BW "
say             " ! NOTE: E330 H UI + V LI 4 GHz BW "
say             " ! ++  E330 H UO + V LO for FTS "
pause
!
!
RETURN

```

!

Normally we use the `RECEIVER` command with 2 parameters: a receiver name and a line name. The line name must be the name of a line in the line catalog selected earlier. The frequency and sideband or EMIR sub band are then taken from the line catalog. Alternatively the frequency and sideband or sub band can be specified directly as the 3rd and 4th parameter.

NOTES.

For the EMIR bands, we distinguish up to 4 “sub bands”, each of 4 GHz bandwidth:

- the lower outer sub band LO from about -12 GHz to -8 GHz frequency shift relative to the local oscillator;
- the lower inner sub band LI from about -8 GHz to -4 GHz;
- the upper inner sub band UI from about $+4$ GHz to $+8$ GHz; and
- the upper outer sub band UO from about $+8$ GHz to $+12$ GHz.

If we select LO, LI, UI, UO as EMIR sub band in the line catalog or directly in `RECEIVER`, the localoscillator will be adjusted so that the specified line frequency goes into that EMIR sub band. For details, see the EMIR user guide. For HERA, the sideband must be “LSB” (lower sideband).

NOTES. *In source names, line names, and parameters of type character, like Project ID, names of PI, observer, operator, one can not use characters that have a special meaning in XML, in particular don't use: & < or >; also don't use: (or) in source names.*

One `RECEIVER` command is needed for each receiver, EMIR band, or part of HERA.

After the receiver is set up, and a source has been selected, the observer should enter

`CALIBRATE [/SKY no]`

`START`

to send the receiver parameters to the NCS. The telescope operator or receiver engineer will then tune the receiver.

`/HORIZONTAL [sb1 [sb2]]` and `/VERTICAL[sb1 [sb2]]` apply only to EMIR. This option informs the system about which EMIR subbands are going to be used for the horizontal and vertical polarization. (about the EMIR sub bands see above, and the EMIR user guide.)

`/CLEAR` completely clears the receiver setup.

`RECEIVER` must be specified before `BACKEND`.

After you enter a receiver setup manually, we recommend to “save” it, optionally to a named file:

`SAVE RECEIVER [/FILE receiver-1]`

It can then at any later time be reloaded with `@ receiver[-1]`, see `HELP SAVE`.

Option `/DEROTATOR angle system` sets the derotator angle for HERA.

`/DOPPLER` controls whether Doppler corrections will be applied for that receiver.

`/WIDTH` allows to select “narrow” or “wide” mode for HERA. Note that simple standard VESPA setups require “narrow”. This option does not apply to EMIR.

`/GAIN` allows to set the gain ratio, I/S, between image and signal sidebands. With the syntax `/GAIN -13 db` you can specify the image gain directly in [dB].

`/TEMP[LOAD]` allows to set the (effective) temperatures of the cold and ambient loads. `/TEMP L L` implies that during the execution of the observations, the NCS will use the “best-known” values. For the cold load this is based on a lookup table, for the ambient load it is derived from a measurement of the physical temperature.

`/EFF[ICIENCY]` allows to set the forward and (main) beam efficiencies.

Gain ratio, load temperatures, and efficiencies describe physical parameters of the system, which can not really be “controlled” by the observer. However, the options are available here to specify these values, because they are important for the calibration of the data during data processing. Normally the system will provide reasonable defaults for all these calibration parameters.

At the 30-M Telescope it is generally recommended to use the antenna temperature scale during observations, and to do any scaling to other scales lateron during off-line data processing. (See the documentation about calibration for more details.)

5.3.3 Setup of the Backends (Spectrometers and Continuum)

```

!
! Id: demo-backend.pako
!   basic BACKEND EXAMPLES,v 1.1.11 2011-11-24 Hans Ungerechts
!
swTotal /default                ! select a switching mode
!                               ! compatible with all backends
!
!   one example of a complex EMIR setup:
!
! pako\RECEIVER
pako\RECEIVER /clear
!
RECEIVER E090 CS(2-1) 97.980965 LI -
  /horizontal LI                -
  /vertical   LI
!
RECEIVER E230 CO(2-1) 230.537994 LI -
  /horizontal LI                -
  /vertical   LI
!
!
BACKEND /CLEAR                  ! clear all backend setups
!
!                               ! EMIR BBC
BACKEND BBC                    /Default    ! connect 1 part
!                                       ! to both polarizations
!                                       ! of each sideband
!                                       ! of each selected EMIR band
pause
!
!                               ! EMIR NBC
backend /clear
BACKEND NBC                    /Default    ! connect 1 part to
!                                       ! each selected EMIR subband
pause
!
!                               ! EMIR WILMA
backend /clear
BACKEND WILMA                  /Default    ! connect 1 part to
!                                       ! each selected EMIR subband
pause
!
!                               ! EMIR 4MHz
!                               ! NOTE: 4MHz has only 2
!                               !           parts with EMIR
backend /clear
BACKEND 4MHz                   /Default    ! connect 1 part to each of

```



```

BACKEND WILMA          /Default          !
BACKEND 4MHz          /Default          !
BACKEND VESPA 1 0.040 40.0 0.0 E090 Horiz LI
BACKEND VESPA 2 0.040 40.0 0.0 E090 Verti LI
BACKEND VESPA 3 0.040 40.0 0.0 E230 Horiz LI
BACKEND VESPA 4 0.040 40.0 0.0 E230 Verti LI
say                    " ! backends can be combined"
pause
!
!
!! EMIR VESPA autocorrelator -- basic mode with fShift. optional: line name
!
backend /clear
BACKEND VESPA 1 0.040 40.0 -120.0 E090 Horiz LI /line EOHU0-M
BACKEND VESPA 2 0.040 40.0 120.0 E090 Horiz LI /line EOHU0-P
BACKEND VESPA 3 0.040 40.0 -100.0 E090 Verti LI /line myLine3
BACKEND VESPA 4 0.040 40.0 110.0 E090 Verti LI /line myLine4
BACKEND VESPA 5 0.040 80.0 -150.0 E230 Horiz LI /line ""
BACKEND VESPA 6 0.040 80.0 150.0 E230 Horiz LI /line apple
BACKEND VESPA 7 0.040 80.0 -200.0 E230 Verti LI /line orange
BACKEND VESPA 8 0.040 80.0 200.0 E230 Verti LI /line red
pause
!
!! EMIR VESPA autocorrelator -- basic and parallel modes
!
backend /clear
BACKEND VESPA 1 0.320 240.0 0.0 E090 Horiz LI
BACKEND VESPA 2 0.320 240.0 0.0 E090 Verti LI
BACKEND VESPA 3 0.320 240.0 0.0 E230 Horiz LI /mode parallel
pause
!
!! NOTE: BACKEND VESPA ... E230 Horiz LI /mode parallel
!!       connects one VESPA part in parallel to
!!       E230 Horiz LI and E230 Verti LI
!!       (both must be selected in RECEIVER command)
!
!
!! HERA with FTS wide bandwidth
!
receiver /clear
RECEIVER HERA1 /WIDTH wide
RECEIVER HERA2 /WIDTH wide
!
backend /clear
BACKEND FTS 1          /RECEIVER HERA1
BACKEND FTS 2          /RECEIVER HERA2
!
!
!! HERA narrow bandwidth with FTS fine resolution
!
receiver /clear
RECEIVER HERA1 /WIDTH narrow
RECEIVER HERA2 /WIDTH narrow
!

```



```

backend /clear
BACKEND FTS 1 /FINE /RECEIVER HERA1
BACKEND FTS 2 /FINE /RECEIVER HERA2
!
!
! Id: demo-backend.pako,
! more BACKEND demos,v 1.1.11 2011-11-24 Hans Ungerechts
!
! one example of a complex EMIR setup:
!
RECEIVER /CLEAR
!
! pako\RECEIVER
pako\RECEIVER /clear
!
RECEIVER E090 CS(2-1) 97.980965 LI -
/horizontal LI -
/vertical LI
!
RECEIVER E230 CO(2-1) 230.537994 LI -
/horizontal LI -
/vertical LI
!
!
BACKEND /CLEAR ! clear all backend setups
!
!! EMIR BBC broad band continuum
!!
!! name # resolu bandw. fShift band polar SB
!! ---- - - - - - - - - - - - - - - - - - - - -
!
BACKEND BBC 1 8000 8000 0 E090 H LSB
BACKEND BBC 2 8000 8000 0 E090 V LSB
BACKEND BBC 3 8000 8000 0 E090 H USB
BACKEND BBC 4 8000 8000 0 E090 V USB
BACKEND BBC 5 8000 8000 0 E230 H LSB
BACKEND BBC 6 8000 8000 0 E230 V LSB
BACKEND BBC 7 8000 8000 0 E230 H USB
BACKEND BBC 8 8000 8000 0 E230 V USB
pause
!
BACKEND /CLEAR ! clear all backend setups
!
!! EMIR VESPA autocorrelator -- basic mode
!! NOTE: VESPA examples give only some possibilities, for
!! a complete list see the VESPA documentation
!!
!! name # resolu bandw. fShift band polar SB
!! ---- - - - - - - - - - - - - - - - - - - - -
!
BACKEND VESPA 1 0.040 40.0 0.0 E090 Horiz LI
BACKEND VESPA 2 0.040 40.0 0.0 E090 Verti LI
BACKEND VESPA 3 0.040 40.0 0.0 E230 Horiz LI
BACKEND VESPA 4 0.040 40.0 0.0 E230 Verti LI

```

```

pause
!
!
backend /clear
BACKEND VESPA 1 1.250 320.0 0.0 E090 Horiz LI
BACKEND VESPA 2 1.250 320.0 0.0 E090 Verti LI
BACKEND VESPA 3 1.250 320.0 0.0 E230 Horiz LI
BACKEND VESPA 4 1.250 320.0 0.0 E230 Verti LI
pause
!
!
!! EMIR VESPA autocorrelator -- basic mode with fShift. optional: line name
!
backend /clear
BACKEND VESPA 1 0.040 40.0 -120.0 E090 Horiz LI /line EOHU0-M
BACKEND VESPA 2 0.040 40.0 120.0 E090 Horiz LI /line EOHU0-P
BACKEND VESPA 3 0.040 40.0 -100.0 E090 Verti LI /line myLine3
BACKEND VESPA 4 0.040 40.0 110.0 E090 Verti LI /line myLine4
BACKEND VESPA 5 0.040 80.0 -150.0 E230 Horiz LI /line ""
BACKEND VESPA 6 0.040 80.0 150.0 E230 Horiz LI /line apple
BACKEND VESPA 7 0.040 80.0 -200.0 E230 Verti LI /line orange
BACKEND VESPA 8 0.040 80.0 200.0 E230 Verti LI /line red
pause
!
!
!! EMIR VESPA autocorrelator -- ultra high resolution mode
!
backend /clear
BACKEND VESPA 1 0.0033 20.0 0.0 E090 Horiz LI
BACKEND VESPA 2 0.0033 20.0 0.0 E090 Verti LI
BACKEND VESPA 3 0.0066 20.0 0.0 E230 Horiz LI
BACKEND VESPA 4 0.0066 20.0 0.0 E230 Verti LI
pause
!
backend /clear
!

```

The command `BACKEND` has up to 8 parameters: backend name, logical part number, resolution [MHz], bandwidth [MHz], frequency shift [MHz], receiver (band), EMIR polarization, and EMIR sub band. The receiver band and subbands must have been previously selected with `RECEIVER`.

For some backends the resolution, bandwidth, and/or frequency shift are fixed and a shorter syntax is possible. See the `HELP BACKEND` for complete information.

`/CLEAR` completely clears the backend setup.

Normally, the continuum backends are used (only) for `POINTING`, `FOCUS`, and `TIP` (antenna tipping or “skydip”).

For `VESPA` only a selected few (!) possibilities are shown; for more information see the `VESPA` user’s guide.

After you enter a backend setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE BACKEND [/FILE backend-1]
```

It can then at any later time be reloaded with `@ backend[-1]`, see `HELP SAVE`.

5.3.4 CALIBRATE

```

!
! Id: demo-calibrate.pako
!   CALIBRATE EXAMPLE,v 1.1.5 2011-04-25 Hans Ungerechts
!
CALIBRATE                               - !
  /AMBIENT                               - ! ambient load
  /COLD                                   - ! cold    load
  /SKY      -600.0  0.0                   - ! sky at offsets -600.0 0.0
  /SYSTEM      projection                   - ! system for sky offset
  /TCALIBRATE  5.0                         ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]"      ! a chance to check
!
START                                     ! start
!
!! Comments:
!! we assume here that source, receivers, and backends
!! already have been selected and setup,
!! see: demo-source, demo-receiver, demo-backend
!! NOTE: this is a generic calibrate for any heterodyne receiver(s)
!! and backends. Remember to select the appropriate backend before
!! Calibrate: normally a continuum backend for POINTING and FOCUS
!! and spectrometer(s) for TRACK, ONOFF, and (heterodyne) OTFMAPs
!

```

In a standard calibration for heterodyne receivers, we observe 3 subscans, “SAC”: on a Sky position, an Ambient temperature load (a.k.a., “hot” load), and a “Cold” load. Calibrations are always and automatically done in TOTAL POWER.

A calibration needs to be done for any heterodyne observation in order to get data with a calibrated intensity scale. It is normally done before the target observations. It must always be done after changing receiver and/or backend setups. It should also be done when changing sources and often enough to follow any variation of the atmosphere, about every 15 minutes.

After you enter a calibrate setup manually, we recommend to “save” it, optionally to a named file:
 SAVE CALIBRATE [/FILE calibrate-1]

It can then at any later time be reloaded with @ calibrate[-1], see HELP SAVE.

5.3.5 POINTING

```

!
! Id: demo-pointing.pako
!   POINTING EXAMPLE,v 1.1.11 2011-11-25 Hans Ungerechts
!
SOURCE   Mars                               !
OFFSETS /CLEAR                               ! clear previously set offsets
!
@ demo-rx                                    ! demo setup of EMIR
!                                           ! REPLACE WITH YOUR SETUP!
!
BACKEND /CLEAR                               ! clear previous backend setup
!
BACKEND BBC      /Default                    ! connect 1 part to each

```

```

!                               ! EMIR subband selected
!
SET ANGLEUNIT arcsec           ! make sure angle unit is arc sec
!
SWBEAM                         ! to select beam switching
!
POINTING /DEFAULT              ! reset all options
!
POINTING      120              - ! pointing with subscan length 120
  /NOTF        4                - ! 4 OTF subscans
  /TOTF       30.0             ! 30 seconds per OTF subscan
!
PAUSE "POINTING OK to start? [c/q]" ! a chance to check
!
START                               ! start
!
RETURN
!
!!
!! NOTE:
!! if you use NASMYTH offsets for an off-center pixel
!! of a mutlibeam receiver don't use OFFSETS/ CLEAR.
!! If you want the intensity of the Pointing data to be
!! calibrated, you have to do a Calibrate with the same
!! receivers and (continuum) backends before the pointing.
!!
!!

```

POINTING observations are done to optimize the positioning of the telescope in Azimuth and Elevation. This is normally done by continuum observations of a cross scan in azimuth and elevation on a point source (or at least a small source) near the intended target source.

It is normally used with BEAM SWITCHING or WOBBLER SWITCHING; it is also possible with TOTAL POWER. (With the bolometer POINTING is done with WOBBLER SWITCHING).

A calibration is not needed for POINTING, if one is only interested in the pointing corrections, and not in the source intensity.

After a pointing the data processing software displays the results and you can enter a correction for the observed pointing offsets with the command

```
SET POINTING azimuthCorrection elevationCorrection
```

Note that this is the total correction, i.e., the previous correction plus the additional offset found with the POINTING observation.

After you enter a pointing setup manually, we recommend to "save" it, optionally to a named file:

```
SAVE POINTING [/FILE pointing-1]
```

It can then at any later time be reloaded with @ pointing[-1], see HELP SAVE.

5.3.6 FOCUS

```

!
! Id: demo-focus.pako
!   FOCUS EXAMPLE,v 1.1.1 2009-05-08 Hans Ungerechts
!
SWBEAM                         ! to select beam switching
!
FOCUS      2.0                 - ! length [mm]
  /NSUBSCANS 6                 - ! number of subscans

```

```

    /TSUBSCAN      12                !   time per subscan
!
PAUSE "FOCUS OK to start? [c/q]"    !   a chance to check
!
START                !   start
!
!! Comments:
!! We assume here that a pointing measurement has been done
!! immediately before the FOCUS (strongly recommended!),
!! see: demo-pointing, and therefore
!! we assume here that source, receivers, and backends
!! already have been selected and set up.
!! If you want the intensity of the Focus data to be
!! calibrated, you have to do a Calibrate with the same
!! receivers and (continuum) backends before.

```

FOCUS measurements are done to optimize the position of the subreflector (secondary) along the telescope axis by maximizing the intensity of the radiation focussed into the receiver(s). It is best done on a strong point source, e.g., on a planet if or when its angular diameter is less than the beam width at the frequency to be observed. It is strongly recommended to do a POINTING on the same source before a FOCUS.

FOCUS is normally used with BEAM SWITCHING or WOBBLER SWITCHING. (With the bolometer FOCUS is done with WOBBLER SWITCHING).

A calibration is not needed for FOCUS, anyhow it will probably already have been done before the POINTING before the FOCUS!

After a focus the data processing software displays the results and you can enter a correction for the observed focus offset with the command

```
SET FOCUS focusCorrection
```

Note that this is the total correction, i.e., the previous correction plus the additional offset found with the FOCUS observation.

The optional focus correction for different receiver bands may be slightly different, by a few times 0.1 mm, and the observer can decide to optimize for one particular band or use a compromise value.

After you enter a focus setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE FOCUS [/FILE focus-1]
```

It can then at any later time be reloaded with @ focus[-1], see HELP SAVE.

5.3.7 TRACK (Single Position with Frequency Switching)

```

!
! Id: demo-track.pako
!   TRACK EXAMPLE,v 1.1.11 2011-11-25 Hans Ungerechts
!
!
@ demo-rx                !   demo setup of receivers
!
BACKEND /CLEAR           !   clear previous backends
BACKEND VESPA 1 0.040 40.0 0.0 E090 hor LI !   high spectral resolution
BACKEND VESPA 2 0.040 40.0 0.0 E090 ver LI !   with VESPA
BACKEND VESPA 3 0.080 80.0 0.0 E230 hor LI
BACKEND VESPA 4 0.080 80.0 0.0 E230 ver LI
!
!                       !   REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec        !

```

```

!
!
! setup frequency switching
SWFREQUENCY  -3.9    3.9  /receiver E090 ! for EMIR band E090
SWFREQUENCY  -11.7   11.7 /receiver E230 ! for EMIR band E230
SWFREQUENCY                /tphase  0.20 ! same for all receivers/bands
!
CALIBRATE                - !
  /AMBIENT                - ! ambient load
  /COLD                    - ! cold    load
  /SKY      -600.0  0.0    - ! sky at offsets -600.0 0.0
  /SYSTEM      projection - ! system for SKY offsets
  /TCALIBRATE  5.0        ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                    ! start
!
TRACK      40.0  -30.0    - ! offsets of on position
  /NSUBSCANS  5          - ! number of subscans
  /SYSTEM      projection - ! system for offset
  /TSUBSCAN   60         ! time per subscan
!
PAUSE "TRACK SWFREQUENCY OK to start? [c/q]" ! a chance to check
!
START                    ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source

```

The TRACK observing mode simply tracks one position relative to the source. It is normally used with FREQUENCY SWITCHING and offsets in /SYSTEM projection.

The basic parameters are the offsets for the position to track; parameters of the options are the (total) number of subscans, and the time per subscan in [s].

After you enter a track setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE TRACK [/FILE track-1]
```

It can then at any later time be reloaded with @ track[-1], see HELP SAVE.

You may want to save the switching mode separately or with TRACK into the same file:

```
SAVE SWITCHING /FILE track-2
```

```
SAVE TRACK      /FILE track-2 /APPEND
```

NOTES. IMPORTANT:

FREQUENCY SWITCHING *is very powerful and efficient for some projects, e. g., mapping of narrow spectral lines in cold dark clouds outside the plane of the Milky Way. However, before deciding to use frequency switching one should consider some potential drawbacks:*

The target lines should be narrow enough so that line signals from the 2 phases of the switching cycle are well separated.

The spectral baseline will generally be less flat than in other switching modes.

Some spectral lines are also emitted in the earth's mesosphere, e.g., the mesospheric lines from (12)CO are rather strong, and they will be seen in FREQUENCY SWITCHING spectra taken toward astronomical

sources with a low Doppler shift. The mesospheric lines will appear at a frequency and velocity that corresponds to the rest frame of the atmosphere, i. e., the observatory. Care must be taken that they are not confused with the lines from the astronomical source. (Information computed by the ASTRO software can help with this decision).

When observing sources near the plane of the Milky Way, line emission from clouds at other velocities than the target source, e. g., other spiral arms, can cause confusion.

In case of doubt, consult the special memo on FREQUENCY SWITCHING or ask an experienced FREQUENCY SWITCHING observer!

5.3.8 ON-OFF (“Position Switching” and Wobbler ON-OFF)

```

!
! Id: demo-onoff.pako
!   ONOFF SWTOTAL EXAMPLE,v 1.1.1 2009-05-05 Hans Ungerechts
!   "POSITION SWITCHING"
!
@ demo-rx-spectrometers           ! demo setup of receivers
!                               ! and spectrometers
!                               ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec                 !
!
SWTOTAL                          - ! select total power
  /TPHASE          0.5           ! time per phase (data sample)
!
CALIBRATE                        - !
  /AMBIENT          - ! ambient load
  /COLD             - ! cold   load
  /SKY              -600.0  0.0 - ! sky at offsets -600.0 0.0
  /SYSTEM           projection - ! system for SKY offsets
  /TCALIBRATE      5.0         ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                            ! start
!
ONOFF          40.0  -30.0        - ! offsets of on position
  /NSUBSCANS   12                - ! number of subscans
  /REFERENCE   -600.0  0.0  projection - ! offsets of off-source reference
  /SYSTEM      projection        - ! system for offsets
  /SYMMETRIC   - ! "symmetric" subscan sequence
  /TSUBSCAN    30                ! time per subscan
!
PAUSE "ONOFF SWTOTAL OK to start? [c/q]" ! a chance to check
!
START                            ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source

```

In its first form ONOFF is used with TOTAL POWER. Subscans are taken alternating between a position that's considered to be “ON-source” and a reference position that's normally assumed to be “OFF-source”,

i.e., free of emission.

The source signal is then calculated as the difference between “ON” and “OFF”.

The basic parameters are the offsets for the ON position, parameters of the options are the offsets for the reference position, the (total) number of subscans, and the time per subscan in [s].

After you enter an ON-OFF setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE ONOFF [/FILE onoff-1]
```

It can then at any later time be reloaded with @ onoff [-1], see HELP SAVE.

You may want to save the switching mode separately or with ONOFF into the same file:

```
SAVE SWITCHING /FILE onoff-2
SAVE ONOFF      /FILE onoff-2 /APPEND
```

/SYMMETRIC selects a subscan sequence that is “symmetric” in time; for details see HELP ONOFF /SYMMETRIC. This requires that the number of subscans is a multiple of 4.

This form of ONOFF is also called “Position Switching”, but it should be noted that the “switching” here is realized by a sequence of subscans at different positions, i.e., in a way completely different from switching in the sense of BEAM SWITCHING, WOBBLER SWITCHING, and FREQUENCY SWITCHING.

```
!
! Id: demo-onoff-swwobbler.pako
!   ONOFF SWWOBBLER EXAMPLE,v 1.1.6 2011-07-31 Hans Ungerechts
!   "WOBBLER SWITCHING"
!
@ demo-rx-spectrometers      ! demo setup of receivers
!                            ! and spectrometers
!                            ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec            !
!
!                            ! select wobbler switching
SWWOBBLER      -120.0  120.0 - ! wobbler +/- 120 arc sec
  /TPHASE        1.0      ! 1 seconds per phase
!
CALIBRATE                - !
  /AMBIENT                - ! ambient load
  /COLD                    - ! cold load
  /SKY      -600.0  0.0    - ! sky at offsets -600.0 0.0
  /SYSTEM      projection - ! system for SKY offsets
  /TCALIBRATE  5.0        ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                    ! start
!
!!                        ! OPTIONAL:
!! OFFSETS  20 30        - ! mapping offsets in
!! /SYSTEM  projection    ! system projection
!
ONOFF  /SWWOBBLER        - ! ONOFF for Wobbler switching
  /NSUBSCANS  12         - ! number of subscans
  /SYMMETRIC                - ! "symmetric" subscan sequence
  /TSUBSCAN   30          ! time per subscan
!
```



```

PAUSE "ONOFF SWOBBLER OK to start? [c/q]" ! a chance to check
!
START ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source
!!
!! IMPORTANT NOTE: ONOFF with SWOBBLER (wobbler switching on-off)
!! requires that the subscans are offset relative to the source
!! in the trueHorizon system by -1 * the Wobbler elongations (offsets).
!! With the commands above, paKo recognizes this and automatically
!! sets the correct values.
!! In this case, OFFSETS can be used to set additional mapping
!! offsets in the "projection" of the astronomical coordinate
!! system. These mapping offsets in the projection apply
!! to all ONOFF subscans.

```

When ONOFF is used with WOBBLER SWITCHING (command SWOBBLER), the position offsets must be set to very specific values in TRUE (ANGLE) HORIZON depending on the parameters of SWOBBLER. This is achieved by using the special option /SWOBBLER of the command ONOFF.

Subscans are then taken alternating between 2 positions in such a way that: (a) in some subscans (one position of the antenna) the source is in the first of the two Wobbler phases, (b) in the other subscans (the other position of the antenna) the source is in the second of the two Wobbler phases. During the data processing, the source signal is computed as a double difference: 1st the difference of the 2 Wobbler phases; 2nd the difference between ONOFF subscans (a) and (b).

This form of ONOFF is also called "Wobbler-Onoff" or sometimes simply "Wobbler Switching".

The combination(!) of ONOFF and WOBBLER SWITCHING provides a very high sensitivity in continuum bolometer observations of compact sources, and excellent baselines for spectroscopy.

It has the disadvantage that the (emission-free?) off-source positions are very close to the source (limited by the maximum Wobbler throw). Also, the Wobbler direction is fixed in the horizontal system relative to the telescope, and therefore in the source system the off-source positions rotate around the source position.

For continuum observations, usually a short time per Wobbler phase, 0.25 s, is used with small Wobbler offsets (throws); for spectroscopy, largest possible Wobbler offsets (throws), up to $\pm 120''$ are preferred, but then the time per phase must be longer, 1 – 2 s.

5.3.9 OTF (On-The-Fly Mapping)

```

!
! Id: demo-otfmap.pako
!   OTFMAP SWTOTAL EXAMPLE,v 1.1.6 2011-07-21 Hans Ungerechts
!
@ demo-rx-spectrometers ! demo setup of receivers
! ! and spectrometers
! ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec !
!
SWTOTAL - ! to select total power
  /TPHASE 0.5 ! time per phase (data sample)
!
CALIBRATE - !
  /AMBIENT - ! ambient load

```

```

/COLD                - ! cold    load
/SKY                 - ! sky at offsets -500.0 -400.0
/SYSTEM              - ! system for SKY offset
/TCALIBRATE         5.0      ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]"      ! a chance to check
!
START                ! start
!
OTFMAP               -300   -15  300  -15  - ! offsets at start and end of first OTF
/CROLOOP             ROR      - ! subscans: reference-OTF-reference
/NOTF                4        - ! number of on-the-fly subscans
/REFERENCE            -500  -400  projection - ! offsets of off-source reference
/STEP                0    10    - ! step (shift) between OTF subscans
/SYSTEM              projection - ! system for offsets
/TOTF                120.0    - ! time per on-the-fly subscan
/TREFERENCE           20.0    - ! time per off-source reference
/ZIGZAG              ! go back and forth
!
PAUSE "OTFMAP SWTOTAL OK to start? [c/q]" ! a chance to check
!
START                ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source
!!
!! /CROLOOP          ROR means that there will be an
!!                   off-source reference subscan (R)
!!                   before and after each OTF suscan (0).
!!                   Therefore with /NOTF 4 on-the-fly subscans the complete
!!                   subscan sequence will be:
!!                   R OTF#1 R   R OTF#2 R   R OTF#3 R   R OTF#4 R
!!                   with
!! /CROLOOP          ROOROR it would be:
!!                   R OTF#1      OTF#2   R   OTF#3      OTF#4 R
!

```

In OTFMAP (on-the-fly) observations, the antenna moves relative to the source while recording its position and taking data a high rate, thus performing “scans” in the strict sense of the word. This is a very fast mode for mapping.

The basic parameters of the command are the position offsets of the start and end of the first OTF subscan; the basic parameters of the options are: the number of OTF subscans, the offsets of an off-source reference position, the step (shift) in x- and y-offsets between subsequent OTF subscans, the time per OTF subscan in [s], and the time per off-source reference subscan [s].

This observing mode is normally used either with:

- (i) TOTAL POWER with an off-source reference for spectral line observations, or
- (ii) FREQUENCY SWITCHING without off-source reference for spectral line observations (see below), or
- (iii) WOBBLER SWITCHING and TRUE (ANGLE) HORIZON offsets for continuum mapping with the bolometer.

After you enter an OTF-map setup manually, we recommend to “save” it, optionally to a named file: SAVE OTFMAP [/FILE otfmap-1]

It can then at any later time be reloaded with @ otfmap[-1], see HELP SAVE.

You may want to save the switching mode separately or with OTFMAP into the same file:

```
SAVE SWITCHING /FILE otfmap-2
SAVE OTFMAP    /FILE otfmap-2 /APPEND
```

And, finally, the demo for OTFMAP with FREQUENCY SWITCHING:

```
!
! Id: demo-otfmap-swfrequency.pako
!   OTFMAP SWFREQUENCY EXAMPLE,v 1.1.11 2011-11-25 Hans Ungerechts
!
@ demo-rx                                ! demo setup of receivers
!
BACKEND /CLEAR                            ! clear previous backends
BACKEND VESPA 1 0.040 40.0 0.0 E090 hor LI ! high spectral resolution
BACKEND VESPA 2 0.040 40.0 0.0 E090 ver LI ! with VESPA
BACKEND VESPA 3 0.080 80.0 0.0 E230 hor LI
BACKEND VESPA 4 0.080 80.0 0.0 E230 ver LI
!                                         ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec                          !
!
!                                         ! setup frequency switching
SWFREQUENCY  -3.9      3.9 /receiver E090 ! for EMIR band E090
SWFREQUENCY -11.7     11.7 /receiver E230 ! for EMIR band E230
SWFREQUENCY                               /tphase  0.20 ! same for all receivers/bands
!
CALIBRATE - !
  /AMBIENT - ! ambient load
  /COLD    - ! cold load
  /SKY     -600.0 0.0 - ! sky at offsets -600.0 0.0
  /SYSTEM  projection - ! system for offset
  /TCALIBRATE 5.0      ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]"      ! a chance to check
!
START                                     ! start
!
OTFMAP  -300 -300 300 -300 - ! offsets at start and end of first OTF
  /CROLOOP 0 - ! only OTF subscans
  /NOTF 4 - ! number of on-the-fly subscans
  /REFERENCE no - ! no off-source reference subscans
  /STEP 0 10 - ! step (shift) between OTF subscans
  /SYSTEM projection - ! system for offset
  /TOTF 120.0 - ! time per on-the-fly subscan
  /ZIGZAG - ! go back and forth
!
PAUSE "OTFMAP SWFREQUENCY OK to start? [c/q]" ! a chance to check
!
START                                     ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source
```

5.3.10 RASTER (Raster Mapping)

RASTER may be implemented in a future revision of the NCS.

It is recommended to use ON-OFF instead.

5.4 Continuum Observations with Bolometers

NOTES.

This subsection is preliminary.

Most bolometer observations are done in the bolometer observing pool, which has its own special instructions. Observers in the bolometer pool should follow these special instructions.

NOTE (2011-07-14): the MAMBO bolometers are out of operation.

5.4.1 Setup of the Bolometer

```
!
! Id: demo-bolometer.pako, 0.9 2005-09-07 by Hans Ungerechts
!
RECEIVER      /CLEAR                ! completely clear receiver setup
RECEIVER BOLOMETER MAMBO2 1 55      ! gainBolometer = 1; channel = 55
!
BACKEND       /DISCONNECT           ! disconnect all backends previously set
!                                       ! (bolometer does not need spec of a backend)
!
```

To execute this script, simply enter:

```
@ demo-bolometer
```

The setup command for a bolometer has only 3 parameters: a name (identifier) for each bolometer; the bolometer gain, a numerical factor; and a number to select one specific bolometer channel (pixel) that will be centered on the selected source for POINTING, FOCUS, and ONOFF.

5.4.2 Switching Mode

Always specify a Switching Mode before an Observing Mode.

Bolometer observation normally use WOBBLER SWITCHING for almost all observations; however, TIP must be done with TOTAL POWER.

The corresponding commands are:

```
SWTOTAL
SWWOBLER
```

The following examples for doing observations contain the specification of an appropriate Switching Mode as well as the Observing Mode.

For more details on Switching Modes see Section “NCS Explained”, subsection “Switching Modes”.

5.4.3 POINTING

```
!
! Id: demo-bolometer-pointing.pako,v 0.2 2005-07-14 by Hans Ungerechts
!
RECEIVER BOLOMETER
!
SWWOBLER -22 22 /TPHASE 0.5        ! select Wobbler switching
!
```

```

SET ANGLEUNIT arcsec          ! make sure angle unit is arc sec
!
POINTING      60              - ! pointing with subscan length 60
  /CALIBRATE no              - ! no calibration
  /NOTF       4               - ! 4 OTF subscans
  /TOTF      15.0            ! 15 seconds per OTF subscan
!
PAUSE "POINTING OK to start? [c/q]"  ! a chance to check
!
START          ! start
!
RETURN
!
```

To execute this script, simply enter:

```
@ demo-bolometer-pointing
```

POINTING observations are done to optimize the positioning of the telescope in Azimuth and Elevation. This is normally done by continuum observations of a cross scan in azimuth and elevation on a point source (or at least a small source) near the intended target source.

It is normally used with BEAM SWITCHING or WOBBLER SWITCHING; it is also possible with TOTAL POWER. (With the bolometer POINTING is done with WOBBLER SWITCHING).

A calibration is not needed for POINTING, if one is only interested in the pointing corrections, and not in the source intensity.

After a pointing the data processing software displays the results and you can enter a correction for the observed pointing offsets with the command

```
SET POINTING azimuthCorrection elevationCorrection
```

Note that this is the total correction, i.e., the previous correction plus the additional offset found with the POINTING observation.

After you enter a pointing setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE POINTING [/FILE pointing-1]
```

It can then at any later time be reloaded with @ pointing[-1], see HELP SAVE.

5.4.4 FOCUS

```

!
! Id: demo-bolometer-focus.pako,v 0.2 2005-07-14 by Hans Ungerechts
!
RECEIVER BOLOMETER
!
SWWOBBLER -22 22 /TPHASE 0.5          ! select Wobbler switching
!
FOCUS          1.0                  - ! length [mm]
  /NSUBSCANS   6                    - ! number of subscans
  /TSUBSCAN    12                   ! time per subscan
!
PAUSE "FOCUS OK to start? [c/q]"      ! a chance to check
!
START          ! start
!
```

To execute this script, simply enter:

```
@ demo-bolometer-focus
```

FOCUS measurements are done to optimize the position of the subreflector (secondary) along the telescope axis by maximizing the intensity of the radiation focussed into the receiver(s). It is best done on a strong point source, e.g., on a planet if or when its angular diameter is less than the beam width at the frequency to be observed. It is strongly recommended to do a POINTING on the same source before a FOCUS.

FOCUS is normally used with BEAM SWITCHING or WOBBLER SWITCHING. (With the bolometer FOCUS is done with WOBBLER SWITCHING).

A calibration is not needed for FOCUS, anyhow it will probably already have been done before the POINTING before the FOCUS!

After a focus the data processing software displays the results and you can enter a correction for the observed focus offset with the command

```
SET FOCUS focusCorrection
```

Note that this is the total correction, i.e., the previous correction plus the additional offset found with the FOCUS observation.

The optional focus correction for different receiver bands may be slightly different, by a few times 0.1 mm, and the observer can decide to optimize for one particular band or use a compromise value.

After you enter a focus setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE FOCUS [/FILE focus-1]
```

It can then at any later time be reloaded with @ focus[-1], see HELP SAVE.

5.4.5 TIP (Antenna Tipping or “Skydip”)

```
!
! Id: demo-bolometer-tip.pako,v 0.2 2005-07-14 by Hans Ungerechts
!
RECEIVER  BOLOMETER
!
SWTOTAL   /TPHASE 0.5                ! select Total Power (IMPORTANT!)
!
TIP    180                          - ! tip at azimuth 180 [deg]
      /AIRMASS  1.1 4.1 0.6          - ! air mass: from - to - by (step)
      /TSUBSCAN 12.0                ! time per subscan [s]
!
PAUSE "TIP OK to start? [c/q]"      ! a chance to check
!
START                                         ! start
!
```

To execute this script, simply enter:

```
@ demo-bolometer-tip
```

TIP (antenna tipping or “skydip”) observations are done to measure the transmission of the Earth’s atmosphere, by taking data at several points with the same azimuth but different elevations, spaced by equal steps in “air mass”.

It is ESSENTIAL that the switching mode is TOTAL POWER during TIP.

This is in particular an important step in the calibration of observations with the bolometer.

The basic parameters of this observing mode and its options are: the azimuth, the range and step in airmass, and the time per subscan.

5.4.6 ON-OFF (Wobbler Switching)

```
!
! Id: demo-bolometer-onoff.pako,v 0.2 2005-07-14 by Hans Ungerechts
```

```

!
RECEIVER BOLOMETER
!
SWWOBLER      -33.0    33.0      - ! Wobbler +/- 33 arc sec
  /TPHASE      0.5              ! 0.5 seconds per phase
!
SET ANGLEUNIT arcsec          ! make sure angle unit is arc sec
!
ONOFF  /SWWOBLER             - ! ONOFF for Wobbler switching
  /NSUBSCANS  16             - ! number of subscans
  /TSUBSCAN   16             ! time per subscan
!
PAUSE "ONOFF OK to start? [c/q]" ! a chance to check
!
START          ! start
!

```

To execute this script, simply enter:

```
@ demo-bolometer-onoff
```

For bolometer observations, ONOFF is used with WOBBLER SWITCHING (command SWWOBLER).

When ONOFF is used with WOBBLER SWITCHING (command SWWOBLER), the position offsets must be set to very specific values in TRUE (ANGLE) HORIZON depending on the parameters of SWWOBLER. This is achieved by using the special option /SWWOBLER of the command ONOFF.

Subscans are then taken alternating between 2 positions in such a way that: (a) in some subscans (one position of the antenna) the source is in the first of the two Wobbler phases, (b) in the other subscans (the other position of the antenna) the source is in the second of the two Wobbler phases. During the data processing, the source signal is computed as a double difference: 1st the difference of the 2 Wobbler phases; 2nd the difference between ONOFF subscans (a) and (b).

This form of ONOFF is also called “Wobbler-Onoff” or sometimes simply “Wobbler Switching”.

The combination(!) of ONOFF and WOBBLER SWITCHING provides a very high sensitivity in continuum bolometer observations of compact sources, and excellent baselines for spectroscopy.

It has the disadvantage that the (emission-free?) off-source positions are very close to the source (limited by the maximum Wobbler throw). Also, the Wobbler direction is fixed in the horizontal system relative to the telescope, and therefore in the source system the off-source positions rotate around the source position.

For continuum observations, usually a short time per Wobbler phase, 0.25 s, is used with small Wobbler offsets (throws); for spectroscopy, largest possible Wobbler offsets (throws), up to $\pm 120''$ are preferred, but then the time per phase must be longer, 1 – 2 s.

5.4.7 OTF (On-The-Fly Mapping with Wobbler Switching)

```

!
! Id: demo-bolometer-onoff.pako,v 0.2 2005-07-14 by Hans Ungerechts
!
RECEIVER BOLOMETER
!
SWWOBLER      -33.0    33.0      - ! Wobbler +/- 33 arc sec
  /TPHASE      0.5              ! 0.5 seconds per phase
!
SET ANGLEUNIT arcsec          ! make sure angle unit is arc sec
!
OTFMAP        -200  -100  200  -100 - ! start and end of first on-the-fly subscan
  /NOTF        60                - ! number of on-the-fly subscans

```

```

/REFERENCE    no                - ! no off-source reference subscans
/STEP        0      6          - ! step (shift) between OTF subscans
/SYSTEM      truehorizon      - ! system for offset: "true" horizon offsets
/TOTF       66.0              - ! time per on-the-fly subscan [s]
/ZIGZAG                        ! go back and forth
!
PAUSE "OTFMAP OK to start? [c/q]"  ! a chance to check
!
START        ! start
!
```

To execute this script, simply enter:

```
@ demo-bolometer-otfmap
```

For bolometer observations, OTFMAP is used with WOBBLER SWITCHING (command SWWOBBLER).

In OTFMAP (on-the-fly) observations, the antenna moves relative to the source while recording its position and taking data a high rate. This is a very fast mode for mapping extended regions.

The basic parameters of the command are the position offsets of the start and end of the first OTF subscan; the basic parameters of the options are: the number OTF subscans, the step (shift) in x- and y-offsets between subsequent OTF subscans, the time per OTF subscan in [s].

This mode is normally used with WOBBLER SWITCHING and the "true horizon" system for continuum mapping with the bolometer.

6 NCS Explained

In this section we explain in more detail some general aspects of the NCS.

6.1 Coordinate Systems, Map Projections, and Position Offsets

The NCS will support a variety of astronomical coordinate systems and projections, as well as “descriptive” coordinate systems defined by the user. Up to now, 2012-12-01, only equatorial coordinates, J2000.0, are well tested and available for use.

Map Projections and Offsets. In general, a “map projection” describes the relation between 2 spherical coordinates, longitude l and latitude b ,⁵ on the celestial sphere, and 2 Cartesian coordinates x and y , which in radio astronomy and the NCS we often call “position offsets”.

Up to now, 2012-12-01, only the “**radio**” projection is supported, for which:

$$x = (l - l_{source}) * \cos(b)$$

$$y = b - b_{source}$$

where l_{source} and b_{source} are the source coordinates specified with **SOURCE**.⁶ Note that this is the same system of offsets as in “OBS” of the old control system.

If we want to observe several positions on the sky at or near the source position as specified with **SOURCE**, we often do this by requesting position offsets in the map projection. Also, the resulting data, e. g., images, are usually stored and displayed as a function of x and y .

For most observations, parameters and options of the observing mode are sufficient to specify the position offsets:

- for **TRACK** and **VLBI** x and y are fixed during the complete scan;
- for **ONOFF** x and y change from subscan to subscan;
- for **OTFMAP** x and y change continuously or “on-the-fly” (OTF) during the OTF subscans.

The **PAKO** commands for most Observing Modes expect fixed offsets (or start- and end-offsets for **OTFMAP**) as parameters. These can be either in the radio projection, specified with the option:

`/SYSTEM projection`

or in the true angle horizon system (see below), specified with the option:

`/SYSTEM trueHorizon`

NOTES. For **POINTING**, the OTF offsets are always in system `trueHorizon`, and are specified implicitly though the angular length of the subscans.

Global Offsets. On the other hand, the command **OFFSETS** can be used to specify additional position offsets in other systems. These globally defined offsets stay fixed during a complete scan. *They are only needed in special cases, e. g., the Nasmyth offsets or for ONOFF with wobbler switching*, see below.

At this time (2012-12-01), the command **OFFSETS** supports offsets in the following 3 systems:

projection Offsets in the “radio” projection (see above).

trueHorizon “true angle horizon” offsets in Azimuth and Elevation:

$$\Delta a = (a - a_{source}) * \cos(e)$$

$$\Delta e = e - e_{source}$$

where a and e are the Azimuth and Elevation of the telescope; a_{source} and e_{source} are the Azimuth and Elevation of the source, calculated from l and b (and the time and other parameters).

⁵ In particular for equatorial coordinates, l corresponds to Right Ascension and b to Declination.

⁶ For the equations all angles are assumed to be in radian.

Nasmyth offsets in the Nasmyth (receiver cabin) system. The purpose of Nasmyth offsets is exclusively to re-position the telescope so that an off-center element of a multibeam receiver looks at the position where otherwise the center pixel would look. E. g., `OFFSETS -33 44 /SYSTEM Nasmyth` adds offsets -33 and 44 in the Nasmyth system (for all observing modes!)

Example 1 Observe a single position with offsets 10 and 20 in system radio projection; typically used with `FREQUENCY SWITCHING`:

```
TRACK 10 20 /SYSTEM projection
```

Example 2 Observe `ONOFF` (“position switching” with `TOTAL POWER`) with `ON` position at 30 40 and off-source reference at -600 -700, both in system radio projection:

```
ONOFF 30 40 /REFERENCE -600 -700 projection /SYSTEM projection
```

Example 3 Pointing with subscans of length 120:

```
POINTING 120
```

NOTES. For `POINTING`, the `OTF` offsets are always in system `trueHorizon`, and are specified implicitly through the angular length of the subscans.

Example 4 `ONOFF` observations with `WOBBLER SWITCHING` are a special case, because the offsets for the subscans must be in system `trueHorizon` and their values must be selected according to the offsets of the `WOBBLER SWITCHING`! E. g.,

```
SWOBBLER -33 +33
ONOFF 33 0 /REFERENCE -33 0 trueHorizon /SYSTEM trueHorizon
```

This can also be achieved simply by saying

```
SWOBBLER -33
ONOFF
```

`PAKO` “knows” the special requirements for `onoff` wobbler switching, and will set the offset parameters for `ONOFF` accordingly, if `SWOBBLER` has been previously selected. ⁷

In this special case, in order to map the source, the observer may add offsets on the source l and b using the command `OFFSETS` with the system “projection”, e. g.:

```
SWOBBLER -33
OFFSETS 110 120 /SYSTEM projection
ONOFF
```

Example (i) Observe an `OTF` map with first `OTF` subscan from offsets -300 -300 to +300 -300, and off-source reference at -600 -700, all in system radio projection:

```
OTFMAP -300 -300 300 -300 /REFERENCE -600 -700 projection /SYSTEM projection
```

⁷ For special purposes, it is possible to overrule this with `/swWobbler no`, e. g., `ONOFF 44 /swWobbler no`.

Example (ii) Observe an OTF map with first OTF subscan from offsets $-300 -300$ to $+300 -300$, in system trueHorizon (and no off-source reference) This is typical for bolometer OTF maps:

```
OTFMAP -300 -300 300 -300 /REFERENCE no /SYSTEM trueHorizon
```

NOTES. Visiting observers have also used ONOFF in trueHorizon combined with OFFSETS ... /SYSTEM projection with TOTAL POWER, apparently with success.

NOTES.

- one should not specify offsets for the same system with the observing mode and OFFSETS (and there is not need to do this!).
 - If the observing mode uses /SYSTEM projection, OFFSETS ... /SYSTEM projection is ignored (not used).
 - If the observing mode uses /SYSTEM trueHorizon, OFFSETS ... /SYSTEM trueHorizon is ignored (not used).
- in the commands for the observing modes, the offsets for off-source reference positions must be in the same system as those of the on-source or OTF positions, i.e., /REFERENCE ... and /SYSTEM must select the same system (normally, PROJECTION).

Details at a technical level about these and more offsets can be found in the documentation of “NCS Antenna Mount Drive” by Alain Perrigouard.

NOTES. More explanations about coordinate systems, projections, and how to define descriptive coordinate systems will be added as they become available for general use.

NOTES. *SOURCE does not clear offsets set with OFFSETS.*

6.2 Azimuth Topology

The 30m antenna has azimuth limits of 60 and 460 degrees. Azimuth 360 degrees is due North. Therefore there is an overlap range approximately toward East-Northeast, which the antenna can reach at a low azimuth 60 to 100 (from the South) or at a high azimuth 420 to 460 (from the North).

SET TOPOLOGY LOW selects to use the azimuth range 60 to 420 degrees.

SET TOPOLOGY HIGH selects to use the azimuth range 100 to 460 degrees.

Note that SET TOPOLOGY only has an effect for sources with an azimuth in the overlap range; when a source is in the azimuth range 100 to 420 degrees SET TOPOLOGY does not matter.

Compare Figure 4.

6.3 Switching Modes

In the NCS we distinguish the following 4 “Switching Modes”:

TOTAL POWER

BEAM SWITCHING

WOBBLER SWITCHING

FREQUENCY SWITCHING (only with heterodyne receivers)

The corresponding commands are:

SWTOTAL

SWBEAM

SWWOBBLER

SWFREQUENCY

BEAM SWITCHING, WOBBLER SWITCHING, and FREQUENCY SWITCHING are realized by a system with hardware synchronization signals that allow a precise and fast switching *within* subscans.

TOTAL POWER simply means that none of the other 3 switching modes is active.

The system switches through a regular cycle with several (1, 2, or 4) switching phases.




Figure 4: Azimuth Topology. The left side shows in blue the range for SET TOPOLOGY LOW, the right side shows in red the range for SET TOPOLOGY HIGH. (Compare Section 6.2; figure prepared by Joaquín Santiago)

The 4 switching modes are mutually exclusive, i.e., at any time the system uses only one of them.

During the transitions between phases, e.g., while the Wobbler is moving between its positions, no data are taken during the short “blanking” time.

The switching mode and its parameters should normally be set before choosing an observing mode, because for some observing modes details of the setup depend on the switching mode.

```

!
! Id: demo-switching.pako,v 1.1.1 2009-05-05 Hans Ungerechts
!
SWTOTAL                /tphase 0.2    ! Total Power
PAUSE
!
SWBEAM                 ! Beam Switching
PAUSE
!
SWFREQUENCY            /default      ! Frequency Switching
PAUSE
!
SWFREQUENCY  -3.3      3.3          ! for all RXs
PAUSE
!
SWFREQUENCY  -3.9      3.9 /receiver E090 ! select frequency switching
SWFREQUENCY  -11.7     11.7 /receiver E230 ! for EMIR band E230
SWFREQUENCY                /tphase  0.20 ! same for all receivers
PAUSE
!
SWWOBLER  -22  +22      /tphase 0.25 ! Wobbler Switching

```

PAUSE

!

!! NOTE:

!! after changing the switching modes, always (re-)execute a command

!! for an observing mode, because internal parameters and error checks

!! of the observing modes depend on the switching mode!

6.3.1 Beam Switching

BEAM SWITCHING is realized through a rotating chopper wheel in the receiver cabin, which during each rotation (= switching cycle) moves 2 reflecting (!) blades into the beam path in front of the 4th mirror, for a total of 4 phases: direct beam path to the source (same as in TOTAL POWER!), beam path offset by one blade of the chopper wheel, direct beam path to the source (same as in TOTAL POWER!), beam path offset by the other blade of the chopper wheel. The offset, rotation period, and blanking times are fixed. BEAM SWITCHING is normally only used for POINTING and FOCUS.

The source signal is calculated as difference between the direct and offset phases.

(NOTES. This “beam-switching” chopper wheel, should not be confused with a “calibration chopper wheel” as it is used at some other mm-wave observatories. Calibration at the 30-M Telescope is done with different hardware.)

6.3.2 Frequency Switching

FREQUENCY SWITCHING switches between 2 different frequencies, so that there are 2 phases. The (source) signal is calculated as the difference between these 2 phases.

FREQUENCY SWITCHING is normally used with TRACK or OTFMAP.

NOTES. IMPORTANT:

FREQUENCY SWITCHING *is very powerful and efficient for some projects, e. g., mapping of narrow spectral lines in cold dark clouds outside the plane of the Milky Way. However, before deciding to use frequency switching one should consider some potential drawbacks:*

The target lines should be narrow enough so that line signals from the 2 phases of the switching cycle are well separated.

The spectral baseline will generally be less flat than in other switching modes.

Some spectral lines are also emitted in the earth’s mesosphere, e.g., the mesospheric lines from (12)CO are rather strong, and they will be seen in FREQUENCY SWITCHING spectra taken toward astronomical sources with a low Doppler shift. The mesospheric lines will appear at a frequency and velocity that corresponds to the rest frame of the atmosphere, i. e., the observatory. Care must be taken that they are not confused with the lines from the astronomical source. (Information computed by the ASTRO software can help with this decision).

When observing sources near the plane of the Milky Way, line emission from clouds at other velocities than the target source, e. g., other spiral arms, can cause confusion.

In case of doubt, consult the special memo on FREQUENCY SWITCHING or ask an experienced FREQUENCY SWITCHING observer!

6.3.3 Wobbler Switching

During WOBBLER SWITCHING the wobbling secondary mirror is switched between 2 positions, which are offset from the telescope axis by \pm a fixed amount.

Thus there are 2 phases, and the signal is calculated as the difference between these 2 phases.

As the positions in both phases are offset from the telescope axis, in some observing modes, e.g, POINTING, FOCUS, ONOFF, the telescope position needs to be adjusted to compensate — this is done automatically.

WOBBLER SWITCHING is normally used with ONOFF or, for bolometer continuum mapping, with OTFMAP.

Note that for OTFMAP with WOBBLER SWITCHING, special restoration algorithms are needed to recover an image of the source brightness distribution. These are available, e. g., in the MOPSIC software.

If WOBBLER SWITCHING and ONOFF are combined in the standard way, we effectively take data at 3 positions: 1. the source position; 2. the `source position + throw` (offset in the “true-angle” horizontal system); 3. the `source position - throw` (offset in the “true-angle” horizontal system), with `throw = ABS(wOffset2-wOffset1)`. Data from 1. are treated as source signal, data from 2. and 3. as off-source reference signal. Note that in the astronomical coordinates, positions 2. and 3. will rotate around the source position 1. Therefore one must normally be sure that the extent of the source is less than `throw-beamWidth (/2)`.

6.3.4 Total Power

TOTAL POWER refers simply to data acquisition without any of the other 3 fast Switching Modes. (Even in this case the same type of hardware synchronization signals is used to control the regular readout of the backends. In this case there is only one switching phase.)

Normally, when using TOTAL POWER one or several positions “ON” the source are observed alternating with one or several “OFF”-source reference positions, and the signal is calculated as the difference between “ON” and “OFF”.

6.4 Observing Modes

The NCS supports the following “Observing Modes”: CALIBRATE, POINTING, FOCUS, TIP, ONOFF, OTFMAP, <<TBD:RASTER not yet implemented >>, TRACK, VLBI.

All Observing Modes are realized by executing a sequence of 1 or more subscans. In most cases, the antenna moves between or during the subscans.

The observing modes are mutually exclusive, i.e., at any time the system executes only one of them.

Several Observing Modes can be combined with different Switching Modes, e.g., OTFMAP with TOTAL POWER, WOBBLER SWITCHING (for bolometer), or FREQUENCY SWITCHING. The Switching Mode should normally be specified before the Observing Mode.

6.4.1 CALIBRATE

In a standard calibration for heterodyne receivers, we observe 3 subscans, “SAC”: on a Sky position, an Ambient temperature load (a.k.a., “hot” load), and a “Cold” load. Calibrations are always and automatically done in TOTAL POWER.

A calibration needs to be done for any heterodyne observation in order to get data with a calibrated intensity scale. It is normally done before the target observations. It must always be done after changing receiver and/or backend setups. It should also be done when changing sources and often enough to follow any variation of the atmosphere, about every 15 minutes.

After you enter a calibrate setup manually, we recommend to “save” it, optionally to a named file:
`SAVE CALIBRATE [/FILE calibrate-1]`

It can then at any later time be reloaded with `@ calibrate[-1]`, see `HELP SAVE`.

The special calibration subscans are done by switching the beam optics so that the receivers see a special calibration unit in the receiver cabin.

6.4.2 POINTING

POINTING observations are done to optimize the positioning of the telescope in Azimuth and Elevation. This is normally done by continuum observations of a cross scan in azimuth and elevation on a point source (or at least a small source) near the intended target source.

It is normally used with BEAM SWITCHING or WOBBLER SWITCHING; it is also possible with TOTAL POWER. (With the bolometer POINTING is done with WOBBLER SWITCHING).

A calibration is not needed for POINTING, if one is only interested in the pointing corrections, and not in the source intensity.

After a pointing the data processing software displays the results and you can enter a correction for the observed pointing offsets with the command

```
SET POINTING azimuthCorrection elevationCorrection
```

Note that this is the total correction, i.e., the previous correction plus the additional offset found with the POINTING observation.

After you enter a pointing setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE POINTING [/FILE pointing-1]
```

It can then at any later time be reloaded with @ pointing[-1], see HELP SAVE.

6.4.3 FOCUS

FOCUS measurements are done to optimize the position of the subreflector (secondary) along the telescope axis by maximizing the intensity of the radiation focussed into the receiver(s). It is best done on a strong point source, e.g., on a planet if or when its angular diameter is less than the beam width at the frequency to be observed. It is strongly recommended to do a POINTING on the same source before a FOCUS.

FOCUS is normally used with BEAM SWITCHING or WOBBLER SWITCHING. (With the bolometer FOCUS is done with WOBBLER SWITCHING).

A calibration is not needed for FOCUS, anyhow it will probably already have been done before the POINTING before the FOCUS!

After a focus the data processing software displays the results and you can enter a correction for the observed focus offset with the command

```
SET FOCUS focusCorrection
```

Note that this is the total correction, i.e., the previous correction plus the additional offset found with the FOCUS observation.

The optimal focus correction for different receiver bands may be slightly different, by a few times 0.1 mm, and the observer can decide to optimize for one particular band or use a compromise value.

After you enter a focus setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE FOCUS [/FILE focus-1]
```

It can then at any later time be reloaded with @ focus[-1], see HELP SAVE.

6.4.4 TIP

TIP (antenna tipping or “skydip”) observations are done to measure the transmission of the Earth’s atmosphere, by taking data at several points with the same azimuth but different elevations, spaced by equal steps in “air mass”.

It is ESSENTIAL that the switching mode is TOTAL POWER during TIP.

This is in particular an important step in the calibration of observations with the bolometer.

The basic parameters of this observing mode and its options are: the azimuth, the range and step in airmass, and the time per subscan.

6.4.5 ONOFF

In its first form ONOFF is used with TOTAL POWER. Subscans are taken alternating between a position that’s considered to be “ON-source” and a reference position that’s normally assumed to be “OFF-source”, i.e., free of emission.

The source signal is then calculated as the difference between “ON” and “OFF”.

The basic parameters are the offsets for the ON position, parameters of the options are the offsets for the reference position, the (total) number of subscans, and the time per subscan in [s].

After you enter an ON-OFF setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE ONOFF [/FILE onoff-1]
```

It can then at any later time be reloaded with @ onoff[-1], see HELP SAVE.

You may want to save the switching mode separately or with ONOFF into the same file:

```
SAVE SWITCHING /FILE onoff-2
SAVE ONOFF      /FILE onoff-2 /APPEND
```

When **ONOFF** is used with **WOBBLER SWITCHING** (command **SWOBBLER**), the position offsets must be set to very specific values in **TRUE (ANGLE) HORIZON** depending on the parameters of **SWOBBLER**. This is achieved by using the special option **/SWOBBLER** of the command **ONOFF**.

Subscans are then taken alternating between 2 positions in such a way that: (*a*) in some subscans (one position of the antenna) the source is in the first of the two Wobbler phases, (*b*) in the other subscans (the other position of the antenna) the source is in the second of the two Wobbler phases. During the data processing, the source signal is computed as a double difference: 1st the difference of the 2 Wobbler phases; 2nd the difference between **ONOFF** subscans (*a*) and (*b*).

This form of **ONOFF** is also called “Wobbler-Onoff” or sometimes simply “Wobbler Switching”.

The combination(!) of **ONOFF** and **WOBBLER SWITCHING** provides a very high sensitivity in continuum bolometer observations of compact sources, and excellent baselines for spectroscopy.

It has the disadvantage that the (emission-free?) off-source positions are very close to the source (limited by the maximum Wobbler throw). Also, the Wobbler direction is fixed in the horizontal system relative to the telescope, and therefore in the source system the off-source positions rotate around the source position.

For continuum observations, usually a short time per Wobbler phase, 0.25 s, is used with small Wobbler offsets (throws); for spectroscopy, largest possible Wobbler offsets (throws), up to $\pm 120''$ are preferred, but then the time per phase must be longer, 1 – 2 s.

6.4.6 OTFMAP

In **OTFMAP** (on-the-fly) observations, the antenna moves relative to the source while recording its position and taking data a high rate, thus performing “scans” in the strict sense of the word. This is a very fast mode for mapping.

The basic parameters of the command are the position offsets of the start and end of the first OTF subscan; the basic parameters of the options are: the number of OTF subscans, the offsets of an off-source reference position, the step (shift) in x- and y-offsets between subsequent OTF subscans, the time per OTF subscan in [s], and the time per off-source reference subscan [s].

This observing mode is normally used either with:

- (i) **TOTAL POWER** with an off-source reference for spectral line observations, or
- (ii) **FREQUENCY SWITCHING** without off-source reference for spectral line observations (see below), or
- (iii) **WOBBLER SWITCHING** and **TRUE (ANGLE) HORIZON** offsets for continuum mapping with the bolometer.

After you enter an OTF-map setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE OTFMAP [/FILE otfmap-1]
```

It can then at any later time be reloaded with **@ otfmap[-1]**, see **HELP SAVE**.

You may want to save the switching mode separately or with **OTFMAP** into the same file:

```
SAVE SWITCHING /FILE otfmap-2
SAVE OTFMAP     /FILE otfmap-2 /APPEND
```

6.4.7 RASTER

<< **RASTER** (not yet implemented), will be similar to **ONOFF** and **TRACK** but allow to observe several “ON” positions. To be used with **TOTAL POWER** or (maybe) **FREQUENCY SWITCHING**. In any case it is recommended to use **ONOFF** instead of **RASTER** with several ON per OFF. >>

6.4.8 TRACK

The **TRACK** observing mode simply tracks one position relative to the source. It is normally used with **FREQUENCY SWITCHING** and offsets in **/SYSTEM projection**.

The basic parameters are the offsets for the position to track; parameters of the options are the (total) number of subscans, and the time per subscan in [s].

After you enter a track setup manually, we recommend to “save” it, optionally to a named file:

```
SAVE TRACK [/FILE track-1]
```

It can then at any later time be reloaded with @ track[-1], see `HELP SAVE`.

You may want to save the switching mode separately or with TRACK into the same file:

```
SAVE SWITCHING /FILE track-2  
SAVE TRACK      /FILE track-2 /APPEND
```

6.4.9 VLBI

VLBI, a special observing mode to track the source position specified with SOURCE during VLBI scans. It should only be used for VLBI and is always used with TOTAL POWER.

6.5 Receivers

This section remains to be written. For the time being please refer to the information available on the web pages about the 30-M Telescope.

6.6 Backends

This section remains to be written. For the time being please refer to the information available on the web pages about the 30-M Telescope.

7 PAKO Language Internal Help

From here follows a reproduction of the Internal Help available in paKo with `HELP PAKO`. Please consult the internal help itself, which may be more up to date than an old printout of the user's manual.

NOTES.

<< and << TBD mark items that are foreseen in the NCS but that are not yet available.

7.1 Language

SUMMARY OF PAKO\ COMMANDS v1.1.14

NEW in 1.1.14:

```
RECEIVER BOLOMETER NIKA          ! Receiver (bolometer) NIKA

SUBSCAN xOffset yOffset /TUNE          ! for NIKA
DIY                                /PURPOSE "play my Tune" ! for NIKA
```

Examples how to use HELP:

```
for detailed HELP on a command:  HELP OTFMAP
                                HELP OTFM
one subtopic or option:          HELP OTFMAP /NOTF
examples:                        HELP OTFMAP EXAMPLES
all subtopics and options:       HELP OTFMAP *
options in general:              HELP OPTIONS
news about paKo:                 HELP PAKO\ NEWS
```

```
NOTE:  <<TBD    ... >>   (To BE DONE) or
        <<      ... >>   flag items that are planned for the NCS, but
                                not yet implemented or propely tested.
                                Observers should not try to use these features
                                without consulting the NCS team.
```

```
    setup:
SET & SHOW          set general parameters (project, observer, ...)
CATALOG             select source or line catalogs
SOURCE             specify a source
OFFSETS            specify source offsets
RECEIVER           set up receivers
BACKEND            set up backends
```

```
    switching modes (select 1)
SWBEAM             select and set up beam switching
SWFREQUENCY        select and set up frequency switching
SWTOTAL           select total power (no switching)
SWWOBBLER          select and set up wobbler switching
```

```
    observing modes (select 1)
CALIBRATE          specify a calibration
FOCUS              specify a focus measurement
POINTING           specify a pointing measurement
TIP                specify an antenna tipping (a.k.a., "skydip")
TRACK              specify tracking of a single position, e.g., with SWFRE
ONOFF              specify on-off (a.k.a., "position switching")
OTFMAP             specify an On-The-Fly (OTF) map
LISSAJOUS          specify an On-The-Fly map along a Lissajous curve
VLBI               specify tracking of a single position for VLBI
```

```

start:
START          start an observation, i.e., send it to the queue

save:
SAVE           save parameters to file, i.e., a .pako script

```

7.1.1 Language NEWS

```

paKo, v1.1.14 (2012-14)
=====

```

```

NEW in 1.1.14:

```

```

RECEIVER BOLOMETER NIKA          ! Receiver (bolometer) NIKA

SUBSCAN xOffset yOffset /TUNE          ! for NIKA
DIY                               /PURPOSE "play my Tune" ! for NIKA

```

```

NEW in 1.1.12:
=====

```

```

RECEIVER BOLOMETER GISMO      ! Receiver (bolometer) GISMO

LISSAJOUS                     ! Observing Mode Lissajous for GISMO, i.e.,
                              ! an On-The-Fly map along a Lissajous curve

```

```

UPDATED in 1.1.11:
=====

```

```

RECEIVER EMIR                 ! Receiver EMIR, upgrade of E230 and E330
BACKEND FTS                   ! Fourier Transform Spectrometer
BACKEND BBC                   ! Broad Band Continuum Backend

SET      EMIRcheck            ! limit checking for EMIR
SET      UserLevel            !

```

```

paKo, v1.1.6
=====

```

```

UPDATED in v1.1.6:

```

```

BACKEND FTS                   ! Fourier Transform Spectrometer

```

```

paKo, v1.1.5
=====

```

NEW in v1.1.5:

BACKEND BBC ! Broad Band Continuum Backend
 BACKEND NBC ! Narrow Band Continuum Backend

paKo, v1.1.4
 =====

NEW in v1.1.4:

BACKEND FTS ! Fourier Transform Spectrometer
 SET EMIRCheck ! "strict"|"relaxed"|"loose"

paKo, v1.1.1
 =====

NEW in v1.1.1: SUPPORT FOR EMIR

--> major changes in

CALIBRATE
 BACKEND
 RECEIVER

paKo, v1.0.9.4
 =====

modifications of some commands FOR MAMBO BOLOMETER OBSERVATIONS, see:

OFFSETS ... /SYSTEM NASMYTH
 OFFSETS ... /SYSTEM NASMYTH /CLEAR
 TIP ... /TPADDLE
 TIP ... /SLEW

paKo, v1.0.9
 =====

paKo, v1.0.8
 =====

100 kHz Filterbank is decommissioned (RM, 12.9.2007)

paKo, v1.0.7
 =====

IMPORTANT CHANGE: NEW LOGIC FOR RECEIVER /TEMPLOAD L L
 for details, see:
 HELP RECEIVER /TEMPLOAD

paKo, v1.0.6.3
 =====

GENERAL:

paKo Lock There is a new lock file mechanism to prevent that
2 instances of pako run in the same working directory

Sequence of Commands It is now enforced for the purpose of consistency che
"scan analysis", i.e., for the translation to subsan

 BACKEND must be specified after RECEIVER.
 Observing Mode must be specified after Switching Mode
 Observing Mode must be specified after SET 2ndRotatio
 ONOFF must be specified after OFFSETS.

 START will not work without SOURCE, RECEIVER, and BAC

Checks There are various stricter limit checks and more cons
checks.

NEW COMMANDS:

SET 2ndRotation set rotation angle for secondary mirror
and Wobbling mechamism. This is ONLY for Bolometer
with Wobbler Switching and POINTING, FOCUS,
and OTFMAP.

SHOW now also shows the pako version (revision number and
and the 2ndRotation.

NOTE the character / is NOT allowed in source names
to avoid confusion with SIC "options" like /VELOCITY

NEW OPTIONS:

POINTING /DOUBLEBEAM "double-beam pointing"
only for Bolometer and Wobbler switching
with 2ndRotation angle = 0.0

NOTE: <<TBD ... >> (To BE DONE) or
 << ... >> flag items that are planned for the NCS, but
 not yet implemented or properly tested.
 Observers should not try to use these features
 without consulting the NCS team.

7.1.2 Language HELP

Examples how to use HELP:

for detailed HELP on a command: HELP OTFMAP
 HELP OTFM

```

one subtopic or option:      HELP OTFMAP /NOTF
examples:                    HELP OTFMAP EXAMPLES
all subtopics and options:   HELP OTFMAP *
options in general:         HELP OPTIONS
news about paKo:            HELP PAKO\ NEWS
help about paKo HELP:       HELP PAKO\ HELP

```

7.2 BACKEND

```

BACKEND name      nPart resolution bandwidth fShift
                receiverBand [polarization subband|sideband]

```

```

BACKEND /CLEAR

```

Alternative short syntax (only for the backends shown here!):

```

BACKEND BBC      nPart      /REC receiverBand [polarization sideband]
BACKEND NBC      nPart      /REC receiverBand [polarization subband]
BACKEND 4MHz     nPart      /REC receiverBand [polarization subband]
BACKEND WILMA   nPart      /REC receiverBand [polarization subband]
BACKEND FTS     nPart      /REC receiverBand [polarization subband]
BACKEND FTS     nPart /FINE /REC receiverBand [polarization subband]

```

Set up backends for heterodyne receivers.

```

Character :: name          ! name of backend
Integer   :: nPart        ! (logical) number of backend part
Real      :: resolution    ! [MHz]
Real      :: bandwidth    ! [MHz]
Real      :: fShift       ! frequency shift [MHz]
Character :: receiverBand  ! receiver band      to connect to backend part
Character :: polarization ! EMIR: polarization to connect to backend part
Character :: subband      ! EMIR: subband     to connect to backend part
Character :: sideband     ! EMIR: sideband    to connect to backend part

```

Choices for (backend) name are:

```

BBC          ! Broad Band Continuum Backend
NBC          ! Narrow Band Continuum Backend
4MHz        ! filter spectrometers with fixed resolution
WILMA       ! autocorrelation spectrometers
FTS         ! Fourier Transform Spectrometer
VESPA       ! autocorrelator with variable resolution

```

Choices for receiverBand are (compare RECEIVER command):

```

E090 E150 E230 E330 HERA1 HERA2

```

Choices for polarization are (for EMIR; compare RECEIVER command):

```

Horizontal Vertical

```

```

Choices for subband | sideband, when observing with EMIR, are:
    LO LI UI UO    |    LSB USB

```

LSB and USB apply only to EMIR bands with 8 GHz bandwidth (E090, E230, and E330) and Backend BBC.

fShift can be used to shift (offset) the backend band within the receiver band; this only applies to some backends, in particular VESPA. For VESPA, the range for fShift is much smaller than the 4GHz subbands of EMIR. For wide-bandwidth backends, fShift is fixed, corresponding to the frequency pattern of the EMIR subbands and backend bands. See EMIR and backend documentation.

/CLEAR completely clears the backend setup.

If option /CLEAR is present, all other parameters and options are ignored.

NOTE: EMIR subbands, IF cables, and Backends

The output signals from EMIR are transmitted to the spectrometers and NBC through 8 IF cables. Each IF cable carries one subband of bandwidth 4 GHz, LO, LI, UI, or UO.

NBC, 4MHz, WILMA, and VESPA can only(!) be connected to IF cables 1 to 4. FTS parts 1 to 4 can also be connected to IF cables 1 to 4.

The command options RECEIVER /HORIZONTAL and RECEIVER /VERTICAL allow to select up to 4 EMIR subbands that will be transmitted through IF cables 1 to 4 (compare HELP RECEIVER /HORIZONTAL and the EMIR user documentation). This selection can include Outer subbands.

In addition, for EMIR bands E090, E230, and E330, the IF cables 5 to 8 carry the 4 Outer subbands corresponding to the subbands selected for IF cables 1 to 4. E.g., if we select for IF 1 to 4:

```
E230 ver UO    E090 ver UI    E230 hor UI    E090 hor UI
then the IF cables 5 to 8 will transmit:
E230 ver UO    E090 ver UO    E230 hor UO    E090 hor UO.
```

Only FTS parts 5 to 8 can be connected to IF cables 5 to 8.

BACKEND NBC|WILMA|FTS /DEFAULT will automatically set the maximum number of backend parts for all available subbands.

BACKEND BBC is completely independant of the sub band selections for the IF cables.

NOTES:

- for some backends the resolution and/or bandwidth are fixed and the short syntax can be used. (The full syntax is supported for all backends).
- for VESPA always use the full syntax!
- after changing the receiver configuration: BACKEND /CLEAR is recommended followed by the backend setup for the new receivers; without that it is possible that pako will not accept BACKEND commands because of unresolved conflicts between the RECEIVER and BACKEND setups.
- However, the backend command will automatically try to disconnect backends that were connected to receiver (sub)bands that are not connected anymore.

7.2.1 BACKEND BBC

BBC ! Broad Band Continuum Backend

BBC works only with the EMIR receiver. One part of BBC always covers the full bandwidth of one available sideband of each polarization of each selected EMIR band:

Band	Sidebands	Subbands	IF [GHz]	Width [GHz]	Polariz.	# BBC parts -----
E090	LSB and USB		4--12	8	H and V	4
E150		LI or UI	4-- 8	4	H and V	2
E230	LSB and USB		4--12	8	H and V	4
E330	LSB and USB		4--12	8	H and V	4

Shortcut: after selecting EMIR bands and subbands, BACKEND BBC /DEFAULT automatically sets all this appropriately!

Notes:

By convention, in the paKo commands, we refer to the IF range 4 to 8 GHz as subband, LI or UI, and to the IF range 4 to 12 GHz as sideband, LSB or USB.

For E090, E230, and E330 the lower sideband (LSB) includes the lower outer (LO) and lower inner (LI) sub bands. For E150 the lower sideband includes only the lower inner sub band, i.e., in this case lower sideband and lower inner subband identical. Similar remarks hold for the Upper sidebands and subbands. Compare the EMIR user documentation.

7.2.2 BACKEND FTS

FTS ! Fourier Transform Spectrometer

The FTS supports two modes:

- wide bandwidth, up to ~ 4000 MHz on EMIR (~ 1000 MHz on HERA), with a resolution of ~ 0.195 [MHz], or
- fine resolution, ~ 0.049 MHz, with a bandwidth up to 1820 MHz on EMIR (~ 500 MHz on HERA)

All parts of the FTS must use the same resolution.

NOTE: EMIR subbands, IF cables, and Backends

The output signals from EMIR are transmitted to the spectrometers and

NBC through 8 IF cables. Each IF cable carries one subband of bandwidth 4 GHz, LO, LI, UI, or UO.

NBC, 4MHz, WILMA, and VESPA can only(!) be connected to IF cables 1 to 4. FTS parts 1 to 4 can also be connected to IF cables 1 to 4.

The command options RECEIVER /HORIZONTAL and RECEIVER /VERTICAL allow to select up to 4 EMIR subbands that will be transmitted through IF cables 1 to 4 (compare HELP RECEIVER /HORIZONTAL and the EMIR user documentation). This selection can include Outer subbands.

In addition, for EMIR bands E090, E230, and E330, the IF cables 5 to 8 carry the 4 Outer subbands corresponding to the subbands selected for IF cables 1 to 4. E.g., if we select for IF 1 to 4:

E230 ver UO	E090 ver UI	E230 hor UI	E090 hor UI
-------------	-------------	-------------	-------------

then the IF cables 5 to 8 will transmit:

E230 ver UO	E090 ver UO	E230 hor UO	E090 hor UO.
-------------	-------------	-------------	--------------

Only FTS parts 5 to 8 can be connected to IF cables 5 to 8.

BACKEND NBC|WILMA|FTS /DEFAULT will automatically set the maximum number of backend parts for all available subbands.

BACKEND BBC is completely independant of the sub band selections for the IF cables.

NOTE: bandwidth selection with EMIR

The pako command already allows some flexibility that is not yet fully supported by the data handling, e.g., to select only part of the full bandwidth.

NOTE: FTS on HERA

With HERA, the FTS can be connected to HERA1 and/or HERA2.

On HERA, the FTS provides some extra bandwidth, which is not symmetrical to the point where the line (the commanded frequency) gets centered.

With HERA /width wide, the line gets centered at the center of WILMA and 4MHz. Relative to this point, the FTS in wide mode covers IF offset frequencies from < -512 to > +512. In pako the nominal value of the bandwidth is 1024, symmetric around the line.

With HERA /width narrow, the line gets centered at the center of VESPA. Relative to this point, the FTS in fine mode covers IF offset frequencies from < -256 to > +360. In pako the nominal value of the bandwidth is 512, symmetric around the line.

It is also possible to connect FTS in fine mode on HERA /width wide or FTS in wide mode on HERA /width narrow. However, in these cases the

FTS band coverages are very asymmetric to the line. (See HERA and FTS documentation for the exact details of the IF ranges).

7.2.3 BACKEND /DEFAULTS

`/DEFAULTS [yes|no]`

Set default values.

If EMIR sub bands have been selected with the RECEIVER command, this option has a special function for some Backends:

BACKEND BBC	<code>/Defaults</code>	connects one BBC part to each sideband (!) of each selected EMIR band (up to 8)
BACKEND NBC	<code>/Defaults</code>	connects one NBC part to each selected EMIR sub band (up to 4)
BACKEND 4MHZ	<code>/Defaults</code>	connects one 4MHz part to each of the 1st and 2nd selected EMIR sub band
BACKEND WILMA	<code>/Defaults</code>	connects one WILMA part to each selected EMIR sub band (up to 4)
BACKEND FTS	<code>/Defaults</code>	connects one FTS part in "wide" bandwidth to each EMIR sub band (up to 4) selected for IF cables 1 to 4, and additionally one part to each of the available Outer subbands (up to 4) on IF cables 5 to 8
BACKEND FTS /Fine	<code>/Defaults</code>	connects one FTS part in "fine" resolution to each EMIR sub band (up to 4) selected for IF cables 1 to 4, and additionally one part to each of the available Outer subbands (up to 4) on IF cables 5 to 8

7.2.4 BACKEND /CLEAR

`/CLEAR [yes|no]`

Completely clear a list of connected hardware, e.g., receivers, backends, or parameters of the associated command.

After changing the receiver configuration: BACKEND /CLEAR is recommended followed by the backend setup for the new receivers; without that it is

possible that pako will not accept BACKEND commands because of unresolved conflicts between the RECEIVER and BACKEND setups.

7.2.5 BACKEND /CONNECT

/CONNECT [yes|no]

connect (or disconnect) the specified hardware, e.g., backend or backend part.

--> DEPRECATED. PROTECTED (needs SET userLevel)

7.2.6 BACKEND /DISCONNECT

/DISCONNECT

disconnect the specified hardware, e.g., backend or backend part.

--> DEPRECATED. PROTECTED (needs SET userLevel)

7.2.7 BACKEND /FINE

/FINE

for BACKEND FTS select the "fine" mode with a resolution of ~ 0.049 [MHz]

Note: with the option /DEFAULT or the short syntax, this allows to select the fine resolution without explicitly entering the values of resolution and bandwidth.

7.2.8 BACKEND /MODE

/MODE mode

Character :: mode ! backend mode

Choices for mode are:

SIMPLE	! simple (standard)
PARALLEL	! parallel mode
POLARIZATION	! polarimetry

Select special mode for VESPA.
See VESPA user's guide for details.

For EMIR, /MODE PARALLEL or /MODE POLARIZATION connect VESPA to the same band and subband in both polarizations; they must previously have been selected with the RECEIVER command. For examples, see:

HELP BACKEND Examples

7.2.9 BACKEND /LINENAME

/LINENAME lineName

Character :: lineName ! name of line. don't use @ < >

--> OPTION OF BACKEND COMMAND FOR USE WITH EMIR

This allows to set a "line" name for each backend part.

If a line name is set for a backend part, it will be used in the CLASS header of the spectrum from that backend part.

If no line name is set for a backend part (default), the line name from the corresponding RECEIVER band will be used in the CLASS header.

This is an optional convenience feature to make it easier to identify spectra by appropriate names, in particular in cases where several different lines are observed simultaneously with the same receiver band.

This is only a name or label, and has no influence on any frequencies or other control parameters.

7.2.10 BACKEND /PERCENTAGE

/PERCENTAGE percentage

Real :: percentage ! percentage of bandwidth to use

This is a special option for the autocorrelators, VESPA and WILMA.

For autocorrelators normally some channels at both ends of the band are blanked because they do not contain usable data, and only the central 'percentage' of the "theoretical" bandwidth is used, typically about 90%. Reasonable conservative defaults are automatically applied: in general 90%, but 82% for VESPA with bandwidth 640. This option allows the observer to adjust the percentage for special purposes.

For WILMA connected to EMIR, the useful bandwidth is 3720 MHz, and counted as 100%.


```

!                                     ! of each sideband
!                                     ! of each selected EMIR band
pause
!
!                                     ! EMIR NBC
backend /clear
BACKEND NBC           /Default       ! connect 1 part to
!                                     ! each selected EMIR subband
pause
!
!                                     ! EMIR WILMA
backend /clear
BACKEND WILMA        /Default       ! connect 1 part to
!                                     ! each selected EMIR subband
pause
!
!                                     ! EMIR 4MHz
!                                     ! NOTE: 4MHz has only 2
!                                     !       parts with EMIR
backend /clear
BACKEND 4MHZ         /Default       ! connect 1 part to each of
!                                     ! the first 2 EMIR subbands
pause
!
BACKEND 4MHZ 1       /Receiver E090 Horiz LI ! connect 1 part to E090 Ho LI
BACKEND 4MHZ 2       /Receiver E230 Verti LI !       2nd part to E230 Ve LI
pause
!
!                                     ! EMIR FTS wide bandwidth mode
!                                     !       /Fine is NOT present
backend /clear
BACKEND FTS          /Default       ! connect 1 part to
!                                     ! each selected EMIR subband
!                                     ! plus 1 part to each of the
!                                     ! 4 outer subbands of E090
pause
!
backend /clear
!                                     ! short syntax (still wide)
BACKEND FTS 1        /Receiver E090 hor LI !
BACKEND FTS 2        /Receiver E090 ver LI !
BACKEND FTS 3        /Receiver E230 hor LI !
BACKEND FTS 4        /Receiver E230 ver LI !
BACKEND FTS 5        /Receiver E090 ver LO !
BACKEND FTS 6        /Receiver E230 ver LO !
BACKEND FTS 7        /Receiver E090 hor LO !
BACKEND FTS 8        /Receiver E230 hor LO !
!                                     !
pause
!
!                                     ! EMIR FTS fine resolution
!                                     !       because /Fine is present
backend /clear

```

```

BACKEND FTS /Fine /Default ! connect 1 part to
! ! each selected EMIR subband
! ! plus 1 part to each of
! ! the 4 outer subbands of E090
pause
!
backend /clear
! ! short syntax (fine)
BACKEND FTS 1 /Fine /Receiver E090 hor LI !
BACKEND FTS 2 /Fine /Receiver E090 ver LI !
BACKEND FTS 3 /Fine /Receiver E230 hor LI !
BACKEND FTS 4 /Fine /Receiver E230 ver LI !
BACKEND FTS 5 /Fine /Receiver E090 ver LO !
BACKEND FTS 6 /Fine /Receiver E230 ver LO !
BACKEND FTS 7 /Fine /Receiver E090 hor LO !
BACKEND FTS 8 /Fine /Receiver E230 hor LO !
! !
pause
!
! ! EMIR WILMA + 4MHz + VESPA
backend /clear
BACKEND WILMA /Default !
BACKEND 4MHz /Default !
BACKEND VESPA 1 0.040 40.0 0.0 E090 Horiz LI
BACKEND VESPA 2 0.040 40.0 0.0 E090 Verti LI
BACKEND VESPA 3 0.040 40.0 0.0 E230 Horiz LI
BACKEND VESPA 4 0.040 40.0 0.0 E230 Verti LI
say " ! backends can be combined"
pause
!
!
!! EMIR VESPA autocorrelator -- basic mode with fShift. optional: line name
!
backend /clear
BACKEND VESPA 1 0.040 40.0 -120.0 E090 Horiz LI /line EOHU0-M
BACKEND VESPA 2 0.040 40.0 120.0 E090 Horiz LI /line EOHU0-P
BACKEND VESPA 3 0.040 40.0 -100.0 E090 Verti LI /line myLine3
BACKEND VESPA 4 0.040 40.0 110.0 E090 Verti LI /line myLine4
BACKEND VESPA 5 0.040 80.0 -150.0 E230 Horiz LI /line ""
BACKEND VESPA 6 0.040 80.0 150.0 E230 Horiz LI /line apple
BACKEND VESPA 7 0.040 80.0 -200.0 E230 Verti LI /line orange
BACKEND VESPA 8 0.040 80.0 200.0 E230 Verti LI /line red
pause
!
!! EMIR VESPA autocorrelator -- basic and parallel modes
!
backend /clear
BACKEND VESPA 1 0.320 240.0 0.0 E090 Horiz LI
BACKEND VESPA 2 0.320 240.0 0.0 E090 Verti LI
BACKEND VESPA 3 0.320 240.0 0.0 E230 Horiz LI /mode parallel
pause
!
!! NOTE: BACKEND VESPA ... E230 Horiz LI /mode parallel

```



```

!!      connects one VESPA part in parallel to
!!      E230 Horiz LI and E230 Verti LI
!!      (both must be selected in RECEIVER command)
!
!
!! HERA with FTS wide bandwidth
!
receiver /clear
RECEIVER HERA1 /WIDTH wide
RECEIVER HERA2 /WIDTH wide
!
backend /clear
BACKEND FTS 1      /RECEIVER HERA1
BACKEND FTS 2      /RECEIVER HERA2
!
!
!! HERA narrow bandwidth with FTS fine resolution
!
receiver /clear
RECEIVER HERA1 /WIDTH narrow
RECEIVER HERA2 /WIDTH narrow
!
backend /clear
BACKEND FTS 1  /FINE  /RECEIVER HERA1
BACKEND FTS 2  /FINE  /RECEIVER HERA2
!

```

7.3 CALIBRATE

CALIBRATE (no parameters)

Specify a calibration measurement with the heterodyne receivers, normally with subscans "SAC": Sky -- Ambient temperature load -- Cold load

NOTE: CALIBRATE is always and automatically done with switching mode "total" and the time per phase is adjusted to be in the range 0.1 to 0.5 [sec]

```

/SKY xOffsetC yOffsetC
or
/SKY NO                ! do not do sky calibration

```

Do a calibration subscan on sky.

```

Real      :: xOffsetC      ! x-offset
Real      :: yOffsetC      ! y-offset

```

NOTES: with the usage /SKY xOffsetC yOffsetC, both parameters are required, but you can replace either parameter with * to leave it unchanged. The system for the offsets is selected through the option /SYSTEM.

7.3.1 CALIBRATE /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.3.2 CALIBRATE /AMBIENT

/AMBIENT [yes|no]

Do a calibration subscan on the ambient temperature load.

Logical :: doAmbient ! default: true

7.3.3 CALIBRATE /COLD

/COLD [yes|no]

Do a calibration subscan on the cold temperature load.

Logical :: doCold ! default: true

7.3.4 CALIBRATE /GAINIMAGE

--> NOTE: OBSOLETE WITH CHANGE TO EMIR

7.3.5 CALIBRATE /GRID

/GRID [yes|no]

NOT YET AVAILABLE FOR EMIR

Do a calibration subscan on a grid. This is a special calibration option for polarization observations.

Logical :: doGrid ! default: true

IMPORTANT NOTE:

remember to turn this option off again for normal calibrations:
e.g., CALIBRATE /GRID NO or CALIBRATE /DEFAULT.

7.3.6 CALIBRATE /SKY

```

/SKY xOffsetC yOffsetC
or
/SKY NO                ! do not do sky calibration

```

Do a calibration subscan on sky.

```

Real      :: xOffsetC      ! x-offset
Real      :: yOffsetC      ! y-offset

```

NOTES: with the usage /SKY xOffsetC yOffsetC, both parameters are required, but you can replace either parameter with * to leave it unchanged. The system for the offsets is selected through the option /SYSTEM.

7.3.7 CALIBRATE /SYSTEM

```

/SYSTEM systemName

```

Name of system for offsets.

```

Character :: systemName      ! name of system, one of:
                             ! PROJECTION
                             ! TRUEHORIZON
                             ! NASMYTH

```

```

<<TBD:                       ! DESCRIPTIVE>>
<<TBD:                       ! BASIS>>
<<TBD:                       ! EQUATORIAL>>
<<TBD:                       ! HADECL>>
<<TBD:                       ! HORIZONTAL>>

```

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing, focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

```

If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM projection,
OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM trueHorizon,
OFFSETS ... /SYSTEM trueHorizon is ignored (not used).

```

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako, the values xOffset yOffset are used during the observations. (this includes the case that they are explicitly set to 0.0). It is up to the observer to make sure that they are "correct". (in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified (cleared), for the MAMBO bolometer, Nasmyth offsets are used automatically according to the selected bolometer channel (pixel).

7.3.8 CALIBRATE /TCALIBRATE

/TCALIBRATE tCalibrate

Time per CALIBRATE subscan.

Real :: tCalibrate ! time

7.4 CATALOG

CATALOG [SOURCE|LINE] fileName

Select a source or line catalog.

Character :: kind ! SOURCE or LINE

Character :: fileName ! file name

Selects a file with name fileName as source or line catalog.

Source Catalog:

The format of a line in the source catalog is the same as that of the parameters of the SOURCE command, without the keyword "SOURCE" and without any options (see HELP SOURCE). Example:

W30H EQ 2000 02:27:03.8812 +61:52:24.572 LSR -45.0 [FLUX 3.73 1.00]

IMPORTANT NOTE:

sourceName is limited to 12 characters.

Line Catalog:

The format of a line in the line catalog is same as that of the 2nd, 3rd, and 4th parameter of the RECEIVER command:

```
lineName      frequency      SB
```

with frequency in unit [GHz] (see HELP RECEIVER).

Example:

```
12CO(1-0)      115.271204      UI      (for EMIR)
12CO(2-1)      230.537990      LI      (for EMIR)
12CO(2-1)      230.537990      LSB     (for HERA)
```

IMPORTANT NOTE:

lineName is limited to 12 characters.

NB: Don't use / & < > in names of sources, lines, projects, PI, observer, operator, etc. Don't use ()/ in source names.

7.4.1 CATALOG SOURCE

Source Catalog:

The format of a line in the source catalog is the same as that of the parameters of the SOURCE command, without the keyword "SOURCE" and without any options (see HELP SOURCE). Example:

```
W3OH EQ 2000 02:27:03.8812 +61:52:24.572 LSR -45.0 [FLUX 3.73 1.00]
```

IMPORTANT NOTE:

sourceName is limited to 12 characters.

7.4.2 CATALOG LINE

Line Catalog:

The format of a line in the line catalog is same as that of the 2nd, 3rd, and 4th parameter of the RECEIVER command:

```
lineName      frequency      SB
```

with frequency in unit [GHz] (see HELP RECEIVER).

Example:

```
12CO(1-0)      115.271204      UI      (for EMIR)
12CO(2-1)      230.537990      LI      (for EMIR)
```

12C0(2-1) 230.537990 LSB (for HERA)

IMPORTANT NOTE:

lineName is limited to 12 characters.

7.5 DISPLAY

DISPLAY REDO

Redo (refresh) the text in the display window.

7.6 DIYLIST

DIYLIST

User-defined list of subscans and segments for observing mode "DIY";
to define subscans, see HELP SUBSCAN.

NB: this is a protected command (needs privilege).

DIYLIST without any parameters or options:

- lists defined subscans and segments in the pako window
(this requires SET LEVEL 2 or lower)
- in the pakoDisplay shows conditions, e.g., maximum possible elevation
- plots defined subscans and segments (depending on SET plotStyle)

7.6.1 DIYLIST /CLEAR

/CLEAR [yes|no]

Completely clear the used-defined list of subscans and segments DIY.

7.6.2 DIYLIST /PURPOSE

/PURPOSE purpose

Set a purpose for a scan, i.e., an intended use of the data.
The applies in particular to DIYLIST.

Character :: purpose !

NOTE: /PURPOSE by itself or
/DIY clears the purpose.

NOTE: at this time (2012-11-08) this is only for information,
and included in the XML, but it has no practical effect.

7.7 FOCUS

FOCUS lengthFocus

Specify a focus measurement.

Real :: lengthFocus ! length [mm] of focus scan

The sequence of focus subscans is determined by
lengthFocus /nSubscans /otfFocus:

```
lengthFocus    ! total length [mm] of the focus scan
/nSubscans     ! number of focus subscans
<< TD:/otfFocus    ! not yet implemented>>
```

```
focus subscan 1 is at offset 0.0
focus subscan 2 is at offset lengthFocus/2
in case /nSubscans 3:
focus subscan 3 is at offset -lengthFocus/2
in case /nSubscans >3:
focus subscan 3 is at offset lengthFocus/2
focus subscan 4 is at offset -lengthFocus/2
focus subscan 5 is at offset -lengthFocus/2
focus subscan 6 is at offset 0.0
(etc.)
```

7.7.1 FOCUS /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.7.2 FOCUS /NSUBSCANS

/NSUBSCANS nSubscans

```
Integer    :: nSubscans      ! number of subscans
```

7.7.3 FOCUS /TSUBSCAN

```
/TSUBSCAN tSubscan
```

```
time per subscan
```

```
Real      :: tSubscan      ! time
```

7.7.4 FOCUS EXAMPLES

```
!
! Id: demo-focus.pako
!   FOCUS EXAMPLE,v 1.1.1 2009-05-08 Hans Ungerechts
!
SWBEAM                                     ! to select beam switching
!
FOCUS          2.0                         - ! length [mm]
  /NSUBSCANS   6                           - ! number of subscans
  /TSUBSCAN    12                          ! time per subscan
!
PAUSE "FOCUS OK to start? [c/q]"          ! a chance to check
!
START                                                ! start
!
!! Comments:
!! We assume here that a pointing measurement has been done
!! immediately before the FOCUS (strongly recommended!),
!! see: demo-pointing, and therefore
!! we assume here that source, receivers, and backends
!! already have been selected and set up.
!! If you want the intensity of the Focus data to be
!! calibrated, you have to do a Calibrate with the same
!! receivers and (continuum) backends before.
```

7.8 LISSAJOUS

```
LISSAJOUS   xAmplitude   yAmplitude
  /CENTER    xCenter     yCenter
  /FREQUENCY frequencyX  frequencyY
  /PHASES    phiX        phiY
  /TOTF      tOtf
  /SYSTEM    system
```

Specify an On-The-Fly (OTF) map with a Lissajous curve in 1 subscan.
LISSAJOUS is at this time (2012-04-01) supported (in data processing)

only for the GISMO bolometer

```

Real      :: xAmplitude      ! amplitude for x-offsets
Real      :: yAmplitude      ! amplitude for y-offsets
Real      :: xCenter         ! center x-offset
Real      :: yCenter         ! center y-offset
Real      :: frequencyX      ! frequency [Hz] for x
Real      :: frequencyY      ! frequency [Hz] for y
Real      :: phiX            ! phase offset [rad] for x
Real      :: phiY            ! phase offset [rad] for y

Real      :: tOtf            ! time [s]
Character :: systemName      ! name of system, one of:
                                ! PROJECTION
                                ! TRUEHORIZON

```

During a Lissajous OTF segment, the position offsets x and y as a function of time t are:

$$x = xCenter + xAmplitude * \sin(2 \text{ Pi } frequencyX t + phiX)$$

$$y = yCenter + yAmplitude * \sin(2 \text{ Pi } frequencyY t + phiY)$$

SIN is the usual sine function, Pi is the number Pi.

```

xAmplitude yAmplitude xCenter yCenter are in angle units ([arc sec])
frequencyX frequencyY          are in [Hz]
phiX      phiY                are in [rad]

```

Note that the possible frequencies are very low, typically 0.01 to 0.15 Hz.

At the start of a Lissajous subscan, paKo will insert a "ramp" along a straight line, i.e., a linear OTF segment, increasing the count of segments by 2. This ramp up starts with speed 0 relative to the source and joins smoothly with the start position and velocity of the Lissajous segment. The purpose is to avoid a sudden acceleration at the start of the Lissajous segment. The inserted ramp up segment and the Lissajous segment become part of the same subscan.

Lissajous curves with large amplitudes or frequencies can reach the antenna's speed and acceleration limits for tracking. Lissajous curves can be executed only for elevations less than a maximum, which depends on the Lissajous parameters. For information, this elevation condition is shown by pako. Even below the limits, during very fast Lissajous curves the tracking errors will be higher, several arc sec, than during most other observations.

DO NOT TRY TO OBSERVE LISSAJOUS ABOVE THIS MAXIMUM ELEVATION.

7.8.1 LISSAJOUS /CENTER

```

/CENTER  xCenter  yCenter

```

position of center

```
Real      :: xCenter      ! center x-offset
Real      :: yCenter      ! center y-offset
```

7.8.2 LISSAJOUS /FREQUENCY

```
/FREQUENCY frequencyX frequencyY
```

```
Real      :: frequencyX   ! frequency [Hz] for x
Real      :: frequencyY   ! frequency [Hz] for y
```

7.8.3 LISSAJOUS /PHASES

```
/PHASES phiX phiY
```

```
Real      :: phiX         ! phase offset [rad] for x
Real      :: phiY         ! phase offset [rad] for y
```

7.8.4 LISSAJOUS /SYSTEM

```
/SYSTEM systemName
```

Name of system for offsets.

```
Character :: systemName   ! name of system, one of:
                          ! PROJECTION
                          ! TRUEHORIZON
                          ! NASMYTH
```

```
<<TBD:                   ! DESCRIPTIVE>>
<<TBD:                   ! BASIS>>
<<TBD:                   ! EQUATORIAL>>
<<TBD:                   ! HADECL>>
<<TBD:                   ! HORIZONTAL>>
```

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing,

focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...) is in /SYSTEM projection, OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...) is in /SYSTEM trueHorizon, OFFSETS ... /SYSTEM trueHorizon is ignored (not used).

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako, the values xOffset yOffset are used during the observations. (this includes the case that they are explicitly set to 0.0). It is up to the observer to make sure that they are "correct". (in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified (cleared), for the MAMBO bolometer, Nasmyth offsets are used automatically according to the selected bolometer channel (pixel).

7.8.5 LISSAJOUS /TOTF

/TOTF t0tf

time per OTF subscan or segment

Real :: t0tf ! time

In commands like OTFMAP that have options /SPEED and /TOTF, either option /SPEED or /TOTF can be used, the values of the other option are then implied!

7.9 OFFSETS

OFFSETS xOffset yOffset

Specify source offsets.

Real :: xOffset ! x-offset
Real :: yOffset ! y-offset

IMPORTANT NOTE: one should be careful with the OFFSETS command, which is only used and only needed in a few special situations, e.g., with Wobbler-switching ONOFF and to set NASMYTH offsets for focal-plane-array receivers. The function of OFFSETS is explained in the paKo user's manual, Section "A Guide to the Perplexed" and, in more detail, in the Section "NCS Explained", Subsection "Coordinate Systems, Projections, and Offsets."

For many observations all "offsets" are specified as parameters or options of the command for the observing mode.

/SYSTEM systemName

Name of system for offsets.

```
Character :: systemName      ! name of system, one of:
                             ! PROJECTION
                             ! TRUEHORIZON
                             ! NASMYTH

<<TBD:                       ! DESCRIPTIVE>>
<<TBD:                       ! BASIS>>
<<TBD:                       ! EQUATORIAL>>
<<TBD:                       ! HADECL>>
<<TBD:                       ! HORIZONTAL>>
```

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing, focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

```
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM projection,
OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM trueHorizon,
OFFSETS ... /SYSTEM trueHorizon is ignored (not used).
```

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

```
If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako,
the values xOffset yOffset are used during the observations.
(this includes the case that they are explicitly set to 0.0).
```

It is up to the observer to make sure that they are "correct".
(in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified
(cleared), for the MAMBO bolometer, Nasmyth offsets are used
automatically according to the selected bolometer channel (pixel).

7.9.1 OFFSETS /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.9.2 OFFSETS /CLEAR

/CLEAR [yes|no]

Completely clear a list of connected hardware, e.g., receivers, backends,
or parameters of the associated command.

7.9.3 OFFSETS /SYSTEM

/SYSTEM systemName

Name of system for offsets.

Character :: systemName	! name of system, one of:
	! PROJECTION
	! TRUEHORIZON
	! NASMYTH
<<TBD:	! DESCRIPTIVE>>
<<TBD:	! BASIS>>
<<TBD:	! EQUATORIAL>>
<<TBD:	! HADECL>>
<<TBD:	! HORIZONTAL>>

PROJECTION for now means only the standard simple "radio" projection
offsets in the chosen coordinate system. This is normally the
astronomical system of offsets in which point-by-point (TRACK, ONOFF)
or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$
applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a
focal-plane array receiver (bolometer, HERA) to the commanded
astronomical position, e.g., to use an off-center pixel for pointing,

focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...) is in /SYSTEM projection, OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...) is in /SYSTEM trueHorizon, OFFSETS ... /SYSTEM trueHorizon is ignored (not used).

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako, the values xOffset yOffset are used during the observations. (this includes the case that they are explicitly set to 0.0). It is up to the observer to make sure that they are "correct". (in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified (cleared), for the MAMBO bolometer, Nasmyth offsets are used automatically according to the selected bolometer channel (pixel).

7.10 ONOFF

ONOFF xOffset yOffset

Specify on-off measurement, a.k.a. "position switching".

Real :: xOffset ! x-offset of "on-source" position
Real :: yOffset ! y-offset of "on-source" position

Character :: sourceName ! name of "on-source" position

NOTE: if SWWOBBLER is the selected switching mode, the special option /SWWOBBLER YES (TRUE) is implied even without specifying it, and the on-off parameters appropriate for on-off Wobbler switching are set.

If SWWOBBLER and ONOFF are combined in the standard way, we effectively take data at 3 positions:

1. the source position
2. the source position + throw (offset in the "true-angle" horizontal system)
3. the source position - throw (offset in the "true-angle" horizontal system)

with throw = ABS(wOffset2-wOffset1).

Data from 1. are treated as source signal, data from 2 and 3 as off-source reference signal. Note that in the astronomical coordinates, positions 2 and 3 will rotate around the source position (1). Therefore one must normally be sure that the extent of the source is less than throw-beamWidth (/2).

```
/REFERENCE xOffsetR yOffsetR [systemNameRef]
or
/REFERENCE NO                ! no reference
```

position of off-source reference subsans

```
Real      :: xOffsetR      ! x-offset
Real      :: yOffsetR      ! y-offset
Character  :: systemNameRef ! name of system
                        ! see /SYSTEM for choices
```

NOTE: with the usage /REFERENCE xOffsetR yOffsetR, both parameters are required but you can replace either parameter with * to leave it unchanged.

```
/SYSTEM systemName
```

Name of system for offsets.

```
Character :: systemName      ! name of system, one of:
                        ! PROJECTION
                        ! TRUEHORIZON
                        ! NASMYTH
```

```
<<TBD:                ! DESCRIPTIVE>>
<<TBD:                ! BASIS>>
<<TBD:                ! EQUATORIAL>>
<<TBD:                ! HADECL>>
<<TBD:                ! HORIZONTAL>>
```

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing, focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

```
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM projection,
```

```

OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM trueHorizon,
OFFSETS ... /SYSTEM trueHorizon is ignored (not used).

```

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako, the values xOffset yOffset are used during the observations. (this includes the case that they are explicitly set to 0.0). It is up to the observer to make sure that they are "correct". (in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified (cleared), for the MAMBO bolometer, Nasmyth offsets are used automatically according to the selected bolometer channel (pixel).

7.10.1 ONOFF /DEFAULTS

```
/DEFAULTS [yes|no]
```

Restore default values for all parameters and options.

7.10.2 ONOFF /NSUBSCANS

```
/NSUBSCANS nSubscans
```

```
Integer    :: nSubscans          ! number of subscans
```

7.10.3 ONOFF /REFERENCE

```
/REFERENCE xOffsetR yOffsetR [systemNameRef]
```

or

```
/REFERENCE NO                      ! no reference
```

position of off-source reference subscans

```
Real       :: xOffsetR           ! x-offset
```

```
Real       :: yOffsetR           ! y-offset
```

```
Character  :: systemNameRef      ! name of system
```

```
! see /SYSTEM for choices
```

NOTE: with the usage /REFERENCE xOffsetR yOffsetR, both parameters are required but you can replace either parameter with * to leave it unchanged.

7.10.4 ONOFF /SWWOBLER

```
/SWWOBLER [yes|no]
```


(option of command ONOFF)

set parameters appropriate for on-off Wobbler switching

Logical :: doSwWobbler

If switching mode SWWOBBLER has been selected, the following parameters of ONOFF are set according to wOffset1 and wOffset2:

ONOFF

xOffset is set to: -wOffset1
yOffset is set to: 0.0

/REFERENCE is set to: Yes
xOffsetR is set to: -wOffset2
yOffsetR is set to: 0.0
systemNameRef is set to: TRUEHORIZON

/SYSTEM

systemName is set to: TRUEHORIZON

NOTE: in this case the values selected by /SWWOBBLER overrule the corresponding values specified directly in the command.

NOTE: To do ONOFF with Wobbler switching and other (unconventional) values for the parameters listed above, simply specify the values using command ONOFF with option /SWWOBBLER NO (not recommended).

NOTE: If the selected switching mode is SWWOBBLER and if the option /SWWOBBLER is no explicitly given, it will be assumed to be .True. (Yes), If the selected switching mode is not SWWOBBLER and if the option /SWWOBBLER is no explicitly given, it will be assumed to be .False. (No),

7.10.5 ONOFF /SYMMETRIC

/SYMMETRIC [yes|no]

Logical :: doSymmetric ! default: no

(For ONOFF) select a subscan sequence that is "symmetric" in time. This requires that the number of subscans is a multiple of 4.

Example for ONOFF with	/SYMMETRIC no	/SYMMETRIC yes
1st subscan:	OFF	OFF
2nd "	ON	ON
3rd "	OFF	ON
4th "	ON	OFF
(and so on)		

NOTE that this does not in anyway change the positions of the ON-source and OFF-source subscans!

7.10.6 ONOFF /SYSTEM

/SYSTEM systemName

Name of system for offsets.

Character :: systemName ! name of system, one of:
 ! PROJECTION
 ! TRUEHORIZON
 ! NASMYTH

<<TBD: ! DESCRIPTIVE>>
 <<TBD: ! BASIS>>
 <<TBD: ! EQUATORIAL>>
 <<TBD: ! HADECL>>
 <<TBD: ! HORIZONTAL>>

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing, focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...) is in /SYSTEM projection, OFFSETS ... /SYSTEM projection is ignored (not used).
 If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...) is in /SYSTEM trueHorizon, OFFSETS ... /SYSTEM trueHorizon is ignored (not used).

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako, the values xOffset yOffset are used during the observations. (this includes the case that they are explicitly set to 0.0). It is up to the observer to make sure that they are "correct". (in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified (cleared), for the MAMBO bolometer, Nasmyth offsets are used automatically according to the selected bolometer channel (pixel).

7.10.7 ONOFF /TSUBSCAN

```

/TSUBSCAN tSubscan

time per subscan

Real      :: tSubscan      ! time

```

7.10.8 ONOFF EXAMPLES

```

!
! Id: demo-onoff.pako
!   ONOFF SWTOTAL EXAMPLE,v 1.1.1 2009-05-05 Hans Ungerechts
!   "POSITION SWITCHING"
!
!
@ demo-rx-spectrometers      ! demo setup of receivers
!                             ! and spectrometers
!                             ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec            !
!
SWTOTAL                      - ! select total power
  /TPHASE          0.5       ! time per phase (data sample)
!
CALIBRATE                    - !
  /AMBIENT          - ! ambient load
  /COLD             - ! cold load
  /SKY          -600.0  0.0  - ! sky at offsets -600.0 0.0
  /SYSTEM          projection - ! system for SKY offsets
  /TCALIBRATE      5.0       ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                        ! start
!
ONOFF          40.0  -30.0     - ! offsets of on position
  /NSUBSCANS   12             - ! number of subscans
  /REFERENCE  -600.0  0.0  projection - ! offsets of off-source referen
  /SYSTEM      projection     - ! system for offsets
  /SYMMETRIC                    - ! "symmetric" subscan sequence
  /TSUBSCAN    30             ! time per subscan
!
PAUSE "ONOFF SWTOTAL OK to start? [c/q]" ! a chance to check
!
START                        ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source
!
! Id: demo-onoff-swwobbler.pako

```

```

!      ONOFF SWWOBLER EXAMPLE,v 1.1.6 2011-07-31 Hans Ungerechts
!      "WOBLER SWITCHING"
!
@ demo-rx-spectrometers          ! demo setup of receivers
!                                ! and spectrometers
!                                ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec                 !
!
!                                ! select wobbler switching
SWWOBLER      -120.0  120.0      - ! wobbler +/- 120 arc sec
  /TPHASE      1.0              ! 1 seconds per phase
!
CALIBRATE                    - !
  /AMBIENT                    - ! ambient load
  /COLD                      - ! cold   load
  /SKY      -600.0  0.0        - ! sky at offsets -600.0 0.0
  /SYSTEM      projection      - ! system for SKY offsets
  /TCALIBRATE  5.0            ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                        ! start
!
!!                            ! OPTIONAL:
!! OFFSETS  20 30            - ! mapping offsets in
!! /SYSTEM projection        ! system projection
!
ONOFF  /SWWOBLER            - ! ONOFF for Wobbler switching
  /NSUBSCANS  12            - ! number of subscans
  /SYMMETRIC  -             - ! "symmetric" subscan sequence
  /TSUBSCAN   30            ! time per subscan
!
PAUSE "ONOFF SWWOBLER OK to start? [c/q]" ! a chance to check
!
START                        ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source
!!
!! IMPORTANT NOTE: ONOFF with SWWOBLER (wobbler switching on-off)
!! requires that the subscans are offset relative to the source
!! in the trueHorizon system by -1 * the Wobbler elongations (offsets).
!! With the commands above, paKo recognizes this and automatically
!! sets the correct values.
!! In this case, OFFSETS can be used to set additional mapping
!! offsets in the "projection" of the astronomical coordinate
!! system. These mapping offsets in the projection apply
!! to all ONOFF subscans.

```

7.11 OTFMAP

```
OTFMAP xStart yStart xEnd yEnd
```

Specify an On-The-Fly (OTF) map with linear OTF subscons.

```
Real      :: xStart      ! x-offset of start of first OTF  subscan
Real      :: yStart      ! y-offset of start of first OTF  subscan
Real      :: xEnd        ! x-offset of end    of first OTF  subscan
Real      :: yEnd        ! y-offset of end    of first OTF  subscan
```

The sequence of subscons is determined by:

```
/croLoop /nOtf /reference /step /zigzag
```

```
/croLoop      sequence of:
                R off-source Reference
                0 on-source OTF
/nOtf          number of OTF subscons
/reference     off-source reference position
/step         step in x and y between OTF subscons
              = translation of one OTF subscons to the next
/zigzag       option to scan back-and-forth
```

The scan analysis loops through the letter codes in croLoop until nOtf OTF subscons have been generated, starting with first letter in the croLoop.

IF THE CROCODE LETTER IS "R" AND /REFERENCE IS TRUE:

1 subscan tracking the fixed off-source reference position is generated

IF THE CROCODE LETTER IS "0":

1 linear OTF subscan is generated.

- The start and end positions of the first OTF subscan are: parameters xStart yStart xEnd yEnd of the OTFMAP command
- For the second and all following OTF subscons:
 - xStart yStart xEnd yEnd of the previous OTF subscan are incremented by parameters dx and dy of option /step.
 - If /zigzag is true, xStart yStart and xEnd yEnd are interchanged.

Then the next letter code in the croLoop is considered in the same way.

If /reference is true, a croCode ending in "R" will ensure that an off-source reference subscan follows the last OTF subscan.

```
/CROLOOP croLoop
```

sequence of R = off-source Reference

0 = On-source subs cans

Character :: croLoop

Example:

/croLoop ROOR

/NOTF nOtf

Integer :: nOtf ! number of OTF (on-the-fly) subs cans

/REFERENCE xOffsetR yOffsetR [systemNameRef]

or

/REFERENCE NO ! no reference

position of off-source reference subs cans

Real :: xOffsetR ! x-offset

Real :: yOffsetR ! y-offset

Character :: systemNameRef ! name of system

! see /SYSTEM for choices

NOTE: with the usage /REFERENCE xOffsetR yOffsetR, both parameters are required but you can replace either parameter with * to leave it unchanged.

/STEP dx dy

Step (shift or translation) between lines in a map.

Real :: dx ! shift in x-offsets

Real :: dy ! shift in y-offsets

/SYSTEM systemName

Name of system for offsets.

Character :: systemName ! name of system, one of:

! PROJECTION

! TRUEHORIZON

! NASMYTH

<<TBD: ! DESCRIPTIVE>>

<<TBD: ! BASIS>>

<<TBD: ! EQUATORIAL>>

<<TBD: ! HADECL>>

<<TBD: ! HORIZONTAL>>

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing, focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...) is in /SYSTEM projection, OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...) is in /SYSTEM trueHorizon, OFFSETS ... /SYSTEM trueHorizon is ignored (not used).

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako, the values xOffset yOffset are used during the observations. (this includes the case that they are explicitly set to 0.0). It is up to the observer to make sure that they are "correct". (in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified (cleared), for the MAMBO bolometer, Nasmyth offsets are used automatically according to the selected bolometer channel (pixel).

7.11.1 OTFMAP /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.11.2 OTFMAP /CROLOOP

/CROLOOP croLoop

sequence of R = off-source Reference
0 = On-source subscans

Character :: croLoop

Example:
/croLoop R00R

7.11.3 OTFMAP /NOTF

/NOTF n0tf

Integer :: nOtf ! number of OTF (on-the-fly) subscans

7.11.4 OTFMAP /REFERENCE

/REFERENCE xOffsetR yOffsetR [systemNameRef]
or
/REFERENCE NO ! no reference

position of off-source reference subscans

Real :: xOffsetR ! x-offset
Real :: yOffsetR ! y-offset
Character :: systemNameRef ! name of system
 ! see /SYSTEM for choices

NOTE: with the usage /REFERENCE xOffsetR yOffsetR, both parameters are required but you can replace either parameter with * to leave it unchanged.

7.11.5 OTFMAP /STEP

/STEP dx dy

Step (shift or translation) between lines in a map.

Real :: dx ! shift in x-offsets
Real :: dy ! shift in y-offsets

7.11.6 OTFMAP /SPEED

/SPEED speed1 [speed2]

speed of OTF subscans

Real :: speed1 ! speed at start
Real :: speed2 ! speed at end

For OTFMAP speed2 = speed1.

In commands like OTFMAP that have options /SPEED and /TOTF, either option /SPEED or /TOTF can be used, the values of the other option are then implied!

7.11.7 OTFMAP /SYSTEM

/SYSTEM systemName

Name of system for offsets.

Character :: systemName ! name of system, one of:
 ! PROJECTION


```

                                ! TRUEHORIZON
                                ! NASMYTH

<<TBD:                          ! DESCRIPTIVE>>
<<TBD:                          ! BASIS>>
<<TBD:                          ! EQUATORIAL>>
<<TBD:                          ! HADECL>>
<<TBD:                          ! HORIZONTAL>>

```

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing, focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

```

If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM projection,
OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM trueHorizon,
OFFSETS ... /SYSTEM trueHorizon is ignored (not used).

```

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

```

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako,
the values xOffset yOffset are used during the observations.
(this includes the case that they are explicitly set to 0.0).
It is up to the observer to make sure that they are "correct".
(in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)

```

```

If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified
(cleared), for the MAMBO bolometer, Nasmyth offsets are used
automatically according to the selected bolometer channel (pixel).

```

7.11.8 OTFMAP /TOTF

```
/TOTF t0tf
```

time per OTF subscan or segment

```
Real      :: t0tf      ! time
```

In commands like OTFMAP that have options /SPEED and /TOTF, either option /SPEED or /TOTF can be used, the values of the other option are then implied!

7.11.9 OTFMAP /TREFERENCE

/TREFERENCE tReference

time per off-source reference

Real :: tReference ! time

7.11.10 OTFMAP /ZIGZAG

/ZIGZAG [yes|no]

alternate direction between lines in a map

Logical :: doZigzag

7.11.11 OTFMAP EXAMPLES

```

!
! Id: demo-otfmap.pako
!   OTFMAP SWTOTAL EXAMPLE,v 1.1.6 2011-07-21 Hans Ungerechts
!
!
! demo-rx-spectrometers           ! demo setup of receivers
!                                 ! and spectrometers
!                                 ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec                   !
!
SWTOTAL                             - ! to select total power
  /TPHASE          0.5              ! time per phase (data sample)
!
CALIBRATE                          - !
  /AMBIENT                - ! ambient load
  /COLD                   - ! cold   load
  /SKY          -500.0 -400.0      - ! sky at offsets -500.0 -400.0
  /SYSTEM      projection          - ! system for SKY offset
  /TCALIBRATE  5.0                ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                               ! start
!
OTFMAP          -300  -15  300  -15  - ! offsets at start and end of f
  /CROLOOP      ROR                - ! subscans: reference-OTF-refer
  /NOTF         4                  - ! number of on-the-fly subscans
  /REFERENCE    -500  -400  projection - ! offsets of off-source referen

```

```

/STEP          0    10          - ! step (shift) between OTF subs
/SYSTEM        projection       - ! system for offsets
/TOTF          120.0           - ! time per on-the-fly subscan
/TREFERENCE    20.0           - ! time per off-source reference
/ZIGZAG                ! go back and forth
!
PAUSE "OTFMAP SWTOTAL OK to start? [c/q]" ! a chance to check
!
START                ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source
!!
!! /CROLOOP        ROR means that there will be an
!!                off-source reference subscan (R)
!!                before and after each OTF suscan (O).
!!                Therefore with /NOTF 4 on-the-fly subscans the complete
!!                subscan sequence will be:
!!                R OTF#1 R   R OTF#2 R   R OTF#3 R   R OTF#4 R
!!                with
!! /CROLOOP        ROOROR it would be:
!!                R OTF#1      OTF#2   R   OTF#3      OTF#4 R
!
!
! Id: demo-otfmap-swfrequency.pako
!   OTFMAP SWFREQUENCY EXAMPLE,v 1.1.11 2011-11-25 Hans Ungerechts
!
@ demo-rx                ! demo setup of receivers
!
BACKEND /CLEAR           ! clear previous backends
BACKEND VESPA 1 0.040 40.0 0.0 E090 hor LI ! high spectral resolution
BACKEND VESPA 2 0.040 40.0 0.0 E090 ver LI ! with VESPA
BACKEND VESPA 3 0.080 80.0 0.0 E230 hor LI
BACKEND VESPA 4 0.080 80.0 0.0 E230 ver LI
!
!                ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec        !
!
!                ! setup frequency switching
SWFREQUENCY  -3.9      3.9 /receiver E090 ! for EMIR band E090
SWFREQUENCY  -11.7     11.7 /receiver E230 ! for EMIR band E230
SWFREQUENCY                /tphase 0.20 ! same for all receivers/bands
!
CALIBRATE                - !
  /AMBIENT                - ! ambient load
  /COLD                    - ! cold load
  /SKY -600.0 0.0         - ! sky at offsets -600.0 0.0
  /SYSTEM projection      - ! system for offset
  /TCALIBRATE 5.0        ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START                ! start

```

```

!
OTFMAP      -300 -300 300 -300      - ! offsets at start and end of f
/CROLOOP    0                      - ! only OTF subscans
/NOTF       4                      - ! number of on-the-fly subscans
/REFERENCE  no                     - ! no off-source reference subsc
/STEP       0    10                 - ! step (shift) between OTF subs
/SYSTEM     projection              - ! system for offset
/TOTF       120.0                  - ! time per on-the-fly subscan
/ZIGZAG     ! go back and forth
!
PAUSE "OTFMAP SWFREQUENCY OK to start? [c/q]" ! a chance to check
!
START                               ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source

```

7.12 POINTING

POINTING length

Specify a pointing measurement with linear OTF subscans in the "true-angle" horizontal system, along azimuth and elevation, all centered on the source.

```
Real      :: length          ! length (angle) of each subscan
```

The first subscan is incrementing in azimuth. If the number of OTF subscans, `nOtf`, is 2, the second subscan is incrementing in elevation. If `nOtf > 2`, the subscan sequence is: incrementing azimuth, decrementing azimuth, incrementing elevation, and if `nOtf > 3`: decrementing elevation, etc.

7.12.1 POINTING /DEFAULTS

```
/DEFAULTS [yes|no]
```

Restore default values for all parameters and options.

7.12.2 POINTING /DOUBLEBEAM

```
/DOUBLEBEAM [yes|no]
```

Pointing: do a "double-beam" pointing

```
Logical    :: doDoubleBeam
```



```

PAUSE "POINTING OK to start? [c/q]"      ! a chance to check
!
START                                     ! start
!
RETURN
!
!!
!! NOTE:
!! if you use NASMYTH offsets for an off-center pixel
!! of a mutlibeam receiver don't use OFFSETS/ CLEAR.
!! If you want the intensity of the Pointing data to be
!! calibrated, you have to do a Calibrate with the same
!! receivers and (continuum) backends before the pointing.
!!

```

7.13 RECEIVER

```

RECEIVER receiverBand lineName [frequency SB]
RECEIVER BOLOMETER    bolometerName

```

Specify selection and setup for receivers.

The first form is for heterodyne receivers,
the second form for bolometers.

Heterodyne:
=====

```

Character    :: receiverBand    ! name of receiver band to connect
Character*12 :: lineName        ! name of line. don't use @ < >
Real         :: frequency       ! [GHz]
Character    :: SB              ! sideband or subband
                                     ! choices for HERA: LSB USB
                                     ! choices for EMIR: LO LI UI UO

```

Choices for receiverBand are:
E090 E150 E230 E330 HERA1 HERA2

lineName is limited to 12 characters.

NB: Don't use / & < > in names of sources, lines, projects,
PI, observer, operator, etc. Don't use ()/ in source names.

E090 E150 E230 E330 are the 4 EMIR (Eight MIXer Receiver) bands,

HERA1 and HERA2 are the 2 parts of HERA (HEterodyne Receiver Array).

If only receiverBand and lineName are specified, we try to read the frequency and sideband/subband from the line catalog specified with: CATALOG LINE fileName.

The local oscillator for the receiverBand will be set so that the frequency (corrected for the Doppler shift) will be in the requested sideband/subband SB. See receiver documentation for the exact values of the IF.

NOTE: EMIR subbands, IF cables, and Backends

The output signals from EMIR are transmitted to the spectrometers and NBC through 8 IF cables. Each IF cable carries one subband of bandwidth 4 GHz, LO, LI, UI, or UO.

NBC, 4MHz, WILMA, and VESPA can only(!) be connected to IF cables 1 to 4. FTS parts 1 to 4 can also be connected to IF cables 1 to 4.

The command options RECEIVER /HORIZONTAL and RECEIVER /VERTICAL allow to select up to 4 EMIR subbands that will be transmitted through IF cables 1 to 4 (compare HELP RECEIVER /HORIZONTAL and the EMIR user documentation). This selection can include Outer subbands.

In addition, for EMIR bands E090, E230, and E330, the IF cables 5 to 8 carry the 4 Outer subbands corresponding to the subbands selected for IF cables 1 to 4. E.g., if we select for IF 1 to 4:

```
E230 ver UO    E090 ver UI    E230 hor UI    E090 hor UI
then the IF cables 5 to 8 will transmit:
E230 ver UO    E090 ver UO    E230 hor UO    E090 hor UO.
```

Only FTS parts 5 to 8 can be connected to IF cables 5 to 8.

BACKEND NBC|WILMA|FTS /DEFAULT will automatically set the maximum number of backend parts for all available subbands.

BACKEND BBC is completely independant of the sub band selections for the IF cables.

Bolometer:
=====

Character :: bolometerName ! name of bolometer

Choices for bolometerName are:
GISMO NIKA

NOTE (2011-07-14): the MAMBO bolometers are out of operation.

7.13.1 RECEIVER /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.13.2 RECEIVER /CLEAR

/CLEAR [yes|no]

Completely clear a list of connected hardware, e.g., receivers, backends, or parameters of the associated command.

7.13.3 RECEIVER /CONNECT

/CONNECT [yes|no]

connect (or disconnect) the specified hardware, e.g., backend or backend part.

--> DEPRECATED. PROTECTED (needs SET userLevel)

7.13.4 RECEIVER /DEROTATOR

/DEROTATOR angle system

Specify derotator angle for HERA

Real :: angle ! in units [deg] (!)
Character :: system !

Choices for system:

"Nasmyth"

"horizon"

"equatorial"

"frame"

! same as Nasmyth

"sky"

! same as equatorial

NOTES: The last 2 are for consistency with old control system and HERA conve
This option works only for RECEIVER HERA1 or RECEIVER HERA2 (of course it's
same angle for HERA1 and HERA2).

7.13.5 RECEIVER /DISCONNECT

/DISCONNECT

disconnect the specified hardware, e.g., backend or backend part.

--> DEPRECATED. PROTECTED (needs SET userLevel)

7.13.6 RECEIVER /DOPPLER

/DOPPLER doppler

Character :: doppler ! apply doppler correction?
! choices: DOPPLER|FIXED

7.13.7 RECEIVER /EFFICIENCY

/EFFICIENCY forwardEfficiency beamEfficiency

specify forward and beam efficiencies

Real :: forwardEfficiency !
Real :: beamEfficiency !

7.13.8 RECEIVER /GAINIMAGE

/GAINIMAGE gainImage [dB]

Specify the gain ratio of image to signal sidebands.

Real :: gainImage !

If "dB" is added after the value, the ratio is assumed to be in dB, otherwise a decimal fraction.

--> A standard value for EMIR is -13 db, for HERA -10 db.

7.13.9 RECEIVER /HORIZONTAL

/HORIZONTAL [sb1 [sb2]]

/HORIZONTAL n[one]

EMIR subbands for Horizontal polarization.

This option applies only to EMIR.

Character :: sb1, sb2 ! for EMIR: LO|LI|UI|UO

This option selects which EMIR subband(s) of this polarization will be transmitted through IF cables 1 to 4. Note that some backends, NBC,

4MHz, WILMA, VESPA, can only be connected to IF cables 1 to 4, i.e., only to the EMIR subbands selected with the RECEIVER command.

For each EMIR band and polarization, at most 2 subbands can be transmitted through IF cables 1 to 4. Which combinations of EMIR bands, polarizations, and subbands are possible is determined by the hardware of the EMIR IF switching box. See the EMIR documentation for details.

If no subband is explicitly specified with this option, paKo will assume that for this polarization the same single subband SB is requested as specified for the main parameters (frequency, tuning) of the RECEIVER command for this EMIR band.

/HORIZONTAL n[one] means that from this polarization no subband will be transported through IF cables 1 to 4.

7.13.10 RECEIVER /SCALE

/SCALE scale

Select the calibration intensity scale.

Character :: scale ! choices: ANTENNA|BEAM

If scale is "ANTENNA", the scale is antenna temperature.
If scale is "BEAM", the scale is (main) beam temperature.

7.13.11 RECEIVER /TEMPLOAD

```
/TEMPLOAD tempColdLoad tempAmbientLoad
/TEMPLOAD L[OOKUP] L[OOKUP]
/TEMPLOAD * ...
```

Set effective temperatures for the calibration loads at cold and ambient temperature.

```
Real      :: tempColdLoad      !
Real      :: tempAmbientLoad    !
```

NEW LOGIC FOR SINGLE-PIXEL SIS RECEIVERS (FROM SUMMER 2007, paKo v1.0.7)

If a numerical value is entered for tempColdLoad or tempAmbientLoad, that value is used for calibration calculations.

Instead of specifying a value one may enter the string L(OOKUP) for

tempColdLoad and/or tempAmbientLoad. This is shown in the pakoDisplay by the letter "L" instead of a number.

In this case, during the execution of the observations, the NCS will use measured values for the corresponding load temperature(s).

A * can be substituted for tempColdLoad, which means to leave the value for tempColdLoad unchanged from the previous RECEIVER command.

NOTE: FOR HERA

measured values are always used during the execution of the observations. This is the same logic as in older versions of paKo/NCS.

7.13.12 RECEIVER /VERTICAL

```
/VERTICAL [sb1 [sb2]]
/VERTICAL n[one]
```

EMIR subbands for Vertical polarization

This option applies only to EMIR.

Character :: sb1, sb2 ! for EMIR: LO|LI|UI|UO

This option selects which EMIR subband(s) of this polarization will be transmitted through IF cables 1 to 4. Note that some backends, NBC, 4MHz, WILMA, VESPA, can only be connected to IF cables 1 to 4, i.e., only to the EMIR subbands selected with the RECEIVER command.

For each EMIR band and polarization, at most 2 subbands can be transmitted through IF cables 1 to 4. Which combinations of EMIR bands, polarizations, and subbands are possible is determined by the hardware of the EMIR IF switching box. See the EMIR documentation for details.

If no subband is explicitly specified with this option, paKo will assume that for this polarization the same single subband SB is requested as specified for the main parameters (frequency, tuning) of the RECEIVER command for this EMIR band.

/VERTICAL n[one] means that from this polarization no subband will be transported through IF cables 1 to 4.

7.13.13 RECEIVER /WIDTH

```
/WIDTH width
```

Select receiver setup for WIDE or NARROW bandwidth mode.

Character :: width ! width. choices: WIDE|NARROW

NOTE: Option /WIDTH NARROW changes the (local oscillator) setup of receivers HERA1 HERA2 in such a way that a line in the center of the receiver bandwidth appears in the center of the bands of VESPA.

Spectrometers with 1GHz or more bandwidth normally require /WIDTH WIDE.

--> NOTE: THIS OPTION DOES NOT APPLY TO EMIR!

7.13.14 RECEIVER EXAMPLES

```

!
! Id: demo-receiver.pako
!   basic RECEIVER EXAMPLES,v 1.1.11 2011-11-24 Hans Ungerechts
!
CATALOG line demo-EMIR.lin ! specify line catalog
!
RECEIVER /CLEAR ! clear all receivers previously set
!
say " ! NOTE: E090 band "
receiver /clear
RECEIVER E090 12C0(1-0) - ! line (f, SB from catalog)
                /Horizontal - ! SB from catalog
                /Vertical ! SB from catalog
!
! ! f = frequency
! ! SB = sideband / subband
pause
!
say " ! NOTE: E090 band "
receiver /clear
REC E090 12C0(1-0) 115.271204 U0 - ! line f SB explicit
                /Horizontal U0 - ! SB explicit
                /Vertical U0 ! SB explicit
say " ! NOTE: E090 H&V 4 GHz BW "
pause
!
!
say " ! NOTE: E090 + E150 bands "
receiver /clear
RECEIVER E090 HCN(1-0) - !
                /Hor LI - ! LSB Inner
                /Ver LI ! LSB Inner
RECEIVER E150 CS(3-2) - !
                /H LI - ! LSB Inner
                /V LI ! LSB Inner
say " ! NOTE: E090 H+V 4 GHz BW "
say " ! E150 H+V 4 GHz BW "
pause

```

```

!
!
say                " ! NOTE: E090 + E230 bands "
receiver /clear
RECEIVER E090   HCN(1-0)      - !
                /Hor         LI   - ! LSB Inner
                /Ver         LI   ! LSB Inner
RECEIVER E230   12C0(2-1)    - !
                /Horizontal LI   - ! LSB Inner
                /Vertical   LI   ! LSB Inner
say                " ! NOTE: E090 H+V 4 GHz BW "
say                " !           E230 H+V 4 GHz BW "
pause
!
!
say                " ! NOTE: E150 + E330 bands "
receiver /clear
RECEIVER E150   CS(3-2)      - !
                /H           LI   - ! LSB Inner
                /V           LI   ! LSB Inner
RECEIVER E330   13C0(3-2)    - !
                /H           LI   - ! LSB Inner
                /V           LI   ! LSB Inner
say                " ! NOTE: E150 H+V 4 GHz BW "
say                " ! NOTE: E330 H+V 4 GHz BW "
pause
!
!!!!
!
RECEIVER        /clear          ! clear all receivers previously set
REC HERA1 12C0(2-1) 230.537990 LSB
REC HERA2 12C0(2-1) 230.537990 LSB
pause
!

```

7.14 SAVE

```

SAVE [commandToSave]
SAVE ALL [CORRECTIONS]
SAVE SET [CORRECTIONS]
SAVE SWITCHING

```

Save parameters and options of a command in the form of a valid .pako script.

Character :: commandToSave ! command to save

If commandToSave is not specified, the last selected observing mode is saved.

SAVE ALL saves (nearly) all current setup parameters, as well as the current switching and observing modes, to file all.pako, or to a different file specified with /FILE.

NOTE: SAVE ALL and SAVE SET save the pointing and focus corrections only if they are used in the form

```
SAVE ALL C[ORRECTIONS]
SAVE SET C[ORRECTIONS]
```

(Normally SAVE ALL and SAVE SET are meant to generate paKo scripts that can be used to re-produce the setup at a later time, when one probably wants to use different corrections. On the other hand the idiomatic usage: SAVE ALL C /FILE LAST allows to save "really everything" in order to recover it with @ LAST)

SAVE SWITCHING saves the currently selected switching mode (total power, beam, frequency, wobblers), to file switching.pako, or to a different file specified with /FILE.

NOTE: the parameters of "unused" (unselected) hardware, switching modes, and observing modes are never saved.

7.14.1 SAVE /APPEND

```
/APPEND [yes|no]
```

Append to existing file, do not create a new one.

```
Logical    :: doAppend          ! default: false
```

7.14.2 SAVE /FILE

```
/FILE fileName
```

Specify file name.

```
Character  :: fileName          !
```

7.14.3 SAVE EXAMPLES

```
!
! SAVE EXAMPLES v1.0.0 2005-12-19 Hans Ungerechts
!
SOURCE ...
SWFREQUENCY ...
SWTOTAL ...
ONOFF ...
OTFMAP ...
SAVE          ! saves OTFMAP          to file otfmap.pako
SAVE ALL      ! saves "everything" to file all.pako
```

```

SAVE ONOFF          ! saves ONOFF          to file onoff.pako
SAVE SOURCE         ! saves SOURCE         to file source.pako
SAVE SWITCHING      ! saves SWTOTAL        to file switching.pako
SAVE SWFREQUENCY    ! saves SWFREQUENCY    to file swfrequency.pako
!
```

7.15 SET

```
SET keyword value [value* ...]
```

Set values for some general parameters.

```
Character           :: keyword
Character|Integer|Real :: value*
```

```
Keywords           Type of Value(s)
=====           =====
```

```

Level              Integer [Integer] ! mininum value(s) for warning and error messa
Project            Character(len=24) ! project ID
PI                 Character(len=24) ! PI. Don't use & < >
Observer           Character(len=24) ! Observer(s). Don't use & < >
Operator           Character(len=24) ! Telescope operator(s). Don't use & < >

Pointing           Real Real          ! Pointing corrections [arc sec]
Focus              Real               ! Focus correction [mm]
Topology           Character(len=24) ! Topology for the overlapping azimuth range
2ndRotation        Real               ! Rotation angle for Secondary and Wobbler

EMIRcheck          Character          ! "strict"|"relaxed"|"loose"

doSubmit           Logical            ! turn submission of jobs to queue on or off
```

NB: Don't use / & < > in names of sources, lines, projects, PI, observer, operator, etc. Don't use ()/ in source names.

In order to include blank characters in a value of type Character, the complete value should be included in " ", see example: SET Observer below.

Only a few of these parameters are shown in the Display. Use command SHOW to list (nearly) all of them.

7.15.1 SET DOSUBMIT

SET DOSUBMIT YES|NO

Logical :: doSubmit

Turn submission of jobs to observing queue on or off. (compare command START).

IMPORTANT NOTE: to avoid any possible confusion, in each project account at the 30-m telescope, only 1 running instance of Pako should have SET DOSUBMIT YES!

7.15.2 SET FOCUS

SET FOCUS focus

Real :: focus ! focus correction [mm]

Set focus correction in [mm]

7.15.3 SET LEVEL

SET LEVEL minimalForStandardOut [minimalForFile]

Integer :: minimalForStandardOut ! in range 0 to 9

Integer :: minimalForFile ! in range 0 to 9

Set minimal "level" for paKo "messages" to be written
1: interactively to the standard output, i.e., the terminal window
2: to the message log file pako.mes.

All paKo "messages" have an associated severity number. With SET LEVEL we can select that only messages with severity higher than minimalForStandardOut (minimalForFile) are written. Very serious messages with severity 9 and higher can NOT be turned off.

The severity number for messages of kind:

I	is 1 or 2	Informational message
W	is 3 or 4	Warning message
E	is 5 or 6	Error message
F	is 7 or higher	Fatal Error message

Example: SET LEVEL 5 3

Has the effect that "I" messages are not shown at all, and only "E" and "F" messages are shown in the terminal window.

7.15.4 SET POINTING

```
SET POINTING azimuthCorrection [elevationCorrection]
```

```
Real :: azimuthCorrection    ! [arc sec]
```

```
Real :: elevationCorrection ! [arc sec]
```

Set pointing corrections in units of [arc sec]

* in place of a number: leave the value unchanged

Example:

```
SET POINTING 1.1 2.2
```

7.15.5 SET 2NDROTATION

```
SET 2ndRotation rotation
```

```
Real :: rotation                ! rotation angle [deg]
```

Set rotation angle for the secondary mirror and Wobbler mechanism [deg].

The angle is limited to be between -50 and +50 [deg].

NOTE: Its sense is opposite to the mathematical convention!

(this will be changed in a future release of the NCS.)

The rotation angle is relative to the horizontal system. A value of 0.0 corresponds to the Wobbler switching purely in Azimuth, i.e., "normal" Wobbler switching.

Observers must inform the operator if they want to use this feature.

A non-zero values is up to know only meaningful and supported for bolometer observations with Wobbler switching and the observing modes: POINTING, FOCUS, and OTFMAP. The OTF map must be set to be in the (true-angle) horizontal system and the direction of the OTF subscans must agree with that of the 2ndRotation. (There is a special pako script available in the bolometer pool to do this).

To avoid un-intentional errors, this feature can only be used by "privileged users": ask the AOD or the NCS team.

7.15.6 SET TOPOLOGY

```
SET TOPOLOGY topology
```

```
topology    Character(len=24) ! Topology for the overlapping azimuth range
```

Choices for topology are:

```
LOW HIGH
```

Select a "topology" for sources in the overlapping azimuth range 60 to 100 degrees = 420 to 460 degrees.

The 30m antenna has azimuth limits of 60 and 460 degrees. Azimuth 360 degrees is due North. Therefore there is an overlap range approximately toward East-Northeast, which the antenna can reach at a low azimuth 60 to 100 (from the South) or at a high azimuth 420 to 460 (from the North).

SET TOPOLOGY LOW selects to use the azimuth range 60 to 420 degrees
 SET TOPOLOGY HIGH selects to use the azimuth range 100 to 460 degrees

Note: this is shown in a figure in paKo's manual, Section "NCS Explained: Azimuth Topology".

7.15.7 SET EMIRCHECK

SET EMIRcheck emirCheck

emirCheck Character !

Choices for emirCheck are:

"strict"|"relaxed"|"loose"

Make the checking of frequency limits less than strict. This allows to command frequencies that are completely outside the designed and tested range of the receiver bands.

The standard and recommended limit checking corresponds to "strict".

THIS MUST BE USED CAREFULLY AND ONLY IN CONSULTATION WITH STAFF ASTRONOMERS OR ENGINEERS.

7.15.8 SET LIMITCHECK

SET LIMITCHECK limitCheck

limitCheck Character(len=24) !

Choices for limitCheck are:

"strict"|"relaxed"|"loose"

Make the checking of some limits less than strict.

The standard and recommended limit checking corresponds to "strict".

THIS MUST BE USED CAREFULLY AND ONLY IN CONSULTATION WITH STAFF
ASTRONOMERS OR ENGINEERS.

NB: this is a protected command (needs privilege).

7.15.9 SET USERLEVEL

```
SET USERLEVEL userLevel
```

```
userLevel Character(len=24) !
```

Choices for userLevel are:

```
"beginner"|"normal"|"experienced"
```

Sets level of user's experience with paKo and the NCS. Some features, that require special care, are only available if userLevel is set to a higher level.

7.15.10 SET EXAMPLES

```
!
! Id: demo-set.pako
!   basic SET EXAMPLES, v 1.1.1 2009-05-18 Hans Ungerechts
!
SIC PRIORITY 1 PAKO           ! PAKO commands get precedence
!                             ! over similar GREG commans!
!
SET Project    111-22          ! project ID (project number)
SET PI        "Dr. Lilo D. Doe" ! principal investigator
SET Observer   "John Doe"     !
SET Operator   Pako           !
SET Topology   low            ! topology for azimuth
!
SET Level      3 3            ! suppress informational message
!                             ! ("I-messages") from paKo
!
DEVICE image w                ! for plots
!
SHOW              ! show the values set with set
!
!! NOTE: don't use special characters like <, >, &, accents in the names!
!!
!
! Id: demo-set2.pako
!   additional SET EXAMPLES, v 1.1.1 2009-05-08 Hans Ungerechts
```

```

!
!! SET doSubmit   YES                ! to allow submission to Queue
!
SET Pointing     -1.1 2.2            ! pointing corrections
SET Focus        -2.3                ! focus correction      [mm]
!
SHOW             ! show the values set with set
!

```

7.16 SHOW

SHOW

List all parameters that can be set with command SET,
as well as their current values.

7.17 SOURCE

```

SOURCE sourceName
      [[systemName epoch] lambda beta
       [referenceFrame velocity  ] ]
SOURCE Body sourceName
      perihelionEpoch ascendingNode      argumentOfPerihelion
      inclination      perihelionDistance eccentricity

```

Select a source from the source catalog or specify source parameters
directly on command the line.

```

Character*12  :: sourceName          ! don't use: & < > ( ) /
Character     :: systemName          !
[C]Real       :: epoch               ! in units [years]
                                     ! NOTE: epoch should be J2000.0
Coordinate    :: lambda              ! longitude
Coordinate    :: beta               ! latitude
Character     :: referenceFrame      ! reference system for velocity
Real          :: velocity            ! in units [km/s]

```

IMPORTANT NOTES:

sourceName is limited to 12 characters.

So far only Equatorial J2000.0 coordinates are well tested.

<<TBD:

Observations of the Sun and near the Sun are not yet supported.

>>

NB: Don't use / & < > in names of sources, lines, projects, PI, observer, operator, etc. Don't use ()/ in source names.

IMPORTANT NOTE ON VELOCITY:

One should not use very large Doppler velocities (thousands of kilometers) to achieve red-shift corrections of frequencies. Instead one should enter the red-shifted frequencies in the line catalog (or with the RECEIVER command) and use Doppler velocity of 0.0.

The alternative approach (with very large Doppler velocities) needs special methods and attention in the data processing, which are **not** implemented in CLASS because it is better to observe in such a way that minimum modification to the data is done later on" (J. Pety). For a full discussion of this question see: Gordon et al. 1992, A&A, 264, 337 in Sect. 6

The second form accepts 6 Real arguments to specify the orbital elements of a solar system body:

```
Body                ! special keyword -- exactly like this!
Real                :: perihelionEpoch      ! Julian Date [d]
Real                :: ascendingNode        ! [deg]
Real                :: argumentOfPerihelion ! [deg]
Real                :: inclination          ! [deg]
Real                :: perihelionDistance   ! [deg]
Real                :: eccentricity         !
```

If only sourceName is specified, we try to read the other parameters from the source catalog specified with CATALOG SOURCE fileName. The sourceName in the command must match a source name in the source catalog with all characters (no minimum match), but the case is ignored for the matching. Example: SOURCE w3oh matches W3OH in the source catalog, but SOURCE w3o does not!

The option: /VELOCITY systemVelocity velocity overrides the values in the catalog.

Epoch can optionally start with a 1-character code "J" or "B" to distinguish between "J" and "B" epochs/ equatorial coordinates. (If this code letter is not present, "J" is implied!).

The coordinates are specified in astronomical sexagesimal format: with : as field separator, i.e.:

```
hh:mm:ss.ss
ddd:'':''.""
```

Examples:

```
12:34:56.78 for 12 hours, 34 minutes, 56.78 seconds
123:45:67.89 for 123 degrees, 45 arc minutes, 67.89 arc seconds
```

For systemName: equatorial and haDec, the longitude, lambda, is

assumed to be in hours; for all other systems it is assumed to be in degrees. Latitude, beta, is always in degrees.

Choices for `systemName`:

"equatorial"
"horizontal"

<<TBD: not yet supported: >>
<<TBD: "galactic" >>
<<TBD: "apparentEquatorial" >>
<<TBD: "ecliptic" >>
<<TBD: "apparentEcliptic" >>
<<TBD: "haDec " >>

Choices for `referenceFrame`:

"LSR"
"barycentric"
"heliocentric"

<<TBD: not yet supported: >>
<<TBD: "3K" >>
<<TBD: "galactocentric" >>
<<TBD: "body" >>
<<TBD: "geocentric" >>
<<TBD: "topocentric" >>
<<TBD: "null" >>

Planets' names are accepted as a special case, if `sourceName` is one of:

"Mercury"
"Venus"
"Mars"
"Jupiter"
"Saturn"
"Uranus"
"Neptune"
"Pluto"

Satellites' (moons') names are accepted, if `sourceName` is one of:

"Phobos"
"Deimos"
"Io"
"Europa"
"Ganymede"
"Callisto"
"Mimas"
"Enceladus"
"Tethys"
"Dione"
"Rhea"
"Titan"
"Hyperion"
"Iapetus"
"Miranda"
"Ariel"

```
"Umbriel"
"Titania"
"Oberon"
"Gabriel"
"Moon"
```

7.17.1 SOURCE /CATALOG

```
/CATALOG catalogName
/CATALOG *
```

Character :: catalogName

Allows to specify that the search (for a source) should be done in the catalog file "catalogName", instead of the catalog specified with command CATALOG. The default file extension is .sou

```
/CATALOG *
```

Implies that the search will be done in the standard pointing source catalog, iram-J2000.sou.

7.17.2 SOURCE /GREP

```
/GREP
```

Does a "grep" search for the (partial) source name or string in the source catalog and lists any matching lines. This search ignores the case. This is only to help the user search through a source catalog. Even if the match is unique, the source found is not selected. (re-enter the SOURCE command with the full source name!)

7.17.3 SOURCE /VELOCITY

```
/VELOCITY referenceFrame velocity
```

Specify reference frame and source radial velocity

```
Character :: referenceFrame    ! reference system for velocity
Real      :: velocity          ! in units [km/s]
```

Choices for referenceFrame:

```
"LSR"
"barycentric"
"heliocentric"
```

```
<<TBD: not yet supported: >>
<<TBD: "3K" >>
<<TBD: "galactocentric" >>
<<TBD: "body" >>
```

```
<<TBD: "geocentric"      >>
<<TBD: "topocentric"    >>
<<TBD: "null"           >>
```

IMPORTANT NOTE ON VELOCITY:

One should not use very large Doppler velocities (thousands of kilometers) to achieve red-shift corrections of frequencies. Instead one should enter the red-shifted frequencies in the line catalog (or with the RECEIVER command) and use Doppler velocity of 0.0.

The alternative approach (with very large Doppler velocities) needs special methods and attention in the data processing, which are **not** implemented in CLASS because it is better to observe in such a way that minimum modification to the data is done later on" (J. Pety). For a full discussion of this question see: Gordon et al. 1992, A&A, 264, 337 in Sect. 6

7.17.4 SOURCE EXAMPLES

```
!
! Id: demo-source.pako
!   basic SOURCE EXAMPLES,v 1.1.1 2009-05-08 by Hans Ungerechts
!
CATALOG SOURCE demo.sou           ! select source catalog
!
SOURCE NGC7027                    ! select source from catalog
!! OFFSETS /Clear                 ! optional: clear previously set off
!
PAUSE
!
!! OTHER WAYS TO SPECIFY A SOURCE:
!
SOURCE CALORI /catalog lines-J2000 ! select source from another catalog
PAUSE
!
SOURCE OCET EQ J2000 -
    02:19:20.71 -02:58:36.17 LSR 46.800 ! command-line specification of sour
PAUSE
!
SOURCE Mars                       ! planet Mars
PAUSE
!
SOURCE Moon                       ! our Moon
PAUSE
!
SOURCE Io                         ! Jupiter's satellite "Io"
PAUSE
!
SOURCE Body Pako -
    2455000.0 22.2 33.3 44.4 55.5 0.66 ! solar system body (orbital element
```



```

PAUSE
!
SOURCE w3oh                      ! will match W30H in demo.sou
!
!! NOTES: source names must match:
!!           full source name in catalog or
!!           full name of planet or satellite
!!           the case is ignored for source name matching
!
RETURN
!
```

7.18 START

START

Start an observation, i.e., translate its specification to XML and submit it to the observing queue.

Observing jobs are sent to the observing queue only if the observer has SET DOSUBMIT YES in paKo (see command SET DOSUBMIT) and if the operator has selected the current project to be the "current observing queue".

IMPORTANT NOTE: to avoid any possible confusion, in each project account at the 30-m telescope, only 1 running instance of Pako should have SET DOSUBMIT YES!

Example:

```

SOURCE ...
OTFMAP ...
START          ! will start and OTF map
```

7.19 SUBSCAN

```

SUBSCAN xOffset    yOffset
SUBSCAN xStart     yStart     xEnd       yEnd
SUBSCAN xAmplitude yAmplitude frequencyX frequencyY xCenter yCenter phiX phi
```

NB: this is a protected command (needs privilege).

Add to user-defined list of subscans and segments for observing mode "DIY"; compare command DIY. The subscan command has the 3 main variants above, depending on the number of parameters:

2 --> Track subscan with fixed offsets
 4 --> Linear OTF segment (subscan)
 8 --> Lissajous OTF segment (subscan), IMPORTANT: SEE NOTE BELOW

Option /TYPE allows to enforce that the command is interpreted for one the 3 different types, independant of the number of parameters.

Option /TUNE allows to specify that a Track subscan will be used to "tune" an instrument, e.g., NIKA.

```
Real :: xOffset      ! x offset fixed-position TRACK subscan
Real :: yOffset      ! y offset fixed-position TRACK subscan

Real :: xStart       ! x offset start   of linear OTF  segment
Real :: yStart       ! y offset start   of linear OTF  segment
Real :: xEnd         ! x offset end     of linear OTF  segment
Real :: yEnd         ! y offset end     of linear OTF  segment

Real :: xAmplitude   ! x amplitude           Lissajous OTF segment
Real :: yAmplitude   ! y amplitude           Lissajous OTF segment
Real :: frequencyX   ! frequency [Hz] for x Lissajous OTF segment
Real :: frequencyY   ! frequency [Hz] for y Lissajous OTF segment
Real :: xCenter      ! x center               Lissajous OTF segment
Real :: yCenter      ! y center               Lissajous OTF segment
Real :: phiX         ! phase offset [rad] for x Lissajous OTF segment
Real :: phiY         ! phase offset [rad] for y Lissajous OTF segment
```

If an asterisk * appears in place of any parameter, the value will remain unchanged from the last valid SUBSCAN command.

NOTES: pako will make its best effort to "guess" the values for unspecified parameters based on the values of its internal variables after the previous valid SUBSCAN command.

Each time a SUBSCAN is accepted without error message, a subscan is added to the list; even if the command is only "SUBSCAN" by itself! Be careful that a parameter in the command line can refer to different variables depending on the type of the segment/subscan, e.g., the 1st parameter can refer to xOffset, xStart, or xAmplitude.

These features should be used with special care, e.g., to experiment with the DIYLIST and SUBSCAN commands.

It is recommended to collect all SUBSCAN commands in a pako script and explicitly specify all parameters for each subscan!

Before START of a DIY subscanlist, you can enter DIYLIST to review pako's I-DIY messages listing the subscan currently defined (this requires SET LEVEL 2 or lower), e.g.:

```
PAKO> set level 2
PAKO> diy
I-DIY, segments #: 1 to 3
I-DIY, 1 track on at -400.0 -300.0 arcsec projection 10.0 s
I-DIY, 2 onTheFly -300.0 -200.0 to 330.0 220.0 arcsec projection 66.0 s
I-DIY, 3 track on at 440.0 330.0 arcsec projection 10.0 s
```

IMPORTANT: LISSAJOUS OTF

During a Lissajous OTF segment, the position offsets x and y as a function of time t are:

$$x = xCenter + xAmplitude * \sin(2 \text{ Pi frequencyX } t + \text{ phiX})$$

$$y = yCenter + yAmplitude * \sin(2 \text{ Pi frequencyY } t + \text{ phiY})$$

SIN is the usual sine function, Pi is the number Pi.

$xAmplitude$ $yAmplitude$ $xCenter$ $yCenter$ are in angle units ([arc sec])
 $frequencyX$ $frequencyY$ are in [Hz]
 $phiX$ $phiY$ are in [rad]

Note that the possible frequencies are very low, typically 0.01 to 0.15 Hz.

At the start of a Lissajous subscan, paKo will insert a "ramp" along a straight line, i.e., a linear OTF segment, increasing the count of segments by 2. This ramp up starts with speed 0 relative to the source and joins smoothly with the start position and velocity of the Lissajous segment. The purpose is to avoid a sudden acceleration at the start of the Lissajous segment. Command DIY lists this inserted OTF segment as well as the Lissajous segment. The inserted ramp up segment and the Lissajous segment become part of the same subscan.

Lissajous curves with large amplitudes or frequencies can reach the antenna's speed and acceleration limits for tracking. Lissajous curves can be executed only for elevations less than a maximum, which depends on the Lissajous parameters. For information, this elevation condition is shown by pako. Even below the limits, during very fast Lissajous curves the tracking errors will be higher, several arc sec, than during most other observations.

DO NOT TRY TO OBSERVE LISSAJOUS ABOVE THIS MAXIMUM ELEVATION.

7.19.1 SUBSCAN /CROFLAG

/CROFLAG croCode

Character :: croCode ! R = off-source Reference
 ! 0 = On-source

7.19.2 SUBSCAN /RAMP

/RAMP "None"
 /RAMP "Up" [tRampUp]
 <<TBD: /RAMP "Down" [tRampDown] ! not yet implemented >>

Real :: tRamp ! minimal time for ramp

/RAMP Up tRamp

/RAMP Up must be used for Lissajous subscans.

At the start of a Lissajous subscan, paKo will insert a "ramp" along a straight line, i.e., a linear OTF segment, increasing the count of segments by 2. This ramp up starts with speed 0 relative to the source and joins smoothly with the start position and velocity of the Lissajous segment. The purpose is to avoid a sudden acceleration at the start of the Lissajous segment. Command DIY lists this inserted OTF segment as well as the Lissajous segment. The inserted ramp up segment and the Lissajous segment become part of the same subscan.

Example:

SUBSCAN 100 200 0.01 0.02 -10 -20 0.1 0.2 /ramp up 9

Lissajous subscan with a ramp up of at least 9 [sec].

7.19.3 SUBSCAN /SYSTEM

/SYSTEM systemName

Name of system for offsets.

Character :: systemName ! name of system, one of:
 ! PROJECTION
 ! TRUEHORIZON

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset. This is the system in which OTF maps with Wobbler switching and the bolometer are normally done.

7.19.4 SUBSCAN /TOTF

/TOTF t0tf

time per OTF subscan or segment

Real :: t0tf ! time

In commands like OTFMAP that have options /SPEED and /TOTF, either option /SPEED or /TOTF can be used, the values of the other option are then implied!

NOTE: this applies to linear and Lissajous OTF subscan segments

7.19.5 SUBSCAN /TSUBSCAN

/TSUBSCAN tSubscan

time per subscan

Real :: tSubscan ! time

NOTE: this applies to Track subscans

7.19.6 SUBSCAN /TUNE

/TUNE [yes|no]

Logical :: doTune

"Tune" an instrument, e.g., NIKA.

NOTE: this applies to Track subscans. If a valid specification of a TRACK subscan is entered without the option /TUNE, "no" is implied.

7.19.7 SUBSCAN /TYPE

/TYPE Type

Specify segment or subscan type.

Character :: Type ! one of:
 ! TRACK
 ! LINEAR
 ! LISSAJOUS

7.20 SWBEAM

SWBEAM (no parameters)

Select beam switching, i.e., switching between 2 positions on the sky using the rotating beam-switch chopper wheel. This mode is usually

only used for POINTING and FOCUS with the heterodyne receivers.

7.21 SWFREQUENCY

SWFREQUENCY fOffset1 [fOffset2]

Select and set up frequency switching (FS).

```
Real      :: fOffset1      ! 1st frequency offset [MHz]
Real      :: fOffset2      ! 2nd frequency offset [MHz]
```

fOffset2 should be set to be = -fOffset1 (symmetric FS).
This is done by default, if only fOffset1 is specified.
(Note that then $\text{ABS}(f\text{Offset1}) = \text{FS amplitude} = 1/2 \text{ FS throw}$).
FS with fOffset2 not equal -fOffset1 is experimental.

/RECEIVER allows to set fOffset1 and fOffset2 for each connected receiver differently.

Parameters of other options are always the same for all receivers.

Limits for fOffset1 and fOffset2 are:

```
-9 to +9   with the 3 mm receivers /bands
-18 to +18 with the 2 mm receivers /bands
-27 to +27 with the 1 mm receivers /bands
```

IMPORTANT NOTES about use of Frequency Switching (FS)

Frequency Switching (FS) can be very powerful and efficient for some projects, e. g., mapping of narrow spectral lines in cold dark clouds outside the plane of the Milky Way. However, before deciding to use frequency switching one should consider some potential drawbacks:

The target lines should be narrow enough so that line signals from the 2 phases of the switching cycle are well separated.

The spectral baseline will generally be less flat than in other switching modes.

Some spectral lines are also emitted in the earth's mesosphere, e.g., the mesospheric lines from (12)CO are rather strong, typically several [K], and they will be seen in FS spectra taken toward astronomical sources with a low Doppler shift. The mesospheric lines will appear at a frequency and velocity that correspond to the rest frame of the atmosphere, i. e., to good approximation, the observatory. If, e. g., you observe using Doppler corrections for the LSR scale, the mesospheric lines will appear in the spectra at $-1 * \text{the velocity of the Local Standard of Rest relative to the observatory}$.

Care must be taken that mesospheric lines are not confused with the lines from the astronomical source, which will appear in the spectrum at the velocity of the source relative to the LSR. The ASTRO software can calculate the velocity of the LSR relative to the observatory for any source and time. During observations, this velocity is also displayed on one of the NCS monitoring windows.

When observing sources near the plane of the Milky Way, line emission from clouds at other velocities than the target source, e. g., other spiral arms, can cause confusion.

In case of any doubt, there is a special report on FS that gives more advice!

7.21.1 SWFREQUENCY /DEFAULTS

```
/DEFAULTS [yes|no]
```

Restore default values for all parameters and options.

7.21.2 SWFREQUENCY /RECEIVER

```
/RECEIVER receiverBand
```

```
Character :: receiverBand ! receiver / EMIR band
```

Choices for receiverBand are:
E090 E150 E230 E330 HERA1 HERA2

7.21.3 SWFREQUENCY /TPHASE

```
/TPHASE tPhase
```

time per switching PHASE

```
Real      :: tPhase      ! time
```

7.21.4 SWFREQUENCY EXAMPLES

```
!
! SWFREQUENCY EXAMPLES, v1.1 2009-05-11 Hans Ungerechts
!
SWFREQUENCY          /default      ! Defaults
!
SWFREQUENCY  -3.8    3.8            ! for all receiver bands
!
SWFREQUENCY  -3.9    3.9 /receiver E090 ! for EMIR band E090
SWFREQUENCY -11.7   11.7 /receiver E230 ! for EMIR band E230
SWFREQUENCY          /tphase  0.20 ! same for all receivers/bands
```

```

!
!
SWFREQUENCY  -3.7          /receiver E090 ! setup frequency switching
SWFREQUENCY  -11.6         /receiver E230 ! fOffset2 will be  +3.7
!
!

```

7.22 SWTOTAL

SWTOTAL (no parameters)

Select total power, i.e., neither beam, frequency, nor wobbler switching. Typically used with OTFMAP with off-source references or ONOFF "position switching".

7.22.1 SWTOTAL /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.22.2 SWTOTAL /TPHASE

/TPHASE tPhase

time per switching PHASE

Real :: tPhase ! time

7.23 SWWOBBLER

SWWOBBLER wOffset1 [wOffset2]

Select and set up wobbler switching using the wobbling secondary mirror to switch between 2 positions on the sky. This is typically used with the observing modes POINTING, FOCUS, ONOFF, or --with the bolometer-- OTFMAP.

Real :: wOffset1 ! 1st wobbler offset (1/2 "throw")
Real :: wOffset2 ! 2nd wobbler offset = -wOffset1

IMPORTANT NOTE: Observers must inform the operator if they want to use this feature.

There is a relation between the maximum allowed Wobbler throw and the minimum time per phase: for large throws the switching must be slow, i.e., time per phase must be large. For /timePhase 1 [sec] or longer, any wobbler throw is allowed up to the maximum of 240 ["].

Possible combinations are, e. g.:

wOffset1	throw	timePhase
-22"	44"	0.25 sec
-22"	44"	1.0 sec
-120"	240"	1.0 sec
-120"	240"	2.0 sec

Note that for OTFMAPs with Wobbler switching, special restoration algorithms are needed to recover an image of the source brightness distribution. These are available, e. g., in the MOPSIC software.

If SWWOBBLER and ONOFF are combined in the standard way, we effectively take data at 3 positions:

1. the source position
2. the source position + throw (offset in the "true-angle" horizontal system)
3. the source position - throw (offset in the "true-angle" horizontal system)

with $\text{throw} = \text{ABS}(\text{wOffset2} - \text{wOffset1})$.

Data from 1. are treated as source signal, data from 2 and 3 as off-source reference signal. Note that in the astronomical coordinates, positions 2 and 3 will rotate around the source position (1). Therefore one must normally be sure that the extent of the source is less than $\text{throw} - \text{beamWidth} / 2$.

7.23.1 SWWOBBLER /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.23.2 SWWOBBLER /TPHASE

/TPHASE tPhase

time per switching PHASE

Real :: tPhase ! time

7.24 TIP

TIP [azimuth]

Specify an antenna tipping (a.k.a., "skydip").

Real :: azimuth ! azimuth of tip

If azimuth is not specified, the current azimuth of the telescope is used.

NOTE:

TIP is always and automatically done with switching mode "total power" and for bolometer observations the time per phase is fixed at 0.5 [sec]

7.24.1 TIP /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.24.2 TIP /AIRMASS

/AIRMASS airmassStart [TO] airmassEnd [BY] airmassStep

range of airmass for TIP.

Real :: airmassStart !

Real :: airmassEnd !

Real :: airmassStep !

NOTE 1: elevation = ASIN(1/airmass)

NOTE 2: for slew-tips, TIP /SLEW:

airmassStep has no effect

airmassStart > airmassEnd is allowed; this implies:

elevation (at start) < elevation (at end), i.e.,

TIP from low to high elevation.

(for "traditional" TIP with /SLEW no, airmassStart < airmassEnd, i.e., they go from high to low elevation.)

7.24.3 TIP /TSUBSCAN

/TSUBSCAN tSubscan

time per subscan

```
Real      :: tSubscan      ! time
```

7.25 TRACK

```
TRACK xOffset yOffset
```

specify tracking of a single position

```
Real      :: xOffset      ! x-offset of "on-source" position
Real      :: yOffset      ! y-offset of "on-source" position
```

NOTES:

TRACK is normally used for observations with frequency switching (SWFREQUENCY); also for some special observations, e.g., of pulsars. There is a built-in limit to the time per subscan, currently (2006-07) it is 3600 seconds (1 hour). If for special purposes one needs to track a source for a longer time, this can easily be done by using several subscans.

7.25.1 TRACK /DEFAULTS

```
/DEFAULTS [yes|no]
```

Restore default values for all parameters and options.

7.25.2 TRACK /SYSTEM

```
/SYSTEM systemName
```

Name of system for offsets.

```
Character :: systemName      ! name of system, one of:
                              ! PROJECTION
                              ! TRUEHORIZON
                              ! NASMYTH

<<TBD:                        ! DESCRIPTIVE>>
<<TBD:                        ! BASIS>>
<<TBD:                        ! EQUATORIAL>>
<<TBD:                        ! HADECL>>
<<TBD:                        ! HORIZONTAL>>
```

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing, focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

```
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM projection,
OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM trueHorizon,
OFFSETS ... /SYSTEM trueHorizon is ignored (not used).
```

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

```
If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako,
the values xOffset yOffset are used during the observations.
(this includes the case that they are explicitly set to 0.0).
It is up to the observer to make sure that they are "correct".
(in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)
```

```
If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified
(cleared), for the MAMBO bolometer, Nasmyth offsets are used
automatically according to the selected bolometer channel (pixel).
```

7.25.3 TRACK /NSUBSCANS

```
/NSUBSCANS nSubscans
```

```
Integer    :: nSubscans          ! number of subscans
```

7.25.4 TRACK /TSUBSCAN

```
/TSUBSCAN tSubscan
```

```
time per subscan
```

```
Real       :: tSubscan          ! time
```

7.25.5 TRACK EXAMPLES

```
!
! Id: demo-track.pako
```

```

! TRACK EXAMPLE,v 1.1.11 2011-11-25 Hans Ungerechts
!
@ demo-rx ! demo setup of receivers
!
BACKEND /CLEAR ! clear previous backends
BACKEND VESPA 1 0.040 40.0 0.0 E090 hor LI ! high spectral resolution
BACKEND VESPA 2 0.040 40.0 0.0 E090 ver LI ! with VESPA
BACKEND VESPA 3 0.080 80.0 0.0 E230 hor LI
BACKEND VESPA 4 0.080 80.0 0.0 E230 ver LI
! ! REPLACE WITH YOUR SETUP!
!
SET ANGLE arcsec !
!
! ! setup frequency switching
SWFREQUENCY -3.9 3.9 /receiver E090 ! for EMIR band E090
SWFREQUENCY -11.7 11.7 /receiver E230 ! for EMIR band E230
SWFREQUENCY /tphase 0.20 ! same for all receivers/bands
!
CALIBRATE - !
 /AMBIENT - ! ambient load
 /COLD - ! cold load
 /SKY -600.0 0.0 - ! sky at offsets -600.0 0.0
 /SYSTEM projection - ! system for SKY offsets
 /TCALIBRATE 5.0 ! time per calibration subscan
!
PAUSE "CALIBRATE OK to start? [c/q]" ! a chance to check
!
START ! start
!
TRACK 40.0 -30.0 - ! offsets of on position
 /NSUBSCANS 5 - ! number of subscans
 /SYSTEM projection - ! system for offset
 /TSUBSCAN 60 ! time per subscan
!
PAUSE "TRACK SWFREQUENCY OK to start? [c/q]" ! a chance to check
!
START ! start
!
!! Comments:
!! we assume here that the source already has been selected,
!! see: demo-source

```

7.26 VLBI

VLBI

Track a single position for VLBI.

This observing mode must not be used for other (non-VLBI) observations.

Some special behaviours are associated with the observing mode VLBI:

- The scan has only one subscan on the (fixed) source position.

- This subscan will be executed for up to 1 hour.

In practice it is ended, when the START command is executed for the next observation, e.g., when a new VLBI scan, or a POINTING or FOCUS is started.

- Normally, the VLBI field system sends the commands

SOURCE ...

VLBI

START

directly to paKo, which is running in a special terminal window. The field system sends these commands for the next scan (immediately) after the VLBI data recording for the current VLBI target source (for the currant scan) is finished.

7.27 OPTIONS

SUMMARY OF OPTIONS FOR PAKO\ COMMANDS:

(For help on commands say HELP PAKO\)

For details say, e.g., HELP OPTIONS /CROLOOP

or: HELP OP /CRO

To see if a command has a particular option, see the end of the HELP for this command.

7.27.1 OPTIONS /AIRMASS

/AIRMASS airmassStart [TO] airmassEnd [BY] airmassStep

range of airmass for TIP.

Real :: airmassStart !

Real :: airmassEnd !

Real :: airmassStep !

NOTE 1: elevation = ASIN(1/airmass)

NOTE 2: for slew-tips, TIP /SLEW:

airmassStep has no effect

airmassStart > airmassEnd is allowed; this implies:

elevation (at start) < elevation (at end), i.e.,

TIP from low to high elevation.

(for "traditional" TIP with /SLEW no, airmassStart < airmassEnd, i.e., they go from high to low elevation.)

7.27.2 OPTIONS /AMBIENT

/AMBIENT [yes|no]

Do a calibration subscan on the ambient temperature load.

Logical :: doAmbient ! default: true

7.27.3 OPTIONS /APPEND

/APPEND [yes|no]

Append to existing file, do not create a new one.

Logical :: doAppend ! default: false

7.27.4 OPTIONS /CLEAR

/CLEAR [yes|no]

Completely clear a list of connected hardware, e.g., receivers, backends, or parameters of the associated command.

7.27.5 OPTIONS /COLD

/COLD [yes|no]

Do a calibration subscan on the cold temperature load.

Logical :: doCold ! default: true

7.27.6 OPTIONS /CONNECT

/CONNECT [yes|no]

connect (or disconnect) the specified hardware, e.g., backend or backend part.

7.27.7 OPTIONS /CROLOOP

/CROLOOP croLoop

sequence of R = off-source Reference
0 = On-source subscans

Character :: croLoop

Example:
/croLoop R00R

7.27.8 OPTIONS /DEFAULTS

/DEFAULTS [yes|no]

Restore default values for all parameters and options.

7.27.9 OPTIONS /DEROTATOR

/DEROTATOR angle system

Specify derotator angle for HERA

Real :: angle ! in units [deg] (!)
Character :: system !

Choices for system:

"Nasmyth"
"horizon"
"equatorial"
"frame" ! same as Nasmyth
"sky" ! same as equatorial

NOTES: The last 2 are for consistency with old control system and HERA conve
This option works only for RECEIVER HERA1 or RECEIVER HERA2 (of course it's
same angle for HERA1 and HERA2).

7.27.10 OPTIONS /DISCONNECT

/DISCONNECT

disconnect the specified hardware, e.g.,
backend or backend part.

7.27.11 OPTIONS /DOPPLER

/DOPPLER doppler

Character :: doppler ! apply doppler correction?
 ! choices: DOPPLER|FIXED

7.27.12 OPTIONS /DOUBLEBEAM

/DOUBLEBEAM [yes|no]

Pointing: do a "double-beam" pointing

Logical :: doDoubleBeam

This is valid only for pointing with Wobbler switching (SWWOBLER).

This option has an effect only if SET 2nRotation 0.0

7.27.13 OPTIONS /EFFICIENCY

/EFFICIENCY forwardEfficiency beamEfficiency

specify forward and beam efficiencies

Real :: forwardEfficiency !

Real :: beamEfficiency !

7.27.14 OPTIONS /FILE

/FILE fileName

Specify file name.

Character :: fileName !

7.27.15 OPTIONS /FINE

/FINE

for BACKEND FTS select the "fine" mode with a resolution of ~ 0.049 [MHz]

Note: with the option /DEFAULT or the short syntax, this allows to select the fine resolution without explicitly entering the values of resolution and bandwidth.

7.27.16 OPTIONS /GAINIMAGE

/GAINIMAGE gainImage [dB]

Specify the gain ratio of image to signal sidebands.

Real :: gainImage !

If "dB" is added after the value, the ratio is assumed to be in dB, otherwise a decimal fraction.

Simple standard values for these gain ratios can be found on the IRAM 30-m web pages (Telescope Summary). If you need accurate values for the single-pixel heterodyne receivers, you should measure them with:
CALIBRATE /GAINIMAGE receiverName

7.27.17 OPTIONS /GREGP

/GREGP

Does a "grep" search for the (partial) source name or string in the source catalog and lists any matching lines. This search ignores the case. This is only to help the user search through a source catalog. Even if the match is unique, the source found is not selected. (re-enter the SOURCE command with the full source name!)

7.27.18 OPTIONS /GRID

/GRID [yes|no]

Do a calibration subscan on a grid in front of the cold temperature load. This is a special calibration option for polarization observations.

Logical :: doGrid ! default: true

IMPORTANT NOTE:

remember to turn this option off again for normal calibrations:
e.g., CALIBRATE /GRID NO or CALIBRATE /DEFAULT.

7.27.19 OPTIONS /HORIZONTAL

/HORIZONTAL [sb1 [sb2]]

/HORIZONTAL n[one]

EMIR subbands for Horizontal polarization.

This option applies only to EMIR.

Character :: sb1, sb2 ! for EMIR: LO|LI|UI|UO

This option selects which EMIR subband(s) of this polarization will be transmitted through IF cables 1 to 4. Note that some backends, NBC, 4MHz, WILMA, VESPA, can only be connected to IF cables 1 to 4, i.e., only to the EMIR subbands selected with the RECEIVER command.

For each EMIR band and polarization, at most 2 subbands can be transmitted through IF cables 1 to 4. Which combinations of EMIR bands, polarizations, and subbands are possible is determined by the hardware of the EMIR IF switching box. See the EMIR documentation for details.

If no subband is explicitly specified with this option, paKo will assume that for this polarization the same single subband SB is requested as specified for the main parameters (frequency, tuning) of the RECEIVER command for this EMIR band.

/HORIZONTAL n[one] means that from this polarization no subband

will be transported through IF cables 1 to 4.

7.27.20 OPTIONS /MODE

/MODE mode

Character :: mode ! backend mode

Choices for mode are:

SIMPLE ! simple (standard)

PARALLEL ! parallel mode

POLARIZATION ! polarimetry

Select special mode for VESPA.
See VESPA user's guide for details.

For EMIR, /MODE PARALLEL or /MODE POLARIZATION connect VESPA to the same band and subband in both polarizations; they must previously have been selected with the RECEIVER command. For examples, see:

HELP BACKEND Examples

7.27.21 OPTIONS /NOTF

/NOTF n0tf

Integer :: n0tf ! number of OTF (on-the-fly) subscans

7.27.22 OPTIONS /NSUBSCANS

/NSUBSCANS nSubscans

Integer :: nSubscans ! number of subscans

7.27.23 OPTIONS /PERCENTAGE

/PERCENTAGE percentage

Real :: percentage ! percentage of bandwidth to use

This is a special option for the autocorrelators, VESPA and WILMA.

For autocorrelators normally some channels at both ends of the band are blanked because they do not contain usable data, and only the central 'percentage' of the "theoretical" bandwidth is used, typically about 90%. Reasonable conservative defaults are automatically applied: in general 90%, but 82% for VESPA with bandwidth 640. This option allows the observer to adjust the percentage for special purposes.

For WILMA connected to EMIR, the useful bandwidth is 3720 MHz, and counted as 100%.

See VESPA user's guide for details.

7.27.24 OPTIONS /RECEIVER

/RECEIVER receiverBand

Character :: receiverBand ! receiver / EMIR band

Choices for receiverBand are:

E090 E150 E230 E330 HERA1 HERA2

7.27.25 OPTIONS /REFERENCE

/REFERENCE xOffsetR yOffsetR [systemNameRef]

or

/REFERENCE NO ! no reference

position of off-source reference subscans

Real :: xOffsetR ! x-offset

Real :: yOffsetR ! y-offset

Character :: systemNameRef ! name of system

! see /SYSTEM for choices

NOTE: with the usage /REFERENCE xOffsetR yOffsetR, both parameters are required but you can replace either parameter with * to leave it unchanged.

7.27.26 OPTIONS /SCALE

/SCALE scale

Select the calibration intensity scale.

Character :: scale ! choices: ANTENNA|BEAM

If scale is "ANTENNA", the scale is antenna temperature.

If scale is "BEAM", the scale is (main) beam temperature.

7.27.27 OPTIONS /SKY

/SKY xOffsetC yOffsetC

or

/SKY NO ! do not do sky calibration

Do a calibration subscan on sky.

```
Real      :: xOffsetC      ! x-offset
Real      :: yOffsetC      ! y-offset
```

NOTES: with the usage /SKY xOffsetC yOffsetC, both parameters are required, but you can replace either parameter with * to leave it unchanged. The system for the offsets is selected through the option /SYSTEM.

7.27.28 OPTIONS /SPEED

```
/SPEED speed1 [speed2]
```

speed of OTF subscans

```
Real      :: speed1        ! speed at start
Real      :: speed2        ! speed at end
```

For OTFMAP speed2 = speed1.

In commands like OTFMAP that have options /SPEED and /TOTF, either option /SPEED or /TOTF can be used, the values of the other option are then implied!

7.27.29 OPTIONS /STEP

```
/STEP dx dy
```

Step (shift or translation) between lines in a map.

```
Real      :: dx            ! shift in x-offsets
Real      :: dy            ! shift in y-offsets
```

7.27.30 OPTIONS /SWWOBBLER

```
/SWWOBBLER [yes|no]
```

(option of command ONOFF)

set parameters appropriate for on-off Wobbler switching

```
Logical   :: doSwWobbler
```

If switching mode SWWOBBLER has been selected, the following parameters of ONOFF are set according to wOffset1 and wOffset2:

```
ONOFF
  xOffset      is set to: -wOffset1
  yOffset      is set to:  0.0
```

```
/REFERENCE      is set to:  Yes
  xOffsetR      is set to: -wOffset2
  yOffsetR      is set to:  0.0
```

systemNameRef is set to: TRUEHORIZON

/SYSTEM

systemName is set to: TRUEHORIZON

NOTE: in this case the values selected by /SWWOBBLER overrule the corresponding values specified directly in the command.

NOTE: To do ONOFF with Wobbler switching and other (unconventional) values for the parameters listed above, simply specify the values using command ONOFF with option /SWWOBBLER NO (not recommended).

NOTE: If the selected switching mode is SWWOBBLER and if the option /SWWOBBLER is no explicitly given, it will be assumed to be .True. (Yes), If the selected switching mode is not SWWOBBLER and if the option /SWWOBBLER is no explicitly given, it will be assumed to be .False. (No),

7.27.31 OPTIONS /SYMMETRIC

/SYMMETRIC [yes|no]

Logical :: doSymmetric ! default: no

(For ONOFF) select a subscan sequence that is "symmetric" in time. This requires that the number of subscans is a multiple of 4.

Example for ONOFF with	/SYMMETRIC no	/SYMMETRIC yes
1st subscan:	OFF	OFF
2nd "	ON	ON
3rd "	OFF	ON
4th "	ON	OFF
(and so on)		

NOTE that this does not in anyway change the positions of the ON-source and OFF-source subscans!

7.27.32 OPTIONS /SYSTEM

/SYSTEM systemName

Name of system for offsets.

Character :: systemName ! name of system, one of:
! PROJECTION
! TRUEHORIZON
! NASMYTH

<<TBD: ! DESCRIPTIVE>>
<<TBD: ! BASIS>>
<<TBD: ! EQUATORIAL>>
<<TBD: ! HADECL>>
<<TBD: ! HORIZONTAL>>

PROJECTION for now means only the standard simple "radio" projection offsets in the chosen coordinate system. This is normally the astronomical system of offsets in which point-by-point (TRACK, ONOFF) or on-the-fly (OTFMAP) maps are made.

TRUEHORIZON means the horizontal system with a factor $1/\cos(\text{elevation})$ applied to the azimuth offset.

NASMYTH are special offsets to point an off-center pixel of a focal-plane array receiver (bolometer, HERA) to the commanded astronomical position, e.g., to use an off-center pixel for pointing, focus, ONOFF.

IMPORTANT NOTE: projection, trueHorizon

```
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM projection,
OFFSETS ... /SYSTEM projection is ignored (not used).
If the observing mode (LISSAJOUS, ONOFF, OTFMAP, ...)
is in /SYSTEM trueHorizon,
OFFSETS ... /SYSTEM trueHorizon is ignored (not used).
```

IMPORTANT NOTE: OFFSETS /SYSTEM Nasmyth

```
If OFFSETS xOffset yOffset /SYSTEM Nasmyth are specified in pako,
the values xOffset yOffset are used during the observations.
(this includes the case that they are explicitly set to 0.0).
It is up to the observer to make sure that they are "correct".
(in pakoDisplay /SYS Nasmyth will be highlighted as yellow alert.)
```

```
If OFFSETS xOffset yOffset /SYSTEM Nasmyth are not specified
(cleared), for the MAMBO bolometer, Nasmyth offsets are used
automatically according to the selected bolometer channel (pixel).
```

7.27.33 OPTIONS /TCALIBRATE

```
/TCALIBRATE tCalibrate
```

Time per CALIBRATE subscan.

```
Real      :: tCalibrate      ! time
```

7.27.34 OPTIONS /TOTF

```
/TOTF t0tf
```

time per OTF subscan or segment

```
Real      :: t0tf           ! time
```

In commands like OTFMAP that have options /SPEED and /TOTF, either option /SPEED or /TOTF can be used, the values of the other option are then implied!

7.27.35 OPTIONS /TPHASE

/TPHASE tPhase

time per switching PHASE

Real :: tPhase ! time

7.27.36 OPTIONS /TREFERENCE

/TREFERENCE tReference

time per off-source reference

Real :: tReference ! time

7.27.37 OPTIONS /TSUBSCAN

/TSUBSCAN tSubscan

time per subscan

Real :: tSubscan ! time

7.27.38 OPTIONS /TEMPLOAD

/TEMPLOAD tempColdLoad tempAmbientLoad

/TEMPLOAD L[OOKUP] L[OOKUP]

/TEMPLOAD * ...

Set effective temperatures for the calibration loads at cold and ambient temperature.

Real :: tempColdLoad !

Real :: tempAmbientLoad !

NEW LOGIC FOR SINGLE-PIXEL SIS RECEIVERS (FROM SUMMER 2007, paKo v1.0.7)

If a numerical value is entered for tempColdLoad or tempAmbientLoad, that value is used for calibration calculations.

Instead of specifying a value one may enter the string L(OOKUP) for tempColdLoad and/or tempAmbientLoad. This is shown in the pakoDisplay by the letter "L" instead of a number.

In this case, during the execution of the observations, the NCS will

use the "best-known" values for the corresponding load temperature(s). For tempColdLoad this is based on a lookup table, for tempAmbientLoad it is derived from a measurement of the physical temperature.

The lookup table for tempColdLoad normally is valid for the standard calibration system with a closed-cycle cooling system.

A * can be substituted for tempColdLoad, which means to leave the value for tempColdLoad unchanged from the previous RECEIVER command.

IF THE OBSERVERS HAVE ANY DOUBT ABOUT THIS, THEY SHOULD ASK A RECEIVER ENGINEER FOR THE CORRECT VALUE AND ENTER IT EXPLICITLY.

NOTE: FOR HERA The new logic is not yet available. However, for HERA "best-known" values are always used during the execution of the observations. This is the same logic as in previous versions of paKo/NCS.

7.27.39 OPTIONS /VELOCITY

/VELOCITY referenceFrame velocity

Specify reference frame and source radial velocity

Character :: referenceFrame ! reference system for velocity
Real :: velocity ! in units [km/s]

Choices for referenceFrame:

"LSR"
"barycentric"
"heliocentric"

<<TBD: not yet supported: >>
<<TBD: "3K" >>
<<TBD: "galactocentric" >>
<<TBD: "body" >>
<<TBD: "geocentric" >>
<<TBD: "topocentric" >>
<<TBD: "null" >>

IMPORTANT NOTE ON VELOCITY:

One should not use very large Doppler velocities (thousands of kilometers) to achieve red-shift corrections of frequencies. Instead one should enter the red-shifted frequencies in the line catalog (or with the RECEIVER command) and use Doppler velocity of 0.0.

The alternative approach (with very large Doppler velocities) needs special methods and attention in the data processing, which are *"not"* implemented in CLASS because it is better to observe in such a way that minimum modification to the data is done later on" (J. Pety). For a full discussion of this question see: Gordon et al. 1992, A&A,

264, 337 in Sect. 6

7.27.40 OPTIONS /VERTICAL

```
/VERTICAL [sb1 [sb2]]
/VERTICAL n[one]
```

EMIR subbands for Vertical polarization

This option applies only to EMIR.

Character :: sb1, sb2 ! for EMIR: LO|LI|UI|UO

This option selects which EMIR subband(s) of this polarization will be transmitted through IF cables 1 to 4. Note that some backends, NBC, 4MHz, WILMA, VESPA, can only be connected to IF cables 1 to 4, i.e., only to the EMIR subbands selected with the RECEIVER command.

For each EMIR band and polarization, at most 2 subbands can be transmitted through IF cables 1 to 4. Which combinations of EMIR bands, polarizations, and subbands are possible is determined by the hardware of the EMIR IF switching box. See the EMIR documentation for details.

If no subband is explicitly specified with this option, paKo will assume that for this polarization the same single subband SB is requested as specified for the main parameters (frequency, tuning) of the RECEIVER command for this EMIR band.

/VERTICAL n[one] means that from this polarization no subband will be transported through IF cables 1 to 4.

7.27.41 OPTIONS /WIDTH

```
/WIDTH width
```

Select receiver setup for WIDE or NARROW bandwidth mode.

Character :: width ! width. choices: WIDE|NARROW

NOTE: Option /WIDTH NARROW changes the (local oscillator) setup of receivers HERA1 and HERA2 in such a way that a line in the center of the receiver bandwidth appears in the center of the bands of the Backends 1MHz (with 256 or 512 MHz bandwidth) and VESPA.

Spectrometers with 1GHz bandwidth normally require /WIDTH WIDE.

7.27.42 OPTIONS /ZIGZAG

/ZIGZAG [yes|no]

alternate direction between lines in a map

Logical :: doZigzag

8 Postscript

*“You will certainly not doubt the necessity of studying astronomy and physics,
if you are desirous of comprehending the relation between the world and Providence as it is in reality,
and not according to imagination.”*

*“You must, however, not expect that everything our Sages say
respecting astronomical matters should agree with observation.”*

*“Astronomy had, in the days of Aristotle,
not yet developed to the height it has reached at present.”*

Moses Maimonides — Moses ben Maimun — Abu Amran Musa
Cordoba, 1135—Cairo, 1204

From the Arabic “*Dalalat al’Haírîn*”,
translated into Hebrew as “*Moreh Nebûkim*” (1204),
and into Latin as “*Doctor Perplexorum*”, “*Dux Dubitantium*”.
French translation entitled “*Guide des égarés*” (Paris, 1856-66).
Here quoted from the English translation “*The Guide of the Perplexed*” (London, 1889).

Index

- BACKEND, 95
 - /CLEAR, 99
 - /CONNECT, 100
 - /DEFAULTS, 99
 - /DISCONNECT, 100
 - /FINE, 100
 - /LINENAME, 101
 - /MODE, 100
 - /PERCENTAGE, 101
 - /RECEIVER, 102
- BBC, 97
- EXAMPLES, 102
- FTS, 97

- CALIBRATE, 105
 - /AMBIENT, 106
 - /COLD, 106
 - /DEFAULTS, 106
 - /GAINIMAGE, 106
 - /GRID, 106
 - /SKY, 107
 - /SYSTEM, 107
 - /TCALIBRATE, 108
- CATALOG, 108
 - LINE, 109
 - SOURCE, 109

- DISPLAY, 110
- DIYLIST, 110
 - /CLEAR, 110
 - /PURPOSE, 110

- FOCUS, 111
 - /DEFAULTS, 111
 - /NSUBSCANS, 111
 - /TSUBSCAN, 112
- EXAMPLES, 112

- Language, 91
 - HELP, 94
 - NEWS, 92
- LISSAJOUS, 112
 - /CENTER, 113
 - /FREQUENCY, 114
 - /PHASES, 114
 - /SYSTEM, 114
 - /TOTF, 115

- OFFSETS, 115
 - /CLEAR, 117
 - /DEFAULTS, 117
 - /SYSTEM, 117

- ONOFF, 118
 - /DEFAULTS, 120
 - /NSUBSCANS, 120
 - /REFERENCE, 120
 - /SWWOBBLER, 120
 - /SYMMETRIC, 121
 - /SYSTEM, 122
 - /TSUBSCAN, 123
- EXAMPLES, 123

- OPTIONS, 166
 - /AIRMASS, 166
 - /AMBIENT, 167
 - /APPEND, 167
 - /CLEAR, 167
 - /COLD, 167
 - /CONNECT, 167
 - /CROLOOP, 167
 - /DEFAULTS, 168
 - /DEROTATOR, 168
 - /DISCONNECT, 168
 - /DOPPLER, 168
 - /DOUBLEBEAM, 168
 - /EFFICIENCY, 169
 - /FILE, 169
 - /FINE, 169
 - /GAINIMAGE, 169
 - /GREP, 170
 - /GRID, 170
 - /HORIZONTAL, 170
 - /MODE, 171
 - /NOTF, 171
 - /NSUBSCANS, 171
 - /PERCENTAGE, 171
 - /RECEIVER, 172
 - /REFERENCE, 172
 - /SCALE, 172
 - /SKY, 172
 - /SPEED, 173
 - /STEP, 173
 - /SWWOBBLER, 173
 - /SYMMETRIC, 174
 - /SYSTEM, 174
 - /TCALIBRATE, 175
 - /TEMPLOAD, 176
 - /TOTF, 175
 - /TPHASE, 176
 - /TREFERENCE, 176
 - /TSUBSCAN, 176
 - /VELOCITY, 177
 - /VERTICAL, 178
 - /WIDTH, 178

