

FROSTIG

BF91

Contents

Safety information	4	What to do if...	9
Product description	6	Technical data	10
Controls	6	Environmental concerns	10
First use	7	Electrical connection for Great Britain and Ireland only	11
Daily use	7	IKEA GUARANTEE	12
Cleaning and maintenance	8		

Safety information

Before first use

This appliance is intended to be used in household.

To ensure best use of your appliance, carefully read this User Manual which contains a description of the product and useful advice.

Keep these instructions for future reference.

1. After unpacking the appliance, make sure it is not damaged and that the door closes properly. Any functional fault must be reported to IKEA After Sales Service as soon as possible.
2. Wait at least two hours before switching the appliance on, to ensure that the refrigerant circuit is fully efficient.
3. The electrical installation and the electrical connection must be carried out by a qualified technician according to the manufacturer's instructions and in compliance with the local safety regulations.
4. Clean the inside of the appliance before using it.

Precautions and general recommendations

Installation and connection

- The appliance must be handled and installed by two or more persons.
- Be careful not to damage the floors (e.g. parquet) when moving the appliance.
- During installation, make sure the appliance does not damage the power cable.
- Make sure the appliance is not near a heat source.
- To guarantee adequate ventilation, leave a space on both sides and above the appliance and follow the installation instructions.
- Keep the appliance ventilation openings free.
- Do not damage the appliance refrigerant circuit pipes.
- Install and level the appliance on a floor strong enough to take its weight and in a place suitable for its size and use.
- Install the appliance in a dry and well-ventilated place. The appliance is arranged for operation in places where the temperature comes within the following ranges, according to the climatic class

given on the rating plate. The appliance may not work properly if it is left for a long time at a temperature outside the specified range.

Climatic Class	Amb. T. (°C)	Amb. T. (°F)
SN	From 10 to 32	From 50 to 90
N	From 16 to 32	From 61 to 90
ST	From 16 to 38	From 61 to 100
T	From 16 to 43	From 61 to 110

- Make sure the voltage specified on the rating plate corresponds to that of your home.
- Do not use single/multi adapters or extension cords.
- For the water connection, use the pipe supplied with the new appliance; do not reuse that of the previous appliance.
- Power cable modification or replacement must only be carried out by qualified personnel or by After-sales Service.
- It must be possible to disconnect the appliance from the power supply by unplugging it or by means of a mains two-pole switch installed upstream of the socket.

Safety

- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not store or use petrol, flammable liquids or gas in the vicinity of this or other electrical appliances. The fumes can cause fires or explosions.
- Do not use mechanical, electric or chemical means other than those recommended by the Manufacturer to speed up the defrost process.
- Do not use or place electrical devices inside the appliance compartments if they are not of the type expressly authorised by the Manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

- To avoid the risk of children becoming trapped and suffocating, do not allow them to play or hide inside the appliance.
- Do not swallow the contents (non-toxic) of the ice packs (in some models).
- Do not eat ice cubes or ice lollies immediately after taking them out of the freezer since they may cause cold burns.

Use

- Before carrying out any maintenance or cleaning operation, unplug the appliance or disconnect it from the power supply.
- All appliances equipped with an automatic ice-maker and water dispenser must be connected to a water supply that only delivers drinking water (with mains water pressure of between 0.17 and 0.81 Mpa (1.7 and 8.1 bar)). Automatic ice-makers and/or water dispensers not directly connected to the water supply must be filled with drinking water only.
- Use the refrigerator compartment only for storing fresh food and the freezer compartment only for storing frozen food, freezing fresh food and making ice cubes.
- Do not store glass containers with liquids in the freezer since they may burst.

The Manufacturer declines any liability if the above advice and precautions are not respected.


Cleaning, sanitization and maintenance of the ice and water dispenser (if present)

Failure to observe the sanitization instructions provided may compromise the hygiene and safety of water dispensed.

- When using the appliance for the first time, discard the first 9-14 litres of water, equivalent to 6-7 minutes of dispensing (not necessarily consecutive, but before initial consumption) and discard the ice produced in the first 24 hours.
- Reposition the removable water dispenser (if present), ensuring your hands are hygienically clean.
- Periodically clean the ice bucket or drawer under running water only.
- Every six months, sanitize the water and ice dispenser system using a food grade disinfectant solution (with sodium hypochlorite) which does not taint the appliance materials. Rinse with water before use.
- Replacement of any parts of the ice and water dispenser must be carried out using original spare parts provided by the Manufacturer.
- Any work on the appliance must be carried out by a qualified technician or the After-sales Service.

Product description

Carefully read the operating instructions before using the appliance.




- 1** Tray (for ice packs and ice cube trays)
- 2** Control unit
- 3** Area for drawers and pull out baskets
- 4** Pull-out defrost water drain
- 5** Data plate (inside the appliance)

Features, technical information and images may vary depending on model

Accessories

Ice packs (if present)




2x

Ice tray



1x

Controls



- A** GREEN LED: indicates that the appliance is on
- B** YELLOW LED: indicates that the fast freeze function is in operation
- C** RED LED: indicates that the freezer temperature is too high (see "what to do if")
- D** Switch for selection of fast freeze function.
- E** Door contact switch (if supplied)
- Ed** Door contact switch for deselection of acoustic alarm (if supplied)
- F** Thermostat

Important:

To set a colder temperature, turn the thermostat clockwise (towards the right).

To switch the freezer off, turn the thermostat anticlockwise (towards the left).

Thermostat set to ● : freezer switched off

Thermostat set to **1**: **least cold** internal temperature

Thermostat set to **2/3**: **intermediate** internal temperature

Thermostat set to **4**: **coldest** internal temperature

The average recommended thermostat setting is 2/3.

Note: the yellow led **must light up only** during fast freezing.

To freeze the **maximum amount** of food possible, select the fast freeze function **24 h** before placing food in the freezer and to **deselect the function 24 h** after placing the food.

First use

Connect the appliance to the mains power supply. The ideal temperatures for preserving food have already been set at the factory (2-3/MED).

Note: After switching the appliance on, it will be necessary to wait for 2 to 3 hours before a temperature suitable for a standard appliance load is reached.

Daily use

Operation of the freezer

The freezer can be used for storing already frozen food and for freezing fresh food. The amount of fresh food (in kg) that can be frozen in 24 hours is indicated on the appliance data plate. The freezer can operate at ambient temperatures between +10°C and +32°C. Optimal performance is obtained at temperatures between +16°C and +32°C.

Switching on the freezer for the first time

- There is no need to set the freezer temperature on the thermostat because the appliance is already factory set.
- Plug in the appliance. The green LED (indicating that the appliance is ON) and the red LED will light up, and on some models also the acoustic alarm (if provided) will sound after about 1 minute, indicating that the freezer has not yet reached a sufficiently cold temperature for storage of foodstuffs.
- To mute the acoustic alarm press the fast freeze button; the yellow LED will light up.
- Deactivate the fast freeze function when the red LED goes out.

Adjusting the thermostat

Select the freezer compartment temperature using the thermostat knob:

1 = Minimum freezing power

4 = Maximum freezing power

Ambient air temperature, the frequency of door opening and the amount of food to freeze can affect the freezer temperature adjustments.

We therefore recommend starting with a medium temperature setting 2 - 3.

Function of LEDs and acoustic alarm (if present)

The green LED indicates whether the appliance is ON. The red LED (and the acoustic alarm on some models) indicates that the internal temperature of the appliance is not suitable for storing food.

The yellow LED indicates that the fast freeze function is activated.

When it is selected, it also mutes the acoustic alarm (on some models only).

Fast freeze operation

To freeze the maximum amount of food, press the fast freeze button 24 hours before placing fresh food in the freezer. The recommended amount of food to be frozen is indicated on the data plate on the inside of the appliance. When putting food in to freeze, the red LED may light up until the ideal temperature is reached.

After 24 hours deactivate the fast freeze function.

Tips for freezing and storing fresh food

- Before freezing, wrap and seal fresh food in: aluminium foil, plastic wrap, cling film, polyethylene containers with lids, and other containers provided they are suitable for freezing foods.
- Foodstuffs (except meat, see below) must be fresh, mature and of prime quality in order to obtain high quality frozen food.
- Fresh vegetables and fruit should preferably be frozen as soon as they are picked to maintain the full original nutritional value, consistency, colour and flavour.

Some meat, especially game, should be hung before it is frozen.

Note:

- Always leave hot food to cool before placing in the freezer.
- Use fully or partially defrosted foods immediately. Do not refreeze unless the food is cooked after it has thawed. Once cooked, the thawed food can be refrozen.

Freezing and storing fresh food

- Place foods to be frozen in the two upper baskets.
- When the freezer is used without the rack, place the ice packs above the food to be frozen at the front of the top drawer.

Removing the baskets (depending on the model)

Pull the drawers out as far as they go, then lift slightly and remove.

Pull the lower basket out fully, then rotate it slightly in order to remove.

Note: The freezer can also be used without the upper drawers, in order to maximise space. For correct operation of the freezer compartment the bottom drawer should not be removed.

Ensure that after placing the food on the racks, the freezer door closes properly.

Making ice cubes (if provided)

Fill the ice cube tray up to 2/3 with water and place in the freezer compartment. Do not use sharp or pointed objects to detach the tray.

Cleaning and maintenance**Defrosting the freezer**

The freezer should be defrosted once or twice a year or when excessive frost is present (3 mm thickness).

The formation of frost is normal. The amount and rate at which frost accumulates depends on room conditions and how often the door is open.

To defrost the unit, switch off the freezer and remove all food products.

Leave the freezer door open to allow the frost to melt.

For appliances in fig. 1 only pull out the defrost water drain and place a container under the drain.

When the operation is completed, replace the defrost water drain.

Clean the inside of the freezer. Rinse and dry thoroughly. Switch the freezer back on and store the food inside.

If the appliance is not going to be used

Disconnect the appliance from the power supply, remove all the food, defrost and clean. Leave the doors open enough for air to circulate inside the compartments. This will prevent the formation of mould and bad odours.

In case of power failures

Keep the doors of the appliance closed. In this way the stored food will stay cold as long as possible.

Do not refreeze partially thawed food, consume it within 24 hours.




fig. 1

What to do if...

Problem	Possible cause	Solution
The control panel is off and the appliance does not operate	There might be a problem with the electric power supply to the appliance.	Check that: <ul style="list-style-type: none"> • there isn't a power supply failure • the power plug is correctly inserted in the power socket and the two-pole switch, if present, is in the correct position (on) • the electric circuit safety devices installed in the house are fully functional • the power supply cable is not broken
The temperature inside the compartments is not cold enough.	There may be several causes (see "Solutions").	Check that: <ul style="list-style-type: none"> • the doors are closed correctly • the appliance is not placed near a heat source • the temperature set is appropriate • air circulation through the ventilation grills at the bottom of the appliance is not obstructed
There is water at the bottom of the freezer.	Check if the appliance is connected and it is working properly. Check if the doors are closed correctly.	Clean and defrost the appliance (see "Cleaning and maintenance").
The front edge of the appliance is hot at the door seal edge.	This is not a fault. It is part of the design to prevent the formation of condensation.	No solution is necessary.
Only if your product has a control panel. If red temperature alarm lights up and an acoustic signal sounds (according to the model)	Temperature Alarm Freezer Compartment. The temperature alarm indicates that the freezer compartment temperature is not optimum. This can occur during first usage, after defrosting and or cleaning, when freezing big quantities of food or when the freezer door doesn't close properly.	To deactivate acoustic signal press the Rapid freezing button. When optimal temperature is reached the temperature alarm light will automatically switch off. If temperature alarm light stays on contact After Sales Service.

Note:

- Gurgling, hissing and humming noises from the refrigerating system are normal.

Before contacting the After-sales service:

Switch the appliance on again to see if the problem has disappeared. If not, switch it off again and repeat the operation after an hour.

If your appliance still does not work properly after carrying out the checks listed in the troubleshooting guide and switching the appliance on again, contact the After-sales service, clearly explaining the problem and specifying:

- the type of fault;
- the model;
- the type and serial number of the appliance (given on the rating plate);

- the Service number (the number after the word SERVICE on the rating plate inside the appliance).




Note:

Reversing of appliance door opening is not covered by the warranty.

Technical data

Dimensions	BF91
Height	847
Width	540
Depth	550
Net Volume (l)	
Fridge	-
Freezer	91
Defrost system	
Fridge	-
Freezer	Manual
Star Rating	4
Rising Time (h)	16
Freezing Capacity (kg/24h)	14
Energy consumption (kwh/24h)	0,53
Noise level (dba)	39
Energy class	A+

The technical information is situated in the rating plate on the internal side of the appliance and in the energy label



Environmental concerns

1. Packing ♻️


The packing material is 100% recyclable and bears the recycling symbol. For disposal, comply with the local regulations. Keep the packing materials (plastic bags, polystyrene parts, etc.) out of the reach of children, as they are a potential source of danger.

2. Scrapping/Disposal

The appliance is manufactured using recyclable material. This appliance is marked in compliance with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). By ensuring the correct disposal of this appliance, you

can help prevent potentially negative consequences for the environment and the health of persons.



The symbol  on the appliance, or on the accompanying documents, indicates that this appliance should not be treated as domestic waste but must be taken to a special collection centre for the recycling of electrical and electronic equipment. When scrapping the appliance, make it unusable by cutting off the power cable and removing the doors and shelves so that children cannot easily climb inside and become trapped. Scrap the appliance in compliance with local regulations on waste disposal, taking it to a special collection centre; do not leave the appliance

unattended even for a few days, since it is a potential source of danger for children.

For further information on the treatment, recovery and recycling of this product, contact your competent local office, the household waste collection service or the shop where you purchased the appliance.

Information:

This appliance does not contain CFCs. The refrigerant circuit contains R600a (HC) (see the rating plate inside the appliance).

Appliances with Isobutane (R600a): isobutane is a natural gas without environmental impact, but is flammable. Therefore, make sure the refrigerant circuit pipes are not damaged.

Declaration of conformity

- This appliance has been designed for preserving food and is manufactured in compliance with Regulation (CE) No. 1935/2004.



- This appliance has been designed, manufactured and marketed in compliance with:
 - safety objectives of the “Low Voltage” Directive 2006/95/CE (which replaces 73/23/CEE and subsequent amendments);
 - the protection requirements of Directive “EMC” 2004/108/EC.

Electrical safety of the appliance can only be guaranteed if it is correctly connected to an approved earthing system.

Electrical connection for Great Britain and Ireland only

Warning - this appliance must be earthed

Fuse replacement

If the mains lead of this appliance is fitted with a BS 1363A 13amp fused plug, to change a fuse in this type of plug use an A.S.T.A. approved fuse to BS 1362 type and proceed as follows:

1. Remove the fuse cover (A) and fuse (B).
2. Fit replacement 13A fuse into fuse cover.
3. Refit both into plug.

Important:


The fuse cover must be refitted when changing a fuse and if the fuse cover is lost the plug must not be used until a correct replacement is fitted.

Correct replacement are identified by the colour insert or the colour embossed in words on the base of the plug.

Replacement fuse covers are available from your local electrical store.

For the Republic of Ireland only

The information given in respect of Great Britain will frequently apply, but a third type of plug and socket is also used, the 2-pin, side earth type.



Socket outlet / plug (valid for both countries)

If the fitted plug is not suitable for your socket outlet, please contact After-sales Service for further instruction. Please do not attempt to change plug yourself. This procedure needs to be carried out by a qualified technician in compliance with the manufactures instructions and current standard safety regulations.

IKEA GUARANTEE

How long is the IKEA guarantee valid?

This guarantee is valid for five (5) years from the original date of purchase of your appliance at IKEA, unless the appliance is named LAGAN in which case two (2) years of guarantee apply. The original sales receipt, is required as proof of purchase. If service work is carried out under guarantee, this will not extend the guarantee period for the appliance.

Which appliances are not covered by the IKEA five (5) years guarantee?

The range of appliances named LAGAN and all appliances purchased in IKEA before 1st of August 2007.

Who will execute the service?

IKEA service provider will provide the service through its own service operations or authorized service partner network.

What does this guarantee cover?

The guarantee covers faults of the appliance, which have been caused by faulty construction or material faults from the date of purchase from IKEA. This guarantee applies to domestic use only. The exceptions are specified under the headline "What is not covered under this guarantee?" Within the guarantee period, the costs to remedy the fault e.g. repairs, parts, labour and travel will be covered, provided that the appliance is accessible for repair without special expenditure. On these conditions the EU guidelines (Nr. 99/44/EG) and the respective local regulations are applicable. Replaced parts become the property of IKEA.

What will IKEA do to correct the problem?

IKEA appointed service provider will examine the product and decide, at its sole discretion, if it is covered under this guarantee. If considered covered, IKEA Service Provider or its authorized service partner through its own service operations, will then, at its sole discretion, either repair the defective product or replace it with the same or a comparable product.

What is not covered under this guarantee?

- Normal wear and tear.
- Deliberate or negligent damage, damage caused by failure to observe operating instructions, incorrect installation or by connection to the wrong voltage, damage caused by chemical or

electrochemical reaction, rust, corrosion or water damage including but not limited to damage caused by excessive lime in the water supply, damage caused by abnormal environmental conditions.

- Consumable parts including batteries and lamps.
- Non-functional and decorative parts which do not affect normal use of the appliance, including any scratches and possible color differences.
- Accidental damage caused by foreign objects or substances and cleaning or unblocking of filters, drainage systems or soap drawers.
- Damage to the following parts: ceramic glass, accessories, crockery and cutlery baskets, feed and drainage pipes, seals, lamps and lamp covers, screens, knobs, casings and parts of casings. Unless such damages can be proved to have been caused by production faults.
- Cases where no fault could be found during a technician's visit.
- Repairs not carried out by our appointed service providers and/or an authorized service contractual partner or where non-original parts have been used.
- Repairs caused by installation which is faulty or not according to specification.
- The use of the appliance in a non-domestic environment i.e. professional use.
- Transportation damages. If a customer transports the product to his home or another address, IKEA is not liable for any damage that may occur during transport. However, if IKEA delivers the product to the customer's delivery address, then damage to the product that occurs during this delivery will be covered by IKEA.
- Cost for carrying out the initial installation of the IKEA appliance.

However, if an IKEA appointed Service Provider or its authorized service partner repairs or replaces the appliance under the terms of this guarantee, the appointed Service Provider or its authorized service partner will reinstall the repaired appliance or install the replacement, if necessary. This does not apply within Ireland, customer should contact the local IKEA dedicated after sales line or the appointed Service Provider for further information.

These restrictions do not apply to fault-free work carried out by a qualified specialist using our original parts in order to adapt the appliance to the technical safety specifications of another EU country.

How country law applies

The IKEA guarantee gives you specific legal rights, which cover or exceed all the local legal demands. However these conditions do not limit in any way consumer rights described in the local legislation.

Area of validity

For appliances which are purchased in one EU country and taken to another EU country, the services will be provided in the framework of the guarantee conditions normal in the new country. An obligation to carry out services in the framework of the guarantee exists only if the appliance complies and is installed in accordance with:

- the technical specifications of the country in which the guarantee claim is made;
- the Assembly Instructions and User Manual Safety Information.

The dedicated AFTER SALES for IKEA appliances

Please don't hesitate to contact IKEA appointed After Sales Service Provider to:

- make a service request under this guarantee;
- ask for clarifications on installation of the IKEA appliance in the dedicated IKEA kitchen furniture;
- ask for clarification on functions of IKEA appliances.

To ensure that we provide you with the best assistance, please read carefully the Assembly Instructions and/or the User Manual before contacting us.

How to reach us if you need our service



Please refer to the last page of this manual for the full list of IKEA appointed After Sales Service Provider and relative national phone numbers.

- i** In order to provide you a quicker service, we recommend to use the specific phone numbers listed on this manual. Always refer to the numbers listed in the booklet of the specific appliance you need an assistance for. Please also always refer to the IKEA article number (8 digit code) and 12 digit service number placed on the rating plate of your appliance.

i SAVE THE SALES RECEIPT!

It is your proof of purchase and required for the guarantee to apply. The sales receipt also reports the IKEA name and article number (8 digit code) for each of the appliances you have purchased.

Do you need extra help?

For any additional questions not related to After Sales of your appliances please contact your nearest IKEA store call centre. We recommend you read the appliance documentation carefully before contacting us.



BELGIË - BELGIQUE - BELGIEN

Telefoon/Numéro de téléphone/Telefon-Nummer:	026200311		
Tarief/Tarif/Tariff:	Lokaal tarief/Prix d'un appel local/Ortstarif		
Openingstijd:	Maandag - Vrijdag	8.00 - 20.00	
Heures d'ouverture:	Lundi - Vendredi	8.00 - 20.00	
Öffnungszeiten:	Montag - Freitag	8.00 - 20.00	

ČESKÁ REPUBLIKA

Telefonní číslo:	225376400		
Sazba:	Místní sazba		
Pracovní doba:	Pondělí - Pátek	8.00 - 20.00	

DANMARK

Telefonnummer:	70150909		
Takst:	Lokal takst		
Åbningstid:	Mandag - fredag	9.00 - 21.00	
	Lørdag	9.00 - 18.00	
	(Åbent udvalgte søndage, se IKEA.dk)		

DEUTSCHLAND

Telefon-Nummer:	06929993602		
Tarif:	Ortstarif		
Öffnungszeiten:	Montag - Freitag	8.00 - 20.00	

ΕΛΛΑΔΑ

Τηλεφωνικός αριθμός:	2109696497		
Χρέωση:	Τοπική χρέωση		
Ώρες λειτουργίας:	Δευτέρα - Παρασκευή	8.00 - 20.00	

ESPAÑA

Teléfono:	913754126		
Tarifa:	Tarifa local		
Horario:	Lunes - Viernes	8.00 - 20.00	
	(España Continental)		

FRANCE

Numéro de téléphone:	0170480513		
Tarif:	Prix d'un appel local		
Heures d'ouverture:	Lundi - Vendredi	9.00 - 21.00	

ÍSLAND

Símanúmer:	5852409		
Kostnaður við símtal:	Almennt mínútuverð		
Opnunartími:	Mánudaga - Föstudaga	9.00 - 17.00	

ITALIA

Telefono:	0238591334		
Tariffa:	Tariffa locale		
Orari d'apertura:	Lunedì - Venerdì	8.00 - 20.00	

MAGYARORSZÁG

Telefon szám:	(06-1)-3285308		
Tarifa:	Helyi tarifa		
Nyitvatartási idő:	Hétfőtől Péntekig	8.00 - 20.00	

NEDERLAND

Telefoon:	09002354532		
	en/of 0900 BEL IKEA		
Tarief:	Lokaal tarief € 0,10 p/min		
Openingstijd:	Maandag t/m - Vrijdag	9.00 - 21.00	
	Zaterdag	9.00 - 20.00	
	Zondag	9.00 - 18.00	

NORGE

Telefon number:	23500112		
Takst:	Lokal takst		
Åpningstider:	Mandag - fredag	8.00 - 20.00	

ÖSTERREICH

Telefon-Nummer:	013602771461		
Tarif:	Ortstarif		
Öffnungszeiten:	Montag - Freitag	8.00 - 20.00	

POLSKA

Numer telefonu:	225844203		
Stawka:	Koszt połączenia według taryfy operatora		
Godziny otwarcia:	Poniedziałek - Piątek	8.00-20.00	

PORTUGAL

Telefone:	213164011		
Tarifa:	Tarifa local		
Horário:	Segunda - Sexta	9.00 - 21.00	

REPUBLIC OF IRELAND

Phone number:	016590276		
Rate:	Local rate		
Opening hours:	Monday - Friday	8.00 - 20.00	

РОССИЯ

Телефонный номер:	84957059426		
Стоимость звонка:	Местная стоимость звонка		
Время работы:	Понедельник - Пятница	8.00 - 20.00	
	(Московское время)		

SCHWEIZ - SUISSE - SVIZZERA

Telefon-Nummer/Numéro de téléphone/Telefono:	0225675345		
Tarif/Tarif/Tariffa:	Ortstarif/Prix d'un appel local/Tariffa locale		
Öffnungszeiten:	Montag - Freitag	8.00 - 20.00	
Heures d'ouverture:	Lundi - Vendredi	8.00 - 20.00	
Orario d'apertura:	Lunedì - Venerdì	8.00 - 20.00	

SLOVENSKO

Telefónne číslo:	(02) 50102658		
Cena za hovor:	Cena za miestny hovor		
Pracovná doba:	Pondelok až piatok	8.00 - 20.00	

SUOMI

Puhelinnumero:	0981710374		
Hinta:	Yksikköhinta		
Aukioloaika:	Maanantaista perjantainhin	8.00 - 20.00	

SVERIGE

Telefon number:	0775-700 500		
Taxa:	Lokal samtal		
Öppet tider:	Måndag - Fredag	8.30 - 20.00	
	Lördag - Söndag	9.30 - 18.00	

UNITED KINGDOM

Phone number:	02076601517		
Rate:	Local rate		
Opening hours:	Monday - Friday	9.00 - 21.00	

