

Quick Setup and Troubleshooting Guide

For use with: all Classic 6", Bluetooth
6" and Bluetooth 8' boards.



CONGRATULATIONS

Thank you for purchasing from iSwegway.com.

All of our boards are ready to use out the box.

This guide will help you quickly get started.
Please follow the steps carefully in order to
ensure you get the most out of your iSwegway.

IN YOUR BOX YOU SHOULD HAVE:

1

Your iSwegway board

2

UK CE 3 pin charger

3

User manual

4

Remote (if applicable)

- ▶ Before we post any Swegway boards we test each one to ensure they are in working condition.
- ▶ All of our Swegway boards undergo testing in clean, dust free designated spaces and are wiped down and packaged carefully for our customers.
- ▶ We also check and test the charger to ensure it is fully operational.

Note: all of our boards come with UK CE 3 pin chargers. We do not supply non-UK chargers.

THINGS YOU SHOULD DO

- ✓ Charge for 2 hours before riding
- ✓ Set your board on flat ground before riding
- ✓ Get on one foot at a time
- ✓ Get off one foot at a time
- ✓ Be patient and calm
- ✓ Wear protective clothing
- ✓ Ride in a safe place free from hazards
- ✓ Stop completely before getting off
- ✓ Ride on level ground
- ✓ Be aware of surroundings

THINGS YOU SHOULD NOT DO

- ✗ Jump on the board
- ✗ Jump off the board
- ✗ Ride through water
- ✗ Tow your board
- ✗ Remove the casing (warranty void)
- ✗ Ride at high speeds for long periods of time
- ✗ Do not leave charger running for prolonged period of time

BLUETOOTH FUNCTIONALITY

(APPLICABLE TO BLUETOOTH MODEL BOARDS ONLY)

After switching on your iSwegway. You will hear a confirmation sound indicating the Bluetooth is ready.

Have your Bluetooth device ready; let's say you are trying to connect the Bluetooth on your phone to the iSwegway. Check your phone has Bluetooth switched on. Use your phone to search for new devices and the iSwegway should appear as "F008" or similar.



Once it has recognised and connected the iSwegway will appear connected on your Bluetooth device.

Now select the music you want to listen to and you are connected.

GETTING STARTED



Quick..on the go steps...

So you are now ready to get moving!


Get on one foot at a time from behind your iSwegway board and always get off the rear one foot at a time. First of all use the iSwegway board using just one foot i.e. one foot on board and one on the ground. Just to feel the movement of the board.

Tip foot forward and feel the board move forward. Tip foot backwards and feel the board move backwards. Master the board moving back and forth before trying both feet. The iSwegway board is incredibly sensitive, slight movements are all that is needed for the board to react.

FIRST TIME ON A SWEGWAY BOARD?

- ▶ Hold on to something i.e. to a person or a fixed object perhaps try holding on to a kitchen work surface. Once on with both feet, stand still and allow your board to
- ▶ Balance before you move. The secret to your success is to make sure you can stand still on your board.
- ▶ Now lean slightly forward and press lightly on the front of the pedals and you will start to move forward. Drop your heels and therefore the opposite applies you will move backwards. Just try to move forward and backward while holding on.
- ▶ To rotate on the board press one pedal forward and one backwards whilst taking care to stay balanced on the. Try moving forward slowly now. Keep holding on to someone's hand till your confidence grows. With a bit of patience and practice you will master it in no time. Most people can start moving with confidence in under an hour, some people pick it up in just 5 minutes.

BATTERY



The battery in your board is Samsung or LG lithium-ion and is of the highest quality available. When you order your board we will state whether it is fitted with a Samsung or LG battery.

When new, it may take up to twenty re-charge cycles for it to reach its full capacity, we recommend using and recharging fully each time, do not leave charging overnight.

RECALIBRATION GUIDE

How do I reset or rebalance my board?

Your board from time to time may need a reset, this is easy to do:

1. Charge the board for two hours.

(The charger has a red light on it, which illuminates when plugged in, this red light will turn to green when fully charged.)

1a. Then unplug the charger.

2. Turn off the board and make sure the tops of both sides of the are level. If it is working fine both lights should be green on the top and your board should work. If just one green light it needs rebalancing.



3. Turn off the board.

4. Hold down the “on” button for 30 seconds. The lights should come on the board and start flashing. Let them continue for 30 seconds.

5. Turn off the board.

6. Turn it back on again two green lights on the top? All done!

How do I use the Keyfob?

The remote control is the key fob in the box. Although this has four buttons it's used for just turning the board on and off to save you having to bend down. Alternatively, if you prefer you can use the silver on/off button on the side of the board. The other buttons are redundant and have no functionality. Some boards come with a locking feature which allows you to remotely lock the board so it is not able to be ridden.

