KEYTEC ACEeBoard Quick Setup – see user's manual for more details.

ACEeBoard consists of 2 receivers, connected by a cable. The <u>left receiver</u> has <u>two cables</u> (one is for the USB cable to the computer and the other is a cable that connects the left receiver to the right receiver). Right receiver should have only <u>1 cable</u> that connects to the left receiver. Please keep in mind that it will not work properly if the receivers are positioned incorrectly. Note: The receivers should be mounted at least 1 " (2.5 cm) above the projected image area. They may need to be mounted higher when using on flat panel displays		
For whiteboard or projection screen with thick frame mounted on the Stand or on the wall - Attach the receivers on the top of the whiteboard frame		
For whiteboard or projection screen with a thin frame mounted on the stand - Assemble the acrylic holders with the receivers as shown below, place each receivers on the top corners of whiteboard frame.	Acrylic holder + Receiver =	
For whiteboard or projection screen with thin frame mounted on wall - Place receiver onto the top of the steel bracket using double-sided tape. Attach the steel bracket to the back side of the whiteboard.	Whiteboard Frame	
For mounting Receivers on the flat surface directly - Place receiver onto the top of the steel bracket using double-sided tape. Attach the steel bracket to the wall using screws or double-sided tape.	Steel Bracket Using a screw or double- sided sticky tape to fix bracket on back-side of whiteboard.	
For mounting the receivers on flat panel displays - You may use any proper method to raise and mount the receivers about 5" above the display. Mounting fixture is not included, but you may contact us to purchase a simple fixture as shown.	ACE e Board DIY Interactive Whiteboard	
Connect USB cable from left receiver to a USB port on the computer. If cable is not long enough, use active USB extension cable. Connect Projector or flat panel display to the Computer with VGA cable.		
Insert the CD, click on Install to start software installation. If auto run does not work, Run POPStarter.exe from CD. It is better to have the computer connected to the Internet for update information.		

After installation is completed, 2 icons will appear on the desktop: Mint Control and Mint Interactive.



Double click Mint control to open the control panel. For the first-time calibration after the hardware setup, click "initial setup". For recalibration in the future, click "screen calibration".		
In the next screen, click "Next" to continue. You will need to select "Quick setup" or "Fine setup". Quick setup is normally recommended. If you experience difficulty of achieving the accuracy of touch, you may run "Fine setup".		
Place PEN at low end point of blue light of Left receiver and Press it continuously till "RECOGNIZED" is displayed.	Place PEN at low end point of blue light of Right receiver and Press it continuously till "RECOGNIZED" is displayed.	
Follow and touch the center of circles appeared on the screen to complete the calibration process. Check the accuracy of touch. Recalibrate if necessary. If "Fine setup" is selected, you will need to touch each X appeared on the top of the screen to complete calibration process.		
 The digital pen works like a mouse pen. Pen tip: same as left mouse click. Lower button: same as right mouse click. Upper button: 1. In Mint Interactive mode – toggle between writing and eraser functions. 2. In Windows mode – press and hold will exit Windows mode and back to Mint Interactive mode. 	Digital Pen:	
The digital pen can be charged from computer's USB port.		
Mint Interactive is an interactive whiteboard software. Double click the Mint Interactive icon to run the program. There are two ways to display the tool bars – Bar type or Floating type. Toggle between Mint Interactive mode and Window mode. Pencil, highlighter, brush. Frasers. Color, size, shapes/lines/diagrams. Color, size, shapes/lines/diagrams. Text input, edit. Core acpture, recording. Previous page, next page. Insert new page, delete selected page. Redo, undo. Shift window, tool & utility. Shift & zoom, setup options. Contact Information:	Bar type Image: Contraction of the contract	

KEYTEC, INC. 520 Shepherd Drive, Garland, Texas, USA 75042 Tel: 972-272-7555 or 800-624-4289 Fax: 972-272-7501 Office Hours: 8:30AM – 5:00PM CST Monday – Friday. Homepage: <u>www.magictouch.com</u> ACEeBoard page: <u>http://www.magictouch.com/board.html</u> Email: for information: <u>info@magictouch.com</u> for sales inquiry: <u>sales@magictouch.com</u> for tech support: <u>tech@magictouch.com</u>. Join KEYTEC facebook for special discounts and free prizes: <u>http://www.facebook.com/Keytec</u>.