# Thank you for choosing to participate in the Ontario Power Authority peaksaverPLUS Program.

As part of this program, you have received a new Energate thermostat and ZIP Connect. Here is a quick review of the program and how you can use your thermostat to help save energy. For more information, consult the user manual provided.

# Please ensure your ZIP Connect is powered on and connected to the internet at all times in order to participate in the program.



**Energate Thermostat** 

**ZIP Connect** 

Go To (URL):	pdiconserves.myenergate.com
Your Userid:	
Your Password:	
Customer Service	
Technical Support:	1-866-869-8406
Peterborough	Connecting Conservation with Comfort Connecting Conservation with Comfort Conservation
UISTRIBUTION INC.	

## 2. Thermostat Screen and Controls

#### **Thermostat Buttons:**



#### **Home Screen**



The Home Screen displays the current room temperature. The SETPOINT shows the target heating or cooling temperature. The HEAT, COLD and FAN icons animate when your equipment is running.

#### 3. Adjusting the Temperature and Mode

## Manually Setting the Temperature (Temporary Hold):



- 1. Press the ARROW keys to select the desired target temperature.
- 2. Press the LEFT TAB key to accept the temporary HOLD.
- 3. This setting will remain until the next SETPOINT change in your schedule.
- 4. Cancel a hold by pressing any ARROW key and then RIGHT TAB key.

#### Changing the Thermostat Operating and Fan Modes:



- 1. Press the MENU/SELECT key to wake the thermostat.
- 2. Pressing the LEFT TAB button changes the thermostat mode (COOL/HEAT/AUTO/EMERG/OFF).
- 3. Pressing the RIGHT TAB button changes the fan mode (ON/AUTO)

#### **Planning Your Schedule:**

Fill in the times and temperatures you would like programmed into your thermostat. If you only change your thermostat at night, fill out just the Wake and Sleep sections.

SETPOINT			Start Time		
	HEAT°	Cool°	Monday - Friday	Saturday & Sunday	
Wake					
Leave					
Return					
Sleep					

#### 4. Schedule and Comfort Screen

## Changing Your Schedule:

The thermostat follows a weekly schedule by programming SETPOINTS (Wake, Leave, Return, Sleep) into timeslots during the week. The temperatures for each SETPOINT can be edited and the TIMES that they become active can be adjusted to your family's schedule. Programming this schedule correctly can help save you energy.

#### **Adjust Setpoint Temperature and Time**

RUICK SCHEDULE M-F (MONDAY-FRIDAY)						
NAME	TIME	HEAT	COOL			
WAKE	6:00 AM	70.0°	78.0°			
LEAVE	8:00 AM	62.0°	85.0*			
RETURN	6:00 PM	70.0*	78.0*			
SLEEP	10:00 PM	62.0*	82.0*			
NEXT DAY			XIT			

- 1. Press the MENU/SELECT key to wake the thermostat.
- 2. Press the MENU/SELECT key to display the Menu.
- 3. Use the ARROW KEYS and MENU/SELECT to choose QUICK SCHEDULE.
- 4. The WAKE time will be underlined, Press the ARROW KEYS to change the time.
- 5. Press the MENU/SELECT key to move to the HEAT temperature.
- 6. Press the ARROW keys to select the desired temperature.
- 7. Press the MENU/SELECT key to move to the COOL temperature.
- 8. Press the ARROW keys to select the desired temperature.
- 9. Repeat for any other setpoints. Press the LEFT TAB key to move to the next day.
- 10. EXIT by pressing the RIGHT TAB menu key.

#### **Energy Conservation Events:**



During periods of high electricity demand, a Blue LED will illuminate on your thermostat and your Setpoint name will be replaced with "Energy Event". This indicates that the Setpoint temperature has been adjusted to save energy and the new target temperature will be displayed below the words "Energy Event".