

# Airolinx<sup>®</sup>

## Industrial Wireless Access Point

### APN-200/APN-200P



## User Manual

Version 1.4

**aaxeon<sup>®</sup>**  
AAXEON TECHNOLOGIES, INC.  
[www.aaxeon.com](http://www.aaxeon.com)

# Table of Content

<b>1</b>	<b>GETTING TO KNOW YOUR ACCESS POINT .....</b>	<b>3</b>
1.1	About the APN-200 Access Point .....	3
1.2	Software Features .....	3
1.3	Hardware Features .....	3
<b>2</b>	<b>HARDWARE INSTALLATION .....</b>	<b>5</b>
2.1	Installation AP on DIN-Rail .....	5
2.2	Wall Mounting Installation.....	6
<b>3</b>	<b>HARDWARE OVERVIEW .....</b>	<b>8</b>
3.1	Front Panel.....	8
3.2	Front Panel LEDs.....	9
3.3	Bottom Panel.....	10
3.4	Rear Panel .....	10
<b>4</b>	<b>CABLES AND ANTENNA .....</b>	<b>12</b>
4.1	Ethernet Cables .....	12
4.1.1	100BASE-TX/10BASE-T Pin Assignments .....	12
4.2	Wireless Antenna .....	13
<b>5</b>	<b>MANAGEMENT INTERFACE.....</b>	<b>14</b>
5.1	Explore APN-200/APN-200P .....	14
5.1.1	AP-Monitor software .....	14
5.1.2	UPnP Equipment .....	15
5.2	Configuration by Web Browser.....	16
5.2.1	About Web-based Management.....	17
5.2.1.1	Main Interface .....	17
5.2.2	Basic Setting .....	18
5.2.2.1	Setting Operation Mode .....	18
5.2.2.2	Setting WDS .....	20
5.2.2.3	Setting Wireless .....	25
5.2.2.4	LAN Setting.....	28
5.2.2.5	Setting DHCP Server .....	30
5.2.3	Advanced Setting .....	31
5.2.4.1	Wireless .....	31
5.2.4.2	MAC Filter.....	32
5.2.4.3	System Event.....	33
5.2.4	System Tools .....	36
5.2.4.1	Administrator.....	36

5.2.4.2	Date & Time .....	37
5.2.4.3	Configuration.....	39
5.2.4.4	Firmware Upgrade .....	39
5.2.4.5	Miscellaneous .....	40
5.2.5	System Status .....	41
5.2.5.1	System Info.....	41
5.2.5.2	System Log.....	41
5.2.5.3	Traffic Statistics .....	42
5.2.5.4	Wireless Clients .....	42
5.2.6	Online Help.....	42
<b>6</b>	<b>TECHNICAL SPECIFICATIONS .....</b>	<b>44</b>

# 1

## Getting to Know Your Access Point

### 1.1 About the APN-200 Access Point

APN-200/APN-200P is a reliable IEEE802.11b/g WLAN 2 LAN port Access Point. It can be configured to operate in AP/Bridge/Repeater mode. You can configure APN-200/APN-200P by a Windows Utility or WEB interface via LAN port or WLAN interface. APN-200/APN-200P provides dual Ethernet ports in switch mode, so you can Daisy Chain to reduce the usage of Ethernet switch ports. APN-200P also provides PD feature on ETH2 which is fully compliant with IEEE802.3af P.O.E. specification.

### 1.2 Software Features

- High Speed Air Connectivity: WLAN interface support up to 54Mbps link speed connection
- High Security Capability: WEP/WPA/WPA2/802.1X/Radius/TKIP supported
- Support AP/Bridge/Repeater Mode
- Switch Mode Supported: Daisy Chain support to reduce usage of switch ports
- Secure Management by HTTPS and SSH
- Event Warning by Syslog, Email, SNMP Trap, Relay and Beeper

### 1.3 Hardware Features

- Fully Compliant with IEEE802.3af (Power Device at ETH2, APN-200P only)
- Redundant Power Inputs: 12~48 VDC on terminal block
- Operating Temperature: -10 to 70°C
- Storage Temperature: -35 to 75°C (-T Model)
- Operating Humidity: 5% to 95%, non-condensing

- Casing: IP-30
- 10/100Base-T(X) Ethernet port
- Dimensions(W x D x H) : 52 mm(W)x 106 mm( D )x 144 mm(H)

# 2

## Hardware Installation

### 2.1 Installation AP on DIN-Rail

Each AP has a Din-Rail kit on rear panel. The Din-Rail kit allows the AP to mount on the Din-Rail.

Step 1: Slant the AP and mount the metal spring to Din-Rail.



Metal Spring


Step 2: Push the AP toward the Din-Rail until you hear a "click" sound.



## 2.2 Wall Mounting Installation

Each AP also supports a wall mount. A wall mount panel can be found in the package. The following steps show how to mount the AP on the wall:


Step 1: Remove Din-Rail kit.



Step 2: Use 6 screws that can be found in the package to install the wall mount panel.



The screws specifications are shown in the following two pictures.



Step 3: Mount the AP on the wall.





# 3

## Hardware Overview


### 3.1 Front Panel

The following table describes the labels on the APN-200/APN-200P.

Port	Description
<b>10/100 RJ-45 fast Ethernet ports</b>	2 10/100Base-T(X) RJ-45 fast Ethernet ports support auto-negotiation. Default Setting : Speed: auto Duplex: auto Flow control : disable
<b>P.O.E. PD Port</b>	ETH2 of APN-200P compliant with IEEE802.3af P.O.E. specifications
<b>ANT.</b>	Reverse SMA connector for external antenna.

APN-200

APN-200P



1. 2.4GHz antenna with typical 2.0dbi antenna gain.
2. LED for P.O.E. power and system status. When the P.O.E. power links, the green LED will be on.
3. LED for PWR1 and system status. When the PWR1 links, the green led will be on.
4. LED for PWR2 and system status. When the PWR2 links, the green led will be on.
5. LED for Fault Relay. When the fault occurs, the amber LED will be on.
6. 10/100Base-T(X) Ethernet ports. (APN-200P contains PD function of P.O.E.)
7. LED for Ethernet ports status.
8. LED for WLAN link status.
9. LED for WLAN signal strength.

### 3.2 Front Panel LEDs


LED	Color	Status	Description
<b>P.O.E.</b>	Green/Red	Green On	P.O.E. power connected.
		Red blinking	Indicates an IP conflict, or DHCP or BOOTP server did not respond properly
<b>PWR1</b>	Green/Red	On	DC power 1 activated.
		Red blinking	Indicates an IP conflict, or DHCP or BOOTP server did not respond properly
<b>PWR2</b>	Green/Red	On	DC power 2 activated.
		Red blinking	Indicates an IP conflict, or DHCP or BOOTP server did not respond properly
<b>Fault</b>	Amber	On	Fault relay. Power failure or Port down/fail.
<b>WLAN</b>	Green	On	WLAN activated.
		Blinking	WLAN Data transmitted.
<b>WLAN Strength</b>	Green	On	WLAN signal strength. 1<25%, 2<50%, 3<75%, 4<100%
10/100Base-T(X) Fast Ethernet ports			
<b>10Mbps</b>	Amber	On	Port link up at 10Mbps.

LNK/ACT		Blinking	Data transmitted.
100Mbps LNK/ACT	Green	On	Port link up at 100Mbps.
		Blinking	Data transmitted.

### 3.3 Bottom Panel

The bottom panel components of APN-200/APN-200P are showed as below:


1. Terminal block includes: PWR1, PWR2 (12 ~ 48V DC) and Relay output (1A@24VDC).
2. Reset bottom. Push the bottom 3 seconds for reset; 5 seconds for factory default.



### 3.4 Rear Panel

The rear panel components of APN-200/APN-200P are showed as below:

1. Screw holes for wall mount kit.
2. Din-Rail kit



# 4

## Cables and Antenna

### 4.1 Ethernet Cables

The APN-200/APN-200P switches have standard Ethernet ports. According to the link type, the switches use CAT 3, 4, 5, 5e UTP cables to connect to any other network device (PCs, servers, switches, routers, or hubs). Please refer to the following table for cable specifications.

Cable Types and Specifications

Cable	Type	Max. Length	Connector
10BASE-T	Cat. 3, 4, 5 100-ohm	UTP 100 m (328 ft)	RJ-45
100BASE-TX	Cat. 5 100-ohm UTP	UTP 100 m (328 ft)	RJ-45
1000BASE-TX	Cat. 5/Cat. 5e 100-ohm UTP	UTP 100 m (328ft)	RJ-45

#### 4.1.1 100BASE-TX/10BASE-T Pin Assignments

With 100BASE-TX/10BASE-T cable, pins 1 and 2 are used for transmitting data, and pins 3 and 6 are used for receiving data.

RJ-45 Pin Assignments

Pin Number	Assignment
1	TD+
2	TD-
3	RD+
4	Not used
5	Not used
6	RD-
7	Not used

8	Not used
---	----------

The APN-200/APN-200P switches support auto MDI/MDI-X operation. You can use a straight-through cable to connect PC and switch. The following table below shows the 10BASE-T/ 100BASE-TX MDI and MDI-X port pin outs.

MDI/MDI-X pins assignment

Pin Number	MDI port	MDI-X port
1	TD+(transmit)	RD+(receive)
2	TD-(transmit)	RD-(receive)
3	RD+(receive)	TD+(transmit)
4	Not used	Not used
5	Not used	Not used
6	RD-(receive)	TD-(transmit)
7	Not used	Not used
8	Not used	Not used

**Note:** "+" and "-" signs represent the polarity of the wires that make up each wire pair.

## 4.2 Wireless Antenna

A 2dbi 2.4GHz antenna is used for APN-200/APN-200P and connected with a reversed SMA connector.

# 5

## Management Interface


### 5.1 Explore APN-200/APN-200P

#### 5.1.1 AP-Monitor software

Each model contains the AP-Monitor software, to find and configure the APN-200/APN-200P on local area network.

Step 1: Open the AP-Monitor and click "Refresh list", the AP devices will show on the list.

Step 2: Choose your access point, and it will show the AP settings. Simultaneously, you can set the AP's IP address.



The screenshot displays the configuration interface for an access point, divided into two main sections: "Basic information" and "Protocol".

**Basic information**

Firmware Version:	1.2e
Description:	2-port 10/100TX LAN Redundant to 802.11b/g Wireless LAN
Mac address:	00:12:44:57:89:21
IP address:	192.168.1.48
IP status:	DHCP

**Protocol**


Protocol:	DHCP
IP address:	192 . 168 . 1 . 48
Subnet mask:	255 . 255 . 255 . 0
Default gateway:	192 . 168 . 1 . 1
Primary dns:	192 . 168 . 1 . 12
Secondary dns:	. . .

Step 3: Click "Access via web" button, it will go to web page.




## 5.1.2 UPnP Equipment

Step 1: To check whether the UPnP UI of the computer is connected to the APN-200/APN-200P, go to **Control Panel>Add or Remove Programs>Windows Components Wizard>Networking Servers>UPnP User Interface** and click on the UPnP User Interface.




Step 2: At the lower right corner of the computer, you will find a sign of the UPnP equipment.





Step 3: Click the sign of the UPnP equipment, then you will find the UPnP equipment in the network neighborhood.



Step 4: Right click the UPnP equipment to choose "Properties."



Step 5: Right click the UPnP equipment or double click the UPnP equipment to transfer; it will go to the web page.

## 5.2 Configuration by Web Browser

This section introduces the configuration by Web browser.

## 5.2.1 About Web-based Management

Each AP contains an embedded HTML web site residing in flash memory. With its advanced management features, it allows you to manage the AP from anywhere on the network through a standard browser such as Microsoft Internet Explorer.

The Web-Based Management supports Internet Explorer 5.0 and above.

**Note:** By default, IE5.0 or later version does not allow Java Applets to open sockets. You need to explicitly modify the browser setting in order to enable Java Applets to use network ports.

Through the front section's information, enter your user name (**admin**) and your password (**admin**), then click **Ok** to continue.




Login screen

For security reasons, we strongly suggest you change the password. Click on **System Tools**→**Administrator** and modify the password.

### 5.2.1.1 Main Interface


The **Home** screen will appear. Please click "Run Wizard" to go to the **Home**→**Setup Wizard** page to install the AP.



Main interface

## 5.2.2 Basic Setting

### 5.2.2.1 Setting Operation Mode



Operation mode interface

The following table describes the labels in this screen.


Label	Description
<b>Bridge</b>	This mode provides Static LAN-to-LAN Bridging functionality. The static LAN-to-LAN bridging function is supported through Wireless Distribution System (WDS).
<b>AP-Client</b>	The AP-Client function provides a 1-to-N MAC address mapping

	mechanism such that multiple stations behind the AP can transparently connect to the other AP even if they don't support WDS.
<b>AP</b>	This mode provides Access Point services for other wireless clients.

In any mode, the APN-200/APN-200P forwards packet between its Ethernet interface and wireless interface for wired hosts on the Ethernet side, and wireless hosts on the wireless side.


### Access Point Mode

- . AP mode provides wireless service for other wireless clients
- . POE supported




### AP Client Mode

- . AP Client Mode provide a 1-to-N MAC address mapping mechanism such that multiple stations behind the AP can transparently connect to other APs even if they don't support WDS



## Bridge Mode

- . Bridge mode provide static LAN-to-LAN Bridging functionality. The static LAN-to-LAN bridging function is supported through wireless distribution system (WDS)



### 5.2.2.2 Setting WDS

**Basic Setting --> WDS**

Operation mode of the AP should be set to "Bridge" mode before these settings changed.

WDS Mode:

Encryption Type:

WDS Key:

Peer Mac Address 1:   Enabled

Peer Mac Address 2:   Enabled

Peer Mac Address 3:   Enabled


Peer Mac Address 4:   Enabled

This type of wireless link is established between two IEEE 802.11 access points. Wireless packets transmitted along the WDS link comply with the IEEE 802.11 WDS (Wireless Distribution System) format at the link layer.

**Point-to-Point WDS Link**



**Point-to-Multipoint WDS Link**



The following table describes the labels in this screen.

Label	Description
<b>WDS Mode</b>	This mode provides Static LAN-to-LAN Bridging functionality. The static LAN-to-LAN bridging function is supported through Wireless Distribution System (WDS).
<b>Encryption Type</b>	Select the type of security for your wireless network
<b>WDS Key</b>	Fill in the encryption key when Encryption Type is TKIP or AES.
<b>Peer MAC Address</b>	Set the Mac address(es) of other access point(s). Simultaneity, choose "Enable".

If linked with WDS mode, they should obey the following rules:

1. IP Addresses should set different IPs in the same subnet.
2. All AP's DHCP Server should be disabled.
3. WDS should be enabled.
4. Each AP should have the same setting except 'Peer Mac Address' set to the other's Mac addresses

5. WEP Key and Channel should be the same.

### WDS – Restricted Mode

**Basic Setting --> WDS**

---

Operation mode of the AP should be set to "Bridge" mode before these settings changed.

WDS Mode: Restricted Mode

Encryption Type: None

WDS Key: None

Peer Mac Address 1:	<span style="border: 1px solid gray; padding: 2px;">TKIP</span>	<span style="border: 1px solid gray; padding: 2px;">00:AB:6C</span>	<input checked="" type="checkbox"/> Enabled
Peer Mac Address 2:	<span style="border: 1px solid gray; padding: 2px;">AES</span>	<span style="border: 1px solid gray; padding: 2px;"></span>	<input type="checkbox"/> Enabled
Peer Mac Address 3:	<span style="border: 1px solid gray; padding: 2px;"></span>	<span style="border: 1px solid gray; padding: 2px;"></span>	<input type="checkbox"/> Enabled
Peer Mac Address 4:	<span style="border: 1px solid gray; padding: 2px;"></span>	<span style="border: 1px solid gray; padding: 2px;"></span>	<input type="checkbox"/> Enabled

The peer WDS APs are according to the MAC address listed in "Peer Mac Address" fields.

### WDS – Bridge Mode

**Basic Setting --> WDS**

---

Operation mode of the AP should be set to "Bridge" mode before these settings changed.

WDS Mode: Bridge Mode


Encryption Type: None

WDS Key: None

Peer Mac Address 1:	<span style="border: 1px solid gray; padding: 2px;">TKIP</span>	<span style="border: 1px solid gray; padding: 2px;">00:AB:6C</span>	<input checked="" type="checkbox"/> Enabled
Peer Mac Address 2:	<span style="border: 1px solid gray; padding: 2px;">AES</span>	<span style="border: 1px solid gray; padding: 2px;"></span>	<input type="checkbox"/> Enabled
Peer Mac Address 3:	<span style="border: 1px solid gray; padding: 2px;"></span>	<span style="border: 1px solid gray; padding: 2px;"></span>	<input type="checkbox"/> Enabled
Peer Mac Address 4:	<span style="border: 1px solid gray; padding: 2px;"></span>	<span style="border: 1px solid gray; padding: 2px;"></span>	<input type="checkbox"/> Enabled

The working principle of the **Bridge Mode** is as follows:

**Bridge Mode**



In the figure, the AP behaves as a standard bridge that forwards traffic between WDS links (links that connect to other AP/wireless bridges) and an Ethernet port. As a standard bridge, the AP learns MAC addresses of up to 64 wireless or 128 total wired and wireless network devices, which are connected to their respective Ethernet ports. Only data destined for stations which are known to reside on the peer Ethernet link, multicast data or data with unknown destinations need to be forwarded to the peer AP via the WDS link.

**WDS – Repeater Mode**



Basic Setting --> WDS

Operation mode of the AP should be set to "Bridge" mode before these settings changed.

WDS Mode: Repeater Mode


Encryption Type: None

WDS Key: None

Peer Mac Address 1:	TKIP	00:AB:6C	<input checked="" type="checkbox"/> Enabled
Peer Mac Address 2:	AES		<input type="checkbox"/> Enabled
Peer Mac Address 3:			<input type="checkbox"/> Enabled
Peer Mac Address 4:			<input type="checkbox"/> Enabled

Apply Cancel

The working principle of the **Repeater Mode** is as follows:



In the figure, Repeater is used to extend the range of the wireless infrastructure by forwarding traffic between associated wireless stations and another repeater or AP connected to the wired LAN.

### 5.2.2.3 Setting Wireless

**Basic Setting --> Wireless**

---

These are the basic wireless settings for the AP.

SSID:

Channel:

Security Options

Security Type:

- None
- WEP
- WPA-PSK/WPA2-PSK
- WPA/WPA2

The following table describes the labels in this screen.

Label	Description
<b>SSID</b>	Service Set Identifier Default is the default setting. The SSID is a unique name that identifies a network. All devices on the network must share the same SSID name in order to communicate on the network. If you change the SSID from the default setting, input your new SSID name in this field.
<b>Channel</b>	Channel 6 is the default channel, input a new number if you want to change the default setting. All devices on the network must be set to the same channel to communicate on the network.
<b>Security options</b>	Select the type of security for your wireless network at <b>Security Type</b> :  <b>None:</b> Select for no security.  <b>WEP:</b> Select for security.  <b>WPA-PSK/WPA2-PSK:</b> Select for WPA-PSK or WPA2-PSK without a RADIUS server.  <b>WPA/WPA2:</b> Select for WPA (Wi-Fi Protected Access) authentication in conjunction with a RADIUS server.

#### Security Type – None

No security protection on your wireless LAN access.

## Security Type – WEP

### Basic Setting --> Wireless

These are the basic wireless settings for the AP.

SSID:

Channel:

Security Options

Security Type:

WEP Encryption:

Key Type:

Default Key Index:

KEY1:

KEY2:

KEY3:

KEY4:

1. Security Type: Select **WEP**
2. WEP Encryption: Select 64 Bit or 128 Bit WEP encryption.
3. Key Type: Select ASCII or Hex key type.
4. Default Key Index: Select one of the keys to be the active key.
5. Key 1-4: Input up to four encryption keys.

**ASCII** (American Standard Code for Information Interchange) is a code for representing English letters as numbers from 0-127. **Hex** digits consist of the numbers 0-9 and the letters A-F.

## Security Type – WPA-PSK/WPA2-PSK

### Basic Setting --> Wireless

These are the basic wireless settings for the AP.

SSID:

Channel:

Security Options

Security Type:

Encryption Type:  TKIP  AES

Shared Key:  (8~64 characters)

1. Security Type: Select **WPA-PSK/WPA2-PSK**.
2. Encryption Type: Select **TKIP** or **AES** encryption.
3. Share Key: Enter your password. The password can be between 8 and 64 characters.

### Security Type – WPA /WPA2

**Basic Setting --> Wireless**

---

These are the basic wireless settings for the AP.

SSID:

Channel:

Security Options

Security Type: WPA/WPA2

Radius Server IP:  .  .  .

Radius Port:


Shared Secret:

---

1. Security Type: Select **WPA/WPA2**
2. Radius Server IP: Enter the IP address of the RADIUS Server.
3. Port: Enter the RADIUS port (1812 is default).
4. Shared Secret: Enter the RADIUS password or key.

**RADIUS** (Remote Authentication Dial-in User Service) is the industrial standard agreement, and it is used to provide an identify verification. The Radius customer (is usually a dial-in server, VPN server or wireless point) sends your identification to the Radius server by Radius news. The Radius server validates the request of the Radius customer.

The principle of the Radius server is shown in the following pictures:



### 5.2.2.4 LAN Setting

The **Basic Setting**→**LAN Setting** page mainly sets IP addresses for LAN interface. To access the AP, a valid IP address of your LAN should be specified to the LAN interface. The default IP setting is DHCP server (Obtain an IP address automatically).

Basic Setting --> LAN Setting

---

LAN settings of AP.

Obtain an IP address automatically

Use the following IP address

IP Address:  .  .  .

Subnet Mask:  .  .  .

Default Gateway:  .  .  .

Obtain DNS server address automatically

Use the following DNS server addresses

Preferred DNS:  .  .  .

Alternate DNS:  .  .  .

Ethernet Mode:  Redundant  Switch

Spanning Tree Protocol:  Enable  Disable

---

The following table describes the labels in this screen.

Label	Description
-------	-------------

<p><b>Obtain an IP address automatically</b></p>	<p>Select this option if you would like to have an IP address automatically assigned to the APN-200/APN-200P by DHCP server in your network</p>
<p><b>Use the following IP address</b></p>	<p>Select this option if you are manually assigning an IP address.</p> <p><b>IP Address:</b> There is a default IP address in the AP, and you can input a new IP address.</p> <p><b>Subnet Mask:</b> 255.255.255.0 is the default Subnet Mask. All devices on the network must have the same subnet mask to communicate on the network.</p> <p><b>Default Gateway:</b> Enter the IP address of the router in your network.</p>
<p><b>Obtain DNS server address automatically</b></p>	<p>This option is selected by DHCP server.</p>
<p><b>Use the following DNS server addresses</b></p>	<p>This option is selected by manually set</p> <p><b>Preferred DNS:</b> There is a default DNS server, and you can input another new DNS server.</p> <p><b>Alternate DNS:</b> There is a default DNS server, and you can input another new DNS server.</p>

### 5.2.2.5 Setting DHCP Server

**Basic Setting --> DHCP Server**

---

The AP can be setup as a DHCP server to distribute IP addresses to the WLAN network.

DHCP Server       Enabled  Disabled

Options

Starting IP address:  .  .  .

Ending IP address:  .  .  .

Lease Time:  hours

DHCP Clients List:

Hostname	Mac Address	IP Address	Expires In
----------	-------------	------------	------------

---

The following table describes the labels in this screen.

Label	Description
<b>DHCP Server</b>	Enable or Disable the DHCP Server function. Enable – the switch will be the DHCP server on your local network
<b>Start IP Address</b>	The dynamic IP assign range. Low IP address is the beginning of the dynamic IP assigns range. For example: dynamic IP assign range is from 192.168.1.100 to 192.168.1.200. 192.168.1.100 will be the Start IP address.
<b>End IP Address</b>	The dynamic IP assign range. High IP address is the end of the dynamic IP assigns range. For example: dynamic IP assign range is from 192.168.1.100 to 192.168.1.200. 192.168.1.200 will be the End IP address
<b>Lease Time (Hour)</b>	It is the time period that system will reset the dynamic IP assignment to ensure the dynamic IP will not been occupied for a long time or the server doesn't know that the dynamic IP is idle.
<b>DHCP Clients List</b>	List the devices on your network that are receiving dynamic IP addresses from the APN-200/APN-200P.

## 5.2.3 Advanced Setting

### 5.2.4.1 Wireless

#### Advanced Setting --> Wireless

Wireless performance tuning.

Beacon Interval:  (msec, range:20~999, default:100)

DTIM Interval:  (range: 1~255, default:1)

Fragmentation Threshold:  (range: 256~2346, default:2346)

RTS Threshold:  (range: 1~2347, default:2347)

Xmit Power:  % (range: 1~100, default:100)

Wireless Mode:  BG Mixed Mode  B Mode  G Mode

Transmission Rate:  ▾

Preamble:  Long  Short

SSID Broadcast:  Enabled  Disabled

The following table describes the labels in this screen.

Label	Description
<b>Beacon Interval</b>	The default value is 100. The Beacon Interval value indicates the frequency interval of the beacon. A beacon is a packet broadcast by the AP to synchronize the wireless network. 50 is recommended in poor reception.
<b>DTIM Interval</b>	The default value is 1. This value, between 1 and 255 milliseconds, indicates the interval of the Delivery Traffic Indication Message (DTIM). A DTIM field is a countdown field informing clients of the next window for listening to broadcast and multicast messages. When the AP has buffered broadcast or multicast messages for associated clients, it sends the next DTIM with a DTIM Interval value. Its clients hear the beacons and awaken to receive the broadcast and multicast messages.
<b>Fragmentation Threshold</b>	This value should remain at its default setting of 2346. The range is 256-2346 bytes. It specifies the maximum size for a packet before data is fragmented into multiple packets. If you experience a high packet error rate, you may slightly increase the Fragmentation Threshold. Setting the Fragmentation Threshold too low may result in



	poor network performance. Only minor modifications of this value are recommended.
<b>RTS Threshold</b>	This value should remain at its default setting of 2347. The range is 0-2347 bytes. Should you encounter inconsistent data flow, only minor modifications are recommended. If a network packet is smaller than the preset RTS threshold size, the RTS/CTS mechanism will not be enabled. The AP sends Request to Send (RTS) frames to a particular receiving station and negotiates the sending of a data frame. After receiving an RTS, the wireless station responds with a Clear to Send (CTS) frame to acknowledge the right to begin transmission.
<b>Xmit Power</b>	This value ranges from 1 - 100 percent, default value is 100 percent. A safe increase of up to 60 percent would be suitable for most users. Higher power settings are not recommended for users due to excess heat generated by the radio chipset, which can affect the life of the AP.
<b>Wireless Network Mode</b>	If you have Wireless-G and 802.11b devices in your network, then keep the default setting, BG Mixed mode. If you have only Wireless-G devices, select G Mode. If you would like to limit your network to only 802.11b devices, then select B Mode.
<b>Transmission Rate</b>	The default setting is <b>Auto</b> . The range is from 1 to 54Mbps. The rate of data transmission should be set depending on the speed of your wireless network. You can select from a range of transmission speeds, or keep the default setting, Auto, to have the AP automatically use the fastest possible data rate and enable the Auto-Fallback feature. Auto-Fallback will negotiate the best possible connection speed between the AP and a wireless client.
<b>Preamble</b>	Values are Long and Short, default value is Long. If your wireless device supports the short preamble and you are having trouble getting it to communicate with other 802.11b devices, make sure that it is set to use the long preamble
<b>SSID Broadcast</b>	When wireless clients survey the local area for wireless networks to associate with, they will detect the SSID broadcast by the AP. To broadcast the AP SSID, keep the default setting, Enable. If you do not want to broadcast the AP SSID, then select Disable.

#### 5.2.4.2 MAC Filter

Use **Advanced Setting** → **MAC Filters** to allow or deny wireless clients, by their MAC

addresses, from accessing the APN-200/APN-200P. You can manually add a MAC address or select the MAC address from **Connected Clients** that are currently connected to the AP.

**Advanced Setting --> MAC Filters**

Filters are used to allow or deny Wireless Clients from accessing the AP.

MAC filter:  Enabled  Disabled

Options

- Only allow MAC address(es) listed below to connect to AP
- Only deny MAC address(es) listed below to connect to AP

MAC Filter List:

-----

Connected Clients: 00:0e:35:9f:cd:60

MAC Address:  :  :  :  :  :

The following table describes the labels in this screen.

Label	Description
<b>MAC Filter</b>	Enable or disable the function of MAC filter. MAC address allowed or denied option is selected by you.
<b>MAC Filter List</b>	This list will display the MAC addresses that are in the selected filter.
<b>Connected Clients</b>	This list will display the wireless MAC addresses that linked with AP.
<b>MAC Address</b>	MAC addresses need to be added to or clear from MAC filter list.
<b>Apply</b>	Click Apply to set the configurations.

**5.2.4.3 System Event**

When the AP event is triggered, the notification procedure will be performed according to the type of the event. Which notification would be performed depends on the selection of corresponding option in the **Advanced Setting → System Event** page.

Advanced Setting --> System Event

System Event Configuration.

Device Event Notification			
Hardware Reset (Cold Start)	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Software Reset (Warm Start)	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Login Failed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
IP Address Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Password Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Redundant Power Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
SNMP Access Failed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Wireless Client Associated	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Wireless Client Disassociated	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog

Fault Event Notification and Fault LED/Relay				
Power 1 Fault	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog	<input type="checkbox"/> Fault LED/Relay
Power 2 Fault	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog	<input type="checkbox"/> Fault LED/Relay
POE Fault	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog	<input type="checkbox"/> Fault LED/Relay
Eth1 Link Down	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog	<input type="checkbox"/> Fault LED/Relay
Eth2 Link Down	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog	<input type="checkbox"/> Fault LED/Relay

System events record the activities of the AP system. When the settings change, the event will be sent to administrator by email. A trap will also be sent to SNMP server. The Syslog will record the event locally and may send the log remotely to a Syslog server. If serious event occurred, such as the power failure or link down, the fault LED will be switched on as warning.

**Email Settings**

E-mail settings

SMTP Server:

Server Port:  (0 represents default)

E-mail Address 1:

E-mail Address 2:

E-mail Address 3:

E-mail Address 4:

The following table describes the labels in this screen.

Label	Description
<b>SMTP Server</b>	Simple Message Transfer Protocol, enter the backup host to use if primary host is unavailable while sending mail by SMTP server.
<b>Server Port</b>	Specify the port where MTA can be contacted via SMTP server.
<b>E-mail Address 1-4</b>	Inputs specify the destination mail address.

### SNMP Settings

SNMP settings

SNMP Agent:  Enable  Disable

SNMP Trap Server 1:

SNMP Trap Server 2:

SNMP Trap Server 3:

SNMP Trap Server 4:

Community:

SysLocation:

SysContact:

The following table describes the labels in this screen.

Label	Description
<b>SNMP Agent</b>	SNMP (Simple Network Management Protocol) Agent is a service program that runs on the access point. The agent provides management information to the NMS by keeping track of various operational aspects of the AP system. Turn on to open this service and off to shutdown it.
<b>SNMP Trap Server 1-4</b>	Specify the IP of trap server, which is the address to which it will send traps AP generates.
<b>Community</b>	Community is essentially password to establish trust between managers and agents. Normally "public" is used for read-write community.
<b>SysLocation</b>	Specify sysLocation string.

<b>SysContact</b>	Specify sysContact string.
-------------------	----------------------------

### Syslog Server Settings

Syslog Server settings

Syslog Server IP:

Syslog Server Port:  (0 represents default)

The following table describes the labels in this screen.

Label	Description
<b>Syslog Server IP</b>	Not only the syslog keeps the logs locally, it can also log to remote server. Specify the IP of remote server. Leave it blank to disable logging remotely.
<b>Syslog Server Port</b>	Specify the port of remote logging. Default port is 514.

## 5.2.4 System Tools

### 5.2.4.1 Administrator

In this page, you can change the username and password. The new password must be typed twice to confirm (the default Name and Password is “**admin**” and “**admin**”).

**System Tools --> Administrator**

---

Modify web administrator's name and password.

Old Name:

Old Password:

New Name:

New Password:

Confirm New Password:

Web Protocol:  HTTP  HTTPS

Port:

---

The following table describes the labels in this screen.

Label	Description
<b>Old Name</b>	This field displays the old login name. It's read only. The default value of login name is "admin".
<b>Old Password</b>	Before making a new setting, you should provide the old password for a verify check. Acceptable inputs of this field contains '0-9', 'a-z', 'A-Z' and must be between 0 to 15 characters in length. The factory default value of login password is null.
<b>New Name</b>	Enter a new login name. Acceptable inputs of this field contains '0-9', 'a-z', 'A-Z' and must be between 1 to 15 characters in length. This field can not accept null input.
<b>New Password</b>	Enter a new login password. Acceptable inputs of this field contains '0-9', 'a-z', 'A-Z' and must be between 0 to 15 characters in length.
<b>Confirm New Password</b>	Retype the password to confirm it. Acceptable inputs of this field contains '0-9', 'a-z', 'A-Z' and must be between 0 to 15 characters in length.
<b>Web Protocol</b>	Choose on the protocol for web. The default value is <b>HTTP</b> , if you want the web pages' security is better, choose the <b>HTTPS</b> protocol.
<b>Port</b>	Corresponding to the Web protocol, there is a default port (HTTP: 80, HTTPS: 443). And you can enter another number which should be in range of 1-65535.

**HTTPS** (HTTP over SSL) is a Web protocol developed by Netscape and built into its browser that encrypts and decrypts user page requests as well as the pages that are returned by the Web server.

#### 5.2.4.2 Date & Time

In this page, set the date & time of the device. The correct date & time will be helpful for logging of system events. A NTP (Network Time Protocol) client can be used to synchronize date & time with NTP server.

**System Tools --> Date/Time**

---

Date/Time settings.

Local Date:    2007 Year 10 Month 12 Day

Local Time:    16 Hour 7 Minute 43 Second

Time Zone:    GMT+08:00 ▼

Get Current Date & Time from Browser

NTP:             Enable

NTP Server 1:    time.nist.gov

NTP Server 2:    time.windows.com (optional)

Synchronise:    Every Hour ▼ at 00 ▼ : 00 ▼

---

Apply    Cancel

The following table describes the labels in this screen.

Label	Description
<b>Local Date</b>	Set local date manually.
<b>Local Time</b>	Set local time manually.
<b>Time Zone</b>	Select the time zone manually
<b>Get Current Date &amp; Time from Browser</b>	Click this button; you can set the time from browser.
<b>NTP</b>	Enable or disable NTP function to get the time from the NTP server.
<b>NTP Server 1</b>	The initial choice about NTP Server.
<b>NTP Server 2</b>	The second choice about NTP Server.
<b>Synchronize</b>	Set the time, and the AP's time synchronize with the NTP Server at the time

### 5.2.4.3 Configuration

**System Tools --> Configuration**

---

You can backup the configuration file to your computer, and restore a previously saved configuration.

Save configuration to local

Restore a previously saved configuration

Use the button below to restore the default settings

---

The following table describes the labels in this screen.

Label	Description
<b>Download configuration</b>	The current system settings can be saved as a file onto the local hard drive.
<b>Upload configuration</b>	The saved file or any other saved setting file can be uploaded back on the AP. To reload a system settings file, click on <b>Browse</b> to browse the local hard drive and locate the system file to be used. Click <b>Upload</b> when you have selected the file to be loaded back onto the AP.
<b>Restore Default Settings</b>	You may also reset the APN-200/APN-200P back to factory settings by clicking on <b>Restore Default Settings</b> . Make sure to save the unit's settings before clicking on this button. You will lose your current settings when you click this button.

### 5.2.4.4 Firmware Upgrade

**System Tools --> Firmware Upgrade**

---

**Do NOT power off the AP while upgrading!**

Current Firmware Version: 1.1b

---

New firmware may provide better performance, bug fixes or more functions. To upgrade,




you need a firmware file correspond to this AP model. It will take several minutes to upload and upgrade the firmware. After the upgrade is done successfully, the access point will reboot and get revalidated.

**Important Notice:** DO NOT POWER OFF THE AP OR PRESS THE RESET BUTTON WHILE THE FIRMWARE IS BEING UPGRADED.

#### 5.2.4.5 Miscellaneous

If you want restart the access point through the **Warm Reset**, click **Restart Now** to restart the AP.



## 5.2.5 System Status

### 5.2.5.1 System Info

System Status --> System Info

---

System information details.

**Model**  
 Model Name: APN-200  
 Model Description: 2-port 10/100TX LAN Redundant to 802.11b/g Wireless LAN Access Point

**Firmware**  
 Version: 1.2e

**Ethernet**  
 MAC Address: 00:12:44:57:89:21  
 IP Address: 192.168.1.48  
 Subnet Mask: 255.255.255.0  
 Default Gateway: 192.168.1.1  
 DHCP Server: Disabled

**Operation Mode**  
 Operation Mode: AP

**Wireless**  
 MAC Address: 00:12:0E:95:19:8F  
 SSID: RT61AP95198F  
 Encryption: 64-bit WEP  
 Channel: 4

**Device Time**  
 Current Time: Wed, 07 May 2008 03:40:20 +0800

This page displays the current information for the APN-200/APN-200P. It will display model, as well as firmware version, Ethernet, Wireless info and device time.

### 5.2.5.2 System Log

System Status --> System Log

---

System log details.

#	Date Time	Content
---	-----------	---------

The system log tracks the important events and setting changes of the AP. If the AP is rebooted, the logs are automatically cleared.

Click the button '**Refresh**' to refresh the page.

Click the button '**Clear**' to clear the log entries.

### 5.2.5.3 Traffic Statistics

[System Status --> Traffic Statistics](#)

---

Traffic statistics display received and transmitted packets passing through the AP.

Interface	Send	Receive
Ethernet	66584 Packets	109511 Packets
Wireless	5870 Packets	77776 Packets

---

This page displays the network traffic statistics for both received and transmitted packets through the Ethernet port and wireless connections associated with the AP. Simultaneously, the traffic counter will reset by the device rebooting.

### 5.2.5.4 Wireless Clients

[System Status --> Wireless Clients](#)

---

List of connected wireless clients.

Mac Address	Send	Receive	Current TxRate
00:0e:35:9f:cd:60	6589 Bytes	11748 Bytes	48 Mbps

---

This page of the list displays the **Mac Address** of the wireless clients connected. **Current TX Rate** is corresponding to the **Transmission Rate** in the **Advanced Setting → Wireless** pages.

### 5.2.6 Online Help

Click on any item in the **Online Help** screen for more information.

## Index

### Home

- Setup Wizard

### Basic Setting

- Operation Mode
- WDS
- Wireless
- LAN Setting
- DHCP Server

### Advanced Setting

- Wireless
- MAC Filter
- Email/SNMP/Syslog
- System Event

### System Tools

- Administrator
- Date & Time
- Configuration
- Firmware Upgrade
- Miscellaneous

### System Status

- System Info
- System Log
- Traffic Stats
- Wireless Clients

## Home -> Setup Wizard

### Setup Wizard

The Setup Wizard is a useful and easy utility to help setup the AP to quickly adapt it to your existing network with only a few steps required. It will guide you step by step to configure the settings of the AP. The Setup Wizard is a helpful guide for first time users to the AP.

For step 1, you can set a new login password if required, the default login name is 'admin', and default login password is null.

For step 2, you can set the wireless SSID name and channel, a default SSID has been provided for you. By default the channel is set to 6.

For step 3, set the wireless encryption to WEP will strengthen the security of the wireless network, or just leave encryption disabled and anyone can connect to the AP.

For step 4, save the previous settings and revalidate the AP.

# 6

## Technical Specifications

<b>LAN Interface</b>	
RJ45 Ports	2 x 10/100Base-T(X), Auto MDI/MDI-X
Protection	Built-in 1.5KV magnetic isolation
Protocols	ICMP, IP, TCP, UDP, DHCP, BOOTP, ARP/RARP, DNS, SNMP MIB II, HTTPS, SSH, SNMPV1/V2, Trap, Private MIB
P.O.E. PD	Present at ETH2 of APN-200P Power Device (IEEE802.3af): IEEE 802.3af compliant input interface Power consumption: 8Watts max. Over load & short circuit protection Isolation Voltage: 1000 VDC min. Isolation Resistance: 10 <sup>8</sup> ohms min
<b>WLAN Interface</b>	
Operating Mode	AP/Bridge/Repeater
Antenna Connector	Reverse SMA
Radio Frequency Type	DSSS
Modulation	IEEE802.11b: CCK, DQPSK, DBPSK IEEE802.11g: OFDM with BPSK, QPSK, 16QAM, 64QAM
Frequency Band	America/FCC: 2.412~2.462 GHz (11channels) Europe CE/ETSI: 2.412~2.472 GHz (13channels)
Transmission Rate	IEEE802.11b: 1/2/5.5/11 Mbps IEEE802.11g: 6/9/12/18/24/36/48/54 Mbps
Transmit Power	IEEE802.11b/g: 18dBm
Receiver Sensitivity	-81dBm@11Mbps, PER< 8%;

	-64dBm@54Mbps, PER< 10%
Encryption Security	WEP: (64-bit, 128-bit key supported) WPA: WPA2:802.11i (WEP and AES encryption) PSK (256-bit key pre-shared key supported) 802.1X and Radius supported TKIP encryption
Wireless Security	SSID broadcast disable
LED Indicators	PWR 1(2) (P.O.E., APN-200P) / Ready: 1) Red On: Power is on and booting up. Red Blinking: Indicates an IP conflict, or DHCP or BOOTP server did not respond properly. 2) Green On: Power is on and functioning normally. Green Blinking: Located by Administrator. ETH1 (2) Link / ACT: Orange ON/Blinking: 10 Mbps Ethernet Green ON/Blinking: 100 Mbps Ethernet WLAN Link/ACT: Green: Link, Orange: Poor signal WLAN Strength:1<25%, 2<50%, 3<75%, 4<100% Fault: WLAN link down (Red)
<b>Power Requirements</b>	
Power Input Voltage	PWR1/2: 12 ~ 48VDC in 6-pin Terminal Block
Reverse Polarity Protection	Present
Power Consumption	6 Watts Max
<b>Environmental</b>	
Operating Temperature	-10 to 70°C
Storage Temperature	-35 to 75°C
Operating Humidity	5% to 95%, non-condensing
<b>Mechanical</b>	
Dimensions(W x D x H)	52 mm(W)x 106 mm( D )x 144 mm(H)
Casing	IP-30 protection
<b>Regulatory Approvals</b>	

Regulatory Approvals	CE class A RoHS
EMS	EN61000-4-2 (ESD), EN61000-4-3 (RS), EN61000-4-4 (EFT), EN61000-4-5 (Surge), Level 3, EN61000-4-6 (CS), Level 3
Shock	IEC60068-2-27
Free Fall	IEC 60068-2-32
Vibration	IEC 60068-2-6