

# Quick Start Guide

---

MF271 Rogers Rocket Hub

**ZTE**



# LEGAL INFORMATION

Copyright © 2014 ZTE CORPORATION.

All rights reserved.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or update specifications without prior notice.

Version No. : R1.0

# Getting to Know Your Device

The device operates on the 4G/3G/HSPA+/LTE networks and supports voice and data service.


## Indicators



Indicator	State	Description
 (Power & battery)	Green steady	External power supply is working normally
	Green blinking	Battery power is more than 50%
	Yellow blinking	Battery power is less than 20%-50%.
	Red blinking	Battery power is less than 20%
	Off	Power is off or external power supply is working abnormally.
 (Voice-mail)	Green blinking	New voicemail.
	Off	No new voicemail.
 (Information)	Green blinking	Check Web UI: New SMS, data balance, Micro-SIM issue and etc.
	Off	No need to check Web UI.

 (Wi-Fi)	Green steady	Wi-Fi works normally with no data transmission.
	Green blinking	Wi-Fi works normally with data transmission.
	Off	The Wi-Fi function is disabled.
 (Signal strength)	Green steady	Signal strength is strong.
	Yellow steady	Signal strength is weak.
	Red steady	No service, limited service or searching for service.
	Red blinking	Micro-SIM checking, Micro-SIM error or other abnormal status

## Interface Description



Port/Button	Description
1. WPS	Press to enable the Wi-Fi Protected Setup.
2. PHONE1/PHONE2	Standard RJ11 connector for telephone.
3. ETHERNET	Ethernet connector for computer.
4. POWER INPUT	Connector to the external power supply.
5. ON/OFF	Turn the device ON or OFF.


# Installation Guide

## Installing the Micro-SIM Card and battery


1. Slide the back cover and remove it



2. Insert the Micro-SIM card.




3. Insert the battery.



4. Replace the back cover.

## Connecting Your Devices

Follow the numbers to connect your devices.



## Switching On Your Device

1. Turn the ON/OFF button on to get started. Make sure that the phone is on hook before you power it on.
2. Wait 1 ~ 2 minutes and then the Power and battery indicator should be lit on.

## Connecting to the Internet

### Via Ethernet

Go to your favorite website on the PC connected to your device via Ethernet cable to confirm your Internet connection.

### Via Wi-Fi


1. Use the Wi-Fi application on a client to search for available wireless networks.



## NOTE:

Set the client to obtain an IP address automatically. For the detailed procedure, refer to *Configuring Your PC*. The client gets an IP address, for example, 192.168.0.101.

2. Select the SSID of your device, and then click **Connect**.



## NOTE:

You can find the default SSID on the label of your device.

3. Enter the password, and then click **Connect**.



**NOTE:**


You may need to enter the password for the Wi-Fi connection. You can view the label on your device to get the default password.

4. Wait until the client is connected to your device successfully.
5. Go to your favorite website to confirm your Internet connection.

# Configuring Your PC

The following procedure describes how to configure the Internet Protocol in the Windows XP operating system for your Wi-Fi connection.


1. Right-click **My Network Places** and select **Properties**.




2. Right-click **Wireless Network Connection** and select **Properties**.



3. Select **Internet Protocol (TCP/IP)** and click **Properties**.



4. Select **Obtain an IP address automatically** and **Obtain DNS server address automatically**, and click **OK**.



For more information, please refer to the detailed User Guide online at [www.rogers.com/userguide.com](http://www.rogers.com/userguide.com).