

USB-CANmodul

**GW-001, GW-002,
3004006, 3204xxx, 3304xxx,
3404xxx**

Systems Manual

Preliminary

Edition February 2015

This manual comprises descriptions for copyrighted products, which are not explicitly indicated as such. The absence of the trademark (™) and copyright (©) symbols does not infer that a product is not protected. Additionally, registered patents and trademarks are similarly not expressly indicated in this manual

The information in this document has been carefully checked and is believed to be entirely reliable. However, SYS TEC electronic GmbH assumes no responsibility for any inaccuracies. SYS TEC electronic GmbH neither gives any guarantee nor accepts any liability whatsoever for consequential damages resulting from the use of this manual or its associated product. SYS TEC Electronic GmbH reserves the right to alter the information contained herein without prior notification and accepts no responsibility for any damages, which might result.

Additionally, SYS TEC electronic GmbH offers no guarantee nor accepts any liability for damages arising from the improper usage or improper installation of the hardware or software. SYS TEC electronic GmbH further reserves the right to alter the layout and/or design of the hardware without prior notification and accepts no liability for doing so.

© Copyright 2015 SYS TEC electronic GmbH, D-08468 Heinsdorfergrund. Rights - including those of translation, reprint, broadcast, photomechanical or similar reproduction and storage or processing in computer systems, in whole or in part - are reserved. No reproduction may occur without the express written consent from SYS TEC electronic GmbH.

	Directly	Your local distributor
Address:	SYS TEC electronic GmbH Am Windrad 2 D-08468 Heinsdorfergrund GERMANY	You find a list of our distributors under http://www.systec-electronic.com/distributors
Ordering Information:	+49 (0)3765 38600-0 info@systec-electronic.com	
Technical Support:	+49 (0)3765 38600-2140 support@systec-electronic.com	
Fax:	+49 (0)3765 38600-4100	
Web Site:	http://www.systec-electronic.com	

29th Edition February 2015

Table of Contents

Preface	1
Introduction	3
1 Getting Started	12
1.1 Installation	12
1.1.1 Installation of the USB-CANmodul under Windows-OS	12
1.1.2 Software Installation	12
1.1.3 Updating an Existing Installation	14
1.1.4 Verifying the Device Installation	15
1.1.5 Device Number Allocation	16
1.1.6 Connection to a CAN Network	17
1.1.7 Starting PCANView (USBCAN).....	18
1.1.8 Creating a debug file from DLL	25
1.1.9 Activation of the network driver.....	26
1.2 Status LEDs on the USB-CANmodul	27
1.3 CAN Supply Voltage	29
1.4 CAN-port with Low-Speed CAN Transceiver	30
1.5 Expansion Port.....	31
1.6 Termination resistor for CAN bus	34
1.7 Order Options	35
1.8 The new sysWORXX USB-CANmoduls.....	37
1.8.1 The Multiport CAN-to-USB.....	37
1.8.2 The USB-CANmodul1	38
1.8.3 The USB-CANmodul2.....	39
1.8.4 The USB-CANmodul8 and USB-CANmodul16	39
1.8.5 The USB-CANmodul2 IP65.....	40
2 Software Support for Windows OS	41
2.1 File Structure	41
2.2 Tools for the USB-CANmodul	42
2.2.1 USB-CANmodul Control	42
2.2.2 PCANView (USBCAN) for Windows	43
2.3 Description of the USBCAN-library	45
2.3.1 Attributes of the USBCAN-library	45
2.3.2 Functions of the USBCAN-library	48
2.3.2.1 General functions.....	49
2.3.2.2 Functions for automatic transmission	106
2.3.2.3 Functions for the CAN Port.....	111
2.3.2.4 Functions for the Expansion Port.....	116
2.3.3 Error Codes of the Functions	121
2.3.4 Baud Rate Configuration	128
2.3.4.1 Baud Rate Configuration for GW-001 and GW-002	128
2.3.4.2 Baud Rate Configuration for sysWORXX Modules.....	130
2.3.4.3 Baud Rate Configuration for Fourth Generation - USB-CANmodul	134
2.3.4.4 Use of non-listed Bit-Rates	137
2.3.5 CAN Messages Filter Function	138
2.3.6 Using multiple CAN-channels	141
2.3.7 Using the Callback Functions	141
2.4 Class library for .NET programming languages	151
2.4.1 Methods of class USBcanServer	152

2.4.1.1	General methods	152
2.4.1.2	Methods for Automatic Sending	174
2.4.1.3	Static Help Methods of Class USBcanServers	177
2.4.2	Event of class USBcanServer	187
2.4.3	Properties of Class USBcanServer	192
3	Software support for Linux OS	194
4	Software support for Windows CE OS	196
4.1	Installation of the driver under Windows CE	196
4.2	API functions under Windows CE	197
4.3	Logging debug information	197
5	Known issues	199
6	Index	200

Index of Figures and Tables

Figure 1:	Installation of the driver at Windows Vista	14
Figure 2:	Device Manager with the USB-CANmodul	15
Figure 3:	USB-CANmodul Control Tool	16
Figure 4:	Device Number Selection Dialog Box	17
Figure 5:	Dialog Box with Hardware Configuration	18
Figure 6:	Dialog Box Message Filter Configuration	19
Figure 7:	PCANView (USBCAN) Main Window	20
Figure 8:	precisely timed CAN messages in PCANView (USBCAN)	21
Figure 9:	configuration of cyclic CAN messages in PCANView (USBCAN)	21
Figure 10:	Debug settings in USB-CANmodul Control	25
Figure 11:	Location of CAN and Expansion Port on GW-002	31
Figure 12:	Location of the Expansion Port on USB-CANmodul2	32
Figure 13:	Position of expansion plugs on USB-CANmodul2 G4	32
Figure 14:	simple example circuit for Expansion Port	33
Figure 15:	termination resistors on CAN bus	34
Figure 16:	Internal structure of the Multiport CAN-to-USB	37
Figure 17:	Dialog Box for Manipulating the Port Expansion and the CAN Port	42
Figure 18:	Software State Diagram	46
Figure 19:	Example for parallel mode with two defined CAN messages	106
Figure 20:	Example of sequential mode with two defined CAN messages	106
Figure 21:	Structure of baud rate register BTR0	129
Figure 22:	Structure of baud rate register BTR1	129
Figure 23:	General structure of a single bit on the CAN-bus	129
Figure 24:	Format of the extended baud rate register for sysWORXX-Modules	131
Figure 25:	Generic structure of one bit on the CAN-bus	131
Figure 26:	Format of the increased baud rate register for fourth generation modules	134
Figure 27:	Calculation of Bit-Timing for Fourth Generation Modules	135

Table 1:	States of the LEDs on the USB-CANmodul GW-001/GW-002.....	27
Table 2:	States of the LEDs on the sysWORXX modules	28
Table 3:	Pinout of the CAN DB-9 Plug	29
Table 4:	Signals available for low-speed CAN port.....	30
Table 5:	CAN Port Pin Assignment for External Transceiver on the GW-002	30
Table 6:	Expansion Port Pin Assignment on the GW-002 and USB-CANmodul2	31
Table 7:	Expansion Port Signal Properties on GW-002	31
Table 8:	Expansion Port Signal Properties on USB-CANmodul2 G3.....	32
Table 9:	<i>Properties of port expansion on USB-CANmodul2 G4.....</i>	33
Table 10:	recommended cable parameters	34
Table 11:	Software File Structure.....	41
Table 12:	Software State Functions	47
Table 13:	Constants for the type of version information.....	51
Table 14:	Constants for CAN transmission mode.....	70
Table 15:	Constants for Product-Code / Hardware-Type	82
Table 16:	Constants for the CAN-frame format	94
Table 17:	Constants for the flags parameter in function UcanGetMsgPending()	103
Table 18:	Constants for the flags parameter in function UcanEnableCyclicCanMsg()	111
Table 19:	Constants for low speed CAN portReturn value:.....	114
Table 20:	Examples for non-listed bit rates	137
Table 21:	Constants for CAN-channel selection	141
Table 22:	tested Windows CE versions and CPU types	196

Preface

This USB-CANmodul Systems Manual describes the board's design and function. Precise specifications for the on-board microcontrollers can be found in the enclosed microcontroller Data Sheet/User's Manual.

In this manual, and in the attached schematics, low active signals are denoted by a "/" in front of the signal name (i.e.: /RD). A "0" indicates a logic-zero or low-level signal, while a "1" represents a logic-one or high-level signal.

Declaration of Electro Magnetic Conformity for the SYS TEC USB-CANmodul



The USB-CANmodul is a tested and ready-to-use interface device and must only be used as such.

Note:

The USB-CANmodul should not be operated without additional protection circuitry and further testing if cables to the product's connectors are longer than 3 m. It is required to use shielded CAN cables.

The USB-CANmodul fulfills the norms of the European Union's Directive for Electro Magnetic Conformity only in accordance to the descriptions and rules of usage indicated in this hardware manual (particularly in respect to the described steps for putting the device into operation).

Implementation of SYSTEC products into target devices, as well as user modifications and extensions of SYSTEC products, is subject to renewed establishment of conformity to, and certification of, Electro Magnetic Directives. Only after doing so the devices are allowed to be put into circulation.

Introduction

Unveiled in 1995, the **Universal Serial Bus (USB)** connectivity standard provides a simple and convenient way to connect various peripheral devices to a host-PC. It will replace a wide variety of serial and parallel connections. The USB standard allows up to 127 devices to be connected to the PC without using multiple connector types, without interrupt conflicts (IRQs), hardware address adjustments (jumpers) or channel changes (DMA). USB provides powerful true hot plug-and-play capability; i.e., dynamic attach and recognition for new devices. It allows the user to work with those devices immediately without restarting the operating system.

The USB-CANmodul takes advantage of this communication standard and provides an easy to use portal from a host-PC to a CAN network. Connecting the USB-CANmodul to the host-PC is simple. The included USB cable supports the two types of USB connectors, type A and type B. The type A plug connects to the host computer or an upstream hub. Type B plug connects downstream to the USB-CANmodul. The USB interface enables data transfer with a rate of up to 12 MBit/s. With a uniform connector for all device types, the system is absolutely user friendly.

Once the USB-CANmodul is connected to the host-PC, the operating system reads the configuration data and automatically loads the device driver. All CAN messages are transferred transparently through the USB Bus. CAN Baud Rates of up to 1 MBit/s are supported. The transmitted and received CAN messages are buffered by the USB-CANmodul. The device supports CAN messages according to CAN 2.0A and 2.0B specifications (11- and 29-Bit identifiers). Connection to the CAN bus meets the CiA Standard DS 102 (DB-9) and features optional optical isolation of the CAN signals.

Drivers for Linux, LabView (contributed), Windows 2000/XP, Vista, 7 and 8 as well as Linux are provided for the USB-CANmodul. The USB configuration tool for Windows enables connectivity and management of more than one device on the USB bus. This USB network is configured using device numbers which are assigned by the user and are stored in an EEPROM. The functions for data exchange with the USB-CAN application are available through a DLL (Dynamic Linked Library). The enclosed demo program shows the easy handling of the DLL API functions.

This manual refers to the following USB-CANmodul versions:

Order number	Features
GW-001	<p>Obsolete, but software support for compatibility reasons.</p> <ul style="list-style-type: none"> - Galvanic isolation configurable via Jumper. - No Software support since Windows driver version V4.00. <p>This hardware is only supported until driver version V4.18r2.</p>
GW-002	<p>Obsolete, but software support for compatibility reasons.</p> <ul style="list-style-type: none"> - More compact housing: 102x54x30 (LxBxH in mm), protection class IP40, supports DIN-rail mounting - USB-CANmodul with galvanic isolated available under separate order number. Thus, it is no longer needed to open the housing and to supply power via CAN-bus. - CAN-ground (CAN-GND) and CAN-shield (CAN-SHLD) not connected internally. - Various CAN-transceivers available optionally for low-speed CAN or single-wire CAN, special PCB pads and socket connector for assembly of special CAN-transceivers - External power supply of up to 30V possible, depending on the CAN-transceiver used - Micro controller's 8-bit user port (I/O with TTL level) provides for customer-specific extensions - Further CAN-transceivers adaptable via plug-in slot on board <p>This hardware is only supported until driver version V4.18r2.</p>
3004006	<p>Multiport CAN-to-USB with 16 CAN-channels</p> <ul style="list-style-type: none"> - 19" rack mounted device - Contains 8 logical devices with 2 channels each. - Fast 32-bit microcontroller - External power-supply with 230VAC/500mA (inlet connector for non-heating devices) - Galvanic isolation of the CAN-channels

Order number	Features
3204000, 3204001, 3304001, 3304004, 3304002	<p>USB-CANmodul1</p> <ul style="list-style-type: none"> - more compact enclosure with dimensions of 78x45x18 (LxWxH in mm) - Single CAN interface - Fast 32-bit MCU, enhanced firmware - Power-supply via USB, current consumption max. 110mA - High-speed CAN transceiver 82C251 - Galvanic isolation available with order no. 3204001 <p>USB-CANmodul1 Revision 2 (R2)</p> <ul style="list-style-type: none"> - same as above but includes better EMC behaviour - 120 ohm termination resistor can be set at PCB <p>USB-CANmodul1 Revision 3 (R3)</p> <ul style="list-style-type: none"> - same as Revision 2 but with changed capacities <p>USB-CANmodul1 Revision 5 (R5 – fourth generation)</p> <ul style="list-style-type: none"> - Redesign with new 32 Bit micro controller. - 1 CAN-channel - Power-supply via USB-cable - Highspeed CAN-transceiver 82C251 galvanically isolated
3204002, 3204003, 3204007, 3204008, 3204009, 3204011, 3204013, 3204017, 3204018, 3204019, 3304003, 3304005	<p>USB-CANmodul2</p> <ul style="list-style-type: none"> - Two CAN-channels, independently utilizable - Fast 32-bit MCU, enhanced firmware - Power-supply via USB - High-speed CAN transceiver 82C251 or Low-speed CAN transceiver TJA1054 or Single-wire CAN transceiver AU5790 - Galvanic isolation available with order no. 3204003 - Micro controller's 8-bit user port (I/O with TTL level) provides for customer-specific extensions with order no. 3204007 <p>USB-CANmodul2 Revision 2 (R2)</p> <ul style="list-style-type: none"> - same as above but includes better EMC behaviour <p>USB-CANmodul2 Revision 3 (R3 – fourth Generation)</p> <ul style="list-style-type: none"> - Redesign with new 32 Bit micro controller. - 2 CAN-channels - Power supply USB-cable - Highspeed CAN-transceiver 82C251 or Lowspeed CAN-Transceiver TJA1054 resp. Single-Wire CAN-transceiver AU5790 - Galvanically isolated <p>Customer specific extensions via a free 8 Bit Port on the micro controller (only with 3204007)</p>

Order number	Features
3404000, 3304000	USB-CANmodul8 <ul style="list-style-type: none"> - 8 CAN-channels, independently utilizable - Table case - Contains 4 logical devices with 2 channels each - Fast 32-bit MCU, enhanced firmware - External power-supply with 230VAC/500mA (inlet connector for non-heating devices) - Galvanic isolation of the CAN-channels
3404001	USB-CANmodul16 <ul style="list-style-type: none"> - 16 CAN-channels, independently utilizable - Table case - Contains 8 logical devices with 2 channels each - Fast 32-bit MCU, enhanced firmware - External power-supply with 230VAC/500mA (inlet connector for non-heating devices) - Galvanic isolation of the CAN-channels

References to Hardware and Software changes

In this section you will find references to new functions in the hardware and software of the USB-CANmodul.

Software Version 4.17

- Bugfix: The old window position of PCANView(USBCAN) has also been set on a second monitor, if this second monitor has not been plugged.
- Bugfix: Context-Menu „Change parameters...” within hardware tab-sheet of UBS-CANmodul Control did not function.
- Bugfix: In tab-sheet „Debug“ of USB-CANmodul Control the browse dialogue could not be used to enter a directory for the Debug Log file under Windows 7.
- Bugfix: Under Windows XP the USB-CANmodul Control could not be initiated from the system control. Notice “execute as...” was displayed.
- Bugfix: If an application crashed (e.g. a protection fault), which initiated an USB-CANmodul, this USB-CANmodul could not be re-initialized by any application on the computer.
- New feature: LabView Demo for LabView 2011

Software Version 4.18

- Bugfix: An access violation appeared in USBCAN32.DLL resp. USBCAN64.DLL, if an application was initiated with a Windows profile without administrator rights.
- Bugfix: The bus-off handling was changed for all sysWORXX USB-CANmoduls.
- Bugfix: Das automatische Firmware-Update der sysWORXX USB-CANmodul funktionierte in V4.17 nicht.
- Driver tested under Windows 8 (32 Bit und 64 Bit) and under Windows Server 2012 (64 Bit). No problems discovered.

Software Version 5.00

- New feature: Support for new hardware USB-CANmodul1 fourth generation.
- Bugfix: At times the USB-CANmodul Control did not display all connected modules. That was the case when simultaneously USB-CANmoduls worked either with the standard driver or the network driver.
- Bugfix: While read-out of EEPROM the EEPROMs content from address 0x0000 to 0x00FF was mirrored every 256 bytes. Additionally: read-out- and write performance was increased.

Software Version 5.01

- New feature: Support of new hardware USB-CANmodul2 fourth generation.
- Bugfix: Fourth generation - USB-CANmodul could lose CAN-reports receive-site, if many CAN-reports appeared in close succession over CAN-bus.
- Bugfix: Endless firmware-update on USB-CANmodul8 and -16.

Software Version 5.02

- New feature: For fourth generation - USB-CANmoduls the time-stamp for reception messages can be adjusted on 100µs.
- New feature: If a fourth generation - USB-CANmodul is plugged the first time on another USB-Port, kernel-drivers are not being installed again.
- Bugfix: User-specific CAN-bit rates could not be set on fourth generation of USB-CANmoduls.
- Bugfix: If a multitude of 4 CAN-reports were sent all at the same time via a fourth generation - USB-CANmodul, this was executed with a delay to the CAN-Bus.

Software Version 5.03

- Software changed: Forced firmware update is necessary for the 4th generation of USB-CANmoduls. The update process lasts for longer time. Please do not unplug the module from USB port until the update process has been finished.
- New feature: The USB-CANmodul Control shows the module type of USB-CANmodul2 of 4th generation in hardware tab-sheet.

Software Version 5.04

- Software changed: Driver support for GW-001 and GW-002 removed. For these obsolete devices the version V4.18r2 is recommended. The simultaneous use of these modules with the modules of 3rd and 4th generation is impossible.
- New feature: API function UcanSetDeviceNr() implemented in USBCAN32.DLL and USBCAN64.DLL for easy way to change the device number from customer applications.
- New feature: API function UcanEnumerateHardware() implemented in USBCAN32.DLL and USBCAN64.DLL for enumeration of connected USB-CANmoduls on a host.
- New feature: API function UcanInitHardwareEx2() implemented in USBCAN32.DLL and USBCAN64.DLL for initializing an USB-CANmodul by its serial number.
- Software changed: API function UcanSetDebugMode() has to be called in UNICODE format.

Software Version 5.05

- New feature: New methods implemented in UcanDotNET server: USBCAN_CALCULATE_AMR() and USBCAN_CALCULATE_ACR() with the same functionality as the macros defined in USBCAN32.H.
- Software changed: Signals EN and /STB of AU5790 at the single-wire USB-CANmodul2 can be separately switched on/off by using the API function UcanWriteCanPortEx().
For the low-speed USB-CANmodul2 the signals EN and /STB are interconnected at TJA1054. Both signals are switched by using the API function UcanWriteCanPortEx() with the bit 6 (UCAN_CANPORT_STB).
- Bug fixed: API Functions UcanInitHardwareEx() and UcanInitHardwareEx2() of version V5.04 returned an error code although the USB-CANmodul was successfully initialized.

Software Version 5.06

- New feature: USB-CANmodul Control can start kernel logger sessions to log debug information from USBCAN kernel drivers.
- Bug fixed: USB-CANmoduls of third generation (G3) only received 2 extended CAN messages (CAN2.0B = 29 bit CAN-ID). Then the reception of extended CAN messages stopped.
- Bug fixed: With driver version V5.05 Windows freezed after initializing the CAN interface of an USB-CANmodul. Apparently this occurred on PC with a special type of USB chip sets.

Software Version 5.07

- Bug fixed: USB-CANmoduls of third generation (G3) only received 2 CAN messages if the acceptance filter AMR/ACR was configured to only receive any CAN-IDs. Then the reception stopped for CAN messages which should be passed.
- Bug fixed: A BSOD occurred when using usbcan.sys and the USB-CANmodul was disconnected while actively sending CAN messages.

Software Version 5.08

- New feature: A new method EnumerateHardware() was added to the UcanDotNET.dll (class USBcanServer). The demo USBcanDemoVB uses this method to show the usage of the new method.

Technical Data:

- CAN interface:
 - Meets the CiA DS 102 Standard and ISO 11898-2/3
 - Optically isolated voltage supply (available as option)
 - GW-001 only: 2 jumpers for configuration of the CAN voltage supply (optically isolated via CAN bus, or via USB bus)
 - Connection to the CAN bus via DB-9 plug
 - Supports CAN frame format according to specifications for CAN 2.0A and 2.0B (11- and 29- bit CAN identifier)
 - Standard version with Philips PCA82C251 CAN transceiver, other variants available on request, i.e. low-speed and single-wire transceivers
 - Further CAN transceivers: 82C252, TJA1054, TJA1041, AU5790
 - GW-002 only: Connector for adapting other CAN transceivers by user (e.g. B10011S)
 - optional power supply via CAN bus, depending on CAN transceiver (see ordering number)
 - intermediate buffer for 768 CAN messages (fix value) in each direction on the USB-CANmodul
 - intermediate buffer for 4096 messages in each direction on the PC (changeable since software version 3.05)
- USB interface:
 - USB connector type B in accordance to the USB standard
 - Power supply through the USB bus (max. 200mA in operating mode) for GW-001, GW-002, USB-CANmodul1 and USB-CANmodul2
 - Transmission type: Bulk, 12MBit/s
- Power (green) and status LED (red) for GW-001 and GW-002
- Power (yellow), status LED (red) and traffic LED (green) for all sysWORXX USB-CANmoduls
- 8 bit expansion port (only GW-002, 3204002 and 3204003)
- Operating temperature 0°C...+55°C for GW-001 and GW-002
- Operating temperature -15°C...+85°C for all sysWORXX modules
- Conforms to CE standard
- Optional mounting accessories for DIN rail and wall assembly

Software Support:

- Kernel-Mode driver for Windows XP (32 bit edition, since driver V4.00 64 bit edition too) or higher (tested up to Windows 8):
 - USBCANLD.SYS, USBCANL2.SYS, USBCANL3.SYS, USBCANL4.SYS and USBCANL5.SYS USBCANL21.SYS and USBCAN22.SYS for automatic firmware download to the USB-CANmodul
 - USBCAN.SYS supports the various functions of the USB-CANmodul
 - UCANNET.SYS (network driver) realizes the use of an USB-CANmodul by up to 6 applications
- User-Mode driver for Windows XP (32 bit edition, since driver V4.00 64 bit edition too) or higher):
- USBCAN.DLL and USBCAN64.DLL for easy use of the USB-CANmodul functions
- Up to 64 CAN-channels (corresponds to i.e. 64 USB-CANmodul1 or 32 USB-CANmodul2)
- Tools for Windows XP (32 bit edition, since driver V4.00 64 bit edition too) or higher:
 - **USB-CANmodul Control** – administration and configuration of more than one USB-CANmodul by allocation of device numbers
 - **PCANView(USBCAN)** – CAN monitor program
- Demo programs in source (Microsoft C/C++ using MFC and Microsoft Visual Basic .NET)
- Contributor drivers for LabView, 8.5, 8.6 and 2011.
- Socket-CAN driver for Linux
- Device driver and Demo for Windows CE 5.0 and 6.0 for ARMv4I and x86

Scope of Delivery

- Assembled and tested device
- Systems Manual
- Software (tools, demos in source, driver software)
- USB cable (type A to type B; approximately 1.5 meters)

1 Getting Started

What you will learn in this Getting Started section:

- Installing the USB-CANmodul
- Software installation
- Connecting the USB-CANmodul to the host-PC
- Connecting the USB-CANmodul to a CAN network
- using PCANView (USBCAN)

1.1 Installation

1.1.1 Installation of the USB-CANmodul under Windows-OS

Ensure that the individual components are not damaged. The contents of the USB-CANmodul are:

- USB-CANmodul
- Installation CD-ROM with electronic version of this Systems Manual and all software and drivers
- USB cable

1.1.2 Software Installation

Note:

Since driver version V3.00 the operating systems Windows 98 and ME are not supported.

The support of Windows 2000 is no longer guaranteed.

Installation and operation of the USB-CANmodul requires a host-PC with a USB port that is running Microsoft Windows 2000, XP and Vista (since driver version 4.00). The USB-CANmodul will not work under Windows NT because there is no USB support in this operating system.

Note:

Make sure to install the software before the USB-CANmodul is connected to the PC. Make sure that you are logged in Windows-OS with admin rights. We provide driver updates for downloading under:

Software updates can be load from: <http://www.systec-electronic.com>

- Start your computer.
- Insert the **USB-CANmodul Utility CD-ROM** in your CD-ROM drive.
- Open the Windows Explorer
- Go to path:
"**<CD-ROM>:\Products\USB-CANmodul_xxxxxx\Software\SO-387**".
Execute file SO-387.exe, which will start the setup tool.
- Click on **"OK"** to start the setup program. The following window will appear:



- Click *Next*. Accept the License Agreement in the next window and click *Next* again.
- In the next windows you select the destination location of the USB-CANmodul software and the type of installation you wish to perform (*Full Installation is recommended*).
- Follow the setup instructions to install the USB-CANmodul software and click *Finish* at the end of the process.
- Connect the USB-CANmodul to your computer using the included USB cable.
- **Windows automatically detects** the USB-CANmodul. The appropriate driver files will be found automatically (*see Note below*). The firmware will now be downloaded to the USB-CANmodul. The red status LED blinks with a frequency of 10 hertz to indicate this procedure.

- After successful download of the device firmware the red status LED will stay on.

Note:

The USB-CANmodul device driver does not have the Microsoft signature. Because of this an error message will appear when using Windows XP operation system that the driver didn't pass the loop test. Ignore this message and click on *Continue Installation*.

Since 64 Bit Edition of Windows Vista all Kernel Mode Drivers has to be shipped with an certificate which identifies the manufacturer of the driver. Installing the driver for the first time a windows appears as shown in Figure 1. Please tick the box for always trusting the software from company SYS TEC electronic GmbH.




Figure 1: Installation of the driver at Windows Vista

1.1.3 Updating an Existing Installation

Follow the steps below if you have an existing USB-CANmodul installation and just want to update the driver:

- Start your computer.
- Open the Windows Explorer
- Go to path:
" <CD-ROM>:\Products\USB-CANmodul_XXXXXX\Software\SO-387 ".
- Execute file SO-387.exe, which will start the setup tool. Follow the setup instructions to install the USB-CANmodul software and click *Finish* at the end of the process. Connect the USB-CANmodul to your computer using the included USB cable.

1.1.4 Verifying the Device Installation

Verification of correct device installation on your host-PC can be done by following the steps listed below:

- Open the System Control from the start menu of Windows.
- Click the symbol "**System**". Under Vista this symbol can be found in the "**Classic View**". Under Windows 7 it may be necessary to re-adjust the "**View-By**" mode (top right corner of the window) to "**Large Icons**" or "**Small Icons**".
- Choose the tab "**Device Manager**" at the top. In Windows 2000,XP and Vista the device manager is located in the "**Hardware**" register card.
- Click on the pull-down menu "**Universal Serial Bus Controller**" resp. "**USB Controller**" resp. "**USB-CAN-Hardware**". If the device "**Systec USB-CANmodul device driver**" or "**Systec USB-CANmodul network driver**" is shown in the list, the new USB device has been detected properly. This is shown in the figure below.

Note:

Starting with version 2.16 of the installation program, the USB-CANmodul will appear in the device manager under the entry "**USB-CAN-Hardware**" and no longer under the entry "**USB Controller**" after setup is completed.




Figure 2: Device Manager with the USB-CANmodul

If the installation was not successful, check the installation steps as described above and try to re-install.

1.1.5 Device Number Allocation

With the help of device number allocation, it is possible to use more than one USB-CANmodul simultaneously on the host-PC. The device number identifies the individual USB-CANmodul.

- Click on **Start → Settings → Control Panel**. Using the Category View in Windows XP additionally click to **Other Control Panel Options** – in Windows Vista use **Additional Options**. In 64 Bit edition of Windows XP or Vista click to **View 32-bit Control Panel Items**.
- Click on the **USB-CANmodul Control** symbol. The following window will appear:




Figure 3: USB-CANmodul Control Tool

- Select/highlight one of the modules shown in the hardware list and then click on the **Change...** button.

Note:

The device number of USB-CANmoduls grayed out in the list cannot be changed because they are used by other applications.




Figure 4: Device Number Selection Dialog Box

- Enter a new device number in the input field or modify the device number using the Up or Down button. Click **OK** to exit this window.
- The new device number will only take effect and gets downloaded into the device after clicking the **Apply** or **OK** button.

1.1.6 Connection to a CAN Network

The USB-CANmodul provides a DB-9 plug for connection to the CAN network. The pin assignment on this connector is in accordance to the CiA (CAN in Automation) specification. Connect your CAN network to this connector with an appropriate CAN bus cable. The pinout is described in *Table 3* on page 29.

Note:

When using the standard version of the GW-002 with on-board high-speed CAN transceivers (82C251) a termination resistor of 120 Ohms at both ends of the CAN cable between CAN_L (pin 2) and CAN_H (pin 7) is required to ensure proper signal transmission. When using a special version of the device featuring a low-speed CAN transceiver (e.g. TJA1054 etc.) no terminating resistor must be used because it is already integrated in the device. It is necessary to use shielded cables if the CAN bus extension exceeds 3 meters.

1.1.7 Starting PCANView (USBCAN)

The included program PCANView (USBCAN) is a CAN bus monitor for Windows.

- Start the utility program using the Windows *Start* button and browse to *Programs* → *USB-CANmodul Utilities* → *PCANView (USBCAN)*. It is recommended that you drag the PCANView (USBCAN) icon onto the desktop of your PC. This enables easy start of this utility program by double-clicking on the icon.
- The *USB-CANmodul settings* window will appear:




Figure 5: Dialog Box with Hardware Configuration

- Select the baud rate of your CAN network in the *Baudrate* box and the *Device Number*. The entry **any** selects the USB-CANmodul that is found first by Windows.
- If "user" is selected in the baud rate field, then the values for registers BTR0 and BTR1 of the SJA1000 can be entered directly. The SJA1000 operates with a 16 MHz clock speed. Refer to the SJA1000 manual for calculation of values for other baud rates.
- When using a sysWORXX USB-CANmodul please enter the user-specific baud rate into field "BTR Ext" (also see Section 2.3.4) and select the CAN-channel you want to use.
- When using the Multiport CAN-to-USB 3004006, USB-CANmodul2 3204002/3204003, USB-CANmodul8 3404000 or USB-CANmodul16 3404001, please set which channel is to be used.

- Only for new fourth generation - USB-CANmodules a high resolution time stamp for CAN-reports can be set via „high res. timer“. The column „Period“ in PCANView has a resolution of 100µs (instead 1ms) for the standard variant.
- Click on the **OK** button to enable these settings.
- A new window *PCANView – Connect to net* will appear. If applicable enter the message filter for the CAN-controller and confirm with **OK**.




Figure 6: Dialog Box Message Filter Configuration

- In this message box you can select Standard (11-bit) or Extended (29-bit) CAN identifier and message filters, if desired. Click on the **OK** button to enable these settings. In the menu „**Transmit**“ > „**New...**“ you can define a new CAN-report. Enter a 0 in the field, the CAN-report will only be sent, if it has been selected in the lower field of the main window and the SPACE key was hit.
- The PCANView (USBCAN) main window will appear:




Figure 7: PCANView (USBCAN) Main Window

This screen is divided into two sections: Receive and Transmit

- Receive: monitors CAN signals that are received from a node
- Transmit: monitors CAN signals sent from the host-PC to the CAN network via the USB-CANmodul

Note:

The tool PCANView is not suitable for sending precisely timed CAN messages to the CAN bus by using the USB-CANmodul.

Since Software version V4.09, in PCANView it is possible to configure cyclic CAN messages which are automatically sent by the firmware of the USB-CANmodul. This feature can be used for instance when precisely timed CAN messages have to be sent to the CAN bus (e.g. SYNC messages). For this purpose, the system menu of PCANView includes a command "SYSTEC cyclic CAN messages" (see Figure 8). A dialog box opens up where all cyclic CAN messages can be configured (see Figure 9). Use button **Add** to add a new cyclic CAN message. With button **Edit** a previously marked cyclic CAN message can be edited. Each sysWORXX USB-CANmodul supports up to 16 cyclic CAN messages. Choose option **parallel** if the cycle time of each CAN message should refer to itself (see Figure 19). With option **sequential** the cycle time of each CAN message refers to its subsequent CAN message (see Figure 20).




Figure 8: precisely timed CAN messages in PCANView (USBCAN)




Figure 9: configuration of cyclic CAN messages in PCANView (USBCAN)

Since Software version V5.09 the tool PCANView (USBCAN) can write a CAN Trace File. To start this feature the command „SYSTEC Write CAN-Trace-File“ has to be clicked

within the system menu of the tools (*refer to Figure 8*). If the feature is activated, then a check is displayed before the command within the system menu. All CAN messages are stored to the CAN Trace File, which are received within this time. The CAN Trace File is stored as binary file with the default file extension “.ucantrc”. The company SYS TEC electronic GmbH provides a .NET tool for conversion of the binary CAN Trace File into a text file. This conversion tool is provided as source code when the “USB-CANmodul Utility Disk” is completely installed. So the customer is able to adapt other formats of the output file. There are no copyrights or license rights for this tool. The source code and the project files for Microsoft Visual Studio 2008 can be found in following subfolder of the installation path of the USB-CANmodul Utility Disk at the hard disk:

```
\Examples\ConvertUcanTrace
```

Within the subfolder „bin“ of the installation path the tool is provided as binary executable. A CAN Trace File created by the tool PCANView (USBCAN) can be converted into a txt file by calling the following command line:

```
ConvertUcanTrace.exe <input-file> [<output-file>] [options]
```

Example:

```
ConvertUcanTrace.exe pcanview_20150206_122846.ucantrc
```

To display a detailed help of the converter tool call the following command line:

```
ConvertUcanTrace.exe --help
```

Please note that the file UcanDotNet.dll for the x86 platform has to be stored into the current working directory of the converter tool too. The tool is compiled for the Microsoft .NET Framework 3.5. But it can be adapted for each other .NET Framework version by the customer.

Since Software version V4.09 it is possible to call PCANView by using command line parameters e.g. for using a batch file. If at least one of these command line parameters is used then the dialog box for hardware parameters is not shown (see Figure 5).

The following command line parameters are available in PCANView:

Syntax:

```
PCANView.exe [-d<devicenr>] [-c<channelnr>] -b<baudrate> [-l]
              [-x<x-pos> -y<y-pos>] [-n]
```

- d <devicenr> defines the device number of the USB-CANmodul. The range of values is between 0 and 254. Any USB-CANmodul that is found first is allocated value 255 (default value).
- c <channelnr> defines the CAN channel that is to be used for multi-channel USB-CANmodules. The range of values is between 0 and 1. Default value is 0 (first CAN channel).
- b <baudrate> defines the bit rate on CAN bus in kBit/sec. Possible values are 1000, 800, 500, 250, 125, 100, 50, 20, 10. There is no default value for this parameter. It must be set if the dialog box for setting hardware parameters shall not be shown.
- l If this parameter is set, the USB-CANmodul will be initialized in listen-only mode. In this case CAN messages cannot be sent.
- x,-y <x-pos> and <y-pos> define the position of the PCANView main window. If those parameters are missing, the position of the PCANView main window is read from the registry and is the same for all instances.
- n If this parameter is set, the dialog box to configure the message filter will be skipped (see Figure 6). In this case all CAN messages will always be received.
- t With <timeout> the send timeout is set, from which a multi-channel USB-CANmodul dismisses all subsequent CAN-reports in order to avoid a block of another CAN-channel (also refer to function *UcanSetTxTimeout()*). The standard value is 0 (no Timeout)
- r As of V5.00 this parameter indicates, that the high resolution time stamp is to be used. The column „Period“ then has a resolution of 100µs (instead 1ms) for the standard variant.

Example:

```
PCANView.exe -d1 -b1000 -n
```

The following command allows for starting more than one instance of PCANView from a batch file. To run the batch file, it is not necessary to wait until the previous PCANView instance is closed:

```
start PCANView.exe -d1 -b1000 -n -x20 -y35
start PCANView.exe -d2 -b1000 -n -x600 -y460
```

Note:

If PCANView is called with the command line parameters described as above, not all settings in the INI file are in effect.

1.1.8 Creating a debug file from DLL

If problems with the software drivers should occur, there is a possibility to create a debug log file from USBCAN32.DLL. You should always send this log file to our support email address so that we can find a solution for your problem.

To activate the feature please open **USB-CANmodul Control** from the control panel. At the tab sheet **Debug** you will find the following window:




Figure 10: Debug settings in USB-CANmodul Control

Enable the feature by ticking the box “**Enable Debug**”. In the list above you can activate different debug information that should be added to the debug log file. Click to “Browse” for choosing the folder in which the debug log file should be stored to. The default setting is the “Documents” folder.

Apply the new settings and close USB-CANmodul Control. Start your application using an USB-CANmodul and wait until the problem will occur. After this close your application.

Afterwards, you will find a file named USBCAN_XXXXXXXX_YYYYYY_ZZZ.LOG. XXXXXXXX represents the creation date of the log file in format YYYYMMDD (year month day) and YYYYYY stands for the creation time in format HHMMSS (hour minute second). ZZZ is the name of the application executed.

Note:

Enabling this feature decreases the performance of the software, because API functions have to execute much more code to generate debug outputs. It limits the debug information by changing the LOG-Level can help to increase performance again. But note that in this case important information could be missing in the log file.

Furthermore, the debug log file may increase in size. Activate the feature "Check max. LOG file size". This way, USBCAN32.DLL will monitor the file size of the debug log file. If it is exceeded, the previous (older) debug outputs will be deleted from the debug log file. Default setting of the maximum debug file size is 10240 Kbytes (means 10 Mbytes).

Since version V3.11 of USBCAN-library, an application can call the function *UcanSetDebugMode()* for subsequent activation of the feature. Refer to *section 2.3.2.1* for more information.

With the Check-Box "**Show Dbg Info**" you can set, if a dialogue box should be opened upon initiating an application and for activated debug-read-outs, reminding of activated debug-read-outs. This is to avoid that debug-read-outs remain continuously activated without being noted filling the main board with log-files.

1.1.9 Activation of the network driver


The network driver UCANNET.SYS was developed for connecting several applications to one physical USB-CANmodul. Therefore, the kernel mode driver creates a virtual CAN network for each physical module to which several applications can connect to. All CAN messages that are sent by an application are not only sent to the physical CAN bus but also to all the other connected applications. Received CAN messages are passed on to all applications.

The network driver can only be activated for sysWORXX USB-CANmoduls – but not for the older modules GW-001 and GW-002.

To activate the network driver for an USB-CANmodul, open the USB-CANmodul Control from the Control Panel. Mark that module within the hardware list that you want to use for the network driver. Push the button "**Change...**" to open the dialog box shown in Figure 4. Tick the box "**use USB-CANnetwork driver**" and confirm with "**OK**". After pushing the button "**Apply**" or "**OK**" in the main window of the USB-CANmodul Control, the USB-CANmodul automatically reconnects to the host PC. This results in exchanging the kernel mode driver. Now you can use several applications with this USB-CANmodul.

1.2 Status LEDs on the USB-CANmodul

The state of each CAN-channel on the USB-CANmodul is displayed via 2 resp. 3 LEDs. In order to distinguish the states, different blinking cycles were defined respectively.



(Not to scale)

A description of the power and status LEDs is shown in the table below:

USB-CANmodul connected?	LED green (Power)	LED red (Status)	Description
no	off	Off	No voltage is supplied to the device.
yes	on	Blinking cycle 1	Device logs in to the host-PC
yes	on	On	Log-in successful, CAN is not initialized, no error.
yes	on	Off	CAN is initialized, no error.
yes	on	Blinking cycle 2	A CAN-bus error occurred on the device.

Table 1: States of the LEDs on the USB-CANmodul GW-001/GW-002

On the Multiport CAN-to-USB each CAN-channel has one Status-LED. Furthermore, each channel has a Traffic-LED (green), indicating CAN-bus traffic, once the channel has been initialized. The Multiport CAN-to-USB, USB-CANmodul2, USB-CANmodul8 and USB-CANmodul16 have the same LED assignment. On USB-CANmodul1 there is only one traffic LED, as there is only one channel available. Table 2 contains a list of all LED states.

USB-CANmodul connected?	LED yellow (Power)	LED red (Status)	Description
no	off	off	No voltage is supplied to the device.
no	on	blinking cycle 1	USB cable not connected.
yes	on	blinking cycle 1	Device logs in to the host-PC.
yes	on	on	Log-in successful, CAN-channel is not initialized, no error.
yes	on	off	CAN-channel is initialized, no error.
yes	on	blinking cycle 2	A CAN-bus error occurred on this channel.
yes	on	blinking cycle 3	Firmware update running. The device must not be powered-off or disconnected while the firmware update is running.

Table 2: States of the LEDs on the sysWORXX modules

All sysWORXX modules also have a green traffic LED for each CAN-channel. While it is blinking it shows an active traffic on CAN bus.

1.3 CAN Supply Voltage

No external CAN supply voltage is necessary for the standard version GW-002 or the GW-002-xx0 versions. The low-speed versions GW-002-xx1 and GW-002-xx2 require an external supply voltage for the CAN transceiver. Be sure to note the limitations for the CAN transceivers when connecting the external supply voltage.

The pin assignment for the DB-9 CAN plug is shown in the table below:

Pin	Pinout of DB-9 plug	
	with 82C251, 82C252, TJA1041, TJA1054 (differential)	with AU5790 (single wire)
1	N/C	N/C
2	CAN-L	N/C
3	GND	GND
4	N/C	N/C
5	CAN shield	CAN shield
6	GND	GND
7	CAN-H	CAN-H
8	N/C	N/C
9	Vcc (+7 to +30 VDC)*	Vcc (+5.3 to +13 VDC)*

Table 3: Pinout of the CAN DB-9 Plug

Note:

The value for Vcc depends on the alternative CAN transceiver that populates the device.

For the standard low-speed version (GW-002-xx2, *refer to section 1.7*) an input voltage between 12V and 30V can be supplied at pin 9 (VCC). The nominal voltage amounts to 24V +/-25%. A temporary maximum voltage of up to 35V is allowed. The CAN transceiver starts functioning with supply voltages as low as 8V. The GW-002-xx2 version features an internal protective circuit and a voltage reduction circuit for the input voltage. This means that when supplying the device from an external 12V (+/-20%) source at VCC, the CAN transceiver's supply voltage CANVBAT can drop below 8V. In this case recognition of the standby mode cannot be guaranteed.

We recommend using the GW-002-xx1 version in 12V systems. This version is specifically designed for an external 12V voltage. It has no extra circuitry for supply voltage reduction; hence the CAN transceivers standby mode recognition will function. The USB-CANmodul in the GW-002-xx1 version can also operate at 24V (+/-20%). Implementation in 24V systems is possible, but not recommended. Use the GW-002-xx2 instead.

1.4 CAN-port with Low-Speed CAN Transceiver

The high-speed CAN transceiver Philips 82C251 is implemented in the standard configuration of the device. As an alternative, other CAN transceiver can be populated on the USB-CANmodul. In this case only the behavior on the CAN bus changes, not the behavior in relation to the software. From the software point of view (e.g. using the included PCANView) any transceiver can be used.

The optional low-speed transceivers TJA1054 or the single wire transceiver AU5790 have multiple signals for setting the operating mode of the transceivers and displaying the operating state. The following signals are supported:

Signal	Name	Meaning	Type	Default value
EN	Enable	turn-on signal	high-active	high level
/STB	Standby	turn-off signal	low-active	high level
/ERR	Error	error signal	low-active	high level
TRM	Termination	termination resistor	high-active	low level

Table 4: Signals available for low-speed CAN port

Note:

It is only possible to read the state of the termination resistor by software using USB-CANmodul2.

The signals /STB and EN of low-speed USB-CANmoduls of 4th generation cannot be separately switched. They are both interconnected at the TJA1054.

The standard levels are set so that the transceivers function in normal operating mode. Thus operation with the PCANview tool is possible immediately. The Error signal is not evaluated. Functions for setting the operating modes and for reading the Error signal are supported by the USBCAN-library and are described in the section on software support (refer to section 2).

Please refer to the data sheet for the CAN transceiver in question when setting the operating mode. The AU5790 does not have an error output.

An additional pin header connector in 2.54 mm pitch (male or female) is provided for support of additional CAN transceivers such as the B10011S.

Resistors with 1 kOhm are populated at pins RTL or RTH when using the TJA1054. When using the AU5790 device a 9.1 kOhm resistor at space R_t is used and a 220 pF capacitor at C_{ui}.

This CAN port connector has the following pinout:

Signal	Pin	Pin	Signal
/STB	1	2	EN
/ERR	3	4	SPLIT
CAN_RX	5	6	CAN_TX
CAN_5V	7	8	CAN_GND
INH	9	10	CAN_LX
CAN_HX	11	12	CANVBAT
RTH	13	14	RTL

Table 5: CAN Port Pin Assignment for External Transceiver on the GW-002

1.5 Expansion Port

The USB-CANmodul features an 8-bit port for functional expansion which can be used to add digital inputs (e.g. push buttons) and digital outputs (e.g. LEDs) to the device. An additional 2*5-pin header connector in 2.54 mm pitch (male or female) is provided on the USB-CANmodul. The connector has the following pinout:

Signal	Pin	Pin	Signal
PB0	1	2	PB1
PB2	3	4	PB3
PB4	5	6	PB5
PB6	7	8	PB7
GND	9	10	Vcc Output

Table 6: Expansion Port Pin Assignment on the GW-002 and USB-CANmodul2

The microcontroller's port pins are connected directly to the expansion port. Make sure that external circuitry connected to this port does not exceed the maximum load tolerance of the corresponding port pins! The port pins can be configured to be used as inputs or outputs. The 5V supply voltage DC5V is turned on only after the CAN interface in the USB-CANmodul is initialized (following the function call of *UcanInitCan()* or *UcanInitCanEx()*). External circuitry supplied by this voltage should not draw more than 2mA current in order to not destroy the microcontroller.

Please do not hesitate to contact us for additional hardware and software implementation support. The following figure depicts the positions of the connectors and sockets. A detailed diagram is available on request.




Figure 11: Location of CAN and Expansion Port on GW-002

Symbol	Parameter	Condition	min.	max.	Unit
V _{IH}	Input High Voltage		2.0	5.25	V
V _{IL}	Input Low Voltage		-0.5	0.8	V
V _{OH}	Output High Voltage	I _{OUT} = 1.6 mA	2.4		V
V _{OL}	Output Low Voltage	I _{OUT} = -1.6 mA		0.4	V
C _{IN}	Input Pin Capacity			10	pF
V _{CC}	Supply Voltage		4.75	5.25	V

Table 7: Expansion Port Signal Properties on GW-002

Functions for expansion port access are described in section 2.3.2.




Figure 12: Location of the Expansion Port on USB-CANmodul2




Figure 13: Position of expansion plugs on USB-CANmodul2 G4

The pinout of the Expansion Port X400 on USB-CANmodul2 is described in Table 6. Please note that pin 1 is located at the upper right corner of X400. This connector is not build in on all modules!

Symbol	Parameter	Condition	min.	max.	Unit
V _{IH}	Input High Voltage		2.0	5.5	V
V _{IL}	Input Low Voltage		-0.3	0.8	V
V _{OH}	Output High Voltage	I _{OUT} = 2 mA	2.9		V
V _{OL}	Output Low Voltage	I _{OUT} = 2 mA		0.4	V
C _{IN}	Input Pin Capacitance			14.1	pF
I _{OUT}	Output Current			2.0	mA
V _{CC}	Supply Voltage		3.2	3.4	V

Table 8: Expansion Port Signal Properties on USB-CANmodul2 G3

Symbol	Parameter	Bedingung	min.	typ.	max.	Einheit
V_{IH}	Input High Voltage		2.0		5.5	V
V_{IL}	Input Low Voltage		-0.3		0.8	V
V_{OH}	Output High Voltage	$I_{OUT} = 8 \text{ mA}$	2.9			V
V_{OL}	Output Low Voltage	$I_{OUT} = 8 \text{ mA}$			0.4	V
C_{IN}	Input Pin Capacitance			5		pF
I_{OUT}	Output Current				8.0	mA
V_{CC}	Supply Voltage		3.2		3.4	V

Table 9: Properties of port expansion on USB-CANmodul2 G4

A user circuit of the Expansion Port depends on the necessity to which level the hardware of USB-CANmodul has to be protected against destruction. You find an example of a user circuit without protection in the next figure.




Figure 14: simple example circuit for Expansion Port

Please note that if V_{CC} is used as power supply for your circuit, the total current of an USB device may not exceed 500 mA (during plug-in the total current actually may not exceed 100 mA). If bus powered USB hubs are used, there could be problems even below 500 mA. Some USB hubs share its power supply with the number of available USB ports. Please note that there could also be problems below 500 mA if other USB devices are connected to these ports. Thus, we advise to implement a galvanic decoupled circuit that has its own power supply.

1.6 Termination resistor for CAN bus

Please note that there always has to be connected two termination resistors with value 120 Ohms, if you are using an USB-CANmodul with a high-speed CAN transceiver. These has to be connected to both ends of the CAN bus:




Figure 15: termination resistors on CAN bus

Note:

When using a special version of the device featuring a low-speed CAN transceiver (e.g. TJA1054 etc.) no terminating resistor must be used because it is already integrated in the device.

On USB-CANmodul2, USB-CANmodul8, USB-CANmodul16 and Multiport CAN-to-USB a termination resistor with 120 Ohms is already build in for each CAN-channel. You can enable or disable it by closing a jumper (USB-CANmodul2) or by switching a switch on front panel (USB-CANmodul8, USB-CANmodul16 and Multiport CAN-to-USB). The default state of the termination resistors is: disabled.

If you decide to enable the termination resistor, change the appropriate switch to ON or close the appropriate jumper (refer to Figure 12 - JP200 for CAN-channel 0; JP300 for CAN-channel 1).

The current state of the termination resistor can be indirectly read back by software only on USB-CANmodul (by calling function *UcanReadCanPort()* or by showing in Control Panel Application USB-CANmodul Control – refer to Figure 17). Please note that the jumper JP104 must have the same state like JP200 (for CAN-channel 0) and the jumper JP105 must have the same stat like JP300 (for CAN-channel 1). Otherwise the read state of the termination resistor is not correct. The reason of this solution is the optical isolation of the CAN-channels.

max. cable length [m]	max. bit rate [kBit/s]	specific resistance [kΩ/m]	Cable cross-section [mm²]
30	1000	70	0,25..0,34
100	500	<60	0,34..0,60
500	100	<40	0,50..0,60
1000	20	<26	0,75..0,80

Table 10: recommended cable parameters

1.7 Order Options

Obsolete USB-CANmoduls which are not available any more:

Part Number	Option
GW-002	Standard version, high-speed (82C251)
GW-002-x0x	high-speed with Philips 82C251 transceiver
GW-002-x1x	low-speed with Philips TJA1054 transceiver
GW-002-x2x	low-speed, single-wire with Philips AU5790*
GW-002-x3x	low-speed with Philips TJA1041 transceiver
GW-002-0xx	without optical CAN signal isolation
GW-002-1xx	with optical CAN signal isolation
GW-002-xx0	internal supply via USB
GW-002-xx1	external supply 7 - 27V**
GW-002-xx2	external supply 12 - 30V**
GW-002-KSMxx	customer-specific version, MOQ=25

* AU5790 requires external supply voltage

** External supply not available with standard 82C251 transceiver

The USB-CANmodul is available in different options:

All sysWORXX-variants:

Part Number	Option
3004006	Multiport CAN-to-USB 16 CAN-channels, high-speed transceiver 82C251, galvanic isolation, separated into 8 logical devices with 2 channels each
3204000	USB-CANmodul1 One CAN-channel, high-speed transceiver 82C251
3204001	USB-CANmodul1 with galvanic isolation One CAN-channel, high-speed transceiver 82C251
3204002	USB-CANmodul2 Two CAN-channels, high-speed transceiver 82C251
3204003	USB-CANmodul2 with galvanic isolation Two CAN-channels, high-speed transceiver 82C251
3204007	USB-CANmodul2, same as 3204000 but with 8 bit Expansion Port

Part Number	Option
3204008	USB-CANmodul2, same as 3204003 but with single-wire CAN transceiver (Philips AU5790) at the first CAN channel.
3204009	USB-CANmodul2, same as 3204002 but with low-speed CAN transceiver (Philips TJA1054) at the first CAN channel.
3204011	USB-CANmodul2, same as 3204002 but with low-speed CAN transceiver (Philips TJA1054) at both CAN channels.
3204017	USB-CANmodul2, same as 3204003 but without housing and with wired LEDs.
3204018	USB-CANmodul2 same as 3204003 but with high-speed CAN-Transceiver (NXP TJA1041) on first CAN-channel.
3204019	USB-CANmodul2, same as 3204003 but with high-speed CAN transceiver (NXP TJA1054) at th first CAN channel.
3404000	USB-CANmodul8 with galvanic isolation 8 CAN-channels, high-speed transceiver 82C251
3404001	USB-CANmodul16 with galvanic isolation 16 CAN-channels, high-speed transceiver 82C251

Currently available order numbers:

3004006, 3204000, 3204001, , 3204003, 3204004, 3204008, 3204017, 3204018, 3204019, 3404000, 3404001

Other accessories:

WK054	Unshielded CAN bus cable for max. 5 nodes, with removable 120 Ohm terminating resistors and configured for supply voltage input
WK-004	Shielded CAN cable for direct connection of 2 nodes with integrated 120 Ohm terminating resistors
GW-002-Z01	Wall mounting plate
GW-002-Z02	DB-9 to 5-pin Combicon pin adapter, pinout according to <i>DeviceNet</i> specification
GW-002-Z03	USB cable 3 m (A-B)
GW-002-Z04	USB cable 4.5 m (A-B)
GW-002-Z05	Mounting plate for DIN rail

1.8 The new sysWORXX USB-CANmodules

1.8.1 The Multiport CAN-to-USB

The Multiport CAN-to-USB 3004006 is an industrial USB-CAN interface with 16 CAN-channels coming in a 19" rack mounted housing. The device is structured into 8 logical USB/CAN devices with 2 CAN-channels each. The logical devices are combined by 2 USB-hubs and connected to the PC via two USB ports (see picture below).




Figure 16: Internal structure of the Multiport CAN-to-USB



There is no separate software driver for the Multiport CAN-to-USB as it is supported by the standard drivers used for USB-CANmodul. A special API function set was implemented to support the extended functions of the Multiport CAN-to-USB, such as

multiple CAN-channels, baud rate configuration and acceptance mask filtering. Please also refer to *sections 2.3.4, 2.3.5 and 2.3.7*. In a limited scope these extended functions are also applicable to GW-002 devices and the standard functions are applicable to the Multiport CAN-to-USB.

The USB device numbers of the 8 logical devices are assigned sequentially. The first logical device (counted from left side) device number 0, the second logical device has number 1 and so on. The device numbers can be reconfigured using the "USB-CANmodul Control" icon in the Windows Control Panel.

1.8.2 The USB-CANmodul1

The USB-CANmodul1 (ordering number 3204000 or 324001) is a cost optimized variant of the new sysWORXX USB-CANmodul series including only one CAN-channel. Optionally you can order this device with or without a galvanic isolation (*refer to section 1.7*). Both variants has built in a high-speed CAN transceiver. There is no Expansion Port for connecting digital inputs or outputs.



1.8.3 The USB-CANmodul2

The USB-CANmodul2 (ordering number 324003) is an extended variant of the new sysWORXX USB-CANmodul series including two CAN-channels. This device has a galvanic isolation (*refer to section 1.7*). This variant has built in a high-speed CAN transceiver. There are variants with build in low-speed CAN transceivers at the first CAN channel (e.g. ordering number 3204019). Here always the second CAN channel has a build in high-speed CAN transceiver.

There is Expansion Port for connecting digital inputs or outputs like the GW-002 does have too. With order number 3204007 you will get an USB-CANmodul2 including an Expansion Port which is described in *section 1.5*.



1.8.4 The USB-CANmodul8 and USB-CANmodul16

Both USB-CANmodul8 (ordering number 3404000) and USB-CANmodul16 (ordering number 3404001) are identical to the Multiport CAN-to-USB but are shipped with a table case. The USB-CANmodul16 consists of two circuit cards of the same type like is built in on USB-CANmodul8.



1.8.5 The USB-CANmodul2 IP65

A variant of USB-CANmodul2 is available in an IP65 metal housing with article number 3104000. However no low-speed variants are featured.



2 Software Support for Windows OS

2.1 File Structure

If during the installation of the USB-CANmodul utilities no other target directory is given, then all files will be installed in the folder C:\Programs\SYSTEC-electronic\USB-CANmodul Utility Disk. The contents of this folder are given in *Table 11*. Some folders are created depending on selected installation options during setup process.

Sub Folder	Contents
Bin\	Program files (PCANView)
Contrib\	Files contributed by other companies
Borland Delphi\	Delphi class with demo in source (is removed)
LabView\	LabView driver with demo
Examples\	Demo projects
Demo\	MFC demo in source for GW-002 and MS Visual Studio 2003 or higher
DemoGW006\	MFC demo in source for an USB-CANmodul including two CAN-channels and MS Visual Studio 2003 or higher
DemoCyclicMsg\	MFC demo in source for MS Visual Studio 2003 or higher and automatically transmitting of cyclic CAN messages using a sysWORXX USB-CANmodul.
Include\	C header files for USBCAN32.DLL. The demo applications for MS Visual Studio refers to these files.
Lib\	Common USBCAN32.DLL/USBCAN64.DLL and import-libraries for MS Visual Studio. The demo applications refer to this import-library.
UcanDotNET\	Wrapper-DLL in source code for use with Microsoft .NET projects.
USBcanDemoNET\	MS Visual Basic .NET demo application in source code (using the Wrapper-DLL UcanDotNET.dll)
Docu\	Manuals
Drv\	Windows Kernel drivers

Table 11: Software File Structure

2.2 Tools for the USB-CANmodul

2.2.1 USB-CANmodul Control

The USB-CANmodul Control tool replaces the UCAN Config tool starting at version 2.18. This tool can be started either from the Control Panel or from the program group **"USB-CANmodul Utilities"**. *Figure 3* shows the tool after start up.

This tool can be used to modify the device number of the USB-CANmoduls (*also refer to section 1.1.5*).

In addition, this tool can also be used to manipulate the 8-bit port expansion (*refer to section 1.5*) and the CAN port for low-speed CAN transceivers (*refer to section 1.4*). To do this you have to select the corresponding USB-CANmodul from the list and then click on the **"Ports..."** button.

Figure 17 shows the dialog box that will appear when choosing this option.




Figure 17: Dialog Box for Manipulating the Port Expansion and the CAN Port

Initially all 8 signals are configured as inputs. With the column OE, the corresponding signal is switched to an output. This activates the box for the output value in the OUT column. If a signal is switched to a logical 1 in this column, then the corresponding signal on the port expansion will be set to high. With every modification the current state of the expansion port will be read again and shown in the IN column for the inputs. To read the current input states without having to change an output, click on the **"Update Input"** button.

The current state of the CAN port for the low-speed CAN transceiver is displayed on the right side of the window. The signals EN and /STB are outputs and the signal /ERR is an input. For more information refer to *section 1.4*.

2.2.2 PCANView (USBCAN) for Windows

The Windows utility **PCANView (USBCAN)** can be used to display CAN messages transmitted via the CAN bus.

After execution of the tool a dialog box is shown for configuring the hardware parameters (*refer to Figure 5*). The device number of the logical USB-CANmodul has to be filled in to the edit field "Device-Nr.". This device number was previously programmed with the Windows Control Panel symbol USB-CANmodul Control (*refer to section 1.1.5*). Within the drop down box "Baudrate" the baud rate on CAN bus can be selected. The option "listen only" configures the CAN controller for only receiving CAN messages. This also means that no acknowledge will be sent back to the sending remote CAN device. For a logical USB-CANmodul including two CAN-channels the channel has to be selected which should be used by the tool.

After applying the settings by clicking to the "OK" button a dialog box is shown like displayed in *Figure 6*. The filter setting depends on the CAN message format you wish to receive: CAN identifier with 11 bits (standard frame = CAN Spec. 2.0A) or CAN identifier with 29 bits (extended frame = CAN Spec. 2.0B). Please choose one of both possibilities and enter the range of the CAN messages which has to be shown on receive section of the tool. If you do not change this range, then all CAN messages will be shown. Apply this setting by clicking to the button "OK".

The main window of the tool appears (*refer to Figure 7*). This screen is divided into two sections: Receive and Transmit:

- Receive: monitors CAN signals that are received from a node
- Transmit: monitors CAN signals sent from the host-PC to the CAN network via the USB-CANmodul

Receive Section

The *Receive* section provides the following information:

- Message: identifier of the CAN message, hexadecimal format, ranging from 0 to 7FFh for 11-bit identifiers and from 0 to 1FFFFFFFh for 29-bit identifiers
- Length: data length code of the message (ranges from 0 to 8)
- Data: values of the messages' data bytes (up to 8) or the text Remote request, if a remote frame has been received
- Period: period of time between the reception of the last two messages with this identifier
- Count: number of messages received with this identifier (no remote frames) since last user reset
- RTR-Per.: period of time between the reception for the last two remote frames
- RTR-Cnt.: number of remote frames with this identifier

Transmit Section

The Transmit section provides the following information:

- Message: identifier of the CAN message, hexadecimal format, ranging from 0 to 7FFh for 11-bit identifiers and from 0 to 1FFFFFFFh from 29-bit identifiers
- Length: data length code of the message (ranges from 0 to 8)
- Data: values of the messages' data bytes (up to 8) or the text *Remote request*, if a remote frame shall be sent
- Period: period of time between the last two message sent

Note:

If, at creation of the message, the period was set to 0, the text *Wait* is shown. In this case the message can only be transmitted manually using the <Space> bar. Or the message is sent automatically after a matching remote frame has been received.

- Count: number of messages sent with this identifier (no remote frames) since last user reset
- Trigger: reason for the last transmission of the message Manual: manual transmission by the user pressing the <Space> bar
- Time: period of time has passed for periodical sending
- RTR: remote frame has been received

Note:

Both sections are sorted by the CAN identifiers. That means no chronology is displayed.

In order to edit the *Transmit* list, the following menu commands are available:

- Transmit → New...: Create a new transmit message. The editor window for the new message is shown.
- Transmit → Delete: Delete the currently selected message from the transmit list.
- Transmit → Edit...: Edit the currently selected message.
- Transmit → Clear all: Delete the entire transmit list.
- Client → Reset: Reset the message counters and reset the connected USB-CANmodul. Deletes the receive list.

2.3 Description of the USBCAN-library

The USBCAN-library is a function library for application programs. At Windows 2000/XP or higher it is a Dynamic Linked Library (DLL – with the file name USBCAN32.DLL) It serves as an interface between the system driver layer and an application program. The USBCAN-Library for the USB-CANmodul enables easy access to the USB-CAN system driver functions. It administers the opened USB-CANmodul and translates the USB data into CAN messages.

Add the file USBCAN32.LIB to your project for linking the USBCAN32.DLL to your own Microsoft Visual C/C++ project. Starting the application program automatically loads the DLL. If the USBCAN32.LIB is not linked to the project, or you are using another environment (e.g. Borland C++ Builder), load the DLL manually with the Windows function *LoadLibrary()* and add the library functions with the function *GetProcAddress()* (refer to the demo application “DemoGW-006”). There was a .NET wrapper DLL implemented for Microsoft .NET applications described in section 2.4.

The PUBLIC calling convention of the DLL functions provides a standardized interface to the user. This standard interface ensures that users of other programming languages than C/C++ (Pascal, etc.) are able to use these functions.

Within this manual the DLL is called USBCAN-library because the API functions (also called USBCAN-API) are also implemented for other platforms at which the library has another file name (e.g. “USBCANCE.DLL” under Windows CE) or at which the library is not a DLL (e.g. under Linux).

Folders <SETUP_DIR>\DEMO.API, <SETUP_DIR>\DEMOGW006 and <SETUP_DIR>\DEMOCYCLICMSG contains example programs written using MFC in Microsoft VisualC/C++6.0 and 7.0. These example projects demonstrates the use of the DLL API functions.

2.3.1 Attributes of the USBCAN-library

With USBCAN-library, it is possible to use 64 USB-CANmoduls simultaneously with one application program, as well as with several application programs (using Windows CE only 9 modules). However, it is not possible to use one USB-CANmodul with several application programs.

Three states within the software are generated for each USB-CANmodul when using this DLL.

After starting the application program and loading the DLL, the software is now in the DLL_INIT state. Concurrently, all required resources for the DLL have been created.

Calling the library function *UcanInitHardware()* and/or *UcanInitHardwareEx()* causes the software to change into the HW_INIT state. This state contains all resources required for communication with the USB-CANmodul. It is not possible to transmit or to receive CAN messages in this state.

If the application software calls the library function *UcanInitCan()*, *UcanInitCanEx()* or *UcanInitCanEx2()* the state changes into CAN_INIT. In this state it is possible to transmit or to receive CAN messages.

Return with the library function *UcanDeinitCan()* into the state HW_INIT and with the library function *UcanDeinitHardware()* into the state DLL_INIT. It is possible to close the application program only after this sequence is completed.

Note:

Make sure to return to the state DLL_INIT before closing the application program.




Figure 18: Software State Diagram

The number of functions differs in different software states. For example, the function *UcanWriteCanMsg()* causes an error at the state DLL_INIT. Table 12 shows the different functions within each state.

If multiple USB-CANmoduls are used in one application, these states have to be considered for each USB-CANmodul that is used. If the first USB-CANmodul is in the state CAN_INIT, the second one can still be in the DLL_INIT state.

State	Functions	obsolete				new	
				sysWORXX (G3)		sysWORXX (G4)	
		GW-001	GW-002	multi-channel	single-channel	multi-channel	single-channel
DLL_INIT	<i>UcanSetDebugMode()</i>	X	X	X	X	X	X
	<i>UcanGetVersion()</i>	X	X	X	X	X	X
	<i>UcanGetVersionEx()</i>	X	X	X	X	X	X
	<i>UcanInitHwConnectControl()</i>	X	X	X	X	X	X
	<i>UcanInitHwConnectControlEx()</i>	X	X	X	X	X	X
	<i>UcanEnumerateHardware()</i>	X	X	X	X	X	X
	<i>UcanInitHardware()</i>	X	X	X	X	X	X
	<i>UcanInitHardwareEx()</i>	X	X	X	X	X	X
	<i>UcanInitHardwareEx2()</i>	X	X	X	X	X	X
HW_INIT	<i>UcanDeinitHwConnectControl()</i>	X	X	X	X	X	X
	<i>UcanGetFwVersion()</i>	X	X	X	X	X	X
	<i>UcanGetHardwareInfo()</i>	X	X	X	X	X	X
	<i>UcanGetModuleTime()</i>	X	X	X	X	X	X
	<i>UcanSetDeviceNr()</i>	X	X	X	X	X	X
	<i>UcanGetHardwareInfoEx2()</i>	XH0	XH0	X	XH0	X	XH0
	<i>UcanGetStatus()</i>	X	X	CH0	X	CH0	X
	<i>UcanGetStatusEx()</i>	XH0	XH0	X	XH0	X	XH0
	<i>UcanResetCan()</i>	X	X	CH0	X	CH0	X
	<i>UcanResetCanEx()</i>	XH0	XH0	X	XH0	X	XH0
	<i>UcanInitCan()</i>	X	X	CH0	X	CH0	X
	<i>UcanInitCanEx()</i>	X	X	CH0	X	CH0	X
	<i>UcanInitCanEx2()</i>	XH0	XH0	X	XH0	X	XH0
	<i>UcanWriteCanPort()</i>	-	X	CH0	-	CH0	-
	<i>UcanWriteCanPortEx()</i>	-	XH0	X	-	X	-
	<i>UcanReadCanPort()</i>	-	X	CH0	-	CH0	-
	<i>UcanReadCanPortEx()</i>	-	XH0	X	-	X	-
	<i>UcanConfigUserPort()</i>	-	X	X	-	X	-
	<i>UcanWriteUserPort()</i>	-	X	X	-	X	-
	<i>UcanReadUserPort()</i>	-	X	X	-	X	-
	<i>UcanReadUserPortEx()</i>	-	X	X	-	X	-
	<i>UcanDefineCyclicCanMsg()</i>	-	-	X	XH0	X	XH0
	<i>UcanReadCyclicCanMsg()</i>	-	-	X	XH0	X	XH0
	<i>UcanDeinitHardware()</i>	X	X	X	X	X	X
CAN_INIT	<i>UcanSetTxTimeout()</i>	-	-	X	-	X	-
	<i>UcanSetBaudrate()</i>	X	X	CH0	X	CH0	X
	<i>UcanSetBaudrateEx()</i>	XH0	XH0	X	XH0	X	XH0
	<i>UcanSetAcceptance()</i>	X	X	CH0	X	CH0	X
	<i>UcanSetAcceptanceEx()</i>	XH0	XH0	X	XH0	X	XH0
	<i>UcanReadCanMsg()</i>	X	X	CH0	X	CH0	X
	<i>UcanReadCanMsgEx()</i>	XH0	XH0	X	XH0	X	XH0
	<i>UcanWriteCanMsg()</i>	X	X	CH0	X	CH0	X
	<i>UcanWriteCanMsgEx()</i>	XH0	XH0	X	XH0	X	XH0
	<i>UcanGetMsgCountInfo()</i>	-	X	CH0	X	CH0	X
	<i>UcanGetMsgCountInfoEx()</i>	-	XH0	X	XH0	X	XH0
	<i>UcanEnableCyclicCanMsg()</i>	-	-	X	XH0	X	XH0
	<i>UcanGetMsgPending()</i>	-	-	X	XH0	X	XH0
	<i>UcanGetCanErrorCounter()</i>	-	-	X	XH0	X	XH0
	<i>UcanDeinitCan()</i>	X	X	CH0	X	CH0	X
	<i>UcanDeinitCanEx()</i>	XH0	XH0	X	XH0	X	XH0

Table 12: Software State Functions

Meaning of entries in Table 12:

"-": Function not supported

"X": Function supported without limitations

"CH0": Function supported for each module with one CAN-channel and/or for CAN-channel 0 of a logical module with two CAN-channels, because the function parameter for selecting the channel number is missing.

"XH0": Function only supported with function parameter selecting CAN-channel 0 of a logical module, because the hardware does only have one CAN-channel.

2.3.2 Functions of the USBCAN-library

This section describes the various functions provided by USBCAN-library. Most of the functions return a value of the type UCANRET containing an error code. The meaning of this code is the same for each function. Besides the syntax, the meaning and the parameters of each function, the possible error codes are shown.

Some of the extended functions have an additional parameter for support of multi CAN instances and enable operations on a single CAN-channel on Multiport CAN-to-USB 3004006 or USB-CANmodul2 3204002/3204003. These extended functions are also applicable on GW-002 or GW-001, as long as CAN channel 0 is used. Otherwise the functions returns with error code USBCAN_ERR_ILLCHANNEL (see section 2.3.3). All standard (single-instance) functions are applicable for Multiport CAN-to-USB 3004006 as well, but do not provide the possibility to access other CAN-channels than CAN 0. If channel other than CAN0 is used, the function returns with error code USBCAN_ERR_ILLCHANNEL (see section 2.3.3).

2.3.2.1 General functions

UcanSetDebugMode

Syntax:

```
BOOL PUBLIC UcanSetDebugMode (DWORD dwDbgLevel_p,  
    _TCHAR* pszFilePathName_p,  
    DWORD dwFlags_p);
```

Usability:

DLL_INIT, HW_INIT, CAN_INIT since version 3.11

Description:

This function enables the creation of a debug log file out of the USBCAN-library. If this feature has already been activated via the USB-CANmodul Control, the content of the "old" log file will be copied to the new file. Further debug information will be appended to the new file.

Parameter:

<i>dwDbgLevel_p:</i>	Bit mask which enables the activation of debug information to be written into the debug log file. This Bit mask has the same meaning as the "LOG-Level" of the USB-CANmodul Control and therefore is not referred to in detail.
<i>pszFilePathName_p:</i>	Path leading to a text-based file which is written by the USBCAN-library with debug information. This parameter may be set to NULL. In this case only the new value of parameter <i>dwDbgLevel_p</i> will be set.
<i>dwFlags_p:</i>	Additional flag parameter. Value 0 will create a new debug log file. If the file referring to parameter <i>pszFilePathName_p</i> does already exist, the old content will be deleted upon opening. Value 1 though will append all new debug information to an existing file.

Return value:

If FALSE returns, the debug log file could not be created. A possible reason could be that the directory path which is set by the parameter *pszFilePathName_p* does not exist.

Example:

```
// set debug mode for USBCAN API  
UcanSetDebugMode (0xE0C00B03L,          // = default Debug-Level  
    _T("C :\\MyAppPath\\MyApp.log"),    // = no append mode  
    0);
```

UcanGetVersion

Syntax:

```
DWORD PUBLIC UcanGetVersion (void);
```

Usability:

DLL_INIT, HW_INIT, CAN_INIT

Description:

This function returns the software version number of the USBCAN-library. It is overage an should not be used in current projects. Use the function *UcanGetVersionEx()* instead of.

Parameter:

none

Return value:

Software version number as DWORD with the following format:

- Bit 0 to 7: least significant digits of the version number in binary format
- Bit 8 to 15: most significant digits of the version number in binary format
- Bit 16 to 30: reserved
- Bit 31: 1 = customer specific version

Example:

```
DWORD    dwVersion;  
_TCHAR   szVersion[8];  
...  
// get version number  
dwVersion = UcanGetVersion ();  
  
// convert into a string  
_stprintf (szVersion, _T („V%d.%2d“), (dwVersion & 0xff00) >> 8,  
          dwVersion & 0xff);  
...
```


UcanGetVersionEx**Syntax:**

```
DWORD PUBLIC UcanGetVersionEx (
    tUcanVersionType    VerType_p);
```

Usability:

DLL_INIT, HW_INIT, CAN_INIT, version 2.16 and higher only

Description:

This function returns the version numbers of the individual software modules.

Parameter:

VerType_p: Type of version information shows from which software module the version is to be returned. *Table 13* lists all possible values for this parameter. The format of the version information differs from that of the *UcanGetVersion()* function.

VerType_p	Value	Meaning
kVerTypeUserDll kVerTypeUserLib	0x0001	Returns the version of the file USBCAN-library.
kVerTypeSysDrv	0x0002	Returns the version of the file USBCAN.SYS (device driver).
kVerTypeNetDrv	0x0004	Returns the version of the file UCANNET.SYS (network driver).
kVerTypeSysLd	0x0005	Returns the version of the file USBCANLD.SYS (firmware loader of USB-CANmodul GW-001).
kVerTypeSysL2	0x0006	Returns the version of the file USBCANL2.SYS (firmware loader of USB-CANmodul GW-002).
kVerTypeSysL3	0x0007	Returns the version of the file USBCANL3.SYS (firmware loader of Multiport CAN-to-USB G3).
kVerTypeSysL4	0x0008	Returns the version of the file USBCANL4.SYS (firmware loader of USB-CANmodul1 G3 3204000 / 3204001).
kVerTypeSysL5	0x0009	Returns the version of the file USBCANL5.SYS (firmware loader of USB-CANmodul2 G3 3204002 / 3204003).
kVerTypeCpl	0x000A	Returns the version of the file USBCANCL.CPL (USB-CANmodul Control from Windows Control Panel).
kVerTypeSysL21	0x000B	Returns the version of loader USBCANL21.SYS for USB-CANmodul2 G4.
kVerTypeSysL22	0x000C	Returns the version of loader USBCANL22.SYS for USB-CANmodul1 G4.

Table 13: Constants for the type of version information

Return value:

Software version number as DWORD using the following format:

Bit 0-7:	Version (Macro USBCAN_MAJOR_VER)
Bit 8-15:	Revision (Macro USBCAN_MINOR_VER)
Bit 16-31:	Release (Macro USBCAN_RELEASE_VER)

Example:

```
DWORD dwVersion;
_TCHAR  szVersion[16];
...
// Get USBCAN-library version number.
dwVersion = UcanGetVersionEx (kVerTypeUserDll);

// convert into a string.
_stprintf (szVersion, _T(„V%d.%02d.%d“),
    USBCAN_MAJOR_VER(dwVersion),
    USBCAN_MINOR_VER(dwVersion),
    USBCAN_RELEASE_VER(dwVersion));
...
```

UcanGetFwVersion**Syntax:**

```
DWORD PUBLIC UcanGetFwVersion (  
                                tUcanHandle  UcanHandle_p);
```

Usability:

HW_INIT, CAN_INIT version 2.18 and higher

Description:

This function returns the version number of the software in the USB-CANmodul.

Parameter:

UcanHandle_p: USB-CAN handle that was received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

Return value:

Software version number as DWORD in the following format:

Bit 0-7:	Version	(Macro USBCAN_MAJOR_VER)
Bit 8-15:	Revision	(Macro USBCAN_MINOR_VER)
Bit 16-31:	Release	(Macro USBCAN_RELEASE_VER)

The version number format is the same format as in the function *UcanGetVersionEx()*.

UcanInitHwConnectControl

Syntax:

```
UCANRET PUBLIC UcanInitHwConnectControl (  
    tConnectControlFkt  fpConnectControlFkt_p);
```

Usability:

DLL_INIT, HW_INIT, CAN_INIT

Description:

Initializes the supervision for recently connected USB-CANmoduls. If a new module is connected to the PC, the callback function that is indicated in the parameter will be called. This callback function is also called if a module is disconnected from the PC.

Parameter:

fpConnectControlFkt_p: Address to the callback function that has to be called if a new USB-CANmodul is connected or disconnected. This address may not be NULL!

The callback function must have the following format (see section 2.3.7):

```
void PUBLIC UcanConnectControlFkt (  
    BYTE          bEvent_p,  
    DWORD         dwParam_p);
```

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_WARN_NULL_PTR

UcanInitHwConnectControlEx

Syntax:

```
UCANRET PUBLIC UcanInitHwConnectControlEx (  
    tConnectControlFktEx    fpConnectControlFktEx_p,  
    void*                   pCallbackArg_p);
```

Usability:

DLL_INIT, HW_INIT, CAN_INIT (version 3.00 and above)

Description:

Initializes the supervision for recently connected USB-CANmodules. If a new module is connected to the PC, the callback function that is indicated in the parameter will be called. This callback function is also called if a module is disconnected from the PC.

Unlike function *UcanInitHwConnectControl()*, this function has an additional parameter, which is also passed to the callback function. This parameter can be used to handle user-specific information, such as the used CAN instance for example.

Attention:

This function must not be used simultaneously with function *UcanInitHwConnectControl()* within the same application!

Parameter:

<i>fpConnectControlFkt_p:</i>	Address to the callback function that has to be called if a new USB-CANmodul is connected or disconnected. This address must not be NULL!
<i>pCallbackArg_p:</i>	User-specific parameter that is passed to the callback function as well.

The callback function must have the following format (see section 2.3.7):

```
void PUBLIC UcanConnectControlFktEx (  
    DWORD                dwEvent_p,  
    DWORD                dwParam_p,  
    void*                pArg_p);
```

Return Value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_WARN_NULL_PTR

UcanDeinitHwConnectControl

Syntax:

```
UCANRET PUBLIC UcanDeinitHwConnectControl (void);
```

Usability:

DLL_INIT, HW_INIT, CAN_INIT

Description:

This function finishes the supervision of the recently connected or disconnected USB-CANmodules. This function must be called after the function *UcanInitHwConnectControl()* or *UcanInitHwConnectControlEx()* was called within an application and before closing this application.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL

UcanEnumerateHardware

Syntax:

```
DWORD PUBLIC UcanEnumerateHardware (
    tUcanEnumCallback    fpEnumCallback_p,
    void*                 pCallbackArg_p,
    BOOL                  fEnumUsedDevs_p,
    BYTE                  bDeviceNrLow_p,
    BYTE                  bDeviceNrHigh_p,
    DWORD                 dwSerialNrLow_p,
    DWORD                 dwSerialNrHigh_p,
    DWORD                 dwProductCodeLow_p,
    DWORD                 dwProductCodeHigh_p);
```

Usability:

DLL_INIT (version 5.04 and above)

Description:

This function scans all USB-CANmodules connected at the host and calls a callback function for each found module. The amount of the USB-CANmodules to be found can be limited by filter parameters. Within the callback function the user can decide whether the found USB-CANmodule should be automatically initialized by the DLL. In this case the module changes to the state HW_INIT.

Parameter:

<i>fpEnumCallback_p:</i>	Address to the callback function which is called for each found USB-CANmodule. This callback function is not called if the filter parameters does not match.
<i>pCallbackArg_p:</i>	User-specific parameter that is passed to the callback function as well.
<i>fEnumUsedDevs_p:</i>	Set to TRUE if USB-CANmodules should be found too which are currently exclusively used by another application. These modules cannot be used by the own application.
<i>bDeviceNrLow_p,</i> <i>bDeviceNrHigh_p:</i>	Filter parameters for the device number. The value <i>bDeviceNrLow_p</i> specifies the lower limit and the value <i>bDeviceNrHigh_p</i> specifies the upper limit of the device number which have to be found.
<i>dwSerialNrLow_p,</i> <i>dwSerialNrHigh_p:</i>	Filter parameters for the serial number. The values specifies the lower and upper limit of the serial number area which have to be found.
<i>dwProductCodeLow_p,</i> <i>dwProductCodeHigh_p:</i>	Filter parameters for the Product-Code. The values specifies the lower and upper limit of the Product-Code area which have to be found. Possible values are shown in <i>Table 15</i> .

The callback function must have the following format (see section 2.3.7):

```
void PUBLIC UcanEnumCallback (
    DWORD                dwIndex_p,
    BOOL                 fIsUsed_p,
    tUcanHardwareInfoEx* pHwInfoEx_p,
    tUcanHardwareInitInfo* pInitInfo_p
    void*                pArg_p);
```

Return value:

The function *UcanEnumerateHardware()* returns the number of found USB-CANmoduls (logical modules).

Example 1:

```
DWORD dwFoundModules;

...
// find all USB-CANmoduls, which are NOT used by other applications
dwFoundModules = UcanEnumerateHardware (AppEnumCallback, NULL,
    FALSE,
    0, ~0,    // no limitation of device number
    0, ~0,    // no limitation of serial number
    0, ~0);   // no limitation of Product-Code
...
```

Example 2:

```
DWORD dwFoundModules;

...
// find all USB-CANmoduls of typ USB-CANmodul1 (G3)
dwFoundModules = UcanEnumerateHardware (AppEnumCallback, NULL,
    FALSE,
    0, ~0,    // no limitation of device number
    0, ~0,    // no limitation of serial number
    USBCAN_PRODCODE_PID_BASIC, USBCAN_PRODCODE_PID_BASIC);
...
```

Example 3:

```
DWORD dwFoundModules;
DWORD dwSerialNr;

...
// find all logical modules of an USB-CANmodul16 (G3)
dwSerialNr = 123456; // <-- serial number at the sticker at the device case
dwFoundModules = UcanEnumerateHardware (AppEnumCallback, NULL,
    FALSE,
    0, ~0,    // no limitation of device number
    (dwSerialNr * 1000) + 1, (dwSerialNr * 1000) + 8,
    USBCAN_PRODCODE_PID_USBCAN16, USBCAN_PRODCODE_PID_USBCAN16);
...
```

UcanInitHardware

Syntax:

```
UCANRET PUBLIC UcanInitHardware (
    tUcanHandle*      pUcanHandle_p,
    BYTE              bDeviceNr_p,
    tCallbackFkt      fpCallbackFkt_p);
```

Usability:

DLL_INIT

Description:

Initializes an USB-CANmodul. The software changes into the state HW_INIT. From this point, other functions as they are defined in *Table 12* can be called. If the function was executed successfully, the function transfers an USB-CAN handle to the variable **pUcabHandle_p*. Other functions have to be called with this handle.

Parameter:

<i>pUcanHandle_p</i> :	Pointer to the variable for the USB-CAN Handle. This pointer may not be NULL!
<i>bDeviceNr_p</i> :	Device number of the USB-CANmodul (0 – 254). The value <i>USBCAN_ANY_MODULE</i> (= 255) makes sure that the first allocated USB-CANmodul is used.
<i>fpCallbackFkt_p</i> :	Address to the callback function of this USB-CANmodul. This value can be NULL. The callback function will not be called if corresponding events appear. This address can also be same as one that is already used from other USB-CANmoduls, because the callback function contains the associated USB-CAN Handle.

The callback function must have the following format (see *section 2.3.7*):

```
void PUBLIC UcanCallbackFkt (
    tUcanHandle      UcanHandle_p,
    BYTE              bEvent_p);
```

Return value:

Error code of the function.
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_HWINUSE
USBCAN_ERR_ILLHW
USBCAN_ERR_MAXMODULES
USBCAN_ERR_RESOURCE
USBCAN_ERR_ILLVERSION
USBCAN_ERR_ILLPARAM
USBCAN_ERR_IOFAILED
USBCAN_ERR_BUSY
USBCAN_ERR_TIMEOUT
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERRCMD_...

Example:

```
UCANRET bRet;  
tUcanHandle UcanHandle;  
  
...  
// initializes an USB-CANmodul without callback function  
bRet = UcanInitHardware (&UcanHandle, USBCAN_ANY_MODULE, NULL);  
...
```

UcanInitHardwareEx**Syntax:**

```
UCANRET PUBLIC UcanInitHardwareEx (
    tUcanHandle*          pUcanHandle_p,
    BYTE                  bDeviceNr_p,
    tCallbackFktEx        fpCallbackFktEx_p
    void*                  pCallbackArg_p);
```

Usability:

DLL_INIT (version 3.00 and higher)

Description:

Initializes an USB-CANmodul. The software changes into the state HW_INIT. From this point, other functions as they are defined in *Table 12* can be called. If the function was executed successfully, the function transfers an USB-CAN handle to the variable **pUcabHandle_p*. Other functions have to be called with this handle.

Unlike function *UcanInitHardware()*, this function has an additional parameter, which is also passed to the callback function.

Parameter:

<i>pUcanHandle_p:</i>	Pointer to the variable for the USB-CAN Handle. This pointer may not be NULL!
<i>bDeviceNr_p:</i>	Device number of the USB-CANmodul (0 – 254). The value <i>USBCAN_ANY_MODULE</i> (= 255) makes sure that the first allocated USB-CANmodul is used.
<i>fpCallbackFkt_p:</i>	Address to the callback function of this USB-CANmodul. This value can be NULL. The callback function will not be called if corresponding events appear. This address can also be same as one that is already used from other USB-CANmoduls, because the callback function contains the associated USB-CAN Handle.
<i>pCallbackArg_p:</i>	User-specific parameter that is passed to the callback function as well.

The callback function must have the following format (see *section 2.3.7*):

```
void PUBLIC UcanCallbackFktEx (
    tUcanHandle          UcanHandle_p,
    DWORD                 bEvent_p,
    BYTE                  bChannel_p,
    void*                  pArg_p);
```

Return value:

Error codes of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_HWINUSE
USBCAN_ERR_ILLHW
USBCAN_ERR_MAXMODULES
USBCAN_ERR_RESOURCE
USBCAN_ERR_ILLVERSION
USBCAN_ERR_ILLPARAM
USBCAN_ERR_IOFAILED
USBCAN_ERR_BUSY
USBCAN_ERR_TIMEOUT
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERRCMD_...

UcanInitHardwareEx2

Syntax:

```
UCANRET PUBLIC UcanInitHardwareEx2 (  
    tUcanHandle*          pUcanHandle_p,  
    DWORD                dwSerialNr_p,  
    tCallbackFktEx       fpCallbackFktEx_p  
    void*                 pCallbackArg_p);
```

Usability:

DLL_INIT (version 5.04 and higher)

Description:

Initializes an USB-CANmodul as alternative to the functions *UcanInitHardware()* and *UcanInitHardwareEx()*. Instead of passing the device number the serial number is passed to identify the USB-CANmodul.

Parameter:

<i>pUcanHandle_p</i> :	Pointer to the variable for the USB-CAN Handle. This pointer may not be NULL!
<i>dwSerialNr_p</i> :	Serial number of the USB-CANmodul (at the bar code sticker at the device's case). For the logical modules of an 8 or 16 channel device the serial number must be calculated with the following formula: $\text{dwSerialNr_p} = \text{BarCodeNr} * 1000 + n;$ where n is the number of the logical module beginning with 1.
<i>fpCallbackFktEx_p</i> :	Address to the callback function of this USB-CANmodul. This value can be NULL. The callback function will not be called if corresponding events appear. This address can also be same as one that is already used from other USB-CANmoduls, because the callback function contains the associated USB-CAN Handle.
<i>pCallbackArg_p</i> :	User-specific parameter that is passed to the callback function as well.

The callback function must have the following format (see section 2.3.7):

```
void PUBLIC UcanCallbackFktEx (  
    tUcanHandle          UcanHandle_p,  
    DWORD                bEvent_p,  
    BYTE                 bChannel_p,  
    void*                 pArg_p);
```

Return value:

Error codes of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_HWINUSE
USBCAN_ERR_ILLHW
USBCAN_ERR_MAXMODULES
USBCAN_ERR_RESOURCE
USBCAN_ERR_ILLVERSION
USBCAN_ERR_ILLPARAM
USBCAN_ERR_IOFAILED
USBCAN_ERR_BUSY
USBCAN_ERR_TIMEOUT
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERRCMD_...

UcanDeinitHardware

Syntax:

```
UCANRET PUBLIC UcanDeinitHardware (  
    tUcanHandle          UcanHandle_p);
```

Usability:

HW_INIT, CAN_INIT

Description:

Shuts down an initialized USB-CANmodul that was initialized with *UcanInitHardware()* or *UcanInitHardwareEx()*. The software returns to the state DLL_INIT. After the function call, the USB-CAN handle is not valid. That means, execution of the valid functions (see *Table 4*) for HW_INIT and CAN_INIT is no longer possible.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_ILLHW

Note:

This function has to be called before closing the application, otherwise other applications are no longer able to access this specific USB-CANmodul.

UcanGetModuleTime**Syntax:**

```
UCANRET PUBLIC UcanGetModuleTime (  
    tUcanHandle          UcanHandle_p,  
    DWORD*               pdwTime_p);
```

Usability:

HW_INIT, CAN_INIT version 3.01 or higher

Description:

This function reads the current time stamp from the device.

Parameter:

UcanHandle_p: USB-CAN-handle, that was returned by *UcanInitHardware()* or *UcanInitHardwareEx()*.

pdwTime_p: Pointer to a variable where the time stamp is to be stored to.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_TIMEOUT
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERRCMD_...

Note:

The execution of this function as well as the transfer of the time stamp needs run-time. In other words, after this function has returned successfully, the time stamp might be out-dated. The accuracy of this time stamp depends on many factors and is unpredictable on non real-time operating systems.

The base time of the time stamp is 1 millisecond. Since firmware versioib V5.09 a standard USB-CANmodul of fourth generation (G4) returns the time stamp in multiple of 100 microseconds, if the flag kUcanModeHighResTimer was set with the initialization of the CAN interface (refer to Table 14).

UcanSetDeviceNr

Syntax:

```
UCANRET PUBLIC UcanSetDeviceNr (  
    tUcanHandle      UcanHandle_p,  
    BYTE             bDeviceNr_p);
```

Usability:

HW_INIT, CAN_INIT (version 5.04 and higher)

Description:

This function writes a new device number to the USB-CANmodul.

Parameter:

UcanHandle_p: USB-CAN-handle, that was returned by *UcanInitHardware()* or *UcanInitHardwareEx()*

bDeviceNr_p: New device number. Valid values are 0 to 254.

Return code:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_ILLHW  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERR_TIMEOUT  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERRCMD_...
```

UcanInitCan

Syntax:

```
UCANRET PUBLIC UcanInitCan (
    tUcanHandle          UcanHandle_p,
    BYTE                  bBTR0_p,
    BYTE                  bBTR1_p,
    DWORD                 dwAMR_p,
    DWORD                 dwACR_p);
```

Usability:

HW_INIT

Description:

Initializes the CAN interface of an USB-CANmodul. The software changes into the state CAN_INIT. Now it is possible to transmit and receive CAN messages. *Table 12* shows the possible functions in this state.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bBTR0_p:</i>	Baud rate register 0 (<i>refer to section 2.3.4</i>)
<i>bBTR1_p:</i>	Baud rate register 1 (<i>refer to section 2.3.4</i>)
<i>dwAMR_p:</i>	Acceptance Mask Register (<i>refer to section 2.3.5</i>)
<i>dwACR_p:</i>	Acceptance Code Register (<i>refer to section 2.3.5</i>)

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_RESOURCE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...

UcanInitCanEx**Syntax:**

```
UCANRET PUBLIC UcanInitCanEx (
    tUcanHandle          UcanHandle_p,
    tUcanInitCanParam*   pInitCanParam_p);
```

Usability:

HW_INIT, version 2.16 or higher

Parameter:

UcanHandle_p: USB-CAN handle, that was received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

pInitCanParam_p: Pointer to an initialization structure

```
typedef struct
{
    DWORD   m_dwSize;           // Size of this structure in bytes
    BYTE    m_bMode;           // CAN Transmission Mode
                                // (see able below)
    BYTE    m_bBTR0;           // Baud rate register 0 of the SJA1000
    BYTE    m_bBTR1;           // Baud rate register 1 of the SJA1000
    BYTE    m_bOCR;            // Output control register of the SJA1000
                                // (should always be 0x1A)
    DWORD   m_dwAMR;           // Acceptance filter mask of the SJA1000
    DWORD   m_dwACR;           // Acceptance filter code of the SJA1000
    DWORD   m_dwBaudrate;      // Baudrate register for Multiport,
                                // USB-CANmodul1 and USB-CANmodul2

    // number of entries in receive buffer in USBCAN-library
    WORD    m_wNrOfRxBufferEntries;

    // number of entries in transmit buffer in USBCAN-library
    WORD    m_wNrOfTxBufferEntries;
} tUcanInitCanParam;
```

Note:

The configuration of the baud rate differs significantly between the older USB-CANmodul versions (GW-001 and GW-002) and the new sysWORXX modules. For standardized baud rate values (see *section 2.3.4*), the baud rate registers BTR0 and BTR1 are as well applicable for the new sysWORXX modules. Therefore set *m_dwBaudrate* to USBCAN_BAUDEX_USE_BTR01.

The mode of CAN transmission is configured by an 8-bit bit-mask. The following table shows all possible constants/modes:

Constant	Value	Meaning
kUcanModeNormal	0x00	normal transmit- and receive mode
kUcanModeListenOnly	0x01	listen-only mode; transmitted CAN messages are not sent out via CAN-bus. Received CAN-messages of remote nodes are not acknowledged.
kUcanModeTxEcho	0x02	<i>UcanReadCanMsg()</i> also returns transmitted messages as transmit echo. (see function <i>UcanReadCanMsg()</i>) (not available for GW-001/GW-002)
kUcanModeHighResTimer	0x08	The time stamp of CAN-message structure <i>tCanMsgStruct</i> is high-resolution for received CAN-reports. This means the value in the member-variable <i>m_dwTime</i> for the standard-variant has 100µs resolution (instead 1ms). The overrun of the 32-Bit value this is reached every 4d:23h:18min:16,7296s. This feature is only available for the newer fourth generation of USB-CANmoduls (G4).

Table 14: Constants for CAN transmission mode

Description:

Initializes the CAN interface of an USB-CANmodul with expanded parameters. This function works like the function *UcanInitCan()*. However, it should not be called in combination with *UcanInitCan()*.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_RESOURCE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...
```

UcanInitCanEx2

Syntax:

```
UCANRET PUBLIC UcanInitCanEx2 (
    tUcanHandle      UcanHandle_p,
    BYTE             bChannel_p
    tUcanInitCanParam* pInitCanParam_p);
```

Usability:

HW_INIT version 3.00 and higher

Parameter:

UcanHandle_p: USB-CAN-handle, that was received with function *UcanInitHardware()* or *UcanInitHardwareEx()*.

bChannel_p: CAN-channel, which is to be initialized.
 USBCAN_CHANNEL_CH0 for CAN-channel 0
 USBCAN_CHANNEL_CH1 for CAN- channel 1

pInitCanParam_p: Pointer a structure containing the initialization data

Structure *tUcanInitCanParam* is described with function *UcanInitCanEx()*.

Description:

Initializes the specified CAN-channel of an USB-CANmodul. For GW-001 and GW-002 only CAN-channel 0 can be initialized. Use this function alternatively for function *UcanInitCanEx()*.

Return value:

Error codes of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_RESOURCE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...
```

UcanSetTxTimeout

Syntax:

```
UCANRET PUBLIC UcanSetTxTimeout (
    tUcanHandle          UcanHandle_p,
    BYTE                 bChannel_p,
    DWORD                dwTxTimeout_p);
```

Usability:

CAN_INIT since version 3.10, only for multi-channel modules

Description:

Is this function called with a timeout value bigger than 0 milliseconds then firmware controls all transmit CAN messages by this timeout. If a CAN message cannot be sent during this timeout then firmware changes to a special state whereas all further transmit CAN messages for the specified channel will be deleted automatically. At each deleted transmit CAN message firmware sets the new CAN driver state USBCAN_CANERR_TXMSGLOST. When the CAN message could be sent later then firmware leaves this special state.

This feature is to prevent that transmit CAN messages of a channel blocks transmit CAN messages of the other channel caused by not connected remote CAN device or any physical problems on CAN bus.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p:</i>	CAN-channel for setting the timeout USBCAN_CHANNEL_CH0 for channel 0 USBCAN_CHANNEL_CH1 for channel 1
<i>dwTxTimeout_p:</i>	Transmission Timeout in milliseconds. The value 0 switches off the timeout control.

Return value: **Error code of the function.**

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...
```

UcanResetCan

Syntax:

```
UCANRET PUBLIC UcanResetCan (tUcanHandle UcanHandle_p);
```

Usability:

HW_INIT, CAN_INIT

Description:

Resets the CAN controller in the USB-CANmodul and erases the CAN message buffer. This function needs to be called if a BUSOFF event occurred. Starting at version 2.17 a CAN status error (readable via *UcanGetStatus()*) is also cleared.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...

UcanResetCanEx**Syntax:**

```
UCANRET PUBLIC UcanResetCanEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bChannel_p,  
    DWORD                dwResetFlags_p);
```

Usability:

HW_INIT, CAN_INIT, version 3.00 and higher

Description:

Resets parametered global features of features of a separate CAN-channel of an USB-CANmodul (see function *UcanResetCan()*). For GW-001, GW-002 and USB-CANmodul1 only features of CAN-channel 0 can be reset.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

bChannel_p: CAN-channel that is to be reset
USBCAN_CHANNEL_CH0 for channel 0
USBCAN_CHANNEL_CH1 for channel 1

dwResetFlags_p: The flags of this parameter specify what components are to be reset (see list below). The logical combination of different flags is possible.

USBCAN_RESET_ALL 0x00000000:
Reset all components. However, the firmware is not reset completely.

USBCAN_RESET_NO_STATUS 0x00000001:
Skip reset of the CAN error status (not supported for GW-001 and/or GW-002).

USBCAN_RESET_NO_CANCTRL 0x00000002:
Skip reset of the CAN controller.

USBCAN_RESET_NO_TXCOUNTER 0x00000004:
Skip reset of the transmit message counter.

USBCAN_RESET_NO_RXCOUNTER 0x00000008:
Skip reset of the receive message counter.

USBCAN_RESET_NO_TXBUFFER_CH 0x00000010:
Skip reset of the transmit buffers of a specific CAN-channel (CAN-channel is specified by parameter *bChannel_p*).

USBCAN_RESET_NO_TXBUFFER_DLL.....	0x00000020:
Skip reset of the transmit buffer for both CAN-channels within the DLL.	
USBCAN_RESET_NO_TXBUFFER_FW	0x00000080:
Skip reset of the transmit buffers of both CAN-channels within the device's firmware.	
USBCAN_RESET_NO_RXBUFFER_CH.....	0x00000100:
Skip reset of the receive buffers of a specific CAN-channel (CAN-channel is specified by parameter <i>bChannel_p</i>).	
USBCAN_RESET_NO_RXBUFFER_DLL	0x00000200:
Skip reset of both receive message counters within the DLL	
USBCAN_RESET_NO_RXBUFFER_SYS.....	0x00000400:
Skip reset of the receive message counter of both CAN-channels within the Kernel-Mode driver.	
USBCAN_RESET_NO_RXBUFFER_FW	0x00000800:
Skip reset of receive message counters of both CAN-channels within the device's firmware.	
USBCAN_RESET_FIRMWARE.....	0xFFFFFFFF:
Complete reset of the device firmware.	

There are the following predefined combinations:

USBCAN_RESET_ONLY_STATUS:.....	0x0000FFFE
Reset of the CAN error status only.	
USBCAN_RESET_ONLY_CANCTRL:.....	0x0000FFFD
Only resets the CAN controller of the USB-CANmodul. This has to be done after each bus-off state because the CAN controller cannot leave this state automatically.	
USBCAN_RESET_ONLY_RXBUFFER_FW:.....	0x0000F7FF
Only resets the receive buffer within the firmware of the USB-CANmodul.	
USBCAN_RESET_ONLY_TXBUFFER_FW:	0x0000FF7F
Only resets the transmit buffer within the firmware of the USB-CANmodul.	
USBCAN_RESET_ONLY_RXCHANNEL_BUFF:	0x0000FEFF
Reset of the receive buffer of only one CAN-channel.	
USBCAN_RESET_ONLY_TXCHANNEL_BUFF:.....	0x0000FFEF
Reset of the transmit buffer of only one CAN-cannel.	
USBCAN_RESET_ONLY_RX_BUFF:	0x0000F0F7
Reset of the receive buffers in all software parts and reset of the receive message counter.	
USBCAN_RESET_ONLY_TX_BUFF:.....	0x0000FF0B
Reset of the transmit buffers in all software parts and reset of the transmit message counter.	

USBCAN_RESET_ONLY_ALL_BUFF: 0x0000F003

Reset off all message buffers (receive and transmit buffers) in all software parts and reset of the reception and transmit message counters.

USBCAN_RESET_ONLY_ALL_COUNTER: 0x0000FFF3

Reset of all reception and transmit counters.

Important:

If the constants USBCAN_RESET_NO_... should be combined, a logical OR has to be used.

Example:

```
dwFalgs =  USBCAN_RESET_NO_COUNTER_ALL  |  
           USBCAN_RESET_NO_BUFFER_ALL;
```

If the constants USBCAN_RESET_ONLY_... has to be combined, a logical AND has to be used.

Example:

```
dwFalgs =  USBCAN_RESET_ONLY_RX_BUFF  &  
           USBCAN_RESET_ONLY_STATUS;
```

For GW-002 the constant USBCAN_RESET_ONLY_RX_BUFF_GW02 has to be used instead of USBCAN_RESET_ONLY_RX_BUFF. But in this case the transmit buffer in module firmware will be reset too.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_CANNOTINIT  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERRCMD_...  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLCHANNEL  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERR_TIMEOUT
```

UcanDeinitCan**Syntax:**

```
UCANRET PUBLIC UcanDeinitCan (tUcanHandle UcanHandle_p);
```

Usability:

CAN_INIT

Description:

Shuts down the CAN interface of an USB-CANmodul. This function sets the operating voltage of the CAN controller to 0 V. After calling this function, all CAN messages received from CAN bus are ignored and not transferred to the PC.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...

UcanDeinitCanEx

Syntax:

```
UCANRET PUBLIC UcanDeinitCanEx (  
    tUcanHandle          UcanHandle_p ,  
    BYTE                 bChannel_p);
```

Usability:

CAN_INIT

Description:

Shuts down a selective CAN interface of an USB-CANmodul. This function sets the operating voltage of the CAN controller to 0 V. After calling this function, all CAN messages received from CAN bus are ignored and not transferred to the PC.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

bChannel_p: CAN-channel that is to be shut down.
USBCAN_CHANNEL_CH0 for CAN-channel 0
USBCAN_CHANNEL_CH1 for CAN-channel 1

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...

UcanGetHardwareInfo

Syntax:

```
UCANRET PUBLIC UcanGetHardwareInfo (
    tUcanHandle          UcanHandle_p,
    tUcanHardwareInfo*   pHwInfo_p);
```

Usability:

HW_INIT, CAN_INIT

Description:

This function returns the hardware information of an USB-CANmodul. This function is especially useful if an USB-CANmodul has been initialized with the device number *USBCAN_ANY_MODULE*. Afterwards, the hardware information contains the device number of the initialized USB-CANmodul.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

pHwInfo_p: Address to the hardware information structure (see description below).

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
```

```
typedef struct
{
    BYTE          m_bDeviceNr; // Device number
    tUcanHandle    m_UcanHandle; // USB-CAN handle
    DWORD          m_dwReserved; // reserved
    BYTE          m_bBTR0; // Baud rate register 0
    BYTE          m_bBTR1; // Baud rate register 1
    BYTE          m_bOCR; // Output control register
    DWORD          m_dwAMR; // Acceptance mask register
    DWORD          m_dwACR; // Acceptance code register
    BYTE          m_bMode; // CAN controller mode
                    // (see tUcanMode)
    DWORD          m_dwSerialNr; // Serial number
                    // of the USB-CANmoduls
} tUcanHardwareInfo;
```

Note:

The parameters *m_bMode* and *m_dwSerialNr* are only available with the software version 2.16 and higher.

Example:

```
UCANRET bRet;
tUcanHandle UcanHandle;
tUcanHardwareInfo HwInfo;
_TCHAR szDeviceNr[24];

...
// initialize USB-CANmodul
bRet = UcanInitHardware (&UcanHandle, USBCAN_ANY_MODULE, NULL);

// no error?
if (bRet == USBCAN_SUCCESSFUL)
{
    // get hardware information
    UcanGetHardwareInfo (UcanHandle, &HwInfo);

    // change the device number into a string
    _stprintf (szDeviceNr, _T („device number = %d\"),
        HwInfo.m_bDeviceNr);
    ...
}
...
```

UcanGetHardwareInfoEx2

Syntax:

```
UCANRET PUBLIC UcanGetHardwareInfoEx2 (
    tUcanHandle          UcanHandle_p,
    tUcanHardwareInfoEx* pHwInfoEx_p,
    tUcanChannelInfo*    pCanInfoCh0_p,
    tUcanChannelInfo*    pCanInfoCh1_p);
```

Usability:

HW_INIT, CAN_INIT ,version 3.00 and higher

Description:

This function returns the extended hardware information of an USB-CANmodul. For the Multiport CAN-to-USB 3004006, USB-CANmodul1 and USB-CANmodul2, the hardware information of each CAN-channel is returned separately.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

pHwInfoEx_p: Pointer to extended hardware information structure (see description below).

pCanInfoCh0_p: Pointer to information structure used for CAN-channel 0. This parameter may be set to NULL.

pCanInfoCh1_p: Pointer to information structure used for CAN-channel 1. This parameter may be set to NULL.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
```

```
typedef struct
{
    DWORD          m_dwSize;           // number of Bytes of
                                        // this structure
    tUcanHandle m_UcanHandle;          // USB-CAN-Handle
    BYTE          m_bDeviceNr;         // device number
    DWORD          m_dwSerialNr;        // serial number
    DWORD          m_dwFwVersionEx;     // Firmware Version
    DWORD          m_dwReserved;        // reserved
    DWORD          m_dwProductCode;     // Hardware Type (see Table 15)
} tUcanHardwareInfoEx;
```

```
typedef struct
{
    DWORD    m_dwSize;           // size of this structure in bytes
    BYTE     m_bMode;           // CAN-mode (see tUcanMode)
    BYTE     m_bBTR0;           // Bus Timing Register 0
    BYTE     m_bBTR1;           // Bus Timing Register 1
    BYTE     m_bOCR;            // Output Control Register
    DWORD    m_dwAMR;           // Acceptance Mask Register
    DWORD    m_dwACR;           // Acceptance Code Register
    DWORD    m_dwBaudrate;      // Baudrate Register for Multiport,
                                // USB-CANmodul1 und USB-CANmodul2
    BOOL     m_fCanIsInit;      // is TRUE when CAN-channel was
                                // initialised
    WORD     m_wCanStatus;      // last CAN state
                                // (see UcanGetStatus())
} tUcanChannelInfo;
```

The 32-Bit value in *m_dwProductCode* of structure *tUcanHardwareInfoEx* specifies the Hardware-Type of the USB-CANmodul with the lower 16 bits. *Table 15* lists all possible values:

Constant USBCAN_PRODCODE_...	Value	Hardware-Type
...PID_GW001	0x1100	USB-CANmodul of first generation (G1)
...PID_GW002	0x1102	USB-CANmodul of second generation (G2)
...PID_MULTIPORT	0x1103	Multiport CAN-to-USB of third generation (sysWORXX, G3) including 16 CAN channels
...PID_BASIC	0x1104	USB-CANmodul1 of third generation (sysWORXX, G3) including one CAN channel
...PID_ADVANCED	0x1105	USB-CANmodul2 of third generation (sysWORXX, G3) including 2 CAN channels
...PID_USBCAN8	0x1107	USB-CANmodul8 of third generation (sysWORXX, G3) including 8 CAN channels
...PID_USBCAN16	0x1109	USB-CANmodul16 of third generation (sysWORXX, G3) including 16 CAN channels
...PID_RESERVED3	0x1110	Resered
...PID_ADVANCED_G4	0x1121	USB-CANmodul2 of fourth generation (sysWORXX, G4) including 2 CAN channels
...PID_BASIC_G4	0x1122	USB-CANmodul1 of fourth generation (sysWORXX, G4) including one CAN channel
...PID_RESERVED1	0x1144	Resered
...PID_RESERVED2	0x1145	Resered rt

Table 15: Constants for Product-Code / Hardware-Type

Use the following macros for getting information about the support of several new features:

USBCAN_CHECK_SUPPORT_CYCLIC_MSG(pHwIndoEx)

This Macro checks whether the logical USB-CANmodul supports the automatic transmission of cyclic CAN messages.

USBCAN_CHECK_SUPPORT_TWO_CHANNEL(pHwInfoEx)

This Macro checks whether the logical USB-CANmodul supports two CAN-channels.

USBCAN_CHECK_SUPPORT_TERM_RESISTOR(pHwInfoEx)

This Macro checks whether the logical USB-CANmodul supports to read back the state of the termination resistor.

USBCAN_CHECK_SUPPORT_USER_PORT(pHwInfoEx)

This Macro checks whether the logical USB-CANmodul supports a programmable Expansion Port (*refer to section 1.5*).

USBCAN_CHECK_SUPPORT_RBUSER_PORT(pHwInfoEx)

This Macro checks whether the logical USB-CANmodul supports a programmable Expansion Port including the storing of the last output configuration to a non-volatile memory. After next power-on this configuration will be automatically set to the Expansion Port.

USBCAN_CHECK_SUPPORT_RBCAN_PORT(pHwInfoEx)

This Macro checks whether the logical USB-CANmodul supports a programmable CAN Port (for low-speed CAN transceivers) including the storing of the last output configuration to a non-volatile memory. After next power-on this configuration will be automatically set to the CAN Port.

Example:

```

UCANRET          bRet;
tUcanHandle      UcanHandle;
tUcanHardwareInfoEx HwInfoEx;

...
// init USB-CANmodul
bRet = UcanInitHardware (&UcanHandle, USBCAN_ANY_MODULE, NULL);
if (bRet == USBCAN_SUCCESSFUL)
{
    memset (&HwInfoEx, 0, sizeof (HwInfoEx));
    HwInfoEx.m_dwSize = sizeof (HwInfoEx);

    // get the extended hardware information
    bRet = UcanGetHardwareInfoEx2 (UcanHandle, &HwInfoEx,
        NULL, NULL);
    if (bRet == USBCAN_SUCCESSFUL)
    {
        TRACE1 ("product code = 0x%04X\n",
            HwInfoEx->m_dwProductCode & USBCAN_PRODCODE_MASK_PID);

        // check whether two CAN-channels are supported
        if (USBCAN_CHECK_SUPPORT_TWO_CHANNEL (&HwInfoEx))
        {
            ...
        }
        ...
    }
    ...
}

```

UcanGetMsgCountInfo

Syntax:

```
UCANRET PUBLIC UcanGetMsgCountInfo (
    tUcanHandle          UcanHandle_p,
    tUcanMsgCountInfo*   pMsgCountInfo_p);
```

Usability:

CAN_INIT , version 3.00 and higher

Description:

Reads the counters for transmitted and received CAN messages from the device.

Parameter:

UcanHandle_p: USB-CAN-handle, that was returned by *UcanInitHardware()* or *UcanInitHardwareEx()*.

pMsgCountInfo_p: Pointer to a structure of type *tUcanMsgCountInfo* where the counters are to be stored to

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERRCMD...
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLPARAM
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
```

```
typedef struct
{
    WORD m_wSentMsgCount; // Counter for transmitted CAN-messages
    WORD m_wRecvdMsgCount; // Counter for received CAN-messages
} tUcanMsgCountInfo;
```

UcanGetMsgCountInfoEx

Syntax:

```
UCANRET PUBLIC UcanGetMsgCountInfoEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bChannel_p,  
    tUcanMsgCountInfo*   pMsgCountInfo_p);
```

Usability:

CAN_INIT, version 2.16 and higher

Description:

Reads the counters for transmitted and received CAN messages of a specific CAN-channel from the device.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN-handle, that was returned by <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p:</i>	CAN-channel to read the counters from. USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pMsgCountInfo_p:</i>	Pointer to a structure of type <i>tUcanMsgCountInfo</i> where the counters are to be stored to

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERR_TIMEOUT  
USBCAN_ERRCMD...
```

Structure *tUcanMsgCountInfo* is described with function *UcanGetMsgCountInfo()*.

UcanGetStatus

Syntax:

```
UCANRET PUBLIC UcanGetStatus (
    tUcanHandle          UcanHandle_p,
    tStatusStruct*       pStatus_p);
```

Usability:

HW_INIT, CAN_INIT

Description:

This function returns the error status from the USB-CANmodul. If an error occurred on the USB-CANmodul, the red status LED starts blinking and a status message is sent to the PC. If a callback function has been handed over to the function *UcanInitHardware()* or *UcanInitHardwareEx()*, this callback function is called, as well as the event *USBCAN_EVENT_STATUS*. After calling the function *UcanGetStatus()*, the error state on the USB-CANmodul is erased and the red status LED stops blinking. Starting at version 2.17 a CAN status error must be cleared by calling the function *UcanResetCan*.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

pStatus_p: Error status of the USB-CANmodul.

```
typedef struct
{
    WORD    m_wCanStatus;    // present CAN status
    WORD    m_wUsbStatus;    // present USB status
} tStatusStruct;
```

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
```

The WORD *m_wCanStatus*, found in the *tStatusStruct* structure, returns the following values:

<i>USBCAN_CANERR_OK</i>	= 0x0000
No error	
<i>USBCAN_CANERR_XMTFULL</i>	= 0x0001
Transmit buffer in CAN controller is overrun	
<i>USBCAN_CANERR_OVERRUN</i>	= 0x0002
Receive buffer in CAN controller is overrun	
<i>USBCAN_CANERR_BUSLIGHT</i>	= 0x0004
Error limit 1 in CAN controller exceeded, CAN controller is in state "Warning limit" now	
<i>USBCAN_CANERR_BUSHEAVY</i>	= 0x0008
Error limit 2 in CAN controller exceeded, CAN controller is in state "Error Passive" now	
<i>USBCAN_CANERR_BUSOFF</i>	= 0x0010
CAN controller is in BUSOFF state	
<i>USBCAN_CANERR_QOVERRUN</i>	= 0x0040
Receive buffer in module is overrun	
<i>USBCAN_CANERR_QXMTFULL</i>	= 0x0080
Transmit buffer in module is overrun	
<i>USBCAN_CANERR_REGTEST</i>	= 0x0100
CAN controller not found (hardware error)	
<i>USBCAN_CANERR_TXMSGLOST</i>	= 0x0400
A transmit CAN message was deleted automatically by the firmware because transmission timeout run over (<i>refer to function UcanSetTxTimeout()</i>).	

This WORD is bit oriented; it can indicate multiple errors simultaneously.

WORD *m_wUsbStatus* is becoming obsolete and is retained only for compatibility purposes. It retains the value 0.

UcanGetStatusEx

Syntax:

```
UCANRET PUBLIC UcanGetStatusEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bChannel_p  
    tStatusStruct*       pStatus_p);
```

Usability:

HW_INIT, CAN_INIT , version 3.00 and higher

Description:

This function returns the error status of a specific CAN-channel from the USB-CANmodul. This function may be used alternatively for function *UcanGetStatus()*.

Structure *tStatusStruct* is described in section *UcanGetStatus()*.

Parameter:

<i>UcanHandle_p</i> :	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>pStatus_p</i> :	Error status of the USB-CANmodul.
<i>bChannel_p</i> :	Specifies the CAN-channel of which the status is to be returned. USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_ILLHW
```

UcanSetBaudrate

Syntax:

```
UCANRET PUBLIC UcanSetBaudrate (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bBTR0_p,  
    BYTE                 bBTR1_p);
```

Usability:

CAN_INIT

Description:

Changes the baud rate configuration of the USB-CANmodul.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bBTR0_p:</i>	Baud rate register 0 (refer to section 2.3.4)
<i>bBTR1_p:</i>	Baud rate register 1 (refer to section 2.3.4)

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_CANNOTINIT  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLCHANNEL  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERR_TIMEOUT  
USBCAN_ERRCMD_...
```

UcanSetBaudrateEx**Syntax:**

```
UCANRET PUBLIC UcanSetBaudrateEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bChannel_p  
    BYTE                 bBTR0_p,  
    BYTE                 bBTR1_p,  
    DWORD                dwBaudrate_p);
```

Usability:

CAN_INIT , version 3.00 and higher

Description:

Changes the baud rate configuration of a specific CAN-channel of the USB-CANmodul. This function may be used alternatively for function *UcanSetBaudrate()*.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p:</i>	CAN-channel that is to be changed USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>bBTR0_p:</i>	Baud rate register BTR0 (<i>refer to section 2.3.4</i>)
<i>bBTR1_p:</i>	Baud rate register BTR1 (<i>refer to section 2.3.4</i>)
<i>dwBaudrate_p:</i>	Baud rate register for all sysWORXX modules (<i>refer to section 2.3.4</i>)

Note:

The configuration of the baud rate differs significantly between the older USB-CANmodul versions (GW-001 and GW-002) and the new sysWORXX modules. For standardized baud rate values (see *section 2.3.4*), the baud rate registers BTR0 and BTR1 are as well applicable for the new sysWORXX modules. Therefore set *m_dwBaudrate* to USBCAN_BAUDEX_USE_BTR01.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...

UcanSetAcceptance

Syntax:

```
UCANRET PUBLIC UcanSetAcceptance (  
    tUcanHandle          UcanHandle_p,  
    DWORD                dwAMR_p,  
    DWORD                dwACR_p);
```

Usability:

CAN_INIT

Description:

Changes the acceptance Mask Register of the USB-CANmodul.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

dwAMR_p: Acceptance Mask Register (see section 2.3.5)

dwACR_p: Acceptance Code Register (see section 2.3.5)

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...

UcanSetAcceptanceEx

Syntax:

```
UCANRET PUBLIC UcanSetAcceptanceEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bChannel_p  
    DWORD               dwAMR_p,  
    DWORD               dwACR_p) ;
```

Usability:

CAN_INIT version 3.00 and higher

Description:

Changes the acceptance Mask Register of a specific CAN-channel of the USB-CANmodul. This function may be used alternatively for function *UcanSetAcceptance()*.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p:</i>	CAN-channel that is to be changed USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>dwAMR_p:</i>	Acceptance Mask Register (see section 2.3.5)
<i>dwACR_p:</i>	Acceptance Code Register (see section 2.3.5)

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_CANNOTINIT  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLCHANNEL  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERR_TIMEOUT  
USBCAN_ERRCMD_...
```

UcanReadCanMsg

Syntax:

```
UCANRET PUBLIC UcanReadCanMsg (  
    tUcanHandle          UcanHandle_p,  
    tCanMsgStruct*       pCanMsg_p);
```

Usability:

CAN_INIT

Description:

Reads a CAN message from the buffer. If the buffer contains no CAN messages, this function returns a warning. If a buffer overrun occurred, this function returns a valid CAN message and a warning.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

pCanMsg_p: Address to a CAN message structure. This address must not be NULL.

```
typedef struct  
{  
    DWORD    m_dwID;           // CAN identifier  
    BYTE     m_bFF;           // CAN frame format  
    BYTE     m_bDLC;           // CAN data length code  
    BYTE     m_bData[8];       // CAN data  
    DWORD    m_dwTime;         // Receipt time in lms  
                                // (or in 100µs - refer to Table 14)  
} tCanMsgStruct;
```

The CAN-frame format is a bit mask that specifies the format of the CAN-message. The following table lists all valid values:

Constant	Value	Description
USBCAN_MSG_FF_STD	0x00	CAN2.0A message with 11-bit CAN-ID
USBCAN_MSG_FF_ECHO	0x20	transmit echo; Is only received if mode kUcanModeTxEcho was enabled at initialization time.
USBCAN_MSG_FF_RTR	0x40	CAN Remote Frame
USBCAN_MSG_FF_EXT	0x80	CAN2.0B message with 29-bit CAN-ID

Table 16: Constants for the CAN-frame format

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_WARN_NODATA
USBCAN_WARN_SYS_RXOVERRUN
USBCAN_WARN_DLL_RXOVERRUN
USBCAN_WARN_FW_RXOVERRUN
```

Example:

```
tUcanHandle UcanHandle;
tCabMsgStruct CanMsg;
UCANRET bRet;

...
while (1)
{
    // read CAN-message
    bRet = UcanReadCanMsg (UcanHandle, &CanMsg);

    // No error? Print CAN-message
    if (USBCAN_CHECK_VALID_RXCANMSG (bRet))
    {
        PrintCanMsg (&CanMsg);
        if (USBCAN_CHECK_WARNING (bRet))
        {
            PrintWarning (bRet);
        }
    }
    // No warning? Print error
    else if (USBCAN_CHECK_ERROR (bRet))
    {
        PrintError (bRet);
        break;
    }
    else
    {
        break;
    }
}
...
```

Note:

In order to avoid receive buffer overflows it is recommended to call function *UcanReadCanMsg()* cyclically (e.g. in a loop) as long as a valid CAN-message was received.

A valid CAN-message was read, even if a warning was returned (except `USBCAN_WARN_NODATA`). You can use the macro `USBCAN_CHECK_VALID_RXCANMSG()` for checking whether a valid CAN message was stored to the CAN message structure (like shown in upper example).

UcanReadCanMsgEx

Syntax:

```
UCANRET PUBLIC UcanReadCanMsgEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE*                pbChannel_p  
    tCanMsgStruct*       pCanMsg_p,  
    DWORD*               pdwCount_p);
```

Usability:

CAN_INIT ,version 3.00 and higher

Description:

Reads a CAN message from the buffer of a specific CAN-channel. If the buffer contains no CAN messages, this function returns a warning. If a buffer overrun occurred, this function returns a valid CAN message and a warning. This function may be used alternatively for function *UcanReadCanMsg()*.

Parameter:

<i>UcanHandle_p</i> :	USB CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p</i> :	CAN-channel to read data from USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1 If USBCAN_CHANNEL_ANY is given, the function will write the number of the CAN-channel that received CAN messages to this parameter
<i>pCanMsg_p</i> :	Address to a CAN message structure. This address must not be NULL.
<i>pdwCount_p</i> :	Address to a variable that specifies the maximum number of CAN messages to be read. This function writes the actual number of CAN messages that were read from the device to this variable. If this parameter is set to NULL, only one CAN message is read from the device.

The structure *tCanMsgStruct* is described in function *UcanReadCanMsg()*.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_WARN_NODATA
USBCAN_WARN_SYS_RXOVERRUN
USBCAN_WARN_DLL_RXOVERRUN
USBCAN_WARN_FW_RXOVERRUN
```

Example:

```
tUcanHandle UcanHandle;
tCabMsgStruct RxCanMsg[16];
UCANRET bRet;
BYTE bChannel;
DWORD dwCount;

while (1)
{
    // read up to 16 CAN messages
    bChannel = USBCAN_CHANNEL_ANY;
    dwCount = sizeof(RxCanMsg) / sizeof(tCabMsgStruct);
    bRet = UcanReadCanMsgEx (UcanHandle, &bChannel,
        &RxCanMsg, &dwCount);

    // No error? print CAN-message
    if (USBCAN_CHECK_VALID_RXMSG (bRet))
    {
        PrintCanMessages (&RxCanMsg[0], dwCount);
        if (USBCAN_CHECK_WARNING (bRet))
            PrintWarning (bRet);
    }
    // No warning? Print error
    else if (USBCAN_CHECK_WARNING (bRet))
    {
        PrintError (bRet);
        break;
    }
    else
    {
        break;
    }
}
...
```


Note:

In order to avoid receive buffer overflows it is recommended to call function *UcanReadCanMsg()* cyclically (e.g. in a loop) as long as a valid CAN-message was received.

A valid CAN-message was read, even if a warning was returned (except *USBCAN_WARN_NODATA*). You can use the macro *USBCAN_CHECK_VALID_RXCANMSG()* for checking whether a valid CAN message was stored to the CAN message structure (like shown in upper example).

Since software version 3.05 the size of the receive buffer (maximum number of CAN messages) is configurable (see function *UcanInitCanEx()* and structure *tUcanInitCanParam*)

UcanWriteCanMsg

Syntax:

```
UCANRET PUBLIC UcanWriteCanMsg (  
    tUcanHandle          UcanHandle_p,  
    tCanMsgStruct*       pCanMsg_p);
```

Usability:

CAN_INIT

Description:

Transmits a CAN message through the USB-CANmodul.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

pCanMsg_p: Address to a CAN message structure. This address must not be NULL.

```
typedef struct  
{  
    DWORD    m_dwID;           // CAN identifier  
    BYTE     m_bFF;           // CAN frame format *)  
    BYTE     m_bDLC;           // CAN data length code  
    BYTE     m_bData[8];       // CAN data  
    DWORD    m_dwTime;         // has no meaning in this function  
}  
tCanMsgStruct;
```

*) The meaning of CAN frame format is given with function *UcanReadCanMsg()*. For transmission of CAN messages, bit USBCAN_MSG_FF_ECHO has no meaning.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_CANNOTINIT  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_DLL_TXFULL  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLCHANNEL  
USBCAN_WARN_FW_TXOVERRUN
```

UcanWriteCanMsgEx

Syntax:

```
UCANRET PUBLIC UcanWriteCanMsgEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE                bChannel_p  
    tCanMsgStruct*       pCanMsg_p  
    DWORD*              pdwCount_p) ;
```

Usability:

CAN_INIT , version 3.00 and higher

Description:

Transmits one or more CAN messages through the specified CAN-channel of the USB-CANmodul. This function may be used alternatively for function *UcanWriteCanMsg()*.

Parameter:

<i>UcanHandle_p:</i>	USB CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>pCanMsg_p:</i>	Address to a CAN message structure. This address must not be NULL.
<i>bChannel_p:</i>	CAN-channel to read data from USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pdwCount_p:</i>	Address to a variable that specifies the maximum number of CAN messages to be transmitted. After calling, this function writes the actual number of CAN messages that were sent to this variable. If this parameter is set to NULL, only one CAN message will be transmitted.

The structure *tCanMsgStruct* is described with function *UcanWriteCanMsg()*.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_CANNOTINIT  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_DLL_TXFULL  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLCHANNEL  
USBCAN_WARN_FW_TXOVERRUN  
USBCAN_WARN_TXLIMIT
```

Note:

If this function is called for transmitting more than one CAN messages, then the return code has also to be checked for the warning USBCAN_WARN_TXLIMIT. Receiving this return value only a part of the CAN messages was stored to the transmit buffer in USBCAN32.DLL. The variable which is referenced by the parameter *pdwCount_p* gets the number of successfully stored CAN messages. The part which was not stored to the transmit buffer has to be tried to be sent again by the application. Otherwise they will be lost.

You can use the macro *USBCAN_CHECK_TX_NOTALL()* for checking the return value whether some CAN messages could not be copied to the transmit buffer (see lower example). The macro *USBCAN_CHECK_TX_SUCCESS()* checks whether all CAN messages could be stored to the transmit buffer while the macro *USBCAN_CHECK_TX_OK()* checks whether one CAN message at least was stored to the transmit buffer.

Example:

```
tUcanHandle UcanHandle;
tCabMsgStruct TxCanMsg[10];
UCANRET bRet;
DWORD dwCount;

...
{
    // transmit up to 10 CAN messages
    dwCount = sizeof (TxCanMsg) / sizeof (tCabMsgStruct);
    bRet = UcanWriteCanMsgEx (UcanHandle, USBCAN_CHANNEL_CH0,
        &TxCanMsg, &dwCount);

    // Check whether no error occurred
    if (USBCAN_CHECK_TX_OK (bRet))
    {
        // check whether a part of the array was not sent
        if (USBCAN_CHECK_TX_NOTALL (bRet))
        {
            ...
        }
        // check whether there was another warning
        else if (USBCAN_CHECK_WARNING (bRet))
        {
            PrintWarning (bRet);
        }
    }
    // check wheher an error occurred
    else if (USBCAN_CHECK_ERROR (bRet))
    {
        PrintError (bRet);
    }
}
...
```

UcanGetMsgPending

Syntax:

```
UCANRET PUBLIC UcanGetMsgPending (
    tUcanHandle          UcanHandle_p,
    BYTE                 bChannel_p,
    DWORD                dwFlags_p,
    DWORD*               pdwCount_p);
```

Usability:

CAN_INIT , version 3.06 and higher, only sysWORXX modules

Description:

This function returns the number of the CAN messages which are currently stored to the buffers within the several software parts. The parameter *dwFlags_p* specifies which buffers should be checked. Should the function check more than one buffer, then the number of CAN messages will be added before writing to the variable which is referenced by the parameter *pdwCount_p*.

Parameter:

<i>UcanHandle_p</i> :	USB CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p</i> :	CAN-channel to read data from USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>dwFlags_p</i> :	Specifies which buffers should be checked (<i>refer to Table 17</i>). The several flags can be combined. In that case the number of CAN messages will be added.
<i>pdwCount_p</i> :	Address to a variable. After calling this function writes the number of CAN messages stored to the specified buffer(s) to this variable. This parameter must not be NULL.

Constant USBCAN_PENDING...	Value	Meaning
..._FLAG_RX_DLL	0x00000001	Checks the number of messages of receive buffer within USBCAN-library.
..._FLAG_RX_FW	0x00000004	Checks the number of messages of receive buffer within module firmware.
..._FLAG_TX_DLL	0x00000010	Checks the number of messages of transmit buffer within USBCAN-library
..._FLAG_TX_FW	0x00000040	Checks the number of messages of transmit buffer within module firmware.

Table 17: Constants for the flags parameter in function *UcanGetMsgPending()*

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLHWTYPE
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_CANNOTINIT
USBCAN_ERRCMD_...

Note:

After function *UcanGetMsgPending()* returned to the application, the number of the CAN messages can already be changed within the several software parts. When the application calls this function too often, the performance can spiral downward.

UcanGetCanErrorCounter**Syntax:**

```
UCANRET PUBLIC UcanGetCanErrorCounter (
    tUcanHandle      UcanHandle_p,
    BYTE             bChannel_p,
    DWORD *          pdwTxCount_p,
    DWORD*           pdwRxCount_p);
```

Usability:

CAN_INIT , version 3.06 and higher, only sysWORXX modules

Description:

Returns the current error counters from CAN controller. This values are directly read from the hardware.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p:</i>	CAN-channel to read data from USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pdwTxCount_p:</i>	Address to a DWORD variable. After calling this function writes the current state of the transmit error counter to this variable. This parameter must not be NULL.
<i>pdwRxCount_p:</i>	Address to a DWORD variable. After calling this function writes the current state of the receive error counter to this variable. This parameter must not be NULL.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLHWTYPE
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_CANNOTINIT
USBCAN_ERRCMD_...
```

2.3.2.2 Functions for automatic transmission

The following functions can only be used for the new sysWORXX modules (not for GW-001 and GW-002). They are used to automatic transmission of cyclic CAN messages by the module firmware. This results a better cycle time as a Windows PC application could realize.

Note:

The accuracy of the cycle time also depends on the configured CAN baud rate. A jitter of 10 milliseconds is a result of using a CAN baud rate of 10 kbit per sec.

There is a maximum of 16 CAN messages which can be defined for the automatic transmission of cyclic CAN messages. Two modes are available for the automatic transmission. The first mode is called "parallel mode" the second one is called "sequential mode".

In parallel mode the cycle times of all defined CAN messages are checked within a process cycle. When a cycle time of a defined CAN message is over it will be sent to the CAN bus. The cycle time of a defined CAN message relates to the previous transmission of the same CAN message (refer to Figure 19).




Figure 19: Example for parallel mode with two defined CAN messages

In sequential mode the defined CAN messages are considered as a list of CAN messages which should be sent sequentially to the CAN bus. The cycle time of a defined CAN message relates to the transmission of the previously defined CAN message (refer to Figure 20). You can define a CAN message including the same CAN identifier but different data bytes more than once in sequential mode.




Figure 20: Example of sequential mode with two defined CAN messages

Important:

The transmission of CAN messages by calling the function *UcanWriteCanMsg()* or *UcanWriteCanMsgEx()* can be influenced by the automatic transmission of cyclic CAN messages. When the CAN bus load is much increased (50% and more) the CAN messages from application are processed more rarely. The result can be that the function *UcanWriteCanMsg()* or *UcanWriteCanMsgEx()* returns the warning indicating a receive overrun.

UcanDefineCyclicCanMsg

Syntax:

```
UCANRET PUBLIC UcanDefineCyclicCanMsg (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bChannel_p,  
    tCanMsgStruct*       pCanMsgList_p,  
    DWORD                dwCount_p);
```

Usability:

HW_INIT, CAN_INIT, version 3.06 and higher, only sysWORXX modules

Description:

The function defines a set of up to 16 CAN messages within firmware of an USB-CANmodul for the automatic transmission of cyclic CAN messages. Call function *UcanEnableCyclicCanMsg()* for enabling the automatic transmission. Please note that *UcanDefineCyclicCanMsg()* completely exchanges a previously defined set of CAN messages.

Parameter:

<i>UcanHandle_p</i> :	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p</i> :	CAN-channel to transmit to USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pCanMsgList_p</i> :	Address to an array of type <i>tCanMsgStruct</i> containing a set of CAN messages for automatic transmission. The member <i>m_dwTime</i> of the structure <i>tCanMsgStruct</i> specifies the cycle time. This parameter may only be NULL when <i>dwCount_p</i> is zero too.
<i>dwCount_p</i> :	Specifies the number of CAN messages included within the array. The value range is 0 to 16. A previously defined set of CAN messages will only be deleted by specifying the number of 0 CAN messages.

Refer to the function *UcanWriteCanMsg()* for the definition of the structure *tCanMsgStruct*.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLHWTYPE  
USBCAN_ERR_ILLCHANNEL  
USBCAN_ERRCMD_...
```

UcanReadCyclicCanMsg

Syntax:

```
UCANRET PUBLIC UcanReadCyclicCanMsg (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bChannel_p,  
    tCanMsgStruct*       pCanMsgList_p,  
    DWORD*               pdwCount_p);
```

Usability:

HW_INIT, CAN_INIT, version 3.06 and higher, only sysWORXX modules

Description:

The function reads back the set of CAN messages which was previously defined for automatic transmission of cyclic CAN messages.

Parameter:

<i>UcanHandle_p</i> :	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p</i> :	CAN-channel to transmit to USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pCanMsgList_p</i> :	Address to an array of type <i>tCanMsgStruct</i> receiving the set of CAN messages for automatic transmission. This parameter must not be NULL.
<i>pdwCount_p</i> :	Address to a variable of type DWORD where the function should copy to the number of defined CAN messages within the set.

Refer to the function *UcanWriteCanMsg()* for the definition of the structure *tCanMsgStruct*.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLHWTYPE  
USBCAN_ERR_ILLCHANNEL  
USBCAN_ERRCMD_...
```

UcanEnableCyclicCanMsg**Syntax:**

```
UCANRET PUBLIC UcanEnableCyclicCanMsg (  
    tUcanHandle      UcanHandle_p,  
    BYTE             bChannel_p,  
    DWORD            dwFlags_p);
```

Usability:

HW_INIT, CAN_INIT, version 3.06 and higher, only sysWORXX modules

Description:

This function specifies the mode of the automatic transmission and specifies whether the automatic transmission of a previous defined set of defined CAN messages should be enabled or disabled. Additionally separate CAN messages of the set can be locked or unlocked.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p:</i>	CAN-channel USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>dwFlags_p:</i>	Specifies flags containing the mode, the enable state and the locking state (refer to Table 18). These flags can be combined.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLHWTYPE  
USBCAN_ERR_ILLCHANNEL  
USBCAN_ERR_CANNOTINIT  
USBCAN_ERRCMD_...
```

Constant USBCAN_CYCLE...	Value	Meaning
..._FLAG_START	0x80000000	When this flag is set, the automatic transmission will be started, otherwise it will be stopped.
..._FLAG_SEQUMODE	0x40000000	When this flag is set, the “sequential mode” is processed, otherwise the “parallel mode” is processed.
..._FLAG_NOECHO	0x00010000	When this flag is set, the sent cyclic CAN messages are not received back using transmit echo.
..._FLAG_LOCK_0 until ..._FLAG_LOCK_15	0x00000001 - 0x00008000	When same of these flags are set, the appropriate CAN message from the set is not sent to the CAN bus (locked state).

Table 18: Constants for the flags parameter in function *UcanEnableCyclicCanMsg()*

2.3.2.3 Functions for the CAN Port

The following functions can only be used with the GW-002-XXX, Multiport CAN-to-USB and USB-CANmodul2 (not applicable for GW-001). They are an expansion for using the USB-CANmodul with a low-speed CAN transceiver (e.g.: GW-002-010, GW-002-020, GW-002-030). If these functions are used with the GW-001 variant, then the error code **USBCAN_ERRCMD_ILLCMD** will be returned. Use of these functions with the GW-002 (82C251 high-speed CAN transceiver) or USB-CANmodul1 has no effect. However no error message will be returned either. In order to be able to use these functions, the header file USBCANLS.H must be included in addition to the USBCAN32.H header file.

UcanWriteCanPort

Syntax:

```
UCANRET PUBLIC UcanWriteCanPort (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bValue_p);
```

Usability:

HW_INIT, CAN_INIT, version 2.15 or higher

Description:

Writes a value to the CAN port interface. Thus additional signals such as Standby (STB) and Enable (EN) on a low-speed CAN transceiver can be controlled.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

bOutValue_p: New output value for the CAN port interface (see Table 19).

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...

Note:

Following initialization of the USB-CANmodul with the function *UcanInitCan()*, these signals are already set for immediate operation of the USB-CANmodul.

Since software version 3.00, the last saved output values are restored after power-on on the sysWORXX modules.

UcanWriteCanPortEx**Syntax:**

```
UCANRET PUBLIC UcanWriteCanPortEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bChannel_p,  
    BYTE                 bOutValue_p);
```

Usability:

HW_INIT, CAN_INIT , version 3.00 and higher

Description:

Writes a value to the CAN port interface. Thus additional signals such as Standby (STB) and Enable (EN) on a low-speed CAN transceiver can be controlled. This function may be used alternatively for function *UcanWriteCanPort()*.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p:</i>	CAN-channel to read data from USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>bOutValue_p:</i>	New output value for the CAN port interface (see Table 19).

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERR_ILLHW  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERR_TIMEOUT  
USBCAN_ERRCMD_...
```

UcanReadCanPort**Syntax:**

```
UCANRET PUBLIC UcanReadCanPort (
    tUcanHandle          UcanHandle_p,
    BYTE*                pbValue_p);
```

Usability:

HW_INIT, CAN_INIT, version 2.15 or higher

Description:

Reads the current input value from the CAN port interface. Thus the additional signal (ERR for error) can be read on a low-speed CAN transceiver. It is also possible to read the state/constant for the terminating resistor on devices with high-speed transceivers (currently only supported for USB-CANmodul2).

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

pbInValue_p: Address pointing to a variable that contains the read input value following the successful return of this function. This variable then has the following meanings (see also section 1.4):

Constant	Bit value	Description
UCAN_CANPORT_TRM	0x10	[IN] termination resistor
UCAN_CANPORT_ERR	0x20	[IN] error signal of low speed CAN transceiver
UCAN_CANPORT_STB	0x40	[OUT] stand-by signal of low speed CAN transceiver
UCAN_CANPORT_EN	0x80	[OUT] enable signal of low speed CAN transceiver

Table 19: Constants for low speed CAN portReturn value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLPARAM
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...

UcanReadCanPortEx

Syntax:

```
UCANRET PUBLIC UcanReadCanPortEx (
    tUcanHandle          UcanHandle_p,
    BYTE                 bChannel_p
    BYTE*                pbInValue_p,
    BYTE*                pbLastOut_p);
```

Usability:

HW_INIT, CAN_INIT , version 3.00 or higher

Description:

Reads the current input value from the specified CAN-channel. This function may be used alternatively for function *UcanReadCanPort()*.

Parameter:

<i>UcanHandle_p:</i>	USB CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bChannel_p:</i>	CAN-channel to read data from USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pbInValue_p:</i>	Address pointing to a variable that contains the read input value following the successful return of this function (see <i>Table 19</i>).
<i>pbLastOut_p:</i>	Address pointing to a variable that contains the last written output value (using <i>UcanWriteCanPort()</i> or <i>UcanWriteCanPortEx()</i>) following the successful return of this function. This parameter may be NULL.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLPARAM
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...
```

2.3.2.4 Functions for the Expansion Port

The following functions can only be used with the GW-002-XXX, Multiport CAN-to-USB 3004006 and USB-CANmodul2 3204002/3204003. They are an expansion for the use of the USB-CANmodul with the expansion port. If these functions are used with the GW-001, then the error code **USBCAN_ERRCMD_ILLCMD** will be returned. In order to use these functions, the file USBCANUP.H must be included in addition to the USBCAN32.H header file.

Note:

These functions are also applicable to for USB-CANmodul1. But as the USB-CANmodul1 does not feature an Expansion Port, these functions are ignored and the functions return with error code USBCAN_SUCCESSFUL.

UcanConfigUserPort

Syntax:

```
UCANRET PUBLIC UcanConfigUserPort (  
    tUcanHandle          UcanHandle_p,  
    BYTE                 bOutEn_p);
```

Usability:

HW_INIT, CAN_INIT, version 2.16 or higher

Description:

Configures the expansion port (*refer to section 1.5*). Each individual pin of the 8-bit port can be used as an input or an output. The logical value 0 of a bit in the parameter *bOutputEnable_p* defines the corresponding pin on the expansion port to function as an input and a logical 1 defines it as an output.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>bOutEn_p:</i>	Configuring the 8-bit port as input or output. Bit X = 0: Pin X = input Bit Y = 1: PinY = output

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERR_ILLHW  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERR_TIMEOUT  
USBCAN_ERRCMD_...
```

Note:

After connecting the USB-CANmodul to the PC all expansion port pins are configured as inputs.
Since software version 3.00, the last saved configuration is restored after power-on on sys WORXX modules.

UcanWriteUserPort

Syntax:

```
UCANRET PUBLIC UcanWriteUserPort (
    tUcanHandle          UcanHandle_p,
    BYTE                 bOutValue_p);
```

Usability:

HW_INIT, CAN_INIT, version 2.16 or higher

Description:

Writes a value to the expansion port. In order to write to output lines, the corresponding bits resp. port pins must be configured as outputs using the *UcanConfigUserPort()* function.

Parameter:

UcanHandle_p: USB-CAN handle received with the function *UcanInitHardware()* or *UcanInitHardwareEx()*.

bOutValue_p: New output value for the expansion port outputs. Each bit in this parameter corresponds to matching pin on the expansion port.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...
```

Note:

For GW-002 the supply voltage for the expansion port (pin 10, *refer to Table 6*) is connected only after the function *UcanInitCan()* is called. After the USB-CANmodul has been connected to the PC, all expansion port pins are configured as inputs. No time critical switching procedures can be performed with this function using the expansion port, since the reaction time is influenced by multiple factors.

Since software version 3.00, the last saved configuration of the outputs is restored after power-on on sysWORXX modules.

UcanReadUserPort

Syntax:

```
UCANRET PUBLIC UcanReadUserPort (  
    tUcanHandle          UcanHandle_p,  
    BYTE*                pbInValue_p);
```

Usability:

HW_INIT, CAN_INIT, version 2.16 or higher

Description:

Reads the current input value from the expansion port.

Parameter:

<i>UcanHandle_p:</i>	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>pbInValue_p:</i>	Address pointing to a variable that contains the read input value following the successful return of this function. This variable then contains the state of the 8-bit expansion port. Each bit in this parameter corresponds to matching pin on the expansion port.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERR_TIMEOUT  
USBCAN_ERRCMD_...
```

Note:

After the USB-CANmodul has been connected to the PC, all expansion port pins are configured as inputs (except sysWORXX modules, see above). This function can also be used to read back the states of ports configured as outputs.

UcanReadUserPortEx

Syntax:

```
UCANRET PUBLIC UcanReadUserPortEx (  
    tUcanHandle          UcanHandle_p,  
    BYTE*                pbInValue_p,  
    BYTE*                pbLastOutEn_p,  
    BYTE*                pbLastOutVal_p);
```

Usability:

HW_INIT, CAN_INIT , version 3.00 and higher

Description:

Reads the current input value from the expansion port. This function may be used alternatively for function *UcanReadUserPort()*.

Parameter:

<i>UcanHandle_p</i> :	USB-CAN handle received with the function <i>UcanInitHardware()</i> or <i>UcanInitHardwareEx()</i> .
<i>pbInValue_p</i> :	Address pointing to a variable that contains the read input value following the successful return of this function. This variable then contains the state of the 8-bit expansion port. Each bit in this parameter corresponds to matching pin on the expansion port.
<i>pbLastOutEn_p</i> :	Address pointing to a variable that contains the configuration data following the successful return of this function (configuration that was previously done with <i>UcanConfigUserPort()</i>). This parameter may be NULL.
<i>pbLastOutVal_p</i> :	Address pointing to a variable that contains the last output value following the successful return of this function. (output value that was written with <i>UcanWriteUserPort()</i>). This parameter may be NULL.

Return value: Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERR_ILLHW  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_DATA  
USBCAN_ERR_ABORT  
USBCAN_ERR_DISCONNECT  
USBCAN_ERR_TIMEOUT  
USBCAN_ERRCMD_...
```

2.3.3 Error Codes of the Functions

The functions of the USBCAN-library return an error code with the type of UCANRET. Each return value represents an error. The only exception is the function *UcanReadCanMsg()* which can also return warnings. The warning *USBCAN_WARN_NODATA* indicates that no CAN messages are in the buffer. Other warnings show the calling function that an event has occurred but a valid CAN message is transferred.

All possible return codes for the functions of the USBCAN-library are listed below:

USBCAN_SUCCESSFUL

Value: 0x00

Description:

This message returns if the function is executed successfully.

USBCAN_ERR_RESOURCE

Value: 0x01

Description:

This error message returns if one resource could not be generated. In this case the term resource means memory and handles provided by Windows.

USBCAN_ERR_MAXMODULES

Value: 0x02

Description:

An application has tried to open more than 64 USB-CANmoduls. The standard version of the USBCAN-library only supports up to 64 USB-CANmoduls at the same time (under Windows CE only 9). This error also appears if several applications try to access more than 64 USB-CANmoduls. For example, application 1 has opened 60 modules, application 2 has opened 4 modules and application 3 wants to open a module. Application 3 receives this error message.

USBCAN_ERR_HWINUSE

Value: 0x03

Description:

An application tries to initialize an USB-CANmodul with the device number x. If this module has already been initialized by its own or by another application, this error message is returned.

USBCAN_ERR_ILLVERSION

Value: 0x04

Description:

This error message returns if the firmware version of the USB-CANmodul is not compatible to the software version of the USBCAN-library. In this case, install the USB-CAN driver again.

USBCAN_ERR_ILLHW

Value: 0x05

Description:

This error message returns if an USB-CANmodul with the device number x is not found. If the function *UcanInitHardware()* or *UcanInitHardwareEx()* has been called with the device number *USBCAN_ANY_MODULE*, and the error code appears, it indicates that no module is connected to the PC or all connected modules are already in use.

USBCAN_ERR_ILLHANDLE

Value: 0x06

Description:

This error message returns if a function received an incorrect USB-CAN handle. The function first checks which USB-CANmodul is initialized to this handle. This error occurs if no module has been initialized to this handle.

USBCAN_ERR_ILLPARAM

Value: 0x07

Description:

This error message returns if a wrong parameter is transferred to this function. For example, the value NULL has been handed over to a pointer variable instead of a valid address.

USBCAN_ERR_BUSY

Value: 0x08

Description:

This error message can occur if several threads are accessing an USB-CANmodul within a single application. After the other threads have finished their tasks, the function may be called again.

USBCAN_ERR_TIMEOUT

Value: 0x09

Description:

This error message occurs if the function transmits a command to the USB-CANmodul but no answer is returned. To solve this problem, close the application, disconnect the USB-CANmodul, and connect it again.

USBCAN_ERR_IOFAILED

Value: 0x0A

Description:

This error message occurs if the communication to the USB-CAN driver was interrupted. This happens, for example, if the USB-CANmodul is disconnected during the execution of a function.

USBCAN_ERR_DLL_TXFULL

Value: 0x0B

Description:

The function *UcanWriteCanMsg()* or *UcanWriteCanMsgEx()* first checks if the transmit buffer within the USBCAN-library has enough capacity to store new CAN messages. If the buffer is full, this error message returns. The CAN message transferred to the function *UcanWriteCanMsg()* or *UcanWriteCanMsgEx()* will not be written into the transmission buffer in order to protect other CAN messages from overwriting. Since software driver version 3.05 the size of the transmit buffer is configurable (see function *UcanInitCanEx()* and Struktur *tUcanInitCanParam*)

USBCAN_ERR_MAXINSTANCES

Value: 0x0C

Description:

In this software version, a maximum amount of 64 applications are able to have access to the USBCAN-library (under Windows CE only 9). If more applications attempt access to the DLL, this error message will occur. In this case, it is not possible to initialize an USB-CANmodul.

USBCAN_ERR_CANNOTINIT

Value: 0x0D

Description:

If an USB-CANmodul is initialized with the function *UcanInitHardware()* or *UcanInitHardwareEx()*, the software changes into the state HW_INIT. Functions like *UcanReadCanMsg()* or *UcanWriteCanMsg()* return this error message while in HW_INIT state. With the function *UcanInitCan()*, the software changes into CAN_INIT state. In this state, it is possible to read and transmit CAN messages.

USBCAN_ERR_DISCONNECT

Value: 0x0E

Description:

This error code occurs if a function from USBCAN-library was called for an USB-CANmodul that was plugged-off from the computer recently.

USBCAN_ERR_NOHWCLASS

Value: 0x0F

Description:

This error code is deprecated and is not used any more.

USBCAN_ERR_ILLCHANNEL

Value: 0x10

Description:

This error code is returned if an extended function of the USBCAN-library was called with parameter `bChannel_p = USBCAN_CHANNEL_CH1`, but USB-CANmodul GW-001, GW-002 or USB-CANmodul1 was used.

USBCAN_ERR_ILLHWTYPE

Value: 0x12

Description:

This error code occurs if an extended function of the USBCAN-library was called for a Hardware which does not support the feature.

USBCAN_ERRCMD_NOTEQU

Value: 0x40

Description:

This error code occurs during communication between the PC and an USB-CANmodul. The PC sends a command to the USB-CANmodul, then the module executes the command and returns a response to the PC. This error message returns if the answer does not correspond to the command.

USBCAN_ERRCMD_REGTST

Value: 0x41

Description:

The software tests the CAN controller on the USB-CANmodul when the CAN interface is initialized. Several registers of the CAN controller are checked. This error message returns if an error appears during this register test.

USBCAN_ERRCMD_ILLCMD

Value: 0x42

Description:

This error message returns if the USB-CANmodul receives a non-defined command. This error shows a version conflict between the firmware in the USB-CANmodul and the USBCAN-library.

USBCAN_ERRCMD_EEPROM

Value: 0x43

Description:

The USB-CANmodul has a serial EEPROM. This EEPROM contains the device number and the serial number. If an error occurs while reading these values, this error message is returned.

USBCAN_ERRCMD_ILLBDR

Value: 0x47

Description:

The Multiport CAN-to-USB 3004006, USB-CANmodul1 3204000/3204001 or USB-CANmodul2 3204002/3204003 has been initialized with an invalid baud rate (BTR0 und BTR1).

USBCAN_ERRCMD_NOTINIT

Value: 0x48

Description:

It was tried to access a CAN-channel of Multiport CAN-to-USB 3004006 or USB-CANmodul2 3204002/3204003 that was not initialized.

USBCAN_ERRCMD_ALREADYINIT

Value: 0x49

Description:

The accessed CAN-channel of Multiport CAN-to-USB 3004006 or USB-CANmodul2 3204002/3204003 was already initialized.

USBCAN_ERRCMD_ILLSUBCMD

Value: 0x4A

Description:

An internal error occurred in USBCAN Library. In this case an unknown sub-command was called instead of a main command (e.g. for the cyclic CAN message-feature).

USBCAN_ERRCMD_ILLIDX

Value: 0x4B

Description:

An internal error occurred in USBCAN Library. In this case an invalid index for a list was delivered to the firmware (e.g. for the cyclic CAN message-feature).

USBCAN_ERRCMD_RUNNING

Value: 0x4C

Description:

The caller tries to define a new list of cyclic CAN messages but this feature was already started. For defining a new list, it is necessary to switch off the feature beforehand.

USBCAN_WARN_NODATA

Value: 0x80

Description:

If the function *UcanReadCanMsg()* returns with this warning, it is an indication that the receive buffer contains no CAN messages.

USBCAN_WARN_SYS_RXOVERRUN

Value: 0x81

Description:

If an overrun in the receive buffer on the USB-CAN system driver occurred, the USBCAN-library is informed about this event. The function *UcanReadCanMsg()* returns this warning and a valid CAN message. The warning indicates that CAN messages are lost. However, it does not indicate the position of the lost CAN messages.

USBCAN_WARN_DLL_RXOVERRUN

Value: 0x82

Description:

The USBCAN-library automatically requests CAN messages from the USB-CANmodul and stores the messages into a buffer of the DLL. If more CAN messages are received than the DLL buffer size allows, this error message returns and CAN messages are lost. However, it does not indicate the position of the lost CAN messages.

Since software driver version 3.05 the size of the receive buffer is configurable (see function *UcanInitCanEx()* and structure *tUcanInitCanParam*)

USBCAN_WARN_FW_TXOVERRUN

Value: 0x85

Description:

This warning is returned by function *UcanWriteCanMsg()* and/or *UcanWriteCanMsgEx()* if flag USBCAN_CANERR_QXMTFULL is set in the CAN driver status. However, the transmit CAN message could be stored to the DLL transmit buffer. This warning indicates that at least one transmit CAN message got lost in the device firmware layer. This warning does not indicate the position of the lost CAN message.

USBCAN_WARN_FW_RXOVERRUN

Value: 0x86

Description:

This warning is returned by function *UcanWriteCanMsg()* and/or *UcanWriteCanMsgEx()* if flag USBCAN_CANERR_QOVERRUN or flag USBCAN_CANERR_OVERRUN are set in the CAN driver status. The function has returned with a valid CAN message. This warning indicates that at least one received CAN message got lost in the firmware layer. This warning does not indicate the position of the lost CAN message.

USBCAN_WARN_NULL_PTR

Value: 0x90

Description:

This warning message is returned by functions: *UcanInitHwConnectControl()* and/or *UcanInitHwConnectControlEx()* if a NULL pointer was passed as callback function address.

USBCAN_WARN_TXLIMIT

Value: 0x91

Description:

This warning message is returned by the function *UcanWriteCanMsgEx()* if it was called to transmit more than one CAN message, but a part of them could not be stored to the transmit buffer within USBCAN-library (because the buffer is full). The parameter *pdwCount_p* includes the number of CAN messages which could be stored successfully to the transmit buffer.

2.3.4 Baud Rate Configuration

2.3.4.1 Baud Rate Configuration for GW-001 and GW-002

The baud rate configuration for USB-CANmodul GW-001 and GW-002 is transferred to the function *UcanInitCan()* and *UcanInitCanEx2()* as parameter *bBTR0_p* and *bBTR1_p*. The configuration can also be changed later by calling the function *UcanSetBaudrate()* resp. *UcanSetBaudrateEx()*. The following values are recommended:

<i>USBCAN_BAUD_10kBit:</i>	0x672f	// CAN baud rate 10 kBit/sec
<i>USBCAN_BAUD_20kBit:</i>	0x532f	// CAN baud rate 20 kBit/sec
<i>USBCAN_BAUD_50kBit:</i>	0x472f	// CAN baud rate 50 kBit/sec
<i>USBCAN_BAUD_100kBit:</i>	0x432f	// CAN baud rate 100 kBit/sec
<i>USBCAN_BAUD_125kBit:</i>	0x031c	// CAN baud rate 125 kBit/sec
<i>USBCAN_BAUD_250kBit:</i>	0x011c	// CAN baud rate 250 kBit/sec
<i>USBCAN_BAUD_500kBit:</i>	0x001c	// CAN baud rate 500 kBit/sec
<i>USBCAN_BAUD_800kBit:</i>	0x0016	// CAN baud rate 800 kBit/sec
<i>USBCAN_BAUD_1MBit:</i>	0x0014	// CAN baud rate 1 MBit/sec

Example:

```
tUcanHandle UcanHandle;
UCANRET bRet;

...
// initializes the hardware
bRet = UcanInitHardware (&UcanHandle, 0, NULL);
...

// initializes the CAN interface
bRet = UcanInitCan (UcanHandle,
    HIBYTE (USBCAN_BAUD_1MBit), // BTR0 for 1MBit/s
    LOBYTE (USBCAN_BAUD_1MBit), // BTR1 for 1MBit/s
    0xFFFFFFFF,                // AMR: all messages received
    0x00000000);                // ACR

// Error? print error
if (bRet != USBCAN_SUCCESSFUL)
    PrintError (bRet);
...
```

Configuration of other baud rates is also possible. The structure of the BTR0 and BTR1 registers is described below. Refer to the SJA1000 Data Sheet for detailed description.


Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
SJW		BPR					

Figure 21: Structure of baud rate register BTR0

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
SAM	TSEG2			TSEG1			

Figure 22: Structure of baud rate register BTR1

- BPR:** *Baudrate Prescaler* specifies the ratio between system clock of the SJA1000 and the bus clock on the CAN-bus.
- SJW:** *Synchronization Jump Width* specifies the compensation of the phase-shift between the system clock and the different CAN-controllers connected to the CAN-bus.
- SAM:** *Sampling* specifies the number of sample points used for reading the bits on the CAN-bus. If SAM=1 three sample points are used, otherwise only one sample point is used.
- TSEG:** *Time Segment* specifies the number of clock cycles of one bit on the CAN-bus as well as the position of the sample points.



Possible values are BRP = 000001, TSEG1 = 0101 and TSEG2 = 010.

Figure 23: General structure of a single bit on the CAN-bus

(source: SJA1000 manual)

The following mathematical connections apply:

$$\begin{aligned}
 t_{CLK} &= 1 / 16\text{MHz} && \text{(system clock)} \\
 t_{scl} &= 2 * t_{CLK} * (BRP + 1) && \text{(bus clock)} \\
 t_{SYNCSEG} &= 1 * t_{scl} \\
 t_{TSEG1} &= t_{scl} * (TSEG1 + 1) \\
 t_{TSEG2} &= t_{scl} * (TSEG2 + 1) \\
 t_{Bit} &= t_{SYNCSEG} + t_{TSEG1} + t_{TSEG2} && \text{(time of one Bit on the CAN-bus)}
 \end{aligned}$$

Example for 125 kBit/s (TSEG1 = 1, TSEG2 = 12, BPR = 3):

t_{scl}	=	$2 * t_{CLK} * 4$	= 500 ns
$t_{SYNCSEG}$	=	$1 * t_{scl}$	= 500 ns
t_{TSEG1}	=	$t_{scl} * 2$	= 1000 ns
t_{TSEG2}	=	$t_{scl} * 13$	= 6500 ns
t_{Bit}	=	$t_{SYNCSEG} + t_{TSEG1} + t_{TSEG2}$	= 8000 ns
$1 / t_{Bit}$	=	125 kBit/sec	

2.3.4.2 Baud Rate Configuration for sysWORXX Modules

Note:

The configuration of the baud rate differs significantly between the older USB-CANmodul versions (GW-001 and GW-002) and the new sysWORXX modules. For standardized baud rate values (see section 2.3.4), the baud rate registers BTR0 and BTR1 are as well applicable for the new sysWORXX modules. Therefore set *m_dwBaudrate* to USBCAN_BAUDEX_USE_BTR01.

The following default values are available for sysWORXX modules:

USBCAN_BAUDEX_1MBit	0x00020354	// CAN baud rate 1 MBit/sec
USBCAN_BAUDEX_800kBit	0x00030254	// CAN baud rate 800 kBit/sec
USBCAN_BAUDEX_500kBit	0x00050354	// CAN baud rate 500 kBit/sec
USBCAN_BAUDEX_250kBit	0x000B0354	// CAN baud rate 250 kBit/sec
USBCAN_BAUDEX_125kBit	0x00170354	// CAN baud rate 125 kBit/sec
USBCAN_BAUDEX_100kBit	0x00171466	// CAN baud rate 100 kBit/sec
USBCAN_BAUDEX_50kBit	0x002F1466	// CAN baud rate 50 kBit/sec
USBCAN_BAUDEX_20kBit	0x00771466	// CAN baud rate 20 kBit/sec
USBCAN_BAUDEX_10kBit	0x80771466	// CAN-baud rate 10 kBit/sec

The following values have a sample point between 85 and 90%:

USBCAN_BAUDEX_SP2_1MBit	0x00020741	// CAN-Baudrate 1 MBit/sec
USBCAN_BAUDEX_SP2_800kBit	0x00030731	// CAN-Baudrate 800 kBit/sec
USBCAN_BAUDEX_SP2_500kBit	0x00050741	// CAN-Baudrate 500 kBit/sec
USBCAN_BAUDEX_SP2_250kBit	0x000B0741	// CAN-Baudrate 250 kBit/sec
USBCAN_BAUDEX_SP2_125kBit	0x00170741	// CAN-Baudrate 125 kBit/sec
USBCAN_BAUDEX_SP2_100kBit	0x001D1741	// CAN-Baudrate 100 kBit/sec
USBCAN_BAUDEX_SP2_50kBit	0x003B1741	// CAN-Baudrate 50 kBit/sec
USBCAN_BAUDEX_SP2_20kBit	0x00771772	// CAN-Baudrate 20 kBit/sec
USBCAN_BAUDEX_SP2_10kBit	0x80771772	// CAN-Baudrate 10 kBit/sec

Configuration of baud rates other than the values given above is possible. The register structure for extended baud rate configuration is given below.

Bit 31	30	29	28	27	26	25	24
CLK	-						SMP
23	22	21	20	19	18	17	16
-	BPR						
15	14	13	12	11	10	9	8
-		SYNC			-	PROPAG	
7	6	5	4	3	2	1	Bit 0
-	PHASE1			-	PHASE2		

Figure 24: Format of the extended baud rate register for sysWORXX-Modules

- BPR:** *Baudrate Prescaler* specifies the ration between system clock of the microcontroller and the bus clock on CAN-bus.
- SYNC:** *Synchronization Jump Width* specifies the compensation of phase shift between the system clock and the different CAN controllers connected to the CAN-bus.
- SAM:** *Sampling* specifies the number of sample points used for reading the bits on the CAN-bus. If SAM=1 three sample points are used, otherwise only one sample point is used.
- PROPAG:** *Programming Time Segment* specifies the compensation of the physical delay time on the CAN-bus.
- PHASE:** *Time Segment* specifies the number of clock cycles of one bit on the CAN-bus as well as the position of the sample points.
- CLK:** *Clock* specifies the frequency of the microcontroller. If set to 0, then the microcontroller runs with 48 MHz clock cycle internally, otherwise with 24 MHz. This influences the CAN-bus baud rate (see system clock t_{MCK} in the example below)




Figure 25: Generic structure of one bit on the CAN-bus

(source: Atmel AT91SAM7A3 manual)

The following mathematical connections apply:

t_{MCK0}	$= 1 / 48\text{MHz}$	(system clock CLK=0)
t_{MCK1}	$= 1 / 24\text{MHz}$	(system clock CLK=1)
t_{CSC}	$= t_{MCKx} * (BRP + 1)$	(bus clock)
$t_{SYNCSEG}$	$= 1 * t_{CSC}$	
t_{PRS}	$= t_{CSC} * (PROPAG + 1)$	
t_{PHS1}	$= t_{CSC} * (PHASE1 + 1)$	
t_{PHS2}	$= t_{CSC} * (PHASE2 + 1)$	
t_{Bit}	$= t_{SYNCSEG} + t_{PRS} + t_{PHS1} + t_{PHS2}$	(time of one bit on CAN-bus)

Example for 125 kBit/s (PROPAG = 3, PHASE1 = 5, PHASE2 = 4, BPR = 23, CLK=0):

t_{CSC}	$= t_{MCK0} * 24$	$= 500 \text{ ns}$
$t_{SYNCSEG}$	$= 1 * t_{scl}$	$= 500 \text{ ns}$
t_{PRS}	$= t_{CSC} * 4$	$= 2000 \text{ ns}$
t_{PHS1}	$= t_{CSC} * 6$	$= 3000 \text{ ns}$
t_{PHS2}	$= t_{CSC} * 5$	$= 2500 \text{ ns}$
t_{Bit}	$= t_{SYNCSEG} + t_{PRS} + t_{PHS1} + t_{PHS2}$	$= 8000 \text{ ns}$
$1 / t_{Bit}$	$= 125 \text{ kBit/sec}$	

Note:

For compatibility reasons, constant USBCAN_BAUDEX_USE_BTR01 was defined. If this constant is used for baud rate configuration of sysWORXX modules, the BTR0 and BTR1 registers become available for configuration. In this case, only the baud rates given in this manual are available. Configuration of user-specific baud rates is not possible (error code USBCAN_ERRCMD_ILLBDR)

Example 1:

```

tUcanHandle UcanHandle;
UCANRET bRet;
tUcanInitCanParam InitParam;

...
// preset init parameters
memset (&InitParam, 0, sizeof (InitParam));
InitParam.m_dwSize      = sizeof (InitParam);
InitParam.m_bMode       = kUcanModeNormal;
InitParam.m_bBTR0       = HIBYTE (USBCAN_BAUD_1MBit);
InitParam.m_bBTR1       = LOBYTE (USBCAN_BAUD_1MBit);
InitParam.m_bOCR         = USBCAN_OCR_DEFAULT;
InitParam.m_dwAMR        = USBCAN_AMR_ALL;
InitParam.m_dwACR        = USBCAN_ACR_ALL;
InitParam.m_dwBaudrate   = USBCAN_BAUDEX_USE_BTR01;
InitParam.m_wNrOfRxBufferEntries = USBCAN_DEFAULT_BUFFER_ENTRIES;
InitParam.m_wNrOfTxBufferEntries = USBCAN_DEFAULT_BUFFER_ENTRIES;

// initialize CAN-channel
bRet = UcanInitCanEx2 (UcanHandle, USBCAN_CHANNEL_CH0,
    &InitParam);
...

```

Example 2: (will not work for GW-001 / GW-002):

```

tUcanHandle UcanHandle;
UCANRET bRet;
tUcanInitCanParam InitParam;

...
// preset init parameters
memset (&InitParam, 0, sizeof (InitParam));
InitParam.m_dwSize      = sizeof (InitParam);
InitParam.m_bMode       = kUcanModeNormal;
InitParam.m_bBTR0       = HIBYTE (USBCAN_BAUD_USE_BTREX);
InitParam.m_bBTR1       = LOBYTE (USBCAN_BAUD_USE_BTREX);
InitParam.m_bOCR         = USBCAN_OCR_DEFAULT;
InitParam.m_dwAMR        = USBCAN_AMR_ALL;
InitParam.m_dwACR        = USBCAN_ACR_ALL;
InitParam.m_dwBaudrate   = USBCAN_BAUDEX_SP2_125kBit;
InitParam.m_wNrOfRxBufferEntries = USBCAN_DEFAULT_BUFFER_ENTRIES;
InitParam.m_wNrOfTxBufferEntries = USBCAN_DEFAULT_BUFFER_ENTRIES;

// initialize CAN-channel
bRet = UcanInitCanEx2 (UcanHandle, USBCAN_CHANNEL_CH0,
    &InitParam);
...

```

2.3.4.3 Baud Rate Configuration for Fourth Generation - USB-CANmodul

As of driver-version V5.00 a new device-revision is supported „ Fourth Generation - USB-CANmodul“, ab rev. G4. Due to discontinue of components changes had to be executed for the setting of baud rates. However the software was altered in order the baud rates set above can still be used for the new device revision. Should other settings still become necessary these settings must be executed as follows:

Due to compatibility reasons the pre-defined values BTR0 and BTR1 from section 2.3.4.1 can still be used for fourth generation - USB-CANmoduls. If for BTR0 and BTR1 the value USBCAN_BAUD_USE_BTREX is being set, the pre-defined values of section 2.3.4.2 for the dwBaudrate can be used for fourth generation – USB-CANmoduls as well. However the correct pre-defined values for the fourth generation are as follows:

```
USBCAN_BAUDEX_G4_1MBit      0x40180001 // CAN-Baud rate 1 MBit/s
USBCAN_BAUDEX_G4_800kBit    0x401B0001 // CAN-Baud rate 800 kBit/s
USBCAN_BAUDEX_G4_500kBit    0x401C0002 // CAN-Baud rate 500 kBit/s
USBCAN_BAUDEX_G4_250kBit    0x401C0005 // CAN-Baud rate 250 kBit/s
USBCAN_BAUDEX_G4_125kBit    0x401C000B // CAN-Baud rate 125 kBit/s
USBCAN_BAUDEX_G4_100kBit    0x412F000B // CAN-Baud rate 100 kBit/s
USBCAN_BAUDEX_G4_50kBit     0x412F0017 // CAN-Baud rate 50 kBit/s
USBCAN_BAUDEX_G4_20kBit     0x412F003B // CAN-Baud rate 20 kBit/s
USBCAN_BAUDEX_G4_10kBit     0x412F0077 // CAN-Baud rate 10 kBit/s
```

These pre-defined values cannot be used for the older sysWORXX USB-CANmoduls

Other values as defined above can be set by the user (ref. section 2.3.4.4) Following the format of the increased baud rate register is explained.

Bit 31	30	29	28	27	26	25	24
0	1	-				SJW	
23	22	21	20	19	18	17	16
-	TS2			TS1			
15	14	13	12	11	10	9	8
-						BRP	
7	6	5	4	3	2	1	Bit 0
BRP							

Figure 26: Format of the increased baud rate register for fourth generation modules

BPR: *Baud rate Prescaler* defines the relation of parts between internal clock of the micro controller and the clock of the CAN-bus.

SJW: *Synchronization Jump Width* defines the compensation of the phase shift between the system clock and the different CAN-controllers plugged to the CAN-bus.

TS1/TS2: *Phase Segment* defines the number of clock cycles on the CAN-bus for one bit and the position of *Sample Points*.




Figure 27: Calculation of Bit-Timing for Fourth Generation Modules
 (Source: „RM0033, Reference Manual, STM32F205xx“)

Following mathematic correlations apply:

t_{PCLK}	$= 1 / 24\text{MHz}$	
t_q	$= t_{PCLK} \times (BRP + 1)$	(tact on CAN-Bus)
$t_{SYNCSEG}$	$= 1 \times t_q$	
t_{BS1}	$= t_q \times (TS1 + 1)$	
t_{BS2}	$= t_q \times (TS2 + 1)$	
t_{Bit}	$= t_{SYNCSEG} + t_{BS1} + t_{BS2}$	(Time for one bit on CAN-Bus)

Example for 125 kBit/s (TS1 = 15, TS2 = 6, BPR = 7):

t_q	$= t_{PCLK} \times 8$	$= 333,3 \text{ ns}$
$t_{SYNCSEG}$	$= 1 \times t_q$	$= 333,3 \text{ ns}$
t_{BS1}	$= t_q \times 16$	$= 5333,3 \text{ ns}$
t_{BS2}	$= t_q \times 7$	$= 2333,3 \text{ ns}$
t_{Bit}	$= t_{SYNCSEG} + t_{BS1} + t_{BS2}$	$= 8000 \text{ ns}$
$1 / t_{Bit}$	$= 125 \text{ kBit/s}$	

Example (will not function for older sysWORXX USB-CANmoduls as well as not for GW-001 and GW-002):

```
tUcanHandle UcanHandle;
UCANRET bRet;
tUcanInitCanParam InitParam;

...

// Initialisierungsparameter ausfüllen
memset (&InitParam, 0, sizeof (InitParam));
InitParam.m_dwSize      = sizeof (InitParam);
InitParam.m_bMode       = kUcanModeNormal;
InitParam.m_bBTR0       = HIBYTE (USBCAN_BAUD_USE_BTREX);
InitParam.m_bBTR1       = LOBYTE (USBCAN_BAUD_USE_BTREX);
InitParam.m_bOCR        = USBCAN_OCR_DEFAULT;
InitParam.m_dwAMR       = USBCAN_AMR_ALL;
InitParam.m_dwACR       = USBCAN_ACR_ALL;
InitParam.m_dwBaudrate  = USBCAN_BAUDEX_G4_250kBit;
InitParam.m_wNrOfRxBufferEntries = USBCAN_DEFAULT_BUFFER_ENTRIES;
InitParam.m_wNrOfTxBufferEntries = USBCAN_DEFAULT_BUFFER_ENTRIES;

// CAN-Kanal initialisieren
bRet = UcanInitCanEx2 (UcanHandle, USBCAN_CHANNEL_CH0,
    &InitParam);
...
```

2.3.4.4 Use of non-listed Bit-Rates

As the setting of the bit rate on the CAN-bus is done via index values, also other bit rates, not listed with above constants can be set. For defining these bit rates the above listed equations must be used. In *table 18* a selection of bit rates which have been occasionally requested is listed.

Bit Rate	GW-001 / GW-002	sysWORXX USB-CANmodul (G3)	sysWORXX USB-CANmodul (G4)
33,33 kBit/sec	bBTR0 = 0x6F bBTR1 = 0x09 dwBaudrate = 0x00000000	bBTR0 = 0x00 bBTR1 = 0x00 dwBaudrate = 0x003B0776	bBTR0 = 0x00 bBTR1 = 0x00 dwBaudrate = 0x412F0023
83,33 kBit/sec	bBTR0 = 0x6F bBTR1 = 0x03 dwBaudrate = 0x00000000	bBTR0 = 0x00 bBTR1 = 0x00 dwBaudrate = 0x00170776	bBTR0 = 0x00 bBTR1 = 0x00 dwBaudrate = 0x411E000F
307,69 kBit/sec	bBTR0 = 0x19 bBTR1 = 0x01 dwBaudrate = 0x00000000	bBTR0 = 0x00 bBTR1 = 0x00 dwBaudrate = 0x000B0450	bBTR0 = 0x00 bBTR1 = 0x00 dwBaudrate = 0x40190005
333,33 kBit/sec	bBTR0 = 0x6F bBTR1 = 0x00 dwBaudrate = 0x00000000	bBTR0 = 0x00 bBTR1 = 0x00 dwBaudrate = 0x00050776	bBTR0 = 0x00 bBTR1 = 0x00 dwBaudrate = 0x402D0003

Table 20: Examples for non-listed bit rates

2.3.5 CAN Messages Filter Function

It is possible to filter the received CAN messages. The SJA1000 CAN controller automatically filters messages in PeliCAN mode (Single-Filter-Mode).

The configurations of the filter are transferred to the function *UcanInitCan()* as parameter *dwAMR_p* and *dwACR_p*. It is also possible to change these values later after calling the function *UcanInitCan()* with the function *UcanSetAcceptance()*.


The following mechanism is used for filtration:

AMR Bit	ACR Bit	Bit of the CAN ID
0	0	0
0	1	1
1	0	x
1	1	x


- 0 The corresponding bit of the CAN identifier has to be 0.
 1 The corresponding bit of the CAN identifier has to be 1.
 x The corresponding bit of the CAN identifier can be either 0 or 1.

These bits correspond to:

- a) Standard frame (11-bit identifier) for GW-001/GW-002 as well as sysWORXX modules since firmware version 3.10:




- b) Extended frame (29-bit identifier) for GW-001/GW-002 as well as sysWORXX modules since firmware version 3.10:



- c) Standard-Frame (11-Bit-Identifier) for all sysWORXX modules until firmware version 3.09:



- d) Extended-Frame (29-Bit-Identifier) for all sysWORXX modules until firmware version 3.09:



The macros `USBCAN_SET_AMR(extended, can_id, rtr)` and `USBCAN_SET_AMR(extended, can_id, rtr)` as well as `USBCAN_CALCULATE_AMR(extended, from_id, to_id, rtr_only, rtr_too)` and `USBCAN_CALCULATE_ACR(extended, from_id, to_id, rtr_only, rtr_too)` can be used to calculate the filter values.

The parameter *extended* indicates if the parameters *can_id*, *from_id* and *to_id* specify a 29-bit message (TRUE) or an 11-bit message (FALSE). The parameter *can_id* shows the filter value as CAN identifier. The parameters *from_id* and *to_id* specify the filter range for CAN-identifiers. The parameters *rtr*, *rtr_only* and *rtr_too* can be used to filter RTR frames. These parameters can be TRUE (=1) or FALSE (=0). If the parameter *rtr_only* is TRUE, then only RTR Frames are received and parameter *rtr_too* is ignored. Otherwise also RTR Frames are received, if *rtr_too* is set to TRUE.

Example 1:

```
tUcanHandle UcanHandle;
UCANRET bRet;

...
// initializes the hardware
bRet = UcanInitHardware (&UcanHandle, 0, NULL);
...

// initializes the CAN interface
// filters 11-bit CAN messages with ID 0x300 to 0x3ff,
// RTR unimportant
bRet = UcanInitCan (UcanHandle,
    HIBYTE (USBCAN_BAUD_1MBit),
    LOBYTE (USBCAN_BAUD_1MBit),
    USBCAN_SET_AMR (FALSE, 0x0ff, 1),
    USBCAN_SET_ACR (FALSE, 0x300, 0));

// Error? print error
if (bRet != USBCAN_SUCCESSFUL)
    PrintError (bRet);
...
```

If, according to example 1, the CAN-controller receives a CAN-message with 29-bit identifier, then it is filtered with the same configuration. However, AMR and ACR are interpreted differently. Here, CAN-messages with 29-bit identifiers from 0x0C000000 to 0x0FFFFFFF are received too.

Example 2:

```
tUcanHandle UcanHandle;
UCANRET bRet;

...
// initializes the hardware
bRet = UcanInitHardware (&UcanHandle, 0, NULL);

// initializes the CAN-interface
// filters 11-bit CAN-messages with ID 0x600 to 0x67F,
// RTR-Frames unimportant
bRet = UcanInitCan (UcanHandle,
    HIBYTE (USBCAN_BAUD_1MBit),
    LOBYTE (USBCAN_BAUD_1MBit),
    USBCAN_CALCULATE_AMR (FALSE, 0x600, 0x67F, FALSE, FALSE),
    USBCAN_CALCULATE_ACR (FALSE, 0x600, 0x67F, FALSE, FALSE));

// error? Print error
if (bRet != USBCAN_SUCCESSFUL)
    PrintError (bRet);
...
```

Filter parameters for RTR frames and the first two data bytes are ignored with all sysWORXX modules.

2.3.6 Using multiple CAN-channels

The USB-CANmodul2 3204002/3204003/3204007 has 2 CAN-channels and both the Multiport CAN-to-USB 3004006 and USB-CANmodul16 have 16 CAN-channels which are divided into 8 logical devices with 2 channels each. In other words, each logical device provides 2 CAN-channels, which need to get initialized. In order to use all 16 channels, each logical device has to get initialized with function *UcanInitHardware()* and/or *UcanInitHardwareEx()*. Furthermore, both CAN-channels of each logical device have to be initialized by function *UcanInitCanEx2()*. The USB-CANmodul8 behaves like USB-CANmodul16 but includes only 4 logical devices and 8 CAN-channels. USB-CANmodul2 has only one logical device and 2 CAN-channels.

There are 3 constants to select a CAN-channel:

Constant	Value	Meaning
USBCAN_CHANNEL_CH0	0	first CAN channel
USBCAN_CHANNEL_CH1	1	second CAN channel
USBCAN_CHANNEL_ANY	255	Any CAN channel
USBCAN_CHANNEL_CAN1	0	first CAN channel
USBCAN_CHANNEL_CAN2	1	second CAN channel

Table 21: Constants for CAN-channel selection

Constant USBCAN_CHANNEL_ANY can only be used with function *UcanReadCanMsgEx()* and/or *UcanGetMsgPending()*. For the function *UcanReadCanMsgEx()* it indicates that the function shall examine, from which CAN-channel the next CAN message is. If this function returns with error code USBCAN_SUCCESSFUL, then it also passes the respective CAN-channel to the calling function: USBCAN_CHANNEL_CH0 or USBCAN_CHANNEL_CH1 (see function *UcanReadCanMsgEx()*).

The constants USBCAN_CHANNEL_CAN1 and USBCAN_CHANNEL_CAN2 have the same values as USBCAN_CHANNEL_CH0 and USBCAN_CHANNEL_CH1. They were defined because on top of the housing of USB-CANmodul2, the first channel was named CAN1 but in the software the first channel is named 0.

2.3.7 Using the Callback Functions

The USBCAN-library provides two types of callback functions. The Connect Control Callback function announces Plug&Play events for the USB-CANmodul (e.g.: new USB-CANmodul connected with the PC; or taken off; ...). The second type announces events, which occur during the work with the USB-CANmodul (e.g.: CAN-message receive; Error status changed; ...).

From software version 3.00 an extended format (support of multiple CAN-channels) exists for both types of the callback function.

Note:

The "Connect control callback" function has a different format than callback functions for the other events. Make sure to use the correct format in your application. It is not possible to use the very same implementation for both types of callback function!

Also the format of the extended callback functions differs from the format of the standard functions. Make sure to use the extended callback functions if the extended API functions are used. Access violations will occur during runtime otherwise!

Also note that the callback functions are declared as PUBLIC, which is defined as “__stdcall” in Microsoft Visual Studio.

UcanConnectControlFkt**Syntax:**

```
void PUBLIC UcanConnectControlFkt (
    BYTE          bEvent_p,
    DWORD         dwParam_p);
```

Description:

This callback function informs the application program if a new USB-CANmodul is connected to the PC, or a connected USB-CANmodul has been disconnected. This callback function is registered with the USBCAN-library by function *UcanInitHwConnectControl()* and may have a different name within the application.

Parameter:

<i>bEvent_p:</i>	Event which occurred.
	<i>USBCAN_EVENT_CONNECT</i> = 6
	<i>USBCAN_EVENT_DISCONNECT</i> = 7
	<i>USBCAN_EVENT_FATALDISCON</i> = 8
<i>dwParam_p:</i>	Additional parameter
	If <i>bEvent_p</i> = 8, then the parameter is returned from the USB-CAN-Handle of the disconnected module. No messages are received from this module and no messages can be sent. The corresponding USB CAN-Handle is invalid; in other instances, the parameter is 0.

UcanConnectControlFktEx**Syntax:**

```
void PUBLIC UcanConnectControlFktEx (  
    DWORD                dwEvent_p,  
    DWORD                dwParam_p,  
    void*                pArg_p);
```

Description:

This callback function informs the application program if a new device is connected to the PC, or a connected device has been disconnected. This callback function is registered with the USB-CAN-library by function *UcanInitHwConnectControlEx()* and may have a different name within the application.

Parameter:

<i>bEvent_p</i> :	Event which occurred. <i>USBCAN_EVENT_CONNECT</i> = 6 <i>USBCAN_EVENT_DISCONNECT</i> = 7 <i>USBCAN_EVENT_FATALDISCON</i> = 8
<i>dwParam_p</i> :	Additional parameter If <i>bEvent p</i> = 8, then the parameter is returned from the USB-CAN-Handle of the disconnected module. No messages are received from this module and no messages can be sent. The corresponding USB-CAN-Handle is invalid; in other instances, the parameter is 0.
<i>pArg_p</i> :	Additional user-parameter, which was handed over to function <i>UcanInitHwConnectControlEx()</i> . as parameter <i>pCallbackArg_p</i>

UcanCallbackFkt**Syntax:**

```
void PUBLIC UcanCallbackFkt (
    tUcanHandle      UcanHandle_p,
    BYTE             bEvent_p);
```

Description:

This callback function informs the application program if an event occurred on an initialized USB-CANmodul. This callback function is registered with the USBCAN-library by function *UcanInitHardware()* and may have a different name within the application.

Parameter:

UcanHandle_p: USB-CAN handle of the USB-CANmodul where the event occurred.
This handle is returned with the function *UcanInitHardware()*.

bEvent_p: Event which occurred.

<i>USBCAN_EVENT_INITHW</i>	= 0
<i>USBCAN_EVENT_INITCAN</i>	= 1
<i>USBCAN_EVENT_RECEIVE</i>	= 2
<i>USBCAN_EVENT_STATUS</i>	= 3
<i>USBCAN_EVENT_DEINITCAN</i>	= 4
<i>USBCAN_EVENT_DEINITHW</i>	= 5

UcanCallbackFktEx**Syntax:**

```
void PUBLIC UcanCallbackFktEx (
    tUcanHandle      UcanHandle_p,
    DWORD            dwEvent_p,
    BYTE             bChannel_p,
    void*            pArg_p);
```

Description:

This callback function informs the application program if an event occurred on an initialized device. This callback function is registered with the USBCAN-library by function *UcanInitHardwareEx()* and may have a different name within the application.

Parameter:

UcanHandle_p: USB-CAN handle of the USB-CANmodul where the event occurred. This handle is returned with the function *UcanInitHardwareEx()*.

bEvent_p: Event which occurred.

<i>USBCAN_EVENT_INITHW</i>	= 0
<i>USBCAN_EVENT_INITCAN</i>	= 1
<i>USBCAN_EVENT_RECEIVE</i>	= 2
<i>USBCAN_EVENT_STATUS</i>	= 3
<i>USBCAN_EVENT_DEINITCAN</i>	= 4
<i>USBCAN_EVENT_DEINITHW</i>	= 5

bChannel_p: CAN-channel, which released the event

<i>USBCAN_CHANNEL_CH0</i>	= 0
<i>USBCAN_CHANNEL_CH1</i>	= 1
<i>USBCAN_CHANNEL_ANY</i>	= 255

pArg_p: Additional user-parameter, which was handed over to function *UcanInitHwConnectControlEx()* as parameter *pCallbackArg_p*

All callback functions have to be initialized before being called by the USBCAN-library.

The events have the following meaning:

USBCAN_EVENT_INITHW:	0x00
The USB-CANmodul is initialized successfully.	
Parameter <i>bChannel_p</i> has no meaning here.	
USBCAN_EVENT_INITCAN:	0x01
The CAN interface is initialized successfully.	
Parameter <i>bChannel_p</i> returns the CAN-channel that was initialized.	
USBCAN_EVENT_RECEIVE:	0x02
A CAN message is received.	
Parameter <i>bChannel_p</i> returns the CAN-channel that was received last by the hardware.	
USBCAN_EVENT_STATUS:	0x03
The error status at the USB-CANmodul has changed.	
Parameter <i>bChannel_p</i> returns the CAN-channel, which CAN error state has been changed.	
USBCAN_EVENT_DEINITCAN:	0x04
The CAN interface is shut down.	
Parameter <i>bChannel_p</i> returns the CAN-channel that is being shut down.	
USBCAN_EVENT_DEINITHW:	0x05
The USB-CANmodul is shut down.	
Parameter <i>bChannel_p</i> has no meaning here.	
USBCAN_EVENT_CONNECT:	0x06
A new USB-CANmodul is connected.	
Parameter <i>dwParam_p</i> has no meaning here.	
USBCAN_EVENT_DISCONNECT:	0x07
An USB-CANmodul is disconnected.	
Parameter <i>dwParam_p</i> has no meaning here.	
USBCAN_EVENT_FATALDISCON:	0x08
An USB-CANmodul in either HW_INIT or CAN_INIT state is disconnected from the computer. Data loss is possible.	
The parameter <i>dwParam p</i> contains the USB-CAN handle of the disconnected module. The handle can no longer be used.	

Note:

The callback functions should not call the functions of the USBCAN-library directly. This can lead to undesired results. The best method for using the callback functions is to wait for an event in the main program (e.g. with the Win32 function *WaitForMultipleObjects()*) and then to call the DLL functions from there after the event has occurred. The callback functions only set the corresponding event (i.e. with the Win32 function *SetEvent()*).

Example:

```
tUcanHandle UcanHandle_g;
tCanMsgStruct CanRxMsg_g;
...

void main (void)
{
    UCANRET bRet;

    // initilizes the first callback function
    bRet = UcanInitHwConnectControl (UcanConnectControlFkt);

    if (bRet == USBCAN_SUCCESSFUL)
    {
        // wait for event
        // e.g. with WaitForMultipleObjects(...) function
        // react to events accordingly:

        case INIT:
            // open USB-CANmodul with USBCAN_ANY_MODULE and
            // initialize second callback function
            bRet = UcanInitHardware (&UcanHandle_g, USBCAN_ANY_MODULE,
                                     UcanCallbackFkt);

            // initialize CAN interface
            bRet = UcanInitCan (UcanHandle_g, 0x00, 0x14, 0xFFFFFFFFFL,
                               0x00000000L);

            case RECV:
                // read CAN message
                bRet = UcanReadCanMsg (UcanHandle_g, &CanRxMsg_g);
    }
    ...
}
```

```
void PUBLIC UcanConnectControlFkt (BYTE bEvent_p, DWORD
    dwParam_p)
{
    UCANRET bRet;

    // which event did occur?
    switch (bEvent_p)
    {
        // new USB-CANmodul connected
        case USBCAN_EVENT_CONNECT:
            // Send signal to main function, so that the USB-CANmodul
            // can now be initialized.
            // i.e. with SetEvent (INIT)
            ...
            break;
        // USB-CANmodul disconnected
        case USBCAN_EVENT_DISCONNECT:
            ...
            break;
    }
}

void PUBLIC UcanCallbackFkt (tUcanHandle UcanHandle_p,
    BYTE bEvent_p)
{
    // what event appeared?
    switch (bEvent_p)
    {
        // CAN message received
        case USBCAN_EVENT_RECEIVE:
            // signal that the CAN message can be read
            // i.e. with SetEvent (RECV);
            break;

        // changes error status
        case USBCAN_EVENT_STATUS:
            // signal that the CAN status can be read
            // i.e. with SetEvent (STATUS);
            break;
        ...
    }
}
```

UcanEnumCallback

Syntax:

```
void PUBLIC UcanEnumCallback (
    DWORD          dwIndex_p,
    BOOL           fIsUsed_p,
    tUcanHardwareInfoEx* pHwInfoEx_p,
    tUcanHardwareInitInfo* pInitInfo_p,
    void*          pArg_p);
```

Description:

This callback function is called from the context of the function *UcanEnumerateHardware()* when a connected USB-CANmodul is found which matches to the filter parameters passed to *UcanEnumerateHardware()*. It may have a different name within the application.

Parameter:

<i>dwIndex_p</i> :	Ongoing index which is incremented by the value 1 for each found USB-CANmodul. The value is 0 for the first call of this callback function.
<i>fIsUsed_p</i> :	This flag is TRUE when the found USB-CANmodul is currently exclusively used by another application. This parameter only can be TRUE if the function <i>UcanEnumerateHardware()</i> was called with the parameter <i>fEnumUsedDevs_p</i> = TRUE. An USB-CANmodul cannot be used by the own application when it is exclusively used by another application.
<i>pHwInfoEx_p</i> :	Pointer to an instance of the structure of type <i>tUcanHardwareInfoEx</i> holding the hardware information of the found USB-CANmodul (see page 81).
<i>pInitInfo_p</i> :	Pointer to an instance of the structure of type <i>tUcanHardwareInitInfo</i> . This structure controls the further process of the function <i>UcanEnumerateHardware()</i> . This structure is detailed explained below. The user has to fill out this structure before returning from the callback function.
<i>pArg_p</i> :	Additional user-parameter, which was handed over to function <i>UcanEnumerateHardware()</i> by parameter <i>pCallbackArg_p</i> .

```
typedef struct _tUcanHardwareInitInfo
{
    DWORD          m_dwSize;           // size of this structure in bytes
    BOOL           m_fDoInitialize;    // set to TRUE to auto-initialize the found
                                      // module.
    tUcanHandle*   m_pUcanHandle;      // Pointer to a variable of type tUcanHandle
                                      // to receive the USB-CAN-Handle of the found
                                      // module
    tCallbackFktEx m_fpCallbackFktEx;  // Pointer to e callback handler
                                      // tCallbackFktEx for the found module
    void*          m_pCallbackArg;     // user defined parameter for the callback
                                      // handler of type tCallbackFktEx
    BOOL           m_fTryNext;         // set to TRUE if UcanEnumerateHardware()
                                      // should try to find further modules.
}
tUcanHardwareInitInfo;
```

Example:

```
#define APP_MAX_DEVICES    10  // <-- for example only 10 modules
tUcanHandle aUcanHandles_g[APP_MAX_DEVICES];
DWORD      dwFoundModules_g;

int main (void)
{
    UCANRET bRet;

    ...
    // find all USB-CANmodules
    dwFoundModules_g = UcanEnumerateHardware (AppEnumCallback, NULL,
        TRUE,      // also find modules, which are currently used by other apps
        0, ~0,     // no limitations for the device number
        0, ~0,     // no limitations for the serial number
        0, ~0);    // no limitations for the Product-Code

    //
    // beginning from here all initialized modules can be used:
    //

    // initialize the CAN interface of the first found module
    bRet = UcanInitCan (aUcanHandles_g[0], 0x00, 0x14, 0xFFFFFFFF, 0x00000000);
    ...
}

void PUBLIC AppEnumCallback (DWORD dwIndex_p, BOOL fIsUsed_p,
    tUcanHardwareInfoEx* pHwInfoEx_p, tUcanHardwareInitInfo* pInitInfo_p,
    void* pArg_p)
{
    if (fIsUsed_p != FALSE)
    {
        printf ("module %d is already used\n", pHwInfoEx_p->m_dwSerialNr);
    }
    else if (dwIndex_p < APP_MAX_DEVICES)
    {
        printf ("initialize module %d...\n", pHwInfoEx_p->m_dwSerialNr);

        // fill out the parameters for auto-initializing
        pInitInfo_p->m_fDoInitialize = TRUE;
        pInitInfo_p->m_pUcanHandle   = &aUcanHandles_g[dwIndex_p];
        pInitInfo_p->m_fpCallbackFktEx = UcanCallbackFktEx;
        pInitInfo_p->m_pCallbackArg   = pArg_p;

        // find further modules
        pInitInfo_p->m_fTryNext = TRUE;
    }
    else
    {
        // do not find further modules
        pInitInfo_p->m_fTryNext = FALSE;
    }
}
```

2.4 Class library for .NET programming languages

In order to use the USBCAN32.DLL with .NET programming languages such as Visual basic .NET, Managed C++ and C#, a Wrapper class UcanDotNET.USBcanServer was developed in VB .NET. This class lies in the dynamic link library (DLL) named UCANDOTNET.DLL. In order to include the DLL into own projects, the following steps under Visual Studio .NET become necessary:

- go to menu -> "Projects" and click on entry "Add reference...", the dialog window "Add reference" appears
- Click on "Browse" button and select the UCANDOTNET.DLL
- Press OK to confirm

Sample for creating an object of class USBcanServer in Visual Basic .NET:

```
Dim WithEvents m_USBcan As UcanDotNET.USBcanServer
```

Note:

The Wrapper class is included as source code. That means it can be changed by user expanding new features of the USBCAN32.DLL or improving the Wrapper.

2.4.1 Methods of class USBcanServer

2.4.1.1 General methods

GetFwVersion

Syntax C#:

```
public int USBcanServer.GetFwVersion();
```

Syntax Visual Basic:

```
Public USBcanServer.GetFwVersion() as Integer
```

Usability:

HW_INIT, version 3.01 and higher

Description:

Returns the firmware version number of the device.

Parameter:

none

Return value:

Firmware version number as Integer with the following format:

Bit 0-7:	Version
Bit 8-15:	Revision
Bit 16-31:	Release

GetUserDllVersion**Syntax C#:**

```
public int USBcanServer.GetUserDllVersion();
```

Syntax Visual Basic:

```
Public USBcanServer.GetUserDllVersion() as Integer
```

Usability:

DLL_INIT, HW_INIT, CAN_INIT, version 3.01 and higher

Description:

Returns the version number of the USBCAN-library.

Parameter:

none

Return value:

Software version number as Integer with the following format:

Bit 0-7:	Version
Bit 8-15:	Revision
Bit 16-31:	Release

EnumerateHardware

Syntax C#:

```
public USBcanServer[] USBcanServer.EnumerateHardware(  
    byte bDeviceNrLow_p, byte bDeviceNrHigh_p,  
    int dwSerialNrLow_p, int dwSerialNrHigh_p,  
    int dwProductCodeLow_p, int dwProductCodeHigh_p,  
    EnumDelegateCallback fpCallback_p = NULL,  
    bool fEnumUsedDevs_p = false);
```

```
public USBcanServer[] USBcanServer.EnumerateHardware(  
    byte bDeviceNrLow_p, byte bDeviceNrHigh_p,  
    EnumDelegateCallback fpCallback_p = NULL,  
    bool fEnumUsedDevs_p = false);
```

```
public USBcanServer[] USBcanServer.EnumerateHardware(  
    int dwProductCodeLow_p, int dwProductCodeHigh_p,  
    EnumDelegateCallback fpCallback_p = NULL,  
    bool fEnumUsedDevs_p = false);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.EnumerateHardware( _  
    ByVal bDeviceNrLow_p As Byte, _  
    ByVal bDeviceNrHigh_p As Byte, _  
    ByVal dwSerialNrLow_p As Integer, _  
    ByVal dwSerialNrHigh_p As Integer, _  
    ByVal dwProductCodeLow_p As Integer, _  
    ByVal dwProductCodeHigh_p As Integer, _  
    Optional ByVal fpCallback_p As EnumDelegateCallback = Nothing, _  
    Optional ByVal fEnumUsedDevs_p As Boolean = False) _  
    As USBcanServer()
```

```
Public Shared Function USBcanServer.EnumerateHardware( _  
    ByVal bDeviceNrLow_p As Byte, _  
    ByVal bDeviceNrHigh_p As Byte, _  
    Optional ByVal fpCallback_p As EnumDelegateCallback = Nothing, _  
    Optional ByVal fEnumUsedDevs_p As Boolean = False) _  
    As USBcanServer()
```

```
Public Shared Function USBcanServer.EnumerateHardware( _  
    ByVal dwProductCodeLow_p As Integer, _  
    ByVal dwProductCodeHigh_p As Integer, _  
    Optional ByVal fpCallback_p As EnumDelegateCallback = Nothing, _  
    Optional ByVal fEnumUsedDevs_p As Boolean = False) _  
    As USBcanServer()
```

Usability:

DLL_INIT, version 5.08 and higher

Description:

This method scans all USB-CANmodules connected at the host and calls a callback handler for each found module. The amount of the USB-CANmodules to be found can be limited by filter parameters. Within the callback handler the user can decide whether the found USB-CANmodule should be automatically initialized by the DLL. In this case the module changes to the state HW_INIT.

Parameter:

<i>bDeviceNrLow_p</i> , <i>bDeviceNrHigh_p</i> :	Filter parameters for the device number. The value <i>bDeviceNrLow_p</i> specifies the lower limit and the value <i>bDeviceNrHigh_p</i> specifies the upper limit of the device number which have to be found.
<i>dwSerialNrLow_p</i> , <i>dwSerialNrHigh_p</i> :	Filter parameters for the serial number. The values specifies the lower and upper limit of the serial number area which have to be found.
<i>dwProductCodeLow_p</i> , <i>dwProductCodeHigh_p</i> :	Filter parameters for the Product-Code. The values specifies the lower and upper limit of the Product-Code area which have to be found. Possible values are shown in <i>Table 15</i> .
<i>fpCallback_p</i> :	Callback handler which is called for each found USB-CANmodule.
<i>fEnumUsedDevs_p</i> :	Set to TRUE if USB-CANmodules should be found too which are currently exclusively used by another application. These modules cannot be used by the own application.

Return value:

This method returns an array of class USBcanServer with all initialized USB-CANmodules.

The Callback handler has the following syntax:

Syntax C#:

```
void PUBLIC MyEnumDelegateCallback(
    DWORD          dwIndex_p,
    BOOL           fIsUsed_p,
    tUcanHardwareInfoEx* pHwInfoEx_p,
    bool*          fDoInitialize_p
    bool*          fTryNext_p);
```

Syntax Visual Basic:

```
Private Sub MyEnumDelegateCallback( _
    ByVal dwIndex_p          As Integer, _
    ByVal fIsUsed_p          As Boolean, _
    ByVal pHwInfoEx_p        As _
        UcanDotNET.USBcanServer.tUcanHardwareInfoEx, _
    ByRef fDoInitialize_p    As Boolean, _
    ByRef fTryNext_p         As Boolean)
```

Parameter:

<i>dwIndex_p:</i>	Ongoing index which is incremented by the value 1 for each found USB-CANmodul. The value is 0 for the first call of this callback function.
<i>flsUsed_p:</i>	This flag is TRUE when the found USB-CANmodul is currently exclusively used by another application. This parameter only can be TRUE if the function <i>UcanEnumerateHardware()</i> was called with the parameter <i>fEnumUsedDevs_p</i> = TRUE. An USB-CANmodul cannot be used by the own application when it is exclusively used by another application.
<i>pHwInfoEx_p:</i>	Pointer to an instance of the structure of type <i>tUcanHardwareInfoEx</i> holding the hardware information of the found USB-CANmodul (see <i>page 81</i>).
<i>fDoInitialize_p:</i>	The callback handler has to overhand to this parameter whether the found USB-CANmodul has to be initialized by the method <i>EnumerateHardware()</i> .
<i>fTryNext_p:</i>	The callback handler has to overhand to this parameter whether a further UBS-CANmodul has to be scanned or not.

Example 1 (VB.NET):

```
Dim FoundModules() As UcanDotNET.USBcanServer

...
' find all USB-CANmodules which are not used by other applikationens
FoundModules = UcanDotNET.USBcanServer.EnumerateHardware ( _
    0, &HFF, _          ' no limits for the device number
    0, &FFFFFFFF, _      ' no limits for the serial number
    0, &FFFFFFFF, _      ' no limits for the produkt code
    MyEnumDelegateCallback)
...
```

Example 2 (VB.NET):

```
Dim FoundModules() As UcanDotNET.USBcanServer

...
' find all USB-CANmodules of type USB-CANmodul1 (G3),
' modules which are used by other applications too
FoundModules = UcanDotNET.USBcanServer.EnumerateHardware ( _
    UcanDotNET.USBcanServer.eUcanProductCode.USBCAN_PROD_CODE_PID_BASIC, _
    UcanDotNET.USBcanServer.eUcanProductCode.USBCAN_PROD_CODE_PID_BASIC, _
    MyEnumDelegateCallback, _
    True)
...
```

Example 3 (VB.NET):

```
Dim FoundModules() As UcanDotNET.USBcanServer
Dim dwSerialNr As Integer

...
' find all logical modules of type USB-CANmodul16 (G3)
dwSerialNr = 123456 ' <-- serial number from sticker at the back
FoundModules = UcanDotNET.USBcanServer.EnumerateHardware ( _
    0, &HFF, _ ' keine Einschränkung der Gerätenummer
    (dwSerialNr * 1000) + 1, _
    (dwSerialNr * 1000) + 8, _
    UcanDotNET.USBcanServer.eUcanProductCode.USBCAN_PRODCODE_PID_USBCAN16, _
    UcanDotNET.USBcanServer.eUcanProductCode.USBCAN_PRODCODE_PID_USBCAN16) _
...

```

InitHardware**Syntax C#:**

```
public byte USBcanServer.InitHardware(  
    byte bDeviceNr_p = USBCAN_ANY_MODULE); 1)
```

```
public byte USBcanServer.InitHardware(int dwSerialNr_p); 2)
```

Syntax Visual Basic:

```
Public Function USBcanServer.InitHardware( _  
    Optional ByVal bDeviceNr_p As Byte _  
        = USBCAN_ANY_MODULE) As Byte 1)
```

```
Public Function USBcanServer.InitHardware( _  
    ByVal dwSerialNr_p As Integer) As Byte 2)
```

Usability:

1) DLL_INIT, version 3.01 and higher

2) DLL_INIT, version 5.08 and higher

Description:

Initializes the device with the corresponding device or serial number.

Parameter:

<i>bDeviceNr_p</i> :	device number (0 – 254). Value <i>USBCAN_ANY_MODULE</i> (= 255) is used to indicate that the first available device shall be used.
<i>dwSerialNr_p</i> :	serial number. The value can be found at the sticker at the ground of the case (or at the back).

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_HWINUSE  
USBCAN_ERR_ILLHW  
USBCAN_ERR_MAXMODULES  
USBCAN_ERR_RESOURCE  
USBCAN_ERR_ILLVERSION
```

Shutdown

Syntax C#:

```
public byte USBcanServer.Shutdown(int dwChannel_p =  
    USBCAN_CHANNEL_ALL,  
    bool fShutDownHardware_p = true);
```

Syntax Visual Basic:

```
Public Function USBcanServer.Shutdown(_  
    Optional ByVal dwChannel_p As Integer _  
        = USBCAN_CHANNEL_ALL, _  
    Optional ByVal fShutDownHardware_p As Boolean _  
        = True) as Byte
```

Usability:

HW_INIT, version 3.01 and higher

Description:

Shuts down an initialized device that was initialized with method *InitHardware()* or *InitCan()*. The software returns to the state DLL_INIT.

Parameter:

<i>bChannel_p</i> :	CAN-channel, which needs to be de-initialized. USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1 USBCAN_CHANNEL_ALL for both CAN-channel
<i>fShutDownHardware_p</i> :	If true, the hardware will be de-initialized.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE

InitCan

Syntax C#:

```
public USBcanServer.InitCan(  
    byte bChannel_p = USBCAN_CHANNEL_CH0,  
    short wBTR_p = USBCAN_BAUD_1MBit,  
    int dwBaudrate_p = USBCAN_BAUDEX_USE_BTR01,  
    int dwAMR_p = USBCAN_AMR_ALL,  
    int dwACR_p = USBCAN_ACR_ALL,  
    byte bMode_p = tUcanMode.kUcanModeNormal,  
    byte bOCR_p = USBCAN_OCR_DEFAULT);
```

Syntax Visual Basic:

```
Public Function InitCan(Optional ByVal bChannel_p As Byte = _  
    USBCAN_CHANNEL_CH0, _  
    Optional ByVal wBTR_p As Short = USBCAN_BAUD_1MBit, _  
    Optional ByVal dwBaudrate_p As Integer = _  
    USBCAN_BAUDEX_USE_BTR01, _  
    Optional ByVal dwAMR_p As Integer = USBCAN_AMR_ALL, _  
    Optional ByVal dwACR_p As Integer = USBCAN_ACR_ALL, _  
    Optional ByVal bMode_p As Byte = _  
    tUcanMode.kUcanModeNormal, _  
    Optional ByVal bOCR_p As Integer = USBCAN_OCR_DEFAULT)  
    As Byte
```

Usability:

HW_INIT, version 3.01 and higher

Description:

Initializes a specific CAN-channel of a device. With GW-001 and GW-002 only channel 0 is available.

Parameter:

<i>bChannel_p</i> :	CAN-channel, to be initialized. USBCAN_CHANNEL_CH0 for CAN- channel 0 USBCAN_CHANNEL_CH1 for CAN- channel 1
<i>wBTR_p</i> :	Baud rate register BTR0 as high byte, Baud rate register BTR1 as low byte
<i>dwBaudrate_p</i> :	Baud rate register of Multiport CAN-to-USB and USB-CANmodul1/2
<i>dwAMR_p</i> :	Acceptance filter mask (see section 2.3.5)
<i>dwACR_p</i> :	Acceptance filter code
<i>bMode_p</i> :	Transmission mode of CAN-channel
<i>bOCR_p</i> :	Output-Control-Register

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_RESOURCE
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERRCMD_...

ResetCan

Syntax C#:

```
public byte USBcanServer.ResetCan(byte pbChannel_p)
```

Syntax Visual Basic:

```
Public Function USBcanServer.ResetCan( _  
    ByVal pbChannel_p As Byte) As Byte
```

Usability:

HW_INIT, CAN_INIT, version 3.01 and higher

Description:

Resets a CAN-channel of a device. (see function *UcanResetCan()*). With GW-001 and GW-002 only CAN-channel 0 is available.

Parameter:

<i>bChannel_p:</i>	CAN-channel, to be reset. USBCAN_CHANNEL_CH0 for CAN- channel 0 USBCAN_CHANNEL_CH1 for CAN- channel 1
<i>dwFlags_p:</i>	<i>These flags indicate what has to be set back and what not. These flags can be combined with each other.</i>

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_CANNOTINIT  
USBCAN_ERR_BUSY  
USBCAN_ERR_IOFAILED  
USBCAN_ERRCMD_...
```


GetHardwareInfo

Syntax C#:

```
public byte USBcanServer.GetHardwareInfo(  
    ref tUcanHardwareInfoEx pHwInfo_p,  
    ref tUcanChannelInfo pCanInfoCh0_p,  
    ref tUcanChannelInfo pCanInfoCh1_p);
```

Syntax Visual Basic:

```
Public Function USBcanServer.GetHardwareInfo( _  
    ByRef pHwInfo_p As tUcanHardwareInfoEx, _  
    ByRef pCanInfoCh0_p As tUcanChannelInfo, _  
    ByRef pCanInfoCh1_p As tUcanChannelInfo) As Byte
```

Usability:

HW_INIT, CAN_INIT, version 3.01 and higher

Description:

Returns the extended hardware information of a device. With Multiport CAN-to-USB 3004006 and USB-CANmodul2 3204002/3204003 the information for both CAN-channels is returned separately.

Parameter:

<i>pHwInfo_p</i> :	Pointer to structure where the extended hardware information is to be stored. (see function <i>UcanGetHardwareInfoEx2</i>).
<i>pCanInfoCh0_p</i> :	Pointer to structure where the information of CAN-channel 0 is to be stored.
<i>pCanInfoCh1_p</i> :	Pointer to structure where the information of CAN-channel 1 is to be stored.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_ILLPARAM

GetStatus

Syntax C#:

```
public byte USBcanServer.GetStatus(byte bChannel_p,  
    ref tStatusStruct pStatus_p);
```

Syntax Visual Basic:

```
Public Function USBcanServer.GetStatus( _  
    ByVal pbChannel_p As Byte, _  
    ByRef pStatus_p As tStatusStruct) As Byte
```

Usability:

HW_INIT, CAN_INIT, version 3.01 and higher

Description:

Returns the error status of a specific CAN-channel. Structure *tStatusStruct* is described with function *UcanGetStatus()*.

Parameter:

<i>bChannel_p</i> :	CAN-Channel, to be used. USBCAN_CHANNEL_CH0 for CAN-Channel 0 USBCAN_CHANNEL_CH1 for CAN-Channel 1
<i>pStatus_p</i> :	Error status of the device.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_ILLPARAM

SetBaud rate**Syntax C#:**

```
public byte USBcanServer.SetBaudrate(
    byte bChannel_p = USBCAN_CHANNEL_CH0,
    short wBTR_p = USBCAN_BAUD_1MBit,
    int dwBaudrate_p = USBCAN_BAUDEX_USE_BTR01);
```

Syntax Visual Basic:

```
Public Function USBcanServer.SetBaudrate(
    Optional ByVal bChannel_p As Byte = USBCAN_CHANNEL_CH0, _
    Optional ByVal wBTR_p As Short = USBCAN_BAUD_1MBit, _
    Optional ByVal dwBaudrate_p As Integer = USBCAN_BAUDEX_USE_BTR01)
    As Byte
```

Usability:

CAN_INIT, version 3.01 and higher

Description:

This function is used to configure the baud rate of specific CAN-channel of a device.

Parameter:

<i>bChannel_p</i> :	CAN-Channel, which is to be configured. USBCAN_CHANNEL_CH0 for CAN-Channel 0 USBCAN_CHANNEL_CH1 for CAN-Channel 1
<i>wBTR_p</i> :	Baud rate register BTR0 as high byte, Baud rate register BTR1 as low byte
<i>dwBaudrate_p</i> :	Baud rate register of Multiport CAN-to-USB 3004006 or USB-CANmodul1/2

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERRCMD_...
```

SetAcceptance**Syntax C#:**

```
public byte USBcanServer.SetAcceptance(  
    byte bChannel_p = USBCAN_CHANNEL_CH0,  
    int dwAMR_p = USBCAN_AMR_ALL,  
    int dwACR_p = USBCAN_ACR_ALL);
```

Syntax Visual Basic:

```
Public Function USBcanServer.SetAcceptance(  
    Optional ByVal bChannel_p As Byte = USBCAN_CHANNEL_CH0, _  
    Optional ByVal dwAMR_p As Integer = USBCAN_AMR_ALL, _  
    Optional ByVal dwACR_p As Integer = USBCAN_ACR_ALL)  
    As Byte
```

Usability:

CAN_INIT, version 3.01 and higher

Description:

This function is used to change the acceptance filter values for a specific CAN-channel on a device.

Parameter:

<i>bChannel_p:</i>	CAN-Channel, which is to be configured. USBCAN_CHANNEL_CH0 for CAN-Channel 0 USBCAN_CHANNEL_CH1 for CAN-Channel 1
<i>dwAMR_p:</i>	Acceptance filter mask (see section 2.3.5)
<i>dwACR_p:</i>	Acceptance filter code

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERRCMD_...

ReadCanMsg

Syntax C#:

```
public byte USBcanServer.ReadCanMsg(ref byte pbChannel_p,
    ref tCanMsgStruct[] pCanMsg_p,
    ref int pdwCount_p = 0);
```

Syntax Visual Basic:

```
Public Function USBcanServer.ReadCanMsg(ByRef pbChannel_p As Byte,
    ByRef pCanMsgStruct_p() As tCanMsgStruct,
    Optional ByRef dwCount_p As Integer = 0) As Byte
```

Usability:

CAN_INIT, version 3.01 and higher

Description:

Reads one or more CAN-messages from the buffer of the specified CAN-channel.

Parameter:

<i>pbChannel_p</i> :	Pointer to a variable containing the CAN-Channel to read from. USBCAN_CHANNEL_CH0 for CAN-Channel 0 USBCAN_CHANNEL_CH1 for CAN-Channel 1 If USBCAN_CHANNEL_ANY is given, then this function writes the CAN-channel to this variable, where the message was read from.
<i>pCanMsg_p</i> :	Address to a CAN message structure. This address must not be NULL.
<i>pdwCount_p</i> :	Address to a variable that specifies the maximum number of CAN messages to be read. This function writes the actual number of CAN messages that were read from the device to this variable.

Structure *tCanMsgStruct* is described with function *UcanReadCanMsg()*.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_ILLPARAM
USBCAN_WARN_NODATA
USBCAN_WARN_SYS_RXOVERRUN
USBCAN_WARN_DLL_RXOVERRUN
```

WriteCanMsg

Syntax C#:

```
public byte USBcanServer.WriteCanMsg(byte bChannel_p,  
    ref tCanMsgStruct[] pCanMsg_p  
    ref int dwCount_p = 0);
```

Syntax Visual Basic:

```
Public Function USBcanServer.WriteCanMsg( _  
    ByVal pbChannel_p As Byte, _  
    ByRef pCanMsgStruct_p() As tCanMsgStruct,  
    Optional ByRef dwCount_p As Integer) As Byte
```

Usability:

CAN_INIT, version 3.01 and higher

Description:

Transmits one or more CAN messages through the specified CAN-channel of the device.

Parameter:

<i>bChannel_p</i> :	CAN-Channel, which is to be used. USBCAN_CHANNEL_CH0 for CAN-Channel 0 USBCAN_CHANNEL_CH1 for CAN-Channel 1
<i>pCanMsg_p</i> :	Address to a CAN message structure. This address must not be NULL.
<i>dwCount_p</i> :	After return this variable holds the number of CAN messages which was successfully stored to the transmit buffer. This value may be less than the number of elements within the array of CAN messages if not all CAN messages could be stored to the transmit buffer. In that case the function returns the warning USBCAN_WARN_TX_LIMIT.

Structure *tCanMsgStruct* is described with function *UcanWriteCanMsg()*.

Return value:

Error code of the function.

```
USBCAN_SUCCESSFUL  
USBCAN_ERR_MAXINSTANCES  
USBCAN_ERR_ILLHANDLE  
USBCAN_ERR_CANNOTINIT  
USBCAN_ERR_ILLPARAM  
USBCAN_ERR_DLL_TXFULL
```

Example for Visual Basic .NET:

```
' variable for return value
Dim bRet As Byte = 0
' array of tCanMsgStruct with length 1
Dim canMsgStruct(0) As UcanDotNET.USBcanServer.tCanMsgStruct

' initialize the first element with a new structure instance
canMsgStruct(0) = _
    UcanDotNET.USBcanServer.tCanMsgStruct.CreateInstance(&H123)

' fill message data with some value
canMsgStruct(0).m_bData(0) = &HAB
canMsgStruct(0).m_bData(1) = &HCD
canMsgStruct(0).m_bData(2) = &HEF
canMsgStruct(0).m_bData(3) = &H12
canMsgStruct(0).m_bData(4) = &H34
canMsgStruct(0).m_bData(5) = &H56
canMsgStruct(0).m_bData(6) = &H78
canMsgStruct(0).m_bData(7) = &H90

' send message
bRet = m_USBcan.WriteCanMsg( _
    UcanDotNET.USBcanServer.USBCAN_CHANNEL_CH0, _
    canMsgStruct)
' check return value
' .....
```

GetMsgCountInfo

Syntax C#:

```
public byte USBcanServer.GetMsgCount(  
    byte bChannel_p,  
    ref short wRecvdMsgCount_p, _  
    ref short wSentMsgCount_p);
```

Syntax Visual Basic:

```
Public Function USBcanServer.GetMsgCount( _  
    ByVal bChannel_p As Byte, _  
    ByRef pwRecvdMsgCount_p As Short, _  
    ByRef pwSentMsgCount_p As Short) As Byte
```

Usability:

CAN_INIT, version 3.01 and higher

Description:

Reads the message counters of the specified CAN-channel.

Parameter:

<i>bChannel_p</i> :	CAN-Channel, which is to be used. USBCAN_CHANNEL_CH0 for CAN-Channel 0 USBCAN_CHANNEL_CH1 for CAN-Channel 1
<i>pwRecvdMsgCount_p</i> :	pointer to variable for receive message counter.
<i>pwSentMsgCount_p</i> :	pointer to variable for transmit message counter.

Return value:

Error code of the function.

USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLCMD
USBCAN_WARN_NOTEQU

GetMsgPending

Syntax C#:

```
public byte USBcanServer.GetMsgPending (
    byte bChannel_p,
    int dwFlags_p,
    ref int pdwPendingCount_p);
```

Syntax Visual Basic:

```
Public Function USBcanServer.GetMsgPending ( _
    ByVal bChannel_p As Byte, _
    ByVal dwFlags_p As Integer, _
    ByRef pdwPendingCount_p As Integer) As Byte
```

Usability:

CAN_INIT ab Version 3.06, ab sysWORXX

Description:

This method calculates the number of CAN-messages that remain in the buffers of single software levels. The parameter *dwFlags_p* indicates, which buffers should be tested. Should several buffers have to be checked then the number of received CAN-messages are added to each other and written to the variable referenced by *pdwPendingCount_p*.

Parameter:

<i>bChannel_p</i> :	CAN-CHANNEL USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1 USBCAN_CHANNEL_ANY for both channels
<i>dwFlags_p</i> :	Indicates which buffers should be tested (<i>refer to Table 17</i>) Each flag can be combined.
<i>pdwPendingCount_p</i> :	Reference to the variable which is supposed to receive the number of CAN-messages in the buffer.

Return Value:

Error Code of Function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLHWTYPE
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_CANNOTINIT
USBCAN_ERRCMD_...
```

GetCanErrorCounter

Syntax C#:

```
public byte USBcanServer.GetCanErrorCounter (
    byte bChannel_p,
    ref int pdwTxErrorCounter_p,
    ref int pdwRxErrorCounter_p);
```

Syntax Visual Basic:

```
Public Function USBcanServer.GetCanErrorCounter ( _
    ByVal bChannel_p As Byte, _
    ByRef pdwTxErrorCounter_p As Integer, _
    ByRef pdwRxErrorCounter_p As Integer) As Byte
```

Usability:

CAN_INIT as of Version 3.06 and higher, as of sysWORXX

Description:

Reads the current count within the CAN-Controller. These values are directly read by the hardware.

Parameter:

<i>bChannel_p</i> :	CAN-CHANNEL USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pdwTxErrorCounter_p</i> :	Reference to a variable which is supposed to receive outbound messages
<i>pdwRxErrorCounter_p</i> :	Reference to a variable which is supposed to receive inbound messages

Return Value:

Error Code of Function.

USBCAN_SUCCESSFUL
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLHWTYPE
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_CANNOTINIT
USBCAN_ERRCMD_...

SetTxTimeout

Syntax C#:

```
public byte USBcanServer.SetTxTimeout (
    byte bChannel_p,
    int dwTxTimeout_p);
```

Syntax Visual Basic:

```
Public Function USBcanServer.SetTxTimeout ( _
    ByVal bChannel_p As Byte, _
    ByVal dwTxTimeout_p As Integer) As Byte
```

Usability:

CAN_INIT as of Version 3.10 and higher, only for multi-channel modules

Description:

This method configures the transmission-timeout for CAN messages in the firmware of the multi-channel modules. For further information, ref. UcanSetTxTimeout on page 72

Parameter:

<i>bChannel_p</i> :	CAN Channel, for which timeout shall apply. USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>dwTxTimeout_p</i> :	Send-Timeout in milli seconds. The value 0 switches the Timeout-control off again.

Return Value:

Error Code of Function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_CANNOTINIT
USBCAN_ERR_BUSY
USBCAN_ERR_IOFAILED
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_DATA
USBCAN_ERR_ABORT
USBCAN_ERR_DISCONNECT
USBCAN_ERR_TIMEOUT
USBCAN_ERRCMD_...
```

2.4.1.2 Methods for Automatic Sending

DefineCyclicCanMsg

Syntax C#:

```
public byte USBcanServer.DefineCyclicCanMsg (
    byte bChannel_p,
    ref tCanMsgStruct[] pCanMsgList_p);
```

Syntax Visual Basic:

```
Public Function USBcanServer.DefineCyclicCanMsg( _
    ByVal bChannel_p As Byte, _
    ByRef pCanMsgList_p() As tCanMsgStruct) As Byte
```

Usability:

HW_INIT, CAN_INIT, as of Version 3.06 and higher, as of sysWORXX

Description:

Defines a list of up to 16 CAN-messages in the USB-CANmodul for automated sending of cyclic CAN-messages. Sending is not initiated after the call of this function. Call the method *EnableCyclicCanMsg()* in order to activate the automatic sending. Please note that a pre-defined list will be completely replaced.

Parameter:

<i>bChannel_p</i> :	CAN-Channel which is supposed to send. USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pCanMsgList_p</i> :	Reference to a list of CAN-messages (as array of type <i>tCanMsgStruct</i> with max. 16 entries) which are to be sent cyclically. The element <i>m_dwTime</i> of structure <i>tCanMsgStruct</i> indicates cycle time in milli seconds. If "NULL" resp. „Nothing“ is stated, only the old list in the module is deleted.

Return Value:

Error Code of Function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLHWTYPE
USBCAN_ERR_ILLCHANNEL
USBCAN_ERRCMD_...
```

ReadCyclicCanMsg**Syntax C#:**

```
public byte USBcanServer.ReadCyclicCanMsg (
    byte bChannel_p,
    ref tCanMsgStruct[] pCanMsgList_p,
    ref int dwCount_p = 0);
```

Syntax Visual Basic:

```
Public Function USBcanServer.ReadCyclicCanMsg ( _
    ByVal bChannel_p As Byte, _
    ByRef pCanMsgList_p() As tCanMsgStruct, _
    Optional ByRef dwCount_p As Integer = 0) As Byte
```

Usability:

HW_INIT, CAN_INIT, as of Version 3.06 and higher, as of sysWORXX

Description:

Reads back the list of CAN-messages from the USB-CANmodul, which were prior defined for the automatic sending.

Parameter:

<i>bChannel_p:</i>	CAN-Channel, from which shall be read back. USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>pCanMsgList_p:</i>	Reference to a list of CAN-messages (as array of type <i>tCanMsgStruct</i> with max. 16 entries) to where the list of cyclic CAN-messages should be copied.
<i>dwCount_p:</i>	Reference to a variable, to where this method writes the number of cyclic CAN-messages within the list.

Return Value:

Error Code of Function.

```
USBCAN_SUCCESSFUL
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLHWTYPE
USBCAN_ERR_ILLCHANNEL
USBCAN_ERRCMD_...
```

EnableCyclicCanMsg

Syntax C#:

```
public byte USBcanServer.EnableCyclicCanMsg (
    byte bChannel_p,
    int dwFlags_p);
```

Syntax Visual Basic:

```
Public Function USBcanServer.EnableCyclicCanMsg ( _
    ByVal bChannel_p As Byte, _
    ByVal dwFlags_p As Integer) As Byte
```

Usability:

CAN_INIT, as of Version 3.06 and higher, as of sysWORXX

Description:

With this function the mode of transmission is set and the sending of cyclic CAN-messages is initiated and stopped. Additionally single CAN-messages from the prior defined list can be locked.

Parameter:

<i>bChannel_p</i> :	CAN-Channel USBCAN_CHANNEL_CH0 for CAN-channel 0 USBCAN_CHANNEL_CH1 for CAN-channel 1
<i>dwFlags_p</i> :	Bit-oriented flags, which can be used for setting the mode, starting resp. Stopping the sending and locking single CAN-messages (<i>ref.</i> Table 18). The flags can be combined.

Return Value:

Error Code of Function

```
USBCAN_SUCCESSFUL
USBCAN_ERR_ILLPARAM
USBCAN_ERR_ILLHANDLE
USBCAN_ERR_MAXINSTANCES
USBCAN_ERR_ILLHW
USBCAN_ERR_ILLHWTYPE
USBCAN_ERR_ILLCHANNEL
USBCAN_ERR_CANNOTINIT
USBCAN_ERRCMD_...
```

2.4.1.3 Static Help Methods of Class USBcanServers

GetCanStatusMessage

Syntax C#:

```
public static String USBcanServer.GetCanStatusMessage(  
    short wCanStatus_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.GetCanStatusMessage( _  
    ByVal wCanStatus_p As Short) As String
```

Usability:

CAN_INIT as of Version 3.01 and higher

Description:

Displays the CAN status as string. If several bits are set in CAN-status code, respective status strings are separated by commas.

Parameter:

wCanStatus_p: CAN-Status Code (ref. USBCAN API Function *UcanGetStatus()*)

Return Value:

String with respective CAN-Status

GetBaudrateMessage

Syntax C#:

```
public static String USBcanServer.GetBaudrateMessage(  
    byte bBTR0_p, byte bBTR1_p);  
  
public static String USBcanServer.GetBaudrateMessage(  
    short wBTR_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.GetBaudrateMessage( _  
    ByVal bBTR0_p As Byte, ByVal bBTR1_p As Byte) As String  
  
Public Shared Function USBcanServer.GetBaudrateMessage( _  
    ByVal wBTR_p As Short) As String
```

Usability:

CAN_INIT as of Version 3.01 and higher

Description:

Displays the baud rate as string for stated BTR registry value. This function can be applied to the baud rate values for the older USB-CANmoduls (GW-001 und GW-002). The sysWORXX USB-CANmoduls are compatible with the known baud rate values described in section 2.3.4.

Parameter:

<i>bBTR0_p</i> :	Baud Rate Registry 0 (BTR0)
<i>bBTR1_p</i> :	Baud Rate Registry 1 (BTR1)
<i>wBTR_p</i> :	Combined Baud Rate Registry Bit15 to Bit8: BTR0 Bit7 to Bit0: BTR1

Return Value:

String with respective CAN-Baud Rate

GetBaudrateExMessage**Syntax C#:**

```
public static String USBcanServer.GetBaudrateExMessage(  
    int dwBTR_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.GetBaudrateExMessage( _  
    ByVal dwBTR_p As Integer) As String
```

Usability:

CAN_INIT as of Version 3.01 and higher

Description:

Displays the baud rate as string for the indicated BTR registry value. This function can only be applied to the baud rate value of sysWORXX USB-CANmodules.

Parameter:

dwBTR_p: 32 bit Baud Rate Registry

Return Value:

String with respective CAN-Baud Rate

ConvertToMajorVer

Syntax C#:

```
public static int USBcanServer.ConvertToMajorVer (
    int dwVersion_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.ConvertToMajorVer ( _
    ByVal dwVersion_p As Integer) As Integer
```

Description:

Converts the version code to major version

Parameter:

dwVersion_p: Version code displayed by methods GetHardwareInfo(), GetUserDllVersion() or GetFwVersion().

Return Value:

Converted Major Version

ConvertToMinorVer

Syntax C#:

```
public static int USBcanServer.ConvertToMinorVer (
    int dwVersion_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.ConvertToMinorVer ( _
    ByVal dwVersion_p As Integer) As Integer
```

Description:

Converts the Version Code to Minor Version

Parameter:

dwVersion_p: Version code, displayed by methods GetHardwareInfo(), GetUserDllVersion() or GetFwVersion().

Return value:

Converted Minor Version

ConvertToReleaseVer**Syntax C#:**

```
public static int USBcanServer.ConvertToReleaseVer (
    int dwVersion_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.ConvertToReleaseVer ( _
    ByVal dwVersion_p As Integer) As Integer
```

Description:

Converts the Version Code to the Release-Version.

Parameter:

dwVersion_p: Version code, displayed by methods GetHardwareInfo(), GetUserDllVersion() or GetFwVersion().

Return Value:

Converted Release-Version

CheckIs_sysWORXX**Syntax C#:**

```
public static bool USBcanServer.CheckIs_sysWORXX (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckIs_sysWORXX ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if USB-CANmodul is a sysWORXX module.

Checks_G3

Syntax C#:

```
public static bool USBcanServer.CheckIs_G3 (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckIs_G3 ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if the USB-CANmodul is a module of the third generation (G3).

Checks_G4

Syntax C#:

```
public static bool USBcanServer.CheckIs_G4 (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckIs_G4 ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if the USB-CANmodul is a module of the fourth generation (G4).

CheckSupportCyclicMsg

Syntax C#:

```
public static bool USBcanServer.CheckSupportCyclicMsg (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckSupportCyclicMsg ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if the USB-CANmodul supports automatic sending of cyclic CAN-messages.

CheckSupportTwoChannel

Syntax C#:

```
public static bool USBcanServer.CheckSupportTwoChannel (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckSupportTwoChannel ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if the USB-CANmodul (as logic module) possesses two CAN-channels. If it is for instance an USB-CANmodul8, it comprises of 4 logic modules with 2 CAN-channels each.

CheckSupportTermResistor

Syntax C#:

```
public static bool USBcanServer.CheckSupportTermResistor (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckSupportTermResistor( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo()

Return Value:

Displays true, if the USB-CANmodul has load resistors for the CAN-bus on board. Depending on the article number these have to be connected first.

CheckSupportUserPort

Syntax C#:

```
public static bool USBcanServer.CheckSupportUserPort (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckSupportUserPort ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if the USB-CANmodul has a port extension (*ref. section 1.5*).

CheckSupportRbUserPort

Syntax C#:

```
public static bool USBcanServer.CheckSupportRbUserPort (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckSupportRbUserPort ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if the USB-CANmodul has a back-readable port extension (*ref. section 1.5*).

CheckSupportRbCanPort

Syntax C#:

```
public static bool USBcanServer.CheckSupportRbCanPort (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckSupportRbCanPort ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if the USB-CANmodul has a back-readable CAN port (*ref. section 1.4*).

Note:

If this method displays true, that does not mean, it is equipped with a low-speed CAN-transceiver.

CheckSupportUcannet

Syntax C#:

```
public static bool USBcanServer.CheckSupportUcannet (
    tUcanHardwareInfoEx HwInfoEx_p);
```

Syntax Visual Basic:

```
Public Shared Function USBcanServer.CheckSupportUcannet ( _
    ByVal HwInfoEx_p As tUcanHardwareInfoEx) As Boolean
```

Parameter:

HwInfoEx_p: Hardware information structure, read with method GetHardwareInfo().

Return Value:

Displays true, if the USB-CANmodul can be used with the USB-CANnetwork driver.

2.4.2 Event of class USBcanServer

Class USBcanServer passes the callback events of the USBCAN32.DLL to the application as .NET events.

Note:

The callback events should not call the methods of class USBcanServer directly. This could lead to undesirable effects. The best method is to wait for an event in a thread (e.g. with method *WaitHandle.WaitAny()*) and call the method of class USBcanServer after the occurrence of the event. The callback events only set the respective signal (e.g. with method *AutoResetEvent.Set()*).

CanMsgReceivedEvent

Syntax C#:

```
public event USBcanServer.CanMsgReceivedEvent (
    byte bChannel_p);
```

Syntax Visual Basic:

```
Public Event USBcanServer.CanMsgReceivedEvent ( _
    ByVal bChannel_p As Byte)
```

Description:

A new CAN-message was received.

Parameter:

<i>bChannel_p:</i>	CAN-Channel that received the message. USBCAN_CHANNEL_CH0 for CAN-Channel 0 USBCAN_CHANNEL_CH1 for CAN-Channel 1
--------------------	--

InitHwEvent

Syntax C#:

```
public event USBcanServer.InitHwEvent();
```

Syntax Visual Basic:

```
Public Event USBcanServer.InitHwEvent()
```

Description:

Device was initialized.

InitCanEvent

Syntax C#:

```
public event USBcanServer.InitCanEvent(byte bChannel_p);
```

Syntax Visual Basic:

```
Public Event USBcanServer.InitCanEvent( _  
    ByVal bChannel_p As Byte)
```

Description:

Specified CAN-channel was initialized.

Parameter:

bChannel_p: CAN-Channel that was initialized.
USBCAN_CHANNEL_CH0 for CAN-Channel 0
USBCAN_CHANNEL_CH1 for CAN-Channel 1

StatusEvent

Syntax C#:

```
public event USBcanServer.StatusEvent(byte bChannel_p);
```

Syntax Visual Basic:

```
Public Event USBcanServer.StatusEvent(ByVal bChannel_p As Byte)
```

Description:

Error status for the specified CAN-Channel has changed.

Parameter:

bChannel_p: CAN-Channel, which error status has been changed.
USBCAN_CHANNEL_CH0 for CAN-Channel 0
USBCAN_CHANNEL_CH1 for CAN-Channel 1

Example of an event handler for the status event in Visual Basic .NET:

```

Private Sub USBcan_Status(ByVal bChannel_p As Byte) _
    Handles m_USBcan.StatusEvent

    ' signal event for status changed
    Dim are As AutoResetEvent = _
        CType (Me.m_StatusWaitHandles(0), AutoResetEvent)
    are.Set()

End Sub

Private Sub ThreadProcStatus()

    Dim fDoExit = False
    Do
        ' wait for event handle
        Dim index As Integer =
            WaitHandle.WaitAny(Me.m_StatusWaitHandles)
        ' ...

        ' status of USB-CANmodul changed
        Dim status As UcanDotNET.USBcanServer.tStatusStruct
        Dim bRet As Byte

        bRet = m_USBcan.GetStatus(bChannel_p, status)
        If bRet = UcanDotNET.USBcanServer.USBCAN_SUCCESSFUL Then
            Console.WriteLine("CAN status of channel "
                + bChannel_p.ToString() + ": "
                + status.m_wCanStatus.ToString("X4"))
        Else
            Console.WriteLine("Error while reading status: "
                + bRet.ToString("X2"))
        End If

        ' ...

    Loop While (fDoExit = False)

End Sub

```

DeinitCanEvent

Syntax C#:

```
public event USBcanServer.DeinitCanEvent (byte bChannel_p) ;
```

Syntax Visual Basic:

```
Public Event USBcanServer.DeinitCanEvent ( _  
    ByVal bChannel_p As Byte)
```

Description:

The CAN-channel was shut down..

Parameter:

<i>bChannel_p:</i>	CAN-Channel, which status has been changed. USBCAN_CHANNEL_CH0 for CAN-Channel 0 USBCAN_CHANNEL_CH1 for CAN-Channel 1
--------------------	---

DeinitHwEvent**Syntax C#:**

```
public event USBcanServer.DeinitHwEvent()
```

Syntax Visual Basic:

```
Public Event USBcanServer.DeinitHwEvent()
```

Description:

The device was shut down.

ConnectEvent**Syntax C#:**

```
public static event USBcanServer.ConnectEvent();
```

Syntax Visual Basic:

```
Public Shared Event USBcanServer.ConnectEvent()
```

Description:

A new device was connected to the USB-port.

DisconnectEvent**Syntax C#:**

```
public static event USBcanServer.DisconnectEvent();
```

Syntax Visual Basic:

```
Public Shared Event USBcanServer.DisconnectEvent()
```

Description:

A previously shut down device was disconnected from the USB-port.

FatalDisconnectEvent

Syntax C#:

```
public event USBcanServer.FatalDisconnectEvent();
```

Syntax Visual Basic:

```
Public Shared Event USBcanServer.FatalDisconnectEvent()
```

Description:

A device was disconnected from the USB-port without prior shutdown.

2.4.3 Properties of Class USBcanServer

IsHardwareInitialized

Syntax C#:

```
public bool IsHardwareInitialized;
```

Syntax Visual Basic:

```
Public ReadOnly Property IsHardwareInitialized() As Boolean
```

Return Value:

Displays true, if the USB-CANmodul was initialized as hardware. The method set() is not implemented.

IsCan0Initialized

Syntax C#:

```
public bool IsCan0Initialized;
```

Syntax Visual Basic:

```
Public ReadOnly Property IsCan0Initialized () As Boolean
```

Return Value:

Displays true, if the first CAN-channel of the USB-CANmodul has been initialized. The method set() is not implemented.

IsCan1Initialized

Syntax C#:

```
public bool IsCan1Initialized;
```

Syntax Visual Basic:

```
Public ReadOnly Property IsCan1Initialized () As Boolean
```

Return Value:

Displays true, if the second CAN-channel of the USB-CANmodul was initialized.

The method set() is not implemented.

3 Software support for Linux OS

For the Linux operating system a Socket-CAN driver is being offered. Please ask at the help desk support for the respective article number or refer to the download-page of the SYS TEC homepage: www.systec-electronic.com.

4 Software support for Windows CE OS

The software package with order number SO-1091 contains a driver for Windows CE, an USBCAN-library as DLL and a demo application in source code for Microsoft eMbedded Visual C++ 4.0. The following Windows CE versions and CPU types are tested with the driver:

Windows CE version	CPU type	Tested at CPU
5.0	ARMV4I	Intel PXA255 Intel PXA270
6.0	X86	Intel Atom

Table 22: tested Windows CE versions and CPU types

On request we can build a driver for other CPU types too. Please contact our support department for this.

4.1 Installation of the driver under Windows CE

After unzipping the archive, you will find the driver in subfolder *Driver\XXX* whereas XXX marks the CPU type. For example, the driver for CPU type ARMV4I is located in subfolder *Driver\ARMV4I*. The name of the driver file in each case is **UsbCanDrv.dll**.

This driver in its current version supports the following USB-CANmoduls:

GW-002, USB-CANmodul1 (3204000 and 3204001) and all derivatives of USB-CANmodul2 (3204001, 3204003, ...)

Prior to connecting the USB-CANmodul to your Windows CE device, copy the driver to the subfolder *Windows*. Now connect the USB-CANmodul with your Windows CE device. If the USB-CANmodul is connected for the first time, a window "Unidentified USB device" appears. Type in the name of the driver: **usbcandrv** (no capitalization rules). Now you can access the USB-CANmodul with an application. You can use our **ConsoleDemo.exe** for example. It sends 100 CAN messages with 1 MBit/sec and prints out received CAN messages in the meantime.

4.2 API functions under Windows CE

UsbCanCE.dll contains the API functions for the USB-CANmodul. This USBCAN-library is located in subfolder *Lib\XXX* whereas XXX marks the CPU type. This DLL contains all functions that are also available in USBCAN32.DLL under Windows 2000/XP/Vista – except for three functions:

UcanInitHwConnectControl()

UcanInitHwConnectControlEx()

UcanDeinitHwConnectControl()

Please refer to *section 2.3* for the description of all available functions.

There are some more differences between UsbCanCE.dll and USBCAN32.dll:

- Under Windows CE up to 9 USB-CANmoduls can only be used simultaneously at one Windows CE device.
- Function *UcanGetVersionEx()* only can be run with the parameters *kVerTypeUserDll*, *kVerTypeUserLib* and *kVerTypeSysDrv*.
- The call of *UcanDeinitCan()* or *UcanDeinitCanEx()* can take up to two seconds until return from this function.

4.3 Logging debug information

If there are problems with the driver it would be helpful if you send us a debug log file with debug information of the USBCAN-library. Using the current version Windows CE, it is momentarily only possible to activate this feature by calling the function *UcanSetDebugMode()* in your application. Please refer to *section 2.3.2* for more information.

5 Known issues

- Using VMware under Windows OS as host there can cause problems when connecting the USB-CANmodul to the guest OS. Until now we have detected problems on Renesas USB 3.0 ports. Furthermore the establishing of the connect can fail when using the USB-CANnetwork driver on the host OS
- With USB-CANmoduls of third generation (USB-CANmodul1 until revision 4, USB-CANmodul2 until revision 2, USB-CANmodul8 and USB-CANmodul16) a CAN message cannot be aborted which was set to the CAN controller for sending, as long as there is no other CAN device which sends the acknowledge to the CAN bus. The only way to abort the transmission is to disconnect the module from powers supply. This problem is not present on the newer USB-CANmoduls of fourth generation. With this modules the transmission can be aborted by calling the API function `UcanResetCan()` or `UcanResetCanEx()` with deleted flag `USBCAN_RESET_NO_CANCTRL`.

6 Index

Acceptance Filter	138	Constant	
ACR	138	kUcanModeListenOnly	70
AMR	138	kUcanModeNormal	70
API Functions	48	kUcanModeTxEcho	70
Baud Rate	3	kVerTypeCpl	51
Baud Rate Configuration	128	kVerTypeNetDrv	51
Borland C++ Builder	45	kVerTypeSysDrv	51
Callback Event		kVerTypeSysL2	51
UcanDotNET.DLL		kVerTypeSysL3	51
CanMsgReceivedEvent	187	kVerTypeSysL4	51
ConnectEvent	191	kVerTypeSysL5	51
DeinitCanEvent	190	kVerTypeSysLd	51
DeinitHwEvent	191	kVerTypeUserDll	51
DisconnectEvent	191	kVerTypeUserLib	51
FatalDisconnectEvent	192	UCAN_CANPORT_EN	114
InitCanEvent	188	UCAN_CANPORT_ERR	114
InitHwEvent	187	UCAN_CANPORT_STB	114
StatusEvent	188	UCAN_CANPORT_TRM	114
USBCAN-library		USBCAN_BAUDEX_USE_BTR01	132
USBCAN_EVENT_CONNECT	146	USBCAN_CHANNEL_ANY	141
USBCAN_EVENT_DEINITCAN	146	USBCAN_CHANNEL_CAN1	141
USBCAN_EVENT_DEINITHW	146	USBCAN_CHANNEL_CH0	141
USBCAN_EVENT_DISCONNECT	146	USBCAN_CHANNEL_CH1	141
USBCAN_EVENT_FATALDISCON	146	USBCAN_CYCLIC_FLAG_LOCK_XX	111
USBCAN_EVENT_INITCAN	146	USBCAN_CYCLIC_FLAG_NOECHO	111
USBCAN_EVENT_INITHW	146	USBCAN_CYCLIC_FLAG_SEQUOMODE	111
USBCAN_EVENT_RECEIVE	146	USBCAN_CYCLIC_FLAG_START	111
USBCAN_EVENT_STATUS	146	USBCAN_MSG_FF_ECHO	94, 100
callback function54, 55, 59, 61, 86, 127, 141, 146		USBCAN_MSG_FF_EXT	94
Callback Function		USBCAN_MSG_FF_RTR	94
USBCAN-library		USBCAN_MSG_FF_STD	94
UcanCallbackFkt	144	USBCAN_PENDING_FLAG_RX_DLL	103
UcanCallbackFktEx	145	USBCAN_PENDING_FLAG_RX_FW	103
UcanConnectControlFkt	142	USBCAN_PENDING_FLAG_TX_DLL	103
UcanConnectControlFktEx	143	USBCAN_PENDING_FLAG_TX_FW	103
UcanEnumCallback	149	USBCAN_RESET_ALL	74
CAN Messages Filter	138	USBCAN_RESET_FIRMWARE	75
CAN port	30, 42, 112, 113, 114	USBCAN_RESET_NO_CANCTRL	74
CAN Supply Voltage	29	USBCAN_RESET_NO_RXBUFFER_CH	75
CAN transceiver	30	USBCAN_RESET_NO_RXBUFFER_DLL	75
CAN-frame format	94	USBCAN_RESET_NO_RXBUFFER_FW	75
CAN-Status		USBCAN_RESET_NO_RXBUFFER_SYS	75
USBCAN_CANERR_BUSHEAVY	87	USBCAN_RESET_NO_RXCOUNTER	74
USBCAN_CANERR_BUSLIGHT	87	USBCAN_RESET_NO_STATUS	74
USBCAN_CANERR_BUSOFF	87	USBCAN_RESET_NO_TXBUFFER_CH	74
USBCAN_CANERR_OK	87	USBCAN_RESET_NO_TXBUFFER_DLL	75
USBCAN_CANERR_OVERRUN	87	USBCAN_RESET_NO_TXBUFFER_FW	75
USBCAN_CANERR_QOVERRUN	87	USBCAN_RESET_NO_TXCOUNTER	74
USBCAN_CANERR_QXMTFULL	87	USBCAN_RESET_ONLY_ALL_BUFF	76
USBCAN_CANERR_REGTEST	87	USBCAN_RESET_ONLY_ALL_COUNTER	76
USBCAN_CANERR_TXMSGLOST	72, 87	USBCAN_RESET_ONLY_CANCTRL	75
USBCAN_CANERR_XMTFULL	87	USBCAN_RESET_ONLY_RX_BUFF	75
		USBCAN_RESET_ONLY_RX_BUFF_GW002	76
		USBCAN_RESET_ONLY_RXBUFFER_FW	75
		USBCAN_RESET_ONLY_RXCHANNEL_BUFF	75
		USBCAN_RESET_ONLY_STATUS	75
		USBCAN_RESET_ONLY_TX_BUFF	75
		USBCAN_RESET_ONLY_TXBUFFER_FW	75
		USBCAN_RESET_ONLY_TXCHANNEL_BUFF	75

debug information	25, 197	ResetCan	162
Demo Program	3, 11	SetAcceptance	166
DEMO.API	45	SetBaudrate	165
DEMOCYCLICMSG	45	Shutdown	159
DEMOGW006	45	WriteCanMsg	168
DLL	3, 11, 45	USBCAN-library	
EEPROM	3	UcanConfigUserPort	117
Eigenschaft		UcanDefineCyclicCanMsg	108
UcanDotNET.DLL		UcanDeinitCan	77, 78, 197
IsCan0Initialized	192	UcanDeinitCanEx	197
IsCan1Initialized	193	UcanDeinitHardware	65
IsHardwareInitialized	192	UcanDeinitHwConnectControl	56, 197
Error Code		UcanEnableCyclicCanMsg	110
USBCAN_ERR_BUSY	122	UcanEnumerateHardware	57
USBCAN_ERR_CANNOTINIT1	123	UcanGetCanErrorCounter	105
USBCAN_ERR_DISCONNECT	124	UcanGetFwVersion	53
USBCAN_ERR_DLL_TXFULL	123	UcanGetHardwareInfoEx2	81
USBCAN_ERR_HWINUSE	121	UcanGetHardwareInfo	79
USBCAN_ERR_ILLCCHANNEL	124	UcanGetModuleTime	66
USBCAN_ERR_ILLHANDLE	122	UcanGetMsgCountInfo	84
USBCAN_ERR_ILLHW	122	UcanGetMsgCountInfoEx	85
USBCAN_ERR_ILLHWTYPE	124	UcanGetMsgPending	103
USBCAN_ERR_ILLPARAM	122	UcanGetStatus	86
USBCAN_ERR_ILLVERSION	122	UcanGetStatusEx	88
USBCAN_ERR_IOFAILED	123	UcanGetVersion	50
USBCAN_ERR_MAXINSTANCES	123	UcanGetVersionEx	51, 197
USBCAN_ERR_MAXMODULES	121	UcanInitCan	68
USBCAN_ERR_NOHWCLASS	124	UcanInitCanEx	69
USBCAN_ERR_RESOURCE	121	UcanInitCanEx2	71, 141
USBCAN_ERR_TIMEOUT	123	UcanInitHardware	59, 141
USBCAN_ERRCMD_ALREADYINIT	125	UcanInitHardwareEx	61
USBCAN_ERRCMD_EEPROM	125	UcanInitHardwareEx2	63
USBCAN_ERRCMD_ILLBDR	125, 132	UcanInitHwConnectControl	54, 197
USBCAN_ERRCMD_ILLCMD	111, 116, 125	UcanInitHwConnectControlEx	55, 197
USBCAN_ERRCMD_ILLDIX	126	UcanReadCanMsg	94
USBCAN_ERRCMD_ILLSUBCMD	125	UcanReadCanMsgEx	97, 141
USBCAN_ERRCMD_NOTEQU	124	UcanReadCanPort	114
USBCAN_ERRCMD_NOTINIT	125	UcanReadCanPortEx	115
USBCAN_ERRCMD_REGTST	124	UcanReadCyclicCanMsg	109
USBCAN_ERRCMD_RUNNING	126	UcanReadUserPort	119
USBCAN_SUCCESSFUL	121	UcanReadUserPortEx	120
USBCAN_WARN_DLL_RXOVERRUN	126	UcanResetCan	73
USBCAN_WARN_FW_RXOVERRUN	127	UcanResetCanEx	74
USBCAN_WARN_FW_TXOVERRUN	127	UcanSetAcceptance	92
USBCAN_WARN_NODATA	126	UcanSetAcceptanceEx	93
USBCAN_WARN_NULL_PTR	127	UcanSetBaudrate	89
USBCAN_WARN_SYS_RXOVERRUN	126	UcanSetBaudrateEx	90
USBCAN_WARN_TXLIMIT	127	UcanSetDebugMode	49
Error Codes	121	UcanSetDeviceNr	67
Expansion Port	31, 116, 118, 119, 120	UcanSetTxTimeout	72
File Structure	41	UcanWriteCanMsg	100
Function		UcanWriteCanMsgEx	101
UcanDotNET.DLL		UcanWriteCanPort	112
GetFwVersion	152	UcanWriteCanPortEx	113
GetHardwareInfo	163	UcanWriteUserPort	118
GetMsgCountInfo	170	Funktion	
GetStatus	164	UcanDotNET.DLL	
GetUserDllVersion	153	CheckIs_G3	182
InitCan	160	CheckIs_G4	182
InitHardware	158	CheckIs_sysWORXX	181
ReadCanMsg	167	CheckSupportCyclicMsg	183
		CheckSupportRbCanPort	185
		CheckSupportRbUserPort	185
		CheckSupportTermResistor	184
		CheckSupportTwoChannel	183
		CheckSupportUcannet	186
		CheckSupportUserPort	184
		ConvertToMajorVer	180
		ConvertToMinorVer	180
		ConvertToReleaseVer	181
		DefineCyclicCanMsg	174
		EnableCyclicCanMsg	176
		EnumerateHardware	154
		GetBaudrateExMessage	179
		GetBaudrateMessage	178
		GetCanErrorCounter	172
		GetCanStatusMessage	177

GetMsgPending	171	USBCAN-library	
ReadCyclicCanMsg	175	tCanMsgStruct	94, 100
SetTxTimeout	173	tStatusStruct	86
Hot Plug-and-Play	3	tUcanChannelInfo	82
Installation	12, 196	tUcanHardwareInfo	79
Introduction	3	tUcanHardwareInfoEx	81
IP65	40	tUcanHardwareInitInfo	149
Jumper	10	tUcanInitCanParam	69
LabView	11	tUcanMsgCountInfo	84
LED	10	Technical Data	10
LIB	45	termination resistor	17, 30, 34
Macro		Traffic-LED	27
USBCAN-library		transmit echo	70
USBCAN_CHECK_SUPPORT_CYCLIC_MSG	82	Type A Plug	3
USBCAN_CHECK_SUPPORT_RBCAN_PORT	83	Type B Plug	3
USBCAN_CHECK_SUPPORT_RBUSER_PORT	83	UCANNET.SYS	26
USBCAN_CHECK_SUPPORT_TERM_RESISTOR	83	USB	3
USBCAN_CHECK_SUPPORT_TWO_CHANNEL	83	USB Connectors	3
USBCAN_CHECK_SUPPORT_USER_PORT	83	USBCAN32.DLL	45
Multiport CAN-to-USB	4, 35, 37, 141	USBCANDRV.DLL	196
network driver	26	USBCAN-library	45, 197
Order Options	35	USBCANLS.H	111
PCANView	18, 43	USB-CANmodul Control	42
Scope of Delivery	11	USB-CANmodul1	5, 35
Serial Number	79	USB-CANmodul16	6
Software	11, 41, 196	USB-CANmodul2	5, 35, 36, 141
Software state		USB-CANmodul2 IP65	40
CAN_INIT	45	USB-CANmodul8	6
DLL_INIT	45	USBCANUP.H	116
HW_INIT	45	Windows CE	196
Status-LED	27		
Structure			

Document:	USB-CANmodul
Document number:	L-487e_29, Edition February 2015

How would you improve this manual?

Did you find any mistakes in this manual? _____ page

Submitted by:

Customer number: _____

Name: _____

Company: _____

Address: _____

Return to: SYS TEC electronic GmbH
 Am Windrad 2
 D-08468 Heinsdorfergrund, Germany
 Fax : +49 (0) 3765 38600 4100