Automation Direct

CHAPTER 1

GETTING STARTED

In This Chapter...

Overview of this Publication

Thank you for purchasing an AutomationDirect CTT Series Digital Counter / Timer / Tach. This manual shows you how to install, program and maintain the unit.

Who Should Read This Manual

This manual contains important information for those who will install, maintain, and/or operate the AutomationDirect CTT Series Digital Counter / Timer / Tach. It will provide the information you need to get and keep your system up and running.

Technical Support

On the Web: support.automationdirect.com

Our technical support group is glad to work with you in answering your questions. If you cannot find the solution to your particular situation, or, if for any reason you need additional technical assistance, please call technical support at 770-844-4200. We are available weekdays from 9:00 a.m. to 6:00 p.m. Eastern Time.

We strive to make our manuals the best in the industry. We rely on your feedback to let us know if we are reaching our goal.

We also encourage you to visit our web site where you can find technical and non-technical information about our products and our company. Visit us at www.automationdirect.com.

Special Symbols



When you see the "exclamation mark" icon in the left-hand margin, the paragraph to its immediate right will be a warning. This information could prevent injury, loss of property, or even death (in extreme cases).



General Description

The CTT series is an extremely versatile multi-function device that is easily configured for operation as a digital counter, timer, combination timer + counter, or tachometer. Both voltage and non-voltage inputs are accepted from a wide variety of sensor types with NPN, PNP, or dry contact outputs. The first output on the CTT is a single-pole, single-throw relay and NPN transistor that operate concurrently. The second CTT output can be ordered as either a single-pole, double throw relay or NPN transistor. Parameters are easily set using the externally accessible DIP switches or the lockable keypad. The double-line, 6-digit, two-color LCD display shows the counter, timer, or tachometer present values, setting values and menu parameters during set-up. Additional individual indicators are provided for inputs, outputs and functions. The standard 1/16 DIN size, included panel mounting clip and gasket make panel mounting a snap. The CTT is available in 120-240VAC and 24VDC powered models.

Counter Functions	Counter Input Modes	Counter Output Modes	
1-Stage	Up	Select from eleven (11) different	
2-Stage	Down	output modes (F, N, C, R, K, P, Q, A, S, T, D)	
Batch	Up / Command Down		
Total	Up/ Down		
Dual	Quadrature		
	Addition		
	Subtraction		

Timer Functions (Up or Down)		
Signal On Delay 1	Repeat Cycle	
Signal On Delay 2	Repeat Cycle Hold	
Signal Off Delay	Repeat Cycle 2	
Signal On	Signal Cumulate	
Power On Delay	Signal Twin On-Start	
Power On Delay Hold	Signal Twin Off-Start	

Timer + Counter				
Timer Functions (Up or Down)	Counter Input Modes	Counter Output Modes		
Signal On Delay 1	Up	Select from eight (8) different out-		
Signal On Delay 2	Down	put modes (F, N, C, R, K, P, Q, A)		
Signal Off Delay				
Signal On				
Power On Delay				
Power On Delay Hold				
Repeat Cycle				
Repeat Cycle Hold				

Tachometer Output Modes

Select from four (4) different output modes 2Lo/1Lo 2Lo/1Hi 2Hi/1Lo 2Hi/1Hi

Features

- -Can operate as a digital counter, timer, combination timer + counter or tachometer
- -Accepts voltage and non-voltage inputs from a wide variety of NPN, PNP, or dry contact sensors
- -Selectable counting speeds from 1 to 10,000 cycles per second
- -Multiple transistor and relay outputs can operate as momentary or maintained
- -Double-line, 6-digit, 2-color LCD display
- -Easy configuration with externally accessible DIP switches or the lockable keypad
- -Display decimal point selection
- Available in 120-240VAC and 24VDC powered models
- -UL508 listed, CE marked

Unpacking

After receiving the CTT Counter/Timer/Tach, please check for the following:

- Make sure that the package includes the CTT Counter/Timer/Tachometer, the mounting bracket and hardware, and the Quick Start Guide.
- Inspect the unit to insure it was not damaged during shipment.
- Make sure that the part number indicated on the label corresponds with the part number of your order.

Model Number Explanation





Label Information





Display, Indicators and Keys



	LCD Disp	play and Ind	icators
RST 1/2	Light on when reset signal is detected	BATCH	"Batch Counting Mode" in Counter
K/P 1/2	Light on when key-protected mode is enabled	SET 1 2	SV1, SV2 display
OUT 1/2	Light on when output is executing	TAC	Light on in Tachometer function
HMS	Hour, minute, second, unit of timer, displayed in Timer function	CNT	Light on in Counter function
TOTAL	"Total Counting Mode" in Counter function	TMR	Light on in Timer function
	Ke	ey Operatio	1
	Increase and decrease SV or change paramter settings		
	Left move 1 digit of the selected digit. The indicator of the selected digit will flash.		
MODE	Save the set parameters or switch among functions.		
LOCK	Prevent settings from being changed. Key-protected mode still works after the power is switched off. Press LOCK to enter key-protected mode. In non-key-protected status, press LOCK to enter Lock 1, press LOCK again to enter Lock 2. Press to a and the same time to disable key-protected mode. In non-key-protected status, ables the functions of all keys. Lock 2) allows users to change SV and functions of RESET remain. LOCK only functions in non-key-protected status.		
RESET	Clear and reset PV.		
	Modes: Operation N	Node and C	onfiguration Mode
Operation	When the power is on, the timer/counter/lachometer is in the operation mode. Press T to change SV, or to select digit to change. The indicator of the selected digit will flash. After the change is made, press to save the setting. If SV or parameters are not changed, press once to switch between SET1 and SET2.		
Configuration	Press Mode in operation mode for more than 3 seconds to enter configuration mode. Press Mode once to switch among parameters. To return to operation mode, press		

General Specifications

Digital Counter / Timer / Tachometer General Specifications					
Input Power Requiremen	ts	100 to 240 VAC 50/60 Hz 24 VDC			
Operation Voltage Range		85 to 264 VAC	21.6 to 26.4 VDC		
Power Consumption		Less that	n 10VA		
Power Source		12VDC ±10%, 100mA			
Display	Double-line, 6-digit LCD display (SV = 8mm, PV = 6mm)		olay (SV = 8mm, PV = 6mm)		
Input Signal		NPN ON impedance 1K ohm max. ON residual voltage: 2V max. PNP 4.5 to 30VDC, low level: 0 to 2VDC			
Output 1		Relay: SPST max. 250VAC, 5A (resistive load), 4A (inductive load); Transistor: NPN open collector. When 100m/ 30VDC, residual voltage = 1.5VDC max			
Autout 2	CTT-1C-xxx	Relay: SPDT max. 250VAC, 5A (resistive load), 4A (inductive load)			
Output 2	CTT-AN-xxx	Transistor: NPN open collector. When 100m/	@ 30VDC, residual voltage = 1.5VDC max		
Output Switching Time		2 milliseconds max			
Dielectric Strength		2000VAC 50/60Hz for 1 minute			
Vibration Resistance		Without damage: 10 ~ 55Hz, amplitude = 0.75mm, 3 axes for 2 hours			
Shock Resistance	Without damage: drop 4 times, 300m/s ² 3 edges, 6 surfaces and 1 corner		/s ² 3 edges, 6 surfaces and 1 corner		
Ambient Temperature		+32°F to +122°F (0°C to +50°C)			
Storage Temperature		-4°F to +149°F (-20°C to +65°C)			
Altitude		2000m or less			
IP Rating		IP 66 (with proper enclosure installation)			
Case Materials		Case = ABS Plastic, Lens = Polycarbonate			
Ambient Humidity		35% to 85% RH (non-condensing)			
Memory Backup upon Po	nory Backup upon Power Failure EEPROM writing up to 100,000 times; Memory duration: 10 years		mes; Memory duration: 10 years		
Terminals	Conforming Wiring	0.25-1.65mm ² (24 to 16 AWG)			
	Permitted Torque	0.5Nm (0.369 ft/lbs)			
Agency Approvals	Approvals UL508 listed (E311366), cULus, CE marked		6), cULus, CE marked		



Drawings mm [inches]



Terminal Layout

CTT-1C-D24	CTT-AN-D24	CTT-1C-A120	<u>CTT-AN-A120</u>
HORE BOARD AND A CONTRACT AND A CONT	CPI GATE LOAD NO. STREET COAD OF THE COAD	CPI CARE LOAD 'NO. CPI CARE LOAD 'NO. CPI START COMPANY START START OF COMPANY START OF COM	UND CP1 CP2/ DAD 1 N.O. CP1 GATE LOAD 1 N.O
N.O. N.C. COM 0.UT 2. 3 4 5 0.UT 2.6.10 26.4VDC	$ \begin{array}{c} 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 $	N.O. U.C. OUT 2 AC100 to 240V S0/60Hz	OV O O O O O O O O O O O O O