

NEC

Business Mobility (IP) DECT

DECT G266 and G566 Handsets

Basic User Guide



Date: February 2013

Great care has been taken to ensure that the information contained in this handbook is accurate and complete. Should any errors or omissions be discovered or should any user wish to make a suggestion for improving this handbook, they are invited to send the relevant details to:

**NEC Nederland B.V.
P.O. BOX 32
1200 JD HILVERSUM
THE NETHERLANDS**

© NEC Nederland B.V. 2013

All rights are reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner. All brand names and product names in this document are trademarks or registered trademarks of their respective companies.

Disclaimer

NEC reserves the right to revise or make changes or improvements to the products described in the user manual or to this user manual itself at any time without obligation to notify any person of such revision or improvements.

The pictures, icons, screen shots and diagrams used in this user manual have been derived from the G566 DECT Handset and might be slightly different for the G255 DECT Handset.

Revision history

February, 2013

Creation of this Basic User Manual.

Contents

Disclaimer	3
Revision history.....	4
Contents	5
Introduction.....	10
Notice on the use of the handsets.....	10
Getting started	11
Installing the battery pack	11
Installing the charger.....	11
Charging the batteries.....	12
Charging a spare battery.....	12
Charging guidelines.....	12
Charging and operating times	12
Charge display	13
Handset keys and display areas	14
Handset keys.....	15
Display.....	17
Icon line	18
Time & Date area	18
Dialogue area	19
<i>Idle mode</i>	19
<i>Call mode</i>	19
<i>Dialogue mode</i>	20
<i>Menu mode</i>	21
<i>Edit mode</i>	21
Soft key line	23
Used notation in this manual	24
General functions	27
Switching the handset on	27
Switching the handset off	27
Key lock	27
Locking or Unlocking	27
Call features	28

Contents

Make a call	28
Dialling a number	28
Using Predial mode	28
Using Central or Private Directory.....	28
Using Speed dial	29
Making an SOS call.....	29
Answering a call	29
Answering a call in Normal mode.....	29
Answering a call using any key.....	29
Auto-answering mode	29
Muting the ringer of an incoming call	29
Rejecting an incoming call	29
Change settings during a call	30
Adjusting the headset or loudspeaker volume	30
Using mute during a call.....	30
<i>Deactivate the microphone (mute)</i>	30
<i>Activate the microphone (unmute)</i>	30
Activate and deactivate the loudspeaker (toggle function)	30
Transferring a call	30
Dialling second destination then transfer	30
Using Private or Central Directory then transfer	31
Shuttle the call	31
Calls list.....	32
Actions on the calls lists	33
Open Calls list	33
Checking the details of a call	33
Dialling the number of the call list entry	33
First edit then dial the number of the call list entry.....	34
Transferring a name/number to your contacts list.....	34
Add a number to an existing contact.....	36
Transferring a number to the caller filter list.....	37
Deleting an entry	37
Missed calls list entries will also be deleted from the list if:	38
Deleting all entries.....	38
Contacts	39
Adding a new contact	39
Changing information of a contact	40
Deleting a contact.....	40
Deleting all contacts	41

Contents

Speed dial feature	41
<i>Adding, replacing or deleting a speed dial contact</i>	42
Adding contact to the caller filter list.....	43
Messaging	44
Normal, urgent and emergency messages	44
Normal messages	44
Urgent messages	44
Emergency messages.....	44
Confirming receipts	45
Message list full.....	45
Message Menu Sections.....	45
Open Message menu section	46
Actions on the messages	46
Reading a message	46
Writing and saving a new/draft message	47
Writing and sending a new/draft message.....	47
Forwarding a message.....	50
Replying to an incoming message	50
Deleting a message.....	51
Deleting all messages	51
Saving sender to the contacts list	52
Add sender to existing contact	52
Message settings	52
Calendar	54
Open the Calendar	54
Changing the calendar format (week or month view)	54
Open schedule for today	54
Open schedule for a given date	54
Adding an appointment	55
Open appointment.....	57
Editing an appointment	57
Copying an appointment	58
Deleting an appointment	58
Additional features (Accessories).....	59
Calculator.....	59
Stopwatch	60
Alarms (alarm clock)	61
Open Alarms	61
Assigning or change a daily alarm	61

Contents

Turning off a daily alarm.....	61
Assigning or change a recurrent alarm	62
Turning off a recurrent alarm.....	62
Setting snooze time.....	63
Telephone settings	64
Open Settings menu section	64
General settings	65
Setting Silent	66
Setting the time and date	66
<i>Setting the time</i>	66
<i>Setting the date</i>	67
Setting the language	68
Configuring shortcuts	68
Configuring the LED signal	69
Security options	70
<i>Setting the Phone lock feature</i>	70
<i>Setting the Automatic keypad lock feature</i>	71
<i>Changing the PIN code</i>	71
<i>Changing the Proxy password</i>	72
Defining the handset name	73
Resetting settings.....	73
View status information	74
Sounds (normal & silent) settings.....	75
Incoming call	77
<i>Setting the ring volume</i>	77
<i>Setting the ring melodies</i>	77
<i>Setting the increasing ring feature</i>	78
<i>Setting the vibrator feature</i>	78
Message notifications.....	79
<i>Setting the notification volume</i>	79
<i>Setting the notification melodies</i>	80
<i>Setting the increasing notification feature</i>	80
<i>Setting the vibrator feature</i>	81
Alerts	82
<i>Setting the alert volume</i>	82
<i>Setting the alert melody</i>	82
<i>Setting the increasing alert feature</i>	83
<i>Setting the vibrator feature</i>	83
Feedback.....	84
<i>Setting the key sound feature</i>	84
<i>Setting confirmation sound</i>	84
<i>Setting the coverage warning feature</i>	85
<i>Setting the charger warning feature</i>	85

Contents

Display settings	86
Selecting Wallpaper	86
Selecting startup screen.....	87
Configuring power save	87
Calls settings.....	89
View statistics information	90
Answer mode configuration.....	90
Caller filter configuration	91
<i>Adding an entry to the Caller filter list.....</i>	91
<i>Changing a Caller filter entry.....</i>	93
<i>Deleting an entry from the Caller filter list.....</i>	94
<i>Deleting all entries in the Caller filter list.....</i>	94
<i>Activating Caller filter.....</i>	95
Configuring emergency or SOS calls	96
<i>Assigning emergency call number.....</i>	96
<i>Assigning an emergency message.....</i>	98
Assigning the Silent charging feature.....	98
Defining the missed call time	99
Voicemail	99
Assigning the Voicemail number.....	100
Connectivity settings	101
DECT system selection	101

Introduction

Also refer to the following document:

- General DECT Handset Information Guide

Notice on the use of the handsets

Like all cordless telephones, the G266 and G566 DECT handsets use radio signals, which do not guarantee a connection under all circumstances. Do not rely exclusively on the DECT handsets when making indispensable calls (such as medical emergencies).

SOS function

The SOS function of the G266 and G566 does not replace companion supervision by a colleague or other people. In case of critical, emergency or life-threatening situations make sure that other persons are present or that appropriate measures are taken.

Getting started

Installing the battery pack

1. Place the handset face down on a flat surface.
2. Pull the lock at the bottom of the battery compartment cover upward and at the same time shift the cover downwards.
3. Remove the battery compartment cover.
4. Push the battery pack into the casing.
5. Replace the battery cover.

Installing the charger

1. Place the charger on a flat surface.
2. Connect the micro-B USB connector of the USB cable to (the back of) the charger.
3. Connect the type A USB connector to the USB AC/DC Adapter.
4. Connect the adapter to an electrical outlet.
5. Place the handset on the charger as shown in [Figure 1](#).



Figure 1: G566d, G566s and G266 in Desktop Charger

Charging the batteries

Place the handset in the charger as shown in [Figure 1](#). For a few seconds the display of the handset shows:




Figure 2: Battery charging display

Attention:

The handset, if switched off, automatically switches on when placed in the charger.

Charging a spare battery

The Gx66 Desktop Charger can be used to charge a spare battery pack for the G266/G566. To charge a spare battery pack:

1. Place the spare battery pack in the spare battery charging slot compartment. (Upside down and text on the battery pack to the front.)
2. Slid the spare battery pack under the metal rim to keep it in place.

Charging guidelines

Please read the concerning section in the DECT Handsets – General Information Guide carefully!

Charging and operating times

Discharged batteries require 7 hours (using the spare battery slot might take longer) to completely recharge. Completely charged batteries provide the handset with up to 20 hours of talk time and 160 hours of standby time.

Charge display

The battery charge status appears on the top of the display screen:

Table 1: Battery charge status icons

Icon	Charge status
	Almost empty
	Less than 10%
	10% to 20%
	20% to 90% (the bigger the green bar, the higher the charged percentage)
	Fully charged (more than 90%)

When the battery is nearly discharged a warning beep sounds and, when not in a call, the display shows:




Figure 3: Battery low display

You cannot make calls while this message appears.

Getting started

Handset keys and display areas



Figure 4: Elements of the G266



Figure 5: Elements of the G566

Handset keys

Table 2: Keys of the Handset

Key	Description
LEFT SOFT KEY	 Key related to the action given on the bottom left of the display.
MIDDLE SOFT KEY	 Key related to the action given on the bottom middle of the display.
RIGHT SOFT KEY	 Key related to the action given on the bottom right of the display.
UP	 Use the navigation keys to: <ul style="list-style-type: none"> — Select the required menu icon or menu element; — Navigate the cursor; — In some cases change (increase/decrease) a given value; — Access the shortcut assigned to it.
DOWN	
LEFT	
RIGHT	
OK	 Used to acknowledge menu selection.
CALL	 Used to go off hook and to initiate enquiry/hold/shuttle.
CLR	 Use the Clear key to <ul style="list-style-type: none"> — Release a call;

Getting started

Table 2: Keys of the Handset

Key	Description
	<ul style="list-style-type: none">— Return to the previous step in a menu;— Switch your handset off (long press)— Switch your handset on.
SOS	 Long press the SOS key to make an emergency call (if configured).
VOLUME UP	 To increase the handset volume.
VOLUME DOWN	 Decrease the handset volume.
1–9	 Use 1 – 9 to <ul style="list-style-type: none">— Insert a digit in a number;— Insert a character;— Select a Speed dial number
0	 Use 0 to <ul style="list-style-type: none">— Insert a 0 in a number;— Insert a character.
*	 Use * to <ul style="list-style-type: none">— Insert a * in a number;— Insert a character— Insert a decimal point (Calculator feature).

Table 2: Keys of the Handset

Key		Description
#		Use # to <ul style="list-style-type: none"> — Insert a # in a number; — Switch between Normal and Silent (sounds & alerts) settings by long pressing (more than 2 seconds) the key. — Toggle the character case (capital, lower case or digit) when in edit mode.
LINE KEY		Only for the G566 Use one of the four Line keys to <ul style="list-style-type: none"> — Select a Speed dial number — Access the shortcut assigned to it.

Display

Figure 6 shows the four areas of the display:

- Icon line
- Time & Date area
- Dialogue area
- Soft key line




Figure 6: Display screen

Getting started

Icon line

The icon line displays the status of the handset.

Table 3: Icon line icons

Icon	Description
	Level of radio signal (always shown)
	New text message received
	Voice message waiting indication
	Keypad locked
	Alarm set
	Missed calls
	Ringer deactivated
	Caller filter active (only for G566 DECT Handset)
	Battery charge status Refer to Table 1 for Battery status icons.

Time & Date area

The Time & Date area is only shown in the Idle mode and gives the current time and date. In any other mode this part of the display is added to the Dialogue area (see next).

Dialogue area

The Dialogue area displays information according to the operational mode of the handset:

Idle mode

In Idle mode, the dialogue area displays information like DECT system name, handset's DNR, and so on.




Figure 7: Idle mode screen

Call mode

In Call mode, the dialogue area displays information related to the call, like number and name of the calling/connected party and some status icons (see [Table 4](#) and [Table 5](#)).

Table 4: Call Set-up icons

Icon	Description
	Incoming call <i>One to three green “circles” intermittently shown</i>
	Outgoing call <i>One to three blue “circles” intermittently shown</i>

Getting started

Table 5: Call Conversation icons

Icon	Description
	Call in conversation <i>Call set-up by this phone</i>
	Call in conversation <i>Call set-up to this phone</i>
	Loudspeaker on
	Microphone muted while loudspeaker on
	Microphone muted while loudspeaker off

Dialogue mode

In Dialogue mode, the dialogue area displays dialogues regarding missed calls (see [Figure 8](#)), messaging, menu settings, warnings and so on (see for some examples).




Figure 8: Examples Dialogue mode

Menu mode

In Menu mode, the dialogue area displays the menu icons or menu sections (tabs) and the specific menu items. E.g., :




Figure 9: Main menu and General setting menu

Edit mode

In Edit mode, you can use the dialogue area to enter and edit digits (e.g., for numbers) and text, e.g., for contact information editing:




Figure 10: Contacts name and number editing

[Table 6](#) shows the key to press to insert letters, numbers or symbols.

Besides the physical keys also the **Symbol** soft key is used in the Edit mode to insert (symbol) characters.

Getting started

Table 6: key functions in text mode

Key	Uppercase	Lowercase
1	1 . ! ? , - " @ + : :	1 . ! ? , - " @ + : :
2	A B C 2 ÄÀÁÂÄ ÅÇ	a b c 2 æàáâäåç
3	D E F 3 ÈÉÊË	d e f 3 èéêë
4	G H I 4 ÍÎÏ	g h i 4 íîï
5	J K L 5	j k l 5
6	M N O 6 œÓÔÖØ	m n o 6 œóôöø
7	P Q R S 7 Šß	p q r s 7 šß
8	T U V 8 ÙÚÛÜ	t u v 8 ùúûü
9	W X Y Z 9 ŸŽ	w x y z 9 ŸŽ
0	(space) 0	(space) 0
*	*	*
#	Toggle character case: Abc → ABC → abc → 123	
Symbol	., ` ? ! " - () @ / : _ ; + & % * = < > £ (space) \$ ¥ ¤ [] { } \ ~ ^ ¡ § ¡ # ¡ ¡	

Soft key line

Soft keys appear below the handset dialogue area. The key functions change automatically according to the operational state of the handset.

Getting started

Used notation in this manual



Main menu icons are used to indicate selection of the appropriate menu.

To select the appropriate main menu item use the **NAVIGATION** keys.



Off-white box with text indicates a selected menu item.

To select the appropriate menu item use the **UP** and/or **DOWN NAVIGATION** key.




White box with dark blue top containing text indicates some text or number needs to be given.

To supply the necessary information use the keypad and the **NAVIGATION** keys.



Dark box with question mark indicates a question that the user needs to answer to.

To supply the answer use the appropriate soft key.



Press the indicated key.



The blue box with text indicates a soft key.



The three icons are special soft keys (available in the idle state).

Select the appropriate soft key to execute the indicated action:



Left soft key



Middle soft key



Right soft key



Use the keypad and/or the **NAVIGATION** keys to enter or change a number, date, name or text:

- Use the keypad to insert one or more digits (0 – 9, * and #) or characters
- To delete a digit or character use soft key **Clear**
- Use the Navigation keys to move the cursor to the insertion point
- Use the Up or Down Navigation key to increase or decrease the value of the selected field



Use (one of) the **NAVIGATION** keys



Use **LEFT** and/or **RIGHT** **NAVIGATION** key



Use **UP** and/or **DOWN** **NAVIGATION** key.

Getting started

[...]ⁿ Press (soft) key given between the brackets one or more times

Optional step(s): The following step(s) is (are) optional (and marked by a **blue** line), i.e.,

- they can be skipped by the user OR
- they are not offered to the user.

→ ①

Used when the following actions (steps) depend on some condition. The condition is preceding the arrow, and the next action to be taken is marked by the indicated number (here: ①).

All actions belonging to set of actions to be taken, are marked by an **orange** line at the beginning of the actions.

General functions

Switching the handset on

1.



1.



> 3s

2.

Yes

Key lock

Attention: You can dial 911 and 112 when the key lock is active.
The key lock does not affect the **SOS** key.

Locking or Unlocking

1.



2.



Also automatic keypad lock can be set from the Settings menu.

Call features

Make a call

Dialling a number

1. 
2.  Enter/edit: Number

Using Predial mode

1.  Enter/edit: Number
2. 

Using Central or Private Directory¹

1.  Or 

Optional step(s):

2.  Enter the first character(s) of the required name
3. 
4.  Select: required contact

Optional step(s):

5.  Select: appropriate number
6.  Or 

¹ Central Directory is only available if it is provided by your communication system

Using Speed dial

1. Long press
Or Long press

Making an SOS call

See also [Configuring emergency or SOS calls \(page 96\)](#).

- 1.

Answering a call

Answering a call in Normal mode

1. Loudspeaker off

Or

1. Loudspeaker on

Answering a call using any key

See also [Answer mode configuration \(page 90\)](#).

1. Loudspeaker off
 Or

Or

1. Loudspeaker on

Auto-answering mode

See also [Answer mode configuration \(page 90\)](#).

To answer an incoming call no manual action is required.

Muting the ringer of an incoming call

- 1.

Rejecting an incoming call

- 1.

Call features

Change settings during a call

Adjusting the headset or loudspeaker volume

Volume up:



Volume down:



Adjusted volume setting is saved for future calls.

Using mute during a call

Deactivate the microphone (mute)

- 1.

Activate the microphone (unmute)

- 1.

Activate and deactivate the loudspeaker (toggle function)

- 1.

Using the loudspeaker enhances the possibility that the speech is distorted. Therefore your DECT handset is no substitute for a conference device!

Transferring a call

Dialling second destination then transfer

- 1.

2. Enter/edit: Number

Optional step(s):

3. Await answer

- 4.

Using Private or Central Directory then transfer

1. 
2.  Contacts Or
Central directory
3.  **Select**

Optional step(s):

4.   Enter the first character(s) of the required name
5.  **OK**
6.  Select: required contact

Optional step(s):

7.  Select: appropriate number
8.  Or  **Call**

Optional step(s):

9.  Await answer
10. 


Shuttle the call

To alternate between the two parties (before transfer):

1. 

Calls list

Table 7: Call type icons and Call type tabs

		Call Type
Call List	Icon	Tab
All calls	-	 All calls
Answered calls		 Answered calls
Dialed calls		 Dialed calls
Missed call (unanswered or rejected)		 Missed calls (One combined list)
Missed call (Caller filter)		




Figure 11: Call lists


Actions on the calls lists

Open Calls list

1.



2.



Checking the details of a call

Open Calls list: Or Or Or

1.



Select: required entry

2.

View

3.



$[]^n$

Dialling the number of the call list entry

Open Calls list: Or Or Or

1.



Select: required entry

2.



Or



Calls list


First edit then dial the number of the call list entry

Open Calls list:  Or  Or  Or 

1.  Select: required entry
2.  **More**
3.  
Edit before call
4.  **Select**
5.   Enter/edit: Number
6.  **R** Or  **Call**

Transferring a name/number to your contacts list

Open Calls list:  Or  Or  Or 

1.  Select: required entry
2.  **More**
3.  
Save as contact
4.  **Select**

Optional step(s):

5.  
Name:
Jim Peters
6.  **Edit**
7.   Enter/edit: **Name**

8.

Save

Work:	
Mobile:	
Home:	
Other:	

9.

Add

Optional step(s):



Enter/edit: Number

10.

Save

Optional step(s):

11.



Ringtone:	
Default	

12.

Edit

<input checked="" type="radio"/> Default
<input type="radio"/> Melody 1
:
:
<input type="radio"/> Melody 20

13.

Select**Save**

Store current-item in local contacts?

Yes




14.

 $[]^n$

Calls list

Add a number to an existing contact

Open Calls list:  Or  Or  Or 


1.  Select: required entry
2.  **More**
3.  **Add to contact**
4.  **Select**
5.  Select: required contact
9.  
 - Work: 
 - Mobile: 
 - Home: 
 - Other: 
10.  **Add** Or **Replace**
11.   **Optional step(s):** Enter/edit: Number
12.  **Save**
17.  **Save**
18.  ?

Store current item in local contacts?

Yes
19.  $[\quad]^n$

Transferring a number to the caller filter list²

Open Calls list:  Or  Or  Or 

1.  Select: required entry
2.   
3. 
4. 

Optional step(s):

5.   Enter/edit: **Name**
6. 
7. 
8.  []ⁿ

Deleting an entry

Open Calls list:  Or  Or  Or 

1.  Select: required entry
2. 
3. 
4. 
5. 

² Only for the G566

Calls list

6. []ⁿ

Missed calls list entries will also be deleted from the list if:

- You answer a call from the to the entry related number (entry moved to the **Answered** calls list).
- You dial the to the entry related number (entry moved to the **Dialed** calls list).

Deleting all entries

Open Calls list:  Or  Or  Or 

1.  **More**
2.   **Delete all items**
3.  **Select**
4.  **Yes**
5. []ⁿ

Contacts

Adding a new contact

1.



2.

More

3.



Add contact

4.

Select

5.




Name:



6.

Edit

7.



8.

Save

9.



Work:	
Mobile:	
Home:	
Other:	

10.

Edit

11.



12.

Save

Contacts

Optional step(s):

13.



Ringtone:

Default

Melody 1

Melody 20

14.

Edit

15.



Default

Melody 1

:

:

Note: Currently set value is marked by a blue dot ()

16.

Select

17.

Save

18.



Store current item in local contacts?

Yes

19.



$[]^n$

Changing information of a contact

1.



2.



Select: required contact

3.

Edit

Continue as in [Adding a new contact \(page 39\)](#) from step 5.

Deleting a contact

1.




2.



Select: required contact

3.  More
4.  Delete contact
5.  Select
6.  Yes
7.  $[]^n$

Deleting all contacts

1. 
2.  More
3.  Delete all contacts
4.  Select
5.  Delete entire local contact list?
Yes
6.  Enter PIN

1	2	3
4	5	6
7	8	9
*	0	#
7.  OK
8.  $[]^n$

Speed dial feature

See also [Using Speed dial \(page 29\)](#).

Attention: Only the first number in the “chain” **Work**, **Mobile**, **Home** and **Other** assigned to the contact will be used by the **Speed dial** key.

Contacts

Adding, replacing or deleting a speed dial contact

1. 
2.  Select: required contact
3.  More
4.  Speed dial
5.  Select
6.  #: → ① add
#: John McLean → ② replace
→ ③ delete

① add

7.  Add
8. ]ⁿ

② replace


7.  Replace
8. ]ⁿ

③ delete

7.  Delete
8. ]ⁿ

³ # = 2 .. 9, L1, L2, L3 or L4

Adding contact to the caller filter list⁴

1. 
2. 
Select: required contact
3. 
More
4. 
Save in caller filter
5. 
Select
6. 
Store current item in caller
filter?
Yes
7.  []ⁿ

⁴ Only for the G566

Messaging⁵

Normal, urgent and emergency messages

The system differentiates between **Normal**, **Urgent** and **Emergency** messages.

Note: It is not possible to send an **Emergency** message from your DECT handset.

Normal messages

The melody assigned to **Notification normal** plays when you receive a normal message. If you receive a normal message during a call, a short alert tone sounds.

Urgent messages

The handset shows urgent messages immediately on the display.

The melody assigned to **Notification urgent** plays when you receive an urgent message. The ringer volume increases to the maximum during the signalling process. If you receive an urgent message during a call, a repeated short alert tone sounds.

Emergency messages

The handset shows emergency messages immediately on the display.

The melody assigned to **Notification emergency** plays when you receive an emergency message. The ringer volume increases to the maximum during the signalling process. If you receive an emergency message during a call, a repeated and in volume increasing short alert tone sounds.

⁵ Only for the G566

Confirming receipts

You must confirm the receipt of urgent and emergency messages. If you do not confirm the message within 60 seconds, the initiator receives a message that indicates the message was not delivered.

To confirm:

Positively:  Or 

Negatively:  Or 

Message list full



Attention:

If the display shows this warning no new message can be received. Delete some messages or change the **Overwrite old** setting to **On** – see [Message settings \(page 52\)](#).

Message Menu Sections

The **Messaging** menu contains a number of sections:

Table 8: Messaging Menu Sections

Description	Section
Drafts	 Drafts
Inbox	 Inbox
Sent messages	 Sent messages
Settings	 Settings

Messaging

Open Message menu section

1. 
2. 
3. **Select**
4.  =  **Drafts**
=  **Inbox**
=  **Sent messages**
=  **Settings**

Actions on the messages

Reading a message

Open Message menu section:   Or 

1.  Select: required message
2. **Select**
Optional step(s):
3.  Scroll the text
4.  []ⁿ

Writing and saving a new/draft message

Open Message menu section:

1.

New

Or

1a.



2.



1b.

Select



Select: required message

3.



4.



Yes

5.



Writing and sending a new/draft message

Open Message menu section:

1.

New

Or

1a.



Select: required message

2.



1b.

Select



3.

Send

4.



Normal

Urgent

5.

Select

Messaging

6.  Contacts → ①
Enter number → ②
Send to many → ③
Central directory → ④

① Contacts

7.  Select

8.  Select: required contact

9.  Send

Optional step(s):

10.  OK

11.  $[]^n$

② Enter number

7.  Select

8.  




9.  Send

Optional step(s):


10.  OK

11.  $[]^n$

③ Send to many



④ Central directory



Messaging

Forwarding a message

Open Message menu section:  Or 

1.  Select: required message
2. **Select**
3. **More**
4.  

Optional step(s):

5.   
6. Continue as in [Writing and sending a new/draft message \(page 47\)](#) from step 3.

Replies to an incoming message

Open Message menu section: 

1.  Select: required message
2. **Reply**
3.   
4. **Send**
5.   
6. **Select**

Optional step(s):

7.  **OK**

8.  **[]ⁿ**

Deleting a message

Open Message menu section:   Or 

1.  Select: required message

2.  **More**

4.  **Delete message**

5.  **Select**

6.  **Delete message?**

Yes

7.  **[]ⁿ**

Deleting all messages

Open Message menu section:   Or 

1.  **More**

2.  **Delete all messages**

3.  **Select**

4.  **Delete all messages?**

Messaging

Yes

5. []ⁿ

Saving sender to the contacts list

Open Message menu section:



1. 
Select: required message
2. **More**
4. 
Save as contact
5. **Select**
6. Continue as in [Transferring a name/number to your contacts list \(page 34\)](#) from step 5.

Add sender to existing contact

Open Message menu section:



1. 
Select: required message
2. **More**
3. 
Add to contact
4. **Select**
5. Continue as in [Add a number to an existing contact \(page 36\)](#) from step 5.

Message settings

The following messaging options can be configured to **On** or **Off**:

- **Overwrite old** to control what happens when the handset receives a new message, but there is no room to store more messages:
 - **On**: the oldest message stored on the phone is overwritten.
 - **Off**: new message is not stored. An **Urgent** or **Emergency** message is shown on the display; a **Normal** message is rejected.
- **Sent messages** to control whether sent messages are stored in the handset (**On**) or not (**Off**).
- **Display** to control whether **Normal** messages are displayed immediately upon receipt (**On**) or not (**Off**).
- **Auto answer msg** – Please contact your System Administrator
- **Silent answer msg** – Please contact your System Administrator

Open Message menu section:



1.



Or

Or

2.



3.



$[]^n$

Calendar⁶

Open the Calendar

1. 
2.  
3. **Select**

Changing the calendar format (week or month view)

Open the Calendar

1. **More**
2.  View week View month
3. **Select**
4. []ⁿ

Open schedule for today

Open the Calendar

1. **More**
2.  Go to today
3. **Select**
4. **View**

Open schedule for a given date

Open the Calendar

1. **More**

⁶ Only for the G566

2.  Go to date
3. Select
4.  
5. Select
6. View

Adding an appointment

Open the Calendar

1. Add
2.  
3. Save
4.  
5. Save
6. 

①

15 minutes

30 minutes

1 hour

2 hours

4 hours

Other

②

①

7. Select

Go to step 12.

Calendar

②

7.

Select

8.



9.

Save

10.



11.

Save

12.



13.

Save

14.



15.

Save

16.



- At start
- 5 minutes
- 10 minutes
- 15 minutes
- 30 minutes
- 1 hour
- Other

③

→ ④

③

17.

Select

18.



4

17.




18.



19.



20.



21.



22.

$$\left[\begin{array}{c} \text{Icon of a computer monitor with a red dot} \\ \text{Icon of a power outlet} \end{array} \right]^n$$

Open appointment

Note: Days with appointments will be marked with a red dot at the bottom right of the date.

Open the day/date of the appointment using [Open schedule for today](#)/[Open schedule for a given date](#)

1.



Select: required appointment

2.

View

Editing an appointment

Open appointment

1.

Edit

2. Make the necessary changes like in [Adding an appointment \(page 55\)](#) from step 2.

Calendar


Copying an appointment

Open appointment

1.  More
2.  Copy
3.  Select
4. Make the necessary changes like in [Adding an appointment \(page 55\)](#) from step 2.

Deleting an appointment

Open appointment

1.  More
2.  Delete
3.  Select
4. 
Delete appointment
 Yes
5. ]ⁿ

Additional features (Accessories)⁷

Calculator

When the **Calculator** is selected the following holds:



used to insert a decimal point

used to make a percentage of the given entry

change the use of the **NAVIGATION** keys between:

- Mathematical operators
- Moving the cursor to the insertion point

- 1.
- 2.
- 3.
- 4.
- 5.
6.
Enter/edit: a value
- 7.
8.
Enter/edit: a value
9. calculate and show the result
10. $[]^n$

⁷ Only for the G566

Additional features (Accessories)

Stopwatch

1. 
2.  
3. 
4.  
5. 

Use of the stopwatch soft keys:

Table 9: Stopwatch soft keys

Soft key	Description
	Start a new measurement Or Continue a stopped measurement
	Halt the measurement
	Save the intermediate result and continue the measurement
	Reset the stopwatch (back to 0)

Alarms (alarm clock)

Open Alarms

- 1.
- 2.
- 3.
- 4.
- 5.

Assigning or change a daily alarm

Open Alarms

1.
Assign new
Change existing
- 2.
- 3.
- 4.
- 5.

Turning off a daily alarm

Open Alarms

- 1.
- 2.
- 3.

Additional features (Accessories)

4. []ⁿ

Assigning or change a recurrent alarm

Open Alarms

1.  Recurrent alarm
Off
Recurrent alarm
hh:mm
2. 
3.  
Save Turn off
4. 

For the required days of the week:

5.  Sunday
:
 Saturday
6.  Or 
7. 

Assign new
Change existing

Note: (Already) selected days are marked with

Turning off a recurrent alarm

Open Alarms

1.  Recurrent alarm
hh:mm
2. 
3. 
4. []ⁿ

Additional features (Accessories)

Setting snooze time

Open Alarms

1.



Snooze time
10 minutes

2.

Select

3.



1 minute
:
:
10 minutes

Note: Currently set value is marked by a blue dot (●)

4.

Select

5.

[]ⁿ


Telephone settings

The **Settings** menu contains a number of sections:

Table 10: Settings Menu Sections

Description	Section
General	 General
Sounds - normal	 Sounds - normal
Sounds - silent	 Sounds - silent
Display	 Display
Calls	 Calls
Connectivity	 Connectivity

Open Settings menu section

1. 
 2. 
 3. 
Select
 4. 
- | | | |
|---|---|---|
|  General | = |  |
|  Sounds - normal | = |  |
|  Sounds - silent | = |  |
|  Display | = |  |
|  Calls | = |  |
|  Connectivity | = |  |

General settings

Table 11: General setting

Item	Description	Page
 Silent	<ul style="list-style-type: none"> Switch to/from the silent “profile” 	66
 Time & date	<ul style="list-style-type: none"> Set the current Time & date 	66
 Language English	<ul style="list-style-type: none"> Set the Language 	68
 Shortcuts	<ul style="list-style-type: none"> Create Shortcuts to the handset menus and features (by pressing a navigation key) 	68
 LED signal	<ul style="list-style-type: none"> Assign a certain condition to one of the three LEDs 	69
 Security	<ul style="list-style-type: none"> Set the security settings: Phone lock, Automatic keylock, PIN Code and Proxy password 	70
 Handset name Empty	<ul style="list-style-type: none"> Set the Handset name 	73
 Reset settings	<ul style="list-style-type: none"> Return settings to the factory values. Not affected are: Contacts, PIN Code, Proxy password and the system registrations 	73
 Status	<ul style="list-style-type: none"> View handset information 	74

Telephone settings

Setting Silent

If **Silent** is **On** the handset uses the sound definitions set with the **Sounds - silent** settings, otherwise it uses the **Sounds - normal** settings.

Open Settings menu section:



- 1.
2. Or
- 3.

Quickly toggle **Silent** setting:

1. Long press

Setting the time and date

Note: If your communication system provides the date and time, then setting the date and time has only a temporary effect and will, in due time, revert to the by the system provided time and date.

Setting the time

Open Settings menu section:



- 1.
- 2.
- 3.
- 4.

Telephone settings




Optional step(s):

6. **Format**
7. 
8. **Select**
9. **Save**
10.  $[]^n$

Note: Currently set value is marked by a blue dot (●)

Setting the date

Open Settings menu section: 



Optional step(s):

6. **Format**
7. 

Note: Currently set value is marked by a blue dot (●)

Telephone settings

8. |  **Select**
9.  **Save**
10. []ⁿ

Setting the language

Open Settings menu section:



1.  
2.  **Select**
3.  : 
: 
4.  **Select**
5. []ⁿ

Note: Currently set value is marked by a blue dot (●)

Configuring shortcuts⁸

Shortcuts are used to get quick access to menu items.

Open Settings menu section:



1.  
2.  **Select**
3.  : 
: 

⁸ Only for the G566

Telephone settings

4. **Select**

5.



: None
: Alarms

Note: Currently set value is marked by a blue dot ()

6. **Select**

7. []ⁿ

Configuring the LED signal

The **Red LED**, **Green LED** and **Yellow LED** can be used to indicate certain conditions to the user:

- **Missed call**
- **Text message**
- **Voice message**
- **Text or voice msg**
- **Low battery**
- **Charging**
- **Silent charging**

Open Settings menu section:



1.



LED signal

2. **Select**

3.



Red LED
 Green LED Charging
 Yellow LED Low battery

4. **Select**

Telephone settings

5.



- Off
- Missed call
- :
- :
- Silent charging

Note: Currently set value is marked by a blue dot (●)

6.

Select

7.

$$\left[\begin{array}{c} \text{Icon of a handset with a red dot} \\ \end{array} \right]^n$$

Security options

Setting the Phone lock feature

If the **Phone lock** is set then upon turning on your handset you'll be asked to enter the **PIN Code**.

Open Settings menu section:



1.



- Security

2.

Select

3.



- Phone lock
- ...

4.

Select


5.



6.

OK

7.



- Off
- On

Note: Currently set value is marked by a blue dot (●)

8.

Select

9.

$$\left[\begin{array}{c} \text{Icon of a handset with a red dot} \\ \end{array} \right]^n$$

Telephone settings

Setting the Automatic keypad lock feature

Open Settings menu section:



- 1.
2. **Select**
3. **Automatic keylock**
....
4. **Select**
5.

:
6. **Select**
7. []ⁿ

Note: Currently set value is marked by a blue dot (●)

Changing the PIN code

Open Settings menu section:



- 1.
2. **Select**
3. **Change PIN code**
4. **Select**
- 5.
6. **OK**

Telephone settings

7.  

8. 
 

9. 
 

10. 



Changing the Proxy password

Change the **Proxy password** that is used at SIP authentication.

Open Settings menu section:



1. 

2. 


3. 


4. 


Optional step(s):

5.  

6. 
 

7. 


8. 


Telephone settings

9.  
10. 
11.  $[]^n$

Defining the handset name

Open Settings menu section:




1.  
2. 
3.  
4. 
5.  $[]^n$

Resetting settings

All user determined **Settings** are set to the default factory values!

Open Settings menu section:



1.  
2. 
3.  
4. 

Telephone settings

- 5.
- 



6. **OK**

7.  $[]^n$

View status information

Open Settings menu section:



1. 



2. **Select**

3. 



Note: In reality divided over
three screens

4. **OK**

5.  $[]^n$

Sounds (normal & silent) settings

Table 12: Sounds settings

Item	Description	Page
 Incoming call	<p>Sound settings related to an Incoming call:</p> <ul style="list-style-type: none"> • Ring volume • Ring external melody for calls from an external source • Ring internal melody for calls from an internal source • Ring unknown call melody for calls from an unknown source • Increasing ring to determine whether the Ring volume increases gradually • Vibrator to define the trembler feature for calls 	77
 Message notification	<p>Sound settings related to an incoming message⁹:</p> <ul style="list-style-type: none"> • Notification volume • Notification normal melody for Normal messages • Notification urgent melody for Urgent messages • Notification emergency melody for Emergency messages • Increasing notification to determine whether the Notification volume increases 	79

⁹ Only for the G566

Telephone settings

Table 12: Sounds settings

Item	Description	Page
	<p>gradually</p> <ul style="list-style-type: none">• Vibrator to define the trembler feature for messages	
 Alerts	<p>Sound settings related to Alerts (for Calendar and Alarms)¹⁰:</p> <ul style="list-style-type: none">• Alert volume• Alert melody• Increasing alert to determine whether the Alert volume increases gradually• Vibrator to define the trembler feature for Alerts	82
 Feedback	<p>Sound settings related to:</p> <ul style="list-style-type: none">• Key sound for the sound that occurs when you press a key• Confirmation sound for the sound that indicates successful setting• Coverage warning to define whether or not a sound is given when the handset moves out of the coverage area• Charger warning to define whether or not a sound is given when the handset is put on the charger	84


¹⁰ Only for the G566

Telephone settings

Incoming call

Setting the ring volume


Open Settings menu section:



Or




1.




2.

Select



3.

Select



Or

4.



5.

6.


OK

7.



Setting the ring melodies

Open Settings menu section:



Or




1.




2.

Select



Or



Or




4.

Select

Telephone settings

5.



Note: Currently set value is marked by a blue dot (●)

Optional step(s):

6.

Play

7.

Stop

8.

Select

9.



Setting the increasing ring feature

Open Settings menu section:



Or



1.



2.

Select

3.



4.

Off

Or

On

5.



Setting the vibrator feature

Open Settings menu section:



Or



1.



2.

Select


3.  
4. **Select**
5.  
6. **Select**
7.  $[]^n$

Note: Currently set value is marked by a blue dot (●)

Message notifications¹¹

Setting the notification volume

Open Settings menu section:



Or



1.  
2. **Select**
3.  
4. **Select**
5.  Or  
6. **OK**


¹¹ Only for the G566

Telephone settings

7. []ⁿ

Setting the notification melodies


Open Settings menu section:



Or



1.



 Message notification

2.

Select

3.



-  Notification normal
Melody n
-  Notification urgent
Melody n
-  Notification emergency
Melody n

Or

Or

4.

Select

5.



 Melody 1 :
: Melody 20

Note: Currently set value is marked by a blue dot ()

Optional step(s):

6.

Play

7.

Stop

8.

Select

9.

[]ⁿ

Setting the increasing notification feature

Open Settings menu section:



Or



1.




 Message notification

2.


Select

Telephone settings

3.  
4.  Or 
5.  $[]^n$

Setting the vibrator feature

Open Settings menu section:  Or 

1.  
2. 
3.  
4. 
5.  

Note: Currently set value is marked by a blue dot (●)


<input checked="" type="radio"/> Off
<input type="radio"/> Vibrate then ring
<input type="radio"/> Vibrate only
<input type="radio"/> Vibrate and ring
6. 
7.  $[]^n$

Telephone settings

Alerts¹²

Setting the alert volume

Open Settings menu section:



Or




1.



2.

Select



3.

Select



Or

4.



5.

OK

6.




7.



$[\quad]^n$

Setting the alert melody

Open Settings menu section:



Or




1.



2.

Select




3.

Select

¹² Only for the G566

Telephone settings

5.



Note: Currently set value is marked by a blue dot (●)

Optional step(s):

6.

Play

7.

Stop

8.

Select

9.



$[\quad]^n$

Setting the increasing alert feature

Open Settings menu section:



Or



1.



2.

Select

3.



4.

Off

Or

On

5.



$[\quad]^n$

Setting the vibrator feature

Open Settings menu section:



Or



1.



2.

Select

Telephone settings

3.  
4. **Select**
5.  
 - Off
 - Vibrate then ring
 - Vibrate only
 - Vibrate and ring
6. **Select**
7.  $[]^n$


Note: Currently set value is marked by a blue dot (●)

Feedback

Setting the key sound feature

Open Settings menu section:



1.  
2. **Select**
3.  
 - Silent
 - Click
 - Tone
4. **Select**
5.  $[]^n$

Note: Currently set value is marked by a blue dot (●)

Setting confirmation sound

Open Settings menu section:



1.  

Telephone settings

2. **Select**
3.  
4. **Off** Or **On**
5.  $[]^n$

Setting the coverage warning feature

Open Settings menu section:  Or 

1.  
2. **Select**
3.  
4. **Off** Or **On**
5.  $[]^n$

Setting the charger warning feature

Open Settings menu section:  Or 

1.  
2. **Select**
3.  
4. **Off** Or **On**

Telephone settings

5. []ⁿ

Display settings

Table 13: Display settings

Item	Description	Page
 Wallpaper	<ul style="list-style-type: none">Select the image that is displayed on the screen of your handset in the idle state	86
 Startup screen	<ul style="list-style-type: none">Select the startup screen image which displays temporarily when the handset starts	87
 Power save xx sec. / yy sec.	<ul style="list-style-type: none">Configure the periods of time after which the handset's display is dimmed and turned off	87

Selecting Wallpaper

For other **Wallpaper** than **Default**: Please contact your System Administrator

Open Settings menu section:



1.



2.

Select

3.



Note: Currently set value is marked by a blue dot (●)

Optional step(s):

4.  View
5.  Select
6.  Select
7.  []ⁿ

Selecting startup screen

For other **Startup screen** than **Default** or **NEC**: Please contact your System Administrator

Open Settings menu section:



1.  
 Startup screen
...
 2.  Select
 3.  
 Default
 NEC
- Note: Currently set value is marked by a blue dot (●)*

Optional step(s):

4.  View
5.  Select
6.  Select
7.  []ⁿ

Configuring power save

The display of your DECT Handset has three intensity levels:

- Display on;
- Display dimmed;
- Display off.

Telephone settings




Figure 12: Display intensity levels On, Dimmed and Off

The various levels are used to save energy and are applied based on the **Power save** setting.

Open Settings menu section:



1.



2.

Select

3.



To never turn off the display
set the second value to 0

4.

Save

5.




Calls settings

Table 14: Calls settings

Item	Description	Page
 Units h:mm:ss nn	<ul style="list-style-type: none"> View information regarding outgoing Call time and Message count. 	90
 Answer mode	<ul style="list-style-type: none"> Determine how incoming calls can be answered: <ul style="list-style-type: none"> Normal using  Or  By pressing Any key Automatically (Auto answer) 	90
 Caller filter	<ul style="list-style-type: none"> Selectively block or accept calls from specified callers. 	91
 Emergency Call	<ul style="list-style-type: none"> Configure the Emergency call feature to dial a number or send a text message by long pressing the SOS key. 	96
 Voicemail number Empty	<ul style="list-style-type: none"> Configure the Voicemail number 	100
 Silent charging	<ul style="list-style-type: none"> Determine what action is taken when the handset is called while in the charger. 	98

Telephone settings

Table 14: Calls settings

Item	Description	Page
 nn sec.	<ul style="list-style-type: none">Determine when a not answered call is added to the Missed calls list	

View statistics information

Open Settings menu section:



1. 
 2. 
 3. 
-  Units
h:mm:ss nn
-  Call time
h:mm:ss
-  Message count
nn
- Or

Optional step(s):

4. 
 5. 

Do you wish to clear the selected counter?


 6. 
- $[]^n$

Answer mode configuration

Open Settings menu section:



1. 
 2. 
-  Answer mode
....

Telephone settings

3.  Normal Any key Auto answer
4. **Select**
5.  $[]^n$

Or Note: Currently set value is marked by a blue dot ()
Or

Caller filter configuration¹³

Adding an entry to the Caller filter list

Open Settings menu section:



1.   ...
2. **Select**
3.  
4. **Select**
5. **Add**
6.  → ①
 → ②
 → ③


① Lookup contact

7. **Select**
8.  Select: required contact
9. **Select**

¹³ Only for the G566

Telephone settings

10.



Yes

11.



$[]^n$

②

Enter number

7.

Select


8.



9.

Save

10.



11.

Save

12.



Yes

13.



$[]^n$

③

Central directory

7.

Select

8.



Enter the first character(s) of the required name

9.

OK

10.



Select: required contact

11.  Select
12. 


Store current item in caller filter?

 Yes
13.  $[\quad]^n$

Changing a Caller filter entry

Open Settings menu section:



1. 
2.  Select
3. 
4.  Caller filter
5.  More
6. 
7.  Edit
8. 
- Select: required entry
3.  Edit

Continue as in Adding an entry to the Caller filter list (page 91),


② - Enter number, from step 8

Telephone settings

Deleting an entry from the Caller filter list

Open Settings menu section:



1.  
2. **Select**
3.  
4. **Select**
5. **More**
6.  
7. **Select**
8.  Select: required entry
9. **Select**
10.  Delete entire caller filter list?
Yes
11.  $[]^n$

Deleting all entries in the Caller filter list

Open Settings menu section:



1.  

Telephone settings


2. **Select**
3.  **List**
4. **Select**
5. **More**
6.  **Delete all**
7. **Select**
8. 
Delete entire caller filter list?
Yes
9. 
10. **OK**
11.  $[]^n$

Activating Caller filter

Open Settings menu section: 

1.  **Caller filter**
....
2. **Select**
3.  **Mode**
....
4. **Select**

Telephone settings

5.   → Accept only calls from callers in the **Caller filter**
 → Don't accept calls from callers in the **Caller filter**
 → **Caller filter** not used
- Note: Currently set value is marked by a blue dot (●)*
6. 
7.  $[]^n$

Configuring emergency or SOS calls

Assigning emergency call number

Open Settings menu section: 

1.   → 1
2. 
3.   → 2
4. 
6.   → 1
 → 2
 → 3

① Lookup contact

7. 
8.  Select: required contact

9.  Select
10.  []ⁿ


② Enter number

7.  Select
8.  

When no number is entered
then the **Emergency call**
feature is disabled

9.  Save
10.  []ⁿ

③ Central directory

7.  Select
8.   Enter the first character(s) of the required name
9.  OK
10.  Select: required contact
11.  Select
12.  []ⁿ

Telephone settings

Assigning an emergency message¹⁴

Open Settings menu section:



1.



2.

Select



4.

Select

5.



To make a voice call **no Emergency call** message should be defined.

6.

Save

7.




Assigning the Silent charging feature

Open Settings menu section:




1.



2.

Select

3.



→ **Silent charging** not used

→ Disconnect from the system while in the charger¹⁵

→ Turn off the ringer (and vibrator) while in the charger

¹⁴ Only for the G566

¹⁵ If configured: redirect call to alternative destination

Telephone settings

Note: Currently set value is marked by a blue dot (●)

4.  Select

5. ]ⁿ

Defining the missed call time

Open Settings menu section:



1.  Missed call time
nn sec.

2.  Select

3.   Missed call time
Save

4.  Save

5. ]ⁿ

Voicemail

Use the Voicemail feature to listen to voice messages left by calling parties¹⁶. You receive a voicemail in the following situations:

- if your handset is switched off
- if your handset is busy
- if your handset is out of the coverage area

A new voice message dialogue appears only once, i.e., when a caller leaves a first new message in the mailbox. A voicemail

¹⁶ Your communications system needs to support the Voicemail feature

Telephone settings

symbol () appears in the icon line; it disappears after you play the message.

Assigning the Voicemail number

Open Settings menu section:



1.



2.

Select

3.



4.

Save

5.



Connectivity settings

Table 15: Connectivity settings

Item	Description	Page
 Register	<ul style="list-style-type: none"> • Register handset to a DECT system Please contact your System Administrator 	-
 Deregister	<ul style="list-style-type: none"> • Remove registration your handset from a DECT system Please contact your System Administrator 	-
 Network select	<ul style="list-style-type: none"> • Select which DECT system is to be used (only if the handset is registered to more DECT systems) 	101

DECT system selection

Open Settings menu section:



1. 
2.  
3. 


 - Handset selects DECT system automatically
 - Select: required DECT system (here e.g., **NEC Hilversum**)

Note: Currently set value is marked by a blue dot (●)

Telephone settings

4. **Select**
5.  $[]^n$

Translation Tables

The following tables are used for translations – they are not part of the published user manual.





Keys table

Bookmark Name	
Key0	
Key1	
Key9	
KeyHash	
KeyLineKey	
KeyLoudspeaker	
KeyMenu	
KeyNavigation	
KeyNavigationLeftRight	
KeyNavigationUpDown	
KeyOffHook	
KeyOk	
KeyOnHook	
KeyPad	
KeySoftKeyLeft	
KeySoftKeyMiddle	
KeySoftKeyRight	





Translation Tables

KeySos	
KeyStar	
KeyVolumeDown	
KeyVolumeUp	





Menu Items/Choices table

Bookmark Name	
MainMenuAccessories	
MainMenuCalendar	
MainMenuCalls	
MainMenuCentralDirectory	
MainMenuContacts	
MainMenuMessaging	
MainMenuSettings	
MenuItem10Minutes	 10 minutes
MenuItem15Minutes	 15 minutes
MenuItem15Seconds	 15 seconds
MenuItem1Hour	 1 hour
MenuItem1Minute	 1 minute
MenuItem24Hour	 24 hour
MenuItem2Hours	 2 hours
MenuItem30Minutes	 30 minutes
MenuItem4Hours	 4 hours
MenuItem5Minutes	 5 minutes
MenuItem5MinutesNotBold	 5 minutes
MenuItemAcceptList	 Accept list






Translation Tables

MenuItemAddContact	 Add contact
MenuItemAddToContact	 Add to contact
MenuItemAlarmHhMm	 Alarm hh:mm
MenuItemAlarmOff	 Alarm Off
MenuItemAlarms	 Alarms
MenuItemAlarmsShortcut	 Alarms
MenuItemAlertMelody	 Alert melody Melody n
MenuItemAlerts	 Alerts
MenuItemAlertVolume	 Alert volume n
MenuItemAmPm	 am/pm
MenuItemAnswerMode	 Answer mode
MenuItemAnyKey	 Any key
MenuItemAtStart	 At start
MenuItemAutoAnswer	 Auto answer
MenuItemAutomaticKeyLock	 Automatic keylock
MenuItemAutoSelect	 Auto. select
MenuItemBlockList	 Block list
MenuItemCalculator	 Calculator
MenuItemCallerFilter	 Caller filter
MenuItemCallTime	 Call time h:mm:ss
MenuItemCentralDirectory	 Central directory
MenuItemChangePinCode	 Change PIN code







Translation Tables

MenuItemChargerWarning	 Charger warning
MenuItemClick	 Click
MenuItemConfirmationSound	 Confirmation sound
MenuItemContacts	 Contacts
MenuItemCopy	 Copy
MenuItemCoverageWarning	 Coverage warning
MenuItemDate	 Date 22-01-2013
MenuItemDdMmYyyy	 dd-mm-yyyy
MenuItemDectSystem	 NEC Hilversum
MenuItemDelete	 Delete
MenuItemDeleteAll	 Delete all
MenuItemDeleteAllContacts	 Delete all contacts
MenuItemDeleteAllItems	 Delete all items
MenuItemDeleteAllMessages	 Delete all messages
MenuItemDeleteContact	 Delete contact
MenuItemDeleteItem	 Delete item
MenuItemDeleteMessage	 Delete message
MenuItemDeregister	 Deregister
MenuItemDisconnect	 Disconnect
MenuItemDisplay	 Display
MenuItemDisplayDefault	 Default
MenuItemDisplayNEC	 NEC
MenuItemDots

Translation Tables

MenuItemEdit	 Edit
MenuItemEditBeforeCall	 Edit before call
MenuItemEditContact	 Edit contact
MenuItemEmergencyCall	 Emergency Call
MenuItemEnglish	 English
MenuItemEnterNumber	 Enter number
MenuItemFeedback	 Feedback
MenuItemFilterOff	 Filter off
MenuItemForward	 Forward
MenuItemGoToDate	 Go to date
MenuItemGoToToday	 Go to today
MenuItemGreenLed	 Green LED Charging
MenuItemHandsetName	 Handset name Empty
MenuItemHome	 Home: 
MenuItemIncomingCall	 Incoming call
MenuItemIncreasingAlert	 Increasing alert
MenuItemIncreasingNotification	 Increasing notification
MenuItemIncreasingRing	 Increasing ring
MenuItemKeySound	 Key sound
MenuItemLanguage	 Language English
MenuItemLedSignal	 LED signal
MenuItemLeftNavKey	 Left nav. key

Translation Tables

MenuItemLineKey4	 Line key 4
MenuItemList	 List
MenuItemLookUpContact	 Lookup contact
MenuItemMelody1	 Melody 1
MenuItemMelody20	 Melody 20
MenuItemMelodyDefault	 Default
MenuItemMessage	 Message ...
MenuItemMessageCount	 Message count nn
MenuItemMessageNotification	 Message notification
MenuItemMissedCall	 Missed call
MenuItemMissedCallTime	 Missed call time nn sec.
MenuItemMobile	 Mobile:
MenuItemMode	 Mode ...
MenuItemName	 Name: Jim Peters
MenuItemNameBlank	 Name: 
MenuItemNetworkSelect	 Network select
MenuItemNone	 None
MenuItemNormal	 Normal
MenuItemNormalDot	 Normal
MenuItemNotificationEmergency	 Notification emergency Melody n
MenuItemNotificationNormal	 Notification normal Melody n
MenuItemNotificationUrgent	 Notification urgent Melody n

Translation Tables

MenuItemNotificationVolume	Notification volume n
MenuItemNumber	Number
MenuItemOffDot	Off
MenuItemOn	On
MenuItemOther	Other:
MenuItemOtherTime	Other
MenuItemOverwriteOld	Overwrite old
MenuItemPhoneLock	Phone lock
MenuItemPowerSave	Power save xx sec. / yy sec.
MenuItemProxyPassword	Proxy password *****
MenuItemRecurrentAlarm	Recurrent alarm Off
MenuItemRecurrentAlarmHhMm	Recurrent alarm hh:mm
MenuItemRedLed	Red LED
MenuItemRegister	Register
MenuItemResetSettings	Reset settings
MenuItemRingExternal	Ring external Melody n
MenuItemRingInternal	Ring internal Melody n
MenuItemRingtoneDefault	Ringtone: Default
MenuItemRingUnknownCall	Ring unknown call Melody n
MenuItemRingVolume	Ring volume n
MenuItemRussian2	Russian-2

Translation Tables

MenuItemSaturday	Saturday
MenuItemSaveAsContact	Save as contact
MenuItemSaveInCallerFilter	Save in caller filter
MenuItemSecurity	Security
MenuItemSendMessage	Send message
MenuItemSendToMany	Send to many
MenuItemSentMessages	Sent Messages
MenuItemShortcuts	Shortcuts
MenuItemSilent	Silent
MenuItemSilentCharging	Silent charging
MenuItemSilentChargingLed	Silent charging
MenuItemSilentDot	Silent
MenuItemSilentDotNotBlue	Silent
MenuItemSnoozeTime	Snooze time 10 minutes
MenuItemSpeedDial	Speed dial
MenuItemSpeedDialEntryHash	#:
MenuItemSpeedDialName	#: John McLean
MenuItemStartUpScreen	Startup screen
MenuItemStatus	Status
MenuItemStopwatch	Stopwatch
MenuItemSunday	Sunday
MenuItemTime	Time 14:45

Translation Tables

MenuItemTimeDate	Time & date
MenuItemTone	Tone
MenuItemUnits	Units h:mm:ss nn
MenuItemUrgent	Urgent
MenuItemVibrateAndRing	Vibrate and ring
MenuItemVibrateOnly	Vibrate only
MenuItemVibrateThenRing	Vibrate then ring
MenuItemVibrator	Vibrator
MenuItemViewMonths	View month
MenuItemViewWeek	View week
MenuItemVoiceMailNumber	Voicemail number Empty
MenuItemWallpaper	Wallpaper
MenuItemWork	Work:
MenuItemYellowLed	Yellow LED Low battery
MenuItemYyyyMmDd	yyyy-mm-dd
MenuItemSaveInCallerFilter	Save in caller filter

Soft Key table

Bookmark Name	
SkAdd	Add
SkCall	Call
SkCalls	
SkCentralDirectory	
SkClear	Clear
SkDelete	Delete
SkDots
SkEdit	Edit
SkFormat	Format
SkLap	Lap
SkMark	Mark
SkMore	More
SkMute	Mute
SkNew	New
SkOff	Off
SkOk	OK
SkOn	On
SkPlay	Play
SkPrivateDirectory	
SkReject	Reject
SkReplace	Replace
SkReply	Reply

Translation Tables

SkReset	Reset
SkSave	Save
SkSelect	Select
SkSend	Send
SkSilent	Silent
SkStart	Start
SkStop	Stop
SkSymbol	Symbol
SkToggle	Toggle
SkTurnOff	Turn off
SkUnmark	Unmark
SkUnmute	Unmute
SkView	View
SkYes	Yes

Display/Icon table

Bookmark Name	
DisplayIncomingCall	
DisplayLoudspeakerOn	
DisplayLoudspOffMicMute	
DisplayLoudspOnMicMute	
DisplayOutgoingCall	
IconAllCalls	-
IconAnsweredCalls	
IconCallsSettings	
IconConnectivitySettings	
IconDialedCalls	
IconDisplaySettings	
IconDrafts	
IconGeneralSettings	
IconInbox	
IconMessageSettings	
IconMissedCallerFilterCalls	
IconMissedCalls	

Translation Tables

IconSentMessages	
IconSoundsNormalSettings	
IconSoundsSilentSettings	
TopAlarmSet	
TopBatteryStatus	
TopCallerFilterActive	
TopKeypadLocked	
TopMissedCalls	
TopNewTextMessage	
TopRingerDeactivated	
TopSignalStrength	
TopVoiceMailMessage	

Menu Tab table


Bookmark Name	
MenuTabAllCalls	 All calls
MenuTabAnsweredCalls	 Answered calls
MenuTabCallsSettings	 Calls
MenuTabConnectivitySettings	 Connectivity
MenuTabDialedCalls	 Dialed calls
MenuTabDisplaySettings	 Display
MenuTabDrafts	 Drafts
MenuTabGeneralSettings	 General
MenuTabInbox	 Inbox
MenuTabMessageSettings	 Settings
MenuTabMissedCalls	 Missed calls
MenuTabSentMessages	 Sent messages
MenuTabSoundsNormalSettings	 Sounds - normal
MenuTabSoundsSilentSettings	 Sounds - silent
TabIconAllCalls	
TabIconAnsweredCalls	
TabIconDialedCalls	
TabIconMissedCalls	

Translation Tables




Screen shot table

Bookmark Name	
QAddContact	
QAlarmTime	
QAlertVolume	
QClearCounter	
QConfirmPassword	
QConfirmPin	
QContactNumbers	
QDate	
QDeleteAllContacts	






Translation Tables

QDeleteAllFromCallerFilter	 Delete entire caller filter list?
QDeleteAllMessages	 Delete all messages?
QDeleteAppointment	 Delete appointment
QDeleteFromCallerFilter	 Delete current item from caller filter list?
QDeleteMessage	 Delete message?
QDots	
QDotsOnDark	?
QEndDate	 End date 15 - 01 - 2013 Save
QEndTime	 End time 20 11 : 30 Save
QEnterCurrentPin	 Enter current PIN --




Translation Tables

QEnterName	
QEnterNewPassword	
QEnterNewPin	
QEnterNumber	
QEnterPassword	
QEnterPin	
QGoToDate	
QHandsetName	
QLocation	
QMessage	
QMissedCallTime	

Translation Tables

QNotificationVolume	
QPowerSave	
QReminderDate	
QReminderTime	
QResetSettings	
QRingVolume	
QSaveAsDraft	
QSaveInCallerFilter	
QStartDate	

Translation Tables

QStartTime	
QStoreInCallerFilter	
QSubject	
QTime	
QVoiceMailNumber	
ScreenShotStorageFull	
StatusInformation	

General text table

Bookmark Name	
AppointmentNote	Note: Days with appointments will be marked with a red dot at the bottom right of the date.
ApprNumber	appropriate number
AwaitAnswer	Await answer
CalcShowResult	calculate and show the result
ContactSystemAdm	Please contact your System Administrator
ContinueAsIn	Continue as in
EnterEdit	Enter/edit:
EnterEditPowerSave	To never turn off the display set the second value to 0
EnterFirstCharacter	Enter the first character(s) of the required name
FromStep	from step
LongPress	Long press
LoudspeakerOff	Loudspeaker off
LoudspeakerOn	Loudspeaker on
MakeNecessaryChanges	Make the necessary changes like in
MathOperator	mathematical operator (+, x, ÷ and -)
NotG266	Only for the G566
OnBlueDot	<i>Note: Currently set value is marked by a blue dot (●)</i>
OnContinue	Continue a stopped measurement
OnLap	Save the intermediate result and continue the measurement
OnMarkDay	<i>Note: (Already) selected days are marked with <input checked="" type="checkbox"/></i>

Translation Tables

OnReset	Reset the stopwatch (back to 0)
OnStart	Start a new measurement
OnStop	Halt the measurement
OptionalStep	Optional step(s):
Or	Or
RepeatDaySelect	For the required days of the week:
ReqAppointment	required appointment
ReqContact	required contact
ReqEntry	required entry
ReqMessage	required message
ReqSystem	required DECT system (here e.g., NEC Hilversum)
ScrollText	Scroll the text
Select	Select:
UseKeypadDigChar	Use the keypad to insert one or more digits (0 – 9, * and #) or characters
UseNavigation	Use the NAVIGATION keys to move the cursor to the insertion point
UseToDeleteDigChar	To delete a digit or character use soft key
UseUpDown	Use the Up or Down NAVIGATION key to increase or decrease the value of the selected field
Value	a value
VolumeDown	Volume down:
VolumeUp	Volume up:

Text Strings taken from handset texts table

Bookmark Name	
AlarmsStr	Alarms
AlertMelodyStr	Alert melody
AlertsStr	Alerts
AlertVolumeStr	Alert volume
AllStr	All
AnsweredStr	Answered
AnyKeyStr	Any key
AutoAnswerMsgStr	Auto answer msg
AutoAnswerStr	Auto answer
AutomaticKeylockStr	Automatic keylock
CalculatorStr	Calculator
CalendarStr	Calendar
CallerFilterStr	Caller filter
CallsStr	Calls
CallTimeStr	Call time
CentralDirectoryStr	Central directory
ChangePinCodeStr	Change PIN code
ChargerWarningStr	Charger warning
ChargingStr	Charging
ConfirmationSoundStr	Confirmation sound
ConnectivityStr	Connectivity
ContactsStr	Contacts
CoverageWarningStr	Coverage warning
DefaultStr	Default
DialedStr	Dialed
DisplayStr	Display
DraftsStr	Drafts
EmergencyCallStr	Emergency call
EmergencyStr	Emergency
EnterNumberStr	Enter number
GeneralStr	General
GreenLedStr	Green LED

Translation Tables

HandsetNameStr	Handset name
HomeStr	Home
InboxStr	Inbox
IncomingCallStr	Incoming call
IncreasingAlertStr	Increasing alert
IncreasingNotificationStr	Increasing notification
IncreasingRingStr	Increasing ring
KeySoundStr	Key sound
LanguageStr	Language
LedSignalStr	LED signal
LookUpContactStr	Lookup contact
LowBatteryStr	Low battery
MessageCountStr	Message count
MessageNotificationStr	Message notification
MessageStr	Message
MessagingStr	Messaging
MissedCallStr	Missed call
MissedStr	Missed
MisssedCallsStr	Missed calls
MobileStr	Mobile
NameStr	Name
NecStr	NEC
NormalStr	Normal
NotificationEmergencyStr	Notification emergency
NotificationNormalStr	Notification normal
NotificationUrgentStr	Notification urgent
NotificationVolumeStr	Notification volume
NumberStr	Number
OffStr	Off
OnStr	On
OtherStr	Other
OverwriteOldStr	Overwrite old
PhoneLockStr	Phone lock

Translation Tables

PinCodeStr	PIN Code
PowerSaveStr	Power save
ProxyPasswordStr	Proxy password
RedLedStr	Red LED
RingExternalStr	Ring external
RingInternalStr	Ring internal
RingUnknownCallStr	Ring unknown call
RingVolumeStr	Ring volume
SendToManyStr	Send to many
SentMessagesStr	Sent messages
SettingsStr	Settings
ShortcutsStr	Shortcuts
SilentAnswerMsgStr	Silent answer msg
SilentChargingStr	Silent charging
SilentStr	Silent
SoundsNormalStr	Sounds - normal
SoundsSilentStr	Sounds - silent
SpeedDialStr	Speed dial
StartupScreenStr	Startup screen
TextMessageStr	Text message
TextOrVoiceMsgStr	Text or voice msg
TimeDateStr	Time & date
UrgentStr	Urgent
VibratorStr	Vibrator
VoiceMailNumberStr	Voicemail number
VoiceMessageStr	Voice message
WallpaperStr	Wallpaper
WorkStr	Work
YellowLedStr	Yellow LED