

20 30 40 50

GPS System 500



User Manual / Getting Started with SKI-Pro

Version 2.0
English

Leica
Geosystems

Congratulations on your purchase of Leica Geosystems SKI-Pro Software



In order to use this software correctly and reliably, you must follow the instructions given in this user manual and/ or in the on-line help system. You must also adhere to the directions given in the user manual for the product with

which you are using the software.

The rights and responsibilities accruing in respect to Leica Geosystems as a result of acquisition of the software are set out in the **Leica Geosystems Software Licence Agreement**.



All of the instructions and directions required for technical specialist to use the software are included in this user manual, which is only available in certain languages.

Product Identification

The software version of your copy of SKI-Pro is written on the CD-ROM label. The License Number is given on the SKI-Pro Software Licence Agreement. Enter the software version and licence number in the spaces provided below and always refer to this information when you need to contact agency or authorized service workshop.

Software Version: _____

Language: _____

Licence Number: _____

Technical Support

Technical Support is provided by Leica Geosystems worldwide network of representatives. We are represented in almost every country in the world. A representative directory is available at:

www.leica-geosystems.com

Symbols used in this manual

Symbols used in this manual have the following meanings:



DANGER

Indicates an imminently hazardous situation which, if not avoided will result in death or serious injury.



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury and/or appreciable material, financial and environmental damage. The symbol is also used to alert against unsafe practices.



Important paragraphs which must be adhered to in practice as they enable the product to be used in a technically correct and efficient manner.

Chapter Overview

Introduction

7

Installation

10

An Overview of SKI-Pro

14

Quick Tour I - Real Time

28

Quick Tour II - Post-Processing

39

Quick Tour III - Format Manager

64

Quick Tour IV - GIS/CAD Export

69

Contents

Introduction	7	Quick Tour II - Post-Processing	39
Licence Agreement and Support	8	Lesson One - Starting a Project and Importing Raw Data	40
Software Protection	8	Lesson Two - Processing Baselines	43
Installation	10	Lesson Three - Creating a Coordinate System	50
Installation Instruction	11	Lesson Four - Importing an ASCII File	52
Uninstall SKI-Pro	12	Lesson Five - Calculating Transformation Parameters	56
Starting and exiting SKI-Pro	13	Lesson Six - Using a Coordinate System with a Project	59
An Overview of SKI-Pro	14	Lesson Seven - Exporting Coordinates to an ASCII File	61
SKI-Pro components	14	Quick Tour III - Format Manager	64
Software Navigation Tools	21	Lesson One - Creating a Format Template File	64
Views	23	Lesson Two - Uploading a Format Template File to the Sensor	68
Accessing the On-line Help	26	Quick Tour IV - GIS/CAD Export	69
Quick Tour I - Real Time	28		
Lesson One - Starting a Project and Importing Raw Data	29		
Lesson Two - Exploring the View/Edit Component	34		
Lesson Three - Exporting Coordinates to a Custom ASCII File	36		

Introduction


Welcome to SKI-Pro, **Static-Kinematic-Professional** GPS software for post-processing and management of GPS data. SKI-Pro is the complete GPS office software package that accompanies Leica Geosystems GPS System 500 Hardware.

What is SKI-Pro

Leica Geosystems's SKI-Pro software is a comprehensive, automated suite of programs for GPS surveying including post-processing and support of real-time measurements.

It's functionality includes:

- Data import
- Data management
- Data processing
- Network adjustment
- Datum transformation
- Data export



SKI-Pro user interface (graphical view)

Licence Agreement and Support



Read the Software License agreement carefully before opening the package containing the installation CD-ROM.

Software Protection

Part of SKI-Pro is not protected and may be used without the software protection key (dongle). The unprotected part contains:

- Satellite Availability
- Data Import
- RINEX Export
- ASCII Import / Export
- Project Management
- Coordinate Set Management
- Coordinate System Management
- Sensor Transfer
- View and Edit
- Codelist Management
- Antenna Management

Software Protection, continued

The protected options are available individually and can be accessed by using the software protection key only.

The protected options are:

- Data Processing
- Datum and Map
- Adjustment
- RINEX Import
- GIS / CAD Export

If you are installing SKI-Pro all options will be installed automatically but the protected options are accessible only if the software protection key is connected to the parallel port of the computer and if the purchased options have been activated on the protection key.

Installation

Installing SKI-Pro is a simple process. This brief chapter explains everything you need to know regarding installation.

System requirements:

The computer and system software you intend to use with SKI-Pro must meet the following minimum requirements. Note that SKI-Pro works best with the recommended requirements.

The operating system must be one of the following:

Windows 95, Windows 98, Windows 2000 or Windows NT 4.0 (or later).

Minimum Hardware requirements:

- PC with Pentium processor 90 Mhz
- 16 MB RAM
- 100 MB free space on harddisk (for typical installation)
- RS232 COM port
- Parallel Port (for software protection key)
- 1.4 MB 3.5 inch disk-drive
- Mouse installed

Recommended Hardware requirements:

- PC with Pentium processor 200 Mhz or faster
- 64 MB RAM
- 300 MB free space on harddisk
- RS232 COM port
- Parallel Port (for software protection key)
- CD-ROM drive
- Mouse installed

Before you install:

Ensure that your computer and software conform to at least the minimum requirements as outlined above.

SKI-Pro requires at least 50 MB of free disk space. The programs on the installation CD are compressed and will be expanded during installation.

Installation Instruction



SKI-Pro is delivered on a CD-ROM. If you do not have a CD-ROM drive you can order the installation on floppy diskettes separately.

To install SKI-Pro from CD-ROM:

➤ Insert the CD-ROM labelled “GPS System 500SW”. The install shield will start automatically and guide you through the installation process.

During the installation you are given the following option to install: **Typical** or **Compact**. If you choose *Typical* all components including the optional components will be installed. This option is recommended in most cases. Choose *Compact* only if you are always using SKI-Pro without the software protection key (dongle) and want to save disk space.

To install SKI-Pro from floppy diskettes:

➤ Insert the floppy diskette labelled Disk 1.
➤ From the Windows™ **Start** bar, click **Run**.
➤ Type **a:\setup**. The Setup program prompts you through the installation process. Follow the instructions on the screen.

Older version of SKI-Pro already installed

If you have an older version of SKI-Pro already installed on your computer all database information such as Projects, Coordinates Sets and Coordinate Systems will be updated automatically.



Database information from SKI 2.3 or earlier will NOT be updated automatically. To update SKI 2.3 (or earlier) Projects you can either re-import raw data and process them again or you can import final coordinates or baselines via SKI ASCII files.

Uninstall SKI-Pro



Do not delete any program files manually by using Windows Explorer or any other File Management program.


To delete the SKI-Pro installation on your computer follow the instruction below:

- From the Windows™ **Start** bar, click **Programs**.
- Select SKI-Pro.
- Click **Uninstall Leica Geosystems SKI-Pro**.
- Confirm with **Yes**. All SKI-Pro files and settings will be removed permanently from the harddisk.

Starting and exiting SKI-Pro


To start SKI-Pro:

- Ensure that the green software protection key (dongle) is inserted into the parallel port of your computer.
- From the Windows™ **Start** bar, click **Programs**.
- Select **SKI-Pro**.
- Click **SKI-Pro**.



To exit SKI-Pro:

- From the **File** menu click **Exit** or click on the  icon of the SKI-Pro main window.



SKI-Pro runs on 32-bit Microsoft® Windows™ 95, 98, 2000 or NT platforms. As SKI-Pro software is based on an intuitive graphical interface with standard Windows™ operating procedures, it is remarkably easy to learn and use. All components have a uniform appearance and interact instantly and seamlessly with each other in a multi-tasking software environment.

Those who are already familiar with Windows™ will find SKI-Pro very easy to handle. Those with no prior knowledge of Windows™ will find it quick and easy to learn.

SKI-Pro consist of several components:

- **Project Management**
- **Coordinate Set Management**
- **Coordinate System Management**
- **Antenna Management**
- **Codelist Management**
- **Sensor Transfer**
- **Raw Data Import**
- **ASCII Import**
- **ASCII Export**
- **RINEX Export**
- **GIS/CAD Export***
- **Datum and Map***
- **Data Processing***
- **Adjustment***
- **RINEX Import***

*Some of these components are delivered as options which gives the user the opportunity to select the combination which best suits his or her needs and budget. Refer to chapter 1.2 Software Protection for more information.

SKI-Pro components, continued

The following external programs cannot be accessed from within SKI-Pro but are installed automatically with SKI-Pro:

- **Satellite Availability**
- **Road Line Editor**
- **Format Manager**

These programs are not explained in this manual. Please refer to the corresponding Help Systems of the programs for more information.



Project Management

All GPS data that is collected and that belongs together can be organized in SKI-Pro within a single Project. This Project could contain, for example, all data relating to a particular contract you are carrying out for a client.

In the Project Management you can create, open, and edit projects as well as register projects not contained in the project list. The Project Management can also be used to attach and modify Coordinate Systems.



Never delete a project or any of the files contained within a project from outside SKI-Pro.

Always use the Project Management to delete unwanted projects. Deletion of projects or project files from outside of SKI-Pro can result in the destruction of the consistency of the database, which will lead to unrecoverable database errors.



Coordinate Set Management

The Coordinate Set Management manages Coordinate Sets that are stored in the SKI-Pro database.

A Coordinate Set is a list of point coordinates that are stored independently from Projects. A Coordinate System may be assigned to a Coordinate Set, allowing you to switch between Cartesian, Geodetic and Grid coordinates.

Points can be added either manually, by importing via ASCII file or by dragging from an existing Project.



A Coordinate Set can either hold WGS84 or Local Coordinates but does not allow to switch between them.



Coordinate System Management

A coordinate system provides the information necessary to convert coordinates to different representations (Cartesian, Geodetic or Grid) and to transform coordinates between the WGS84 and the Local System. A Coordinate System may be attached to a Coordinate Set or to a Project.

Within SKI-Pro the user can work in the global system (WGS84) or in a local coordinate system. The local coordinate system may be a geodetically defined system or it may be a simple grid system with neither an ellipsoid nor a projection associated with it.

The Coordinate System Management is linked to a database that stores the parameters. This database is independent from the project database.



Antenna Management

The Antenna Management allows you to define and edit parameters for different GPS antennas. This information is stored in a global database and can be used to upload to the Sensor or in a Project for Data-Processing. All Leica Geosystems antennas are pre-defined upon installing the software and the user is not permitted to make any changes to these pre-defined antennas.



Codelist Management

A Codelist contains Thematical or Free Coding information that may be assigned to points during measurement in the field. A Codelist may be attached to a Project.

The Codelist Manager enables you to create and edit Codelists for later use in the field.



Sensor Transfer

The Sensor Transfer component allows you to download and upload data from the sensor.

Data can be downloaded or uploaded by a serial cable or directly on to a PCMCIA memory card.

The following data may be downloaded from a sensor:

- GPS Raw Data
- Report files
- ASCII files
- Format Files
- Codelists
- Coordinate System Parameters
- Geoid Model field files
- Antenna definitions
- Configuration Sets

The following data may be uploaded to a sensor:

- Point information
- Coordinate System Parameters
- ASCII files
- Format Files
- Codelists
- Geoid Model field files
- Antenna definitions
- Configuration Sets
- Language Versions
- Firmware

SKI-Pro components, continued



Raw Data Import

The Raw Data Import component enables you to import GPS field data into SKI-Pro.

It is possible to transfer GPS raw observations for post-processing along with related point information as well as coordinates recorded using the Real-Time RT-SKI option into Projects or Coordinate Sets.

GPS raw observations may be in Leica Geosystems System 200, 300 or 500 format. Optionally GPS raw observations may be imported in RINEX format. See also RINEX Import.

It is also possible to import coordinate files in ASCII format into Projects or Coordinate Sets.

Additionally, there is the facility to import Precise Ephemeris data.



ASCII Import

The ASCII Import component enables you to import coordinates and baselines from pre-defined or user-defined files.

You may import pre-defined files of Leica Geosystems standard format SKI-ASCII or IDEX (InDependent EXchange format).

An import wizard allows to define unknown file formats and enables you to import any kind of user-defined coordinate files.

SKI-Pro components, continued



ASCII Export

The Export component enables you to export data from SKI-Pro.

Coordinate information may be exported to ASCII files in various pre-defined or user-defined formats.

See also GIS/CAD Export option.



RINEX Export

The RINEX Export enables you to export GPS raw observations to an ASCII file in RINEX format. Unlike the RINEX Import this function is not an option and is available as standard.



GIS/CAD Export (optional)

The GIS/CAD Export is an optional Export tool. It enables you to write the point coordinates to AutoCAD (DXF/DWG), MicroStation (DGN) or MapInfo (MIF) formatted files.



Datum and Map (optional)

If the user requires final coordinate output in the coordinate system to which the GPS measurements are related (WGS84) then this optional tool is not necessary. However, in most cases it is necessary to transform the WGS84 coordinates into a local coordinate system.

The Datum and Map option provides you with a tool to determine transformation parameters which can then be used to perform datum transformations within two sets of coordinates.

SKI-Pro components, continued



Data Processing (optional)

The Data Processing is an option that can be accessed via the Data-proc Tab from within a Project window. It allows you to process GPS observations that have been recorded in the field to achieve WGS84 coordinates and their relative accuracy.

Static, Rapid-Static, Stop and Go, Kinematic, Kinematic on the Fly, and Single-Point data can be processed.

The data to be processed may be selected graphically. The computation itself is completely hidden for the user. All selected data is processed automatically in a batch process without the need for any user interaction.

After the Data Processing is completed the results can be viewed and stored for further use in the Results-View.



Adjustment (optional)

Adjustment is an option that can be accessed via the Adjustment Tab from within a Project window. It provides you with a powerful tool for performing a least squares adjustment on a network of baseline vectors and terrestrial data (directions, distances, vertical angles and azimuths).

Additionally it enables you to perform a network simulation based upon default observation precisions to find out how good the design of your network is before you measure.

A graphical user interface similar to that of View/Edit allows you to select the points and observations to be adjusted.




RINEX Import (optional)

RINEX Import is the optional part of the data Import tool. It enables you to import GPS observation data collected with third party receivers in RINEX (Receiver INdependent EXchange) format.

Software Navigation Tools

The various components of SKI-Pro may be accessed using different methods. In order to navigate through the software you may choose the tools which you prefer:



Software Navigation Tools, continued

Menu Bar

The Menu Bar is a special Toolbar at the top of the screen that contains menus such as File, Edit, and View.

The Menu Bar lists the available commands. If a command is not applicable it is greyed out and not accessible.

Toolbar

Toolbars allow you to organize the commands you use most often the way you want to, so you can find and use them quickly. You can easily customize toolbars - for example, you can add and remove buttons, create your own custom toolbars, hide or display toolbars, and move toolbars.

List Bar

The List Bar gives you single-click access to all available components and tools of SKI-Pro. Additionally if a Project or a Coordinate Set is open it lists them. Therefore the List Bar allows you to simply switch between a tool and/or a Project or Coordinate Set.

You can display small or large icons, re-arrange them or hide the List Bar.

The List Bar is divided into groups (folders) to help organize your information. Click a folder, e.g. Management, to move to a different set of tasks.

Context Menu

Almost everywhere upon right-click on a particular item in SKI-Pro a Context-Menu is available. A Context-Menu lists all useful commands at a particular instant for a particular item on the screen. It is possible to navigate through the entire software by only using commands from the Context-Menu.


Tabbed-View

Upon opening a Project, tabs at the bottom of the view allow you to quickly switch from one view to another. You may instantly switch from for example the Graphical-View (View/Edit) to the Points-View or Data-processing-View.

Views



Explorer-View


Throughout SKI-Pro a powerful Explorer-View is utilized to list information, be it database information or results from calculations. This view which has similar functionality as the Windows™ Explorer view normally consists of two panes. A **Tree-View** on the left-hand side and a **Report-View** or **Property-View** to the right hand side. Listed data may be easily arranged, sorted, selected and even printed.




Explorer-View


Tree-View

The Tree-View pane provides you with an overview of the items you are currently working with, in an expandable/collapsible hierarchy of folders  and pages 

Double-click on a folder or click  to expand (open) it.

If a folder is open double-click on it or click  to collapse (close) it.

Click on a folder or page to display the content of it. Depending on the type of data to be displayed the data will be listed in a **Report-View** or **Property-View**.



Tree-View

Views, continued

Report-View

Database information such as e.g. Points or Observations may be listed in a Report View.

Point Id	Point Class	Epoch	Latitude	Longitude	Height
<input checked="" type="checkbox"/> B215	Navigated	12/21/1998 13:49:45	47° 23' 45.73110" N	9° 38' 10.52060" E	448.1217
<input checked="" type="checkbox"/> TP306	Navigated	12/21/1998 14:22:00	47° 23' 51.78132" N	9° 39' 04.09567" E	461.0808
<input checked="" type="checkbox"/> B218	Navigated	12/21/1998 14:57:30	47° 23' 10.67503" N	9° 37' 13.65965" E	432.3451
<input checked="" type="checkbox"/> TP214	Navigated	12/21/1998 15:16:45	47° 23' 51.74697" N	9° 37' 12.30504" E	416.3859
<input checked="" type="checkbox"/> B313	Navigated	12/21/1998 15:50:00	47° 22' 58.30884" N	9° 38' 36.75722" E	449.8015

Report-View

The data records are listed in rows and columns. Each row displays one record.

The columns are fully user configurable. You can change the width, sort the records according to columns or view and hide individual columns.

Certain data items may be modified by simply double-click on them.

Property-View

Database information such as e.g. Project Properties may be listed in a Property-View:

Property	Value
Name	Sample1
Location	C:\SKIPro\Data\Projects\Sample1\
Date Created	05/30/2000 13:55:55
Last Used	05/30/2000 13:56:03
Avg. Limit Pos.	0.0750
Avg. Limit Hgt.	0.0750
Coordinate System	WGS 1984
Compute Mod. Grid Coordinates	No
Avg. Combined Factor	1.0000
Northing Shift	0.0000
Easting Shift	0.0000
Time Zone	1h00'
Manager	
Client	
Street	
Map Reference	
Print Header	
Print Footer	
Note	

Property-View

The information is listed in two columns. The first column lists the description (Property) and the second column lists the actual value.

Property-Views are not user configurable.


Views, continued

Graphical-View


The data contained within a Project may not only be viewed and edited using the Report-View but also using a graphical user interface. Two types of Graphical-Views may be utilised. Points and Baselines are displayed in a map-view while observation data is displayed in a combined Report /Graphical-View.

Both views enable you to select and modify data, zoom in, zoom out and even print the view.

To switch between the different views of a Project simply click on the tabs below the view.



Graphical-View of View/Edit or Adjustment



Graphical-View of Data-Processing

Accessing the On-line Help

The SKI-Pro On-line Help System is a very comprehensive reference and includes all the detailed information about the whole software package.






Any Information NOT contained in this user manual can be found in the On-line Help System.



To display the On-line Help System:

- From the **Help** menu click  **Contents and Index**.

The Help Topics property sheet appears:



All topics contained in the Help are listed in books  and pages .

- Double-click on a book  to open it .

Accessing the On-line Help, continued

A book may contain pages  or other books .

➤ Double-click on a page  to open the help text.

To find a topic in the Help:

➤ Click the **Contents** tab to browse through topics by category.

➤ or click the **Index** tab to see a list of index entries: either type the word you're looking for or scroll through the list.

➤ or click the **Find** tab to search for words or phrases that may be contained in a Help topic.

To print Help text:

➤ If the Contents tab isn't already displayed, click on **Contents**.

➤ Select the book or the page that you want to print.


➤ Click on the **Print** button.

➤ Make sure the printer information is correct.

➤ Select **OK** to confirm.

What's this Help:

Help topics may also be accessed via the controls and commands from the SKI-Pro user interface:

➤ Click the  icon from the Toolbar and click on another Toolbar or List Bar icon or select a command from the menu to open the appropriate help topics.

Alternatively select "**What's This?**" from the **Help** menu.

Glossary of terms:

If you do not understand a particular term used in the software refer to the Glossary of terms contained in the On-line Help System.

➤ If the Contents tab isn't already displayed, click on **Contents**.

➤ Double-click the **Getting Help** book.

➤ Double-click the **Glossary of Terms** page and click on the desired term in the list.



For more information about the On-line Help System refer to Windows™ help by selecting Help from the Start menu.

Quick Tour I - Real Time

This Quick Tour is a step-by-step tutorial in which you learn how to work with real time GPS data. When using real time the processing and the applying of coordinate systems is already done in the field, so that the office work is reduced to importing raw data, eventually checking the results and directly exporting the final grid coordinates.



This exercise does NOT need your green software protection dongle to be connected.

The exercise comprises of the following scenario:

A number of real time points have been measured. Two different reference stations have been used. The points BM1 to BM4 have been measured from both reference stations, all other points from either reference station TP306 or from reference station B215. The raw data is given in the directory:

...\\SkiPro\Data\SampleData\Sys500\Realtime.

A local coordinate system has been used in the field, which comprises of a *UTM Zone 32 North* Projection on the *Bessel* Ellipsoid and a Classical 3D Transformation called "*Sample WGS-Bess*".

This Quick Tour comprises of the following steps:

Lesson One

- Importing GPS raw data and the attached coordinate system
- Creating the RealTime Fieldbook report
- Creating a Project

Lesson Two

- Exploring the View/Edit component

Lesson Three

- Exporting coordinates to a customized ASCII file


Lesson One - Starting a Project and Importing Raw Data

In Lesson One you will learn how to import GPS raw data and at the same time create a new Project.

Start-up SKI-Pro:

➤ From the **Start** menu select **Programs, SKI-Pro** and then click on **SKI-Pro**.


The main SKI-Pro window appears.



➤ From the **Import** menu or Toolbar select **GPS Raw Data** .


or

➤ from the **Tools** List Bar select **Import GPS Raw Data**



Lesson One - Starting a Project and Importing Raw Data, continued

The following dialog appears:




- Under **Files of type:** select **GPS500 raw data**.
- Under **Look in:** select the directory that contains the sample data:
... \SkiPro\SampleData\Sys500\Realtime\Data\Geodb



Depending where you installed SKI-Pro the path for the sample data may vary slightly. By default SKI-Pro will be installed in:
C:\Program Files\Leica Geosystems\...

- From the browser select the job **RT-Sample**
- Click **Import**.


The following Property Sheet appears:



- This is where you can view and modify the raw data.
- If you have not yet created any Project, the list of Projects is empty and you can not select an existing Project.
- Right-click on **Projects** and select **New**.

Lesson One - Starting a Project and Importing Raw Data, continued

The following dialog appears and allows you to create a new project while you are still in the Import (Assign) procedure:



➤ Under **Location** enter a path

e.g **C:\SKIPro\Data\Projects**

Alternatively you may use the browser.

➤ Enter a **Project Name** e.g. **RT Sample**. Note that the directory *RT Sample* has been added automatically to the

path. This is necessary because a Project consists of several files and each Project shall be stored under a separate directory.

➤ Click **OK** to confirm. The New Project Dialog will be closed and a new Project will be created and selected automatically.




Alternatively you can also create a Project using the New Project command from the File menu or Toolbar or via the Project Management of the List Bar.



Lesson One - Starting a Project and Importing Raw Data, continued

➤ Back in the Assign dialog click the **Settings** tab.




Here you can select the coordinate system, that has been used in the field to be imported into the SKI-Pro Coordinate System Management. Additionally the Coordinate System will be automatically attached to the project to which you assign the data.

➤ Make sure both options are checked as indicated above.



Alternatively you can also attach any other coordinate system to the project later.

➤ Click the **Fieldbook** tab to create a fieldbook report.



➤ Select Coordinate Type **Local** and **Grid** as shown above.

➤ Click **Preview...** to view the report.

Lesson One - Starting a Project and Importing Raw Data, continued

A GPS Fieldbook Report will be generated and shown in a Report View:

GPS Fieldbook Report

Job

Job Name: RT-Sample
Time: All results in local time (GPS + 1.00 hr)
RT-Skl Version: 1.21 Processing Kernel Version: 0.232

Coordinate System

Coord. System Name: Sample RT Creation Date: 03/24/1999 15:17:43
Transformation: Sample WGS-Bess
Type: Strict
Residuals: No distribution
Ellips oid: Bessel
Projection: UTM32 North Transformation model: Bus a-Wolf

System A: WGS 84 Ellips oid:
System B: Bessel Ellips oid:

3D-Helmert Transformation

Number of common points: 0
Rotation origin: X0 0.0000 m
Y0 0.0000 m
Z0 0.0000 m

No.	Parameter	Value	Unit
1	Shift dX	-607.1842	m
2	Shift dY	-15.4647	m
3	Shift dZ	-400.9572	m
4	Rotation about X	-1.74331	"
5	Rotation about Y	1.40504	"

The GPS Fieldbook Report displays the details of the survey completed in the field.

To scroll through the report use the toolbar buttons and . or press **Ctrl PgDown** and **Ctrl PgUp**.

To print the report click on .

➤ To close the Report View click in the upper right corner.

➤ Click the **General** tab to return to the General page of the Assign dialog

➤ Select **Assign** and then **Close**.


The Project window will open automatically and display the surveyed points in the local grid coordinate system.


Continue with Lesson Two – Exploring the View Edit component

Lesson Two – Exploring the View/Edit Component

In Lesson Two you will learn some useful features of the View Edit component.


The View/Edit project window opens directly in local grid zooming to the full extents including the reference stations.



➤ Use the  toolbar button to zoom into the detail points.

To get a clearer view you may additionally want to switch off the GPS baseline vectors (the red lines) and switch on the grid lines and the chains (yellow lines) showing how the survey was performed.


➤ Right-click on the background select **Graphical Settings** and change the settings as shown below.





Refer to the Online Help for more information about the other graphical settings.


Lesson Two – Exploring the View/Edit Component, continued

The display should now look as follows:



The Point symbols  indicate, that the point class is already *Measured*, as the points were measured in real time in the field. For some points (e.g. BM1) the point symbol  indicates, that the point class is *Averaged*, because these points have been occupied twice. For these two solutions a weighted average is automatically computed.

➤ Right-click on point **BM1** and select **Properties**. Alternatively you can also double-click on the point symbol.

If the point is not within the zooming extents, you can use the scroll-to point combobox and the Edit Point  toolbar button.

➤ Click the **Mean** tab in the property sheet.

The following Property page displays the two solutions and their differences to the weighted average:

Use	Reference Point	Epoch	State	Posn. diff	Hgt. diff
yes	TP306	03/24/1999 14:10:24	Automatic	0.0037	-0.0030
yes	B215	03/24/1999 15:27:23	Automatic	0.0052	0.0045

➤ Drag the horizontal scroll bar to the right to display more information.

➤ Click **OK** or **Cancel** to exit the property sheet.

Lesson Three - Exporting Coordinates to a Custom ASCII File

In this Lesson you will learn how to Export coordinates to a customized ASCII file. The *Custom ASCII File* export type is using a pre-defined format template file (*.frt) to export the data. Format template files can be created using the *Leica Geosystems Format Manager* program. To complete this exercise a sample format template file (sample.frt) is installed automatically on your computer with SKI-Pro. However If you wish to create your own format template file please refer to **Quick Tour III - Format Manager**.




You can export coordinates in a variety of other pre-defined formats. Please refer to the On-line Help on Export ASCII and Export GIS/CAD for more information.

While the Project is still open:

- From the **Export** menu select **ASCII**,
- or
- from the **Tools** List Bar or Toolbar select **Export ASCII Data**




The following dialog appears:



- Under **Save in** select a path.
- Under **Save as type** select **Custom ASCII File**.
- Enter a **File name** e.g. **RT Sample1** without extension.
- Click on the **Settings** button to change the settings and select the format template file.

Lesson Three - Exporting Coordinates to a Custom ASCII File, continued

The following Property page appears:



- To continue, click on the **Coordinate System** tab.
- Make sure the **Coordinate System *Sample RT*** is selected. By default the coordinate system attached to the current project is already selected.
- Click on **OK** to close the Settings property page, and finally,
- Click **Save** to write the file to the harddisk.

➤ Change Coord. Class to **Main**. The coordinate triplets of the highest class will be exported.


➤ Use the browser  to select the file
... \Shared\Templates\Format Manager\ **Sample.frt**.



Depending where you installed SKI-Pro the path for the sample file may vary slightly. By default SKI-Pro will be installed in:
C:\Program Files\Leica Geosystems\...

Lesson Three - Exporting Coordinates to a Custom ASCII File, continued

If you open the ASCII file with a Text Editor it will display the following information:



```
rt sample1.cst - Notepad
File Edit Search Help

Header Information
-----
Company Name                                     Company Address
-----

(For each point, this format file displays Point ID, Coordinates, CQ and Class.
On the next line is then the Coding Layer, Code ID and the Code Description. Note
also that this format is tab delimited.)

9001      549054.610      5248334.959      463.632      0.011      MEAS
ROAD      EB
EDGE OF BITUMEN

9002      549050.415      5248336.065      463.720      0.015      MEAS
ROAD      EB
EDGE OF BITUMEN

9003      549045.748      5248338.127      463.841      0.014      MEAS
ROAD      EB
EDGE OF BITUMEN

9004      549041.228      5248341.946      463.932      0.014      MEAS
ROAD      EB
EDGE OF BITUMEN

9005      549038.206      5248348.189      463.945      0.014      MEAS
ROAD      EB
EDGE OF BITUMEN

9006      549035.323      5248357.507      463.812      0.016      MEAS
```

Congratulations !

You have successfully completed this Quick Tour.

You have learnt how to create a Project, Import GPS real time data including the attached coordinate system, check the data in View/Edit and finally how to export these coordinates to a customized ASCII file.

Quick Tour II - Post-Processing

This Quick Tour is a step-by-step tutorial in which you learn to post-process GPS data from importing raw data to exporting final local Grid coordinates.



This exercise assumes that your green software protection dongle is connected and the two options **Data processing** and **Datum and Map** are activated.

The exercise comprises of the following scenario:

A rapid static network has been measured. It consists of the points TP214, B215, TP306, B218 and B313. The whole network has been measured with two receivers only. The raw data is given in the directories:

```
... \SkiPro\Data\SampleData\Sys500\Static\data1  
... \SkiPro\Data\SampleData\Sys500\Static\data2.
```

The local coordinates of the points B215, B218, B313 are known in *UTM Zone 32 North* Projection and *Bessel Ellipsoid*. The coordinates are given in the file:

```
... \SkiPro\Data\SampleData\Static\Local.txt
```

The local grid coordinates of the points **TP214** and **TP306** shall be derived.

This Quick Tour comprises of the following steps:

Lesson One

- Importing GPS raw data
- Creating a Project

Lesson Two

- Modifying reference coordinates
- Processing baselines

Lesson Three

- Creating a Coordinate System

Lesson Four

- Importing an ASCII file with local coordinates

Lesson Five

- Calculating Transformation Parameters

Lesson Six

- Using a Coordinate System with a Project

Lesson Seven

- Exporting Coordinates to an ASCII file


Lesson One - Starting a Project and Importing Raw Data


In Lesson One you will learn how to import GPS raw data and at the same time create a new Project.

Start-up SKI-Pro:

➤ From the **Start** menu select **Programs, SKI-Pro** and then click on **SKI-Pro**.


The main SKI-Pro window appears.



➤ From the **Import** menu or Toolbar select **GPS Raw Data** .


or

➤ from the **Tools** List Bar select **Import GPS Raw Data**.



Lesson One - Starting a Project and Importing Raw Data, continued

The following dialog appears:




- Under **Files of type:** select **GPS500 raw data**.
- Under **Look in:** select the directory that contains the sample data: ...*SkiPro*\Data*SampleData*\Sys500**Static**
- Check **Include subfolders:** all GPS500 raw data in the two sub-directories *data1* and *data2* will be imported in one run.



Depending where you installed SKI-Pro the path for the sample data may vary slightly. By default SKI-Pro will be installed in:
C:\Program Files\Leica Geosystems\...

- Click **Import**.

The following Property Sheet appears:




This is where you can view and modify the raw data. e.g. to change instrument heights or point id's.

As you have not yet created a Project the list of Projects is empty and you can not select an existing Project.

- Right-click on **Projects** and select **New**.

Lesson One - Starting a Project and Importing Raw Data, continued

The following dialog appears and allows you to create a new project while you are still in the Import (Assign) procedure:




➤ Under **Location** enter a path
e.g **C:\SKIProData\Projects**
Alternatively you may use the browser .

➤ Enter a **Project Name** e.g. **PP Sample**. Note that the directory *PP Sample* has been added automatically to the

path. This is necessary because a Project consists of several files and each Project shall be stored under a separate directory.

➤ Click **OK** to confirm. The New Project Dialog will be closed and a new Project will be created and selected automatically.



Alternatively you can also create a Project using the New Project command from the File menu or Toolbar or via the Project Management of the List Bar .

➤ Back in the Assign dialog select **Assign** and then **Close**.

The Project window will open automatically.


Continue with Lesson Two - Processing Baselines.

Lesson Two - Processing Baselines

In Lesson Two you will learn how to process and store baselines.

The Project window allows you to display the content of a Project by using different tabbed views. Click on the tabs below the window to switch between the different views.

View/Edit shows a graphical representation of each point of the Project.


The Point Symbols indicate that the point class is still *Navigated* . I.e. the accuracy of the points is low ($\pm 100\text{m}$).

In order to avoid that the results of the baselines are influenced by systematic errors, the coordinates of the first reference point in the network have to be known within about 20m in the WGS84 coordinate system.

This can be achieved by starting the GPS survey on a point with known WGS84 coordinate or by using a Single Point Processing for the starting point of the network.

Please refer to the on-line help on how to perform a Single Point Processing. In our case we will start the survey on a known point and therefore have to modify the coordinates of our first reference point.

➤ Right-click on point **B215** and select **Properties**.



Lesson Two - Processing Baselines, continued

The Point Property Sheet appears:

Point Properties

General | Stochastics | Thematical Data

Point Id: B215 Activated

Point Class: **Control**

Point Subclass: Fixed in Position and Height

Coordinate Type: Geodetic WGS84 Local

Coordinate Format: Latitude, Longitude, Height

Height Mode: Ellipsoidal Orthometric

Latitude: 47° 23' 45.92367 " N Standard deviation: 0 m

Longitude: 9° 38' 10.58353 " E Standard deviation: 0 m

Height: 429.279 m Standard deviation: 0 m

OK Cancel Apply

➤ Change the Point Class to **Control**.

➤ Change the Coordinates to the values below:

Latitude: 47° 23' 45.92367 N

Longitude: 9° 38' 10.58353 E

Height: 429.279 m


➤ Click **OK** to confirm.

The Point Symbol of point B215 indicates that the point class is now *Control*. ▲

You are now ready to switch to the Data-Processing View and select the baselines to be processed.

➤ Click the **Data-proc** tab at the bottom of the window.

The following View displays a list of all observation intervals and a graphical representation of the observation time for each interval:



Lesson Two - Processing Baselines, continued

A Baseline is always processed between a Reference point and a Rover point. In the graphical window all observations are represented by horizontal bars which you can select as Reference or Rover.

In our network the point B215 was first used as a Reference and the points TP214, TP306, B313 and B218 have been observed as Rover points.

Afterwards point B218 was used as the Reference and the points TP214, B215 and B313 were observed as Rover.

Finally point B313 was the Reference and TP306 was the Rover.

Therefore to process all baselines we have to make three processing runs.

➤ Right-click on the background of the graphical window, click on **Select Mode** and then **Rover**.

-or-

➤ click on  **Select Mode: Rover** from the Toolbar.

The cursor indicates Rover.

➤ Click on the horizontal bars of the first instant of point **TP214**, **TP306**, **B313** and **B218**.

The colour of the Rover intervals changes to Green.

To select the Reference point:

➤ Right-click on the horizontal bar of point **B215** and select **Reference**.


The colour of the Reference interval changes to Red.

We are now ready to start the first processing run and process four baselines.

➤ Right-click on the background and select **Process** or


➤ click on  **Process** from the Toolbar.

A progress indicator will be displayed and the number below indicates which baseline out of the total number is currently being processed.



Lesson Two - Processing Baselines, continued

After the processing run is completed the display will automatically switch to the Results-View allowing you to examine and store the processed baselines:



The screenshot shows a software interface with a tree view on the left and a table on the right. The tree view shows a folder named 'Results' containing sub-folders for 'Baselines', 'Points', 'Parameters', and 'Logfile'. The table on the right has the following data:

Point Id	Epoch	Stored Status	Ambiguity Status	
TP214	12/21/1998 14:01:45	no	yes	42647
TP306	12/21/1998 14:22:00	no	yes	42643
B313	12/21/1998 14:39:00	no	yes	42656
B218	12/21/1998 14:57:30	no	yes	42656

All Rover points are listed together with its coordinates, quality and the Ambiguity Status. The points for which the Ambiguity Status is **yes** are selected automatically.

What does Ambiguity Status mean?

The Ambiguity Status is an essential indicator if you want to achieve centimetre level accuracy with short observation times (Rapid Static).

Ambiguity Status **yes** indicates that the determination of the integer number of cycles between the satellites and the GPS receiver was successful, i.e. the baseline calculation is correct.

Ambiguity Status **yes*** indicates that the result should be treated with caution.

Ambiguity Status **no** indicates that the ambiguities could not be resolved.

Ambiguity Status **?** indicates that no attempt was made to resolve the ambiguities.


If the Ambiguity Status is **no** or **?** you may further analyse the data by viewing the Logfile. Please refer to the On-line Help for more information about the Logfile.



By default, ambiguities can only be resolved for baselines up to 20 km. For longer distances the ambiguity resolution becomes unreliable. To achieve good results on baselines longer than 20 km you will need to observe for longer periods of time e.g. 1 hour or more.

Lesson Two - Processing Baselines, continued

In our case the Ambiguity Status is **Yes** for all points (baselines) and we can store the coordinates to the database.


➤ Right-click on the selected points and select **Store** or use the toolbar .

The results of the four baselines are now stored in the database.

➤ To verify that the baselines have been stored, click the **View/Edit** tab at the bottom of the window.

➤ Right-click in the background and select **Graphical Settings...** Make sure **GPS** is checked.

The following view is displayed:



To complete the network we have to process the remaining two processing runs.

➤ To return to the Data-Processing View click the **Data-proc** tab.


➤ Right-click on the background and click on **Deselect All**.

➤ Select the second instant of the points **TP214**, **B215**, **B313** as Rover and the point **B218** as Reference.

➤ **Process** and **Store** the second run.

➤ Finally, **Select**, **Process** and **Store** the remaining baseline between **B313** and **TP306**.

The following view is displayed:



Lesson Two - Processing Baselines, continued

In View/Edit you will notice that the point symbols have now changed for all points. The point classes are no longer *Navigated*. Points that have been used as reference points are now awarded the point class *Reference* ▾. Others have point class *Measured* ⊙ or, if they have been measured from two different reference stations, class *Averaged* ⊙.



In a project database there may exist many coordinate triplets for any one point. The coordinate classes represent the hierarchical order of a coordinate triplet. SKI-Pro always displays the coordinate triplet with the highest class for each point as default. For a complete list of all Coordinate Classes refer to the On-line Help.

The points TP214 and TP306 consist of two coordinate triplets of class *Measured* ⊙. From these two coordinate triplets a weighted average is calculated automatically and a new coordinate triplet of class *Averaged* ⊙ is displayed.

➤ Right-click on point **TP214** and select **Properties**. Click the **Mean** tab on the top of the Property Sheet.

The following Property Sheet displays the two solutions and their differences to the weighted average:

Use	Reference Point	Epoch	State	Posn.diff	Hgt. diff	Posn. + Hgt
yes	B215	12/21/1998 14:01:44	Automatic	0.0057	0.0064	0.0
yes	B218	12/21/1998 15:16:45	Automatic	0.0089	-0.0038	0.0


- Drag the horizontal scroll bar to the right to display more information.
- Click **OK** or **Cancel** to exit the Property Sheet.

Lesson Two - Processing Baselines, continued

To display all point information in a Report-View:

- Click the **Points** tab at the bottom of the window.

The following view is displayed:



Point Id	Point Class	Epoch	Latitude	Longitude	Ellip. Hgt.
<input checked="" type="checkbox"/> B215	Control	06/08/2000 11:44:28	47° 23' 45.92367" N	9° 38' 10.58353" E	429.2790
<input checked="" type="checkbox"/> B218	Reference	12/21/1998 14:57:29	47° 23' 11.07196" N	9° 37' 13.44096" E	431.9235
<input checked="" type="checkbox"/> B313	Reference	06/09/2000 08:32:34	47° 22' 58.25933" N	9° 38' 36.56183" E	441.6392
<input checked="" type="checkbox"/> TP214	Averaged	06/09/2000 08:32:34	47° 23' 51.97413" N	9° 37' 11.40874" E	430.1684
<input checked="" type="checkbox"/> TP306	Averaged	06/09/2000 08:32:47	47° 23' 51.90869" N	9° 39' 03.43769" E	437.1632

To change the width of a column:

- Drag the right side of a column header as required.
- or
- Right-click on any column header and select **Auto arrange**. All columns will be arranged automatically.


To sort the list:

- Click on a column header. The records will be sorted in ascending or descending order according to the selected column.

To display and hide information:

- Right-click on a column header and select **Hide**.
- Right-click on any column header, select **View** and select the required item from the list.


To print the content of the Report-View:

- From the **File** menu or Toolbar select **Print** .



The print function can be accessed from any view, be it a Graphical-View or a Report-View.

You have now finished the data processing. Five points in the WGS84 coordinate system with centimetre accuracy are now available.

- From the **Window** menu select **Close** or click the lower  icon in the top right corner.

Continue with Lesson Three - Creating a Coordinate System

Lesson Three - Creating a Coordinate System

In this Lesson you will learn how to create a Coordinate System.

A Coordinate System defines the parameters used to calculate different coordinate representations. If a Coordinate System is attached to a Project or a Coordinate Set it enables you to switch between displaying the coordinates in Cartesian (X,Y,Z), Geodetic (Latitude, Longitude, Height) or Grid (Easting, Northing, Height) format. Additionally if a Transformation is defined you can switch the coordinates of a Project between the WGS84 and a local datum.


What we already know of our Coordinate System is that the local Ellipsoid is *Bessel* and the Map Projection is *UTM32 North*. The Transformation is not yet known and has to be determined by using the Datum/Map tool first.

To open the Coordinate System Management:

➤ From the **Tools** menu or **Management** List Bar, select **Coordinate System Management**.




The following Explorer-View appears:



First you have to define the Map Projection:

➤ In the Tree-View right-click on **Projection** and select **New**.

The following Property page appears:




➤ Fill in the Property page as above.

➤ Click **OK** to confirm.

Lesson Three - Creating a Coordinate System, continued

➤ In the Tree-View right-click on **Coordinate Systems** and select **New**.


The following Property page appears:



The screenshot shows a dialog box titled "New Coordinate System" with a "General" tab. The dialog contains the following fields and options:

- Name: Text box containing "FP Sample"
- Transformation: Dropdown menu set to "None"
- Trans. Type: Empty text box
- Residuals: Dropdown menu set to "No distribution"
- Ellipsoid: Dropdown menu set to "Bessel"
- Projection: Dropdown menu set to "UTM 32 North"
- Proj. Type: Text box containing "UTM"
- Geoid Model: Dropdown menu set to "None"
- Note: Empty text box

At the bottom of the dialog are "OK" and "Cancel" buttons.

- Fill in the Property page as above.
- Click **OK** to confirm.
- From the **Window** menu select **Close** or click the lower  icon in the top right corner to close the Coordinate System Management.


Lesson Four - Importing an ASCII File

In this Lesson you will learn how to import the local control points from a user defined ASCII file and create a Coordinate Set.

- From the **Import** menu click **ASCII data**.
- or
- from the **Tools** List Bar click **Import ASCII Data**



The following dialog appears:




- Choose the file type **Text files**.
- Under **Look in** select the directory that also contains the sample data: ...\\SkiPro\\Data\\SampleData\\Sys500**Static**
- Select the file **Local.txt**

- Under Coordinate System select **Local**.

- Click **Import**.

This is the first time you are importing an ASCII file of this type. The import Wizard for user defined ASCII files appears automatically, allowing you to define the file format:



The file to be imported is a simple ASCII file. The local coordinates of the points B215, B218 and B313 are separated with spaces and neither a column header nor a keyword is defined.

- Click **Free** and then **Next** to continue.

Lesson Four - Importing an ASCII File, continued

The Wizard Step 2 appears:

User Defined ASCII File Import Wizard - Step 2 of 4

Here you can select the appropriate column delimiter character. The data preview window automatically displays how the data will be imported.

Column Separators:

Tab Semicolon Comma Treat consecutive delimiters as one

Space Other:

0	1	2	3	
B215	548107.0800	5248990.9500	476.8100	
B218	546917.8800	5247905.3700	479.4100	
B313	548663.8100	5247524.0200	489.1200	

< Back **Next >** Cancel

- Check **Space**, the columns will be selected automatically.
- Click **Next** to continue.

The Wizard Step 3 appears:

User Defined ASCII File Import Wizard - Step 3 of 4

Here you assign headers to the selected columns. Select the desired column and use the right mouse button to assign the headers from the pop-up list.

Coordinate Type: Attribute Separator:

Linear Units: File Type: Point Baseline

Default Coord. Class:

Poi..	Easting	2	3	
B215	548107.0800	524899		
B218	546917.8800	524790		
B313	548663.8100	524752		

Context Menu (over column 1):

- Coordinates
- Coordinate Class
- Coordinate Quality
- Coordinate Type
- Variance
- Error Ellipse
- Reliability
- Thematical Code
- Layer
- Attribute
- Annotation

Sub-menu (over column 2):

- Easting
- Northing**
- Ell. Height
- Geoid-Sep

Next > Cancel

- Right-click on the first column heading (0) and select **Point Id**
- Right-click on the second column heading (1) and select **Coordinates** and then **Easting**.
- Select **Northing** and **Ell. Height** for the third (2) and fourth (3) column respectively.
- Click on **Next** to continue.

Lesson Four - Importing an ASCII File, continued

The Wizard Step 4 appears:

Enter a name for the mask if you would like to store this template in the database. Use SaveAs to store this template to a file.

Mask Name: Save As...

Poi...	Easting	Northing	Ell. Height
B2 15	548 107.0800	5248890.9500	476.8100
B2 18	546917.8800	5247905.3700	479.4100
B3 13	548663.8100	5247524.0200	489.1200

< Back Finish Cancel

➤ Click on **Finish** to close the Wizard.



If you want to import coordinate files of the same type again you can enter a Mask Name and then use this Mask as a Template the next time you import an ASCII file.

You can now assign the points to either a Project or a Coordinate Set. Since these are our control points for the determination of the transformation parameters we will assign them to a Coordinate Set.

➤ Right-click on **Coordinate Sets** and select **New**.

The following Property-Sheet appears:

General Dictionary

Coordinate Set Name : PP Sample local

Coordinate Type : Unknown

WGS84 Local

Coordinate System : PP Sample View...


Ellipsoid : Bessel Transformation : Not Used
Projection : UTM32 Geoid Model :

OK Cancel

- Enter the **Coordinate Set Name** e.g. *PP Sample local*.
- Select the Coordinate System **PP Sample** from the list.
- Click on **OK** to confirm.


Lesson Four - Importing an ASCII File, continued

The Coordinate Set is created and selected automatically:



➤ Click on **Assign** and then **Close**.

The Coordinate Set will open automatically and display the local coordinates for the points B215, B218 and B313.

➤ From the **Window** menu select **Close** or click the lower  icon in the top right corner.

Lesson Five - Calculating Transformation Parameters

In this Lesson you will learn how to use the Datum/Map tool to calculate the transformation parameters.

In order to be able to calculate Transformation parameters we need two sets of coordinates. The first set will be the coordinates of our Project *PP Sample* in the WGS84 coordinate system. The second set will be the imported local coordinates from the Coordinate Set *PP Sample local*.

➤ From the **Tools** menu click **Datum/Map**.

or

➤ from the **Tools** List Bar or Toolbar click **Datum and Map**.



The following view appears:

Contents	Property	Value
Projects	Name	PP Sample
PP Sample	Location	D:\ski_projects\PP_Sample\
Coordinate Sets	Date Created	05/31/2000 10:08:33
	Last Used	06/08/2000 10:22:58
	Avg. Limit Pos.	0.0750
	Avg. Limit Hgt.	0.0750
	Coordinate System	WGS 1984
	Compute Mod. Grid Coordinates	No
	Avg. Combined Factor	1.0000
	Northing Shift	0.0000
	Easting Shift	0.0000
	Time Zone	1h00'
	Manager	
	Client	
	Street	


Contents	Property	Value
Projects	Name	PP Sample local
Coordinate Sets	Type	Grid
PP Sample local	Note	
	Date Created	06/08/2000 11:24:58
	Last Used	06/08/2000 11:25:03
	Coordinate System	PP Sample
	No. Points	3
	Manager	
	Client	
	Street	
	Map Reference	
	Print Header	
	Print Footer	

Selection Match Results Chart Report

- In the upper Tree-View open the **Projects** folder and select **PP Sample**.
- In the lower Tree-View open the **Coordinate Sets** folder and select **PP Sample local**.
- Click on the **Match** tab to continue.

Lesson Five - Calculating Transformation Parameters, continued

The following view appears:




The *Classical 3D* is the transformation type that should normally be used when the local Ellipsoid and the Map Projection is known. However SKI-Pro supports a variety of different transformation types. Please refer to the On-line Help for more information.

You can select the common points of system A and system B by selecting them manually or by using the Auto Match command:

- Right-click on the background in one of the views and select **Auto Match**.
- Click the **Results** tab to continue.

The transformation parameters are instantly calculated.

To configure the Transformation type:

➤ Right-click on the background in one of the views and select Configuration or use the Toolbar button .

➤ Under **Transformation** select **Classical 3D** and confirm with **OK**.

Lesson Five - Calculating Transformation Parameters, continued

The following view appears and displays the residuals:

System A	System B	X	Y	Z	Position+Height
B215	B215	0.0018	-0.0012	-0.0015	0.0026
B218	B218	-0.0014	-0.0012	0.0014	0.0023
B313	B313	-0.0004	0.0023	0.0000	0.0024

Store transformation parameter set

Name of new parameter set : PP Sample WGS-local

Automatically create new coordinate system

Name of new coordinate system : PP Sample WGS-local

Automatically attach to project A and close Datum / Map

OK Cancel

Selection Match Results Chart Report

This view allows you to judge the quality of the transformation. Additionally you may display a **Chart** of the residuals or a **Report** by clicking on the appropriate tabs at the bottom of the window.

➤ Right-click on the background and select **Store**.

The following dialog allows you to store the transformation parameters, create a new coordinate system based on the coordinate system of *System B* and attach it to the project (*System A*).

➤ Enter a name e.g. **PP Sample WGS-local**, check the two boxes and click on **OK** to confirm.



By default the names of the new transformation parameter set and the new coordinate system are the same. You may change the name of the coordinate system if you wish.

The transformation parameters and the new coordinate system are now stored and the new coordinate system is already attached to the project.

Continue with Lesson Six - Using a Coordinate System.

Lesson Six - Using a Coordinate System with a Project

In this Lesson you will learn how to use a Coordinate System with a Project and switch between WGS84 and local coordinates.

If the Project Management is not already open:


➤ From the **Management List Bar**, select **Project Management**.



➤ Right-click on the Project **PP Sample** and select **Properties**.

➤ Click on the **Coordinates** tab.

The following dialog appears:



Here you can check that the new Coordinate System is attached to the Project and verify the parameters. Ellipsoid: *Bessel*, Map Projection: *UTM 32 North* and Transformation: *PP Sample WGS-local* should now be displayed.

➤ Click **OK** to continue.

➤ Right-click on the Project **PP Sample** and select **Open**.

The Project window opens with the last used View active.

➤ Select the Points tab.

The view displays WGS 1984 coordinates in Geodetic format:

Project PP Sample

Point Id	Point Class	Epoch	Latitude	Longitude	Ellip. Hgt.
<input checked="" type="checkbox"/> B215	Control	06/08/2000 11:44:28	47° 23' 45.92367" N	9° 38' 10.58353" E	429.2790
<input checked="" type="checkbox"/> B218	Reference	12/21/1998 14:57:29	47° 23' 11.07196" N	9° 37' 13.44096" E	431.9235
<input checked="" type="checkbox"/> B313	Reference	06/09/2000 08:32:34	47° 22' 58.25933" N	9° 38' 36.56183" E	441.6392
<input checked="" type="checkbox"/> TP214	Averaged	06/09/2000 08:32:34	47° 23' 51.97413" N	9° 37' 11.40874" E	430.1684
<input checked="" type="checkbox"/> TP306	Averaged	06/09/2000 08:32:47	47° 23' 51.90869" N	9° 39' 03.43769" E	437.1632

View/E... Data-pr... Adjustme... Poin... Antenn... Resul... Codelist

Lesson Six - Using a Coordinate System with a Project, continued

Since you are now using a Coordinate System with Ellipsoid, Map Projection and Transformation defined, you are able to switch the Coordinate System to Local and change the Coordinate type to Grid.

Using the Coordinate Format Toolbar it is possible to switch between the following different possibilities:

- WGS 1984 Cartesian
- WGS 1984 Geodetic
- Local Cartesian
- Local Geodetic (Bessel Ellipsoid)
- Local Grid (UTM 32 North Projection)

➤ From the Toolbar click on **Local** and then **Grid**.



The local grid coordinates of the unknown points **TP214** and **TP306** are now available.

You may now print the list
or
continue with Lesson Seven - Exporting local coordinates to an ASCII file.

The view displays Local coordinates in Grid format:

Point Id	Point Class	Epoch	Easting	Northing	Ellip. Hgt.
<input checked="" type="checkbox"/> 8215	Control	12/21/1998 12:49:44	548107.0785	5248990.9478	476.8100
<input checked="" type="checkbox"/> 8218	Reference	12/21/1998 13:57:29	546917.8791	5247905.3721	479.4100
<input checked="" type="checkbox"/> 8313	Reference	06/19/2000 14:12:19	548663.8124	5247524.0201	489.1200
<input checked="" type="checkbox"/> TP214	Averaged	06/19/2000 14:12:19	546865.1955	5249167.6967	477.7000
<input checked="" type="checkbox"/> TP306	Averaged	06/19/2000 14:12:28	549213.4321	5249184.8885	484.7063

View/Edit | Data-proc | Adjustment | Points | Antennas | Results | Codelist

Lesson Seven - Exporting Coordinates to an ASCII File

In this Lesson you will learn how to Export coordinates to a user defined ASCII file.




You can export coordinates to a variety of other pre-defined formats. Please refer to the On-line Help Export ASCII and Export GIS/ CAD for more information.

While the Project is still open:

- From the **Export** menu select **ASCII**,
- or
- from the **Tools** List Bar or Toolbar select **Export ASCII Data**.



The following dialog appears:




- Under **Save in** select a path.
- Under **Save as type** select **Text File**.
- Enter a **File name** e.g. **PP Sample1** without extension.

Since you are using this export type for the first time you have to modify the Settings:

- Click on the **Settings** button to change the export settings.


Lesson Seven - Exporting Coordinates to an ASCII File, continued

The following Property page appears:



- Change Coord Type to **Local** and **Grid**.
- Change Coord. Class to **Main**. The coordinate triplets of the highest class will be exported.
- To continue, click on the **Points** tab.

The following Property page appears:




Here you can define the actual point list of the ASCII file. You can select the items to export in the order you want.

- Double-click on **Point Id** then **Easting**, then **Northing** then **Ell. Height**.
- To continue, click on the **Coordinate System** tab.

Lesson Seven - Exporting Coordinates to an ASCII File, continued

- Make sure the **Coordinate System** *PP Sample WGS-Local* is selected.
- Click on **OK** to close the Settings property page, and finally,
- Click **Save** to write the file to the harddisk.

If you open the ASCII file with a Text Editor it will display the following information:



```
PP Sample1.txt - Notepad
File Edit Search Help
B215  548107.08    5248990.95    476.81
B218  546917.88    5247905.37    479.41
B313  548663.81    5247524.02    489.12
TP214 546865.20    5249167.70    477.70
TP306 549213.43    5249184.89    484.71
```

Congratulations !

You have successfully completed this Quick Tour.

You have learnt how to start a Project, Import GPS raw data, process baselines, determine a transformation, how to derive local Grid coordinates and finally how to export these coordinates to a user-defined ASCII file.

Quick Tour III - Format Manager

Lesson One - Creating a Format Template File

This Quick Tour is a step-by-step tutorial in which you learn how to work with the Leica Geosystems Format Manager program. For further details see the 'Getting Started with Format Manager' manual.

The Format Manager is installed as an external program during the SKI-Pro installation. It allows the creation of a Format Template file (*.frt) which can be used within SKI-Pro to export data to a customized ASCII file. *Custom ASCII File* export is the most flexible ASCII export type.

For more information refer to **Quick Tour I - Real Time** or the online help of SKI-Pro.

Additionally a Format Template file can be uploaded to the Sensor to convert Jobs to an ASCII file directly on the field system.



This exercise does NOT need your green software protection dongle to be connected.

This Quick Tour comprises of the following steps:

Lesson One


- Creating a Format Template File

Lesson Two


- Uploading a Format Template File to the Sensor

Start-up the Format Manager:

- From the **Start** menu select **Programs**, **SKI-Pro** and then click on **Format Manager**.




The main Format Manager window appears.

- From the **File** menu select **New** or
- Click on  to create a new mask.


Lesson One - Creating a Format Template File, continued

The following dialog appears:



- Select Instrument class **GPS500**.
- Click **OK** to confirm.

The workspace displays a tree-view on the left hand side:



To start creating the mask the tree-view has to be expanded.

- Double-click on **Export Formatstrings**, then double-click on **Fixpoint (TPS/GPS)** and finally click on **Exportstring**.

A dialogue appears with the available variables, which can be exported.

Lesson One - Creating a Format Template File, continued

- For this example double-click on the following variables:

Point ID (Target)

Target (North)

Target (East)

Target (Elev)



Target (Elev) stands for Orthometric Height, in order to export Ellipsoid Height you have to select *Local Ellipsoid Height*.

The list is filled automatically and displayed as follows:

«Point ID (Target)»«Target (North)»«Target (East)»«Target (Elev)»
PP123-985123333.5650000004140123.87700000001000.2230000000

- To add thematical information change the combo box *Datablock-Type* to **Code(TPS/GPS)**.

- Double-click on the following variables:

Code ID

Code description

- To add quality information change the combo box *Datablock-Type* to **Quality Information (GPS)**.

- Double-click on the following variable:
3D Coordinate Quality.

The thematical and the quality information shall be written to the second line of each data block.

- Move the cursor between the >> << symbols of <<*Target (Elev)*>> and <<*Code ID*>> and press **ENTER** to get a carriage return (new line) after *Target (Elev)*.

- Go to the end of the second line and press **ENTER** to ensure that each data block starts at a new line!

- To set the delimiter between the variables click between the >> << symbols of each variable and press the **TAB** key.



As delimiter you can use any character from the keyboard. Even a combination of several characters is possible.

Lesson One - Creating a Format Template File, continued

The display should now look as follows:

```
«Point · ID · (Target)»→«Target · (North)»→«Target · (East)»→«Target · (Elev)»
«Code · ID»→«Code · description»→«3D · Coordinate · Quality»

PP123-98  5123333565.0000003000  140123877.0000000000  1000223.000
Tree01  This is a  6324.5000000000
```

Note, that the lower window changes and shows an example of how your string will look like using dummy values.

At the moment the variables with real numbers contain 10 digits after the decimal point. This formatting can be changed for every variable.

➤ In the upper window **double-click** on each variable name and change the formatting properties. For this example set the *Precision* to **3** for *Easting*, *Northing* and *Elevation*, and to **2** for the *3D Coordinate Quality*.

For more information about the variable formatting refer to the online help.

➤ Finally from the **File** menu select **Save** and enter a name for the format file. The extension (*.FRT) will be added automatically.

Congratulations !

You have learnt how to create a simple customized format mask. Now you can use this format file as an export template either directly on board the sensor or from within SKI-Pro using the *Custom ASCII Export*.

For the *Custom ASCII Export* of SKI-Pro please refer to the **Quick Tour I - Real Time** of this book.

If you want to use the format mask file on the System 500 sensors, proceed with Lesson Two - Uploading a Format Template File to the Sensor


Lesson Two - Uploading a Format Template File to the Sensor

On the PC:

➤ **Copy** the file onto your Sensor into the **CONVERT** subdirectory of the PCMCIA card

or

➤ If you have no PCMCIA slot on your PC, transfer the file to the sensor using the Sensor transfer component of SKI-Pro. In the tree-view **right-click** on **Sensor** and select **Transfer Any File**.



On the Sensor:


➤ Select **Transfer**, then **GSI/ User File**. Select the *Job* you want to convert, the *Format* file and give a *File* name.

➤ Note that Format Files need to be stored in the System RAM of the Sensor. Press **FORMT (F3)** to transfer such files from the \CONVERT directory of the PC Card or internal memory to the System RAM or vice versa.

➤ Under *Destinatn* select **User File**, then the converted file will be written into the DATA directory on the PCMCIA card.

➤ **FILT (F6)** allows to select a filter and set the sort order.

➤ **CONT (F1)** to write the file.



For further details please refer to the *Technical Reference* manual, available as an online PDF-file.

Quick Tour IV - GIS/CAD Export

This Quick Tour is a step-by-step tutorial in which you learn how to export data from SKI-Pro to a GIS or CAD System using the DXF format.

The GIS/CAD Export requires a DXF-header file. A DXF-header file can be created in your CAD package and contains all block and attribute definitions, layer definitions, line styles, drawing extents and other settings needed by your GIS/CAD program in order to convert the DXF file into a drawing file. The DXF header file should be based on your GIS/CAD template file such that it contains all definitions that you work with. For information on how to create a DXF-header file please refer to the documentation of your GIS/CAD software package.

To complete this exercise a DXF-header sample file is already copied to your harddisk with the installation of SKI-Pro.



This exercise assumes that your green software protection dongle is connected and the option **GIS/CAD Export** is activated.



Before you start with this Quick Tour make sure that you have already imported the real time sample data into SKI-Pro as explained in **Quick Tour I - Real Time**.

Quick Tour IV - GIS/CAD Export, continued


➤ Open the Project **RT Sample**, then click on the **Points** tab to display local grid coordinates.




The following list should be displayed:

Point Id	Point Class	Epoch	Easting	Northing	Ellip. Hgt.	Posn. + H...
✓ BM4	Averaged	07/21/1999 09:35:04	549015.6877	5248399.5450	463.6816	0.0109
✓ BM3	Averaged	07/21/1999 09:35:04	549001.5503	5248386.3083	464.7723	0.0079
✓ BM2	Averaged	07/21/1999 09:35:04	548998.7767	5248379.5363	464.8289	0.0030
✓ BM1	Averaged	07/21/1999 09:35:04	548995.1957	5248368.2212	464.7304	0.0063
✓ B215	Reference	03/24/1999 15:27:49	548105.1604	5248994.1254	455.2429	0.0000
✓ 9063	Measured	03/24/1999 14:37:29	549009.5777	5248393.6259	464.7209	0.0163
✓ 9062	Measured	03/24/1999 14:37:15	549010.5860	5248400.1653	464.5126	0.0121
✓ 9061	Measured	03/24/1999 14:37:02	549010.0274	5248405.7410	464.5815	0.0169
✓ H12	Measured	03/24/1999 14:36:05	549006.1907	5248400.8876	464.7970	0.0140
✓ H11	Measured	03/24/1999 14:35:50	549000.7209	5248401.3396	464.9044	0.0147
✓ H10	Measured	03/24/1999 14:35:35	549000.0159	5248393.4023	464.8833	0.0129
✓ H09	Measured	03/24/1999 14:35:23	549005.4558	5248392.9007	464.7437	0.0124
✓ H08	Measured	03/24/1999 14:34:07	549008.3694	5248381.4031	464.3689	0.0154
✓ H07	Measured	03/24/1999 14:33:53	549013.1217	5248379.8427	464.0770	0.0162
✓ H06	Measured	03/24/1999 14:33:34	549011.5094	5248375.0657	464.3543	0.0194
✓ H05	Measured	03/24/1999 14:33:16	549006.7832	5248376.6532	464.5458	0.0125
✓ H04	Measured	03/24/1999 14:32:50	549006.0649	5248372.1503	464.4946	0.0149
✓ H03	Measured	03/24/1999 14:32:35	549002.0657	5248373.4913	464.6176	0.0146
✓ H02	Measured	03/24/1999 14:32:19	548999.9109	5248366.9922	464.5976	0.0182
✓ H01	Measured	03/24/1999 14:32:02	549003.8989	5248365.6870	464.4924	0.0114

If you start the GIS/CAD Export with no Project open the program will prompt you to select a Project from the list before showing the following dialog:



➤ Under **Save as type** select **AutoCAD Files (*.dxf; *.dwg)**.

- From the **Export** menu select **GIS/CAD...**
- or
- Click on  from the **Toolbar**.

We now have to create a new Lookup Table. A Lookup Table enables you to match thematical codes used in the field with blocks in the DXF-header file. Thus every thematical code can be matched with the required symbol in your CAD/GIS package.


Quick Tour IV - GIS/CAD Export, continued

➤ In the **Lookup Table** box **right-click** and select **New** to create a new lookup table.



Once a lookup table is created it is available for future use.


The following property sheet appears:



➤ Enter a **Lookup Table Name**.

➤ To continue click the **AutoCAD Settings** tab.

The following property sheet appears:



Here we select the DXF- header file for use for the GIS/ CAD Export.

➤ Use the browser  to select the file
... \Shared\Templates\GisCad\Sample_head.dxf



Depending where you installed SKI-Pro the path for the sample file may vary slightly. By default SKI-Pro will be installed in:
C:\Program Files\Leica Geosystems\...


➤ Click **OK** to confirm the Lookup Table Settings.

The **Export File** dialog appears again and the **Lookup** button is now active.

➤ To continue click the **Lookup** button.

Quick Tour IV - GIS/CAD Export, continued


The following property sheet appears:



On the left hand side is a tree view of the codelist used in the field. On the right hand side you can open boxes for the AutoCAD Layers and Blocks as defined in the DXF-header file. You have to match the thematical codes used in the field with the AutoCad Coding (Layers and Blocks).

Additionally it is possible to match the attributes of each “Leica Geosystems” Code with the attributes as defined for the AutoCAD blocks.

To match the first “Leica Geosystems” Code with the AutoCAD Coding proceed as follows:

- In the Tree-View on the left expand all Layers by clicking on the  icons.
- In the Tree-View click on **BM** and select **LAYER1** and **BENCHMARK** from the combo boxes.
- In the Attributes window right-click, select **Add Extra Attribute** and then **Point Id**.
- Right-click again, select **AutoCAD Attribute** and then **POINTID**.
- In the same manner match the *Extra Attribute Elevation* with the *AutoCAD Attribute HEIGHT*.

The Code *BM* is now matched!



In the Sample Project the codes do not contain Attributes. Therefore it is only possible to match the default Attributes *Point Id* and *Elevation*.

Quick Tour IV - GIS/CAD Export, continued

➤ Continue to match the remaining “Leica Geosystems” Codes according to the list below:








“Leica Geosystems” Code	“Leica Geosystems” Attributes	Block Symbol and Attributes	AutoCAD Layer	AutoCAD Block	AutoCAD Attributes
BLDG (and) HOUS	Point Id Elevation	 PT123 345.780	Layer 2	CROSS_PT	POINTID HEIGHT
SHED	Point Id Elevation	 254 122.846	Layer 4	MEAS-POINT	POINTID HEIGHT
BM	Point Id Elevation	 PT2 122.345	Layer 1	BENCHMARK	POINTID HEIGHT
SM	Point Id Elevation	 A-26 123.142	Layer 6	MANHOLE	POINTID HEIGHT
EB	Elevation	 122.365	Layer 3	EDGE_BITUMEN	HEIGHT
EL	Point Id Elevation	 Test 122.318	Layer 5	LIGHTPOLE	POINTID HEIGHT

Table 1: Block definitions of the DXF-header file *sample_head.dxf*

➤ When all the Codes are matched click **OK** to confirm.


Quick Tour IV - GIS/CAD Export, continued

The following dialog appears again:



- Click the **Settings** button.


The following Property sheet appears:



- Change Coord. Class to **Main**. The coordinate triplets of the highest class will be exported.
 - Make sure the **Coord Type** is set to **Grid** and **Local**.
 - To continue, click on the **Coordinate System** tab.
 - Make sure the **Coordinate System Sample RT** is selected.
 - To continue, click on the **AutoCAD** tab. Ensure that the **Format** is set to **DXF** as this is the ASCII format which is supported by most GIS/CAD packages.
- The remaining settings do not matter for this exercise.
- Click on **OK** to close the Settings property page.

Quick Tour IV - GIS/CAD Export, continued

The following dialog appears once again:



➤ Enter a **File name** and ensure the correct path. The extension *.DXF will be added automatically.


and finally,

➤ Click **Save** to export the file.

Congratulations !

You have successfully created a GIS/CAD file in DXF-format.

You can now import the file into your GIS/CAD package. It should then look as follows:



***Leica Geosystems AG, Heerbrugg,
Switzerland, has been certified as
being equipped with a quality system
which meets the International Stan-
dards of Quality Management and
Quality Systems (ISO standard 9001)
and Environmental Management
Systems (ISO standard 14001).***



***Total Quality Management-
Our commitment to total customer
satisfaction***

*Ask your local Leica Geosystems agent
for more information about our TQM
program*

712223-2.0.0en

Printed in Switzerland - Copyright Leica
Geosystems AG, Heerbrugg, Switzerland 2000
Original text

Leica
Geosystems

*Leica Geosystems AG
CH-9435 Heerbrugg
(Switzerland)
Phone +41 71 727 31 31
Fax +41 71 727 46 73
www.leica-geosystems.com*