HD IR Waterproof Network Dome Camera

User's Manual

Version 4.0.1

Welcome

Thank you for purchasing our Network camera!

This user's manual is designed to be a reference tool for your system.

Please read the following safeguard and warnings carefully before you use this series product!

Please keep this user's manual well for future reference!

Important Safeguards and Warnings

1 . Electrical safety

All installation and operation here should conform to your local electrical safety codes. The power shall conform to the requirement in the SELV (Safety Extra Low Voltage) and the Limited power source is rated 12V or 24V AC DC in the IEC60950-1. (Refer to general introduction)

Please note: Do not connect two power supplying sources to the device at the same time; it may result in device damage!

We assume no liability or responsibility for all the fires or electrical shock caused by improper handling or installation.

We are not liable for any problems caused by unauthorized modification or attempted repair.

2. Transportation security

Heavy stress, violent vibration or water splash are not allowed during transportation, storage and installation.

3 . Installation

Do not apply power to the camera before completing installation. Please install the proper power cut-off device during the installation connection. Always follow the instruction guide the manufacturer recommended.

4 . Qualified engineers needed

All the examination and repair work should be done by the qualified service engineers. We are not liable for any problems caused by unauthorized modifications or attempted repair.

5. Environment

This series network camera should be installed in a cool, dry place away from direct sunlight, inflammable, explosive substances and etc.

Please keep it away from the electromagnetic radiation object and environment.

Please make sure the CCD (CMOS) component is out of the radiation of the laser beam device.

Otherwise it may result in CCD (CMOS) optical component damage.

Please keep the sound ventilation.

Do not allow the water and other liquid falling into the camera.

Thunder-proof device is recommended to be adopted to better prevent thunder.

The grounding studs of the product are recommended to be grounded to further enhance the reliability of the camera.

6. Daily Maintenance

Please shut down the device and then unplug the power cable before you begin daily maintenance work.

Do not touch the CCD (CMOS) optic component. You can use the blower to clean the dust on the lens surface.

Always use the dry soft cloth to clean the device. If there is too much dust, please use the water to dilute the mild detergent first and then use it to clean the device. Finally use the dry cloth to clean the device.

Please put the dustproof cap to protect the CCD (CMOS) component when you do not use the camera. Dome enclosure is the optical component, do not touch the enclosure when you are installing the device or clean the enclosure when you are doing maintenance work. Please use professional optical clean method to clean the enclosure. Improper enclosure clean method (such as use cloth) may result in poor IR effect of camera with IR function.

7. Accessories

Be sure to use all the accessories recommended by manufacturer.

Before installation, please open the package and check all the components are included. Contact your local retailer ASAP if something is broken in your package.

Accessory Name	Amount
Network Camera Unit	1
Quick Start Guide	1
Installation Accessories Bag	1
CD	1

Table of Contents

1	Genera	al Introduction	1
	1.1	Overview	1
	1.2	Features	1
	1.3	Specifications	2
	1.4	Factory Default Setup	3
2	Structu	ure	9
	2.1	Components	9
	2.2	Framework and Dimension	9
3	Device	e Installation	.11
	3.1	Installation Steps	.11
	3.2	Restore Factory Default Setup Introduction	.13
4	Quick	Configuration Tool	.14
	4.1	Overview	.14
	4.2	Operation	.14
5	Web C	Dperation	.16
	5.1	Network Connection	.16
	5.2	Login and Main Interface	.16
6	FAQ		. 19
Ар	pendix ⁻	Toxic or Hazardous Materials or Elements	.20

1 General Introduction

1.1 Overview

This series network camera integrates the traditional camera and network video technology. It adopts video data collection, transmission together. It can connect to the network directly without any auxiliary device.

This series network camera uses standard H.264 video compression technology, which maximally guarantees the video quality.

It supports the IR night vision function. In the night environments, the device can use the IR light to highlight the object which is suitable for the surveillance function in the low illumination environments. The waterproof design conforms to the IP 66 level. It has the sound waterproof function suitable for use in the outdoor environments.

It can be used alone or used in a network area. When it is used lonely, you can connect it to the network and then use a network client-end. Due to its multiple functions and various uses, this series network camera is widely used in many environments such office, bank, road monitor and etc.

User	 Different user rights for each group, one user belongs to one group. The user right shall not exceed the group right.
Management	
Storage Function	 Support central server backup function in accordance with your configuration and setup in alarm or schedule setting Support record via Web and the recorded file are storage in the client-end PC.
	 Support network storage function such as FTP.
Network Monitor	 Network camera supports one-channel video data transmit to network terminal and then decode. Delaying time is within 270ms (network bandwidth support needed) Max supports 20 connections. Adopt the following video transmission protocol: HTTP, TCP, UDP, MULTICAST, RTP/RTCP, RTSP and etc.
	 Support web access.
Network	 Realize network camera configuration and management via Ethernet.
	 Support device management via web or client-end.
Management	
	 External power adapter DC 12V. Support PoE.
Bower	
Power	Warning!
	Do not connect these two power supplying sources to the device at the same time; it may result in device damage!
	 Log function
	 Support system resource information and running status real-time display. Day/Night mode auto switch.
	 Support picture parameter setup such as electronic shutter and gain setup.
Assistant	Support motion detect.
Function	 Backlight compensation: screen auto split to realize backlight compensation
	to adjust the bright.
	 Support video watermark function to avoid vicious video modification.
	 Built-in IR light. Support IR night vision. The englosure conformation the IR COnstruction.
	• The enclosure conforms to the IP 66 protection. Has the waterproof function.

1.2 Features

1.3 Specifications

Discos refer to the fallouting	also at fair is a true il company	
Please refer to the following	sneet for network camera	a performance specification.

Parame	Model eter	IPC-HDW2100	IPC-HDW3105S	IPC-HDW2105					
S	Main Processor	TI Davinci high perform	ance DSP						
System	OS	Embedded LINUX							
em	System Resources	Support real-time network, local record, and remote operation at the same time.							
	User Interface	· · ·	Remote operation interface such as WEB, DSS, PSS						
	System Status	Bit stream statistics, log	g, and software version.						
<u> </u>	Image Sensor	1/3-inch CMOS	<u>.</u>						
Video Parameter	Pixel	1280(H)*960(V)	1280(H	H)*720(V)					
	Day/night	Support IR-CUT switch	I						
arai	Gain Control	Fixed/Auto							
met	White Balance	Manual/Auto							
ër	BLC	valid only when exposu	djustable)/HLC(anti-flick ire mode is auto with rar						
	Exposure Mode	Manual/Auto PAL: It ranges from 1/3 NTSC: It ranges from 1							
	Video Compression Standard	H.264/H.264H/H.264B/MJPEG							
	Video Frame	Main stream (1280*960@15fps), extra stream (704*576@15fps) Main stream (1280*720@25fps), extra stream (704*576@25fps)	PAL: Main stream (1280*72 extra stream (704*576	1 / 1					
	Rate	NTSC: Main stream (1280*960@15fps), extra stream (704*480@15fps) Main stream (1280*720@30fps), extra stream (704*480@30fps)	NTSC: Main stream (1280*72 extra stream (704*480	1 77					
	Video Bit Rate	H.264: 56Kbps-6144Kbps H.264H: 16Kbps-6144Kbps H.264B 56Kbps-6144Kbps MJPEG: adjustable and bit rate is adjustable. Support customized setup.							
	Video Flip	Support mirror. Support flip function.	Support mirror.						
	Snapshot	Max 1f/s snapshot. File	e extension name is JPE	G.					
	Privacy Mask	Supports max 4 privacy	/ mask zones						
	Video Setup	Support parameter set	up such as bright, contra	ast.					
	Video	Channel title, time title,	motion detect, camera	masking.					

	Information					
	Lens	2.8mm, 3.6mm, 6mm, 8	3mm. Fixed focus.			
	Lens Interface	M12. Lens is the defaul	M12. Lens is the default accessories			
Video	Motion Detect	396 (18*22) detection zones; sensitivity level ranges from 0 to 100; area threshold ranges from 0 to 100. Activation event: video storage, image snapshot, log, email function and etc.				
Record	Record Priority	Manual>External alarm >Video detect>Schedule				
	Wire Network	1-ch 10/100 M Ethernet , RJ45 port				
Network	Network Protocol HTTP, TCP/IP, ARP, RTSP, RTP, UDP, RTCP, SMTP, FTF DNS, DDNS, PPPOE, IPv4/6, SNMP, UPNP, NTP					
rork	Remote Operation	Monitor, system setup, upgrade and etc	file download, log information, maintenance,			
	Restore Default Setup					
	IR light	IR light 15M.				
General Parameter	Power	DC12V power and PoE. Warning! Do not connect these two power supplying sources to the device at the same time; it may result in device damage!	DC12V			
	Power Consumption	4.5W MAX				
	Working Temperature	-10℃~+60℃				
	Working Humidify	10%~90% Ф 113×86				
	Dimensions(mm)					
	Weight					
	Installation	Fixed on the wall, ceilin	g and etc.			

1.4 Factory Default Setup

Please refer to the following sheet for factory default setup information.

			Default Setup		
Setup	up	Item	IPC-HDW2100	IPC- HDW3105S	IPC-HDW2105
S	Co	Config File	Normal		
Camera	s nd	Brightness	50		
ĩa	ť	Contrast	50		

					Default Setup		
Setu	ıp	ltem			IPC-HDW2100	IPC- HDW3105S	IPC-HDW2105
		Sharpness			50		
		Saturatio	on		50		
		Anti-flick	er		Outdoor		
		Exposur	e Mode		Auto		
		Scene M	lode		Auto		
		Day/nigh	nt Mode		Auto		
		BLC			Off		
		Mirror			Off		
		Flip			Off		
		Profile N	lanagement		Normal		
	Video	Video bit stream		Bit stream type	General		
	0	o bit		Encode mode	H.264		
		: stre		Resolution	720P (1280*720)		
		eam		Frame Rate(FPS)	PAL: 25 NTSC:30		
			Main Stream	Bit Rate Type	CBR		
				Recommende d Bit	1536-6124Kb/S		
				Bit Rate	4096		
				l Frame interval	50		
				Watermark	Enable		
				Watermark character	DigitalCCTV		
				Enable	Enable		
				Bit stream type	General		
				Encode mode	H.264B		
				Resolution	CIF(352*288)		
			Sub Stream	Frame Rate(FPS)	PAL: 25 NTSC:30		
			Stream	Bit Rate Type	CBR		
				Recommend ed Bit	192-1024Kb/S		
				Bit Rate	512		
				l Frame interval	50		
		Snapsho	ot	Snapshot Type	General		

				Default Setup		
Setu	up	Item		IPC-HDW2100	IPC- HDW3105S	IPC-HDW2105
			Image Size	720P (1280*720)		
			Quality	Better		
			Bit Rate	Main stream		
			Interval	1s		
			Privacy Mask	Disable		
		Video Overlay	Channel Title	Enable		
			Time Title	Enable		
		Path	Snapshot Path	C:\PictureDownlo	ad	
			Record Path	C:\RecordDownlo	bad	
Ne			Host Name	IPC		
Network			Ethernet Card	Wire		
ŤŔ	<u>s</u>		Mode	Static		
			Mac Address	Device MAC add factory	Iress when it is s	hipped out of the
			IP Version	IPV4		
			IP Address	192.168.1.108		
			Subnet Mask	255.255.255.0		
		TCP/IP	Default Gateway	192.168.1.1		
			Preferred DNS	8.8.8.8		
			Alternate DNS	8.8.8.8		
			Enable ARP/Ping set device IP address service			
			Max Connection	10		
			TCP Port	37777		
			UDP Port	37778		
		Connection	HTTP Port	80		
			RTSP Port	554		
			Enable HTTPs	Disable		
			HTTPs Port	443		
			Enable	Disable		
		PPPoE	Username	none		
			Password	N/A		

				Default Setup		
Setup	Item			IPC-HDW2100	IPC- HDW3105S	IPC-HDW2105
	DDNS		Server Type	Disable, CN99 [
			Server Address	www.3322.org		
			Domain Name	none		
			Username	none		
			Password	***		
	IP Filter		Trusted sites	Disable		
			SMTP Server	none		
			Port	25		
			Anonymity	Disable		
			User Name	anonymity		
			Password	****		
			Sender	none		
	SMTP(Email)		Authenticatio n (Encryption mode)	N/A		
			Title (Subject)	IPC Message		
			Attachment	Enable		
			Mail Receiver	0 seconds		
			Email Test	Disable, interval	=60 seconds	
	UPnP		Enable UPnP	Disable		
			SNMP Port	161		
			Read Community	public		
	0.11/5		Write Community	private		
	SNMP		Trap Address	N/A		
			Trap Port	162		
			SNMP v1	Disable		
			SNMP v2	Disable		
			SNMP v3	Disable		
	Boniour		Enable	Enable		
	Bonjour		Server Name	Device factory SI	N	
			Enable	Enable		
	Multicast	Main Stream	Multicast Address	239.255.42.42		
			Port	36666		

	_				Default Setup		
Setup	Item				IPC-HDW2100	IPC- HDW3105S	IPC-HDW2105
				Enable	Disable		
			Extra Stream	Multicast Address	239.255.42.42		
				Port	36667		
				Enable	Disable		
	IEEE802			Authenticatio n	PEAP		
				Username	None		
				Password	****		
	QoS			Real-time Monitor	0		
		1		Command	0		
П	√ic			Enable	Disable		
ent	Video			Anti-dither	5 seconds		
	Video detect	Mot	ion Detect	Record Channel	Enable		
				Record Delay	10 seconds		
				Send Email	Disable		
				Snapshot	Disable		
		Video Masking		Enable	Disable		
			Record Channel	Enable			
			asking	Record Delay	10 seconds		
				Send Email	Disable		
				Snapshot	Disable		
	Ab			Enable	Disable		
	Abnormity	Disconne	connection	Record	Enable		
	nity			Record Delay	10 seconds		
				Enable	Disable		
		IP C	Conflict	Record	Enable		
				Record Delay	10 seconds		
Storage	Schedule		liday	Record	Disable		
ge	dule	Sc	hedule	Snapshot	Disable		
	St			Enable FTP	Disable		
	Storage			Server IP	N/A		
	Je			Port	21		
		FTP)	Username	anonymity		
				Password	N/A		
				Remote path	Share		

				Default Setup			
Setup	ltem			IPC-HDW2100	IPC- HDW3105S	IPC-HDW2105	
		Rec	Pack Duration	8 minutes			
		sord	Pre-record	5 seconds			
		င်	Disk Full	Overwrite			
	Record Contro	ntro	Record Mode	Auto	Auto		
			Bit Stream	Main Stream			
Sy	Ge		Device No	Device factory SI	N		
System	Genera	Local Host	Language	English			
3	<u>a</u>		Video Standard	PAL/NTSC			
			Date Format	Y-M-D			
		Date and time	Time Format	24H			
			Time Zone	GMT+08:00			
			System Time	Sync			
			DST	Disable			
			DST Type	Date			
			Start Time	00:00:00 of Jan.1	st		
			End Time	00:00:00 of Jan.2	nd		
			NTP	Disable			
			NTP Server	clock.isc.org			
			Port	123			
			Update Period	10 minutes			
	Ассо	unt	Anonymous Login	Disable			
			Auto Reboot	Enable, Tuesday	02:00		
	Auto Maintenance		Auto Delete Old Files	Disable			

2 Structure

2.1 Components

You can refer to the following figure for multiple-function combination cable information. See Figure 2-1.



Figure 2-1 Multiple-function combination cable

Please refer to the following sheet for detailed information.

Component	Component Name
Component 1	Device lens
Component 2	Dome body
Component 3	Dome enclosure

No.	Port	Name	Connector	Note		
4	LAN	Network port	Ethernet	To connect to standard Ethernet.		
5	DC12V	DC 12V power		To connect to DC12V power supply.		

2.2 Framework and Dimension

Please refer to the following two figures for dimension information. The unit is mm. See Figure 2-2 and Figure 2-3.



Figure 2-2 Dimension illustration 1





3 Device Installation

3.1 Installation Steps

Important

Before the installation, please make sure the installation environments can at least support 3x weight of the camera.

Please follow the steps listed below to install the device. Please refer to Figure 3-1 for reference.

<u>Step 1</u>

Turn clockwise to remove the decoration ring from the snap joints.

<u>Step 2</u>

Please take the installation position map in the accessories bag, and then paste it on the ceiling or the wall according to your monitor area requirements. Draw and then dig three plastic expansion bolts holes in the installation surface and then insert three expansion bolts in the holes. Secure these three bolts firmly. Please draw the cable out from the cable exit when you install the device.

Step 3

Adjust the device installation pedestal to the proper position and then line up the three screw holes in the device pedestal to the three plastic expansion bolt holes in the installation position. Put the three self-tapping screws in the three plastic expansion bolts firmly. Loosen the M3X8 cross recessed pan head slot screw of the pedestal to unfasten the preforming. (Do not remove, loosen a little bit will be OK.). Adjust the lens to the proper monitor angle and then use the original preforming to turn the M3X8 cross recessed pan head slot screw back.

Step4

Line up the three spigots of the decoration ring to the jags from the bottom to the top and then turn clockwise until you hear a clear sound "KA". Now the installation is complete.



Figure 3-1 Device installation illustration 1

Important

Please pay attention to the dome camera direction when you are installing. Please refer to the following figure for detailed information. See Figure 3-2.



Figure 3-2 Device installation illustration 2

Note

This series product supports two cable exits. One is from the bottom and the other is from the side. Please refer to the following figure for cable exit from the side information.



Figure 3-3 Device installation illustration 3

Please earth the GND port of the device to enhance the device reliability. The GND port is near the cable exit port on the rear of the dome. The GND screw uses the M2X5 pan screw.



Figure 3-4 Device installation illustration 4

3.2 Restore Factory Default Setup Introduction

Important

Please use RESET button when device is running.

<u>Step1</u>

Please refer to step1 and step2 in chapter 3.1to loose the dome body. Push a little bit; you can take the dome body from the gland cover.

Step2

Take the dome body out and then turn the top cover hard to remove.

<u>Step3</u>

Slightly press the RESET button to complete the reset function. See Figure 3-5.

Step4

Turn the top cover back to the original position. Please make sure it reaches the original position, otherwise it may result in water leakage!

Step5

Put the dome back to the gland cover. Please refer to step4 in chapter 3.1 to install the decoration ring back.



Figure 3-5 Reset

4 Quick Configuration Tool

4.1 Overview

Quick configuration tool can search current IP address, modify IP address. At the same time, you can use it to upgrade the device.

Please note the tool only applies to the IP addresses in the same segment.

4.2 Operation

Double click the "ConfigTools.exe" icon, you can see an interface is shown as in Figure 4-1. In the device list interface, you can view device IP address, port number, subnet mask, default gateway, MAC address and etc.

SN	IP Address	Port	Subnet Mask	Default Gateway	Mac Address
	192.168.1.108	37777	255. 255. 255. 0	192.168.1.1	90:02:a9:7b:50
1					>
Tip:	You can click "login" button	directly and			
Tip: then	You can click "login" button input corresponding informat	directly and ion to login.			

Figure 4-1 Search interface

Select one IP address and then right click mouse, you can see an interface is shown as in Figure 4-2. Select the "Open Device Web" item; you can go to the corresponding web login interface.

SN	IP Address	Port	Subnet Mask	Default Gateway	Mac Address
	192.168.1.108 Open Device Web	37777	255, 255, 255, 0	192, 168, 1, 1	90:02:49:76:5
		_			
		0.000			

Figure 4-2 Search interface 2

If you want to modify the device IP address without logging in the device web interface, you can go to the configuration tool main interface to set.

In the configuration tool search interface (Figure 4-1), please select a device IP address and then double click it to open the login interface. Or you can select an IP address and then click the Login button to go to the login interface. See Figure 4-3.

In Figure 4-3, you can view device IP address, user name, password and port. Please modify the corresponding information to login.

Please note the port information here shall be identical with the port value you set in TCP port in Web Network interface. Otherwise, you cannot login the device.

If you are using device background upgrade port 3800 to login, other setups are all invalid.

Login		×
IP Address:	192.168.1.108	
User Name:	admin	
Password:	****	
Port:	37777	
	Login Cancel	

Figure 4-3 Login prompt

After you logged in, the configuration tool main interface is shown as below. See Figure 4-4.

	DHCP Enable IPv4	-	
IP Address:	192.168.1.108		
Subnet Mask:	255.255.0.0		
Gateway:	10.15.0.1		
Mac Address:	90:02:a9:7f:d8:21		
		Save	Return



For detailed information and operation instruction of the quick configuration tool, please refer to the *Quick Configuration Tool User's Manual* included in the resources CD.

5 Web Operation

This series network camera products support the Web access and management via PC. Web includes several modules: Monitor channel preview, system configuration, alarm and etc.

5.1 Network Connection

Please follow the steps listed below for network connection.

- Make sure the network camera has connected to the network properly.
- Please set the IP address, subnet mask and gateway of the PC and the network camera respectively. Network camera default IP address is 192.168.1.108. Subnet mask is 255.255.255.0. Gateway is 192.168.1.1
- Use order ping ***.***.***(* network camera address) to check connection is OK or not.

5.2 Login and Main Interface

Open IE and input network camera address in the address bar. See Figure 5-1.



Figure 5-1 IP address

The login interface is shown as below. See Figure 5-2.

Please input your user name and password.

Default factory name is admin and password is admin.

Note: For security reasons, please modify your password after you first login.

IP Camera	
Username: Password: Login Cancel	

Figure 5-2 Web login

If it is your first time to log in, system pops up warning information to ask you whether install web plugin or not after you logged in for one minute. For detailed plug-in installation, please refer to the Web Operation Manual included in the resource CD.

After you logged in, you can see the main window. See Figure 5-3.



Figure 5-3 Web monitoring window

Please refer to the Web Operation Manual included in the resource CD for detailed operation instruction.

6 FAQ

Bug			
I can not boot up the device or operate properly.	Please click RESET button for at least five seconds to restore factory default setup.		
The water leakage occurred.	The unauthorized front or rear cap remove many result in water leakage.		
	The glass front cap has sustained heavy push or strike.		
	The waterproof plug of the rear cap becomes loosen.		
IR video is poor.	Do not use the proper supplying power. The IR light can not turn on completely.		
	The object is out of the IR distance range of current device.		
	IR-CUT does not turn to the night mode. The photosensitive chip of the front-end can not sense the IR light.		
I can not upgrade the device via network.	When network upgrade operation failed, you can use port 3800 to continue upgrade.		
I can not login the client-end or the WEB.	For Windows OS 98 or Windows ME user, if you can not install the client-end or can not view after the installation. We recommend the win2000sp4 OS or install the client-end of the low version. The Active X control is blocked.		
	The display card version shall be dx8.1 or higher.		
	Network connection error occurred.		
	Invalid network setup.		
	Invalid user name or password.		
I can not play the	There is no player.		
download file.	There is no DX8.1 or higher.		
	For the MEDIA PLAYER, there shall be Div X503Bundle.exe plugin if you play the .AVI file.		
	For Windows XP user, you need to install the plugin DivX503Bundle.exe and ffdsho-2004 1012.exe.		
To guarantee setup update	After you modified the important setup, please reboot the device via the software to make sure the setup has been updated to the storage medium.		
Power adapter	The general power adapter can work ranging from 0° to 40 $^{\circ}$. The device may result in unstable power supply when the temperature exceeds the working temperature.		
	Please replace an industry-level power adapter if you are using in the harsh environments.		

Component Name	Toxic or Hazardous Materials or Elements							
	Pb	Hg	Cd	Cr VI	PBB	PBDE		
Circuit Board Component	0	0	0	0	0	0		
Device Case	0	0	0	0	0	0		
Wire and Cable	0	0	0	0	0	0		
Packing Components	0	0	0	0	0	0		
Accessories	0	0	0	0	0	0		

Appendix Toxic or Hazardous Materials or Elements

O: Indicates that the concentration of the hazardous substance in all homogeneous materials in the parts is below the relevant threshold of the SJ/T11363-2006 standard.

X: Indicates that the concentration of the hazardous substance of at least one of all homogeneous materials in the parts is above the relevant threshold of the SJ/T11363-2006 standard. During the environmental-friendly use period (EFUP) period, the toxic or hazardous substance or elements contained in products will not leak or mutate so that the use of these (substances or elements) will not result in any severe environmental pollution, any bodily injury or damage to any assets. The consumer is not authorized to process such kind of substances or elements, please return to the corresponding local authorities to process according to your local government statutes.

Note

- This user's manual is for reference only. Slight difference may be found in user interface.
- All the designs and software here are subject to change without prior written notice.
- All trademarks and registered trademarks mentioned are the properties of their respective owners.
- If there is any uncertainty or controversy, please refer to the final explanation of us.
- Please visit our website for more information.