



RADIO OCEAN

Chart Plotter Name	Description	SOFTWARE
O.CHART5	<i>5" Sunlight Readeable Color Display Internal GPS Receiver</i>	S4xgRO5vc
O.CHART5F	<i>5" Sunlight Readeable Color Display Internal GPS Receiver & Internal Fish Finder</i>	S4xgRO5vc
O.CHART7	<i>7" wide Sunlight Readeable Color Display Internal GPS Receiver</i>	S4xgRO8wc
O.CHART7F	<i>7" wide Sunlight Readeable Color Display Internal GPS Receiver & Internal Fish Finder</i>	S4xgRO8wc

User Manual

code: (d1620-040810e)

Table of Contents

Important Information	11
WARNING	11
LIMITED WARRANTY	11
CAUTION	12
CLEANING PROCEDURE FOR THE PLOTTER SCREEN	12
1. Introduction	13
1.1 FEATURES	13
1.2 BASICS	14
1.3 IF YOU NEED ASSISTANCE	15
2. Before You Begin	17
2.1 THE KEYBOARD	17
2.1.1 ONLY FOR O.CHART5/5F: The PAGE key	18
2.1.2 ONLY FOR O.CHART7/7F: Zoom Slider and Map Rotor	19
2.2 TURNING THE CHART PLOTTER ON AND OFF	20
2.2.1 Turning On	20
2.2.2 Turning Off	20
2.3 FIRST SETUP PAGE	20
2.4 LCD ADJUSTMENT	21
2.4.1 Palette	21
2.5 SELECTING THE USER INTERFACE LANGUAGE	22
2.6 SELECTING THE CHART LANGUAGE	22
2.7 EXTERNAL CONNECTIONS	23
2.7.1 Autopilot Connections	23
2.7.2 External NMEA Connections	23
2.7.3 C-COM Connections	23
2.7.4 ONLY FOR O.CHART7/7F: External Alarm Connection	23
2.8 USING C-MAP BY JEPPESEN DATA MEDIA	23
2.9 SIMULATION MENU	24
2.9.1 Simulation Mode	24
2.9.2 Speed	24
2.9.3 Heading	24
2.9.4 Date	24
2.9.5 Time	24
2.9.6 Cursor Control	24
3. For the New User	25
3.1 SCREEN DISPLAY CONFIGURATION	25
3.1.1 Chart Page	26
3.1.2 Chart+Databoxes Page	27
3.1.3 Rolling Road Page	27
3.1.4 GPS Status Page	28
3.1.5 Depth Graph Pages	28
3.1.6 ONLY FOR O.CHART7/7F: Video Input Pages	29
3.2 MAP ORIENTATION	30
3.3 NAVIGATING TO A SINGLE DESTINATION	30
3.3.1 Distance and Bearing to Target	30
3.3.2 Time To Go	31
3.3.3 Deleting Target	31
3.4 NAVIGATION ON A ROUTE	31
3.4.1 Adding Waypoint	31
3.4.2 Creating a Route	31
3.4.3 Deleting Waypoint	31
3.4.4 Time To Go	32
3.4.5 Deleting Target	32
3.5 C-MAP BY JEPPESEN MAX CARTOGRAPHY INFORMATION	32
3.5.1 Data Features	32
3.5.2 Presentation Features	32

3.5.3	Cartographic Data related Features	33
3.6	BACKGROUND CHARTS	33
3.7	PICTURES & DIAGRAMS	33
3.7.1	Quick Info on Objects with Pictures	34
3.7.2	Expanded Info on Objects with Pictures	34
3.7.3	Change Picture Size	34
3.8	MAP MENU	34
3.8.1	Zoom Type	34
3.8.2	Fonts & Symbols	34
3.8.3	Perspective View	35
3.8.4	Dynamic Nav-Aids	35
3.8.5	Mixing Levels	35
3.8.6	Safety Status Bar (DSI = Data Safety Indicator)	35
3.8.7	Satellite Imagery	36
3.8.8	Currents Prediction	36
3.9	INFO FUNCTION	37
3.9.1	Info Tree and Expanded Info page	37
3.9.2	Getting Tide Info	37
3.9.3	Getting Port Info	38
3.9.4	Enhanced Port Info	39
3.10	MAP SETTINGS	39
3.10.1	Display Mode	39
3.10.2	Getting Automatic Info	42
3.10.2.1	Quick Info on Lakes	43
3.10.2.2	Full Info on Lakes	44
3.11	FIND FUNCTION	44
3.11.1	Finding Port Services	44
3.11.2	Finding Port By Name	45
3.11.3	Finding Port By Distance	45
3.11.4	Finding Tide Stations	45
3.11.5	Finding Wrecks	45
3.11.6	Finding Obstructions	45
3.11.7	Finding Lakes Information	45
3.11.8	Finding Lakes By Name	46
3.11.9	Finding PointS Of Interest	46
3.11.10	Finding Cursor	47
3.11.11	Finding Coordinates	47
3.11.12	Finding User Points	47
3.12	ALARMS MENU	47
3.12.1	Auto Off	47
3.12.2	Arrival Alarm	47
3.12.3	XTE Alarm	47
3.12.4	Anchor Alarm	47
3.12.5	Depth Alarm	48
3.12.6	HDOP Alarm	48
3.12.7	Heading Alarm	48
3.12.8	Grounding Alarm	48
3.12.9	Grounding Alarm Range	48
3.12.10	Grounding Alarm Report	48
3.12.11	ONLY FOR O.CHART7/7F: External Alarm	48
4.	For the Experienced User	49
4.1	MORE ABOUT CREATING AND USING ROUTES	49
4.1.1	Routes	49
4.1.1.1	Selecting Route	49
	Changing Notes	49
	Route Color	49
	Displaying Route	49
4.1.1.2	Deleting Route	49
4.1.1.3	Finding Info on Route: Route Data Report	49
	Changing Fuel values	50
	Changing Speed values	50
	Reversing Route	50
	Selecting the Databoxes Setup and User Points List pages	50
4.1.1.4	Route Color	50
4.1.1.5	Sending Route	50
4.1.1.6	Receiving Route	50
4.1.1.7	Safe Route Checking	51

4.1.2	Waypoints	51
4.1.2.1	Adding Waypoints	52
4.1.2.2	Moving Waypoint	52
4.1.2.3	Deleting Waypoint	53
4.1.2.4	Editing Waypoint	53
4.1.2.5	Goto	54
4.1.2.6	Inserting Waypoint	54
4.1.2.7	Finding Waypoint	55
4.1.2.8	Finding Information on Waypoints: User Points List page	55
	View Waypoint on the map	55
	Find Waypoint in the User Points List page	56
	Deleting Waypoint	56
	Selecting the Databoxes Setup and the Route Data Report pages	56
4.1.2.9	Send Waypoints	56
4.1.2.10	Receive Waypoints	56
4.2	MARKS	56
4.2.1	Adding Mark	56
4.2.2	Moving Mark	56
4.2.3	Deleting Mark	57
4.2.4	Edit Mark	57
4.2.5	Goto	57
4.2.6	Finding Mark	57
4.2.7	Finding Information on Marks: User Points List	57
4.2.8	Send Marks	57
4.2.9	Receive Marks	57
4.3	USING THE TRACK FUNCTIONS	58
4.3.1	Enabling Track storing	58
4.3.2	Deleting Track	58
4.3.3	Config Menu	58
4.3.3.1	Selecting Active Track	58
4.3.3.2	Displaying Track	58
4.3.3.3	Selecting Track Color	58
4.3.3.4	Selecting Track memorizing type	58
4.3.3.5	Selecting Time	58
4.3.3.6	Selecting Distance	58
4.3.3.7	Deleting All Tracks	59
4.3.4	Deleting Total and Partial Distance (LOG)	59
4.3.5	Track To Route Conversion	59
4.3.5.1	Track to Route	59
4.3.5.2	Select Track Number	59
4.3.5.3	Select Route Number	59
4.4	MEMORY CARD MENU	59
4.4.1	Saving File	59
4.4.2	Loading File	60
4.4.3	Deleting File	60
4.4.4	MEDIA	60
4.4.4.1	Reading Directory on MEDIA	60
4.4.4.2	Formatting MEDIA	60
4.4.4.3	Sorting Directory	60
5.	Special Functions	61
5.1	C-WEATHER	61
5.1.1	C-Weather Menu	61
5.1.1.1	Copy from Media	61
5.1.1.2	Download	61
	Select Country to Call	62
	Telephone number	62
	SIM PIN	62
	Download Area	62
5.1.1.3	Weather Forecast	62
5.1.1.4	Real Time View	62
5.1.1.5	Type of Data	63
5.2	AIS MENU	63
5.2.1	AIS System Definitions	63
5.2.2	AIS Menu	64
5.2.2.1	Display	64
5.2.2.2	CPA Alarm	64
5.2.2.3	TCPA Alarm	64

5.2.3	To Set the Plotter for Receiving AIS	65
5.2.4	Quick Info on AIS Target	65
5.3	C-LINK	65
5.3.1	C-Link serial connection	65
5.3.2	C-Link Navigation Data transfer	65
5.3.3	Operations	66
5.3.3.1	Master Chart Plotter	66
	Operating mode	66
5.3.3.2	Slave Chart Plotter	67
	Operating mode	67
	Stop current navigation	67
	Inhibit Navigation operation	67
	Inhibit Route following	67
	MOB handling	67
5.3.3.3	C-Link navigation data: Acquisition and Display	67
5.3.3.4	Route Data Report	68
5.3.3.5	Quick Info	69
5.4	DSC	69
5.4.1	Distress Call and Position Request	69
5.4.2	DSC Menu	70
5.4.2.1	Log	70
	Locate	70
	Clr-One	70
	Clr-All	71
	Hide/Show	71
	Distress Call/Position Request	71
5.4.2.2	Directory	71
	Edit	71
	Add	71
	Delete	71
	Delete All	71
5.4.3	Quick Info on DSC Icons	71
5.5	FISH FINDER MENU	72
6.	Fish Finder For O.CHART5F/O.CHART7F	73
6.1	SETTING THE INTERNAL FISH FINDER ON	73
6.2	UNDERSTANDING THE FISH FINDER PAGE	74
6.2.1	Understanding the Echogram display	75
6.3	DISPLAYING THE FISH FINDER PAGE	76
6.3.1	How to select the Fish Finder page	76
6.3.1.1	Fish Finder Full page	77
	The Cursor key	77
	The CLEAR key	77
	The ZOOM IN and ZOOM OUT keys	77
6.3.1.2	Fish Finder Full + Databoxes page	78
6.3.1.3	Dual Fish Finder page	78
	The Cursor key	78
	The ZOOM IN and ZOOM OUT keys	79
6.3.1.4	Fish Finder and Chart page	79
	The Focus Soft Key (to change the active window)	79
6.4	ZOOM MODES	79
6.4.1	The Bottom Lock Zoom	79
6.4.2	The Marker Zoom	80
6.5	FISH FINDER SETUP MENU	80
6.5.1	Preset Mode	80
6.5.2	Gain Mode	80
6.5.3	Range Mode	81
6.5.4	Depth	81
6.5.5	Shift	81
6.5.6	Bottom Range	81
6.5.7	Frequency	81
6.5.8	Interference Rejection	81
6.5.9	Sensitivity Menu	81
6.5.9.1	Frequency	81
6.5.9.2	Gain	82
6.5.9.3	STC	82
6.5.9.4	STC Length	82
6.5.9.5	STC Strength	82

6.5.9.6	Surface Noise Filter	82
6.5.10	Display Setup	82
6.5.10.1	Color Settings	82
6.5.10.2	Scrolling Speed	82
6.5.10.3	White Line	82
6.5.10.4	Fish Symbols	82
6.5.10.5	Water Temperature	83
6.5.11	Transducer Setup	83
6.5.11.1	Keel Offset	83
6.5.11.2	Calibrate Sound Speed	83
6.5.11.3	Calibrate Water Speed	83
6.5.11.4	Calibrate Water Temperature	83
6.5.11.5	Calibrate Aux Temperature	83
6.5.11.6	Set Default settings	83
6.5.12	Alarms	83
6.5.12.1	Shallow Water	83
6.5.12.2	Deep Water	83
6.5.12.3	High Water Temperature	84
6.5.12.4	Low Water Temperature	84
6.5.12.5	Water Temperature Rate	84
6.5.12.6	Fish Alarm	84
6.5.13	Save & Load	84
6.5.13.1	Load Settings from MEDIA	84
6.5.13.2	Save Settings to MEDIA	84
6.5.13.3	Restore Current Preset Defaults	84
6.6	Transducers	84
6.6.1	Dedicated Available Transducers	85
7.	Terms & Functions	87
8.	System Test	99
8.1	SYSTEM TEST	99
8.1.1	RAM Menu	99
8.1.2	DIM Menu	99
8.1.3	Cartridges	100
8.1.4	Modem Test	100
8.1.5	Serial Port	100
8.1.6	Video Test	100
8.1.7	ONLY FOR O.CHART7/7F: External Alarm	100
appendix A .	Troubleshooting	101
O.CHART5/O.CHART5F	103
TECHNICAL SPECIFICATIONS		103
ONLY FOR O.CHART5F FF MODULE 600W-50-200KHz TECHNICAL SPECIFICATIONS		104
INSERTING/REMOVING PROCEDURE		104
Inserting MEDIA		104
Removing MEDIA		104
DIMENSIONS		105
INSTALLATION		105
EXTERNAL WIRING		106
O.CHART7/O.CHART7F	107
TECHNICAL SPECIFICATIONS		107
ONLY FOR O.CHART7F FF MODULE 600W-50-200KHz TECHNICAL SPECIFICATIONS		108
INSERTING/REMOVING PROCEDURE		108
Inserting MEDIA		108
Removing MEDIA		108
DIMENSIONS		109
INSTALLATION		109
EXTERNAL WIRING		110
Wiring Diagrams	113
Analytical Index	119

Important Information

WARNING

Electronic charts displayed by the chart plotter are believed to be accurate and reliable, but they are not intended to replace official charts which should remain your main reference for all the matters related to the execution of a safe navigation. For this reason we would like to remind you that you are required to carry on board and use the officially published and approved nautical charts.

LIMITED WARRANTY

FURUNO France warrants every RADIO OCEAN units to be free from defects in material and workmanship under normal use and service for a period of 24 months from original retail purchase. During the warranty period, FURUNO France will repair or replace any component which fails in normal use without charges for parts or labour. Are not concerned accessories and consumables.

Given technological developments, modifications and upgrades of software are not covered by warranty (except commercial decision).
After troubleshooting and repair of an antenna, parts and changed the relevant labor are guaranteed for a period of three months.

To receive warranty service, contact your local authorized dealer for shipping instructions. The chart plotter should be securely packed with its tracking code clearly written on the outside of the package, shipping to be paid by the customer. Include a copy of the original sales receipt as the proof of purchase.

This limited warranty does not extent to any chart plotter which has been subjected to misuse, neglect, accident, incorrect wiring or improper installation. FURUNO France reserves the right to repair or replace the chart plotter at its sole discretion. For more warranty information please see the web site: www.furuno.fr/GarantieMondiale web.

FURUNO France invites you to contact us should you require technical advice or assistance at:

FURUNO France

Tel: 05 56 13 48 00

Fax: 05 56 13 48 01

N° Hotline Furuno Aftersale – SAV : 0825.000.150 (0,18€ ttc/min)

12 rue Laplace - Espace Phare

BP 90268 - 33698 Mérignac

CAUTION

- Please read through this manual before the first operation. If you have any questions, please contact the Company's customer service or your local dealer.
- The chart plotter is not built water proof. Please give attention to avoid water intrusion into the chart plotter. Water damage is not covered by the warranty.
- Extensive exposure to heat may result in damage to the chart plotter.
- Connection to the power source with reversed polarity will damage the chart plotter severely. This damage is not covered by the warranty.
- The chart plotter contains dangerous high voltage circuits which only experienced technicians MUST handle.
- The C-MAP BY JEPPESEN MEDIA are available from your local dealer.
- Exposure of the display to UV rays may shorten the life of the liquid crystals used in your plotter. This limitation is due to the current technology of the LCD displays.
- Avoid overheating which may cause loss of contrast and, in extreme cases, a darkening of the screen. Problems which occur from overheating are reversible when temperature decreases.

WARNING ON SERIAL PORTS CONNECTION

Please be aware that the serial ports are not opto-isolated and then the external device is electrically connected to the chart plotter. This allows the connection of high speed devices, like Fish Finder. If you are connecting a NMEA0183 device and you would like to isolate it from the chart plotter, you have to add the opto-isolator externally.

CLEANING PROCEDURE FOR THE PLOTTER SCREEN

Cleaning your chart plotter screen is a very important operation and must be done carefully. Since the surface is covered by an antireflective coating, the procedure for cleaning all the surfaces can be performed in the following way. You use a tissue or lens tissue and a cleaning spray containing Isopropanol (a normal spray cleaner sold for the PC screen, for example PolaClear by Polaroid). Fold the tissue or lens tissue into a triangular shape, moisten the tip and use the index finger behind a corner to move the tissue across the surface, in overlapping side to side strokes. If the tissue is too wet, a noticeable wet film will be left in its path and you will need to repeat the process. If too dry, the tissue won't glide easily, and may damage the surface.

We will not be liable for errors contained herein, or for incidental or consequential damages in connection with the performance or use of this material.

1. Introduction

If you have not used a position-finding instrument before and intend to use your chart plotter for navigating, we suggest you should read this User Manual and make sure you are familiar with its contents.

The User Manual is divided into three main parts. Chapter "Before You Begin" introduces you to the basic information to get you start using the chart plotter. Chapter "For the New User" should be read first to become familiar with your new instrument. Chapter "For the Experienced User" introduces the advanced features of the chart plotter.

Throughout this User Manual, the labelled keys are shown in capitals letters enclosed between single inverted commas, for example 'MENU'; the software keys are shown in small capital letters enclosed in square brackets, for example 'ACCEPT'.

Menu operations are in bold characters listed by keys sequence with the menu names enclosed between inverted commas, for example '**ENTER**' + "**MARK**" + '**ENTER**' + '**Move**' + '**ACCEPT**' means: press the 'ENTER' key, using the cursor key select the Mark option and press 'ENTER' to place Mark, press the software key '**Move**' to change the Mark position and press the software key '**ACCEPT**' to confirm the new position.

Terms underlined, for example Mark, are explained in the Chapter 7.

Into all information windows items are displayed in gray color when there are not active (it is not possible to select them and place on the cursor).

Any menu operation and function activation in this User Manual is related to all chart plotter models (see the previous table). The pictures are related to the 5" vertical chart plotters, whenever it is necessary a note has been inserted for the other models.

1.1 FEATURES

The chart plotter is a computer specifically designed for nautical use but, more precisely, to ease and speed up all calculations, which so far have been done manually. If connected to a positioning instrument, the chart plotter displays the current position, the speed, and the heading of the boat and its Track. The user information like Waypoints, Marks and Tracks can then be stored on a MEDIA and can be recalled at any time. On the screen are shown navigation data and cartographic information obtained from electronic charts of C-MAP By JEPPESEN DATA MEDIA.

- "C-MAP By JEPPESEN" MAX electronic charts, object-oriented chart system with enhanced functionality including:
 - Guardian alarm, Safety Status Bar, Safe Route Checking
 - Perspective View
 - Satellite Image coverage
 - Turbo and Smooth Zoom

Multilanguage
Enhanced Port Information database
Tides & Currents data
Photos & Diagrams
Automatic Information on all chart objects and User Points
Find function for Ports Services, Ports By Name, Ports By Distance,
Tide Stations, Wrecks, Obstructions, Lakes Information, Lakes By
Name, Points Of Interest, Cursor, Coordinates and User Points

- Positional information from GPS
- Depth Graph pages
- Navigation Data page
- Rolling Road page
- GPS Status page
- AIS Report List page
- DSC Log and DSC Directory pages
- O.CHART7/7F : Video Input pages
- Fish Finder pages
- O.CHART5/5F : 500 Waypoints/Marks and 25 Routes
1000 Track Points and 3 Tracks
- O.CHART7/7F : 10000 Waypoints/Marks and 50 Routes
10000 Track Points and 5 Tracks
- Create, Move, Insert, Edit, Delete, Send, Receive Waypoint
- Create, Move, Edit, Delete, Send, Receive Mark/Event
- Navigation to Goto
- Create, Save, Name, Edit, Delete, Send, Receive or Follow a Route
- Route Data Report and User Points (Marks/Waypoints) List pages
- Display vessel's position, direction and Track
- Alarms Handling (Auto Off, Arrival Alarm, XTE Alarm, Anchor Alarm, Depth Alarm, HDOP Alarm, Heading Alarm, Grounding Alarm, ONLY FOR O.CHART7/7F External Alarm)
- Man OverBoard (MOB) to navigate back to a missing person or object
- C-Link and C-Weather Service
- R-B function
- Simulation Mode with cursor control
- O.CHART5F/7F : Internal Fish Finder

1.2 BASICS

The chart plotter is controlled by a keyboard: there are labelled keys and software keys (soft keys).

The labelled keys are dedicated to specific functions, the soft keys have different functions according to the modes of operation: their labels for the current

functions, located on the front panel, are shown on the screen right above the keys. There is also a cursor key to move a cursor across the screen.

As you press a key, a single audio beep confirms the key action; every time the key pressed is not valid, three rapid beeps sound indicates that no response is available.

1.3 IF YOU NEED ASSISTANCE

If your chart plotter does not operate properly, please refer to System Test (see Chapter 8). Most common operating difficulties can be diagnosed using these tests.

If you still need assistance, call your local dealer, reporting the information available in the System Information page, selected following the procedure:

- 'MENU' + "About..." + 'ENTER'

2. Before You Begin

This chapter provides basic information to get you start using the chart plotter; it will help you to become familiar with the chart display and the functions of the controls before you start using the chart plotter.

2.1 THE KEYBOARD

The cursor key

Moves the cursor about on the display screen, quickly and accurately. It also scrolls the desired option in the menu page(s): up/down move the current menu selection; right executes the function assigned to the active selection in the menu (same as 'ENTER'). Up/down in the number/character input procedure changes the value, left/right move the cursor on the previous/next position.

If in Home (Navigate) mode, it allows to exit from Home mode.

The 'ZOOM IN' and 'ZOOM OUT' keys



Press 'ZOOM IN' shows more details of a smaller area, by changing the chart scale and zooming in on your display. Press 'ZOOM OUT' to operate similarly to the 'ZOOM IN', except in reverse, by changing the scale and showing a wider, otherwise less detailed view.

The 'ENTER' key

Selects the desired option, confirms selection, creates Objects (Mark, Waypoint, MOB) and finds Information on Objects.

The 'CLEAR' key

Excluding specific situations, returns to the previous menu or leaves a menu without making changes. If you are not into a menu, if the GPS computing a valid fix position and the chart plotter is not in Home mode, pressing 'CLEAR' sets Home mode. When Home (called also Navigate) mode is set, the cursor is not shown anymore and all cartographic functions (zoom, scroll, etc.) are led by the fix position. The fix is centered in the map display and the map scrolls underneath as the fix position changes. To deactivate Home mode move the cursor.

The 'GOTO' key

Allows to select the main navigation functions to a Target. The 'GOTO' key is an *auto-diagnostic* type because the associated menu disables automatically the menu items that are not allowed in that moment. A menu item is disabled when the label is shown in

light grey color, otherwise if the item label is shown in black color, the item is enabled. An item is automatically disabled when the associated function is not allowed.

The Goto menu that appears after the 'GOTO' key pressing shows the following 6 items: "LAST GOTO", "CURSOR", "MARK", "ROUTE", "PORT SERVICES", "CLEAR GOTO".

The "LAST GOTO" item when selected shows a window with the coordinates of the previous inserted Target.

The "CURSOR" item is disabled when in Navigation mode (for the Navigation (Home) mode meaning see the 'CLEAR' key in this paragraph); this item is enabled only if the cursor is moved to the desired position for inserting Target.

The "MARK" item is disabled if no Mark has been stored.

The "ROUTE" item is disabled if no Waypoint has been stored.

The "PORT SERVICES" item is disabled if no MEDIA with charting data has been inserted.

The "CLEAR GOTO" is enabled only if a Target has been inserted and all other items are disabled (because the Target is present yet).

Another characteristic of the 'GOTO' key is the following: to confirm selection it is possible to press 'ENTER' or 'GOTO'. So you can set many navigation functions without moving finger from the 'GOTO' key. For example to set navigation to cursor, pressing 'GOTO' twice, or to delete navigation pressing this key for 3 times.

The 'MENU' key

Press 'MENU' to open the Settings menu.

The software keys (soft keys)

The software keys (soft key) have different functions according to the modes of operation: their labels for the current functions, located on the front panel, are shown on the screen right above the soft key. When the soft key labels are shown, by pressing the associated soft key the relative function is executed. By pressing 'CLEAR' the four soft key labels disappear.

When the soft key labels are not shown and any menu is not open, by pressing one of the four soft keys their labels for the current functions are shown on the screen immediately above the soft keys:

'MAP' : selects the Map Menu

'DATA' : selects wrap around the User Points List, the Route Data Report and the Databox Setup pages

'FOCUS' : is active only if the Fish Finder mode has been selected. Allows to select the active page among the Chart page and the Fish Finder page.

The 'POWER' key

Press and hold 'POWER' down for 1 second to turn the chart plotter On. Press and hold 'POWER' down (once the chart plotter has been turned On) for 3 seconds turns the chart plotter Off.

Press 'POWER' adjusts brightness and contrast and handles the Palette.

2.1.1 ONLY FOR O.CHART5/5F: THE PAGE KEY

The 'PAGE' key

Press 'PAGE' to select the configuration. After pressing 'PAGE', the Page selection menu (with current page selected) is shown on the screen.

2.1.2 ONLY FOR O.CHART7/7F: ZOOM SLIDER AND MAP ROTOR

On the front panel of the chart plotter, there are two special "controls" or sensors, Zoom Slider and Map Rotor. Both sensors became active by keeping the finger on the sensible area for more than 2 seconds. When the sensors are active, you will see a little icon on the lower right bottom of the display, see the following picture. If you don't touch a sensor for 5 seconds, this icon disappears from the screen.




Fig. 2.1.2 - Zoom Slider and Map Rotor

The Zoom Slider

The Zoom Slider is always used to change the chart scale (Zoom In and Zoom Out): sliding up, the chart plotter recognizes a Zoom Out; sliding down, the chart plotter recognizes a Zoom In.

When the movement on the Zoom Slider is from top to bottom, Zoom In operation is executed. Otherwise when the movement on the Zoom Slider is from bottom to top, Zoom Out operation is executed.

A more advanced use of the Zoom Slider takes into account the movement range. If the movement has a short range, the Zoom operation (Zoom In or Zoom Out) is executed only once. If the movement has a wider range, the Zoom operation (Zoom In or Zoom Out) is executed twice or more times.

The Map Rotor

The function associated to the Map Rotor depends on the status of the function Perspective View, see the Par. 3.8.3.

When Perspective View is set On, the Map Rotor rotates the chart in the center of the screen, the rotation is proportional to the movement.

When Perspective View is set Off, the Map Rotor scrolls the chart (acts like when the cursor touches the edge of the scrollable chart and keeps moving to the same direction).

The Sensors Calibration menu

The Sensors Calibration menu is accessible from the Setup menu:

► 'MENU' + "Setup" + 'ENTER' + "Sensors Calibration" + 'ENTER'

Two options are available: Default and Manual. Default sets the sensitivity value to 7. Otherwise if Manual has been selected, the screen shows an image with the two sensors, Zoom Slider and Map Rotor on the page. You can change the level of sensitivity by pressing 'ZOOM IN' or 'ZOOM OUT' keys.

You touch the desired sensor, Zoom Slider or Map Rotor. The screen shows an indicator (green line) over the image of the relative sensor. The position of the indicator corresponds to the touched location on the physical sensor.

You can save the selected level and exit by pressing 'ENTER' (otherwise pressing 'CLEAR' you can exit without saving settings).

2.2 TURNING THE CHART PLOTTER ON AND OFF

Before powering On the chart plotter, check for the correct voltage (10-35 volt dc) and the correct connections with the positioning instrument.

2.2.1 TURNING ON

► **Press and hold 'POWER' for 1 second**


The chart plotter emits one rapid beep sound and a title page is opened. After a few seconds, the Caution Notice pages is displayed, reminding you that the chart plotter is only an aid to navigation, and should be used with appropriate prudence. The electronic charts are not intended to substitute for the official charts.

2.2.2 TURNING OFF

Press 'POWER' and hold for 3 seconds: a countdown timer appears on the screen, if you release the key before the countdown timer reaches zero, the chart plotter will remain On.

2.3 FIRST SETUP PAGE

This menu allows you to configure the chart plotter and the external devices the first time the chart plotter is powered On. This information can be changed at any time either from the Setup menu (see Chapter 7) or by resetting the chart plotter. Select the correct setup option and press '**ENTER**', when complete press '**Ok**' to exit.



First Setup Page	
Language	English
Chart Language	►
Distance+Speed Units	Nm+Kts
Depth+Altitude Units	Mt
Temperature Units	°C
Time Reference	UTC
Daylight Saving Time	Off
Time Format	24 hour
Date Format	DD-MM-YY
Nav-Aids Presentation	INT
Keypad Beep	On
Input/Output	►
Simulation Mode	►

Fig. 2.3 - First Setup Page menu

The possible selections are listed in the table below:

Language	: The map information will still be displayed in the language of the official digitalized paper chart.
Chart Language	: Selects a sub-menu with two items: Language to set the language to display chart information and Mode to define how objects are translated.
Distance+Speed Units	: Selects the unit for Distance and Speed (among Nm+Kts, Sm+Mph, Km+Kph). The <u>default</u> setting is Nm+Kts.
Depth+Altitude Units	: Selects the unit for Depth and Altitude among Ft and Mt. The <u>default</u> setting is Mt.
Temperature Units	: Selects the unit among °C and °F. The <u>default</u> setting is °C.

Time Reference	: Allows switching between UTC or local time, by entering the Local Time offset. The <u>default</u> setting is UTC.
Daylight Saving Time	: Sets On/Off the Daylight Saving Time. The <u>default</u> setting is Off.
Time Format	: Selects the format for the time between 12 and 24 hour. The <u>default</u> setting is 24 hour.
Date Format	: Selects the Date Format between MM-DD-YY (month-day-year) and DD-MM-YY (day-month-year). The <u>default</u> setting is DD-MM-YY.
Nav-Aids Presentation	: Allows to set the Nav Aids presentation as US (Draw Nav-Aids using NOAA symbology) or INTERNATIONAL (Draws Nav-Aids using international symbology). When selected it affects Lights, Signals, Buoys & Beacons display. The <u>default</u> setting is INT.
Keypad Beep	: Enables or disables the single audio beeps emitted any time the chart plotter keypad is pressed. If the incorrect key is pressed or the function required cannot be executed, the chart plotter emits three beeps. The <u>default</u> setting is On.
Input/Output	: Allows to setup the devices that needs a dedicated port as C-Com, BBFF 50/200 and AIS 38400. The <u>default</u> setting is None for all.
Simulation Mode	: Allows to setup the simulation data before use the Simulation function .

2.4 LCD ADJUSTMENT

To adjust the brightness and contrast of the LCD screen follow the procedure:

➤ 'POWER'

or:

➤ 'MENU' + "LCD Adjustment" + 'ENTER'

On the screen two control bars appear, that indicate the actual values for contrast and brightness.

The screen brightness can be controlled using the 'BRIGHT -' and 'BRIGHT +' soft keys: adjusting the control bar the backlight reaches the desired level. Press 'ENTER' to confirm the new value (the soft key and the graphic windows disappear from the screen). To modify the contrast value follow the same procedure, using the 'CONTR -' and 'CONTR +' soft key .

The new values for contrast and brightness are retained until they are reset.

2.4.1 PALETTE

It is possible to set the palette used to enhance the visibility of the screen depending on the surrounding light condition. To select this option:

➤ 'POWER' + 'MENU'

or:

➤ 'MENU' + "LCD Adjustment" + 'ENTER' + 'MENU'

It is possible to select Normal, Sunlight, Night Vision or NOAA for Palette. **Normal** is recommended when the chart plotter is not exposed to the direct sunlight. When this mode is set the maps are displayed in order to use colors as similar as possible to the ones used in the original paper charts. **Sunlight** is designed to enhance the visibility of the screen when the chart plotter is exposed to the sunlight. The maps are much brighter than in the other modes and the depth areas are filled with white color so different depth areas are not easily distinguishable. **Night Vision** is recommended when the environment is dark in order to reduce the glare of the display. The chart plotter displays maps and screen in darker colors. **NOAA** allows setting NOAA paper chart colors presentation.

2.5 SELECTING THE USER INTERFACE LANGUAGE

It is possible to set the language to display menus, data pages, warning/ alarm messages, full/quick info, list of objects found by find/nearest function, and on charts (such as place's names, buoy's names and so on). To select the language you want:

➤ 'MENU' + "Setup" + 'ENTER' + "Language" + 'ENTER'

Note

If the selected language is not available on cartographic data, English language is used instead.

WARNING

If you have accidentally selected an incomprehensible language, and you don't be able to reselect your language (the above procedure is not of help to you), follow this procedure: press 'MENU', then move the cursor to highlight: For O.CHART5/5F the first item and For O.CHART7/7F the second item (starting from the top) which corresponds to the Setup menu and press 'ENTER'. Then a window appears with "Language" message, press 'ENTER': now select your language and press 'ENTER' again. Anyway if you in trouble, see Chapter 8 "System Test" for a RAM Clear operation: the chart plotter will also return all selections, in particular language, to original default values.

2.6 SELECTING THE CHART LANGUAGE

To select the language you want:

➤ 'MENU' + "Setup" + 'ENTER' + "Chart Language" + 'ENTER'

The possible choices are listed below:

- LANGUAGE: Allows setting the language to display chart information. The language is chosen among the list of languages available on the cartographic data (DATA MEDIA or embedded charts).
- MODE : Defines how objects are translated. It is possible to choose between the three following options:
 - Off** Uses the same Language used for LANGUAGE. If the selected language is not present on the objects information, English is used instead;
 - English** Always uses English;
 - Local** Uses the first Local language present on data. If no Local language is available, English is used instead.

Note

a. When User Interface Language is changed, Chart Language settings are set as follows: MODE is set to Off and Chart Language is set as the User Interface Language selection if available on the chart data, otherwise is set to English.

b. If the cartographic data is changed (for example the DATA MEDIA is removed or replaced), Chart Language settings should be verified and if necessary changed.

2.7 EXTERNAL CONNECTIONS

Note

In the following paragraphs, n = 1, 2, 3 for O.CHART5/O.CHART 5F and n = 1, 2, 3, 4, 5 for O.CHART7/O.CHART 7F.

2.7.1 AUTOPILOT CONNECTIONS

To connect the Autopilot to the serial Port n. To choose your preferred setting follow the procedure:

- **'MENU' + "Input/Output" + 'ENTER' + "Port n Output" + 'ENTER'**

Then choose your preferred setting among the NMEA available settings NMEA-0183 4800-N81-N, NMEA-0180, NMEA-0180/CDX (the default setting is NMEA-0183 4800-N81-N) and press 'ENTER' to confirm.

2.7.2 EXTERNAL NMEA CONNECTIONS

To connect the External NMEA to the serial Port n. To choose your preferred setting follow the procedure:

- **'MENU' + "Input/Output" + 'ENTER' + "Port n Input" + 'ENTER'**

Then choose your preferred setting among the NMEA available settings NMEA-0183 1200-N81-N, NMEA-0183 4800-N81-N, NMEA-0183 4800-N82-N, NMEA-0183 9600-N81-N, NMEA-0183 9600-O81-N (the default setting is NMEA-0183 4800-N81-N) and press 'ENTER' to confirm.

2.7.3 C-COM CONNECTIONS

To connect the modem C-COM to the chart plotter Port 1 verify that the Port 1 setting is the following:

- **'MENU' + "Input/Output" + 'ENTER' + "Port 1 Input" + 'ENTER' + "C-COM" + 'ENTER'**

Note

The connection is valid for the C-COM IR and C-COM RS232 too.

Also the modem C-COM can be connected to the other ports, in this case set the format for the selected Port.

2.7.4 ONLY FOR O.CHART7/7F: EXTERNAL ALARM CONNECTION

Once the connection is active, to enable the External Alarm follow the procedure:

- **'MENU' + "Alarms" + 'ENTER' + "External Alarm" + 'ENTER' + "On" + 'ENTER'**

Note

The connection is available also on the AUX-IN I/O Port.

2.8 USING C-MAP BY JEPPESEN DATA MEDIA

The chart plotter has a built-in world map. To use the chart plotter as a navigation aid, DATA MEDIA with detailed information for the area you wish to navigate are required. See the technical details of your chart plotter for inserting/removing DATA MEDIA procedure.

Note

During normal operations the MEDIA should not be removed since the chart plotter may lock up.

2.9 SIMULATION MENU

Used in order to use your chart plotter without input data. It generates a display with a moving vessel, so that you can practice using the controls in safety.

- 'MENU' + "Simulation" + 'ENTER'

2.9.1 SIMULATION MODE

Enables (On) or disables (Off) the Simulation mode. The default setting is Off.

- 'MENU' + "Simulation" + 'ENTER' + "Simulation Mode" + 'ENTER'

2.9.2 SPEED

Sets the value for speed in the Simulation mode. The default setting is 1.0 Kts.

- 'MENU' + "Simulation" + 'ENTER' + "Speed" + 'ENTER'

2.9.3 HEADING

Sets the desired value for heading in Simulation mode. The default setting is 000° M.

- 'MENU' + "Simulation" + 'ENTER' + "Heading" + 'ENTER'

2.9.4 DATE

Sets the date of the simulated fix.

- 'MENU' + "Simulation" + 'ENTER' + "Date" + 'ENTER'

2.9.5 TIME

Sets the time of the simulated fix.

- 'MENU' + "Simulation" + 'ENTER' + "Time" + 'ENTER'

2.9.6 CURSOR CONTROL

Enables (On)/disables (Off) the cursor control. The default setting is Off.

- 'MENU' + "Simulation" + 'ENTER' + "Cursor Control" + 'ENTER'

3. For the New User

In order to get started using your chart plotter, you must do the following things:

1) Your chart plotter must have been installed properly according to the installation instruction.

2) You must have performed the proper settings for use with your positioning instrument and inserting the DATA MEDIA for navigating in area you wish.

3) You must have Power On to the chart plotter and adjust the brightness and contrast of the display.

Once this is done, you can use your chart plotter for navigation.

3.1 SCREEN DISPLAY CONFIGURATION

The chart plotter screen may be displayed in several modes. To select the screen configuration you wish:

ONLY FOR O.CHART5/5F

➤ 'PAGE'

ONLY FOR O.CHART7/7F

➤ 'MENU' + "Page" + 'ENTER'

An icons menu appears on the screen: it shows the available pages. Move the cursor to select the page you want and the press 'ENTER'. In the following paragraphs are displayed examples of these pages.




Fig. 3.1 - Example of Page Selection menu

Note that if the Fish Finder pages are not available, the Chart + Fish Finder, full Fish Finder and Fish + Data boxes pages are respectively replaced by Chart + Depth, full Depth and Depth + Data boxes pages, if valid NMEA0183 depth data is available. If the Fish Finder is present, then the Depth pages are not shown in this page.

At the same time as these pages displayed, it is possible to show on the screen the display of chart and/or navigation information:

➤ **Press any soft key + 'DATA'**

to select wrap around the User Points List, the Route Data Report and the Databox Setup pages, see the following figure:




Fig. 3.1a - Example of Data pages

Databox Setup : Selects the desired configuration for the data window, allowing to select the number of lines (max 4) and the values that are shown in the Text Area. The first column says that the line is displayed or not; moving the cursor up and down select the desired line and using 'ENTER' to select it. After pressing 'ENTER' the data type has been selected.

User Points List : Displays information on all stored User Points (Marks and Waypoints).

Route Data Report: Displays information on Routes.

3.1.1 CHART PAGE

It is very important to know what is displayed on the screen.

ONLY FOR O.CHART5/5F

➤ 'PAGE' + "Chart" + 'ENTER'

ONLY FOR O.CHART7/7F

➤ 'MENU' + "Page" + 'ENTER' + "Chart" + 'ENTER'

shows the chart at full screen:




Fig. 3.1.1 - Example of Chart page

3.1.2 CHART+DATABOXES PAGE

It is possible to display the chart and the selected Data Boxes on the screen:

ONLY FOR O.CHART5/5F

➤ 'PAGE' + "Chart+Databoxes" + 'ENTER'

ONLY FOR O.CHART7/7F

➤ 'MENU' + "Page" + 'ENTER' + "Chart+Databoxes" + 'ENTER'



Fig. 3.1.2 - Example of Chart+Databoxes page

3.1.3 ROLLING ROAD PAGE

The Rolling Road page displays the navigation data in graphic mode. It is possible to set the information in the page according to the user requirements.

ONLY FOR O.CHART5/5F

➤ 'PAGE' + "Rolling Road" + 'ENTER'

ONLY FOR O.CHART7/7F

➤ 'MENU' + "Page" + 'ENTER' + "Rolling Road" + 'ENTER'




Fig. 3.1.3 - Example of Rolling Road page

3.1.4 GPS STATUS PAGE

The GPS data page shows in graphic mode GPS data.

ONLY FOR O.CHART5/5F

➤ 'PAGE' + "GPS Status" + 'ENTER'

ONLY FOR O.CHART7/7F

➤ 'MENU' + "Page" + 'ENTER' + "GPS Status" + 'ENTER'




Fig. 3.1.4 - Example of GPS Status page

On the top side of the screen, there is a polar representation of the azimuth and elevation of each satellites. The circle contains a number indicating the PRN of the satellite and it is filled when it is used for the fix solution. On the bottom side there are histograms indicating the S/N ratio (SNR). The bar is filled when the satellite is used for solution. When a valid fix is received, the Lat/Lon, Date, Time, HDOP, VDOP, SOG, COG and Altitude are shown in the page.

3.1.5 DEPTH GRAPH PAGES¹

The Depth Graph can be selected in three different modes: in a reduced form with chart, in a reduced form with Databoxes, or at full screen.

To select the Depth Graph with chart follow the procedure:

ONLY FOR O.CHART5/5F

➤ 'PAGE' + "Chart+Depth" + 'ENTER'

ONLY FOR O.CHART7/7F

➤ 'MENU' + "Page" + 'ENTER' + "Chart+Depth" + 'ENTER'




Fig. 3.1.5 - Example of Depth Graph with charts

and to select the Depth Graph with Data Boxes:

ONLY FOR O.CHART5/5F

➤ 'PAGE' + "Depth+Databoxes" + 'ENTER'

ONLY FOR O.CHART7/7F

➤ 'MENU' + "Page" + 'ENTER' + "Depth+Databoxes" + 'ENTER'




Fig. 3.1.5a - Example of Depth Graph with Data Boxes

Otherwise to select the Depth Graph at full screen, select:

ONLY FOR O.CHART5/5F

➤ 'PAGE' + "Depth" + 'ENTER'

ONLY FOR O.CHART7/7F

➤ 'MENU' + "Page" + 'ENTER' + "Depth" + 'ENTER'




Fig. 3.1.5b - Example of Depth Graph at full screen

Note¹

If valid NMEA0183 depth data is not available, or the Fish Finder is present, Chart + Depth, full Depth and Depth + Data boxes pages are respectively replaced by the Chart + Fish Finder, full Fish Finder and Fish + Data boxes pages.

3.1.6 ONLY FOR O.CHART7/7F: VIDEO INPUT PAGES

It is possible to see a video input picture on the chart plotter screen. This is allowed only if an external video signal source is connected to the chart plotter.

To select the Video Input pages follow the procedure:

➤ 'MENU' + "Page" + 'ENTER' + select the Video Input page you want + 'ENTER' + 'Yes'

Two types of Video pages are available. The Chart + Video page that shows the chart at full screen and the image from the video camera on a rectangular window which can be moved up/down and/or left/right using the cursor key, to select where the window is placed. Otherwise it is available the Video page displayed at full screen.

Note

Once the Video Mode is active, press 'POWER' and use the following keys to adjust video settings: press the Soft Keys to adjust LCD contrast and backlight; move cursor up/down to adjust brightness and left/right to adjust colors; press 'ZOOM IN'/ 'ZOOM OUT' to adjust hue phase. Press any other key to exit from Video Mode.

3.2 MAP ORIENTATION

Selects the orientation of your chart according to: North Up (the map is shown with North upwards), Head Up (the map is shown with the ship's current heading upwards) and Track Up (the map is shown with the currently selected course leg upwards). The default setting is North Up.

- 'MENU' + "Setup" + 'ENTER' + "Map Orientation" + 'ENTER'

If Head Up or Track Up has been selected, a window is shown to insert the

Map Resolution:

- 'MENU' + "Setup" + 'ENTER' + "Map Orientation" + 'ENTER' + "Head Up" or "Track Up" + 'ENTER' + use cursor to insert values + 'ENTER'

The resolution angle, which may be selected in the range [5 – 60] degrees, defines the maximum variation of the reference angle after which the map changes its orientation.

3.3 NAVIGATING TO A SINGLE DESTINATION

3.3.1 DISTANCE AND BEARING TO TARGET

Place the cursor on location to navigate to and press 'GOTO', select "CURSOR" and press 'GOTO' again or 'ENTER'.

A straight line is shown on the screen connecting the Target with the ship's position. When the Target is placed, all navigation data are referred to this Target.




Fig. 3.3.1 - Navigation to a single destination

3.3.2 TIME TO GO

When the Target is set the TIG value (if selected) is displayed in the Text Area (see Fig. 3.3.1).

3.3.3 DELETING TARGET

Place cursor on Target icon, press 'STOP'. A window to confirm the navigation interruption appears on the screen. Press 'ENTER' or 'GOTO': the symbol that identifies Target remains on the screen until it is redrawn.

3.4 NAVIGATION ON A ROUTE

It is possible to define several positions, Waypoints, in a sequence called route and to navigate follow the route towards the end point.

3.4.1 ADDING WAYPOINT

To create a Waypoint place the cursor on the desired position, press 'ENTER', select "WAYPOINT", press 'ENTER' again. The Waypoint is shown on the screen and it becomes the first point of the first route. A window with information on route number, symbol and name, Latitude/Longitude of Waypoint is shown on the screen. Also it is indicated the distance to cover (and/or covered, if there are several Waypoints) refer to the next Waypoint.

3.4.2 CREATING A ROUTE

Repeat the "Adding Waypoint" procedure described in the previous Par. 3.4.1. The sequence of moving the cursor and pressing 'ENTER' is continued to create the route, until you have reached the last Waypoint, your final destination. Segments connecting the Waypoints are shown, and the starting point is identified by a circle surrounding the first Waypoint of the route; the distance to cover is shown too.

3.4.3 DELETING WAYPOINT

To delete the Waypoint, place the cursor on the desired Waypoint, press 'DELETE'. Press 'ACCEPT' to confirm the deletion. The Waypoint is deleted and a new line between previous and next Waypoint is shown. The deleted Waypoint remains shaded until the screen is redrawn.

When the cursor is placed on the desired starting Waypoint (it can be the first Waypoint of the route or not) press 'GOTO', select "CURSOR" and press 'GOTO' again or 'ENTER'. The Waypoint symbol is shown enclosed in a circle and a dot line connecting the Target with the ship. All navigation data are referred to the Target placed.

The Target automatically is moved on the next Waypoint on the route when the Target is reached.

Otherwise placing the cursor on Target and pressing 'NEXT' the Target is moved on the next Waypoint on the route. The cursor is moved on the actual Waypoint Target (if the Target is placed on the last Waypoint on the route 'NEXT' is not active). When the cursor is on the Target, pressing 'PREVIOUS' the Target is moved on the previous Waypoint in the route. The cursor is moved on the actual Waypoint Target (if the Target is on the first Waypoint of the route 'PREVIOUS' is not active).

3.4.4 TIME TO GO

When the Target is placed the TTG value (if selected) is shown in the Text Area.

3.4.5 DELETING TARGET

Place cursor on Target icon, press 'STOP'. Press 'ENTER' or 'GOTO': the symbol that identifies Target remains the screen until it is redrawn.

3.5 C-MAP BY JEPPESEN MAX CARTOGRAPHY INFORMATION

MAX is a major evolution of the product technology. Key points are:

3.5.1 DATA FEATURES

- **ISO Certification** (*electronic chart production process with quality certification*)
- **Extra Large Coverage** (*all the C-MAP By JEPPESEN electronic chart detail and a huge coverage without having to change cartridge*)
- **Official data source** (*data based on use of official data sources*)
- **Detailed World Background** (*worldwide background chart with details*)
- **Depths & Land Elevation** (*color shading of sea depth and land altitude for improved chart reading*)
- **Bathymetric & Spot Soundings** (*additional Data Base with depth and bathy information for an extraordinary view of the seabed depth*)
- **Detailed Port Plan** (*complete port and marina charts with detail*)
- **Search & Find** (*quickly locates chart contents and objects*)
- **Tides Preview** (*dynamic simulation of tides*)
- **Dynamic Currents** (*current arrows dynamically display direction and speed*)
- **Dynamic Nav-Aids** (*displays Nav-Aids in true color and with real interval lighting*)
- **Port Info** (*all the information of the available services in the ports and how to contact them*)
- **Enhanced Port Info & Roads** (*details of the available facilities and services in ports and surrounding areas*)
- **Object Info** (*indicates restricted area details and related information*)
- **Quick Info** (*full information on objects, buoys, wrecks, shoals and Nav-Aids*)
- **Photos & Diagrams** (*high definition pictures of ports, piers, bridge diagrams and nav-aids*)
- **Multilanguage Support** (*displays charts in the local character set*)
- **True-Type Font** (*improves text on chart for optimal reading*)

3.5.2 PRESENTATION FEATURES

- **Clear View** (*advanced legibility techniques providing more chart data on the screen*)
- **Clear Info** (*sophisticated "Human Dictionary" to translate Nav-Aid abbreviations found on paper charts*)
- **Dynamic Nav-Aids** (*an innovative and dynamic presentation mode*)

- **Flexi-Zoom** (*increased Under and Over Zoom between chart levels, resulting in optimal scale display for any situation*)
- **Dynamic Elevation Data** (*optimized palettes including the NOAA color palette*)
- **Perspective View** (*"Real World" perspective view of the chart, updated real-time during navigation*)
- **Smooth-Zoom** (*smooth transition of cartographic levels*)
- **Enhanced Turbo-Zoom** (*extra fast cartography level change displaying the most important cartographic objects*)
- **Enhanced Mixing Levels** (*seamless data presentation*)
- **Off-line redraw** (*cartography level transition without image construction*)

3.5.3 CARTOGRAPHIC DATA RELATED FEATURES

- **Guardian Alarm** (*automatic control and alarm over obstacles on charts in front of your boat*)
- **Safety Toolbar** (*interactive alarm system for situational awareness on screen*)
- **Safety Route Check** (*sophisticated function checking dangerous objects along your navigation route*)

3.6 BACKGROUND CHARTS

The internal background charts can be updated to include the MAX A and B level charts which provide improved marine data, rivers, lakes, terrestrial data (major streets, highways, railways, etc...), nav-aids, depth areas, territorial water areas, etc... by reading them from a special DATA MEDIA (contact your local dealer).

3.7 PICTURES & DIAGRAMS

The MAX data format allows assigning one or more image to any cartographic object. These *Pictures* are typically used to facilitate the identification of cartographic objects or places around the map: they can be the landscape layout nearby a harbor, the shape of a bridge or of a buoy etc. On some objects, such as bridges, the image associated can represent the *Diagram* representing the shape of the objects and the various characteristics (length, height, type of bridge etc.).




Fig. 3.7 - Pictures and Diagrams

3.7.1 QUICK INFO ON OBJECTS WITH PICTURES

On the Quick Info, there will be the camera icon on the top bar of the window if at least one of the objects found has one or more pictures associated.

3.7.2 EXPANDED INFO ON OBJECTS WITH PICTURES

On the Full Info, there will be the small camera icon on a corner of the square containing the object icon or a big photo icon centered on the square for the object without icon. To see the picture press **'PICTURE'** when the object with a picture is highlighted.

3.7.3 CHANGE PICTURE SIZE

When the picture is shown, it is possible to fit it to screen by pressing **'ENTER'**.

3.8 MAP MENU

To select the map configuration (available only from the chart page):

- Press any soft key + **'MAP'**

3.8.1 ZOOM TYPE

- Press any soft key + **'MAP'** + **"Zoom Type"** + **'ENTER'**

Allows larger expansion or compression of the chart scale while zooming in or out. Zoom Type has two options: Standard (default) or Flexi-Zoom. When in Flexi-Zoom mode, a short **'ZOOM...'** push causes a change of chart, whilst a long **'ZOOM...'** push (press and hold) causes a pop-up window to be displayed on a corner of the screen. The window shows the current Zoom Factor. By pressing **'ZOOM IN'**/**'ZOOM OUT'** the map is expanded or compressed according to the zoom factor selected. The Window is automatically closed if **'ZOOM...'** is not pressed for 2 seconds and the selected zoom factor will be used at the next zoom in/out.

3.8.2 FONTS & SYMBOLS

- Press any soft key + **'MAP'** + **"Fonts & Symbols"** + **'ENTER'**

It is possible to set the size of all names and symbols drawn on the charts, selecting between Normal size (the regular characters size) and Large size.




Fig. 3.8.2 - Example of Normal size (on the left side) and Large size (on the right side) settings

3.8.3 PERSPECTIVE VIEW

- Press any soft key + 'MAP' + "Perspective View" + 'ENTER'

Chart data may be projected in perspective mode during navigation. This function allows setting the panoramic view of the chart. As the upper side of the map is more compressed than the lower side, a wider map area is visible. The perspective view allows showing more chart information immediately ahead and around the cursor.



Fig. 3.8.3 - Perspective View

Note _____ **ONLY FOR O.CHART7/O.CHART 7F**
See also the Rotor usage on Par. 2.1.1.

3.8.4 DYNAMIC NAV-AIDS

- Press any soft key + 'MAP' + "Dynamic Nav-Aids" + 'ENTER'

This function allows settings blinking lights on Nav-Aids. The blinking period and color of each Nav-aid is read from the Nav-Aid attributes available on the data cartridge. When the ship is inside the Nav-Aid nominal range, the light of the Nav-Aid will start blinking.

3.8.5 MIXING LEVELS

- Press any soft key + 'MAP' + "Mixing Levels" + 'ENTER'

When the map coverage at the current zoom level does not fill the entire screen, the chart plotter draws the rest of the map expanding the cartographic information read from, at most, two zoom levels above the current zoom level. For this reason the map is drawn three times: firstly it draws the two levels before the current level and then the current level. The area covered by the cartographic data read from the previous levels is identified by a grayed pattern. When the cursor is moved on an area not covered by data of the current level the chart plotter zooms out to the first level covered by cartographic data. The default setting is Off.

Note _____
The Mixing Levels function affects the speed of the redraw of the screen. If this function is not used it maybe disabled.

3.8.6 SAFETY STATUS BAR (DSI = Data Safety Indicator)

- Press any soft key + 'MAP' + "Safety Status Bar" + 'ENTER'

The possible choices are listed in the table below:

- ON : the Safety Status Bar is shown
- OFF : the Safety Status Bar is not shown

- **ICON** : the Safety Status Bar is not shown, but a Warning alarm Icon will blink on the corner of the map screen as soon as any item controlled by the DSI (**Data Safety Indicator**) function returns an alarm condition. The Warning Icon remains displayed until the alarm condition persists.

When Safety Status Bar is On, a status bar with six boxes showing the status of certain functions is displayed. Any warning or alarm condition is identified by the red color to indicate possible risk.



Fig. 3.8.6 - Safety Status Bar

Boxes definition is as follows:

- ① **Zoom**
 Normal : when the chart is displayed at normal scale.
 U. Zoom : red when the chart is under-zoomed out more than twice normal scale, gray otherwise.
 O. Zoom : red when the chart is over-zoomed in more than twice normal scale, gray otherwise.
 Chart Lock: red when the chart is zoomed in more than twice normal scale, gray otherwise.
- ② **Best Map**
 Red when a more detailed chart is available under the cursor position.
- ③ **Data Off**
 Red when at least one of the following objects or layers is turned off (by the user): Depths/soundings; Wrecks/obstructions; Tracks/routes; Attention areas; Nav-Aids.
- ④ **Declutter**
 Displays when Clear View function is On.
- ⑤ **Dangers**
 Red when "Guardian Technology" detects one of the following objects: Land, Intertidal, Depth Area, Rocks, Obstructions, Shoreline Constructions, Fishing Facility, Wrecks, Dredged area, Diffusion area, Mooring facilities, Pingos and Production installations.
- ⑥ **Cautions**
 Red when "Guardian Technology" detects cautionary or restricted area.

3.8.7 SATELLITE IMAGERY

- Press any soft key + 'MAP' + "Satellite Imagery" + 'ENTER'.

It is possible to overlay the satellite image for background map. When it is set On, the Palette is set to Normal to display the proper colors.

3.8.8 CURRENTS PREDICTION

- Press any soft key + 'MAP' + "Currents Prediction" + 'ENTER'.

It is possible to see the variation of the Tidal arrows on the selected area at any given time. A window is shown on the low-left side of the chart, press 'SET' to set data and time, and 'DECR'/'INCR' to decrease/increase the time. Press 'EXIT' to exit.

3.9 INFO FUNCTION

Place the cursor on the desired position then:

- Press any soft key + 'MAP' + "Info" + 'ENTER' to display the Info tree and the expanded Info page.

3.9.1 INFO TREE AND EXPANDED INFO PAGE

This page combines the Info Tree and the Expanded Info pages; this gives the advantage of showing the details of the object selected on the Info Tree while the cursor is moving through the Info Tree's items. The upper side of the page contains the Info Tree and the lower side contains the expanded information. While moving the cursor through the Info Tree, all the relevant information of the selected object is shown on the lower part of the page. When the selected object is a Tide Height, pressing 'ENTER' the Tide page is shown. Pressing 'CLEAR' the page is closed. To select the next page press 'PAGE DN'. 'HOME' restarts the Expanded Info function.

3.9.2 GETTING TIDE INFO

To obtain Tide Info:




Fig. 3.9.2 - Tide Info Icon

Place the cursor on the Tide symbol, an automatic Info window is opened:



Fig. 3.9.2a - Automatic Info on Tide

To display the Tide Graph page press 'EXPAND' then 'ENTER' (otherwise press 'EXP ALL' to select all available information).




Fig. 3.9.2b - Tide Graph

Using the cursor key, it is possible to move the cursor anywhere on the graph and display the time, height (vertical cursor) and draught (horizontal cursor) on a particular graph point. Also use 'ZOOM IN' or 'ZOOM OUT' to go to previous or next day and 'ENTER' to set date (move the cursor key up/down to insert the desired number and use it left/right to move cursor to left/right).

Note

Tide graphs are an approximation of the tide and they should be used in conjunction with traditional tide tables and navigational methods.

3.9.3 GETTING PORT INFO

Upon viewing the chart of a port or harbor, you will see a Port Info icon that can be clicked on to query the available information immediately displayed with many details.




Fig. 3.9.3 - Port Info icon

The available information is shown in the Automatic Info window where icons of the available services are shown:



Fig. 3.9.3a - Automatic Info window

To expand information on the object press 'EXPAND' (otherwise press 'EXP ALL' to select all available information).

3.9.4 ENHANCED PORT INFO

MAX charts include additional port services that were not present before. Additional attributes of Port Areas and Port Marinas have been included (Location, Country, Region, State, Harbor master telephone number etc).

3.10 MAP SETTINGS

This menu allows the user to customize the screen:

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER'

3.10.1 DISPLAY MODE

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER'

Selects from a predefined table what cartographic objects are displayed and which display options are set. Preprogrammed settings are user selectable from Full, Medium, Low, Radar, Tides, Custom.

The table below shows the selections for each mode:

Setting	Full	Medium	Low	Radar	Tides	Custom (Default values)
Place Names	On	On	On	On	On	On
Name Tags	On	Off	Off	Off	Off	Off
Nav Aids & Light Sectors	On	No Sector	No Sector	No Sector	Off	No Sector
Attention Areas	On	On	Off	Off	Off	On
Tides & Currents	On	Off	Off	Off	On	On
Seabed Type	On	Off	Off	Off	Off	Off
Ports & Services	On	On	Off	On	Off	On
Tracks & Routes	On	Off	Off	Off	Off	On
Depth Range Min	0 Mt	0 Mt	0 Mt	0 Mt	0 Mt	0 Mt
Depth Range Max	9999 Mt	9999 Mt	9999 Mt	9999 Mt	9999 Mt	10 Mt
Land Elevation	On	On	Off	Off	Off	On
Land Elevation Values	On	Off	Off	Off	Off	Off
Roads	On	Off	Off	Off	Off	On
POI	On	Off	Off	Off	Off	Off

Lat/Lon Grid	On	Off	Off	Off	Off	Off
Chart Boundaries	On	Auto	Off	Off	Off	Auto
Value-Added Data	On	Off	Off	Off	On	On
Chart Lock	On	On	On	On	On	On
Underwater Objects Limit	304 Mt	10 Mt	10 Mt	10 Mt	10 Mt	10 Mt
Rocks	Icon+Depth	Icon	Icon	Icon	Icon	Icon
Obstructions	Icon+Depth	Icon	Icon	Icon	Icon	Icon
Diffusers	Icon+Depth	Icon	Icon	Icon	Icon	Icon
Wrecks	Icon+Depth	Icon	Icon	Icon	Icon	Icon

The following are the available selections only if Custom has been selected:

Place Names: Turns On/Off the displaying of the names.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Place Names" + 'ENTER'

Name Tags: Displays a tag for particular chart objects that either includes the name of the chart object or the depth of an underwater chart object.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Name Tags" + 'ENTER'


Nav Aids & Light Sectors: Turns On (Nav Aids & Light Sectors are shown)/Off (Nav Aids & Light Sectors are not shown)/No Sector (Nav Aids are shown, Light Sectors are hidden).

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Nav Aids & Light Sectors" + 'ENTER'

Attention Areas: Turns On/Off the displaying of the Attention Areas, areas in which special attention by the mariner is required, because of natural or man-made hazards, or sailing regulations and restrictions.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Attention Areas" + 'ENTER'

Tides & Currents: Turns On/Off the displaying of the Tides and Currents. The worldwide database with tidal stream information is available with MAX DATA MEDIA.



When data/time is available, Tidal stream arrows are shown on the charts, indicating the direction and strength of the Tide. If no data/time is available from the GPS or the chart plotter is not in Simulation mode, the icon on the map is generic one. The color of the arrow denotes the strength of the current as follows:

0 to 0.1 kn - □	← Yellow
0.2 to 1.0 kn - ◁	← Yellow
1.1 to 2.0 kn - ▢	← Orange
2.1 to 3.0 kn - ▣	← Orange
3.1 to 9.9 kn - ▤	← Red

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Tides & Currents" + 'ENTER'

Seabed Type: Turns On/Off the displaying of the Seabed Type.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Seabed Type" + 'ENTER'

Ports & Services: Turns On/Off the displaying of the nearest available facilities of a particular type (i.e. the nearest Hospital, sailmaker, bank, etc.). The icons list of the available services is shown on the screen.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Ports & Services" + 'ENTER'

Tracks & Routes: Turns On/Off the displaying of Tracks and Routes (recommended and established routes for ships at sea, including traffic separation schemes, deep water routes, ...).

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Tracks & Routes" + 'ENTER'

Depth Range Min: Allows to insert a minimum value for the depth range.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Depth Range Min" + 'ENTER'

Depth Range Max: Allows to insert a maximum value for the depth range.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Depth Range Max" + 'ENTER'

Land Elevation: Turns On/Off the displaying of Land Elevation.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Land Elevation" + 'ENTER'

Land Elevation Values: Turns On/Off the displaying of Land Elevation Values.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Land Elevation Value" + 'ENTER'

Roads: Turns On/Off the displaying of Roads on the screen.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Roads" + 'ENTER'

POI: Turns On/Off the displaying of Points Of Interest.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "POI" + 'ENTER'

Lat/Lon Grid: Turns On/Off the displaying of the Latitude and Longitude grids.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Lat/Lon Grid" + 'ENTER'

Chart Boundaries: Turns On or turns Off the displaying of the Chart Boundaries.

Selecting Auto instead, if we are in background charts only the first charts level contained in the DATA MEDIA are displayed, if we are in a charts level contained in the DATA MEDIA the next four charts level are displayed.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Chart Boundaries" + 'ENTER'

Value-Added Data: The Value-Added Data (VAD) is a collection of additional cartographic objects which are not present on the original paper chart (from which the electronic chart derives). These objects have been obtained from other sources and then merged to the electronic charts in order to provide more information useful for the navigation. VAD object can be any cartographic objects and it can be distinguished from the official-chart-objects from the Quick Info. A dedicated icon is shown on the Quick Info window to indicate that the object queried is a VAD. The same icon is also shown on the Full Info page and in addition the extended text Value-Added Data is shown on the details of the VAD object.

- Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Value-Added Data" + 'ENTER'

Chart Lock: When Chart Lock is On, the available zoom scales are only the ones containing cartographic data. Instead when Chart Lock is Off, it is possible to zoom down into zoom scales not covered by cartographic data after the last available zoom scale covered by cartographic data.

Note

When an empty level is entered, the message "No cartographic coverage" is shown on a window in a corner of the map display. The warning message is always displayed as long as the current zoom has no data coverage. The DSI window, if present, will show "NO CHART".

- **Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Chart Lock" + 'ENTER'**

Underwater Object Limit: Selects the max depth value to display Underwater Objects.

- **Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Underwater Object Limit" + 'ENTER'**

If value is set to 0 Mt, the Underwater Objects are not shown on the charts. Menu options are greyed out.

If value is more than 0 Mt (i.e. 10 Mt), in the Range from 0 Mt to the selected value the Underwater Objects are displayed according to their setting below.

Rocks: Turns Off/Icon/Icon+Depth (*).

- **Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Rocks" + 'ENTER'**

Obstructions: Turns Off/Icon/Icon+Depth (*).

- **Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Obstructions" + 'ENTER'**

Diffusers: Turns Off/Icon/Icon+Depth (*).

- **Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Diffusers" + 'ENTER'**

Wrecks: Turns Off/Icon/Icon+Depth (*).

- **Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER' + "Custom" + 'ENTER' + "Wrecks" + 'ENTER'**

Note*

Choose the option:

OFF : the object is not visible independently of the selected "Underwater Object Depth Value"

ICON : the object icon is visible without tags, in the range selected from "Underwater Object Depth Value" option

ICON+DEPTH: the object icon and tag is visible, in the range selected from "Underwater Object Depth Value" option

3.10.2 GETTING AUTOMATIC INFO

The type of Automatic Info is user selectable.

- **'MENU' + "Setup" + 'ENTER' + "Auto Info" + 'ENTER'**

The possible settings are:

- **Off** : disabled, no automatic info shown at all
- **On Points** : only on points. This is the default setting
- **On All** : on all objects (points, lines and areas)

The Automatic Info On Points shows information when the cursor is placed on points (as Port Services, Tides, lights, wrecks, rocks, buoys, beacons, obstructions, land markers, etc.). The Automatic Info On All shows information when the cursor is placed on points, on lines (as Depth contours, Traffic Separation, Territorial Sea, Cartographic Lines etc.) on areas (Depth, Built-up, Sea, Attention, Restricted etc.) and on names (on the beginning of the text -hot spot- or on any of the characters of the name -name message box-). The details on Land, Source of Data,

Cartographic Area and Spot Soundings are not shown.

If you press 'EXPAND' you get the information about that object. Otherwise press 'EXP ALL' to select all available information.

3.10.2.1 Quick Info on Lakes

Upon viewing the chart of a lake, you will click on to query the available information immediately displayed with many details. Example: see the following picture:




Fig. 3.10.2.1 - Example of Lakes Info

When the cursor is placed over the icon, the icons of the available services are shown:




Fig. 3.10.2.1a - Quick Info: available services

If you press 'EXPAND' all available information about the cartographic point under the cursor will be shown. See the next paragraph.

3.10.2.2 Full Info on Lakes

The following is an example of Full Info on Lakes:




Fig. 3.10.2.2 - Example of Full Info page

To see the "Fishing" object press 'PICTURE' (when the "Fishing" object is highlighted). On the screen appears:




Fig. 3.10.2.2a - Example of picture associated to the Fishing object

3.11 FIND FUNCTION

The chart plotter allows to find and display on the screen the nearest and available objects: Port Services, Port By Name, Port By Distance, Tide Stations, Wrecks, Obstructions, Lakes Information, Lakes By Name, Points of Interest, Cursor, Coordinates and User Points. The research of these objects refers to the boat position (if a valid fix is received) or to the cursor position (if the received fix position is not valid).

3.11.1 FINDING PORT SERVICES

To select the research of Port Services (up to 10) (i.e. the nearest Hospital, sailmaker, bank, etc.) following the procedure:

► Press any soft key + 'MAP' + "Find" + 'ENTER' + "Port Services" + 'ENTER'

The icons of the available services are shown. Use the cursor key to select any facility and press 'ENTER' or 'FIND'. The list of the nearest ports containing the facility will be shown on the screen. Then choose the port you want and press 'ENTER' or 'FIND'.

3.11.2 FINDING PORT BY NAME

To select the research of Port By Name following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Port by Name" + 'ENTER' + "Port by Name" + 'ENTER'**

Shows the list in alphabetical order of all ports stored on the DATA MEDIA. To select next/previous page press 'ZOOM IN'/'ZOOM OUT' or use the cursor key up/down to slide in the list; otherwise press 'NAME' and use the cursor key to manually insert the name of port. Press 'ENTER' or 'FIND' to locate it on the map.

Note

To filter the list, select the distance range by following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Port by Name" + 'ENTER' + "Range" + 'ENTER' + Insert the desired value**

3.11.3 FINDING PORT BY DISTANCE

To select the research of Port By Distance (up to 10) following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Port by Distance" + 'ENTER'**

Shows the list of ports stored on the DATA MEDIA in closest distance order. Use the cursor key up/down to select one of them and press 'ENTER' or 'FIND' to locate it on the map.

3.11.4 FINDING TIDE STATIONS

To select the research of Tide Station (up to 10) following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Tide Stations" + 'ENTER'**

Shows the list of Tide Stations. Choose one of them and press 'ENTER' or 'FIND' to display the Tide Graph page). Press 'CLEAR' to locate on the map the Tide Station chosen.

3.11.5 FINDING WRECKS

To select the research of Wrecks (up to 10) following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Wrecks" + 'ENTER'**

Shows the list of wrecks stored on the DATA MEDIA in closest distance order. Use the cursor key up/down to select one of them and press 'ENTER' or 'FIND' to locate it on the map.

3.11.6 FINDING OBSTRUCTIONS

To select the research of Obstructions (up to 10) following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Obstructions" + 'ENTER'**

Shows the list of obstructions stored on the DATA MEDIA in closest distance order. Use the cursor key up/down to select one of them and press 'ENTER' or 'FIND' to locate it on the map.

3.11.7 FINDING LAKES INFORMATION

To select the research of Lakes Information following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Lakes Info" + 'ENTER'**

Note

An optional MAX Lake MEDIA must be inserted into the chart plotter to take advantage Lakes Information. The available MAX Lake MEDIA are: NA-M017 USA: North; NA-M018 USA: East; NA-M019 USA: South; NA-M020 USA: West; NA-M029: Alaska; NA-M048: Canada.

It finds the Outdoor Recreational Area objects. See the following picture:




Fig. 3.11.7 - Outdoor Recreational Area objects

Use the cursor key to select any objects and press 'FIND'. The list of the nearest lakes (up to 10) containing the facility will be shown on the screen.

Name	DST [Nm]	BRG [°M]
STRELNA LAKE	6112.28	283
STRELNA LAKE	6112.28	283
PAXSON LAKE	6074.66	284
PAXSON LAKE	6074.66	284
MOOSE LAKE	6141.27	283
MOOSE LAKE	6141.27	283
CROSSWIND LAKE	6126.05	283
CROSSWIND LAKE	6126.05	283
LAKE LOUISE	6145.84	283

Fig. 3.11.7a - Nearest Lakes list

Choose the lake you want and press 'FIND': the Full Info page is shown.

3.11.8 FINDING LAKES BY NAME

To select the research of Lakes By Name following the procedure:

- Press any soft key + 'MAP' + "Find" + 'ENTER' + "Lakes by Name" + 'ENTER' + "Lakes by Name" + 'ENTER'

Shows the list in alphabetical order of all lakes stored on the DATA MEDIA.

To select next/previous page press 'ZOOM IN'/'ZOOM OUT' or use the cursor key up/down to slide in the list; otherwise press 'NAME' and use the cursor key to manually insert the name of lake. Press 'ENTER' or 'FIND' to locate it on the map.

Note

To filter the list, select the distance range by following the procedure:

- Press any soft key + 'MAP' + "Find" + 'ENTER' + "Lakes by Name" + 'ENTER' + "Range" + 'ENTER' + Insert the desired value

3.11.9 FINDING POINTS OF INTEREST

To select the research of Points of Interest (POI) following the procedure:

- Press any soft key + 'MAP' + "Find" + 'ENTER' + "Points of Interest" + 'ENTER'

A sub-menu is shown to find different categories of POIs. Use the cursor key to select the category and press 'ENTER' to display the list of points. Press 'ENTER' again to locate the point on the map.

3.11.10 FINDING CURSOR

To select the research of Cursor position following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Cursor" + 'ENTER'**
Shows the cursor placing it on the center of the screen.

3.11.11 FINDING COORDINATES

To select the research of Coordinates following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "Coordinates" + 'ENTER'**
Use the cursor key to manually insert the coordinates and press 'ENTER' or 'CONFIRM' to locate them on the map.

3.11.12 FINDING USER POINTS

To select the research of User Points following the procedure:

- **Press any soft key + 'MAP' + "Find" + 'ENTER' + "User Points" + 'ENTER'**
Use the cursor key to manually insert the user point name and press 'ENTER' or 'CONFIRM' to locate it on the map.

3.12 ALARMS MENU

Sets the desired values/settings for the alarms.

3.12.1 AUTO OFF

To set the automatic shutdown of the alarms when the alarm condition disappears. The default setting is On.

- **'MENU' + "Alarms" + 'ENTER' + "Auto Off" + 'ENTER'**

3.12.2 ARRIVAL ALARM

To set an acoustic alarm to sound when the vessel is approaching the destination. Specifies the radius of a circle around the Waypoint of a route: when your vessel reaches this circle the alarm sounds. You can disable (Off) the Arrival Alarm or insert value. The default setting is 4.99 Nm.

- **'MENU' + "Alarms" + 'ENTER' + "Arrival Alarm" + 'ENTER'**

3.12.3 XTE ALARM

To set an acoustic alarm to sound when the vessel is deviating from a defined course. The default setting is Off.

- **'MENU' + "Alarms" + 'ENTER' + "XTE Alarm" + 'ENTER'**

3.12.4 ANCHOR ALARM

This function allows inserting of the limit of anchor dragging: beyond that, the alarm is activated. The chart plotter computes the distance between the current GPS position and the GPS position saved at the activation of the anchor alarm in the

menu. If the computed distance exceeds the value set in the menu, the chart plotter shows the alarm message and starts the acoustic alarm. The default setting is Off.

- 'MENU' + "Alarms" + 'ENTER' + "Anchor Alarm" + 'ENTER'

3.12.5 DEPTH ALARM

This function is used to set an acoustic alarm automatically triggered when the depth value read by the depth transducer is too shallow. The default setting is Off.

- 'MENU' + "Alarms" + 'ENTER' + "Depth Alarm" + 'ENTER'

3.12.6 HDOP ALARM

This function is used to show a warning when the received HDOP value exceeds the Alarm Limit for more than 2 seconds. The default setting is Off.

- 'MENU' + "Alarms" + 'ENTER' + "HDOP Alarm" + 'ENTER'

3.12.7 HEADING ALARM

This function is used to show a warning when the HDG sentence is not received from a magnetic sensor reading. The default setting is Off.

- 'MENU' + "Alarms" + 'ENTER' + "Heading Alarm" + 'ENTER'

3.12.8 GROUNDING ALARM

The chart plotter is provided with a function that, by querying the map's data, verifies potential danger to navigation due to shallow water, land, rocks, obstructions and shoreline constructions. The maps are scanned periodically (every 10 seconds). When the Grounding Alarm is active, the chart plotter scans an area in front of the boat. This area is identified by a triangle drawn in front of the boat icon whose direction is determined by the current boat heading. The length of the triangle is user selectable and its angle is 30 degrees. If any of the above objects are found, the chart plotter notifies the danger on a dedicated warning message box in the Grounding Alarm Report page. The Grounding Alarm is switched Off by default after a Master Reset. Once the Grounding Alarm has been activated, a warning message is shown.

- 'MENU' + "Alarms" + 'ENTER' + "Grounding Alarm" + 'ENTER'

3.12.9 GROUNDING ALARM RANGE

Allows setting the length of the sector to be detected among 0.25, 0.5, 1.0 Nm. The default setting is 0.5 Nm. When any of the searched objects is found in the scanned area, a tick marker is printed on the relative box in the Grounding Alarm Report page to identify which dangerous objects have been currently detected.

- 'MENU' + "Alarms" + 'ENTER' + "Grounding Alarm Range" + 'ENTER'

3.12.10 GROUNDING ALARM REPORT

Allows displaying the report of the dangerous objects currently detected.

- 'MENU' + "Alarms" + 'ENTER' + "Grounding Alarm Report" + 'ENTER'

3.12.11 ONLY FOR O.CHART7/7F: EXTERNAL ALARM

When any alarm condition occurs the pin is switched from High Impedance to ground. This signal can be used by an external device (as a hooter or buzzer). The default setting is On.

- 'MENU' + "Alarms" + 'ENTER' + "External Alarm" + 'ENTER'

4. For the Experienced User

Now you have had a chance to become familiar with your new chart plotter, there are a great number of advanced features that you will find helpful.

4.1 MORE ABOUT CREATING AND USING ROUTES

At anytime, you may add or delete Waypoints, see a route summary, reverse the direction of the route or erase the entire route.

4.1.1 ROUTES

To select the Routes menu:

- 'MENU'+ "Route" + 'ENTER'

The following functions are used for the route management.

4.1.1.1 Selecting Route

- 'MENU'+ "Route" + 'ENTER' + "Select" + 'ENTER'

A window appears with the route number list and the related route name. Select the route number. The following functions are available.

Changing Notes

- 'MENU'+ "Route" + 'ENTER' + "Select" + 'ENTER'+ 'NOTES'

Another window is opened: insert the notes (it is possible only if the route is already created). Press 'ENTER' or 'CONFIRM' ('CLEAR' or 'CANCEL' otherwise).

Route Color

- 'MENU'+ "Route" + 'ENTER' + "Select" + 'ENTER' + 'COLOR'

A window allows to choose the color, by using the cursor key. Press 'ENTER' or 'CONFIRM' ('CLEAR' or 'CANCEL' otherwise).

Displaying Route

- 'MENU'+ "Route" + 'ENTER' + "Select" + 'ENTER' + 'HIDE'/'SHOW'

The function allows to hide/show the segment that joins the Waypoints.

4.1.1.2 Deleting Route

- 'MENU'+ "Route" + 'ENTER' + "Delete" + 'ENTER'

A window is opened: press 'ENTER' or 'CONFIRM' ('CLEAR' or 'CANCEL' otherwise). The route remains on the screen shaded until the screen is redrawn.

4.1.1.3 Finding Info on Route: Route Data Report

- 'MENU'+ "Route" + 'ENTER' + "Report" + 'ENTER'

4.1.1.7 Safe Route Checking

This function checks the presence of particular cartographic objects (see the list below) on a range set by the user for all Route legs:

- Land Areas
- Shallow Water
- Intertidal Areas
- Rocks
- Wrecks
- Obstructions
- Shoreline Constructions
- Fishing Facility
- Dredged Areas
- Diffusers
- Mooring/Warping Facility
- Production Installation
- Pingos
- No Data Available

If any of these alarm conditions is detected, then the chart plotter highlights the list of dangerous objects and the correspondent dangerous Route leg. The Route leg is then drawn in a different color.

It is possible to make the Safe Route Check from menu following the procedure:

➤ 'MENU' + "Route" + 'ENTER' + "Route Check Report" + 'ENTER'

or:

➤ Place the cursor on the desired Route leg + 'CHECK'

The list of the dangerous objects found on the charts crossed by the Route is shown in the Route check report.

It is also possible to activate this function in automatic mode:

➤ 'MENU' + "Route" + 'ENTER' + "Automatic Route Check" + 'ENTER' + "On" + 'ENTER'

If Automatic Route Check is activated, the modified Route legs are checked everytime a Waypoint is added, inserted, edited or moved.

Before activating the function, you could change the function parameters, as the width and the depth of the detected area and the research accuracy.

To select the width of the detected area aside the Route:

➤ 'MENU' + "Route" + 'ENTER' + "Route Width" + 'ENTER' + insert the desired value + 'ENTER'

Note

Safe Route width value represents half the total width checked by the function.

To select the depth of the detected area aside the Route:

➤ 'MENU' + "Route" + 'ENTER' + "Route Depth" + 'ENTER' + insert the desired value + 'ENTER'

It also possible to select the accuracy for the Route check, among Minimum, Low, Medium, High and Maximum:

➤ 'MENU' + "Route" + 'ENTER' + "Route Check Accuracy" + 'ENTER'

4.1.2 WAYPOINTS

You may add Waypoints (see Par. 3.4.1), delete Waypoints from a route, move any Waypoint in the route to another location, insert a Waypoint between two existing ones, find any Waypoint at anytime.

4.1.2.1 Adding Waypoints

➤ 'ENTER' + "WAYPOINT" + 'ENTER'

The Waypoint appears on the cursor position. An info window is shown containing route number, date and time, Waypoint name, symbol and Latitude/Longitude, information on previous/next Waypoint. It is also shown the distance to cover (and/or covered, if there are several Waypoints) refer to next Waypoint. The sequence of moving the cursor and pressing 'ENTER' selecting "WAYPOINT" and pressing 'ENTER' again is continued to create the route.

Every time you place the cursor on a Waypoint, the following functions are available:

4.1.2.2 Moving Waypoint

➤ Adding Waypoint ('ENTER' + "WAYPOINT" + 'ENTER') or Place cursor on Waypoint

Press 'Move'. Use the cursor key to move the cursor: a dotted line, connecting the Waypoint to the new position, is shown.




Fig. 4.1.2.2 - Moving Waypoint function (I)

Press 'ENTER' or 'ACCEPT' ('CLEAR' or 'CANCEL' otherwise) and the Waypoint will be placed in the new position.




Fig. 4.1.2.2a - Moving Waypoint function (II)

The "old" Waypoint remains on the screen shaded until the screen is redrawn.

4.1.2.3 Deleting Waypoint

- **Adding Waypoint ('ENTER' + "WAYPOINT" + 'ENTER') or Place cursor on Waypoint**
Press 'DELETE'. A window is opened: press 'ENTER' or 'ACCEPT' ('CLEAR' or 'CANCEL' otherwise). The Waypoint is deleted and a new line between previous and next Waypoint is shown. The deleted Waypoint remains shaded until the screen is redrawn.

4.1.2.4 Editing Waypoint

- **Adding Waypoint ('ENTER' + "WAYPOINT" + 'ENTER') or Place cursor on Waypoint**
Press 'EDIT'. A window will be shown with Symbol, Name, Color and Latitude/Longitude of the Waypoint.




Fig. 4.1.2.4 - Edit Waypoint

Use the cursor key to select the field.

If Symbol field is selected, press 'ENTER': a window with 16 different symbols appears.




Fig. 4.1.2.4a - Waypoint symbols

Use the cursor key to select the symbol and press 'ENTER'.

If Name field is selected, press 'ENTER': use the cursor key to insert the character (8 characters max), then press 'ENTER'.

If Color field is selected, press 'ENTER': a window with 8 different colors appears. Use the cursor key to select the color and press 'ENTER'.

If Coordinates field is selected, press 'ENTER'. Use the cursor key to insert the value and press 'ENTER'.

Press 'ENTER' or 'ACCEPT'.

4.1.2.5 Goto

- **Adding Waypoint ('ENTER' + "WAYPOINT" + 'ENTER') or Place cursor on Waypoint**
Press 'GOTO', select "CURSOR" and press 'GOTO' again or 'ENTER': a circle surrounds the Waypoint symbol. A line is shown, connecting the Target with the ship's position. When the Target is placed, all navigation data are referred to this Target.
Press 'GOTO', select "LAST GOTO" and press 'GOTO' again or 'ENTER': a windows appears on the screen containing coordinates of the previous inserted Targets. Select the desired Target and press 'GOTO' again or 'ENTER': the Target is placed on the selected previous Target.
Otherwise press 'GOTO', select "ROUTE" and press 'GOTO' again or 'ENTER': the Target is placed on the first Waypoint of the route.
Press 'GOTO', select "MARK" and press 'GOTO' again or 'ENTER': the User Points List is shown on the screen. Select the desired User Point and press 'GOTO' again or 'ENTER': the Target is placed on the selected User Point.

4.1.2.6 Inserting Waypoint

Every time you place the cursor on the segment connecting two existing Waypoints of a route the following function is available.

- **Place cursor on route leg**




Fig. 4.1.2.6- Placing Waypoint between two existing ones (1)

Press 'INSERT'. The line between the two Waypoints is turned into a dotted line: move the cursor to the new position. When the cursor is stationary for one second or two, the line will "rubberband", drawing a dotted line between the last Waypoint and the cursor, and another dotted line between the cursor and the next Waypoint:




Fig. 4.1.2.6a - Placing Waypoint between two existing ones (11)

Once you have positioned the cursor at new location, press 'ENTER' or 'ACCEPT' ('CLEAR' or 'CANCEL' otherwise).




Fig. 4.1.2.6b - Placing Waypoint between two existing ones (III)

4.1.2.7 Finding Waypoint

- Press any soft key + 'MAP' + "FIND" + 'ENTER' + "USER POINTS" + 'ENTER'

A window is shown to find the Waypoint inserting label. Using the cursor to insert the name and press 'ACCEPT' ('CANCEL' otherwise). For example, if the inserted name is W005, the cursor will be placed on this Waypoint, and the window containing route information is shown.

4.1.2.8 Finding information on Waypoints: User Points List page

- 'MENU' + "List" + 'ENTER' + "List" + 'ENTER'

A full page window is shown with information on stored User Points. Move cursor up/down to select the desired User Point.

Note

In the list a circle surrounds the User Point symbol of the User Point on which the Target is set.




Fig. 4.1.2.8 - User Points List page

View Waypoint on the map

- 'MENU' + "List" + 'ENTER' + "List" + 'ENTER' + 'VIEW'

The chart plotter exits from the User Points List page and redraws the map. On the

screen the selected point appears centered, with the cursor placed on it. Press 'Exit' to return to the User Points List page.

Find Waypoint in the User Points List page

➤ 'MENU' + "List" + 'ENTER' + "List" + 'ENTER' + 'FIND'

A window is shown to insert the name by using the cursor key. Press 'ENTER' and the chart plotter will point the Waypoint out in the User Points List page.

Deleting Waypoint

➤ 'MENU' + "List" + 'ENTER' + "List" + 'ENTER' + 'DELETE'

To delete Waypoints:

- **Deleting Selected Waypoint:** Using the cursor key to select the Waypoint to delete and press 'SELECTED'. A warning message appears, press 'ENTER' or 'YES' ('CLEAR' or 'No' otherwise). If you want to delete the Waypoint on which Target is set, first delete the Target and then delete the Waypoint.
- **Deleting all stored User Points:** A warning message appears. Press 'ENTER' or 'YES' ('CLEAR' or 'No' otherwise) to delete all stored User Points. If a Target is set on an User Point, first delete the Target and then delete all User Points.

Selecting the Databoxes Setup and the Route Data Report pages

➤ 'MENU' + "List" + 'ENTER' + "List" + 'ENTER' + 'DATA'

To select wrap around the Databox Setup, the User Points List and the Route Data Report pages, see also Par. 3.1 and Par. 4.1.2.8.

4.1.2.9 Send Waypoints

To transmit all User Points onto the NMEA output port.

➤ 'MENU' + "List" + 'ENTER' + "Send" + 'ENTER'

4.1.2.10 Receive Waypoints

To save all User Points received from the NMEA input port.

➤ 'MENU' + "List" + 'ENTER' + "Receive" + 'ENTER'

4.2 MARKS

You may tag a location on the chart with a Mark symbol and number, which you can record for later use.

4.2.1 ADDING MARK

➤ 'ENTER' + "MARK" + 'ENTER'

The new Mark appears on your cursor position. An info window containing Mark symbol, name and Latitude/Longitude is shown.

Every time you place the cursor on a Mark the following functions are available:

4.2.2 MOVING MARK

➤ **Adding Mark ('ENTER' + "MARK" + 'ENTER') or Place cursor on Mark**

Press 'Move'. Use the cursor key to move the cursor: a dotted line, connecting the Mark to the new position, is shown. Press 'ENTER' or 'ACCEPT' ('CLEAR' or 'CANCEL' otherwise) and the Mark will be placed in the new position. The "old" Mark, remains on the screen shaded until the screen is redrawn.

4.2.3 DELETING MARK

- **Adding Mark ('ENTER' + "MARK" + 'ENTER') or Place cursor on Mark**

Press 'DELETE'. A window is opened: press 'ENTER' or 'ACCEPT' ('CLEAR' or 'CANCEL' otherwise). The deleted Mark remains shaded until the screen is redrawn.

4.2.4 EDIT MARK

- **Adding Mark ('ENTER' + "MARK" + 'ENTER') or Place cursor on Mark**

Press 'EDIT'. A window will be shown with Symbol, Name, Color and Latitude/Longitude of the Mark.

Use the cursor key to select the field.

If Symbol field is selected, press 'ENTER': a window with 16 different symbols appears.

Use the cursor key to select the symbol and press 'ENTER'.

If Name field is selected, press 'ENTER': use the cursor key to insert the character (8 characters max), then press 'ENTER'.

If Color field is selected, press 'ENTER': a window with 8 different colors appears. Use the cursor key to select the color and press 'ENTER'.

If Coordinates field is selected, press 'ENTER'. Use the cursor key to insert the value and press 'ENTER'.

Press 'ENTER' or 'ACCEPT'.

4.2.5 GOTO

- **Adding Mark ('ENTER' + "MARK" + 'ENTER') or Place cursor on Mark**

Press 'GOTO', select "CURSOR" and press 'GOTO' again or 'ENTER': a circle surrounds the Mark symbol. A line is shown, connecting the Target with the ship's position. When the Target is placed, all navigation data are referred to this Target.

Otherwise press 'GOTO', select "MARK" and press 'GOTO' again or 'ENTER': the User Points List is shown on the screen. Select the desired User Point (the Mark) and press 'GOTO' again or 'ENTER': the Target is placed on the selected User Point.

4.2.6 FINDING MARK

- **Press any soft key + 'MAP' + "FIND" + 'ENTER' + "USER POINTS" + 'ENTER'**

A window is shown to find the Mark inserting label. Use the cursor to insert the name and press 'ACCEPT' ('CANCEL' otherwise).

4.2.7 FINDING INFORMATION ON MARKS: USER POINTS LIST

- **'MENU' + "List" + 'ENTER' + "List" + 'ENTER'**

A full page window is shown with information on stored User Points (Mark e Waypoint). Moving cursor up/down select the desired User Point. See the previous Par. 4.1.2.8.

4.2.8 SEND MARKS

To transmit all User Points onto the NMEA output port.

- **'MENU' + "List" + 'ENTER' + "Send" + 'ENTER'**

4.2.9 RECEIVE MARKS

To save all User Points received from the NMEA input port.

- **'MENU' + "List" + 'ENTER' + "Receive" + 'ENTER'**

4.3 USING THE TRACK FUNCTIONS

The chart plotter can be set up for recording your track as you move and for plotting this track on the chart.

- 'MENU' + "Track" + 'ENTER'

4.3.1 ENABLING TRACK STORING

- 'MENU' + "Track" + 'ENTER' + "Activate" + 'ENTER'

To enable the track storing. It is not possible to use the track storing if you are not receiving a valid fix.

To disable the track storing (if the track is enabled):

- 'MENU' + "Track" + 'ENTER' + "Deactivate" + 'ENTER'

4.3.2 DELETING TRACK

- 'MENU' + "Track" + 'ENTER' + "Delete" + 'ENTER'

Delete the all track or only a part. 'WHOLE', 'BEGIN' and 'END' allow to identify the begin and end points of the segment to be delete.

4.3.3 CONFIG MENU

- 'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER'

4.3.3.1 Selecting Active Track

- 'MENU' + "TRACK" + 'ENTER' + "Config" + 'ENTER' + "Active Track" + 'ENTER'

Select the number of the active track. The default setting is 1.

4.3.3.2 Displaying Track

- 'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Display Mode" + 'ENTER'

Select to display (Visible) or not (Hidden) the track. The default setting is Visible.

4.3.3.3 Selecting Track Color

- 'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Color" + 'ENTER'

Select the desired color for the selected track. The default setting is Black.

4.3.3.4 Selecting Track memorizing type

- 'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Step Unit" + 'ENTER'

Select the Distance (the chart plotter can store a fix when the distance from its last stored position is greater than a defined distance) or Time (the chart plotter can store a fix after a defined time). The default setting is Time.

4.3.3.5 Selecting Time

- 'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Time Step" + 'ENTER'

When the tracking function is On and the type of track storing is Time, the chart plotter can store a fix after a defined time. It allows to choose among 1, 5, 10, 30 sec, 1, min. The default setting is 1 sec.

4.3.3.6 Selecting Distance

- 'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Distance Step" + 'ENTER'

When the tracking function is On and the type of track storing is Distance, you can store a fix when the distance from its last stored position is greater than a defined distance. It allows to choose in the range 0.01, 0.05, 0.1, 0.5, 1.0, 2.0, 5.0, 10.0 Nm (the distance unit is selected by the user, see Setup menu Cap. 7). The default setting is 0.01 Nm.

4.3.3.7 Deleting All Tracks

- 'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Delete All Tracks" + 'ENTER'
A warning window appears: press 'ENTER' or 'Yes' ('CLEAR' or 'No' otherwise).

4.3.4 DELETING TOTAL AND PARTIAL DISTANCE (LOG)

- 'MENU' + "Track" + 'ENTER' + "Log" + 'ENTER'
It is possible to reset the total and partial distance that the ship has travelled from the begin of the navigation. Press 'TOTAL' to reset the total Log or 'PARZ' to reset the partial Log.

4.3.5 TRACK TO ROUTE CONVERSION

- This function creates a Route from a pre-recorded Track. To select this menu:
➤ 'MENU' + "Track" + 'ENTER' + "Track To Route" + 'ENTER'
A new window appears on the screen with the following options.

4.3.5.1 Track to Route

- Executes the function that converts the given Track into a Route.
➤ 'MENU' + "Track" + 'ENTER' + "Track To Route" + 'ENTER' + "Track To Route" + 'ENTER'

4.3.5.2 Select Track Number

- Selects the Track input number
➤ 'MENU' + "Track" + 'ENTER' + "Track To Route" + 'ENTER' + "Select Track No." + 'ENTER'

4.3.5.3 Select Route Number

- Selects the Route output number
➤ 'MENU' + "Track" + 'ENTER' + "Track To Route" + 'ENTER' + "Select Route No." + 'ENTER'

4.4 MEMORY CARD MENU

The chart plotter allows to copy information to a MEDIA. You can also return the information to internal memory at a later time. This allows virtually unlimited storage.

- 'MENU' + "Memory Card" + 'ENTER'

4.4.1 SAVING FILE

- 'MENU' + "Memory Card" + 'ENTER' + 'SAVE'
Select the data type to save pressing respectively 'MARK', 'EVENT', 'ROUTE' or 'TRACK'. A window is opened with a default name shown: use the cursor key to insert the desired name and press 'ENTER' or 'ACCEPT' ('CLEAR' or 'CANCEL' otherwise).

Note

When naming a file, you may have trouble finding a name that uniquely identifies the file's contents. Dates, for example, are often used in filenames; however, they take up several characters, leaving you with little flexibility. The secret is to find a compromise, a point where you can combine a date with a word, creating a unique filename. The maximum length of the filename is 8 characters. The characters may be numbers (0, ..., 9), letters (A, ..., Z) and spaces (for example legal identifiers are "ABC", "AA", "12121212", "A B C", "1 A 1", and so on).

4.4.2 LOADING FILE

- 'MENU' + "Memory Card" + 'ENTER' + 'LOAD'

In the list choose the file name using the cursor key and press 'LOAD'.

4.4.3 DELETING FILE

- 'MENU' + "Memory Card" + 'ENTER' + 'DELETE'

A warning window is shown, press 'ENTER' or 'ACCEPT' ('CLEAR' or 'CANCEL' otherwise). This operation remove old or unnecessary files to clean up your MEDIA. Remember that this option permanently erases the file.

4.4.4 MEDIA

- 'MENU' + "Memory Card" + 'ENTER' + 'MEDIA'

4.4.4.1 Reading Directory on MEDIA

- 'MENU' + "Memory Card" + 'ENTER' + 'MEDIA' + 'READ'

Appears the list of the files present on the MEDIA inserted. During the reading, if it is going well, the message "READING DIR .. OK" appears in the frame in the right bottom corner.

4.4.4.2 Formatting MEDIA

- 'MENU' + "Memory Card" + 'ENTER' + 'MEDIA' + 'FORMAT'

A warning window is shown, press 'ENTER' or 'ACCEPT' ('CLEAR' or 'CANCEL' otherwise). The formatting of the MEDIA must be done before using a new MEDIA: this operation prepares the MEDIA to receive and store information.

4.4.4.3 Sorting Directory

- 'MENU' + "Memory Card" + 'ENTER' + 'MEDIA' + 'SORT BY'

Sort files in the directory. This is possible in the following modes:

- Press 'NAME' to sort using file name
- Press 'TIME' to sort using the file creation time
- Press 'TYPE' to sort using the file data

5. Special Functions

5.1 C-WEATHER

C-Weather is an innovative meteorological forecasting system with the ability to visualize the weather forecast, overlaying it on cartography. The weather data is held on Jeppesen Marine's weather server, which can be accessed via a C-COM modem connected to the chart plotter or by using the PC Planner (or the DPS - Dealer Programming System) saving the weather data on a MEDIA. The weather data are overlaid on a map page as layers. The weather format data available are:










Data Type	Display
WIND (Speed & Dir)	- 0 
WAVE Height & Dir	- 1 
TEMPERATURE	18°
HUMIDITY (%)	30
VISIBILITY	20
WEATHER TYPE: Sun	
WEATHER TYPE: Rain	
WEATHER TYPE: Fog	
WEATHER TYPE: Snow	
WEATHER TYPE: Clouds	
WEATHER TYPE: Partly Cloudy	
WEATHER TYPE: Thunderstorm	

Fig. 5.1 - Weather data package

5.1.1 C-WEATHER MENU

To select the menu:

- 'MENU' + "C-Weather" + 'ENTER'

The C-Weather menu is shown on the screen, the items are described in the following paragraphs.

5.1.1.1 Copy from Media

- 'MENU' + "C-Weather" + 'ENTER' + "Copy from Media" + 'ENTER'

Allows the C-Weather data loading from the MEDIA.

5.1.1.2 Download

- 'MENU' + "C-Weather" + 'ENTER' + "Download" + 'ENTER'

Allows to connect the software to the Jeppesen Marine weather server and to download Jeppesen Marine weather data directly via C-COM. It activates the following sub-menu:

Select Country to Call

Allows the selection of the country to call. The whole telephone number set is automatically updated after every download.

Telephone number

Shows the telephone number to get through to the server.


SIM PIN

Allows inserting of the PIN relating of the SIM.

Download Area

Allows the weather download: a squared grey area, where the weather data will be downloaded, is centered on cursor position.

Area of coverage of downloaded data is located by default with its center on the cursor position



Cursor is locked to the gray area. Moving the cursor also moves the gray area allowing locating it over the area where the user wants to download the Meteo forecast.

Soft Keys to manage the download procedure

Indicates the LAT/LON position of the cursor

Fig. 5.1.1.2 - Area of coverage

Press 'LOAD' to activate the C-Weather Download: the whole data package (see the previous "Weather data package" table) are downloaded. At the end of the operation press 'EXIT' to close the window.

5.1.1.3 Weather Forecast

➤ 'MENU' + "C-Weather" + 'ENTER' + "Forecast" + 'ENTER'

Allows selecting the Layer of specific weather data to be displayed on the screen and to change date and time of the forecast preview.

The following functions are available:

- **Panning:** Default usage of the cursor key is the normal panning function.
- **Zoom In/Out:** allowed as usual by using 'ZOOM IN'/'ZOOM OUT'.
- **Set type of data:** 'TYPE' to choose data among: Wind, Wave Data, Wheater, Humidity, Temperature, Visibility.
- **Set Date and Time:** 'DATE/TIME' to choose date and time among the pre-set one by the server.
- **Exit:** 'EXIT' to close the weather prediction page.

5.1.1.4 Real Time View

➤ 'MENU' + "C-Weather" + 'ENTER' + "Real Time View" + 'ENTER'

The following selections are available:

- **Real Time View On:** The data is shown (the area of the download) at the current date and time (received from the GPS)
- **Real Time View Off:** The weather data is not displayed.
The layer displayed is the one selected into the previous menu item.

5.1.1.5 Type of Data

➤ 'MENU' + "C-Weather" + 'ENTER' + "Type of Data" + 'ENTER'

Allows selecting the type of data among: Wind, Wave Data, Wheater, Humidity, Temperature, Visibility. See the previous Fig. 5.1.

5.2 AIS MENU

AIS is an Automatic Identification System. It has been introduced to improve the safety of navigation by assisting in the efficient operation of ship-to ship, ship reporting and VTS applications. The system should enable operators to obtain information from the ship automatically, requiring a minimum of involvement of ship's personnel, and should have a high level of availability. AIS transponders installed on IMO vessels use VHF frequencies to:

- Transmit details of their own vessel
- Receive details from other vessels or navigation aids within VHF range.

Information being transmitted from vessels over 300 tons that, due to recent worldwide legislation, are required to fit Class "A" AIS transponders.

Connecting to the chart plotter an AIS receiver (please contact your local dealer), vessels with AIS transponder within VHF range are displayed on screen giving the skipper or navigator a visual interpretation of the data of nearby vessels. This improves safety, and specifically for collision avoidance reasons.

5.2.1 AIS SYSTEM DEFINITIONS

Target	= It is a vessel equipped with <u>AIS</u> . Information about the targets is being received by <u>AIS</u> Receiver and displayed on the screen.
CPA	= Closest Point of Approach is the closest distance that will be achieved between your vessel and the tracked target, based on your vessel's speed and direction and the target's speed and direction.
CPA Limit	= This is the distance from your vessel that a target may reach before a target is deemed a threat.
CPA Alarm	= Occurs if CPA is less or equal to CPA Limit. This test is done for active targets only.
TCPA	= Time to closest Point of Approach is the time remaining until the CPA will occur.
TCPA Limit	= This is the time remaining before the CPA is reached.
TCPA Alarm	= Occurs if TCPA is less or equal to TCPA Limit. This test is done for active targets only and if CPA value is less or equal to CPA Limit.
Radio Call Sign	= International call sign assigned to vessel, often used on voice radio.
Name	= Name of ship, 20 characters.
MMSI	= Maritime Mobile Service Identity.
MMSI number	= A unique 9 digit number that is assigned to a DSC radio station. It primarily registers the boat information in the U.S. Coast Guard's national distress database for use in emergency situations.
Active Target	= Target located within the Activation Range. Active target is

represented by oriented triangle with COG and Heading vectors. Rate of turn may also be displayed.

Dangerous Target = Target detected by CPA or TCPA Alarm. Dangerous target is Active Target by definition. For better visibility Dangerous Target symbol is flashing.

Sleeping Target = Target located outside the Activation Range. Sleeping target is represented by a small oriented triangle.

Lost Target = When the AIS info is not received from that vessel for 3.5 minutes. The presentation will be a flashing black triangle with a cross through.

Activation Range = Range around your boat where targets become active. AIS target become active within this range. Activation Range should be greater than CPA Limit by definition.

Note

A target is removed from the screen if data is not received for 10 minutes. The maximum number of tracked targets is 200. Depending on the scale the presentation of the targets change to remove clutter on the screen. This information is updated every 3 seconds to 6 minutes depending on speed and rate of turn, enabling the track of the vessels in range to be plotted.

TARGET STATUS	DESCRIPTION	SYMBOL
ACTIVE TARGET	Target located within the Activation Range.	
DANGEROUS TARGET	Target detected by CPA or TCPA Alarm. Dangerous Target is Active Target by definition.	
SLEEPING TARGET	Target located outside the Activation Range.	
LOST TARGET	Ais info is not received from that vessel for 3.5 minutes.	

Fig. 5.2.1 - AIS Symbols

5.2.2 AIS MENU

To configure the chart plotter to receive AIS data, follow the procedure:

➤ 'MENU' + "Devices" + 'ENTER' + "AIS" + 'ENTER'

The AIS menu is shown on the screen, the items are described in the following paragraphs.

5.2.2.1 Display

➤ 'MENU' + "Devices" + 'ENTER' + "AIS" + 'ENTER' + "Display" + 'ENTER'

Turns Off the display of AIS targets overlay on the cartography or defines the range from the fix within which the AIS Target becomes active. The values allowed are from 0.1 to 20 Nm. The default setting is 5 Nm.

5.2.2.2 CPA Alarm

➤ 'MENU' + "Devices" + 'ENTER' + "AIS" + 'ENTER' + "CPA Alarm" + 'ENTER'

Turns Off the alarm or defines the CPA Limit (the values allowed are from 0.1 to 10 Nm). The default setting is Off.

5.2.2.3 TCPA Alarm

➤ 'MENU' + "Devices" + 'ENTER' + "AIS" + 'ENTER' + "TCPA Alarm" + 'ENTER'

Turns Off the alarm or defines the TCPA Limit (The values allowed are from 1 to 30 min). The default setting is Off.

5.2.3 TO SET THE PLOTTER FOR RECEIVING AIS

Make sure that the AIS receiver is properly connected to the chart plotter. The chart plotter reads the AIS NMEA message VMD, type 1, 2, 3 and 5.

Select the used serial port and transmission speed by following the procedure:

► 'MENU' + "Input/Output" + 'ENTER' + "Port n Input" + 'ENTER' + "m" + 'ENTER'
Where:

m = NMEA-0183 4800-N81-N or AIS 38400 according to the transmission speed of your AIS receiver

n = 1, 2, 3 for O.CHART5/O.CHART 5F

1, 2, 3, 4, 5 for O.CHART7/O.CHART 7F

5.2.4 QUICK INFO ON AIS TARGET

By placing the cursor over a AIS target icon, this information is displayed:

- **Vessel Name**
- **MMSI number**
- **Radio Call Sign**
- **SOG**
- **COG**
- **CPA and TCPA values**

Note


The selected AIS target icon is surrounded by a square frame when user places the cursor over the icon.

5.3 C-LINK

C-Link system is a feature which allows to sharing the same Navigation Data (Route Name, Destination ID & Position, Next Waypoint ID & Position, Total Route length, Fuel Consumption Rate, ETA, TTG etc.) between two chart plotter units linked via serial I/O port.

5.3.1 C-LINK SERIAL CONNECTION

The two chart plotters should be connected via serial ports. Any of the available ports can be used, the software will recognize automatically the serial ports used. A typical connection is as follows:



5.3.2 C-LINK NAVIGATION DATA TRANSFER

The chart plotters can be set to operate in two modes:

- Master mode (Primary chart plotter)
- Slave mode (Secondary chart plotter)

When the navigation is activated on the Master chart plotter, the C-Link navigation data will be continuously sent to the Slave until the navigation is active.

If the Master is navigating to a Single Destination, the Slave will show the Destination position and activate the navigation to it.

If the Master is navigating to a route, the Slave will show the route leg

composed by the Destination and the Waypoint after the Destination (Next Waypoint) and activate the navigation to it.

Any variation to the current C-Link Navigation Data will be transferred from the Master to the Slave.

The Slave will be provided with a dedicated page to show the C-Link Navigation Data received from the Master, selected from the Route menu:

➤ **'MENU' + "Route" + 'ENTER' + "Report" + 'ENTER'**

A data page (different from the Route Data Report page) appears on the screen, that shows the C-Link Navigation Data sent from the Master.

5.3.3 OPERATIONS

It is important remark, once more, that this function does not transfer the whole route but just the information relative to the navigation. Such information will be removed from the Slave chart plotter as soon as the navigation is terminated. C-Link Navigation Data is exchanged by using two NMEA-0183 C-MAP proprietary sentences: \$PCMPN,1 and \$PCMPN,2.

When the navigation is activated on the Master, it starts outputting the C-Link Navigation Data. If the Slave is connected, all C-Link Navigation Data received are stored in its memory and the navigation is started.

The information sent by the Master consists of the following values:

- Navigation mode (To Single Destination/to a Route)
- Route Name*
- Destination ID
- Destination Position
- Next Waypoint ID*
- Range from Destination to next Waypoint*
- Bearing from Destination to next Waypoint*
- Route Length*
- Distance from Destination to Last Route Waypoint*
- Remaining Route Legs*
- Planned Cruising Speed
- Average Fuel Consumption
- Initial Fuel Load

Values identified by * are sent only for Route Following navigation. The Destination Icon, Navigation leg (Fix Position to Destination), the Next Waypoint Icon and all other relevant C-Link Navigation Data will be shown on the Slave chart plotter. Any variation of the C-Link Navigation Data on the Master will be communicated to the Slave so to keep data aligned on both devices.

5.3.3.1 Master Chart Plotter

Operating mode

To select the Master mode (Primary Station) follow the procedure:

➤ **'MENU' + "Input/Output" + 'ENTER' + "C-Link" + 'ENTER' + "Primary Station" + 'ENTER'**

Master mode is the default factory setting. All regular chart plotters functions are allowed. As soon as the Destination is placed, the Master chart plotter will start transmitting all C-Link Navigation Data.

In Master mode the C-Link Navigation Data received from the NMEA port is ignored. So, if the two chart plotters are both operating in Master mode, the C-Link Navigation Data sent by the other chart plotter never processed. Under such condition if the navigation is activated on one of the two chart plotters, a warning message will be shown to notify that the C-Link Navigation Data will be ignored by the other chart plotter.

5.3.3.2 Slave Chart Plotter

Operating mode

To select the Slave mode (Secondary Station) follow the procedure:

- 'MENU' + "Input/Output" + 'ENTER' + "C-Link" + 'ENTER' + "Secondary Station" + 'ENTER'

When Slave mode is set, the chart plotter cannot manipulate the C-Link Navigation Data anymore.

It is necessary to disable the Internal GPS on the Slave chart plotter before start to work with the C-Link system:

- 'MENU' + "Input/Output" + 'ENTER' + "GPS Configuration" + 'ENTER' + "GPS Antenna" + 'ENTER' + "No" + 'ENTER'

Stop current navigation

If the navigation was already active, it will be disabled as soon as Slave mode is set. An appropriate warning message will be shown to notify that the Navigation is already active and to confirm whether Slave mode can be set.

Inhibit Navigation operation

As soon as Slave mode is set, the Destination cannot be placed anymore either the C-Link Navigation Data is received from the Master or not. Also, when the C-Link Navigation Data is received from the Master, it will not be allowed to deactivate the Navigation.

Inhibit Route following

While navigating to the route received from the Master and the Destination is reached the Destination will be moved to the next Waypoint on the route.

MOB handling

If the Navigation to the external Destination is active and the MOB is set:

- 'ENTER' + "MOB" + 'ENTER'

on the Slave Chart Plotter, the MOB is placed but the navigation to the MOB is not activated.

Note

While navigating to the external Destination the operating mode is switched to Master, the navigation to the external Destination will be terminated.

5.3.3.3 C-Link navigation data: Acquisition and Display

As soon as the C-Link Navigation Data is received, the Slave parses the information received and executes the relative actions depending on its current working status.

Note

When the Navigation to the external Destination is activated, the Slave chart plotter will show all relevant C-link Navigation Data exactly like when the destination is not the external one: (Destination Name, DST and BRG to Destination, calculate XTE, calculate TTG etc). These values will be displayed all places where required and they will be used to format NMEA-0183 output data.




DESCRIPTION	SYMBOL
External Destination - RED Icon	
Next Waypoint - GREEN Icon	
Navigation Leg - RED Line	

Fig. 5.3.3.3 - Graphical Displaying

5.3.3.4 Route Data Report

On the Slave chart plotter, when the navigation to the External route is received, it is possible to display the information related to the External route by entering the Route Data Report:

➤ 'MENU' + "Route" + 'ENTER' + "Report" + 'ENTER'

EXTERNAL NAVIGATION: 25/01/10 00				
Cruising Speed:	10.0Kts			
Total Route length:	>999Nm			
Waypoints in Route:	6			
Remaining Waypoints:	4			
Fuel Consumption Rate:	10.0			
Total Fuel Consumption:	>999			
Initial Fuel Load:	10.0			
Remaining Fuel:	2.6			
	DST Nm	TTG HH.MM	ETA HH.MM	Cons lit
To Dest	20.9	2:05	03:03	20.9
To Next Wpt	48.5	4:51	05:49	48.5
To Last Wpt	>999	>99h	10:01	>999

Fig. 5.3.3.4 - Route Report on the Slave chart plotter

- External Route : Name of the external route (da PCMPN,0)
- Cruising Speed : Planned cruising speed (da PCMPN,1)
- Total Route Length : Length from First to Last Wpt (da PCMPN,1)
- Waypoints in Route : No. of Wpts in the Route (da PCMPN,1)
- Remaining Waypoints : No. of Wpts from Dest to Last Wpt (da PCMPN,1)
- Fuel Consumption Rate : Planned Fuel Consumption Rate (da PCMPN,1)
- Total Fuel Consumption : Calculated fuel consumption to navigate the whole route
- Initial Fuel Load : Volume of fuel available before the navigation was started (*Liters*)
- Remaining Fuel : Volume of remaining fuel
- To Dest : DST - Distance from ship to Destination (calculated)
: TTG - Estimated Time to travel the Distance to Destination, calculated using Cruising Speed
: ETA - Estimate Time of Arrival to the Destination point calculated as Current Time + TTG To Destination
: CONS- Fuel consumption (calculated)
- To Next Wpt : DST - Distance to travel from ship to the Wpt after the Destination (calculated: Distance to Dest + Next Route Leg length)
: TTG - Estimated Time to travel the Distance to Next Waypoint, calculated using Cruising Speed
: ETA - Estimate Time of Arrival to the Waypoint after the Destination calculated as Current Time + TTG To Next Waypoint
: CONS- Fuel consumption (calculated)
- To Last Wpt : DST - Distance to travel from ship to the end of the route
: TTG - Estimated Time to travel the Distance to Last Waypoint calculated using Cruising Speed
: ETA - Estimate Time of Arrival to the end of the route calculated as Current Time + TTG To Last Wpt
: CONS- Fuel consumption (calculated)

5.3.3.5 Quick Info

In the following picture an example of Quick Info on the Destination into an external route is shown:

EXTERNAL WAYPOINT			
04/03/10 12: WPT001	4/5		
	DST	TTG	Cons
	Nm	HH:MM	lit
Dest	4.2	0:25	2.5
Last	>999	>99 h	>999
Route Length:	>999 Nm		

Fig. 5.3.3.5 - Quick Info on Destination

Also in the following picture an example of Quick Info on single Destination is shown:

EXTERNAL DESTINATION		
MRK006		
DST	1.4	Nm

Fig. 5.3.3.5a - Quick Info on Single Destination

5.4 DSC

The DSC (*Digital Selective Calling*) is a method of establishing a VHF radio call; it is used to announce urgent maritime safety information broadcasts. This system allows mariners to instantly send Distress Call or/and Position Request to the other vessels equipped with a DSC transceiver within range of the transmission. The Distress Call, that allows to receive a position of the vessel in distress, and the Position Request, a great feature for anyone wanting to know the location of another vessel - for example you buddy that is catching fish, or finding the location of a person you are cruising with, are performed by an external device, the DSC VHF radio. The chart plotter interfaced with a DSC VHF radio prompts the user to see the GPS position of the vessel in distress and also allows for easy navigation to the vessel. The Distress Call and the Position Request icons that are displaying on the screen, are shown in the following table:



DESCRIPTION	SYMBOL
Position Request icon	
Distress Call icon	

Fig. 5.4 - Distress Call and Position Request icons

Note

The label can be the MMSI or the corresponding vessel's name. If in the DSC Directory the MMSI has been associated to its relative vessel name, the vessel's name is shown in the label instead of the MMSI.

5.4.1 DISTRESS CALL AND POSITION REQUEST

In During a distress situation, a vessel that is equipped with a DSC VHF radio and connected to a GPS, has the capability to transmit a DSC Distress Call with GPS Position.

When the VHF radio receives a DSC Distress Call, the position information of the vessel in distress is transferred to the chart plotter. The chart plotter logs the Distress Call into the DSC Log and also marks the position of the vessel in distress on the Chart page. A pop-up screen advises the user that a Distress Call has been received. Within the pop-up screen it asks the user if he would like to view the call on the Chart page or exit the pop-up screen. By selecting the item "VIEW ON CHART" and press 'ENTER' two options are shown:

Go To Vessel : Activates the navigation to the Distress Call or Position Request icon. The chart plotter changes the map scale to allow showing the Distress Call (or Position Request) icon and the vessel's icon simultaneously on the screen. The chart plotter then verifies if there are obstructions (land or low water) between the two positions. If obstructions are found the chart plotter shows a pop-up screen saying that the navigation to the Distress Call cannot be set automatically and the user must define a route to avoid the obstacles.

Stay on View : Exits the pop-up screen and remains on the selected map screen.

5.4.2 DSC MENU

To select the DSC menu:

- 'MENU' + "Devices" + 'ENTER' + "DSC" + 'ENTER'

The DSC menu is shown on the screen, the items are described in the following paragraphs.

5.4.2.1 Log

- 'MENU' + "Devices" + 'ENTER' + "DSC" + 'ENTER' + "DSC Log" + 'ENTER'

Selecting Log shows the Distress Call Log page or Position Request Log page (it depends which of the two was selected):

Date Time	Lat Long	Name MMSI	Shown
03-03-01 08:31 PM	33°30.505 N 118°18.529 W	LILLY 0080457645	NO
03-04-01 00:11 PM	33°34.167 N 118°21.864 W	MARCO 0023244524	SI
03-04-01 08:31 PM	33°30.431 N 118°23.121 W	IAN 0286477743	NO

ENTER to change mode: Position Request

Locate Clr-One Clr-All Hide

Fig. 5.4.2.1 - Example of DSC Log page

Pressing 'GOTO' activates the navigation on the selected DSC position. Other available operations are:

Locate

Centers the map on the selected DSC position.

Clr-One

Deletes selected DSC position.

Clr-All

Deletes all entries.

Hide/Show

Allows hiding/showing the selected DSC position on the chart display.

Distress Call/Position Request

Shows Position Request/Distress Call page. When Position Request page is active this message changes to Distress Call.

5.4.2.2 Directory

► 'MENU' + "Devices" + 'ENTER' + "DSC" + 'ENTER' + "DSC Directory" + 'ENTER'
Selects the DSC Directory page. From this page the user can assign the Vessel Name, Contact Name and Phone number to any MMSI (*Maritime Mobile Service Identity*) so that, when a DSC Distress Call or Position Request is received, the name of the vessel is displayed in place of the MMSI number - a unique number that is assigned to a DSC radio station for use in emergency situations:

Vessel Name		Contact	
MMSI		Phone	
TIZIANA	0000000055	TIZIANA	+113429439
VITTORIA	0000001265	EMMA	+21943605
ACQUARIO	7300400407	FILI	0013454 6578

Buttons: Edit, Add, Delete, Del All

Fig. 5.4.2.2 - Example of DSC Directory page

Edit

Edit the fields of any existing entry in the Directory: Vessel Name, MMSI number, contact and phone number.

Add

Add a new entry to the Directory.

Delete

Delete the selected entry.

Delete All

Deletes all entries in the page.

5.4.3 QUICK INFO ON DSC ICONS

Placing the cursor on the Distress Call or Position Request icon, the following information is displayed:

- **Vessel Name/MMSI Number**
- **Position**
- **Date and Time**
- **Distance and Bearing from current vessel position**

Pressing 'ENTER' it is possible, by selecting "DELETE" deletes the DSC icon from the DSC Log page, otherwise by selecting "DSC LOG" the DSC Log page is shown.

5.5 FISH FINDER MENU

The chart plotter combined with the sonar performance of the Fish Finder is one of the most advanced marine navigation system available.

To select the Fish Finder menu, first select one of the page related to the Fish Finder:

ONLY FOR O.CHART5/5F

➤ **'PAGE' + select the Fish Finder page you want**

ONLY FOR O.CHART7/7F

➤ **'MENU' + "Page" + 'ENTER' + select the Fish Finder page you want**

Then to select the Fish Finder menu:

➤ **'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER'**

6. Fish Finder FOR O.CHART5F/O.CHART7F

The Fish Finder consists of a high power transmitter, sensitive receiver and a transducer. The Fish Finder sends an electrical pulse to the transducer which contains an element that converts the pulse into acoustic (sound) wave which is sent through the water. As this wave travels from the transducer to the bottom, it may strike fish, structures, thermal clines (temperature changes in the water). When the wave strikes an object(s) a certain amount of the wave is reflected back to the transducer depending on the composition and shape of the object. When the reflected wave is returned to the transducer it is converted into an voltage and is amplified by the receiver, processed and sent to the display. The speed of sound in water is roughly 4800 ft./sec, so the time lapse between the transmitted signal and the received echo can be measured and the distance to the object determined.




Fig. 6 - Fish Finder working principle

6.1 SETTING THE INTERNAL FISH FINDER ON

The Fish Finder driver is embedded on the chart plotter: it is connected directly to the dedicated serial Port2. To switch the internal Fish Finder transmission On follow the procedure:

► 'MENU' + "Input/Output" + 'ENTER' + "Fish Finder" + 'ENTER' + "On" + 'ENTER'

Note

It is not possible to connect any external Fish Finder unit to the chart plotter.

6.2 UNDERSTANDING THE FISH FINDER PAGE

The display on chart plotters shows a history of time of the echoes received by the transducer. The chart plotters have a menu that allows adjustments to receiver sensitivity, depth range and scrolling speed of the Fish Finder display.

- ① Warning message
- ② Echogram window
- ③ Color Bar
- ④ Digital Depth
- ⑤ Water temperature
- ⑥ Alarm Bar
- ⑦ Depth ruler
- ⑧ Variable Depth Marker (VDM)
- ⑨ Zoom Bar
- ⑩ A-Scope
- ⑪ Operating Frequency




Fig. 6.2 - The Fish Finder page

The following is a short description of terms listed in the previous Fig. 6.2:

- ① **Warning Message**
Flashing label "Simulation" when the echo sounder is in Simulation mode.
- ② **Echogram window**
Graphic presentation of sonar soundings recorded as a continuous profile scrolling across the screen from right to left. Such recordings represent the image of the water beneath your boat, items appear as they pass under your transducer; the items on the right side of the screen are closer to you than those on the left. The correct interpretation of the Echogram allows retrieving useful information about what is under the boat. See the following Par. 6.2.1 for more information.
- ③ **Color Bar**
Colored scale located on the left side of the screen that shows the colors used in the Echogram to represent the echoes strength. The color on the top of the bar represents the maximum sonar strength, while the color on the bottom of the bar represents the minimum sonar strength.
- ④ **Digital Depth**
Readout of the current bottom depth.
- ⑤ **Water Temperature**
Readout of the current water temperature returned by the TEMP 1 sensor included into specific transducers.
- ⑥ **Alarm Bar**
Bars showing the shallow water and deep water alarm values. The alarm is triggered when depth is outside the range.

- ⑦ **Depth ruler**
Vertical graduated bar. It is a scale which reflects the depth of the area being displayed.
- ⑧ **Variable Depth Marker (VDM)**
Horizontal line on to the Echogram window with a depth label. The up/down cursor keys can move it up and down. The label displays the depth of the cursor position. It can be moved to any location pinpointing the depth of a target.
- ⑨ **Zoom Bar**
Bar showing the portion of the Echogram currently represented in the zoomed window (on the left part of the screen). It is turned on selecting Zoom Full display page.
- ⑩ **A-Scope**
A real time representation of fish and bottom features passing through the beam of the transducer. It is drawn as horizontal lines whose length and hue is proportional to the sonar strength returned. When the default palette is selected, the strongest sonar returns will be shown as the color displayed of the top of Color Bar while the weakest as the bottom color.
- ⑪ **Operating Frequency**
Readout of the selected operating frequency.

6.2.1 UNDERSTANDING THE ECHOGRAM DISPLAY

The main elements that can be easily distinguished into an Echogram are:

- ① Fishes
- ② Thermoclines
- ③ White Line
- ④ Surface Clutter
- ⑤ Structures
- ⑥ Bottom Echo Profile




Fig. 6.2.1 - The Fish Finder Echogram

- ① **Fishes**
Fishes are represented as arcs because of the cone angle of the transducer. In fact as the boat passes over the fish the leading edge of the cone strikes the fish, causing a display pixel to be turned on. As the boat passes over the fish, the distance to the fish decreases turning each pixel on at a shallower depth on the display. When the boat is directly over the fish, the first half of the arch is formed and since the fish is closer to the boat, the signal is stronger and the arch is thicker. As the boat moves away from the fish, the distance increases and the pixels appear at progressively deeper depths forming the remaining half of the arch.

② Thermoclines

Are the zones where two layers of different water temperatures meet. The greater the temperature differential, the thicker the thermocline is shown on the screen. Thermoclines are represented as horizontal stripes of noise. They are very important for fishing since often many species of game fish like to suspend in, just above, or just below the thermoclines.

③ White Line

The White Line shows the difference between hard, soft bottoms and even distinguishes between fishes and structures located near the bottom. In this way it is easier to tell the difference between a hard and soft bottom and even to distinguish fishes and structures located nearby the bottom. For example, a soft, muddy or weedy bottom returns a weaker echo that is shown with a narrow white line while a hard bottom returns a strong echo that causes a wide white bottom line.

④ Surface Clutter

Appears like noise at the top of the screen extending many feet below the surface. It's caused by many things, including air bubbles, bait fish, plankton and algae.

⑤ Structures

Generally, the term "structure" is used to identify objects like wrecks and weeds rising from the bottom.

⑥ Bottom Echo Profile

Bottom profile recorded by the Fish Finder. When the echo sounder is set in auto-range mode it is automatically kept in the lower half of the screen.

Other Elements

Large anchoring cables are returned by the echo sounder as very long and narrow arcs on the screen.

6.3 DISPLAYING THE FISH FINDER PAGE

This section will take you through the frequently used operations and assist you to customize the look of the chart plotter using the Fish Finder.

6.3.1 HOW TO SELECT THE FISH FINDER PAGE

The Page Selection menu allows you to change the Fish Finder page displayed.

To access this menu:

ONLY FOR O.CHART5F

➤ 'PAGE'

ONLY FOR O.CHART7F

➤ 'MENU' + "Page" + 'ENTER'

The Page selection menu (with current page selected) is shown on the screen (see also Fig. 3.1). Moving cursor selects the desired Fish Finder page, and then press 'ENTER' to select.

6.3.1.1 Fish Finder Full page

To display the Fish Finder Full page Echogram, follow this procedure:

ONLY FOR O.CHART5F

➤ 'PAGE' + "Fish Finder" + 'ENTER'

ONLY FOR O.CHART7F

➤ 'MENU' + "Page" + 'ENTER' + "Fish Finder" + 'ENTER'

Note

To select the 200kHz or 50 kHz Fish Finder page, press 'ENTER' and then select the desired Frequency among 50kHz or 200kHz (see Par. 6.5.9).



Fig. 6.3.1.1 - Example of 200kHz (left) or 50 kHz (right) Fish Finder Full display

To activate the Fish Finder Setup menu (see Par. 6.5) press:

➤ 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER'

The Cursor key

Moving the Cursor key up/down adjusts the Variable Depth Marker (VDM) up or down on the screen.

The ENTER key

Pressing 'ENTER' activates the Sensitivity menu (see Par. 6.5.9) that allows tuning Frequency, Gain, the Surface Noise Filter and the STC.

Sounder	
Frequency	200 kHz
Gain	0 %
STC	Off
STC Length	0 Mt
STC Strength	0 %
Surf Noise Filter	Off

Fig. 6.3.3.1a - Sensitivity sub-menu

Pressing 'CLEAR' turns off the Sensitivity menu.

The CLEAR key

By pressing 'CLEAR' the Variable Depth Marker (VDM) is hidden.

The ZOOM IN and ZOOM OUT keys

From this page pressing 'ZOOM IN' once changes to Zoom 2X, pressing 'ZOOM IN' twice changes to Zoom 4X, while pressing 'ZOOM OUT' reverts to Zoom 2X and no zoom.

6.3.1.2 Fish Finder Full + Databoxes page

It is possible to have the same picture of the previous Par. 6.3.1.1 with the Data Boxes on the top of the screen:

ONLY FOR O.CHART5F

➤ 'PAGE' + "Fish + Databoxes" + 'ENTER'

ONLY FOR O.CHART7F

➤ 'MENU' + "Page" + 'ENTER' + "Fish + Databoxes" + 'ENTER'




Fig. 6.3.1.2 - Example of Fish Finder with Databoxes page

6.3.1.3 Dual Fish Finder page

To display the Dual Fish Finder echogram, follow this procedure:

ONLY FOR O.CHART5F

➤ 'PAGE' + "Dual Fish Finder" + 'ENTER'

ONLY FOR O.CHART7F

➤ 'MENU' + "Page" + 'ENTER' + "Dual Fish Finder" + 'ENTER'




Fig. 6.3.1.3 - Example of Dual Fish Finder page

Note

The gray box surrounds the area of the screen that it is active.

The Cursor key

Moving the Cursor key to the right or the left to change the gray box from the left window to the right window. Moving the Cursor key up or down adjusts the Variable Depth Marker (VDM) up or down on the active screen window. Press 'CLEAR' to hide the VDM.

The ZOOM IN and ZOOM OUT keys

From this page pressing 'ZOOM IN' once changes to Zoom 2X, pressing 'ZOOM IN' twice changes to Zoom 4X, while pressing 'ZOOM OUT' reverts to Zoom 2X and no zoom.

6.3.1.4 Fish Finder and Chart page

To display the Chart page on the half of the screen and the Fish Finder Echogram on the other half of the screen, follow this procedure:

ONLY FOR O.CHART5F

➤ 'PAGE' + "Chart + Fish Finder" + 'ENTER'

ONLY FOR O.CHART7F

➤ 'MENU' + "Page" + 'ENTER' + "Chart + Fish Finder" + 'ENTER'




Fig. 6.3.1.4 - Example of Fish Finder 200kHz (left) and 50kHz (right) and Chart page

The Focus Soft Key (to change the active window)

When in Chart and Fish Finder mode pressing any Soft Keys and then 'Focus' changes the focus (the active window), from the Chart window to the Fish Finder window and vice versa.

Note

When the focus is on the Chart, all keys behave as in standard chart mode.

6.4 ZOOM MODES

6.4.1 THE BOTTOM LOCK ZOOM

The Bottom Lock Zoom mode is activated when the Fish Finder is in Auto Range or Bottom Lock mode (see Par. 6.5.3) and the Variable Depth Marker (VDM) is not displayed on the screen.

In Bottom Lock Zoom mode the Fish Finder Echogram is automatically moved up/down as to keep the Bottom Line always visible in the lower half of the screen.

Note

Moving the Cursor key up/down displays the Variable Depth Marker (VDM) switching the Fish Finder in Marker Zoom mode.

6.4.2 THE MARKER ZOOM

The Marker Zoom mode is activated either when the Fish Finder is in Manual Range mode (see Par. 6.5.3) or the Depth Cursor is displayed on the screen. In Marker Zoom mode the Fish Finder Echogram position is controlled by moving the Variable Depth Marker (VDM) and pressing and holding '**ENTER**' for 1 second on the selected position. Moving the Variable Depth Marker (VDM) over the top or below the bottom of the screen, automatically moves up/down the current zoomed Echogram view and re-position the Variable Depth Marker (VDM) at the center of the screen.

Note

*Pressing '**CLEAR**' hides the Depth Cursor and if the Fish Finder is in Auto Range or Bottom Lock mode switches into Bottom Lock Zoom mode.*

6.5 FISH FINDER SETUP MENU

The Fish Finder Setup menu provides access to additional functions, setup and layout/data field options. From the Fish Finder page, access this menu by pressing:

- '**MENU**' + "**Devices**" + '**ENTER**' + "**Fish Finder Setup**" + '**ENTER**'

Preset Mode	Fish
Gain Mode	Manual
Range Mode	Manual
Depth	▶
Shift	▶
Bottom Range	▶
Frequency	Dual
Interf Reject	Off
Sensitivity Menu	▶
Display Setup	▶
Transducer Setup	▶
Alarms	▶
Save & Load	▶

Fig. 6.5 - Fish Finder Setup menu

6.5.1 PRESET MODE

Preset modes are pre-defined settings of the Fish Finder operating parameters. You can use them to quickly set the Fish Finder in the most commonly used operating modes. These are Cruise (sets the Fish Finder in full auto mode with the sensitivity settings optimized for displaying at best the bottom) and Fish (sets the Fish Finder in full auto mode with the sensitivity setting optimized for target searching). See the following table.

- '**MENU**' + "**Devices**" + '**ENTER**' + "**Fish Finder Setup**" + '**ENTER**' + "**Preset Mode**" + '**ENTER**'

Fish	: Gain Mode = Auto, Range Mode = Auto, Frequency = do not change, Shift = 0, STC = Short if Freq=200kHz and Mid if Freq=50kHz, Scrolling Speed = 10, Fish Symbols = Echo, A-Scope = On, Surface Noise Filter = Off.
Cruise	: Gain Mode = Auto, Range Mode = Auto, Frequency = do not change, Shift = 0, STC = Short if Freq=200kHz and Mid if Freq=50kHz, Scrolling Speed = 10, Fish Symbols = Echo, A-Scope = On., Surface Noise Filter = 4.

6.5.2 GAIN MODE

Selects Auto or Manual.

- 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Gain Mode" + 'ENTER'

6.5.3 RANGE MODE

Selects among Manual, Auto Range and Bottom Lock. When in **Manual Range Mode** it is possible to set Shift (the offset from the surface) (see Par. 6.5.5) and Depth (see Par. 6.5.4) on which the Fish Finder shall operate. When in **Auto Range Mode** the Fish Finder determines automatically the range as to keep the bottom visible in the lower left of the screen. In this mode, Shift is always set to 0. In **Bottom Lock Mode** the Fish Finder automatically tracks the range around the bottom specified by the Bottom Range value.

- 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Range Mode" + 'ENTER'

6.5.4 DEPTH

This option is available only when Range Mode is Manual and it is disabled in Auto Range and Bottom Lock Mode.

- 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Depth" + 'ENTER'

6.5.5 SHIFT

This option is available only when Range Mode is Manual and it is disabled in Auto Range and Bottom Lock Mode.

- 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Shift" + 'ENTER'

6.5.6 BOTTOM RANGE

This option is available when Range Mode is Bottom Lock.

- 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Bottom Range" + 'ENTER'

6.5.7 FREQUENCY

Allows you to choose the frequency between Auto, 50 kHz or 200 kHz when single frequency page is selected.

- 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Frequency" + 'ENTER'

6.5.8 INTERFERENCE REJECTION

Selects a filter to remove interference from other Fish Finders.

- 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Interf Reject" + 'ENTER'

6.5.9 SENSITIVITY MENU

The Sensitivity menu is accessible both from the Fish Finder Setup menu and by pressing 'ENTER' when in Fish Finder pages. All settings in the Sensitivity menu are related to the Frequency selected.

- 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Sensitivity Menu" + 'ENTER'

6.5.9.1 Frequency

It allows you to select the Frequency to which the Sensitivity parameters are applied.

6.5.9.2 Gain

Allows you to control the Gain of the unit's receiver. To see more details on the screen, increase the receiver sensitivity by selecting a higher gain percentage. If there is too much detail or if the screen is cluttered, lowering the sensitivity may increase the clarity of the display.

6.5.9.3 STC

Sensitivity Time Constant: it is a time varying gain curve which attenuates the sonar receiver gain in shallow water, increasing the gain gradually as the depth increases. This is for the purpose of filtering out surface clutter.

6.5.9.4 STC Length

If STC is Custom, it is possible to change the Length of the Sensitivity Time Constant.

6.5.9.5 STC Strength

If STC is Custom, it is possible to change the Strength of the Sensitivity Time Constant.

6.5.9.6 Surface Noise Filter

This function implements an advanced time varying filter that allows suppressing the surface clutter efficiently while leaving fish targets visible.

Note

Thus imposing the capability of the Fish Finder to correctly detect the weakest echoes coming from a very deep bottom.

6.5.10 DISPLAY SETUP

The Display Setup Menu allows you to change the color scheme of the Fish Finder display, adjusts the chart scrolling rate, enables or disables the White Line and allows determining the graphical representation of fishes.

➤ 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Display Setup" + 'ENTER'

6.5.10.1 Color Settings

Allows you to change the color scheme of the Fish Finder display. The available colors are Blue Background, White Background, Black Background, Gray Scale and Reversed Gray Scale.

6.5.10.2 Scrolling Speed

Adjusts the chart scrolling rate. Note that the scrolling rate is limited by the sound speed and the depth according with the following relation: the deeper the setting, the slower the scrolling rate. 100% is the maximum possible.

6.5.10.3 White Line

Controls how the chart plotter displays information about the bottom type (hard or soft).

6.5.10.4 Fish Symbols

This selection allows determining the graphical representation of underwater suspended targets. See the following table.

Echo	: shows echoes
Echo + Icon	: shows the Fish icon and echoes
Echo + Icon + Depth	: shows the Fish icon, depth values and the fish echoes
Echo + Depth	: shows depth values

Icon : shows Fish icons

Icon + Depth : shows Fish icons and their depth (accordingly to currently selected depth unit)

The Fish icons displayed are among four different shapes depending on the size of the Target (Small, Med, Big, Huge).

6.5.10.5 Water Temperature

Allows you to choose the Water Temperature label displayed over the echogram between Primary and External.

6.5.11 TRANSDUCER SETUP

Selects the Transducer Setup menu that contains the settings that should not require frequent change.

► 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Transducer Setup" + 'ENTER'

6.5.11.1 Keel Offset

It is the transducer depth offset from the surface. This makes it possible to measure depth from the surface instead of from the transducer's location.

6.5.11.2 Calibrate Sound Speed

Allows calibrating the value of Sound Speed in the water, depending on the water temperature and salinity.

6.5.11.3 Calibrate Water Speed

Allows calibrating the value of Water Speed sensor. The calibration value, in the range between -10% to +10%, will be applied to the water speed from the transducer.

6.5.11.4 Calibrate Water Temperature

Allows the calibration on the Water Temperature sensor. Using the readings from a precise temperature measuring device, insert here a positive/negative offset to display right value on Fish Finder screens.

6.5.11.5 Calibrate Aux Temperature

Allows the calibration of the Aux Temperature sensor. Using the readings from a precise temperature measuring device, insert here a positive/negative offset to display right value on FF screens.

6.5.11.6 Set Default settings

Restores the default values

6.5.12 ALARMS

The Alarms menu allows you to define additional sonar alarm settings for Fish Alarm, Shallow Alarm, Depth Alarm and Temperature Upper/Lower/Rate.

► 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Alarms" + 'ENTER'

6.5.12.1 Shallow Water

Triggers an alarm when depth becomes shallower than the value set.

6.5.12.2 Deep Water

Triggers an alarm when depth becomes deeper than the value set.

6.5.12.3 High Water Temperature

Triggers an alarm when the transducer reports a temperature (from TEMP 1 sensor) above the value set.

6.5.12.4 Low Water Temperature

Triggers an alarm when the transducer reports a temperature (from TEMP 1 sensor) below the value set.

6.5.12.5 Water Temperature Rate

Triggers an alarm when the transducer reports a temperature (from TEMP 1 sensor) variation rate above the value set.

6.5.12.6 Fish Alarm

The options for Fish Alarm set the size of the fishes that, if detected by the unit, switches an alarm to sound. These options are: Off, Small, Medium, Big and Huge. The alarm sounds if the set size (or bigger) is detected.

6.5.13 SAVE & LOAD

Insert the MEDIA into the slot, then follow the procedure:

- ▶ 'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER' + "Save & Load" + 'ENTER'

6.5.13.1 Load Settings from MEDIA

Load the complete settings from the MEDIA and changes the active menu settings.

6.5.13.2 Save Settings to MEDIA

This is useful to avoid the user having to retune up Fish Finder after a Clear RAM operation or a software update.

6.5.13.3 Restore Current Preset Defaults

Restors the default values only for the current presets (see Par. 6.5.1, Preset Mode) and does not affect the other presets.

6.6 TRANSDUCERS


The transducer is a device that transmits and receives sound waves into the water. The active component inside the transducer is commonly referred to as an element but actually is a piezoelectric ceramic material.

Please refer to installing instructions of the transducer manufacturer.

Note

In the following tables, related to the transducer functions in the "Funct." column, these abbreviations are used: D = Depth, S = Speed and T = Temperature.

6.6.1 DEDICATED AVAILABLE TRANSDUCERS

	AIRMAR #	Model Designation	Housing	Mount	Funct.	Power
P58 	31-492-1-01	P58 Low cost Transom Mount	Plastic	Transom	D/S/T	600W
P66 	31-680-1-01	P66 Hi Performance	Plastic	Transom	D/S/T	600W
P79 	31-494-2-01	P79 Plastic	Plastic	In-hull	D	600W
P319 	31-495-2-01	P319 Plastic	Plastic	Thru-hull	D	600W
B744V 	31-658-2-02	B744V W/ Hi Performance Fairing	Bronze	Thru-hull	D/S/T	600W
B45 	31-696-1-01	B45 W/ Hi Performance Fairing	Bronze	Thru-hull	D/T	600W

7. Terms & Functions

This section explains the terms that may be unfamiliar to the reader. The symbol ■ indicates that the term is followed only by an explanation, while the symbol ► indicates that the term is more widely explained; you will also find a briefly description on how to select the related menu option, listing the operation a keys sequence with the menu names enclosed between double apices. For example 'ENTER' + "Waypoint" + 'ENTER' means that you must press the 'ENTER' key, using the cursor key to select the Waypoint item and press the 'ENTER' key to place it.

► AIS (menu)

Automatic Identification System. It has been introduced to improve the safety of navigation by assisting in the efficient operation of ship-to-ship, ship reporting and VTS applications.

... Display

'MENU' + "Devices" + 'ENTER' + "AIS" + 'ENTER' + "Display" + 'ENTER'

... CPA Alarm

'MENU' + "Devices" + 'ENTER' + "AIS " + 'ENTER' + "CPA Alarm" + 'ENTER'

... TCPA Alarm

'MENU' + "Devices" + 'ENTER' + "AIS" + 'ENTER' + "TCPA Alarm" + 'ENTER'

► ALARMS (menu)

Sets the desired values/settings for the alarms.

... Auto Off (On, Off)

'MENU' + "Alarms" + 'ENTER' + "Auto Off" + 'ENTER'

... Arrival Alarm (value, Off)

'MENU' + "Alarms" + 'ENTER' + "Arrival Alarm" + 'ENTER'

... XTE Alarm (value, Off)

'MENU' + "Alarms" + 'ENTER' + "XTE Alarm" + 'ENTER'

... Anchor Alarm (value, Off)

'MENU' + "Alarms" + 'ENTER' + "Anchor Alarm" + 'ENTER'

... Depth Alarm (value, Off)

'MENU' + "Alarms" + 'ENTER' + "Depth Alarm" + 'ENTER'

... HDOP Alarm (value, Off)

'MENU' + "Alarms" + 'ENTER' + "HDOP Alarm" + 'ENTER'

... Heading Alarm (On, Off)

'MENU' + "Alarms" + 'ENTER' + "Heading Alarm" + 'ENTER'

... Grounding Alarm (value, Off)

'MENU' + "Alarms" + 'ENTER' + "Grounding Alarm" + 'ENTER'

... Grounding Alarm Range (0.25 Nm, 0.5 Nm, 1.0 Nm)

'MENU' + "Alarms" + 'ENTER' + "Grounding Alarm Range" + 'ENTER'

... Grounding Alarm Report

'MENU' + "Alarms" + 'ENTER' + "Grounding Alarm Report" + 'ENTER'

... External Alarm (On, Off) ONLY FOR O.CHART7/O.CHART7F

'MENU' + "Alarms" + 'ENTER' + "External Alarm" + 'ENTER'

► AUTO INFO

The type of Automatic Info is user selectable. The possible settings are: **Off**: disabled, no automatic info shown at all; **On Points**: only on points. This is the default setting. **On All**: on all objects (points, lines and areas).

'MENU' + "Setup" + 'ENTER' + "Auto Info" + 'ENTER'

■ AZIMUTH

Angular measurement from the horizon to a satellite or another object.

■ BEACON

Prominent, specially constructed object forming a conspicuous vertical mark as a fixed aid to navigation.

■ BRG = Bearing

Angle between the North (True or Magnetic) and a destination. It represents the direction to follow.

■ BUOY

Floating object moored to the sea bottom in a particular (charted) place, as an aid to navigation.

➤ Cartridge

Also called MEDIA.

➤ CHART (page)

Shows the chart at full screen.

ONLY FOR O.CHART5/5F

'PAGE' + "Chart" + 'ENTER'

ONLY FOR O.CHART7/7F

'MENU' + "Page" + 'ENTER' + "Chart" + 'ENTER'

➤ CHART + DATABOXES (page)

Shows the chart and the Text Area.

ONLY FOR O.CHART5/5F

'PAGE' + "Chart + Databoxes" + 'ENTER'

ONLY FOR O.CHART7/7F

'MENU' + "Page" + 'ENTER' + "Chart + Databoxes" + 'ENTER'

■ C-LINK

Allows to sharing the same navigation data between two chart plotters linked via serial I/O port.

■ COG = Course Over Ground

Direction of the path over ground actually followed by a vessel.

➤ CONFIG Track (menu)

Handles track settings.

... Active Track

'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Active Track" + 'ENTER' + insert the number of the desired Track (1, ..., 5) + 'ENTER'

... Display Mode (Visible/Hidden)

'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Display Mode" + 'ENTER' + "Visible"/"Hidden" + 'ENTER'

... Track Color

'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Color" + 'ENTER' + select color + 'ENTER'

... Step Unit (Time/Distance)

'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Step Unit" + 'ENTER' + "Distance"/"Time" + 'ENTER'

... Time Step (1 sec, 5 sec, 10 sec, 30 sec, 1 Min)

'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Time Step" + 'ENTER' + select the desired Time Step + 'ENTER'

... Distance Step (0.01, 0.05, 0.1, 0.5, 1.0, 2.0, 5.0, 10.0)

'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Distance Step" + 'ENTER' + select the desired Disatance Step + 'ENTER'

... Delete All Tracks

'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER' + "Delete All Tracks" + 'ENTER' + 'Yes'

■ CURRENT

Non-periodical movement of sea-water, generally horizontal, due to many causes such as different temperatures and prevalent winds. Some may be temporary, others permanent.

➤ C-WEATHER

Meteorological forecasting system with the ability to visualize the weather forecast, overlaying it on cartography.

... Copy From Media

'MENU' + "C-Weather" + 'ENTER' + "Copy from Media" + 'ENTER'

... Download (Select Country To Call, Telephone Number, Pin Sim, Download Area)

'MENU' + "C-Weather" + 'ENTER' + "Download" + 'ENTER'

... Forecast

'MENU' + "C-Weather" + 'ENTER' + "Forecast" + 'ENTER'

... Real Time View (On, Off)

'MENU' + "C-Weather" + 'ENTER' + "Real Time View" + 'ENTER'

... Type of Data (Wind, Wave Data, Weather, Humidity, Temperature, Visibility)

'MENU' + "C-Weather" + 'ENTER' + "Type Of Data" + 'ENTER'

■ DATA MEDIA

Chart cartridge that contains detailed charts of the area covered.

■ DATUM

The Latitude and Longitude lines printed on any map are based on certain models of the shape of the earth: these models are called Datum or Coordinate Systems. There are many different Datum in use, each one gives different Lat/Lon positions for an identical point on the surface of the earth.

■ **Dedicated Key**

Key with a specified function. These keys have a label printed on them.

■ **DEFAULT**

Indicates a value or a setting which is used if the user has not defined a particular value. You can modify this value using the menu settings.

➤ **DEPTH (pages)**

Allows to display the Depth Graph (if Fish Finder pages are not available and if valid NMEA0183 depth data is available):

ONLY FOR O.CHART5/5F

full screen: 'PAGE' + "Full Depth" + 'ENTER'

split screen+chart: 'PAGE' + "Chart+Depth" + 'ENTER'

split screen+data boxes: 'PAGE' + "Depth+Databoxes" + 'ENTER'

ONLY FOR O.CHART7/7F

full screen: 'MENU' + "Page" + 'ENTER' + "Full Depth" + 'ENTER'

split screen+chart: 'MENU' + "Page" + 'ENTER' + "Chart+Depth" + 'ENTER'

split screen+data boxes: 'MENU' + "Page" + 'ENTER' + "Depth+Databoxes" + 'ENTER'

■ **DEPTH RANGE**

The sea area that is **beyond** the selected range is filled by an uniform white color, the sea area that is **inside** the selected range is filled by ordinary multicolor shading. The Spot Soundings and Depth Contours are displayed on the range only.

➤ **DEVICES (menu)**

Allows to select the following menu:

... **FISH FINDER SETUP Menu**

'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER'

... **AIS Menu**

'MENU' + "Devices" + 'ENTER' + "AIS" + 'ENTER'

... **DSC Menu**

'MENU' + "Devices" + 'ENTER' + "DSC" + 'ENTER'

■ **DGPS = Differential GPS**

Provides even greater positioning accuracy than standard GPS.

➤ **DSC**

Digital Selective Calling. Method of establishing a VHF radio call; it is used to announce urgent maritime safety information broadcasts.

... **DSC Log**

'MENU' + "Devices" + 'ENTER' + "DSC" + 'ENTER' + "DSC Log" + 'ENTER'

... **DSC Directory**

'MENU' + "Devices" + 'ENTER' + "DSC" + 'ENTER' + "DSC Directory" + 'ENTER'

■ **DTG = Distance To Go**

Actual distance to reach the Target.

■ **EVENT**

User point that refers to the ship's position. It is simply a way of marking where the boat is.

■ **FILE**

Collection of information (of the same type) stored on a MEDIA. Each file must have a unique name, ideally one that describes its contents. Filenames are kept in a directory on each MEDIA.

➤ **FIND (menu)**

Allows finding Port Services, Port By Name, Port By Distance, Lakes By Name, Lakes Information, Points Of Interest, Tide Stations, Wrecks, Obstructions, Cursor, Coordinates and User Points.

... **Port Services**

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Port Services" + 'ENTER'

... **Port By Name**

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Port by Name" + 'ENTER'

... **Port By Distance**

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Port by Distance" + 'ENTER'

... **Tide Stations**

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Tide Stations" + 'ENTER'

... **Wrecks**

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Wrecks" + 'ENTER'

... **Obstructions**

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Obstructions" + 'ENTER'

... **Lakes Info**

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Lakes Info" + 'ENTER'

... **Lakes By Name**

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Lakes by Name" + 'ENTER'

... Points Of Interest

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Points of Interest" + 'ENTER'

... Cursor

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Cursor" + 'ENTER'

... Coordinates

Press any soft key + 'MAP' + "Find" + 'ENTER' + "Coordinates" + 'ENTER'

... User Points

Press any soft key + 'MAP' + "Find" + 'ENTER' + "User Points" + 'ENTER'

➤ FISH FINDER SETUP (menu)

The chart plotter combined with the sonar performance of the Fish Finder is one of the most advanced marine navigation system available. From any Fish finder page:

'MENU' + "Devices" + 'ENTER' + "Fish Finder Setup" + 'ENTER'

➤ GOTO (menu)

Allows to select the main navigation functions to a Target.

... Last GoTo

'GOTO' + "Last GoTo" + 'ENTER' (or 'GOTO')

... Cursor

'GOTO' + "Cursor" + 'ENTER' (or 'GOTO')

... Mark

'GOTO' + "Mark" + 'ENTER' (or 'GOTO')

... Routes

'GOTO' + "Route" + 'ENTER' (or 'GOTO')

... Port Services

'GOTO' + "Port Services" + 'ENTER' (or 'GOTO')

... Clear GOTO

'GOTO' + "Clear GoTo" + 'ENTER' (or 'GOTO')

■ GPS = Global Positioning System

Satellite based navigation system operated by the US Department of Defence. It gives the navigator a position 24 hours a day, 365 days a year under any weather conditions.

➤ GPS Status (page)

Shows in graphic mode GPS data.

ONLY FOR O.CHART5/5F

'PAGE' + "GPS Status" + 'ENTER'

ONLY FOR O.CHART7/7F

'MENU' + "Page" + 'ENTER' + "GPS Status" + 'ENTER'

➤ GPS SETUP (menu)

Sets the your preferred configuration for the connected GPS.

... Restart GPS

'MENU' + "Input/Output" + 'ENTER' + "GPS Setup" + 'ENTER' + "Restart GPS" + 'ENTER'

... Differential Correction (*None, WAAS-EGNOS, RTCM-104*)

'MENU' + "Input/Output" + 'ENTER' + "GPS Setup" + 'ENTER' + "Diff Corr" + 'ENTER'

... Navigation Speed (*High, Low*)

'MENU' + "Input/Output" + 'ENTER' + "GPS Setup" + 'ENTER' + "Navigation Speed" + 'ENTER'

... PRN WAAS SATELLITE Selection (*Auto, 120*) (*ACTIVE IF DIFFERENTIAL CORRECTION IS WAAS-EGNOS*)

'MENU' + "Input/Output" + 'ENTER' + "GPS Setup" + 'ENTER' + "PRN WAAS Satellite" + 'ENTER'

■ HDG = Heading

Horizontal direction in which a ship actually points or heads in any moment (see also COG).

■ HDOP = Horizontal Dilution Of Precision

Index for position-fixing accuracy. The smaller the HDOP value, the more accurately the position can be fixed.

➤ HOME (or Navigation)

See Navigation mode.

'CLEAR'

➤ INPUT/OUTPUT (menu)

Allows to select the following options Port Input n, Port Output n, Port Output Sentences n, C-Link and the Cable Wiring pages.

Note

Where $n = 1, 2, 3$ for O.CHART5/O.CHART 5F and $n = 1, 2, 3, 4, 5$ for O.CHART7/O.CHART 7F.

Warning

After every software upgrade the RAM is cleared and the chart plotter re starts with the usual default settings. Please go to the Input/output menu and set the proper input format once again.

... **Port n Input** (NMEA-0183 1200-N-81-N, NMEA-0183 4800-N-81-N, NMEA-0183 4800-N-82-N, NMEA-0183 9600-N-81-N, NMEA-0183 9600-O-81-N, C-Com, BBF 50/200, AIS 38400, Disabled)

'MENU' + "Input/Output" + 'ENTER' + "Port n Input" + 'ENTER'

... **Port n Output** (NMEA-0183 4800-N-81-N, NMEA-0180, NMEA-0180/CDX, Disabled)

'MENU' + "Input/Output" + 'ENTER' + "Port n Output" + 'ENTER'

... **Port n Output Sentences** (GLL, VTG, BOD, XTE, BWC, RMA, RMB, RMC, APB, WCV, GGA, HSC, HDG, MWV, ZDA, GSA, DPT)

'MENU' + "Input/Output" + 'ENTER' + "Port n Output Sentences" + 'ENTER'

... **Internal GPS Setup Menu**

'MENU' + "Input/Output" + 'ENTER' + "Internal GPS Setup" + 'ENTER'

... **C-LINK Menu**

'MENU' + "Input/Output" + 'ENTER' + "C-Link" + 'ENTER'

... **Cable Wiring**

'MENU' + "Input/Output" + 'ENTER' + "Cable Wiring" + 'ENTER'

■ LATITUDE

Angular distance North or South of the equator measured by lines encircling the earth parallel to the equator in degrees from 0° to 90°.

■ LAT/LON

Coordinate system using [Latitude](#) and [Longitude](#) coordinates to define a position on earth.

➤ LIST (User Points) (menu)

Displays the User Points list on the screen.

... **List**

'MENU' + "List" + 'ENTER' + "List" + 'ENTER'

... **Send**

'MENU' + "List" + 'ENTER' + "Send" + 'ENTER'

... **Receive**

'MENU' + "List" + 'ENTER' + "Receive" + 'ENTER'

■ LONGITUDE

Angular distance East or West of the prime meridian (Greenwich meridian) as measured by lines perpendicular to the parallels and covering at the poles from 0° to 180°.

■ MAGNETIC DEVIATION

Angle between the Magnetic North and the Compass North.

■ MAGNETIC VARIATION

The angle between the magnetic and geographic meridians at any place, expressed in degrees West or East to indicate the direction of magnetic North from true North. It changes from point to point, and (at the same point) with time.

➤ MAP (menu)

The user may choose either to display or not on the screen the selected objects, depending on his specific requirement.

... **Zoom Type** (Standard, Flexi-Zoom)

Press any soft key + 'MAP' + "Zoom Type" + 'ENTER'

... **Fonts & Symbols** (Normal, Large)

Press any soft key + 'MAP' + "Fonts & Symbols" + 'ENTER'

... **Perspective View** (On, Off)

Press any soft key + 'MAP' + "Perspective View" + 'ENTER'

... **Dynamic Nav-Aids** (On, Off)

Press any soft key + 'MAP' + "Dynamic Nav-Aids" + 'ENTER'

... **Mixing Levels** (On, Off)

Press any soft key + 'MAP' + "Mixing Levels" + 'ENTER'

... **Safety Status Bar** (On, Off, Icon)

Press any soft key + 'MAP' + "Safety Status Bar" + 'ENTER'

... **Satellite Imagery** (On, Off)

Press any soft key + 'MAP' + "Satellite Imagery" + 'ENTER'

... **Currents Prediction**

Press any soft key + 'MAP' + "Currents Prediction" + 'ENTER'

... **Other Map Configurations Menu**

Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER'

... **Info**

Press any soft key + 'MAP' + "Info" + 'ENTER'

... **Find Menu**

Press any soft key + 'MAP' + "Find" + 'ENTER'

➤ MARK

Reference points related to cursor position

Add Mark: 'ENTER' + "MARK" + 'ENTER'
Move Mark: place cursor on Mark+ 'Move' + cursor + 'ENTER'
Delete Mark: place cursor on Mark+ 'DELETE' + 'ENTER'
Edit Mark: place cursor on Mark+ 'EDIT' + 'ENTER' + select field (*Symbol/Name/Color/Coordinates*) using cursor + 'ENTER'
GoTo on Mark: place cursor on Mark+ 'GoTo' + 'ENTER'
Find Mark: press any soft key + 'MAP' + "Find" + 'ENTER' + "User Points" + 'ENTER'
Info on Mark: 'MENU' + "List" + 'ENTER' + "List" + 'ENTER'
Send Mark: 'MENU' + "List" + 'ENTER' + "Send" + 'ENTER'
Receive Mark: 'MENU' + "List" + 'ENTER' + "Receive" + 'ENTER'

■ MEDIA

Also called simply cartridge.

➤ MEDIA (menu)

Before a new MEDIA can be used, you must format it. The formatting function initializes the MEDIA and prepares it for storing information. Remember that if an MEDIA is not blank, formatting it will destroy any data already present on the MEDIA (the MEDIA must be formatted in order to be reused, this operation means all old data memorized on the MEDIA will be lost).

... Read

'MENU' + "Memory Card" + 'ENTER' + 'MEDIA' + 'READ'

... Format

'MENU' + "Memory Card" + 'ENTER' + 'MEDIA' + 'FORMAT'

... Sort By

'MENU' + "Memory Card" + 'ENTER' + 'MEDIA' + 'SORT BY'

➤ MEMORY CARD (menu)

The chart plotter uses the optional MEDIA to save user data: it is a convenient medium to store and retrieve your information.

... Save File (*Mark, Event, Routes, Tracks*)

'MENU' + "Memory Card" + 'ENTER' + 'SAVE'

... Load File

'MENU' + "Memory Card" + 'ENTER' + 'LOAD'

... Delete File

'MENU' + "Memory Card" + 'ENTER' + 'DELETE'

... Media Menu

'MENU' + "Memory Card" + 'ENTER' + 'MEDIA'

➤ MOB = Man OverBoard

It is an important function useful in the case someone or something falls overboard.

Inserting MOB: 'ENTER' + "MOB" + 'ENTER'

Deleting MOB: 'ENTER' + "MOB" + 'ENTER' + 'ACCEPT'

➤ NAVIGATION (or Home)

From charting, while receiving a fix position and the chart plotter is not in Navigation mode, enables the Navigation mode (also called Home).

When in Navigation mode, the cursor is not shown and all cartographic functions are related to the ship position. The received fix position is centered in the cartography area and the window screen follows the ship position as the position changes. When the cursor key has been pressing, the Navigation mode is disabled and the cursor symbol is shown again. Note that also the cursor symbol is not shown while Navigation mode is active, its coordinates are updated with ship position coordinates.

'CLEAR'

➤ OTHER MAP CONFIGURATIONS (menu)

Selects from a predefined table what cartographic objects are displayed and which display options are set.

... Display Mode (*Full, Medium, Low, Radar, Tide, Custom*)

Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Display Mode" + 'ENTER'

The following are the available selections only if Custom has been selected:

... Place Names (*On, Off*)

Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Place Names" + 'ENTER'

... Name Tags (*On, Off*)

Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Name Tags" + 'ENTER'

... Nav-Aids & Light Sectors (*On, Off, No Sector*)

Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Nav Aids & Light Sectors" + 'ENTER'

... Attention Areas (*On, Off*)

Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Attention Areas" + 'ENTER'

... Tides & Currents (*On, Off*)

Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Tides & Currents" + 'ENTER'

... *Seabed Type* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Seabed Type" + 'ENTER'

... *Ports & Services* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Ports & Services" + 'ENTER'

... *Tracks & Routes* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Tracks & Routes" + 'ENTER'

... *Depth Range Min*
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Depth Range Min" + 'ENTER'

... *Depth Range Max*
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Depth Range Max" + 'ENTER'

... *Land Elevation* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Land Elevation" + 'ENTER'

... *Land Elevation values* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Land Elevation values" + 'ENTER'

... *Roads* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Roads" + 'ENTER'

... *Points Of Interest* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "POI" + 'ENTER'

... *Lat/Lon Grid* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Lat/Lon Grid" + 'ENTER'

... *Chart Boundaries* (On, Off, Auto)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Chart Boundaries" + 'ENTER'

... *Value-Added Data* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Value-Added Data" + 'ENTER'

... *Chart Lock* (On, Off)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Chart Lock" + 'ENTER'

... *Underwater Objects Limit*
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Underwater Objects Limit" + 'ENTER'

... *Rocks* (Off, Icon, Icon + Depth)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Rocks" + 'ENTER'

... *Obstructions* (Off, Icon, Icon + Depth)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Obstructions" + 'ENTER'

... *Diffusers* (Off, Icon, Icon + Depth)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Diffusers" + 'ENTER'

... *Wrecks* (Off, Icon, Icon + Depth)
 Press any soft key + 'MAP' + "Other Map Configurations" + 'ENTER' + "Wrecks" + 'ENTER'

■ ORIENTATION RESOLUTION

Resolution angle for the [Map Orientation](#), range [5, 30] degrees. The [default](#) setting is 30°.

► PALETTE

It is possible to select Normal, NOAA, Night Vision or Sunlight for Palette. **Normal** is recommended when the chart plotter is not exposed to the direct sunlight. When this mode is set the maps are displayed in order to use colors as similar as possible to the ones used in the original paper charts. **NOAA** allows setting NOAA paper chart colors presentation. **Sunlight** is designed to enhance the visibility of the screen when the chart plotter is exposed to the sunlight. The maps are much brighter than in the other modes and the depth areas are filled with white color so different depth areas are not easily distinguishable. **Night Vision** is recommended when the environment is dark in order to reduce the glare of the display. The chart plotter displays maps and screen in darker colors.

'POWER' + 'MENU'

or:

'MENU' + "LCD Adjustment" + 'ENTER' + 'MENU'

■ PORT INFO

Combination of a Port Info database containing all the relevant Safety and Navigational information normally found in good pilot books and a presentation software which displays special Port Facility Symbols.

► ROLLING ROAD (page)

Allows to display the Navigation plane in prospective mode.

ONLY FOR O.CHART5/5F

'PAGE' + "Rolling Road" + 'ENTER'

ONLY FOR O.CHART7/7F

'MENU' + "Page" + 'ENTER' + "Rolling Road" + 'ENTER'

► ROUTE

Sequence of Waypoints connected by segments. Among the available routes, only one is the active route, which is shown by a straight line and arrows to indicate the direction. The first Waypoint of the active route is surrounded by a circle.

... Select

'MENU' + "Route" + 'ENTER' + "Select" + 'ENTER' + 'SELECT'/'NOTE'/'COLOR'/'HIDE'

... Delete

'MENU' + "Route" + 'ENTER' + "Delete" + 'ENTER'

... Report

'MENU' + "Route" + 'ENTER' + "Report" + 'ENTER'

... Color

'MENU' + "Route" + 'ENTER' + "Color" + 'ENTER'

... Send

'MENU' + "Route" + 'ENTER' + "Send" + 'ENTER'

... Receive

'MENU' + "Route" + 'ENTER' + "Receive" + 'ENTER'

... Automatic Route Check (*On, Off*)

'MENU' + "Route" + 'ENTER' + "Automatic Route Check" + 'ENTER'

... Route Depth

'MENU' + "Route" + 'ENTER' + "Route Depth" + 'ENTER'

... Route Width

'MENU' + "Route" + 'ENTER' + "Route Width" + 'ENTER'

... Route Check Accuracy (*Minimum, Low, Medium, High, Maximum*)

'MENU' + "Route" + 'ENTER' + "Route Check Accuracy" + 'ENTER'

... Route Check Report

'MENU' + "Route" + 'ENTER' + "Route Check Report" + 'ENTER'

■ **RTCM = Radio Technical Commission for Maritime Services**

Data format created by the Radio Technical Commission Maritime to transmit Differential GPS corrections.

► SETTINGS (menu)

Allows to select the following menu:

... PAGE Menu ONLY FOR O.CHART7/7F

'MENU' + "Page" + 'ENTER'

... SETUP Menu

'MENU' + "Setup" + 'ENTER'

... Input/Output Menu

'MENU' + "Input/Output" + 'ENTER'

... C-WEATHER Menu

'MENU' + "C-Weather" + 'ENTER'

... DEVICES Menu

'MENU' + "Devices" + 'ENTER'

... Memory Card Menu

'MENU' + "Memory Card" + 'ENTER'

... List Menu

'MENU' + "List" + 'ENTER'

... Track Menu

'MENU' + "Track" + 'ENTER'

... Route Menu

'MENU' + "Route" + 'ENTER'

... Alarms Menu

'MENU' + "Alarms" + 'ENTER'

... Simulation Menu

'MENU' + "Simulation" + 'ENTER'

... LCD Adjustment

'MENU' + "LCD Adjustment" + 'ENTER'

... About page

'MENU' + "About..." + 'ENTER'

► SETUP (menu)

Allows to select the following menu:

... **Language**
'MENU' + "Setup" + 'ENTER' + "Language" + 'ENTER'

... **Chart Language**
'MENU' + "Setup" + 'ENTER' + "Chart Language" + 'ENTER'

... **Distance + Speed Units** (*Nm & Kts, Sm & Mph, Km & Kph*)
'MENU' + "Setup" + 'ENTER' + "Distance+Speed Units" + 'ENTER'

... **Depth + Altitude Units** (*Ft = Feet, Mt = Meter*)
'MENU' + "Setup" + 'ENTER' + "Depth + Altitude Units" + 'ENTER'

... **Temperature Units** (*°C, °F*)
'MENU' + "Setup" + 'ENTER' + "Temperature Units" + 'ENTER'

... **Time Reference** (*UTC, Local time*)
'MENU' + "Setup" + 'ENTER' + "Time Reference" + 'ENTER'

... **Daylight Saving Time** (*On, Off*)
'MENU' + "Setup" + 'ENTER' + "Daylight Saving Time" + 'ENTER'

... **Time Format** (*24 hour, 12 hour*)
'MENU' + "Setup" + 'ENTER' + "Time Format" + 'ENTER'

... **Date Format** (*MM-DD-YY, DD-MM-YY*)
'MENU' + "Setup" + 'ENTER' + "Date Format" + 'ENTER'

... **Bearing** (*Auto Mag, True*)
'MENU' + "Setup" + 'ENTER' + "Bearing" + 'ENTER'

... **Visual COG Bar** (*On, Off*)
'MENU' + "Setup" + 'ENTER' + "Visual COG Bar" + 'ENTER'

... **Map Orientation** (*North Up, Head Up, Track Up*)
'MENU' + "Setup" + 'ENTER' + "Map Orientation" + 'ENTER'

... **Auto Info** (*Off, On Points, On All*)
'MENU' + "Setup" + 'ENTER' + "Auto Info" + 'ENTER'

... **Nav-Aids Presentation** (*International, US*)
'MENU' + "Setup" + 'ENTER' + "Nav-Aids Presentation" + 'ENTER'

... **Keypad Beep** (*On, Off*)
'MENU' + "Setup" + 'ENTER' + "Keypad Beep" + 'ENTER'

... **Sensors Calibration** (*Default, Manual*)
'MENU' + "Setup" + 'ENTER' + "Sensors Calibration" + 'ENTER'

➤ **SIMULATION** (menu)

Used in order to use your chart plotter without input data. It generates a display with a moving vessel, so that you can practice using the controls in safety.

... **Speed**
'MENU' + "Simulation" + 'ENTER' + "Speed" + 'ENTER'

... **Heading**
'MENU' + "Simulation" + 'ENTER' + "Heading" + 'ENTER'

... **Date**
'MENU' + "Simulation" + 'ENTER' + "Date" + 'ENTER'

... **Time**
'MENU' + "Simulation" + 'ENTER' + "Time" + 'ENTER'

... **Cursor Control** (*On, Off*)
'MENU' + "Simulation" + 'ENTER' + "Cursor Control" + 'ENTER'

... **Simulation Mode** (*On, Off*)
'MENU' + "Simulation" + 'ENTER' + "Simulation Mode" + 'ENTER'

■ **SNR = Signal to Noise Ratio**

Ratio of the magnitude of a signal that of the noise (interference).

■ **SOFT KEY**

Software keys have different functions according to the modes of operation: their labels for the current functions, located on the front panel, are shown on the screen right above the soft key.

■ **SOG = Speed Over Ground**

Calculation of the rate of movement of the ship over the ground.

■ **SPEED**

Current velocity at which you are travelling, relative to a ground location.

➤ **TARGET (or GoTo)**

See [GoTo](#).

■ **TIDE**

Periodic rise and fall of the surface of oceans, bays, etc., due principally to the gravitational interactions between the Moon and Earth.

■ **TIDE INFO**

Combination of a [tide](#) heights database and features which calculate the [tide](#) graph for all primary and secondary ports world-wide. This function can calculate the [tide](#) heights for any past or

future date and as a by-product of this calculation will also display the Maximum and Minimum Tide height and time for the day selected plus the times of Sunrise and Sunset. At some chart levels, the chart plotter will display a new Tide Diamond Symbol for every Port or tide point in the database covered by that particular DATA MEDIA.

➤ TRACK (menu)

As long as the chart plotter is connected to a positioning instrument, it stores all points in its memory. The chart plotter can store a fix when the distance from its last stored position is greater than a defined distance or after a defined time. A line connects such points and represents the past course, called the track of the ship.

... **Activate/Deactivate Track**

'MENU' + "Track" + 'ENTER' + "Activate/Deactivate" + 'ENTER'

... **Delete Track**

'MENU' + "Track" + 'ENTER' + "Delete" + 'ENTER' + 'BEGIN'/'END'/'WHOLE' + 'YES'

... **Config Track Menu**

'MENU' + "Track" + 'ENTER' + "Config" + 'ENTER'

... **LOG**

'MENU' + "Track" + 'ENTER' + "Log" + 'ENTER' + 'TOTAL'/'TRIP'

... **Track To Route Menu**

'MENU' + "Track" + 'ENTER' + "Track to Route" + 'ENTER'

➤ TRACK TO ROUTE (menu)

This function creates a Route from a pre-recorded Track.

... **Track To Route**

'MENU' + "Track" + 'ENTER' + "Track to Route" + 'ENTER' + "Track to Route" + 'ENTER'

... **Select Track No.**

'MENU' + "Track" + 'ENTER' + "Track to Route" + 'ENTER' + "Select Track No." + 'ENTER'

... **Select Route No.**

'MENU' + "Track" + 'ENTER' + "Track to Route" + 'ENTER' + "Select Route No." + 'ENTER'

■ TTG = Time To Go

Estimated time needed to reach your destination, based on your current speed and the distance to destination.

■ UTC = Universal Time Coordinated

Time scale based on the rotation of the earth that is used by most broadcast time services.

■ USER POINT

Place on the chart identified by its coordinates and displayed on the screen with a reference symbol (see Mark, Waypoint).

➤ VIDEO (pages) ONLY FOR O.CHART7/O.CHART7F

It is possible to see images on the chart plotter display captured from an external video signal source, if connected to the chart plotter. Two types of Video pages are available:

full screen: 'MENU' + "Page" + 'ENTER' + "Video" + 'ENTER'

chart+video: 'MENU' + "Page" + 'ENTER' + "Chart+Video" + 'ENTER'

■ WAAS = Wide Area Augmentation System

The Federal Aviation Administration (FAA), in cooperation with other DOT organizations and DOD, is augmenting the GPS/SPS with a satellite-based augmentation system, the WAAS. It will provide a signal-in-space to WAAS users to support en route through precision approach navigation. After achieving initial operational capability, the WAAS will then be incrementally improved over the next years to expand the area of coverage, increase the availability of precision approaches, increase signal redundancy and reduce operational restrictions.

➤ WAYPOINT

Any point to which one intends to navigate. A sequence of Waypoints makes up a route plan.

Add WPT: 'ENTER' + "WAYPOINT" + 'ENTER'

Move WPT: place cursor on WPT + 'Move' + move cursor + 'ENTER'

Delete WPT: place cursor on WPT + 'DELETE' + 'ENTER'

Edit WPT: place cursor on WPT + 'Edit' + 'ENTER' + select field (Symbol/Name/Color) using cursor + 'ENTER'

Insert WPT: place cursor on leg + 'INSERT' + move cursor + 'ENTER'

GoTo on WPT: place cursor on WPT + 'GoTo' + 'ENTER'

Find WPT: press any soft key + 'MAP' + "Find" + 'ENTER' + "User Points" + 'ENTER'

Info on WPT: 'MENU' + "List" + 'ENTER'

Send WPT: 'MENU' + "List" + 'ENTER' + "Send" + 'ENTER'

Receive WPT: 'MENU' + "List" + 'ENTER' + "Receive" + 'ENTER'

■ WGS-84 = World Geodetic System 1984

Coordinate System or Datum developed by the Defense Mapping Agency (DMA).

■ ZOOM IN

Shows more detail in a smaller area.

■ **ZOOM OUT**

Operates similarly to zoom -in, but in the reverse, showing a wider but less detailed view.

■ **XTE = Cross Track error**

Distance from the ship's present position to the closest point on a line between the origin and destinations Waypoints of the navigation leg being travelled.

8. System Test

8.1 SYSTEM TEST

If you have connected your position-finding device according to the instructions, and chosen the proper menu selection for your device, and are still having problems with your chart plotter, the extended auto-test should help determine the problem. Make sure the chart plotter is turned Off. While pressing and holding any other key, turn the chart plotter On. A new menu will appear on the display:




Fig. 8.1 - System Test

Use the cursor key to select the desired test: this will display in reverse video and with the relative menu window. To choice the test press 'ENTER'. To exit from any submenu press 'CLEAR'. To exit from the System Test turn Off the chart plotter.

8.1.1 RAM Menu

This test verifies the integrity of the memories and if desired during this test all the internal memory can be erased and the default setting restored.

■ RAM Clear

To clear internal memory. If the chart plotter exhibits unusual behavior, or appears to be malfunctioning, it may be possible to correct the problem by clearing RAM. This operation will erase all Marks, Events, Routes, stored track plots and destinations. It will also return all selections (Input Data Format, Autopilot selection, etc.) to original default values.

8.1.2 DIM Menu

To select the desired value for keypad light.

■ Contrast

The first option allows to adjust the contrast. Each time you pressed the cursor key to right, the screen will decrease brightness, instead of to left it will increase brightness.

■ Backlight

The second option allows to set the keyboard backlight.

8.1.3 CARTRIDGES

To check the MEDIA.

■ Internal Data Base Test

The first option allows to check the background cartography.

■ MEDIA Test

To test the MEDIA. There are the possible situations:

1. if there is a MEDIA inserted in the slot and there is not a malfunction, the name of the MEDIA zone and the message "OK" are shown.
2. if there is a MEDIA inserted in the slot, but it is a damaged MEDIA
3. if there is not any MEDIA inserted in the slot, the message "not present" is shown.
4. if there is an MEDIA inserted in the slot, the message "USER MEDIA" is shown.

■ MEDIA Connector

Indicates if there is a malfunction in the connector. It is used only in production.

8.1.4 MODEM TEST

To check the Modem connections. Press 'ENTER' to select the preferred Port related to the connections made, to the Port that the Modem C-COM is connected.

8.1.5 SERIAL PORT

If you are having problems receiving data from the position-finding instrument, this test should help determine the problem.

■ Change Parameters

To change the parameters of the serial interface. This menu allows to select the **Port**, the **Baud Rate** between 4800 or 9600, the **Data Bits** (Word Length) between 7 or 8, the **Parity** between even, odd or none, the **Stop Bits** between 1 or 2.

■ Input Data Display

To allow the chart plotter to act as a computer terminal and display the incoming data exactly as it received. If the data displayed on the screen is unrecognizable, you may have selected the wrong input parameters for your particular receiver. Check your receiver manual to be sure that you have selected the proper interface format. If the screen is blank, you may have a broken connection, and no data is being received. Use 'ZOOM IN' to stop (or continue after pause) data displaying, 'ENTER' to show data in hex or ASCII mode (normal or small) and 'CLEAR' to exit.

8.1.6 VIDEO TEST

Allows a full text on the functionality of the screen.

8.1.7 ONLY FOR O.CHART7/7F: EXTERNAL ALARM

To check if the External Alarm has been transmitted.

appendix **A.** Troubleshooting

THE CHART PLOTTER DOES NO TURN ON

Make sure that the correct voltage (10-18 volt dc) is present. Check also that the polarity is correct. Refer to the Par. 2.2.

THE CHART PLOTTER DOES NOT GET A VALID FIX

Make sure that no metal obstacle is placed around the chart plotter acting as a shield for the antenna. If, after 15 minutes, the chart plotter does not get the fix, turn it Off and On again.

THE SCREEN BECOMES DARK AFTER SOON EXPOSITION


Adjust contrast (see Par. 2.4).

THE CHART PLOTTER DOES NOT RESPOND TO ANY COMMAND

Try to turn Off, and then turn On. If the problem persists, erase the memory (see Par. 8.1.1).

O.CHART5

O.CHART5F



TECHNICAL SPECIFICATIONS

- Power Consumption
 - O.CHART5 : 600 mA max @12V
 - O.CHART5F : 12W Average; 24W peak (with FF on)
- Power Supply : 10 - 35 Volt dc, 7Watt max
- Display : TFT LCD 5" vertical color sunlight
- Display Resolution : QVGA 320 x 240 pixels
- Cartography : C-MAP By JEPPESEN MAX DATA MEDIA
- MEDIA : SD Card
- Operating temperature range : 0/+55°C (32/+131°F)
- Memory : Non volatile
- Keyboard : Silicon rubber, backlight
- Weight
 - O.CHART5 : 580 gr.
 - O.CHART5F : 700 gr.

- Accessories :
 - Protective cover
 - Quick Disconnect Bracket
 - Flush mount template and kit
 - Fuse 2 Amp. + fuseholder (O.CHART5)
 - Fuse 3 Amp. + fuseholder (O.CHART5F)
 - User Manual


ONLY FOR O.CHART5F FF MODULE 600W-50-200KHZ TECHNICAL SPECIFICATIONS

- Power Output : 600W (4800Wpp), 50/200KHz Dual Frequency
- Max Depth : 213m (700Ft) at 200kHz, 457m(1500Ft) at 50kHz
- Automatic Recognition of the AIRMAR "X-DUCER ID" transducers for best performance
- Advanced Digital Signal Processing
- Speed & Temperature Sensor (if available on transducer)
- Alarms (shallow water, depth, Fish, temp)
- Trip Log, Fish Symbols
- STC, Interference Rejection, Automatic noise reduction
- A-scope, White Line, Zoom x2/x4
- Auto range/gain/frequency/shift/ping rate

INSERTING/REMOVING PROCEDURE

INSERTING MEDIA


Open the door, hold the MEDIA by the short side with the cut corner up. Gently push the MEDIA into the slot as far as it will go to hold fixed into the slot and close the door.




REMOVING MEDIA

To remove the MEDIA open the door, then press gently on the MEDIA and take it out from the slot.


DIMENSIONS



INSTALLATION




Flush mounting (on the left) and Bracket mounting (on the right)




Mounting Screws

EXTERNAL WIRING



External Wiring for O.CHART5




External Wiring for O.CHART5F

Note

The Active GPS Antenna must be used only if the Internal GPS doesn't work.

O.CHART7

O.CHART7F



TECHNICAL SPECIFICATIONS

- Power Consumption
 - O.CHART7 : 900 mA max @12V
 - O.CHART7F : 12W Average; 27W peak (with FF on)
- Power Supply : 10 - 35 Volt dc, 11Watt max
- Display : TFT LCD 7" landscape color sunlight
- Display Resolution : WVGA 800 x 480 pixels
- Video Input : PAL or NTSC video signals automatically selected
- Cartography : C-MAP By JEPPESEN MAX DATA MEDIA
- MEDIA : SD Card
- Operating temperature range : 0/+55°C (32/+131°F)
- Memory : Non volatile
- Keyboard : Silicon rubber, backlight
- Weight
 - O.CHART7 : 1150 gr.
 - O.CHART7F : 1310 gr.
- Accessories :
 - Protective cover
 - Quick Disconnect Bracket
 - Flush mount template and kit
 - Fuse 2 Amp. + fuseholder (O.CHART7)
 - Fuse 3 Amp. + fuseholder (O.CHART7F)
 - User Manual



ONLY FOR O.CHART7F FF MODULE 600W-50-200KHZ TECHNICAL SPECIFICATIONS

- Power Output : 600W (4800Wpp), 50/200KHz Dual Frequency
- Max Depth : 213m (700Ft) at 200kHz, 457m(1500Ft) at 50kHz
- Automatic Recognition of the AIRMAR "X-DUCER ID" transducers for best performance
- Advanced Digital Signal Processing
- Speed & Temperature Sensor (if available on transducer)
- Alarms (shallow water, depth, Fish, temp)
- Trip Log, Fish Symbols
- STC, Interference Rejection, Automatic noise reduction
- A-scope, White Line, Zoom x2/x4
- Auto range/gain/frequency/shift/ping rate

INSERTING/REMOVING PROCEDURE

INSERTING MEDIA


Open the door, hold the MEDIA by the short side with the cut corner up. Gently push the MEDIA into the slot as far as it will go to hold fixed into the slot and close the door.




REMOVING MEDIA

To remove the MEDIA open the door, then press gently on the MEDIA and take it out from the slot.


DIMENSIONS




INSTALLATION




Flush mounting




Bracket mounting



Mounting Screws




EXTERNAL WIRING



QUICK DISCONNECT BRACKET POWER & I/O CABLE		
WIRE COLOR	DESCRIPTION	FUNCTION
BLACK	POWER INPUT- (GND)	POWER SUPPLY GND
RED	POWER INPUT+ (10+35VDC)	POWER SUPPLY+
WHITE	INPUT 1+	NMEA0183/C-COM/BBFF/C-LINK/AIS
GREEN	SIGNAL GROUND	
YELLOW	OUTPUT 1+	NMEA0183/AUTOPILOT
BROWN	INPUT 2+	NMEA0183/C-COM/ BBFF/C-LINK/AIS
GRAY	OUTPUT 2+	NMEA0183/AUTOPILOT
ORANGE	NC	
PINK	NC	
BLUE	SIGNAL GROUND	

External Wiring for O.CHART7




External Wiring for O.CHART7F

Note

The Active GPS Antenna must be used only if the Internal GPS doesn't work.




Wiring Diagrams



HOTLINE ☎: 0825 000 150 coût 0,18€ TTC/min depuis un fixe


02/2010

Wiring/Câblage RO4800 – O₂CHART5 F



HOTLINE ☎: 0825 000 150 coût 0.18€ TTC/min depuis un fixe


02/2010



HOTLINE ☎: 0825 000 150 coût 0.18€ TTC/min depuis un fixe

02/2010

Wiring/Câblage RO4800 – O_oCHART7F




HOTLINE ☎ 0825 000 150 coût 0.18€ TTC/min. depuis un fixe

02/2010




Wiring/Câblage AIS RadioOcéan – O.CHART5/7/5F/7F DATA1



HOTLINE ☎: 0825 000 150 coût 0.18€ TTC par min.depuis un fixe

02/2010



Analytical Index

A

A-Scope	75
About page	94
Accessories	103, 107
Activation Range	64
Active Target	63
Active Track	58, 88, 96
Adding Mark	56, 92
Adding Waypoint	31, 52, 96
Advanced	96
AIRMAR	85
AIS	63
AIS Definitions	63
AIS Menu	64, 87, 89
AIS receiver	65
AIS Symbols	64
Alarm	23
Alarm Bar	74
Alarms Menu	83, 87, 94
Altitude	28
Anchor Alarm	47, 87
APB	91
Area of coverage	62
Arrival Alarm	47, 87
ASSISTANCE	15
Attention Areas	36, 39, 40, 92
Auto Info	42, 87, 95
Auto Off	47, 87
Automatic Info	42
Automatic Route Check	51, 94
Autopilot Connections	23
azimuth	28, 87

B

background charts	33
Backlight	100
BASICS	14
Bathymetric	32
BEACON	87
Bearing	30, 87
beep	15
Best Map	36
blinking lights	35
BOD	91
Bottom Echo Profile	76
Bottom Lock Zoom	79
Bottom Range	81
BRG	87
brightness	18, 21
BUOY	88
BWC	91

C

C-COM	23, 61, 100
C-COM Connections	23
C-COM modem	61
C-Link	66, 67, 88
C-LINK Menu	91
C-MAP By Jeppesen	13, 32
C-WEATHER	88
C-Weather Service	61

C-Weather Service Menu	61, 94
Cable Wiring	91
Calibrate Aux Temperature	83
Calibrate Sound Speed	83
Calibrate Water Speed	83
Calibrate Water Temperature	83
Cartography	103, 107
Cartridge	100
Caution	11, 12, 36
Caution Notice page	20
change active window	79
Change Picture Size	34
Changing Fuel values	50
Changing Speed values	50
Chart	26, 27, 28, 29
Chart Boundaries	40, 41, 93
Chart Language	20, 22, 95
Chart Lock	36, 40, 42, 93
Chart page	79, 88
chart plotter On	18
CLEAR	17, 77
Clear GOTO	18, 90
Clear Info	32
Clear View	32
COG	28, 88
Color (route)	94
Color (track)	88
Color Bar	74
Color Settings	82
Config Menu	58
Config Track Menu	88, 96
configuration	18
contrast	18, 21, 99
Coordinate Systems	88
Coordinates	47, 90
Course Over Ground	88
CPA	63
CPA Alarm	63, 64, 87
CPA Limit	63
create a Waypoint	31
Creating a Route	31
Cross Track error	97
Cruise	80
CURRENT	88
Currents Prediction	36, 91
CURSOR	18, 31, 54, 57
Cursor	15, 17, 47, 90
Cursor Control	24, 95
Cursor key	15, 17, 77, 78

D

Dangerous Target	64
Dangers	36
DATA	18, 55, 56, 58
Data Features	32
DATA MEDIA	23
Data Menu	18, 26, 50, 56
Data Off	36
Data page	25, 26
Data Safety Indicator	35

Databoxes Setup	56	DSC Icons	71
Date	95	DSC Log page	70
Date (simulation)	24	DSC Menu	70, 89
Date Format	21, 95	DSI	35
DATUM	88	DTG	89
Daylight Saving Time	21, 95	Dual page (FF)	78
Declutter	36	Dynamic Currents	32
Dedicated Key	89	Dynamic Nav-Aids	32, 35, 91
Deep Water	83	E	
DEFAULT	89	Echogram	75
Deleting all stored User Points	56	Echogram window	74
Deleting All Tracks	59, 88	Edit Mark	57, 92
Deleting all User Points	56	Edit Waypoint	96
Deleting File	60, 92	Elevation Data	33
Deleting Mark	57, 92	ENTER	17, 77
Deleting MOB	92	EVENT	89
Deleting Route	49, 94	External Alarm	23, 48, 87, 100
Deleting Selected Waypoint	56	External Alarm Connection	23, 48
Deleting Target	31, 32	EXTERNAL CONNECTIONS	23
Deleting Track	58	External NMEA	23
Deleting Waypoint	31, 56, 96	External NMEA Connections	23
Depth	28, 29, 36, 81	EXTERNAL WIRING	106, 110
DEPTH (page)	89	Extra Large Coverage	32
Depth + Altitude Units	95	F	
Depth Alarm	48, 87	FEATURES	13
Depth Area	36	FF MODULE	104, 108
Depth Graph	89	File	59, 89
Depth Graph Pages	28, 29	Find	32
DEPTH RANGE	89	FIND FUNCTION	44
Depth Range Max	39, 41, 93	Find Menu	89, 91
Depth Range Min	39, 41, 93	Finding Coordinates	47
Depth ruler	75	Finding Cursor	47
Depth Unit	20, 95	Finding Lakes By Name	46
Depths	32	Finding Lakes Information	45
DEVICES Menu	89, 94	Finding Mark	57, 92
DGPS	89	Finding Obstructions	45
Diagram	32, 33	Finding Points Of Interest	46
Differential Correction	90	Finding Ports By Distance	45
Differential GPS	89	Finding Ports By Name	45
Diffusers	40, 42, 51, 93	Finding Ports Services	44
Diffusion area	36	Finding Tide Stations	45
Digital Depth	74	Finding User Points	47
DIM Menu	99	Finding Waypoint	55, 56, 96
DIMENSIONS	105, 109	Finding Wrecks	45
Directory (DSC)	71, 89	First Setup Page menu	19, 20
Directory on MEDIA	60	Fish	80
Display	64, 103, 107	Fish Alarm	84
Display (AIS)	87	Fish Finder	18, 72, 73
Display Mode	39, 92	Fish Finder 200kHz	77
Display Mode (track)	88	Fish Finder Dual Frequency	78
Display Resolution	103, 107	Fish Finder Echogram	75
Display Setup Menu	82	Fish Finder Full page	77
Displaying Track	58	Fish Finder page	74
Dist & Speed Units	95	Fish Finder Setup Menu	80, 89, 90
Distance	30	Fish Finder transmission	73
Distance (track)	58	Fish Icons	83
Distance + Speed Units	95	Fish Symbols	82
Distance Step	88	Fishes	75
Distance To Go	89	Fishing Facility	36, 51
Distance Unit	20	Flexi-Zoom	33, 34
Distress Call	69	Focus Soft Key	79
Download	61, 88	Fonts & Symbols	34, 91
Download Area	62	Forecast	61, 62, 88
DPS	61	Format	92
DPT	91	Formatting MEDIA	60
Dredged Areas	36, 51	Frequency	81
DSC	69, 89	Fuel	50
DSC Directory page	71	Full Info	34

Full Info on Lakes	44	Language	20, 22, 26, 95
Functions	87	Last GoTo	18, 90
G		Lat/Lon	28, 91
Gain	82	Lat/Lon Grid	40, 41, 93
Gain Mode	80	LATITUDE	91
GGA	91	LCD Adjustment	19, 21, 94
GLL	91	LCD screen	21
Global Positioning System	90	List	91
GO TO	17, 30, 31, 54, 57	LIST (User Points)	91
Goto	54, 57, 95	List Menu	94
GOTO (menu)	90	Load From File	88
GoTo on Mark	92	Load Settings	84
GoTo on WPT	96	Loading File	60, 92
GPS	17, 28, 90	Log	59, 70, 96
GPS Page	47, 90	Log (DSC)	89
GPS SETUP (menu)	90	LONGITUDE	91
Grounding Alarm	48, 87	Lost Target	64
Grounding Alarm Range	48, 87	Low Water Temperature	84
Grounding Alarm Report	48, 87		
GSA	91	M	
Guardian Alarm	33	MAGNETIC DEVIATION	91
Guardian Technology	36	MAGNETIC VARIATION	91
H		Man OverBoard	92
HDG	48, 90, 91	Map Menu	18, 34, 91
HDOP	28, 48, 90	Map Orientation	30, 95
HDOP Alarm	48, 87	Map Resolution	30
Head Up	30	Map Rotor	19
Heading	24, 90, 95	MAP SETTINGS	39
Heading Alarm	48, 87	MARK	18, 57, 91
High Water Temperature	84	Mark	17, 56, 57, 90
Highway 3D	94	Marker Zoom	80
Home	17, 92	Master Chart Plotter	66
HOME (or Navigation)	90	MEDIA	23, 59, 60, 84, 92, 103, 104, 107, 108
Horizontal Dilution Of Precision	90	MEDIA (menu)	92
HSC	91	Memory	103, 107
Humidity	62, 63	MEMORY CARD	59
I		Memory Card Menu	92, 94
Info	17, 91	Mixing Levels	33, 35, 91
Info on Lakes	43, 44	MMSI	63, 71
Info on Mark	92	MOB	17, 67, 92
Info on Route	49	Modem C-COM	23, 100
Info on WPT	96	Modem Test	100
Info page	37	Mooring	51
Information on Mark	57	Mooring facilities	36
Information on Waypoint	55	Moving Mark	56, 92
Input/Output Menu	90, 94	Moving Waypoint	52, 96
Inserting MEDIA	104, 108	Multilanguage	32
Inserting MOB	92	MWV	91
Inserting Waypoint	54, 96	N	
INSTALLATION	105, 109	Name (ship)	63
Interference Rejection	81	Name Tags	39, 40, 92
Internal GPS Setup Menu	91	Nav-Aids	36
Intertidal Areas	36, 51	Nav-Aids & Light Sectors	40, 92
ISO Certification	32	Nav-Aids Presentation	21, 95
K		Navigate	17
Keel Offset	83	NAVIGATION	92
key	14, 17	navigation data	27
Keyboard	14, 17, 103, 107	Navigation Speed	90
Keypad Beep	21, 95	Night Vision (palette)	21
L		NMEA	50, 65
labelled key	14	NMEA input port	50, 56
Lakes	43	NMEA output port	50, 56
Lakes By Name	46, 89	NMEA-0183	23, 66
Lakes Info	43, 45, 89	NOAA (palette)	21
Lakes Information	45	Normal (palette)	21
Land	36	North Up	30
Land Areas	51	O	
Land Elevation	32, 39, 41, 93	O. Zoom	36
Land Elevation Values	39, 41, 93	Obstructions	36, 40, 42, 45, 51, 89, 93

Off-line redraw	33
Official data source	32
Operating Frequency	75
Operating temperature range	103, 107
ORIENTATION RESOLUTION	92, 93
Other Map Configurations	39
Other Map Configurations Menu	91, 92
over-zoom	36
P	
PAGE	18, 76
Page Selection menu	18, 76
Palette	18, 21, 36, 93
panoramic view	35
PC Planner	61
Perspective View	19, 33, 35, 91
Picture	33
PIN	62
Pingo	36, 51
Place Names	39, 40, 92
POI	39, 41, 93
Points Of Interest	46, 90, 93
Port By Distance	45, 89
Port By Name	45, 89
Port Info	32, 38, 93
Port Info icon	38
Port n Input	91
Port n Output	91
Port n Output Sentences	91
Port Plan	32
Port Services	18, 44, 89, 90
Ports & Services	39, 41, 93
Position Request	69
POWER	18
Power Consumption	103, 107
Power Supply	103, 107
powering On chart plotter	20
Presentation Features	32
Preset Mode	80
press a key	15
Primary Chart Plotter	65
PRN WAAS SATELLITE	90
Production Installations	36, 51
Q	
Quick Info	32, 34, 43, 65, 69, 71
R	
Radio Call Sign	63
RAM Clear	99
RAM Menu	99
Range Mode	81
Read (MEDIA)	92
Reading Directory	60
Real Time View	62, 88
Receive	91
Receive (route)	94
Receive Mark	57, 92
Receive Waypoint	56, 96
Receiving Route	50
Removing MEDIA	104, 108
Report (route)	94
reset partial distance	59
reset total distance	59
Resolution angle	30
Restart GPS	90
Restore Current Preset Defaults	84
Reversing Route	50
RMA	91
RMB	91
RMC	91

Roads	32, 39, 41, 93
Rocks	36, 40, 42, 51, 93
ROLLING ROAD	94
Rotor	19
ROUTE	18, 94
Route	31, 36, 49, 54, 66, 68, 90
Route Check	33, 51
Route Check Accuracy	51, 94
Route Check Report	51, 94
Route Color	50
Route Data Report	49, 56, 68
Route Depth	51, 94
route management	49
Route Menu	49, 94
Route Width	51, 94
Routes & Tracks	93
RTCM	94
RTE	50
S	
S/N ratio	28
Safe Route Checking	51
Safety Route Check	33
Safety Status Bar	35, 91
Safety Toolbar	33
Satellite Imagery	36, 91
Save & Load	84
Save Settings	84
Saving File	59, 92
screen brightness	21
Scrolling Speed	82
SD Card	103, 107
Seabed Type	39, 41, 93
Search	32
Secondary Chart Plotter	65
Select (route)	94
Select Country to Call	62
Select Route No.	96
Select Track No.	96
Selecting Track Color	58
Send	91
Send (route)	94
Send Mark	57, 92
Send Waypoint	56, 96
Sending Route	50
Sensitivity Menu	77, 81
Sensors	19
Sensors Calibration	19, 95
Serial Port	12, 23, 100
Set Default settings	83
SETTINGS (menu)	94
Settings menu	18
SETUP Menu	94
Shallow Water	51, 83
Shift	81
Shoreline Constructions	36, 51
Signal to Noise Ratio	95
SIM PIN	62
Simulation	74
Simulation Menu	94, 95
Simulation Mode	21, 24, 95
Slave Chart Plotter	67
Sleeping Target	64
Slider	19
Smooth-Zoom	33
SNR	28, 95
Soft Key	14, 18, 95
software key	14, 18, 19
SOG	28, 95

Sort By (MEDIA)	92
Sorting Directory	60
Special Functions	61
Speed	24, 50, 95
Speed Over Ground	95
Spot Soundings	32
Standard (zoom)	34
STC	77, 82
STC Length	82
STC Strength	82
Step Unit	88
Structures	76
Sunlight (palette)	21
Surface Clutter	76
Surface Noise Filter	77, 82
System Information page	15
System Test	15, 99
T	
Target	17, 30, 31, 54, 57, 63, 90, 95
TCPA	63
TCPA Alarm	63, 64, 87
TCPA Limit	63
TECHNICAL SPECIFICATIONS	103, 107
Telephone number	62
Temperature	62, 63
Temperature Unit	20, 95
Terms	87
Thermoclines	76
Tidal arrows	36
Tidal stream	40
Tide	37, 40, 95
Tide Graph	38
Tide Info	37, 95
Tide Stations	45, 89
Tides & Currents	39, 40, 92
Tides Preview	32
Time	24, 95
Time (track)	58
Time Format	21, 95
Time Reference	21, 95
Time Step	88
Time To Go	31, 32, 96
title page	20
Track	36, 58, 59
Track Color	58
Track memorizing type	58
Track Menu	94, 96
Track storing	58
Track To Route	59, 96
Track To Route Menu	96
Tracks & Routes	39, 41
transducer	84
Transducer Setup menu	83
Troubleshooting	101
True-Type Font	32
TTG	31, 32, 96
Turbo-Zoom	33
turn chart plotter On	18
Turning Off	20
Turning On	20
Type of Data	63, 88
TYPICAL CONNECTIONS	111
U	
U. Zoom	36
under-zoom	36
Underwater Objects Limit	40, 42, 93
Universal Time Coordinated	96
User Interface Language	22
User Point	55, 57, 96
User Points	47, 90
User Points List	55, 57
UTC	96
V	
VAD	41
Value-Added Data	40, 41, 93
Variable Depth Marker	75
VDM	75
VDOP	28
VIDEO (pages)	96
Video Input	107
Video Input Menu	96
VIDEO Pages	29
Video Test	100
View Waypoint on map	55
Visibility	62, 63
Visual COG Bar	95
VMD	65
voltage	20
VTG	91
W	
WAAS	96
WARNING	11
Warning Message	74
Warping Facility	51
Water Temperature	74, 83
Water Temperature Rate	84
Wave Data	62, 63
Waypoint	17, 31, 49, 51, 54, 55, 56, 96
WCV	91
Weather data package	61
weather forecast	61
Weight	103, 107
WGS-84	96
Wheater	62, 63
White Line	76, 82
Wind	62, 63
Wiring Diagrams	113
World Background	32
WPL	50
Wrecks	36, 40, 42, 45, 51, 89, 93
X	
XTE	47, 91, 97
XTE Alarm	47, 87
Z	
ZDA	91
Zoom	33, 35, 36
Zoom Bar	75
zoom factor	34
ZOOM IN	17, 34, 62, 77, 79, 96
zoom level	35
ZOOM MODES	79
ZOOM OUT	17, 34, 62, 77, 79, 97
Zoom Slider	19
Zoom Type	34, 91

FURUNO

Declaration of Conformity Déclaration de conformité Konformitätserklärung Declaración de conformidad



We / nous / Wir / nosotros

Furuno France
12 rue Laplace
33698 Mérignac Cedex (France)

Declare on our own responsibility that the finished product:
Déclarons sous notre propre responsabilité que le produit fini:
Erklären voll verantwortlich dass nachfolgendes Produkt:
Declaramos bajo nuestra sola responsabilidad que el producto mencionado a continuación:

Chart Plotter for Marine Navigation with internal GPS receiver Model Radio Ocean – O-CHART 5 & 7

Constituting the subject of this declaration conforms to the essential requirements and other relevant stipulations of the directives : 2004/108/EEC (EMC) + 1999/05/EEC (R&TTE).
Faisant l'objet de la présente déclaration, satisfait aux exigences essentielles et toute autre stipulation pertinente des directives : 2004/108/EEC (EMC) + 1999/05/EEC (R&TTE).
auf das sich diese Erläuterung bezieht, den grundlegenden Anforderungen und anderen relevanten Vereinbarungen der Richtlinie : 2004/108/EEC (EMC) + 1999/05/EEC (R&TTE).
Cumple los requisitos esenciales y las otras estipulaciones relevantes de las directivas : 2004/108/EEC (EMC) + 1999/05/EEC (R&TTE).

The product conforms to the following standards:
Le produit est conforme aux normes suivantes :
Das Produkt entspricht den folgenden Normen:
Es conforme a las siguientes normas:

Conducted emissions CEI EN 60945 (2002/10)	ETSI EN 301 489-1 V1.5.1 ETSI EN 301 489-19 V1.2.1
Radiated emissions CEI EN 60945 (2002/10)	ETSI EN 301 489-1 V1.5.1 ETSI EN 301 489-19 V1.2.1
Radiated interferences Radiated RF immunity	CEI EN 60945 (2002/10) ETSI EN 301 489-1 V1.5.1 ETSI EN 301 489-19 V1.2.1
Electrostatic discharge ESD	CEI EN 60945 (2002/10) ETSI EN 301 489-1 V1.5.1 ETSI EN 301 489-19 V1.2.1
Conducted radiofrequency interferences Conducted RF immunity	CEI EN 60945 (2002/10) ETSI EN 301 489-1 V1.5.1 ETSI EN 301 489-19 V1.2.1
Compass Safe Distance	CEI EN 60945 (2002/10) ISO/R 694
EFT – Bursts Fast Transients	CEI EN 60945 (2002/10)
DC Power Interruptions, Variation and Polarity inversion	CEI EN 60945 (2002/10)
Safety, Part 1: general requirements	CEI EN 60950 (2004)

We / nous / Wir / nosotros



RADIO OCEAN

Declare that **Radio Ocean** is a commercial brand, sole propriety of Furuno France.
Déclarons que la marque commerciale **Radio Ocean**, est la propriété exclusive de Furuno France.
Radio Ocean ist ein Markenzeichen von Furuno France. Sämtliche Markenrechte sind Eigentum von Furuno France.
Declaramos que la marca comercial **Radio Ocean**, es la propiedad exclusiva de Furuno France.

On behalf of Furuno France - Bordeaux, the 7th January 2010

Didier BUREAU
Managing Director