# SiS S-ATA User's Manual

Serial ATA Serial ATA RAID 0 or 1 Serial ATA JBOD

Quick User's Guide

Version 0.1

#### Edition

April 2003

## Copyright

### Trademarks

SiS is a registered trademark of Silicon Integrated Systems Corp.

All brand or product names mentioned are trademarks or registered trademarks of their respective holders.

## **Revision History**

Revision	History	Date
0.1	First release	May '03

## **CONTENTS**

Introduction	1
Step 0. What is RAID	
KNOW HOW	2
PERFORMANCE HINTS AND RECOMMEND SETTING	2
Step 1. Installing Software Drivers	
WINDOWS 2000/XP	3
NEW WINDOWS 2000/XP INSTALLATION	3
EXISTING WINDOWS 2000/XP INSTALLATION	4
CONFIRMING WINDOWS 2000/XP DRIVER INSTALLATION	4
Step 3. BIOS Utility Operation (for RAID only)	5
CREATING AN ARRAY FOR PERFORMANCE(RAID0)	6
CREATING A MIRROR ARRAY(RAID1)	8
CREATING A JBOD ARRAY	11
Step 4. SIS 180 RAID Utility Operation	14
VIEWING THE "CREATE RAID"	16
CREATE A RAID SET	18
VIEWING THE RAIDTYPE MEANING	24
DELETE A RAID SET	25
RAID RECOVERY OPERATION	27

## Introduction

The SiS 180 S-ATA/RAID controller is build-in the 964 south bridge. It combines two independent SATA ports and support RAID 0, RAID 1 and JBOD. Specifications are as follows:

#### Serial ATA Interface

Serial ATA (SATA) is the latest generation of the ATA interface. SATA hard drives deliver blistering transfer speeds of up to 150MB/sec. Serial ATA uses long, thin cables, making it easier to connect your drive and improving the airflow inside your PC.

- Supports 150 MB/s transfers with CRC error checking
- ◆ Large LBA support for drives over 137 GB
- Data handling optimizations including tagged command queuing, elevator seek and packet chain command

#### Serial ATA RAID Interfaces

The Serial ATA RAID is designed to provide a cost-effective, high performance RAID solution that adds performance and/or reliability to PC desktops and/or servers using Serial ATA/150 hard disks.

Serial ATA RAID function supports striping (RAID 0), mirroring (RAID 1) and span (JBOD). *Please note that the function supports* **SATA hard disk** *drives only*.

With striping, identical drives can read and write data in parallel to increase performance. Mirroring increases read performance through load balancing and elevator sorting while creating a complete backup of your files. Span would increase the logic hard disk space.

Serial ATA RAID striped arrays can double the sustained data transfer rate of Serial ATA/150. Serial ATA RAID fully supports Serial ATA/150 specification of up to 150MB/sec per drive, depending on individual drive specifications.

The technology also offers fault tolerant, data redundancy for entry-level network file servers or simply for desktop PC users wanting to continually protect valuable data on their PC. The Serial ATA RAID offers RAID 1 mirroring (for two drives) to protect data. Should a drive that is part of a mirrored array fail, Serial ATA RAID technology uses the mirrored drive (which contains identical data) to assume all data handling. When a new replacement drive is later installed, Serial ATA RAID rebuilds data to the new drive from the mirrored drive to restore fault tolerance.

## Step 0. What is RAID

#### Know How

This section will give you an overview about the RAID system and introduce the basic background and glossary which you need to know before using "SiS 180 RAID Controller Application".

- 1. **RAID**: (Redundant Array of Independent Disk Drives) use jointly several hard drives to increase data transfer rates and data security. It depends on the number of drives present and RAID function you select to fulfill the security or performance purposes or both.
- RAID 0: Also known as "Stripping". All of the data are distributed evenly to all of the existing drives. You gain benefits on performance because the data transfer rate is multiplied by the number of drives. However, RAID 0 has high risks of data security. All of the stored data will be lost if even any one drive in the RAID set crashes.
- 3. **RAID 1**: Also known as "Mirroring". Two hard drives are required. The goal of RAID 0 is to ensure data security. Data is written to two or more drives synchronously. That is, 100% duplication of data from one drive to another.
- 4. **JBOD**: (Just a Bunch of Drives). Also known as "Spanning". Two or more hard drives are required. Several hard disk types configured as a single hard disk. The hard drives are simply hooked up in series. This expands the capacity of your drive and results in a useable total capacity. However, JBOD will not increase any performance or data security.

## Performance hints and recommend setting

For the best performance and reliability, please read the following suggestions.

- 1. In serial ATA port, use Native serial ATA drives. Parallel ATA to Serial ATA converter board is *NOT* suggested.
- 2. Use the same model hard drives.
- 3. We strongly recommend you should use "DMA" transfer mode.

2

4. The recommended block size is 64K when creating RAID 0.

## Step 1. Installing Software Drivers

SiS provides Mini IDE driver for SiS180 SATA function and RAID driver for SiS180 SATA with RAID function.

SiS Mini IDE driver for Windows 2000/XP

SiS RAID driver for Windows 2000/XP

- 1. For SATA function, both of Mini IDE driver and RAID driver support SATA.
- For RAID function, SiS180 support RAID0, RAID, RAID0+1 and JBOD by software RAID driver only.

For special occasions, users can refer to the following section with details on the SiS180 driver installation when used with various operating systems.

### Windows 2000/XP

#### New Windows 2000/XP Installation

The following details the installation of the drivers while installing Windows 2000/XP.

1. Start the installation:

Boot from the CD-ROM. Press F6 when the message "Press **F6** key if you need to install third party SCSI or RAID driver" appears.

- 2. When the Windows 2000/XP Setup window is generated, press **S** key to specify an Additional Device(s).
- 3. Insert the driver diskette into drive A: and press Enter.
- 4. Choose one of the following items:

"WinXP SiS Raid/IDE Controller " (for RAID),

"WinXP SiS Mini IDE Controller" (for SATA),

"Win2000 SiS Raid/IDE Controller" (for RAID),

*"Win2000 SiS Mini IDE Controller"* (for SATA) that appears on screen, and then press the Enter key.

- Press Enter to continue with installation or if you need to specify any additional devices to be installed, do so at this time. Once all devices are specified, Press Enter to continue with installation.
- 6. From the Windows 2000/XP Setup screen, press the Enter key. Setup will now load all device files and then continue the Windows 2000/XP installation.
- 7. Please install the driver package again (ex. SiS RAID driver v1.00) while the operation system has been setup.

#### Remark:

If you would like to install windows to any RAID set, you should create RAID from BIOS utility first and then follow the steps above.

#### Existing Windows 2000/XP Installation

- 1. Install the driver by execute SiS driver setup utility.
- 2. The drivers and WinXP RAID utility will be automatically installed.

#### Confirming Windows 2000/XP Driver Installation

- 1. From Windows 2000/XP, open the Control Panel from "My Computer" followed by the System icon.
- 2. Choose the "Hardware" tab, then click the "Device Manager" tab.
- Click the "+" in front of "SCSI and RAID Controllers" hardware type. The driver "WinXP SiS180 Raid Controller" (for RAID) or "Win2000/XP SiS180 IDE Controller" (for SATA) should appear.


# **Step 3. BIOS Utility Operation (for RAID only)**

**Note:** For the best performance and reliability, please read "Performance Hints and Recommend Setting" section in *Step 0* 

 Boot your system. If this is the first time you have booted with the SIS 180 and the drives installed, the onboard BIOS will display the following screen.

Silicon Integrated Systems Corp. RAID Card BIOS Setting Utility 1.00.0.XX (c) 2003-2006 Silicon Integrated Systems Corp. All Rights Reserved. Press <Ctrl><S> to run BIOS Setting Utility

- 2. Press <Ctrl-S> keys to display the SIS180 Utility Main Menu.
- 3. Press "R" to display the RAID setup menu below. This is the fastest and easiest method to creating your first array.



Copyright (c) 2003-2005. Silicon Integrated Systems Corp | www.sis.com

## Creating an Array for Performance(RAID0)

**NOTE:** SIS 180 enables users to create striped(RAID0) arrays with 1, 2 drives.

To create an array for best performance, follow these steps:

1. Press "A" to create array .

Press <a> key to add disk to RAID, and press <d> key to remove disk from RAID         Q : Exit the menu         Location       Model       Capacity       Mode       RAID Type         Pri       Master       WDC AC310200R       9787MB       UDMA 4       Single*         Pri_Slave       QUANTUM FIREBALL       9787MB       UDMA 4       Single         See_Master       Maxtor 6Y060M0       58644MB       UDMA 6       Single         Sec_Slave       ST3120023AS       114473MB       UDMA 6       Single</d></a>		Disk S	tatus —					
Location         Model         Capacity         Mode         RAID         Type           Pri_Master         WDC AC310200R         9787MB         UDMA 4         Single*           Pri_Slave         QUANTUM FIREBALL         9787MB         UDMA 4         Single           Sec_Master         Maxtor 6Y060M0         58644MB         UDMA 6         Single	and press <d> key to remove disk from RAID</d>							
Pri Slave QUANTUM FIREBALL 9787MB UDMA 4 Single Sec_Master Maxtor 6Y060M0 58644MB UDMA 6 Single			Capacity	Mode F	RAID Type			
	Pri_Slave	QUANTUM FIREBALL	9787MB	UDMA 4	Single			

2. Press <2> and <Enter> to select Stripe .



3. Press <1>---<7> keys and <Enter> to select Block Size. ( Default : 32K )



Press <1>—<2> keys and <Enter> to select Transfer Mode. ( Default : DMA )

Stripe Transfer Mode: <1> PIO <2> DMA : 2

5. Use<  $\uparrow><\downarrow>$  to select disk , and press <Enter> to select disk, <Q> to exit.

Stripe Use 1↓ to select disk,and press <enter> to select disk Q : Exit the menu</enter>	
Q : Exit the menu	
Location Model Capacity Mode RAID Ty	ре
Pri_Master WDC AC310200R 9787MB UDMA 4 Single	*
Pri_Slave QUANTUM FIREBALL 9787MB UDMA 4 Single	
Sec Master Maxtor 6Y060M0 58644MB UDMA 6 Single	
Sec Slave ST3120023AS 114473MB UDMA 6 Single	

6. Press <N> and <Enter> to Create Stripe only. (If Press <Y> and <Enter>, it will split the data on source disk to other disks)

Sis RAID	Card BIOS Setting Utility ————————————————————————————————————	
	Stripe Do you want to Split the SOURCE disk data to other disks?N Q : Exit the menu	
	Location Model Capacity Mode RAID Type	
	Pri_Master       WDC AC310200R       9787MB       UDMA 4       Stripe*         Pri_Slave       QUANTUM FIREBALL       9787MB       UDMA 4       Single         Sec_Master       Maxtor 6Y060M0       58644MB       UDMA 6       Stripe         Sec_Slave       ST3120023AS       114473MB       UDMA 6       Single	
Copyright	: (c) 2003–2005. Silicon Integrated Systems Corp   www.sis.com	

7. Press <Q> until escape the setup menu

RAID	Card BIOS Se	tting Utility	Status —		
	Stripe: Di	sk 1 Disk3	Status —		
		7 to add disk to RAID, • key to remove disk fron			
	Q : Exit t		IKAID		
	Location	Model	Capacity	Mode RAID T	уре
	Pri_Master	WDC AC310200R	9787MB	UDMA 4 Stripe	*
	Pri_Slave	QUANTUM FIREBAL	L 9787MB	UDMA 4 Single	
	Sec_Master	Maxtor 6Y060M0	58644MB	UDMA 6 Stripe	
	Sec_Slave	ST3120023AS	114473MB	UDMA 6 Single	
L					
		05. Silicon Integrat			

8. Press <Y> and <Enter> to save changes.

Stripe: Di	sk 1 Disk3	tatus —			
B : \$ R : E	Do You Want to Save	changes?N			
Q : E	Model	Capacity	Mode	RAID Type	
Pri_Master Pri_Slave Sec_Master	WDC AC310200R QUANTUM FIREBALL Maxtor 6Y060M0	58644MB	UDMA 4 UDMA 4 UDMA 6	Single Stripe	
Sec_Slave	ST3120023AS	114473MB	UDMA 6	Single	

9. Once the array has been created, you will need to FDISK and format the array as if it were a new single hard drive.

## Creating a Mirror Array(RAID1)

To create an Mirror array(RAID1) , follow these steps:

1. Press "A" to create array .

		———— Disk S	tatus 🥮			]
		y to add disk to RAID, • key to remove disk from F	AID			
	ESC: Exit t	he menu				
	Location	Model	Capacity	Mode F	AID Type	
	Pri_Master Pri_Slave	WDC AC310200R QUANTUM FIREBALL	9787MB 9787MB	UDMA 4 UDMA 4	Single* Single	
	Sec_Master Sec_Slave		58644MB 114473MB	UDMA 6 UDMA 6	Single Single	
L						

2. Press <3> and <Enter> to select Mirror.



3. Use<  $\uparrow><\downarrow>$  to select disk , and press <Enter> to select disk, <Q> to exit.

S RAID Card	BIOS Set	ting Utility ————————————————————————————————————	tatus —					
Use	Mimror Use î↓ to select disk,and press <enter> to select disk O : Exit the menu</enter>							
Loc	ation	Model	Capacity	Mode UDMA 4	RAID Type			
Pri Sec	<u>Master</u> Slave Master Slave	WDC AC310200R QUANTUM FIREBALL Maxtor 6Y060M0 ST3120023AS	9787MB 9787MB 58644MB 114473MB	UDMA 4 UDMA 6	Single Single			
vright (c)	2003-200	5. Silicon Integrate	d Systems C	orp	WWW.sis.c	.om		

4. Press <N> and <Enter> to Create Mirror only. (If Press <Y> and <Enter>, it will Duplicate the data on source disk to mirror disk)

SIS RAID	Card BIOS Set	ting Utility ————————————————————————————————————	tatus —				
Mirror Do you want to Duplicate the SOURCE disk data to MIRROR disk?N Q : Exit the menu							
	Location	Model	Capacity	Mode	RAID Type		
	Pri_Master Pri_Slave Sec_Master Sec_Slave	WDC AC310200R QUANTUM FIREBALL Maxtor 6Y060M0 ST3120023AS	9787MB 9787MB 58644MB 114473MB	UDMA 4 UDMA 4 UDMA 6 UDMA 6	Single Mirror		
Copyright	: (c) 2003-200	5. Silicon Integrated	d Systems (	Corp	WWW.Sis.com		

5. Press <Q> until escape the setup menu

SiS RAID	Card BIOS Se	tting Utility	Disk Status —					
	Mirror: Di	sk 1 Disk3	DISK Status —					
		y to add disk to R⊿ > key to remove di						
	Q : Exit the menu							
	Location	Model	Capacity	Mode R	AID Type			
	Pri_Master	WDC AC31020			Mirror*			
		QUANTUM FI			Single			
	Sec_Master				Mirror			
	Sec_Slave	ST3120023AS	114473M	B UDMA 6	Single			
Copyright	(c) 2003-20	05. Silicon In	tegrated Systems	Corp	www.sis.co	m		

6. Press <Y> and <Enter> to save changes.

Mirror: Di	sk 1 Disk3			
B · S				
B : S R : E	Do You Want to Save	changes?N		
Q : E				
Location	Model	Capacity	Mode I	RAID Type
Pri_Master	WDC AC310200R	9787MB	UDMA 4	Mirror*
Pri_Slave	QUANTUM FIREBALL	9787MB	UDMA 4	Single
Sec_Master	Maxtor 6Y060M0	58644MB	UDMA 6	Mirror
Sec_Slave	ST3120023AS	114473MB	UDMA 6	Single

7. Once the array has been created, you will need to FDISK and format the array as if it were a new single hard drive.

## Creating a JBOD Array

To create an JBOD array , follow these steps:

1. Press "A" to create array .

	> key to add disk to RA s <d> key to remove disl</d>			
Q : E	it the menu			
Locatio	n Model	Capacity	Mode	RAID Type
Pri_Mas	ter WDC AC310200	)R 9787MB	UDMA 4	
Pri_Slav	e QUANTUM FIR	EBALL 9787MB	UDMA 4	
Sec_Ma	ster Maxtor 6Y060M	0 58644MB	UDMA 6	
Sec_Sla	ve ST3120023AS	114473MB	UDMA 6	Single

2. Press <1> and <Enter> to select JBOD.





Press <1>—<2> keys and <Enter> to select Transfer Mode. ( Default : DMA )

4. Use<  $\uparrow><\downarrow>$  to select disk , and press <Enter> to select disk, <Q> to exit.

SiS RA	ID Card BIOS Se	etting Utility				
		— Disk S	Status —			7
	JBOD					
	Use 1↓ to s	elect disk,and press	<enter> to</enter>	select d	disk	
	O : Exit	the menu				
			· · · ·			
	Location	Model	Capacity	Mode	RAID Type	
	Pri_Master	WDC AC310200R	9787MB	UDMA 4		
	Pri_Slave	QUANTUM FIREBALI		UDMA 4		
	Sec_Master	Maxtor 6Y060M0	58644MB	UDMA 6		
	Sec_Slave	ST3120023AS	114473MB	UDMA 6	5 Single	

Copyright (c) 2003-2005. Silicon Integrated Systems Corp | www.sis.com

5. Press <Q> until escape the setup menu

JBOD: Di	sk 1 Disk3	isk Status 💻		
	y to add disk to RAⅡ > key to remove disk			
Q : Exit t	he menu			
Location	Model	Capacity	Mode	RAID Type
Pri_Master	WDC AC310200F	R 9787MB	UDMA 4	JBOD*
Pri_Slave	QUANTUM FIRE	BALL 9787MB	UDMA 4	Single
Sec_Master	Maxtor 6Y060M0	58644MB	UDMA 6	5 JBŌD
Sec_Slave	ST3120023AS	114473MB	UDMA 6	5 Single

6. Press <Y> and <Enter> to save changes.

1	2
1	


JBOD: Di	sk 1 Disk3			
B : S				
R : E	Do You Want to Save	changes?N		
Q : E				
Location	Model	Capacity	Mode	RAID Type
Pri_Master	WDC AC310200R	9787MB	UDMA 4	JBOD*
Pri_Slave	QUANTUM FIREBALL	9787MB	UDMA 4	Single
Sec_Master	Maxtor 6Y060M0	58644MB	UDMA 6	JBOD
Sec_Slave	ST3120023AS	114473MB	UDMA 6	Single

7. Once the array has been created, you will need to FDISK and format the array as if it were a new single hard drive.

## Step 4. SIS 180 RAID Utility Operation

**Note:** For the best performance and reliability, please read "Performance Hints and Recommend Setting" section in *Step 0.* 

 After installing the SiS RAID utility, go to "Start" menu and choose "Programs." From the "Programs" menu, choose "SiS RAID Utility" and click on "SiSRaid"



2) The SiS RAID Utility window opens as below. The main interface has two tabs: View and Configuration. You can switch to different tabs by clicking on it. On "View" tab, we can see some device information. The default value is the information of the first device.



ew Configuration Present Physical Devices IDE/ATAPI CD-ROM	
ST340016A ST3120023AS	
Physical Device Information	
ltem s	Device Information Description
Location	Primary Channel, Master
Serial Number	
Device Capacity	<u>0.0 G</u>
Device Type	CDROM
Device Support Transfer Mode	UDMA mode 2 and below is supported
Device Current Mode	UDMA 0
Device Status	
Array Mode	
Array Block Size	<u>2</u>

 Click the tab "configuration", you can find three tabs: Create Raid, Delete Raid and Raid Recovery. In the same way, you can switch to different tabs by clicking on it.

Raid Type :	▼ Block Size :	64K 💌	Mode : DMA	•
Available Disks >				
	i (Primary_Slave -2) 8 G (Secondary_Master -3)	ı		
	Ţ			
Selected Disks >				

 Click the tab "Create Raid", you can find three drop-down box and three panes. Those meaning will be showing below.

## Viewing the "Create Raid"

a) Raid Type: Click the drop-down box "Raid Type". This box enables the user to select array type. There are four array types that the user can select: JBOD, RAID 0, RAID 1. User can select any one array type to create a RAID set.

(Available Disks >	ile Configurat reate Raid Dele Raid Type :		Block Size :	Mode :	
	QUANTUM FIR	RAID 0 RAID 1		sr -1 )	
	Selected Disks >		4	1	

b) Block Size: If user selected RAID 0 array types in the "Array Type" box, the "Block Size" drop-down box will be enabled and user must select a block size. Clicking the drop-down box "Block Size", there are seven block size that the user can select: 8k, 16k, 32k, 64k, 128k, 256k and 512k. User can select any one block size to create a RAID 0 set. The default selection is 64k.

SIS Raid	
File Configuration Create Raid Delete Raid Raid Recovery	
Raid Type : Block Size : < Available Disks > QUANTUM FIREBALLP AS20.5 19.1 G ( Primary ST340016A 37.3 G ( Primary_Slave -2 )	Mode :         V           8k         15k           15k         5k           32k         64k           128k         258k           512k         512k
< Selected Disks >	
Information :	Create

c) Mode Type: Click the drop-down box "Mode Type". This box enables the user to select mode type. There are two mode types that the user can select: PIO and DMA. User can select any one mode type to create a RAID set. The default selection is DMA.

🏶 SIS Raid			_ 🗆 🛛
File Configuration Create Raid Delete Raid Rai	d Beenverel		
Raid Type : < Available Disks >	Block Size : 20.5 19.1 G (Primary_)	▼ Mode : Aaster -1 )	PIO DMA
< Selected Disks >	4	1	
Information :			Create

d) Available Disks: This pane will list out all the disks that can be used to create a RAID set currently. It will show some disk information (ex. Location, serial numbers, the ability of boot and the status of recovering).

SIS Raid File Configuration Create Raid Delete Raid Raid	Recovery		
Raid Type :	Block Size :	▼ Mode :	•
		HD>	
Selected Disks >	ł		
Information :			Create

- e) Selected Disks: This pane will list out all the disks that have been selected to create a RAID set. User can highlight the specific disk that we wants in the "Available Disks" pane and click the downward arrow icon or double click the marked disk to select that disk into the "Selected Disks" pane. In the same way, user can click the upward arrow icon or double click the marked disk in the "Selected Disks" to get back the disk that we might select wrong to the "Available Disks" pane.
- f) Information: This pane will show the information about creating a RAID set after clicking the button "Create". The information may be "Please select the <Raid Type> first!", "Please select the <Mode Type> first!", "Please select the <Block Size> first!", "Please select the disk you want first!", "Mirror supports TWO DISKS only.", , "Raid Created successful! Reboot please!!" or "Raid Creation failed!".

Information :	Please select the <raid type=""> first!</raid>		Create
<u> </u>		· · · · · · · · · · · · · · · · · · ·	

## Create a RAID set

- a) To create a JBOD array, follow these steps:
  - 1. "Configuration"  $\rightarrow$  "Create Raid"  $\rightarrow$  "Raid Type"  $\rightarrow$  JBOD.
  - 2. From the drop-down box "Mode Type", select the mode type you want.

File	Raid Configuration				
Creat	e Raid Delete Rai	d Raid Ree	covery		
ſ		D +	Block Size :	 Mode :	MA

 From the "Available Disks" pane, select the disk and click downward arrow icon or double click it to add the disk on the "Selected Disks" pane.

Raid Type :	JBOD	▼ Block Size :	*	Mode :	DMA 💌
QUANTUM F	s > IREBALLP AS20.6	i 19.1 G (Primary	_Master-1) <boot< th=""><th>able HD&gt;</th><th></th></boot<>	able HD>	
Selected Disks	•>	•			
	S 111.8 G (So 37.3 G (Prim	condary_Slave -4 ) ary_Slave -2 )			

NOTE: You must have at least two hard disks to create a JBOD array.

.

4. When the JBOD array's configuration is finished, click the button "Create". Then a warning message will be popup. Pay attention to the warning message, and then click "Yes" button to finish the creation of JBOD array, or click "No" button to cancel.


SiS Soft	ware RAID
!	If you want to create this RAID, all data on the disks you selected will be lost! Are you sure to continue?
	Yes No

**NOTE:** If the disk you selected has the ability of booting, another warning message will be popup before "SiS Software RAID" message. You can click "Yes" button to continue or click "No" button to cancel.



5. Next, another message box will be popup to tell user that disk setting has been changed and ask whether to restart the computer or not. Click "Yes" button to restart the computer or click "Cancel" button to skip restarting.

You have changed the disks setting! Do you want to restart the windows now?	Confirm	X
	2	You have changed the disks setting!
OK Careal	~	Do you want to restart the windows now?
		OK Cancel



- b) To create a RAID 0 (Stripe) array, follow these steps:
  - 1. "Configuration"  $\rightarrow$  "Create Raid"  $\rightarrow$  "Raid Type"  $\rightarrow$  RAID 0.
  - 2. From the drop-down box "Block Size", select the block size you want.
  - 3. From the drop-down box "Mode Type", select the mode type you want.
  - 4. From the "Available Disks" pane, select the disk and click downward arrow icon or double click it to add the disk on the "Selected Disks" pane.

C	Raid Type :		- Block S	ize : 64K	•	Mode : DM	A 💌
	railable Disks QUANTUM FI	> REBALLP AS2	0.5 19.1 G (	Primary_Master	r-1) <bootabl< th=""><th>le HD&gt;</th><th></th></bootabl<>	le HD>	
			4		<b>a</b>		
100	lected Disks	216 -	imary_Slave -2 )				
	ST3120023A5		Secondary_Slave	e -4 )			

NOTE: You must have at least two hard disks to create a RAID0 array.

5. When the RAID0 array's configuration is finished, click the button "Create". Then a "Create Stripe RaidSet" dialog will be popup.

Source :	QUANTUM FIREBALLP AS	20.5 19.1 G (Prima	y_Master -1 )	
Target :	ST340016A 37.3 G (P	rimary_Slave -2 )		
	1			
	Only C Split data (Boot fo		oot form 180) OK	Cancel

#### <Note>

Source: The first selected disk.

Target: All other disks but first one.

- Create Only: This operation will destroy all data on all the selected disks and create a clean stripe array without any data on it.
- Split data (Boot from IDE): Split operation will split data from source disk into all the selected disks. In this operation, the boot disk can't be placed on 180.
- Split data (Boot from 180): This operation is similar to "Split data into Raid0" operation, but system boots from 180.

Ok: Start the operation.

Cancel: Cancel the operation.

<Disk Copy Remaining Sector>: Show the remaining splitting data.

NOTE: miniCapacity x N > SourceCapacity miniCapacity: The minimum size of all selected disks. SourceCapacity: The size of source disk. N: Total disk numbers.

- 6. Next, you can click "Cancel" button to leave or click "Ok" button to continue after the operation being selected. The differential warning messages will be popup following the differential operations. The warning messages are similar to JBOD array creation but the operation is "Split data into Raid0".
- 7. If the operation is "Split data into Raid0", a warning message will be popup, seeing below:

♪	If you want to create this RAID, all data on the source disk will be split into Raid0 set ! If the source disk is your BOOT device, the system will be broken ! Are you sure to continue?
	Yes No

Next, you can click "Yes" button to start the operation or click "No" button to cancel.

8. When the operation is finished, the restart warning message will be popup as well as JBOD array creation except for the operation "Split boot OS into Raid0".

Confirm	l.		×
2	Spliting OS will b	e executed afte	r restarting!
~	Do you want to	restart the wind	ows now?
	ОК	Cancel	

Next, you can click "Ok" button to restart the windows and start the operation "Split boot OS into Raid0". Or click "Cancel" button to suspend this operation. But, this operation is still done after restarting the windows next time.

- c) To create a RAID 1 (Mirror) array, follow these steps:
  - 1. "Configuration"  $\rightarrow$  "Create Raid"  $\rightarrow$  "Raid Type"  $\rightarrow$  RAID 1.
  - 2. From the drop-down box "Mode Type", select the mode type you want.
  - From the "Available Disks" pane, select the disk and click downward arrow icon or double click it to add the disk on the "Selected Disks" pane.

Available Disks >	Sector Sector	Mode	: DMA 🔻
QUANTUM FIREBALLP A	520.5 19.1 G (Primary_	Master-1) <bootable hd=""></bootable>	
Selected Disks >			
ST340016A 37.3 G (	Primary_Slave -2 )		
ST3120023AS 111.8 G			

NOTE: The RAID1 array supports two hard disks only.

4. When the RAID1 array's configuration is finished, click the button "Create". Then a "Create Mirror RaidSet" dialog will be popup.

Disk				
Source :	ST340016A 37.3 G	( Primary_Slave -2 )		
Target :	ST3120023A5 111.8 0	G (Secondary_Slave -4)		
0.0	Create Only C Cre	ate and Duplicate	ок	Cancel
<disk (<="" td=""><td>Copy Remaining Sectors&gt;</td><td></td><td></td><td></td></disk>	Copy Remaining Sectors>			

#### <Note>

Source: The first selected disk.

Target: The second selected disk.

- Create Only: This operation will destroy all data on all the selected disks and create a clean mirror array without any data on it.
- Create and Duplicate: Duplicate operation will reserve data on the source disk and copy them onto the target disk.

Ok: Start the operation.

Cancel: Cancel the operation.

<Disk Copy Remaining Sector>: Show the remaining copying data.

2	0
2	J

- 5. Next, you can click "Cancel" button to leave or click "Ok" button to continue after the operation being selected. The warning messages will be popup following the differential operations and the message is similar to JBOD array creation.
- 6. When the operation is finished, the restart warning message will be popup as well as JBOD array creation.

## Viewing the RaidType meaning

General case: RAID0 (A = B C | D E)

<Meaning>

RAID0: Raid Type

- A: total number of disks in this Raid
- B,C: the serial number of each disk in this Raid
- D,E: a) Raid is correct, B=D C=E
  - b) Raid is error, D or E will show "?" or "!".

In which, the meaning of "?" and "!" will show below.

Sraid	
	This RAID is error!! Check the condition of your HD please!!
	<illustration> :</illustration>
	?: No HD exist at this position or this HD is not a part of this RAID!! !: This HD is a part of this RAID but its position is wrong!!
	ОК

<Example>



te Raid Delete Raid Raid Recovery	
30D (2 = 1 3   ! 3) AID0 (2 = 2 4   ? 4)	Information
	Delete
AIDTYPE INFORMATION ILLUSTRATION	<hd information=""></hd>
RaidType :	
BlockSize :	
HodeType:	

<Showing its information>

e Raid Delete Raid	Raid Recovery	
rent RaidType >		
IOD (2 = 1 3   ! 3) AIDO (2 = 2 4   ? 4)		Inform ation
		Delete
AIDTYPE INFORMATIC		
	You use 2 hard disks to do this ! List be	low :
	(	
RaidType : JBOD BlockSize :	(!: Wrong Position HD_P: Present Posi !: QUANTUM FIREBALLP AS20.5 19 3: ST3120023AS 111.8 G	

## Delete a Raid set

a) To delete a JBOD, RAID0 or RAID1 array, follow these steps:

1. "Configuration"  $\rightarrow$  "Delete Raid", the following windows will appear:

rent RaidType >	
D0 (2 = 2 3   2 3)	Inform ation
	Delete
IDTYPE INFORMATION ILLUSTRATION	NFORMATION>
aidType :	

2. Highlight the disk array in the "Current RaidType" pane, and then click the "Information" button or double click the array. You can get some information about the disk array.

e Raid Delete Raid	Raid Recovery	
rrent RaidType >		
ID0 (2 = 2 3   2 3)		Inform ation
		Delete
AIDTYPE INFORMATIC	N ILLUSTRATION <hd information=""></hd>	
AIDTYPE INFORMATIC		w :
RaidType : RAID 0	<hd information=""> You use 2 hard disks to do this ! List beline (!: Wrong Position HD_P: Present Positi 2 : \$7340016A 37.3 G</hd>	
	<hd information=""> You use 2 hard disks to do this ! List beling ( !: Wrong Position HD _ P: Present Position HD _ P: P: Present Position HD _ P: P: Present Position HD _ P: P:</hd>	

3. If you want to delete a disk array you selected, you can highlight the disk array and then click the button "Delete". Then a warning message will be popup, and pay attention to the warning message. You can click "Yes" to delete the selected disk array or click "No" to cancel.

Confirm	X
⚠	Do you confirm that you want to delete this RaidType?
	Yes No

4. Next, another message will be popup to tell user the setting of these disks have been changed and ask whether to restart the computer.

Confirm		
?		nged the disks setting! restart the windows now?
	ОК	Cancel

## Raid Recovery Operation

- **NOTE:** The recovering operation is workable only when error RAID1 set or error RAID0+1 set (must at least an error RAID0 set) exist.
- a) First, you can click the button "Available Raid" to find whether any error Raid set existing. See below:

Available	RAID
Raid1 (? 4)	
ок	Cancel

Next, highlight the error Raid set you want to recovery. And you can click the button "Ok" to continue or click "Cancel" to cancel this operation.

b) After "Available RAID" selected, click the button "Available Disk" to find whether any empty hard disk existing. See below:

2	7
2	1

Available Disk	
QUANTUM FIREBALLP AS20.5 ST3120023AS 111.8 G	19.1 G
ок	Cancel

Next, highlight the empty hard disk you want to select. And you can click the button "Ok" to continue or click "Cancel" to give up this selection.

c) When the "Available Raid" and "Available Disk" is finished, you can click the button "Start" to start this operation. And the button "Start" will become "Pause". Then you can click the button "Pause" to pause the thread operation. And the button "Pause" will become "Start". Or you can click the button "Stop" to cancel this operation.

SOURCE	DESTINATION
Raid1 (? 4)	ST3120023AS 111.8 G
Availabe Raid	Available Disk
Copy data form Disk 4 to Disk 3	Disk Copy Remaining Sectors = 75691056