

# **Wireless Handheld Keyboard and Mouse Touchpad**

## **User Manual**

**Rev. 1.4**

## **Using Wireless Handheld Keyboard and Mouse Touchpad**

This section explains what you can do with a Wireless Handheld Keyboard and Mouse Touchpad. How it works and what the benefits are to the purchaser.

The Wireless Handheld Keyboard and Mouse Touchpad is a unique and capable tool for people who need to be apart from their personal computer yet must control it for presentations, lecturing, teaching or casual viewing of internet content, be they network television, Internet movies or other Internet content. The Wireless Handheld Keyboard and Mouse Touchpad provides a powerful solution for Remote PC Operation. First to resolve any confusion this unit does not operate or control your TV or your projector.

It operates your PC from a distance up to 33' away. That is its sole function and purpose.

But you should understand that the ability to operate your PC from this distance offers you access too many conveniences that make using the PC in certain applications far more enjoyable than is otherwise available to the user.

## **What's in your Package?**

In the package with Wireless Handheld Keyboard and Mouse Touchpad you will find a USB transceiver, a USB cable for charging the Wireless Handheld Keyboard and Mouse Touchpad and this manual.

## **Features:**


Wireless Handheld Keyboard and Mouse Touchpad has been designed for the "33 feet Interface": it should be driveable from anywhere within a 33 feet radius.

This handheld unit is a compromise between functionality, simplicity and usability that strikes at the heart of many of the Personal Computer's deficits regarding remote/wireless operation. For years the powerful personal computer has under achieved in usability and media convenience. Now with the Wireless Handheld Keyboard and Mouse Touchpad users will enjoy the convenience of using their personal computer from more convenient locations and in more convenient configurations, like sitting in your favorite easy chair or on your bed while watching Internet TV and controlling your viewing options without having to get up and manually operate the

computer from the keyboard console. Sure you can still get up and manually search on your primary keyboard, just like you can get up and physically change the channel on your TV, but instead you use a remote control to change channels on your TV and now changing channels on your TV when they come from the Internet can be accomplished in the same exact manner.

**Let's familiarize ourselves with Wireless Handheld Keyboard and Mouse**

**Touchpad:**



<b>NUMBERED FEATURE</b>	<b>FUNCTION</b>	<b>OPERATION</b>
LED 1	RECHARGER INDICATOR	LIGHT GOES OUT WHEN FULLY CHARGED
LED 2	CONNECTED TO EXTERNAL POWER SOURCE	LIGHTS WHEN CONNECTED
LED 3	RF STATUS	BLINKS WHEN TRANSMITTING
LED 4	BATTERY POWER	LIGHT ON WHEN WEAK, LIGHT OFF WHEN STRONG
LED 5	CAPS LOCK OR INPUT SWITCH KEY	WHEN PRESS “CAP”, THIS LED BLINKING CONTINUOUSLY. WHEN FIXED WITH LED ON THIS MEANS THAT YOU HAVE SELECTED SWITCH INPUT TO THE ALTERNATIVE KEY MEANINGS.
ARROW 6	CAPS LOCK KEY	CAPS LOCK ON/OFF SWITCH KEY, WATCH LED # 5
ARROW 7	MINI USB JACK	FOR CONNECTION TO USB CABLE. OTHER END OF CABLE GOES INTO USB PORT ON COMPUTER
ARROW 8	POWER SWITCH	URNS UNIT ON AND OFF
ARROW 9	BACK LIGHT FOR KEYBOARD	URNS BACK LIGHT ON BY DOUBLE PRESSING THIS KEY
ARROW 10	THE SF KEY IS FOR THE INPUT SWITCH KEY	MOST KEYS HAVE TWO INPUT OPTIONS. PRESS THIS KEY WHEN YOU WANT TO SWITCH TO THE SECOND KEY MEANING.
ARROW 11	MOUSE TOUCHPAD	SLIDING YOUR FINGER ACROSS PAD MOVES THE MOUSE
ARROW 12	LEFT MOUSE BUTTON	OPERATES LIKE LEFT MOUSE BUTTON
ARROW 13	RIGHT MOUSE BUTTON	OPERATE LIKE RIGHT MOUSE BUTTON
ARROW 14	USB TRANSCEIVER	COMMUNICATION DEVICE REQUIRED TO MANAGE UNIT

Note: The following keys operate identically to the standard keys on a personal computer keyboard: Ctrl; Esc; Del; Enter; BS(Backspace); ↑; ↓; ←; →; Alt;

## Starting Wireless Handheld Keyboard and Mouse Touchpad

Starting up this hardware and application is simple.

1. Plug the USB adaptor into any available USB port.
2. Power on the Wireless Handheld Keyboard and Mouse Touchpad by moving the slide switch as shown by arrow 8.




3. LED 3 will light up and then go out, this is normal. When you touch the Touch Pad or press any keys LED 3 will flash indicating proper operation of the unit and transmission between the USB adaptor and the Wireless Handheld Keyboard and Mouse Touchpad. The USB adaptor will also flash about every second.



If you find that LED 3 is blinking rapidly please check the following two items:

1. Check your distance between the Keyboard and the computer. Is it within 30'?
2. Check to see if you have plugged in the USB adaptor to your computer correctly.

4. The Wireless Handheld Keyboard and Mouse Touchpad has a battery saving feature. This feature puts the device into sleep mode if you do not use it after 3 minutes. LED 3 will blink continuously. You can wake up the unit by pressing any key for one second.

5. Arrow 10 points to the Input Switch Key 

When this key is pressed LED 5 will light up. This LED will stay on until this key is pressed again. That means while this light is on any key you press will use its secondary input rather than its primary input. For example the key B is normally B or b, but when you press the SF key it becomes the number 0. When you have selected the Input Switch Key LED 5 will light up. When you are in normal mode LED 5 will be turned off.

6. Switch between upper-case and lower-case input mode: If you are in lower-case input mode, press key . This way you can turn to upper-case input mode, LED 5 will blink at an interval about 1 second. In order to return to lower-case input mode pressing the key again after you completed your upper-case input, the LED 5 goes out. Every time, completed your upper-case input, please switch to lower-case input mode immediately, if waiting for the device enters sleep mode, LED 5 status will be incorrect.
7. When LED 4 lights up this indicates your battery voltage has a low charge and needs to be recharged. The Wireless Handheld Keyboard and Mouse Touchpad is equipped with a re-chargeable battery. We have supplied you with a USB cable, which is plugged into a vacant USB slot on your computer and the bottom of the Wireless Handheld Keyboard and Mouse Touchpad, as indicated by arrow 8 above. During charging LED 1 & 2 will light up with a steady on. When fully charged LED 1 will turn off. Please unplug the Wireless Handheld Keyboard and Mouse Touchpad from the USB cable. LED 2 will then turn off and your battery is now fully charged.
8. The Wireless Handheld Keyboard and Mouse Touchpad can work with a low battery charge (LED 4 only lit up) but if LED 3 and LED 4 are both lit up you should re-charge battery as described above. The backlight feature of the keyboard draws more power so take care when you battery indicators both light up. The unit becomes unstable when the battery lights are both on.
9. If you wish to operate this Wireless Handheld Keyboard and Mouse Touchpad in a darkened room then you will want to use the Backlight Keyboard feature. In order to activate the Backlight feature please double press .
10. The Touch Mouse Pad (TMP) is quite versatile. To create input with the TMP place your finger on the pad. Just move your finger on the TMP as though you were using your mouse pad. Watch the mouse move to where you want it, and then use the keyboard for whatever action you desire. You can draw patterns using the TMP if you have installed MS Paint, ScreenPen or other Paint software.

11. Rarely but possible if two or more Wireless Handheld Keyboard and Mouse Touchpad are within a close proximity the units may get confused. In that situation you need to run an ID Code Verification procedure. This is very simple process. Please unplug all the Wireless Handheld Keyboard and Mouse Touchpad USB Adaptors from their respective computers and then power off all of the Wireless Handheld Keyboard and Mouse Touchpad. Then take any pair which of Wireless Handheld Keyboard and Mouse Touchpad and USB Adaptor to begin ID Code Verification procedure. First turn on your Wireless Handheld Keyboard and Mouse Touchpad and then re-insert the USB Adaptor into a vacant USB port. Now simultaneously press the Left Mouse Button as indicated by arrow 12 above and the RF key indicated by arrow 9 above until LED 3 begins to flash slowly. Immediately release both keys. You should see LED 3 flash rapidly for about 5 seconds. If you have observed this then you have successfully completed ID Code Verification

After completed ID Code Verification, use mouserate.exe to confirm the Wireless Handheld Keyboard and Mouse Touchpad works fine. Move TMP on Mouserate window, you read the average is about 70 or above, as more as better. If it is below the value, please repeat to adjust.

After you have completed the ID Code Verification the Wireless Handheld Keyboard and Mouse Touchpad will immediately enter power save mode. In order to wake the unit please presses any key.

If you find that LED 3 are flashing slowly after your attempt at ID Code Verification then it means you have not successfully completed the pairing of the Wireless Handheld Keyboard and Mouse Touchpad with the USB Adaptor. You must then repeat this process until both units pair together. This process usually takes one time. We recommend that you are near your computer during this process.


The Wireless Handheld Keyboard and Mouse Touchpad will operate in parallel with your existing keyboard and mouse. Any of the keyboards or mice will operate equally and simultaneously without interference or any configuration. This is truly a plug and play product.

## WEEE Directive & Product Disposal



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal

Notice to customers:



This symbol on the battery indicates that the battery is to be collected separately.

The following apply only to users in European countries.

This battery is designed for separate collection at an appropriate collection point.

Do not dispose of as household waste

For more information, contact the retailer or local authorities in charge of waste management.



### Caution :

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Compliance statement:

1: This device is verified to comply with Part 15 of the FCC Rules. Operation subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

2: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed



And used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help