




A company of SIM Tech

T900_User Guide_V1.02



Document Title	T900 User Guide
Version	1.02
Date	2013-05-22
Status	Release
Document Control ID	T900_User Guide_V1.02

General Notes

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of SIMCom Limited, copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2013

Contents

Contents	3
Version History	6
1 Introduction	7
2 Key features	7
3 Terminal dimensions	9
4 Installation	10
5 Interface introduction	11
5.1 Overview	11
5.2 T900 Functional Diagram	12
5.3 Accessory information	13
6 Application Interface	13
6.1 Power Supply	13
6.2 Serial Interface	15
6.3 10 PIN I/O interface	16
6.3.1 Audio interface	17
6.3.2 ADC channel	20
6.3.3 GPIO interfaces	21
6.4 Antenna interface	21
6.4.1 Antenna connector	21
6.4.2 Antenna specifications	22
6.4.3 Antenna placement	22
6.5 LED indicator	23
6.6 SIM Card Interface	23
7 Electrical, Reliability and Radio Characteristics	25
7.1 Absolute Maximum Ratings	25
7.2 Recommended Operating Conditions	25
7.3 Electro-Static Discharge	25
7.4 Operating frequency	26
7.5 Transmitter output power and receiver sensitivity	26
8 Software/ Firmware Upgrade	26
8.1 Tool introduction	26
8.2 Illustration of software updating	26
Appendix	32
A. Related Documents	32
B. Terms and Abbreviations	32
C. Safety Caution	34

Table Index

TABLE 1: T900 KEY FEATURES.....	8
TABLE 2: THE CONSUMPTION IN SLEEP MODE.....	14
TABLE 3: THE POWER LINE ASSIGNMENT.....	14
TABLE 4: 9-POLE D-SUB (FEMALE) RS-232.....	15
TABLE 5: SIGNAL ASSIGNMENT OF 10 PIN CABLE	17
TABLE 6: AUDIO OUTPUT CHARACTERISTICS	18
TABLE 7: AT+CMIC CHANGE THE MICROPHONE GAIN LEVEL.....	18
TABLE 8: AT+CLVL CHANGE THE SPEAKER VOLUME LEVEL.....	19
TABLE 9: ADC SPECIFICATION	20
TABLE 10: AT+CADC READ ADC.....	20
TABLE 11: AT+SGPIO CONTROL THE GPIO	21
TABLE 12: ANTENNA SPECIFICATIONS.....	22
TABLE 13: STATUS OF THE NETLIGHT INDICATOR (GREEN).....	23
TABLE 14: AT+CSDT SWITCH ON OR OFF DETECTING SIM CARD.....	23
TABLE 15: ABSOLUTE MAXIMUM RATINGS.....	25
TABLE 16: RECOMMENDED OPERATING CONDITIONS	25
TABLE 17: THE ESD CHARACTERISTICS (TEMPERATURE: 25℃, HUMIDITY: 45 %).....	25
TABLE 18: OPERATING FREQUENCY.....	26
TABLE 19: TRANSMITTER OUTPUT POWER AND RECEIVER SENSITIVITY	26
TABLE 20: RELATED DOCUMENTS	32
TABLE 21: TERMS AND ABBREVIATIONS.....	32
TABLE 22: SAFETY CAUTION.....	34

Figure Index

FIGURE 1: T900 OVERVIEW	7
FIGURE 2: MECHANICAL DIMENSIONS OF T900 (UNIT: MM)	10
FIGURE 3: INSTALLATION OF THE TERMINAL	10
FIGURE 4: T900 INTERFACE FRONT VIEW	11
FIGURE 5: T900 INTERFACE BACK VIEW	11
FIGURE 6: T900 FUNCTIONAL DIAGRAM	12
FIGURE 7: ACCESSORY INFORMATION.....	13
FIGURE 8: DIMENSIONS OF POWER LINE (UNIT: MM)	14
FIGURE 9: POWER INTERFACE	14
FIGURE 10: PIN ASSIGNMENT RS-232 (D-SUB 9-POLE FEMALE)	15
FIGURE 11: COM PORT PROPERTIES OF THE HYPER TERMINAL.....	16
FIGURE 12: SIGNAL ASSIGNMENT OF 10PIN I/O PORT	16
FIGURE 13: DIMENSIONS OF 10-LINE CABLE.....	17
FIGURE 14: AUDIO REFERENCE CIRCUIT.....	18
FIGURE 15: ANTENNA INTERFACE	22
FIGURE 16: INDICATOR LED.....	23
FIGURE 17: INSTALLATION OF SIM CARD	24
FIGURE 18: MAIN UI.....	27
FIGURE 19: PARAMETER SETTING	27
FIGURE 20: BROWSE THE SOURCE FILE	28
FIGURE 21: CONNECT TO PC BY RS232 INTERFACE WITHOUT POWER UP	29
FIGURE 22: CLICK DOWNLOAD BUTTON WITHOUT POWER UP	29
FIGURE 23: POWER UP THE TERMINAL.....	30
FIGURE 24: UPGRADE IN PROCEEDING.....	30
FIGURE 25: FINISH UPGRADING	31

Version History

Date	Version	Description of change	Author
2012-05-3	1.00	Origin	Honggang Ma Demin Wu
2012-08-15	1.01	§ 6.3 Correct the PIN assignment	Honggang Ma
2013-05-22	1.02	§ 6.3 Correct the signal assignment	Honggang Ma

SIMCOM CONFIDENTIAL FILE

1 Introduction

This document describes features, functions and interfaces of T900 terminal in great detail.

T900 is a quad-band GSM/GPRS DTU that works on frequencies of GSM 850MHz, EGSM 900MHz, DCS 1800MHz and PCS 1900MHz, which is a ideal solution for wireless m2m applications, the terminal features GPRS multi-slot class 10/ class 8 (optional) and supports the GPRS coding schemes CS-1, CS-2, CS-3 and CS-4. With the help of this document user can understand T900 interface specifications, electrical and mechanical quickly.



Figure 1: T900 overview



Note: The T900 Terminal is fully complying with RoHS requirements of European standards.

2 Key features

T900 terminal has the following features:

1. Standard AT commands set
2. SIMCom proprietary AT commands set
3. Watch-dog function
4. Short circuit protection
5. Voice call
6. GPIOs
7. ADC function


Table 1: T900 key features

Feature	Implementation
Power supply	5V ~ 30V
Power saving	Typical power consumption in sleep mode is 70mW (BS-PA-MFRMS=9)
Frequency bands	● T900 Quad-band: GSM 850, EGSM 900, DCS 1800, PCS 1900. T900 can search the 4 frequency bands automatically. The frequency bands also can be set by AT command “AT+CBAND”. For details, please refer to <i>document [1]</i>. ● Compliant to GSM Phase 2/2+
Transmitting power	● Class 4 (2W) at GSM 850 and EGSM 900 ● Class 1 (1W) at DCS 1800 and PCS 1900
GPRS connectivity	● GPRS multi-slot class 10 (default) ● GPRS multi-slot class 8 (option)
Temperature range	● Normal operation: -30°C ~ +80°C ● Restricted operation: -40°C ~ -30°C and +80 °C ~ +85°C* ● Storage temperature -45°C ~ +90°C
Data GPRS	● GPRS data downlink transfer: max. 85.6 kbps ● GPRS data uplink transfer: max. 42.8 kbps ● Coding scheme: CS-1, CS-2, CS-3 and CS-4 ● Integrate the TCP/IP protocol. ● Support Packet Broadcast Control Channel (PBCCH)
CSD	● Support CSD transmission
USSD	● Unstructured Supplementary Services Data (USSD) support
SMS	● MT, MO, CB, Text and PDU mode ● SMS storage: SIM card
FAX	Group 3 Class 1
SIM interface	Support SIM card: 1.8V, 3V
External antenna	SMA type RF connector
Audio features	Speech codec modes: ● Half Rate (ETS 06.20) ● Full Rate (ETS 06.10) ● Enhanced Full Rate (ETS 06.50 / 06.60 / 06.80) ● Adaptive multi rate (AMR) ● Echo Cancellation ● Noise Suppression
RS232 serial port	Serial port: ● Full modem interface with status and control lines, unbalanced, asynchronous. ● 1200bps to 115200bps. ● Can be used for AT commands data stream. ● Support RTS/CTS hardware handshake and software ON/OFF flow control. ● Multiplex ability according to GSM 07.10 Multiplexer Protocol. ● Autobauding supports baud rate from 1200 bps to 57600bps.
Phonebook management	Support phonebook types: SM, FD, LD, RC, ON, MC.
SIM application toolkit	GSM 11.14 Release 99

Physical characteristics	Size: 98*60*23mm Weight: 125g
Firmware upgrade	Firmware upgradeable by RS232 interface

*T900 does work at this temperature, but some radio frequency characteristics may deviate from the GSM specification.

3 Terminal dimensions






Figure 2: Mechanical dimensions of T900 (Unit: mm)

4 Installation

The terminal can be fixed by two kickstands (Optional) that provided by SIMCom, the following figure is the illustration.




Figure 3: Installation of the terminal

5 Interface introduction

5.1 Overview

T900 Terminal provides the following connectors for power supply, GPIOs, Audio, ADC, Serial port and antenna:

- The GSM antenna interface(SMA type female connector)
- The 4 PIN I/O port for power supply
- The 10 PIN I/O port for audio, GPIOs and ADC
- The standard RS232 interface
- LED indicator for power (Red) and GSM Netlight (Green)
- SIM card holder




Figure 4: T900 interface Front view




Figure 5: T900 interface Back view

Note: For the I/O interface, SIMCom could provide 4-line cable and 10-line cable (optional) to assist developers; it will be introduced at the following chapter.

5.2 T900 Functional Diagram

The following figure shows a functional diagram of T900 and typical accessories.




Figure 6: T900 functional diagram

5.3 Accessory information



Figure 7: Accessory information

- A: T900 Terminal
- B: GSM Antenna
- C: Male to Female DB9 Line
- D: 5V Adapter
- E: Two kickstands (Optional)
- F: 10-Line cable (Optional)
- G: 4-Line power line (Optional)

6 Application Interface

6.1 Power Supply

Customer can use the DC adapter that SIMCom provides as the power source.

If customer does not use the adapter, then DC source should be satisfied with the following requirements.

- Input voltage range 5-30V
- Normal voltage 12V
- Current ability 1A

Table 2: The consumption in sleep mode

T900	@5V	@12V	@15V
Sleep current	14.5mA	7.75mA	5.02mA

The following chapter introduces the power line that SIMCom provides to customers, customer can power the terminal by connect the terminal to the DC source via this line.

The power line includes four lines as the following figure shows, and table 3 gives a detailed description.

Table 3: The power line assignment

PIN Number	Colour	Item
1	white	NC
2	Red	Power
3	Yellow	NC
4	Black	Ground



Figure 8: dimensions of power line (Unit: mm)

Figure 9: Power interface

When a valid power appears the terminal will power up automatic, for the MCU that inside the terminal processed the power up part, MCU also acts as a Watch Dog, when the terminal runs wrong, MCU will cut off the power and recover it immediately to restart the terminal.

6.2 Serial Interface

T900 provides one asynchronous RS232 serial port (female). The RS232 standard interface serves to connect a PC, Data Terminal Equipment (DTE) or other application, which acts as host controller of the T900 Terminal with all its functions. Through the RS232 interface it can be used as GSM/GPRS modem for sending and receiving of SMS, Data and Fax calls.



Figure 10: Pin assignment RS-232 (D-Sub 9-pole female)

Table 4: 9-pole D-Sub (female) RS-232

Pin no	Signal name	I/O	Function
1	DCD	O	Data Carrier Detected
2	RXD	O	Receive Data
3	TXD	I	Transmit Data
4	DTR	I	Data Terminal Ready Attention: The ignition of T900 Terminal is activated via a rising edge of high potential (+3 ... +15 V)
5	GND	-	Ground
6	DSR	O	Data Set Ready
7	RTS	I	Request To Send
8	CTS	O	Clear To Send
9	RING	O	Ring Indication

Note: T900 supports autobauding, Autobauding allows T900 to automatically detect the baud rate of the host device. User can use AT command "AT+IPR=x" to set a fixed baud rate and the setting will be saved to non-volatile flash memory automatically. After the configuration is set as fixed baud rate, the URC such as "RDY", "+CFUN: 1" and "+CPIN: READY" will be reported when T900 is powered on.

Hyper terminal usually as the PC software tool to operate T900; customer can set up a connection between PC and terminal, configure the port properties as the figure 9 shows.




Figure 11: COM port properties of the hyper terminal

6.3 10 PIN I/O interface

T900 provides a 10 PIN I/O interface for customer use, including Audio, GPIOs and 1 ADC channel. The following figure gives a brief view of signal assignment.




Figure 12: signal assignment of 10PIN I/O port

To make the usage conveniently, SIMCom provides a cable for customer, it can be inserted to the 10 PIN I/O port so customer can develop their application by connecting some devices.

Figure 13 shows the specification of the cable.




Figure 13: Dimensions of 10-line cable

Table 5: signal assignment of 10 pin cable

Connecting diagram					
P1	Wire color and cutting length		Terminal signal		
			Signal name	I/O	Comments
1	Green	1007 26#	GPIO3	I/O	Configurable by AT commands
2	Yellow		GPIO1	I/O	
3	Black		GND		Ground
4	Orange		SPK+	O	
5	Brown		MIC+	I	
6	White		GPIO4	I/O	Configurable by AT commands
7	Gray		GPIO2	I/O	
8	Red		ADC	I	
9	Purple		SPK-	O	
10	Blue		MIC-	I	

6.3.1 Audio interface

T900 has one pair of audio input and audio output; it can be connected to a handset directly.




Figure 14: Audio reference circuit

Table 6: Audio Output Characteristics

Parameter	Conditions	Min	Typ	Max	Unit
Normal Output(SPK)	RL=32Ω THD=0.1%	-	91	-	mW
	RL=32Ω THD=1%	-	96	-	mW
	Output swing Voltage (single ended)			1.1	Vpp
	Output swing Voltage (differential)			2.2	Vpp

Customer can set the terminal MIC gain level to make the sounds louder so that the listener can hear more clearly. And if the sound a little lower on the terminal side, customer can use the “AT +CLVL” to make the sound higher so that customer can hear clearly.

The AT commands should be send to the terminal by RS232 interface, and the following table shows the detail commands.

Table 7: AT+CMIC Change the Microphone Gain Level

AT+CMIC Change the Microphone Gain Level	
Test Command AT+CMIC=?	Response +CMIC: (list of supported <channel>s),(list of supported <gainlevel>s) OK Parameters See Write Command
Read Command AT+CMIC?	Response +CMIC: (<channel0>,<gainlevel0>),...,<channeln>,<gainleveln>) OK

	Parameters See Write Command
Write Command AT+CMIC= <channel>,<gain level>	Response OK ERROR
	Parameters <channel> 0 Main audio handset channel <gain level> Int: 0 – 15 0 0dB 1 +1.5dB 2 +3.0 dB 3 +4.5 dB 4 +6.0 dB 5 +7.5 dB 6 +9.0 dB 7 +10.5 dB 8 +12.0 dB 9 +13.5 dB 10 +15.0 dB 11 +16.5 dB 12 +18.0 dB 13 +19.5 dB 14 +21.0 dB 15 +22.5 dB
Example:	AT+CMIC=0,10 This command used to set the terminal MIC gain level to +15db.

Table 8: AT+CLVL Change the Speaker Volume Level

AT+CLVL Loud Speaker Volume Level	
Test Command AT+CLVL=?	Response +CLVL: (list of supported <level>s) OK If error is related to ME functionality: +CME ERROR: <err>
	Parameter See Write Command
Read Command AT+CLVL?	Response +CLVL: <level> OK If error is related to ME functionality:

	+CME ERROR: <err>
	Parameter See Write Command
Write Command AT+CLVL=<level> I>	Response OK If error is related to ME functionality: +CME ERROR: <err>
	Parameter <level> 0-100 Integer type value with manufacturer specific range (smallest value represents the lowest sound level)
Reference GSM 07.07 [13]	Note

Please refer to *document [1]* and *document [5]* for details.

6.3.2 ADC channel

T900 provides an auxiliary ADC, which can be used to measure the voltage. User can use AT command “AT+CADC” to read the voltage value.

Table 9: ADC specification

Parameter	Min	Typ	Max	Unit
Voltage range	0	-	2.8	V
ADC Resolution	-	10	-	bits
Sampling rate	-	-	200K	Hz

Note: the maximum voltage that the ADC can gather is 2.8V

Table 10: AT+CADC Read ADC

AT+CADC Read ADC	
Test Command AT+CADC=?	Response: +CADC: (list of supported <status>s),(list of supported <value>s) OK
	Parameters <status> 1 Success 0 Fail <value> Integer 0-2800
Read Command AT+CADC?	Response: +CADC: <status>,<value> OK
	Parameters See Test Command

6.3.3 GPIO interfaces

T900 provides 4 GPIO pins. The output voltage level of the GPIO can be set by the AT command “AT+ SGPIO”. The input voltage level of the GPIO can also be read by the AT command “AT+ SGPIO”. The following table shows the detail commands about GPIO.

Table 11: AT+SGPIO Control the GPIO

AT+ SGPIO Control the GPIO	
Test Command AT+SGPIO=?	Response +SGPIO: (0-1),(1-12),(0-2),(0-1) OK
	Parameters See Write Command
Write Command AT+SGPIO= <operation>,<GPIO> ,<function> ,<level>	Response OK ERROR
	Parameters <Operation> 0 Set the GPIO function including the GPIO output and GPIO as the Keypad. 1 Read the GPIO level. Please note that only when the gpio is set as input, user can use parameter 1 to read the GPIO level, otherwise the module will return "ERROR". <GPIO> The GPIO you want to be set. (It has relations with the hardware, please refer to the hardware manual) <function> Only when <Operation> is set to 0, this option takes effect. 0 Set the GPIO to input. 1 Set the GPIO to output 2 Set the GPIO to keypad <level> 0 Set the GPIO low level 1 Set the GPIO high level

6.4 Antenna interface

6.4.1 Antenna connector

Antenna connector allows transmission of radio frequency (RF) signals between the modem and the external supplied antenna. The T900 modem is fitted with a 50Ω male SMA connector.



Figure 15: Antenna interface

6.4.2 Antenna specifications

The antenna is a very important component in the system. Since the antenna transmits and receives electromagnetic signal, and its efficiency depends on the antenna's type, placement and the environment of the antenna operating.

The recommended antenna specifications are showed in Table 12:

Table 12: antenna specifications

Frequency range	GSM 850/900/1800/1900MHz
Impedance	50 ohm
Input power	> 33dBm (2W) peak power in GSM
VSWR recommended	$\leq 2:1$
VSWR absolute max	$\leq 10:1$
Gain	$\leq 3\text{dBi}$

6.4.3 Antenna placement

The antenna performance is very easily influenced by other electronic devices. So the antenna placement should be considered carefully as follow.

1. Place away from other electronic devices or other antennas.
2. Place far away from metal material.
3. Face the base station antenna directly if the signal strength is very weak.

6.5 LED indicator

A red led indicates the power status, when a valid power appears, the red led will lighten up. But a lighten up red led does not mean that the terminal has been powered up.

A green led indicates the terminal status and GSM net status, after the terminal been powered up and registered to the network, it will blink at a certain frequency.




Figure 16: Indicator LED

Table 13: Status of the NETLIGHT indicator (Green)

Status	T900 behavior
Off	T900 is not running
64ms On/ 800ms Off	T900 not registered the network
64ms On/ 3000ms Off	T900 registered to the network
64ms On/ 300ms Off	GPRS communication is established

6.6 SIM Card Interface

The SIM interface complies with the GSM Phase 1 specification and the new GSM Phase 2+ specification for FAST 64 kbps SIM card. Both 1.8V and 3.0V SIM card are supported. The SIM interface is powered from an internal regulator inside the terminal.

T900 supports SIM card “hot” plug, which means that the terminal can sense the SIM card inserted in or drawn out when the module is on

AT command “AT+CSDT” is used to enable or disable SIM card detection function. For details of this AT command, please refer to the following table.

Table 14: AT+CSDT Switch On or Off Detecting SIM Card

AT+CSDT Switch On or Off Detecting SIM Card

Test Command AT+CSDT=?	Response +CSDT: (0-1) OK
	Parameter See Write Command
Read Command AT+CSDT?	Response +CSDT: <mode> OK
	Parameter See Write Command
Write Command AT+CSDT=<mode>	Response OK ERROR
	Parameter <mode> 0 Switch off detecting SIM card 1 Switch on detecting SIM card

Note: when the detecting function is activated, the status of sim card will auto report via the serial port. The sensing of a hot removal of the SIM is not supported during power saving mode (AT+CFUN=4).



Figure 17: Installation of SIM Card

7 Electrical, Reliability and Radio Characteristics

7.1 Absolute Maximum Ratings

The absolute maximum ratings stated in following table are stress ratings under non-operating conditions. Stresses beyond any of these limits will cause permanent damage to T900.

Table 15: Absolute maximum ratings

Symbol	Parameter	Min	Typ	Max	Unit
V _{BAT}	Power supply voltage	4.5	-	42	V
V _I *	Input voltage	-0.3	-	3.1	V
I _I *	Input current	-	-	10	mA
I _O *	Output current	-	-	10	mA

* These parameters are for digital interface pins, such as GPIO, UART and DEBUG.

7.2 Recommended Operating Conditions

Table 16: Recommended operating conditions

Symbol	Parameter	Min	Typ	Max	Unit
V _{BAT}	Power supply voltage	5	12	30	V
T _{OPER}	Operating temperature	-40	+25	+85	°C
T _{STG}	Storage temperature	-45		+90	°C

7.3 Electro-Static Discharge

T900 is an ESD sensitive component, so more attention should be paid to the procedure of handling and packaging. The ESD test results are shown in the following table.

Table 17: The ESD characteristics (Temperature: 25°C, Humidity: 45 %)

Test item	Contact discharge	Air discharge
Shell	±10KV	±15KV
RF interface	±10KV	±15KV
RS232 interface	±10KV	±15KV
Audio interface	±10KV	±15KV
SIM card holder	±10KV	±15KV

7.4 Operating frequency

The operating frequencies in GSM850, EGSM900, DCS, PCS modes are conform to the GSM Specifications, shown as bellow.

Table 18: Operating frequency

Mode	Freq. TX(MHz)	Freq. RX(MHz)	Channels(A RFC)	TX-RX offset
GSM-850	824 – 849	869 – 894	128 - 251	45 MHz
E-GSM-900	890-915	935-960	0–124	45MHz
	880-890	925 - 935	975-1023	45MHz
DCS-1800	1710-1785	1805-1880	512–885	95 MHz
PCS-1900	1850 - 1910	1930 - 1990	512 - 810	80 MHz

7.5 Transmitter output power and receiver sensitivity

The T900's conducted transmitter output power and receiver sensitivity are shown as bellow:

Table 19: Transmitter output power and receiver sensitivity

Mode	Power(dBm)	Sensitivity(dBm)
GSM-850	+33	-108
E-GSM-900	+33	-108
DCS-1800	+30	-107
PCS-1900	+30	-107

8 Software/ Firmware Upgrade

The software can be upgraded via the RS232 interface with the help of tools provided by SIMCom,

8.1 Tool introduction

The tool name is “SIM900 Series download Tools Customer 1.6”, which runs on the windows OS, customers can upgrade software conveniently by it.

This tool is a single-road download tool, one terminal can be upgraded by it every time. SIMCom also provides multi-road download tools for customer's factory use. Contact SIMCom sales for support.

8.2 Illustration of software updating

- Open the tools, the main operation interface as the figure 16 shows:




Figure 18: Main UI

- Configure the download parameter




Figure 19: parameter setting

- Browse the source file




Figure 20: Browse the source file

- Terminal setup
Before click the “Start Download”, make sure that the terminal is off, and connect the terminal to PC by RS232 interface.



Figure 21: Connect to PC by RS232 interface without power up

- Software download

Click the button,

Start Download

then the window will change like the following figure shows.




Figure 22: click download button without power up

When the status window shows “Power On/Reset Target”, powering up the terminal by connecting the DC source.



Figure 23: power up the terminal

- Upgrade in proceeding




Figure 24: Upgrade in proceeding

- Finish upgrading

Now the software is the new version, click “Exit” to finish upgrading, customer can check the software version by “AT+GSV”.




Figure 25: Finish upgrading

Appendix

A. Related Documents

Table 20: Related documents

SN	Document name	Remark
[1]	SIM900_AT Command Manual	SIM900 AT Command Manual
[2]	AN_SIM900_TCPIP	TCP/IP Applications User Manual
[3]	SIM900_Multiplexer User Manual_Application Note	SIM900 Multiplexer User Manual Application Note
[5]	AN_SIM900_AUDIO	Applications Note About T900 Audio
[6]	AN_SIM900_Audio LINE-IN input	Applications Note About T900 LINE-IN Input
[7]	SIM900_Embedded AT Application Note	SIM900 Embedded AT Application Note
[8]	AN_Serial Port	Application Note About Serial Port
[9]	T900 GPRS Setup User Guide	T900 GPRS Setup User Guide
[11]	ITU-T Draft new recommendation V.25ter:	Serial asynchronous automatic dialing and control
[12]	GSM 07.07:	Digital cellular telecommunications (Phase 2+); AT command set for GSM Mobile Equipment (ME)
[13]	GSM 07.10:	Support GSM 07.10 multiplexing protocol
[14]	GSM 07.05:	Digital cellular telecommunications (Phase 2+); Use of Data Terminal Equipment – Data Circuit terminating Equipment (DTE – DCE) interface for Short Message Service (SMS) and Cell Broadcast Service (CBS)
[15]	GSM 11.14:	Digital cellular telecommunications system (Phase 2+); Specification of the SIM Application Toolkit for the Subscriber Identity Module – Mobile Equipment (SIM – ME) interface
[16]	GSM 11.11:	Digital cellular telecommunications system (Phase 2+); Specification of the Subscriber Identity Module – Mobile Equipment (SIM – ME) interface
[17]	GSM 03.38:	Digital cellular telecommunications system (Phase 2+); Alphabets and language-specific information
[18]	GSM 11.10	Digital cellular telecommunications system (Phase 2); Mobile Station (MS) conformance specification; Part 1: Conformance specification

B. Terms and Abbreviations

Table 21: Terms and Abbreviations

Abbreviation	Description
--------------	-------------

ADC	Analog-to-Digital Converter
AMR	Adaptive Multi-Rate
AT	Attention commands
CS	Coding Scheme
CSD	Circuit Switched Data
CTS	Clear to Send
DTE	Data Terminal Equipment (typically computer, terminal, printer)
DTR	Data Terminal Ready
DTU	Data Transmit Unit
DTX	Discontinuous Transmission
EFR	Enhanced Full Rate
EGSM	Enhanced GSM
ESD	Electrostatic Discharge
ETS	European Telecommunication Standard
FR	Full Rate
GPRS	General Packet Radio Service
GSM	Global Standard for Mobile Communications
HR	Half Rate
IMEI	International Mobile Equipment Identity
Li-ion	Lithium-Ion
MO	Mobile Originated
MS	Mobile Station (GSM engine), also referred to as TE
MT	Mobile Terminated
NC	NO Connect
NA	Not Access
PAP	Password Authentication Protocol
PBCCH	Packet Broadcast Control Channel
PCB	Printed Circuit Board
PCL	Power Control Level
PCS	Personal Communication System, also referred to as GSM 1900
PDU	Protocol Data Unit
PPP	Point-to-point protocol
RF	Radio Frequency
RMS	Root Mean Square (value)
RTC	Real Time Clock
RX	Receive Direction
SIM	Subscriber Identification Module
SMS	Short Message Service
TE	Terminal Equipment, also referred to as DTE
TX	Transmit Direction
UART	Universal Asynchronous Receiver & Transmitter
URC	Unsolicited Result Code

USSD	Unstructured Supplementary Service Data
Phonebook abbreviations	
FD	SIM fix dialing phonebook
LD	SIM last dialing phonebook (list of numbers most recently dialed)
MC	Mobile Equipment list of unanswered MT calls (missed calls)
ON	SIM (or ME) own numbers (MSISDNs) list
RC	Mobile Equipment list of received calls
SM	SIM phonebook
NC	Not connect

C. Safety Caution

Table 22: Safety caution

Marks	Requirements
	When in a hospital or other health care facility, observe the restrictions about the use of mobiles. Switch the cellular terminal or mobile off, medical equipment may be sensitive to not operate normally for RF energy interference.
	Switch off the cellular terminal or mobile before boarding an aircraft. Make sure it is switched off. The operation of wireless appliances in an aircraft is forbidden to prevent interference with communication systems. Forget to think much of these instructions may lead to the flight safety or offend against local legal action, or both.
	Do not operate the cellular terminal or mobile in the presence of flammable gases or fumes. Switch off the cellular terminal when you are near petrol stations, fuel depots, chemical plants or where blasting operations are in progress. Operation of any electrical equipment in potentially explosive atmospheres can constitute a safety hazard.
	Your cellular terminal or mobile receives and transmits radio frequency energy while switched on. RF interference can occur if it is used close to TV sets, radios, computers or other electric equipment.
	Road safety comes first! Do not use a hand-held cellular terminal or mobile when driving a vehicle, unless it is securely mounted in a holder for hands free operation. Before making a call with a hand-held terminal or mobile, park the vehicle.
	GSM cellular terminals or mobiles operate over radio frequency signals and cellular networks and cannot be guaranteed to connect in all conditions, for example no mobile fee or a invalid SIM card. While you are in this condition and need emergent help, please remember using emergency calls. In order to make or receive calls, the cellular terminal or mobile must be switched on and in a service area with adequate cellular signal strength. Some networks do not allow for emergency call if certain network services or phone features are in use (e.g. lock functions, fixed dialing etc.). You may have to deactivate those features before you can make an emergency call. Also, some networks require that a valid SIM card be properly inserted in the cellular terminal or mobile.

Contact us:**Shanghai SIMCom Wireless Solutions Ltd.**

Add: SIM Technology Building, No.633, Jinzhong Road, Changning District, Shanghai P.R. China 200335

Tel: +86 21 3235 3300

Fax: +86 21 3235 3301

URL: www.sim.com/wm

SIMCOM CONFIDENTIAL FILE